



Yamaha 115BETO 2000

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM	3
BRACKET	6
BRACKET 1	8
BRACKET 2	10
CARBURETOR	13
CONTROL	15
CRANKSHAFT.	18
CYLINDER.	20
CYLINDER. CRANKCASE 2	22
ELECTRICAL 1	24
ELECTRICAL 2	26
FUEL1	28
FUEL2	31
GENERATOR	32
INTAKE	34
LOWER	37
METER	44
OIL PUMP	46
OIL TANK	48
OILTANK	50
POWER	51
POWER TRIM & TILT ASSY 1	54
REMOTE	56
REMOTE CONTROL ASSY	58
REMOTE CONTROL BOX	60
REPAIR	61
REPAIRKIT	63
REPAIRKIT 1	65
REPAIRKIT 2	66
STARTING MOTOR	67
STEERING	69
TOP COWLING	70
UPPER	72

Bottom




FWD
6E50300-0150

D

Ref	Part	
1	6E5W4271054D Cowling, bottom	Buy now
2	6H44274800 Grommet	Buy now
3	68842815014D Lever, clamp	Buy now
4	6884281600 Lever, clamp 2	Buy now
5	9038613M38 Bushing (697)	Buy now
7	9011906M09 Bolt, with washer	Buy now
8	6E542817014D Lever, clamp	Buy now
9	6G54281600 Lever, clamp 2	Buy now
10	6E54281601 Lever, clamp 2	Buy now
12	9020613M10 Washer, wave (6e5)	Buy now
14	6E54439100 Nipple, hose	Buy now
15	6E54272511 Grommet	Buy now
16	6ES427380158 "Plate, Fitting	Buy now
17	9709506016 Bolt, hexagon deep recess	Buy now
18	9299506600 Washer, plain (646)	Buy now

Bottom




FWD
6E50300-0150

D

Ref	Part	
19	9048022M15 Grommet (6e5)	Buy now
20	9038708M37 Coller (6e5)	Buy now
22	9707508035 Bolt(70w)	Buy now
23	9011908M22 Bolt, with washer	Buy now
24	6884272610 Grommet	Buy now
24	6E503000150 -	Buy now
40	APRON ~~ Ttt Ttt Otto RI	Buy now
28	9709506020 Bolt(7u8)	Buy now
30	6ES52436701 Clamp, Fuel Pipe 2	Buy now
31	9015706MO1 Screw, Pan Head	Buy now
32	9299006600 Washer, plain (646)	Buy now
33	6E52436710 Clamp, fuel pipe 2	Buy now
36	BES4271600 Rubber, Seal 1	Buy now
37	6E58258800 Plate	Buy now
40	6888259400 Clamp	Buy now

Bottom




FWD
6E50300-0150

D

Ref	Part	
41	BES58259400 Clamp	Buy now
42	BK78258800 Plate	Buy now

Bracket




FWD
6N60010-7160

D


Ref	Part	
2	6G54525101 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506030 Bolt(jf7)	Buy now
5	9299506100 Washer(6a1) SPRING 4	Buy now
7	9709506010 Bolt	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	64E43112018D Bracket, clamp	Buy now
10	6ES8214800 Wire, Lead 4	Buy now
11	9788006012 Screw, pan head(62j)	Buy now
12	9299006600 Washer, plain (646)	Buy now
13	9370006M03 Nipple, grease(6a1)	Buy now
14	6634511900 Cap, grease nipple AP	Buy now
15	B4E4313101 Bolt, Clamp Bracket	Buy now
17	9299508100 Ybs67-8 washer, spring	Buy now
18	9038625M31 Bushing (6e5)	Buy now

Bracket




Ref	Part	
19	9020126M59 Washer, plate (6e5)	Buy now
20	9018522M11 Nut, self-locking	Buy now
22	64E43311108D Bracket, swivel L	Buy now
23	6N600107160 25 663-45119-00	Buy now
23	9046508M63 Clamp(61u)	Buy now
27	6G54314400 Hook, spring	Buy now

Bracket 1




Ref	Part	
28	9709506010 Bolt	Buy now
29	6G54318102 Lever, tilt stop 1	Buy now
30	6G54318502 Lever, tilt stop 2	Buy now
31	9038610M16 Bushing (688)	Buy now
32	6G54314800 Collar, distance	Buy now
33	9024906M19 Pin(6e5)	Buy now
34	9038710M05 Collar	Buy now
35	9169030020 Pin, spring (6h4)	Buy now
36	9050614M24 Spring, tension(6e5)	Buy now
37	64E4312600 Pin, upper shock mount	Buy now
38	9038622M98 Bush(61u)	Buy now
39	9341022M11 Circlip(61u)	Buy now
40	9010112M03 Bolt (l:115mm)	Buy now
41	9020113M01 Washer, plate(6e5)	Buy now
42	9020112M05 Washer, Plate	Buy now

Bracket 1




Ref	Part	
43	9538012600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	64E4313900 Cam, trim sender (with screw)	Buy now
2	9778060525 Screw, tapping(65j)	Buy now
3	64E8367200 Trim sender	Buy now
4	9788506016 Screw, pan head(6b0)	Buy now
5	9046511M10 Clamp	Buy now
7	9020240M47 Washer, plate(61a)	Buy now
8	61A4337600 Bolt, thrust receiver	Buy now
9	9578010300 Nut, nylon (6e5)	Buy now
10	6E542510058D Steering bracket assembly L	Buy now
11	90201-38M60 Washer, plate (6e5)	Buy now
12	9038638M32 Bush(6e5)	Buy now
14	9341037M04 Circlip (6e5)	Buy now
15	6E54457500 Damper, lower mount rubber	Buy now
17	9020232M19 Washer, plate (6e5)	Buy now
18	9020116Ms5 Washer, Plate	Buy now

Bracket 2



Ref	Part	
19	6E58214900 Wire, lead 3	Buy now
20	9010914M34 Bolt(6e5)	Buy now
22	9538014800 Nut, crown (6e5)	Buy now
23	64D00107170 Boitier, Silent-Bloc Inferieur	Buy now
23	9299514600 Washer (6e5)	Buy now
25	9709510045 Bolt(64d) a	Buy now
27	6E544553018D Cover, lower mount	Buy now
28	9050116M28 Spring (6e5)	Buy now
30	9017906066 Nut(663)	Buy now
31	6E5445140094 Mount damper, upper side	Buy now
32	9020126M57 Washer, plate (6e5)	Buy now
33	9020226M18 Washer, plate (6e5)	Buy now
34	9020114M56 Washer, plate (6e5)	Buy now
35	9010912M37 Bolt	Buy now
36	9018512M12 Nut, self-locking(6e5)	Buy now


Bracket 2



E

Ref	Part	
37	6634457500 Damper, lower mount rubber	Buy now
38	6ES , EI	Buy now
40	9299510100 Ybs67-10 washer, spring	Buy now


Carburetor



B

Ref	Part	
1	6E51430115 Carburetor assembly 1	Buy now
2	61A1438301 Screw, drain	Buy now
2	61A1492H12 Jet, slow air (#60)	Buy now
2	61U1495900 Gasket	Buy now
2	6401438400 Valve, Drain	Buy now
2	64D1438100 Body, float chamber	Buy now
2	64D1438400 Gasket, float chamber	Buy now
2	64D1492E88 Jet, main (#176)	Buy now
2	64D1492F39 Jet, air slow (#78)	Buy now
2	6E51430215 Carburetor assembly 2	Buy now
2	6E51432303 Screw, air adjusting	Buy now
2	6E51432400 Screw, flat head	Buy now
2	6E51432801 Plug	Buy now
2	6E51438502 Float	Buy now
2	6E51438602 Pin, float	Buy now


Carburetor



B

Ref	Part	
2	6E51439800 Gasket	Buy now
2	6E51452701 Plate	Buy now
2	6E51454600 Valve, needle	Buy now
2	6E51432100 Screw, Throttle	Buy now
2	6E51432300 Spring, Air Adjusting	Buy now
2	6E551415900 Clip	Buy now
2	6J81433400 Spring, throttle #2	Buy now
2	9798005108 Screw, with washer	Buy now
2	9798005116 Screw, pan head	Buy now
2	B6E51497900 {Gasket	Buy now


Control



D

Ref	Part	
1	6E54853100 Bracket, remote control	Buy now
2	6E54853800 Clamp, cable	Buy now
3	9169030012 Pin, spring	Buy now
4	9709508020 Bolt, hexagon	Buy now
5	9299508100 Ybs67-8 washer, spring	Buy now
6	6E541632021S Lever, magneto control	Buy now
7	6E54834400 Cable end, remote control	Buy now
8	9299006200 Ybs66-6 washer, plain	Buy now
9	9018506M07 Nut, self-locking(6e5)	Buy now
11	9015706013 Screw, pan head(697)	Buy now
12	9050116M12 Spring, compression (688)	Buy now
13	9530306600 Nut(661)	Buy now
14	6884419400 Cap	Buy now
15	9701308045 Bolt	Buy now
16	9020108M23 Washer, plate (6e5)	Buy now


Control



D

Ref	Part	
17	9038612089 Bushing(663)	Buy now
18	9038708M16 Collar	Buy now
19	9038622M13 Bushing (688)	Buy now
20	6E54163601 Rod, magneto control	Buy now
20	6NB00100151 ~4 JOINT, LINK	Buy now
20	9020212092 Washer, plate(663)	Buy now
20	9050820M12 Spring, Torsion	Buy now
20	9538005600 Nut, hexagon (663)	Buy now
29	6884163600 Rod 1	Buy now
31	6624123701 Joint, link	Buy now
32	6E54121300 Cam, accel.	Buy now
34	9020610M04 Washer, wave (676)	Buy now
35	9709506025 Bolt	Buy now
36	6E544117001S Bracket	Buy now
37	9011906MA2 Bolt, with washer	Buy now

Control




6N60010-0151

D

Ref	Part	
38	68F4412100 Lever, shift rod	Buy now
39	6E54412200 Bushing, Shift Rod Lever	Buy now
40	9020208M20 Washer, plate (6e5)	Buy now
41	9046818008 Clip 620436610000	Buy now
44	6E5441180194 Bracket 2	Buy now
45	9701308030 Bolt	Buy now
46	9290308600 Washer, plain (663)	Buy now
47	9350104M02 Ball (697)	Buy now
49	6484271500 Bushing 2	Buy now
50	9370006M03 Nipple, grease(6a1)	Buy now
51	6E54412003 Handle gear shift assembly	Buy now
54	9020216061 Washer, plate(663)	Buy now
55	9341016006 Circlip	Buy now

Crankshaft.




Ref	Part	
1	6N71141100 Crankshaft	Buy now
2	BES1144700 3-2	Buy now
3	6E515163001S Housing, bearing 1	Buy now
4	93311940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	9310240M14 Oil seal(61a)	Buy now
6	9321104M36 O-ring (705)	Buy now
7	9011906MA2 Bolt, with washer	Buy now
8	93310954U1 Bearing, cylindrical(64c)	Buy now
9	6R31153600 Gear, drive	Buy now
10	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	9341040M03 Circlip(n02)	Buy now
12	B6G5153590094 Housing, Oil Seal	Buy now
13	9310235M13 Oil seal (6e5)	Buy now
14	9310122M15 Oil seal (6e5)	Buy now
15	9321074M35 O-ring (6e5)	Buy now

Crankshaft.



Yamaha 115BETO 2000 Parts Manual
Page 19 of 74


Cylinder.



A

Ref	Part	
1	6E5W0090541S Crank cylinder assembly	Buy now
2	6NB15100011S Crankcase assembly	Buy now
3	6241137900 Valve, check	Buy now
4	6631151801 Lock, bearing	Buy now
8	9038406M07 Bush, bimetal formed(6r3)	Buy now
9	9038414M09 Bush, bimetal formed(6r3)	Buy now
10	9360812063 Pin, dowel (626)	Buy now
11	90105-10M20 Bolt (6e5)	Buy now
12	9011908M94 Bolt, with washer	Buy now
13	9011608M45 Bolt, stud (6e5)	Buy now
14	BES1132500 Anode	Buy now
15	9878004015 Screw, flat head(ga5)	Buy now
16	6ES1111901 2-16 i	Buy now
17	9011908MA3 Bolt, with washer	Buy now
18	6ES42761001S Stopper	Buy now


Cylinder.



A

Ref	Part	
19	BE542762001S Stopper	Buy now
20	6634453300 Damper, upper mount	Buy now
22	6E511371001S Cover	Buy now
23	6ES11381A2 Gasket 1	Buy now
24	9011906MA2 Bolt, with washer	Buy now
25	9046506M8s Clamp	Buy now


Cylinder. Crankcase 2



B

Ref	Part	
2	6ES511181A1 Gasket, Cylinder Head	Buy now
3	9011908MA8 Bolt, with washer	Buy now
4	BES511191011S Cover, Cylinder Head 1	Buy now
5	6ES11193A0 Gasket, Head Cover 1	Buy now
7	BE51241120 Thermostat	Buy now
9	68312414A1 Gasket, Cover	Buy now
10	9011906MAG Bolt, With Washer	Buy now
12	BES41112A1 Gasket, Exhaust Inner Cover	Buy now
13	BES41112A1 Gasket, Exhaust Inner Cover	Buy now
14	6N741113001S Outer cover, exhaust	Buy now
15	6502437800 Pipe, joint 2	Buy now
17	9046708004 Clip, pipe 6162435600	Buy now
18	9011906MAS 18-21	Buy now
19	6G51241600 Valve, pressure control	Buy now
20	9050116M11 Spring, compression (688)	Buy now


Cylinder. Crankcase 2



B

Ref	Part	
22	6G511382A1 Gasket 2	Buy now
23	6G511372001S Cover, bypass 2	Buy now
24	9011906MA2 Bolt, with washer	Buy now
25	6E51257600 Hose 1	Buy now
25	6NG00100040 Tuyau	Buy now
26	904B53Mi8 Tt Clamp	Buy now
27	9470200247 Plug, spark (br8hs-10)	Buy now

Electrical 1




6E50010-0090

C

Ref	Part	
1	6N785542011S Bracket	Buy now
2	6A08231700 Damper, ignition coil	Buy now
3	6244254200 Collar	Buy now
4	9011906M59 Bolt, with washer	Buy now
7	6E58554000 C.d.i. unit assembly	Buy now
8	9788006040 Screw pan head	Buy now
9	9299006100 Washer(6a1)	Buy now
10	9299006600 Washer, plain (646)	Buy now
12	9015906M11 Screw, with washer(6I2)	Buy now
13	6H08196000 Rectifier & regulator assembly	Buy now
14	9701306045 Bolt, hexagon	Buy now
15	9290306600 Washer, plain (646)	Buy now
17	9020106M0S Washer, Plate	Buy now
18	6E58196100 Cover	Buy now
19	9046506M86 Clamp	Buy now

Electrical 1





6E50010-0090

C


Ref	Part	
20	9709506012 Bolt(gh1)	Buy now

Electrical 2




Ref	Part	
1	6G58215200 Holder, fuse	Buy now
2	6R38557001 Ignition coil assembly	Buy now
3	9709506020 Bolt(7u8) a	Buy now
4	9299508600 Washer, plain (663)	Buy now
5	6G18237021 Plug cap assembly	Buy now
7	6898195210 Holder, starter relay	Buy now
8	6E58195000 Relay assembly	Buy now
9	6E58195A00 Relay assembly	Buy now
10	6G58714910 Connector	Buy now
11	6G58211900 Cover, lead wire	Buy now
12	6E58211600 Wire, minus lead	Buy now
13	6E58194822 Bracket	Buy now
14	9709506016 Bolt, hexagon deep recess	Buy now
15	9299506600 Washer, plain (646)	Buy now
18	6E58611002 Solenoid	Buy now

Electrical 2



Ref	Part	
19	6E58611601 Wire, pull	Buy now
20	9160930010 Pin, spring (663)	Buy now
23	6ES00107100 25 6E5-82590-15	Buy now
23	9321003261 O-ring (663)	Buy now
26	6638215106 © © Fuse (13V 30R) CCT TTT TT TTC BIE	Buy now
27	6E58210512 Battery cable	Buy now
28	6N78211700 Wire, lead	Buy now
29	BR38251900 Wire, Earth Lead	Buy now
30	9709506012 Bolt(gh1)	Buy now
32	BE58253110 Wire, Lead	Buy now
35	6628251900 Wire, earth lead	Buy now
38	9046512M25 Clamp (6e5)	Buy now
39	9046505M87 Clamp	Buy now
40	9046508M89 Clamp	Buy now
40	BE500107100 —f	Buy now

Fuel1




6E50300-4090

C

Ref	Part	
1	BE52430410 Fuel Pipe Joint Comp.	Buy now
2	9709506028 Bolt (6g0)	Buy now
3	6E52431300 Pipe 3	Buy now
4	9046511M10 Clamp	Buy now
5	6R32456000 Filter assembly	Buy now
6	61N2456300 Element, filter	Buy now
7	61N2452100 Cup, filter	Buy now
8	9321032738 O-ring(1wg)	Buy now
9	6E52456600 Bracket, filter	Buy now
10	9701306014 Bolt(gj3)	Buy now
11	9280306100 Nut(661) SPRING	Buy now
12	9538008600 Nut (661)	Buy now
13	6E52431400 Pipe 4	Buy now
16	6Es244 Fuel Pump assembly i	Buy now
17	9850305035 Screw, pan head (686)	Buy now

Fuel1




FWD
6E50300-4090

C

Ref	Part	
18	9290305600 Washer, plain (646)	Buy now
19	BE52441300 Body	Buy now
20	6E52447100 Diaphragm	Buy now
22	6E52441100 Diaphragm	Buy now
23	6482442400 Seat,spring	Buy now
24	6E52442300 Spring, diaphragm	Buy now
27	6A01432500 Screw, pan head	Buy now
28	9538003600 Nut (6g8)	Buy now
29	6E52441210 Body 1	Buy now
30	65024431A0 Gasket,fuel pump	Buy now
31	9700506050 Bolt	Buy now
32	9299506600 Washer, plain (646)	Buy now
36	6E52437610 Pipe, joint 1	Buy now
37	6G52431810 Hose (I90)	Buy now
41	9044615M07 Hose(6g4)	Buy now


Fuel1



FWD
6E50300-4090

C

Ref	Part	
42	656W281002 Tool kit	Buy now





6E50300-0100

C

Ref	Part	
1	6YK2430651 Fuel Pipe Comp. 1 AP	Buy now


Generator



C

Ref	Part	
1	6E58555000 Rotor assembly	Buy now
2	BE58551000 Stator assembly	Buy now
3	6E58558000 Coil, pulser	Buy now
4	9028005015 Key, woodruff	Buy now
5	9020121M18 Washer, plate (663)	Buy now
6	9017020137 Nut, hexagon(663)	Buy now
7	9701306060 Bolt, hexagon	Buy now
8	9290306600 Washer, plain (646)	Buy now
9	6884161100 Retainer, magneto base 1	Buy now
10	6884161200 Retainer, magneto base 2	Buy now
12	9046412M00 Clamp	Buy now
13	6E58133200 Plate, timing	Buy now
14	9788506010 Screw pan head	Buy now
15	9299506600 Washer, plain (646)	Buy now
16	6ES8133701 Cover, Flywheel	Buy now


Generator



C


Ref	Part	
17	6G58231700 Damper	Buy now
18	6A08231700 Damper, ignition coil	Buy now
19	6244254200 Collar	Buy now
20	9011906M59 Bolt, with washer	Buy now

Intake




Ref	Part	
1	6E51361000 Reed valve assembly	Buy now
2	6E5W000400 Reed set	Buy now
3	6E513621A1 Gasket, valve seat	Buy now
4	9788005025 Screw, panhead (a93)	Buy now
5	9299005600 Washer, plain (646)	Buy now
6	6E513641111S Manifold 1	Buy now
7	6ES1355200 Nozzle	Buy now
8	6241448500 Pipe, joint	Buy now
9	6E51137000 Check valve assembly	Buy now
10	9044507M28 Hose (I200)	Buy now
11	90445-07M24 Hose (I390)	Buy now
12	9044507M46 Hose (I390)	Buy now
13	9011606M30 Bolt, stud(6e5)	Buy now
14	BES13645A1 Gasket, Manifold 1	Buy now
15	9011906MA3 Bolt, with washer	Buy now

Intake



Ref	Part	
16	9048506M86 Cyr	Buy now
17	9701306012 Bolt(gh1)	Buy now
18	6ES514198A2 -	Buy now
19	9538006600 Nut(661)	Buy now
20	9209506100 Wi	Buy now
22	6E54125601 Rod, choke 1	Buy now
23	6614126202 Joint, choke lever	Buy now
24	6E54127102 Knob, choke	Buy now
25	6894127300 Grommet	Buy now
28	BE51448500 Pipe, joint	Buy now
29	9044507M23 Hose (I570)	Buy now
30	6E514483A1 Gasket	Buy now
31	9701306020 Bolt(62y)	Buy now
32	9290306600 Washer, plain (646)	Buy now
33	BE551441800 Cover 2	Buy now


Intake



B


Ref	Part	
34	6ES1441K00 Emblem	Buy now
35	6E514416A1 Gasket, air cleaner	Buy now
36	9011906M31 Bolt, with washer(680)	Buy now

Lower




Ref	Part	
1	6ES545300158D Lower	Buy now
6	9034008M04 Plug, straight screw	Buy now
7	6884534100 Plug, drain	Buy now
8	2 N64-83510-00	Buy now
8	9043008020 Gasket	Buy now
9	BES4553600 Sleeve, Drive Shaft	Buy now
11	9044507ME8 Hose (I250) L	Buy now
12	6E58355810 End, nipple	Buy now
13	6E54532100 Plate	Buy now
13	6E5455670115 Shim (t:0.15mm) UR	Buy now
13	6E5455670118 Shim (t:0.18mm) UR	Buy now
13	6E5455670130 Shim (t:0.30mm) UR	Buy now
13	6E5455670140 Shim (t:0.40mm)	Buy now
13	a» item_description	Buy now
14	9321058144 O-ring(47x)	Buy now

Lower




Ref	Part	
15	9310609014 Oil seal	Buy now
16	9011906M10 Bolt, with washer	Buy now
17	6E54415002 Shift cam assembly	Buy now
18	9343008006 Circlip(2r6)	Buy now
19	64W01710220 40 6E5-45344-00	Buy now
19	9050111M10 Spring, compression (663)	Buy now
21	9020122M01 Washer, plate(61a)	Buy now
22	9020622M19 Washer, wave(61a)	Buy now
27	9321037160 O-ring (6g8)	Buy now
28	BE54435201 Impeller	Buy now
29	9028004M05 Key, Woodruff	Buy now
30	6E54432300 Outer plate, cartridge	Buy now
31	6E544315A0 Gasket,water pump	Buy now
32	9360612019 Pin, dowel (614)	Buy now
33	9011908M14 Bolt, with washer	Buy now

Lower




Ref	Part	
34	6E5453310094 Housing, bearing	Buy now
35	9310128M16 Oil seal (6e5)	Buy now
36	6E5455870112 Shim (t:0.12mm) UR	Buy now
36	6E5455870115 Shim (t:0.15mm) UR	Buy now
36	6E5455870118 Shim (t:0.18mm) UR	Buy now
36	6E5455870130 Shim (t:0.30mm) UR	Buy now
36	6E5455870150 Shim (t:0.50mm) UR	Buy now
36	9331733002 22 36	Buy now
38	93341930V2 Bearing, thrust(64d)	Buy now
39	9321055M14 O-ring (70e)	Buy now
42	9299508600 Washer, plain (663)	Buy now
1	44 6Ta-11372-00	Buy now
10	~3 - A i	Buy now
43	6E54550101 Drive shaft comp. L	Buy now
52	9350732009 Ball (12r)	Buy now

Lower




Ref	Part	
53	9351132017 Ball (498)	Buy now
54	9350316003 Ball	Buy now
55	9025008MO7 Pin, Straight	Buy now
56	6E54563101 Clutch, dog	Buy now
57	6E54563301 Ring, cross pin	Buy now
59	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
60	6E54557101 Gear 2	Buy now
61	6E54557600 Washer, thrust 2	Buy now
62	93315430U8 Bearing	Buy now
63	9310730Mi7 Oil Seal	Buy now
64	9321086M39 O-ring (6e5)	Buy now
65	6L6455770010 Shim (t:0.10mm) UR	Buy now
65	6L6455770012 Shim (t:0.12mm) UR	Buy now
65	6L6455770015 Shim (t:0.15mm) UR	Buy now
65	6L6455770030 Shim (t:0.30mm) UR	Buy now

Lower




Ref	Part	
823	--21 50 6E5-45634-01	Buy now
823	I - I. a.	Buy now
823	o21 Arbre, Helice	Buy now
823	S22 49 Bes-45641-02	Buy now
1	id item_description	Buy now
5	B36 Tower Unit	Buy now
20	69 688-45384-00 h	Buy now
65	6L6455770040 Shim (t:0.40mm)	Buy now
1	BE54436600 Damper, Water Seal	Buy now
2	BE54436100 Tube, Water L	Buy now
3	BES54436500 Damper, Water Seal	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9707510045 Bolt(64d)	Buy now
6	9299510100 Ybs67-10 washer, spring	Buy now
7	9011910M89 Bolt, with washer	Buy now

Lower




Ref	Part	
9	6884537500 Damper, seal 2	Buy now
10	6884521402 Cover, water inlet	Buy now
12	9015205M07 Screw, countersunk	Buy now
13	9018505002 Nut nylon (sus)(ex4)	Buy now
14	6E54537101 Trim tab	Buy now
15	9010510M00 Bolt, hexagon (663)	Buy now
17	6E58355800 End, nipple	Buy now
18	9046511M10 Clamp	Buy now
19	BE54436500 Damper, Water Seal	Buy now
20	6E54431200 Cover, water pump housing HOUSING 1	Buy now
21	6Es. 1"	Buy now
22	6884599701 Spacer 2	Buy now
23	9299018200 Washer (6e5)	Buy now
24	6N600104220 -	Buy now
24	9017118M04 Nut, castle (6e5)	Buy now

Lower



Ref	Part	
25	9149040030 Pin, cotter (663)	Buy now
26	688459300298 Propeller (3x13x17) UR	Buy now
26	688459326098 Propeller (3x13-1/2"x14"-k) UR	Buy now
26	688459700398 Propeller (3x13"x19"-k)	Buy now
26	688459740298 Propeller (3x13"x23"-k) UR	Buy now
26	688459760198 Propeller (ss 3x13"x25"-k)	Buy now
26	688459786098 Propeller (3x13-1/2"x16"-k) UR	Buy now
26	6E54595600EL Propeller (3x13"x25"-k) UR CTT	Buy now
26	6E54597210 Propeller (ss 3x14"x24"-p) UR	Buy now
26	6E54597410 Propeller (ss 3x14"x28"-p) UR	Buy now
26	6E54597610 Propellar assembly (3x14"x22"-p) UR	Buy now
26	6E54594501EL Propeller	Buy now
26	BE54595400EL - UR	Buy now
29	BES54599410 Plate, Tooth	Buy now

Meter





6E50300-0270

B

Ref	Part	
1	6Y58354005 Tachometer assembly AP WITH OIL LAMP	Buy now
2	6Y58351700 Bulb (12v-1.7w)	Buy now
3	6Y58353610 Socket, meter	Buy now
4	6Y58352300 Damper	Buy now
5	6Y58351400 Plate, fitting	Buy now
6	6Y58350903 Socket cord assembly To	Buy now
7	6Y58351800 Bulb (12v-1.7w) t6.5	Buy now
8	9530305600 Nut, hexagon (663)	Buy now
9	9290305100 Ybs67-5 washer, spring	Buy now
10	6Y58195002 Relay assembly AP	Buy now
11	9046513M18 Clamp eee	Buy now
12	6Y58367011 Trim Meter assembly AP	Buy now
14	6Y58353600 Socket, meter	Buy now
15	8Y58357700 Plate, FITTING 1	Buy now
16	6888366400 Damper	Buy now

Meter




6E50300-0270

B.

Ref	Part	
17	6Y58355300 Wire, lead (l=2.5m) AP	Buy now
18	1E68215100 Fuse (10a)	Buy now
19	6Y58211700 Wire, lead AP	Buy now
20	6R38252170 Wire, lead (for tacho., 7m) AP 7M	Buy now


Oil Pump



B

Ref	Part	
1	6NB1320000 Oil Injection Pump assembly	Buy now
2	6R31347100 Screw	Buy now
3	6L21347500 Gasket, breather bolt	Buy now
4	9321019MA7 O-ring(6r0)	Buy now
6	9010906M39 Bolt(6h0)	Buy now
7	6N71341600 Pipe, oil 1	Buy now
12	6R31318310 Valve, check	Buy now
17	6R31311700 Collar, distance	Buy now
18	9321013M04 93210-13m04	Buy now
19	9020208Md4 Washer, Plate	Buy now
20	6R34124100 Rod, link	Buy now
22	9538005600 Nut, hexagon (663)	Buy now
23	6R54128700 Joint, Link	Buy now
24	6NG00104070 25 90202-05088 WASHER, PLATE	Buy now
24	9046805M03 Clip(6j8)	Buy now


Oil Pump



B

Ref	Part	
27	9169030016 Pin, spring	Buy now

Oil Tank




6E50300-0080

B

Ref	Part	
1	6E52170808 Sub oil tank assembly	Buy now
2	6E52173302 Sub tank, oil (10.5l)	Buy now
3	6E52177003 Oil tank cap assembly	Buy now
4	6E52432200 Pipe 11	Buy now
5	9046511M10 Clamp	Buy now
7	BE52431901 Pipe, Oil	Buy now
9	6E58190001 Oil feed pump assembly	Buy now
10	6E58192200 Grommet	Buy now
11	6E52432101 Pipe 10	Buy now
12	6E52437900 Pipe, joint 4	Buy now
13	9044511M81 Hose (I3000)	Buy now
15	6E58572004 Oil level gauge assembly	Buy now
17	6E5217340133 Holder, oil sub tank	Buy now
18	6E5217980133 Bracket,	Buy now
19	6E52174600 Damper	Buy now

Oil Tank




6E50300-0080

B

Ref	Part	
20	9708006100 Bolt, hexagon	Buy now
22	9538006600 Nut(661)	Buy now
23	6E52175005 Oil tank assembly	Buy now
24	6E503000080 25 6E5-13411-00	Buy now
24	6E58573014 Oil Level Gauge assembly	Buy now
26	BES I	Buy now
27	9044505M02 Hose (I700)	Buy now


Oiltank



6E50300-0080

Ref	Part	
28	BA08231700 Damper, Ignition Coil	Buy now
29	6244254200 Collar	Buy now
30	9011906M65 Bolt, with washer	Buy now
32	9046511M10 Clamp	Buy now
34	9044512M11 Hose (L350)	Buy now
35	6E52446100 Pipe, Joint	Buy now
37	BE58574002 Control Unit assembly	Buy now
38	9046415M11 Clamp (3y2)	Buy now
39	6A08231700 Damper, ignition coil	Buy now

Power




Ref	Part	
29	6E54382G00 Valve seat	Buy now
32	64E4381801 Lower shock mount pin set	Buy now
33	90386-22M98 Bush(61u)	Buy now
1	64E4388E00 Bolt ,screw (l:14mm)	Buy now
2	64E4383100 Connector, shaft	Buy now
3	64E4386800 O-ring 8	Buy now
4	64E4383000 Gear pump assembly	Buy now
5	72X4385800 Ball	Buy now
6	64E4384300 Screw, valve lock	Buy now
7	64E4384100 Piston, shuttle	Buy now
8	64E4380200 Valve sub assembly	Buy now
9	6E54389600 O-ring	Buy now
11	64E43-85100 Seat, Relief Valve	Buy now
12	64E4385800 Ball	Buy now
13	64E4385900 Pin, Valve Support	Buy now

Power




Yamaha 115BETO 2000 Parts Manual
Page 52 of 74

Power




Ref	Part	
32	64E4380F00 Holder, brush 2	Buy now
33	64E4389200 Breaker comp. (brush 2)	Buy now
34	6G54386500 O-ring	Buy now
35	9310208M43 Oil seal(6b0)	Buy now
36	64E4380500 Armature assembly	Buy now
37	64E4384310 Screw valve lock	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
5	64E4381700 Filter 2	Buy now
6	B4E4381000 Piston Sub assembly	Buy now
7	64E4389800 Seal, dust 2	Buy now
8	64E4386700 O-ring 7	Buy now
9	64E4386600 O-ring 6	Buy now
10	6E54386200 O-ring 2	Buy now
11	64E4388300 O-ring 10 q	Buy now
12	6E54387200 Ring, back-up 2	Buy now
13	6E54381402 Piston, free	Buy now
15	64E4382000 Trim piston sub assembly	Buy now
17	64E4382200 Seal, trim dust	Buy now
18	64E4384J00 Seal, trim down	Buy now
20	6E54386400 O-ring 4	Buy now
22	64E4382800 Body, reservoir	Buy now
24	64E4389700 O-ring	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
27) item_description	Buy now
27	64E4381G00 Pin 1	Buy now
31	A - ER	Buy now


Remote



B

Ref	Part	
28	7034822300 Lock, neutral	Buy now
29	7034822500 Cover	Buy now
30	7034821900 Cover, lead	Buy now
31	7034828100 Screw, flat head	Buy now
32	7034828200 Screw	Buy now
33	970950803 Bolt, hexagon (fj1) i	Buy now
34	9299008600 Washer, plain (663)	Buy now
35	9858004010 Screw, pan head (e56)	Buy now
36	9858004006 Screw, pan head (7h3)	Buy now
37	9858005010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151) EEA	Buy now
39	7034829110 Screw	Buy now
40	9538006600 Nut(661)	Buy now
41	7034829310 Spacer, remote control SINGLE	Buy now
42	7014828700 Washer 1	Buy now


Remote



B

Ref	Part	
43	70324821500 E	Buy now
44	7024821700 Mark	Buy now
45	7038251041 Main switch assembly	Buy now
46	7038253100 Wire, lead	Buy now
47	6888257501 Engine stop switch assembly	Buy now
48	6826255600 ©". i	Buy now
49	6888258A20 10p main harness mec 2m (6ft) Li5M (10P)	Buy now
50	7038254000 Neutral switch assembly	Buy now
51	6E507009240 52 703-48284-00 GROMMET	Buy now
51	7038338302 Buzzer	Buy now
54	7038259200 Band	Buy now


Remote Control Assy



A

Ref	Part	
?	7034820515 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	7034826101 Arm, throttle	Buy now
3	7034815300 Shaft, free accel.	Buy now
4	7034823500 Bushing	Buy now
6	7034826400 Throttle, friction	Buy now
7	9538005600 Nut, hexagon (663)	Buy now
8	9738005025 Bolt	Buy now
9	7034826500 Shaft Friction	Buy now
10	9343006024 Circlip (701)	Buy now
12	7034825200 Roller, cam	Buy now
13	7014824800 Roller, free accel	Buy now
14	7034819800 Washer, wave 3	Buy now
15	7034824300 Bushing 3	Buy now
16	7034823600 Bushing	Buy now
17	7034818900 Retainer	Buy now


Remote Control Assy



A

Ref	Part	
19	7034834501 Cable end, remote control 2	Buy now
20	7034835800 Anchor, cable	Buy now
22	7034823800 Spring, detent	Buy now
23	7034824600 Spacer 1	Buy now
24	6E507009240 52 703-48284-00	Buy now
24	7034822700 Spring, neutral lock	Buy now
27	7034822200 Grip, control lever SINGLE	Buy now
55	7038256301 Trim & tilt switch assembly	Buy now
56	7034822100 Grip	Buy now
57	7034815200 Knob, free accel	Buy now
58	7034821200 Rear housing	Buy now
59	7034821300 Back, panel	Buy now
61	7034821101 Housing,1	Buy now
62	7034823200 Drive gear	Buy now

Remote Control Box




67M0100-8280

A


Ref	Part	
1	7034820515 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	7014832050 Cable, Remote Control L=15F UR	Buy now
2	7014832060 Cable, Remote Control L=16F UR	Buy now
2	7014832080 Cable, Remote Control L=17F	Buy now
2	7014835000 Cable, Remote Control L=21F	Buy now
2	7014835020 Cable, Remote Control L=23F 3F 2 UR	Buy now

Repair



Ref	Part	
1	6E541134A0 Gasket, exhaust manifold	Buy now
1	6E541135A0 Gasket, exhaust manifold	Buy now
1	6E54436500 Damper, water seal 1	Buy now
1	6E54436600 Damper, water seal 2	Buy now
1	6E54512300 Gasket, muffler	Buy now
1	6E5W0001F1 Gasket kit, lower unit	Buy now
1	6G545114A0 Gasket, upper casing	Buy now
8	9043008020 Gasket	Buy now
9	9321058144 O-ring(47x)	Buy now
10	9310609014 Oil seal	Buy now
12	9321037160 O-ring (6g8)	Buy now
13	6E544315A0 Gasket,water pump	Buy now
14	9310128M16 Oil seal (6e5)	Buy now
15	9321055M14 O-ring (70e)	Buy now
17	9310130M17 Oil seal (6e5)	Buy now


Repair



B

Ref	Part	
18	6NEW007801 Water Pump Repair Kit	Buy now
19	61A4432202 Insert, cartridge	Buy now
20	9321086M38 O-ring (6e5)	Buy now
22	6E54435201 Impeller	Buy now
23	6E500104220 24 Bes5-44315-A0 GASKET, WATER PUMP	Buy now
23	6E54432300 Outer plate, cartridge	Buy now
25	9360612019 Pin, dowel (614)	Buy now
27	9028004M05 Key, Woodruff	Buy now


Repairkit



B.


Ref	Part	
1	6F3W0001A4 Gasket kit, power unit	Buy now
2	BES14416A1 Gasket, Air Cleaner	Buy now
2	{~~ item_description	Buy now
3	6E514483A1 Gasket	Buy now
4	BES14198A2 Gasket	Buy now
5	6E511381A2 Gasket 1	Buy now
6	6ES11181A1 Gasket, Cylinder Head 1	Buy now
9	6E541112At Gasket, exhaust inner cover	Buy now
10	6ES41112A1 Gasket, Exhaust Inner Cover	Buy now
11	9310240Mi4 I	Buy now
12	9321104M36 O-ring (705)	Buy now
13	9310235M13 Oil seal (6e5)	Buy now
15	9321074M35 O-ring (6e5)	Buy now
16	6E513 F ale	Buy now
17	6E513645A1 Gasket, manifold 1	Buy now

Repairkit



Ref	Part	
19	6G545113A1 Gasket, upper casing	Buy now
20	65024431A0 Gasket, fuel pump	Buy now
22	6ES1415900 Clip	Buy now
23	6E514198A2 Gasket	Buy now
24	6E51454600 Valve, needle	Buy now
27	64D1438400 Gasket, float chamber	Buy now


Repairkit 1



B

Ref	Part	
28	BES51439800 Gasket	Buy now
29	6ES51432801 Plug	Buy now
30	BES51497900 (Gasket	Buy now
32	61U1495900 Gasket	Buy now


Repairkit 2



B


Ref	Part	
28	6ES5W00783A Chrome Pump Kit	Buy now
29	6R34432242 Insert, cartridge	Buy now

Starting Motor



Ref	Part	
1	6N78180010 Starting motor assembly	Buy now
2	6N78185010 Armature assembly	Buy now
3	61A8180900 Washer kit	Buy now
4	61A8182400 Washer 2	Buy now
5	6N78181000 Stator assembly	Buy now
6	6K78182G10 Bush, terminal	Buy now
7	6N78184000 Brush holder assembly	Buy now
8	6N78180100 Brush set	Buy now
9	6N78181300 Spring, brush	Buy now
10	6N78182010 Rear bracket assembly	Buy now
11	6N78180700 Gear assembly, starting motor	Buy now
12	6N78185700 Pinion stopper set	Buy now
13	6N78183000 Front bracket assembly	Buy now
14	6K78182610 Bolt	Buy now
15	6E58182E10 Washer, spring	Buy now


Starting Motor



D

Ref	Part	
17	6E58182A10 Nut	Buy now
18	6E58182K10 Nut	Buy now
19	6E5818220298 Bracket, starting motor	Buy now
20	9011908M76 Bolt, with washer(6e5)	Buy now
22	9011908M57 Bolt, with washer	Buy now
23	9209008600 Washer, Plate	Buy now
24	6E500100110 25 92995-08600 WASHER	Buy now
24	9709508016 Bolt, hexagon deep recess	Buy now

Steering




67H0100-9290

A

Ref	Part	
1	6E56135002 Steering guide attachment kit AP	Buy now
2	6E56135101 Rod, steering link	Buy now
3	9038710M61 Collar (6e5)	Buy now
4	9056012Mo1 Spacer	Buy now
6	9018509M01 Nut, nylon (663)	Buy now
7	9020110M20 Washer, plate (663)	Buy now
8	6E54314500 Cap, clamp bracket	Buy now
9	9321016275 O-ring	Buy now

Top Cowling




FWD
6E50300-8010

A

Ref	Part	
1	6E542610G14D Top Cowling assembly [Buy now
2	BE5426470094 Holder, Clamp Band	Buy now
3	6E5426490194 Holder, clamp band	Buy now
4	6634266200 Damper	Buy now
5	9026606009 Rivet (697)	Buy now
6	9026606M02 Rivet (697) BE	Buy now
7	6E54265200 Hook 2	Buy now
8	6884265200 Hook 2	Buy now
9	9709506016 Bolt, hexagon deep recess	Buy now
10	9299506600 Washer, plain (646)	Buy now
11	B6E54261700 Damper, Form EO	Buy now
12	BES4261900 Damper, Form	Buy now
13	6E54262700 Damper, Form	Buy now
14	6E54261500 Seal	Buy now
16	9700506016 Ene	Buy now

Top Cowling




6E50300-8010

A

Ref	Part	
18	68842677C0 Graphic, front YAMAHA	Buy now
19	6E54267831 Graphic Rear	Buy now
20	6N7W007030 Graphic Set	Buy now
22	6E503008010 24 6N7-42682-30	Buy now
22	6N74267830 Graphic, Rear	Buy now


Upper



F

Ref	Part	
1	BE545111028D Casing, Upper L	Buy now
2	6E507000180 92995-08600 WASHER	Buy now
2	6E51473700 Damper, muffler	Buy now
2	6E541132105B Manifold, exhaust	Buy now
2	6E541134A0 Gasket, exhaust manifold	Buy now
2	6E54272400 Grommet	Buy now
2	6E54276900 Seal, rubber	Buy now
2	6E54515500 Cap	Buy now
2	6G5411310158 Manifold, Ext. 1	Buy now
2	6G5411370294 Guide, exhaust	Buy now
2	6G545113A1 Gasket, upper casing	Buy now
2	6G545114A0 Gasket, upper casing	Buy now
2	9011908M78 Bolt, with washer	Buy now
2	9011908M79 Bolt, hexagon (fj1)	Buy now
2	9299506600 Washer, plain (646)	Buy now

Upper



Ref	Part	
2	9299508100 Ybs67-8 washer, spring	Buy now
2	9299508600 Washer, plain (663) ~~~~" 7	Buy now
2	9360812M05 Pin, dowel b (6e5)	Buy now
2	9709506010 Bolt	Buy now
2	9709508030 Bolt, hexagon (fj1)	Buy now
2	9709508045 Bolt, hexagon	Buy now
28	9018305M02 Nut, spring (6e5)	Buy now
29	6ES54512300 Gasket, Muffler	Buy now
30	BES541135A0 Gasket, Exhaust Manifold	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.