



Yamaha 115CETO 2013

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


SCHEDULED SERVICE PARTS	3
BOTTOM COWLING	4
BRACKET 1	8
BRACKET 2	11
CARBURETOR	14
CONTROL	16
CRANKSHAFT & PISTON	20
CYLINDER & CRANKCASE 1	23
CYLINDER & CRANKCASE 2	25
ELECTRICAL 1	27
ELECTRICAL 2	29
FUEL 1	32
FUEL 2	35
GENERATOR	36
INTAKE	38
LOWER CASING & DRIVE 1	40
LOWER CASING & DRIVE 2	46
METER	50
OIL PUMP	51
OIL TANK	53
POWER TRIM & TILT ASSY 1	57
POWER TRIM & TILT ASSY 2	60
REPAIR KIT 1	63
REPAIR KIT 2	65
STARTING MOTOR	67
STEERING GUIDE	69
TOP COWLING	70
UPPER CASING	72

Scheduled Service Parts




Ref	Part	
1	6E51132500 Anode	Buy now
2	6E51241130 Thermostat	Buy now
3	68812414A1 Gasket, cover	Buy now
4	9470200247 Plug, spark (br8hs-10)	Buy now
5	6462425102 Strainer 1	Buy now
6	6R32456300 Element, filter	Buy now
7	9321032738 O-ring(1wg)	Buy now
8	6G54525102 Anode	Buy now
9	9043008020 Gasket	Buy now
10	6E54537101 Trim tab	Buy now
11	6E54537110 Tab-trim	Buy now
12	6N6W007802 Water pump repair kit	Buy now

Bottom Cowling




Ref	Part	
1	6N742711438D Cowling, bottom	Buy now
2	9016905M00 Screw truss head tapping	Buy now
3	6H44274800 Grommet	Buy now
4	6N742815018D Lever, clamp	Buy now
5	9038613M88 Bush(6r3)	Buy now
6	9020613M10 Washer, wave (6e5)	Buy now
7	9010908M45 Bolt(6r3)	Buy now
8	9299008200 Ybs66-8 washer, plain	Buy now
9	6E54439100 Nipple, hose	Buy now
10	6N74272530 Grommet	Buy now
11	6N742738028D Plate, fitting	Buy now
12	9709506016 Bolt, hexagon deep recess	Buy now
13	9299506600 Washer, plain (646)	Buy now
14	6R34282400 Base, clamp lever	Buy now
15	6R34281101 Stay	Buy now

Bottom Cowling




Ref	Part	
16	6R34281600 Lever, clamp	Buy now
17	6N74285000 Wire, complete	Buy now
18	6R34281110 Stay	Buy now
19	6N74285010 Wire, complete	Buy now
20	6N74285020 Wire, complete	Buy now
21	6R34281300 Spring, clamp lever	Buy now
24	6N74282800 Plate, clamp	Buy now
25	6R34282801 Plate, clamp	Buy now
26	9709506010 Bolt	Buy now
28	6884272610 Grommet	Buy now
29	6N742741018D Apron	Buy now
30	6R342771018D Apron	Buy now
31	9709506020 Bolt(7u8)	Buy now
33	9048022M15 Grommet (6e5)	Buy now
34	9038708M37 Coller (6e5)	Buy now

Bottom Cowling




Ref	Part	
35	9020108M54 Washer, plate (6e5)	Buy now
36	9707508035 Bolt(70w)	Buy now
37	9011908M22 Bolt, with washer	Buy now
40	6E52436710 Clamp, fuel pipe 2	Buy now
41	9015706M01 Screw (6e5)	Buy now
42	9299006600 Washer, plain (646)	Buy now
43	6E54271600 Seal	Buy now
44	6K78258800 Plate	Buy now
45	6E58258800 Plate	Buy now
48	6888259400 Clamp	Buy now
49	6E58259400 Clamp	Buy now
50	9046512M25 Clamp (6e5)	Buy now
51	9709506012 Bolt(gh1)	Buy now
53	6R3Y125J70 Flushing kit	Buy now
54	6R31257200 Adapter	Buy now

Bottom Cowling




Ref	Part	
55	6R31258000 Joint assembly	Buy now
56	9044511M35 Hose (I700)	Buy now
57	9046511M10 Clamp	Buy now
59	6AH4279440 Label, warning (ge	Buy now
60	6AH4279450 Label, warning (ge	Buy now

Bracket 1




Ref	Part	
1	64E43111028D Bracket, clamp	Buy now
2	6G54525102 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506030 Bolt(jf7)	Buy now
5	9299506600 Washer, plain (646)	Buy now
6	6E58214800 Wire, lead 5	Buy now
7	9709506010 Bolt	Buy now
9	64E43112028D Bracket, clamp	Buy now
11	9788506012 Screw, pan head(62j)	Buy now
13	9370006M03 Nipple, grease(6a1)	Buy now
14	64E4313101 Bolt, clamp bracket	Buy now
15	9709508020 Bolt, hexagon	Buy now
16	9299508600 Washer, plain (663)	Buy now
17	9038625M31 Bushing (6e5)	Buy now
18	9020126M59 Washer, plate (6e5)	Buy now

Bracket 1




Ref	Part	
19	9018522M11 Nut, self-locking	Buy now
20	9046511M10 Clamp	Buy now
21	64E43311108D Bracket, swivel L(20.3")	Buy now
22	9046508M63 Clamp(61u)	Buy now
24	6E58214700 Wire, lead 5 L(20.3")	Buy now
25	6G54314400 Hook, spring	Buy now
27	6G54318102 Lever, tilt stop 1	Buy now
28	6G54318502 Lever, tilt stop 2	Buy now
29	9038610M16 Bushing (688)	Buy now
30	6G54314800 Collar, distance	Buy now
31	9024906M19 Pin(6e5)	Buy now
32	9038710M05 Collar(6e5)	Buy now
33	9169030020 Pin, spring (6h4)	Buy now
34	9050614M24 Spring, tension(6e5)	Buy now
35	64E4312600 Pin, upper shock mount	Buy now

Bracket 1




Ref	Part	
36	9038622M98 Bush(61u)	Buy now
37	9341022M11 Circlip(61u)	Buy now
38	9010112M03 Bolt (l:115mm)	Buy now
39	9020113M01 Washer, plate(6e5)	Buy now
40	9020112426 Washer, plate(663)	Buy now
41	9538012600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	64E4313910 Cam, trim sender	Buy now
2	9015905059 Screw, with washer	Buy now
3	67H8367201 Trim sender	Buy now
4	9798506216 Screw, with washer(6h2)	Buy now
5	9046511M10 Clamp	Buy now
6	9321037MH7 O-ring(61u)	Buy now
7	9020240M47 Washer, plate(61a)	Buy now
8	61A4337600 Bolt, thrust receiver	Buy now
9	9578010300 Nut, nylon (6e5)	Buy now
10	6E542510C08D Steering bracket assembly L(20.3")	Buy now
11	9020138M60 Washer, plate (6e5)	Buy now
12	9038638M32 Bush(6e5)	Buy now
13	6G544551018D Housing, lower mount rubber	Buy now
14	9341037M04 Circlip (6e5)	Buy now
15	6E54457500 Damper, lower mount rubber	Buy now

Bracket 2




Ref	Part	
16	6E54455500 Mount damper, lower side	Buy now
17	9020232M19 Washer, plate (6e5)	Buy now
18	9020116M55 Washer, plate (6e5)	Buy now
19	6E58214900 Wire, lead 3	Buy now
20	9010914M34 Bolt(6e5)	Buy now
21	9020115M58 Washer, plate (6e5)	Buy now
22	9538014800 Nut, crown (6e5)	Buy now
23	9299514600 Washer (6e5)	Buy now
24	6E54455201CA Housing, lower mount rubber	Buy now
25	9709510045 Bolt(64d)	Buy now
26	9299510600 Washer, plate	Buy now
27	6E544553018D Cover, lower mount	Buy now
28	9050116M28 Spring (6e5)	Buy now
29	9788506016 Screw, pan head(6b0)	Buy now
30	9017906066 Nut(663)	Buy now

Bracket 2




Ref	Part	
31	6E54451400 Mount damper, upper side	Buy now
32	9020126M57 Washer, plate (6e5)	Buy now
33	9020226M18 Washer, plate (6e5)	Buy now
34	9020114M56 Washer, plate (6e5)	Buy now
35	9010912007 Bolt	Buy now
36	9018512M12 Nut, self-locking(6e5)	Buy now
37	6634457500 Damper, lower mount rubber	Buy now
38	6E5445110094 Cover, upper mount	Buy now

Carburetor




Ref	Part	
1	6E51430117 Carburetor assembly 1	Buy now
2	6E51430217 Carburetor assembly 2	Buy now
3	64D1438401 Gasket, float chamber	Buy now
4	64D1438100 Body, float chamber	Buy now
5	6E51438502 Float	Buy now
6	6E51454600 Valve, needle	Buy now
7	6E51415900 Clip	Buy now
8	6E51438602 Pin, float	Buy now
9	64D1492F39 Jet, air slow (#78)	Buy now
10	61U1495900 Gasket	Buy now
11	64D1439400 Valve, drain	Buy now
12	64D1492E88 Jet, main (#176)	Buy now
13	6E51439801 Gasket	Buy now
14	61A1492H12 Jet, slow air (#60)	Buy now
15	61A1438301 Screw, drain	Buy now

Carburetor




Ref	Part	
16	6E51432100 Screw, throttle #2	Buy now
17	6J81433400 Spring, throttle #2	Buy now
18	6E51432801 Plug	Buy now
19	6E51497900 Gasket	Buy now
20	6E51432303 Screw, air adjusting	Buy now
21	6E51422300 Spring, air adjusting	Buy now
22	9798005116 Screw, pan head	Buy now
23	6E51452701 Plate	Buy now
24	9798005108 Screw, with washer	Buy now
25	6E51432400 Screw, flat head	Buy now
26	6J81499500 Gasket, drin screw	Buy now

Control




Ref	Part	
1	6E54853100 Bracket, remote control	Buy now
2	6E54853800 Clamp, cable	Buy now
3	9169030012 Pin, spring	Buy now
4	9709508020 Bolt, hexagon	Buy now
5	9299508600 Washer, plain (663)	Buy now
6	6E541632021S Lever, magneto control	Buy now
7	6E54834400 Cable end, remote control	Buy now
8	9299006200 Ybs66-6 washer, plain	Buy now
9	9018506M07 Nut, self-locking(6e5)	Buy now
10	6E541631011S Lever, magneto control	Buy now
11	9015706013 Screw, pan head(697)	Buy now
12	9050116M12 Spring, compression (688)	Buy now
13	9530306600 Nut(661)	Buy now
14	6884419400 Cap	Buy now
15	9701308045 Bolt	Buy now

Control




Ref	Part	
16	9020108M23 Washer, plate (6e5)	Buy now
17	9038612089 Bushing(663)	Buy now
18	9038708M16 Collar	Buy now
19	9038622M13 Bushing (688)	Buy now
20	9020212092 Washer, plate(663)	Buy now
21	9020108M13 Washer plate (682)	Buy now
22	9050829M12 Spring (6e5)	Buy now
23	6E54163601 Rod, magneto control	Buy now
24	9538005600 Nut, hexagon (663)	Buy now
25	6624123701 Joint, link	Buy now
29	6884163600 Rod 1	Buy now
32	6E54121301 Cam, accel.	Buy now
33	9038706M29 Collar (6a0)	Buy now
34	9020610M04 Washer, wave (676)	Buy now
35	9709506025 Bolt	Buy now

Control




Ref	Part	
36	6E5441170094 Bracket	Buy now
37	9011906MA2 Bolt, with washer	Buy now
38	68F4412100 Lever, shift rod	Buy now
39	6E54412200 Bushing, shift rod lever	Buy now
40	9020208M20 Washer, plate (6e5)	Buy now
41	9046818008 Clip 620436610000	Buy now
43	9038606M12 Bushing (688)	Buy now
44	6E5441180194 Bracket 2	Buy now
45	9701308030 Bolt	Buy now
46	9290308600 Washer, plain (663)	Buy now
47	9350104M02 Ball (697)	Buy now
48	9050112082 Spring 6484411600	Buy now
49	6484271500 Bushing 2	Buy now
50	9370006M03 Nipple, grease(6a1)	Buy now
51	6E54412003 Handle gear shift assembly L(20.3")	Buy now

Control



Ref	Part	
52	9321009165 O-ring	Buy now
53	9038616M66 Bush(6e5)	Buy now
54	9020216061 Washer, plate(663)	Buy now
55	9341016006 Circlip	Buy now


Crankshaft & Piston



6N42100-4030


Ref	Part	
1	6N71141101 Crankshaft	Buy now
2	6E51144700 Seal, ring	Buy now
3	6R315163001S Housing, bearing 1	Buy now
4	93311940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	9310240M14 Oil seal(61a)	Buy now
6	9321104001 O-ring	Buy now
7	9011906MA2 Bolt, with washer	Buy now
8	93310954U1 Bearing, cylindrical(64c)	Buy now
9	6R31153600 Gear, drive	Buy now
10	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	9341040M03 Circlip(n02)	Buy now
12	6G5153590094 Housing, oil seal	Buy now
13	9310235M13 Oil seal (6e5)	Buy now
14	9310122M15 Oil seal (6e5)	Buy now
15	9321074M35 O-ring (6e5)	Buy now

Crankshaft & Piston



Ref	Part	
17	6R5116311193 Piston (std)	Buy now
17	6R51163511 Piston (0.25mm o/s) AP	Buy now
17	6R51163611 Piston (0.50mm o/s) AP	Buy now
18	64D1160302 Piston ring set (std)	Buy now
18	64D1160402 Piston ring set (0.25mm o/s) AP	Buy now
18	64D1160502 Piston ring set (0.50mm o/s) AP	Buy now
19	6R5116421193 Piston 2 (std)	Buy now
19	6R51164511 Piston 2 (0.25mm o/s) AP	Buy now
19	6R51164611 Piston 2 (0.50mm o/s) AP	Buy now
21	6R51163310 Pin, piston	Buy now
22	6R51163410 Clip, piston pin	Buy now
23	6R51165010 Connecting kit	Buy now
24	9010908022 Bolt	Buy now
25	9331032337 Bearing	Buy now
26	9020123M01 Washer, plate(6g6)	Buy now


Crankshaft & Piston



6N42100-4030


Ref	Part	
27	93310836U0 Bearing, cylindrical(61u)	Buy now

Cylinder & Crankcase 1




Ref	Part	
1	6N6W0090181S Crank cylinder assembly	Buy now
2	6N61510010 Crankcase assembly	Buy now
3	6241137900 Valve, check	Buy now
4	6631151801 Lock, bearing	Buy now
5	6E51137201 Nipple, hose	Buy now
6	9034014M06 Plug, straight screw(62y)	Buy now
7	9043014115 Gasket (663)	Buy now
8	9038406002 Bush, bimetal formed	Buy now
9	9038414011 Bush, bimetal formed	Buy now
10	9360812063 Pin, dowel (626)	Buy now
11	9010510M20 Bolt (6e5)	Buy now
12	9011908M94 Bolt, with washer	Buy now
13	9011608026 Bolt, stud (6e5)	Buy now
14	6E51132500 Anode	Buy now
15	9878004015 Screw, flat head(ga5)	Buy now

Cylinder & Crankcase 1




Ref	Part	
16	6E51111901 Hanger, engine	Buy now
17	9011908MA3 Bolt, with washer	Buy now
18	6E542761001S Stopper	Buy now
19	6E542762001S Stopper	Buy now
20	68F4453301 Damper, upper mount rubber	Buy now
21	9011906MA2 Bolt, with washer	Buy now
22	6K711371011S Cover	Buy now
23	6E511381A2 Gasket 1	Buy now
25	9046506M86 Clamp	Buy now

Cylinder & Crankcase 2




Ref	Part	
1	6E51111101S Head, cylinder 1	Buy now
2	6E511181A2 Gasket, cylinder head 1	Buy now
3	9011908MA8 Bolt, with washer	Buy now
4	6E511191011S Cover, cylinder head 1	Buy now
5	6E511193A0 Gasket, head cover 1	Buy now
6	9011906MA4 Bolt, with washer	Buy now
7	6E51241130 Thermostat	Buy now
8	6881241200 Seal, thermostat	Buy now
9	6G512413001S Cover, thermostat	Buy now
10	68812414A1 Gasket, cover	Buy now
11	9011906MA6 Bolt, with washer	Buy now
12	6E541111001S Inner cover, exhaust	Buy now
13	6E541112A1 Gasket, exhaust inner cover	Buy now
14	6E541114A0 Gasket, exhaust inner cover	Buy now
15	6N741113001S Outer cover, exhaust	Buy now

Cylinder & Crankcase 2



Ref	Part	
16	6502437800 Pipe, joint 2	Buy now
17	6E52431200 Pipe 2	Buy now
18	9046708004 Clip, pipe 6162435600	Buy now
19	9011906MA5 Bolt, with washer	Buy now
20	60H1241600 Valve, pressure control	Buy now
21	9050116M11 Spring, compression (688)	Buy now
22	9048020M05 Grommet (688)	Buy now
23	6G511382A1 Gasket 2	Buy now
24	6G511372001S Cover, bypass 2	Buy now
25	9759506520 Bolt(7u8)	Buy now
26	6E51257600 Hose 1	Buy now
27	9046513M18 Clamp	Buy now
28	9470200247 Plug, spark (br8hs-10)	Buy now


Electrical 1




 6N60010-4110

Ref	Part	
1	6N785542011S Bracket	Buy now
2	6A08231700 Damper, ignition coil	Buy now
3	9038706119 Collar	Buy now
4	9011906M59 Bolt, with washer	Buy now
5	6N78554001 C.d.i. unit assembly	Buy now
6	9788006020 Screw pan head	Buy now
7	9299006600 Washer, plain (646)	Buy now
8	6N78553700 Cover	Buy now
9	9015906M11 Screw, with washer(6l2)	Buy now
10	6N7819480094 Bracket	Buy now
11	9701306016 Bolt, hexagon deep recess	Buy now
12	9290306600 Washer, plain (646)	Buy now
13	6R38196000 Rectifier & regulator assembly	Buy now
14	9701306025 Bolt(62y)	Buy now
16	6R38194200 Cover	Buy now


Electrical 1




6N60010-4110

Ref	Part	
17	9015906M08 Screw, with washer(6k7)	Buy now
18	9709506012 Bolt(gh1)	Buy now
19	9299506600 Washer, plain (646)	Buy now


Electrical 2



6N43110-C130

Ref	Part	
1	6R38557001 Ignition coil assembly	Buy now
2	9709506020 Bolt(7u8)	Buy now
3	9299506600 Washer, plain (646)	Buy now
4	6G18237021 Plug cap assembly	Buy now
5	6628251900 Wire, earth lead	Buy now
6	9709506012 Bolt(gh1)	Buy now
8	61A8194100 Starter relay assembly	Buy now
9	6898195210 Holder, starter relay	Buy now
10	6E58195000 Relay assembly	Buy now
11	6E58195A00 Relay assembly	Buy now
12	6G58714910 Connector	Buy now
13	6G58211900 Cover, lead wire	Buy now
14	6E58211600 Wire, minus lead	Buy now
15	6E58194822 Bracket	Buy now
16	9709506016 Bolt, hexagon deep recess	Buy now


Electrical 2



6N43110-C130

Ref	Part	
18	6N78355700 Tube	Buy now
19	9046513M18 Clamp	Buy now
20	6N78611000 Solenoid	Buy now
21	6N78611600 Wire, pull	Buy now
22	9160930010 Pin, spring (663)	Buy now
23	9709506030 Bolt(jf7)	Buy now
25	6N78611200 Stay, solenoid	Buy now
26	9321003261 O-ring (663)	Buy now
27	6888256010 Thermo switch assembly	Buy now
28	9046505M87 Clamp	Buy now
29	9046508M89 Clamp	Buy now
30	6N78259040 Wire harness assembly	Buy now
31	6638215100 Fuse	Buy now
32	7058215100 Fuse (30a)	Buy now
33	6G58215200 Holder, fuse	Buy now


Electrical 2



6N43110-C130


Ref	Part	
34	6N78210502 Battery cable	Buy now
35	6E58211701 Wire, lead	Buy now
36	6R38251900 Wire, earth lead	Buy now
39	6E58253110 Wire, lead	Buy now
43	6R38256300 Trim & tilt switch assembly	Buy now
44	6E58258700 Gasket	Buy now
45	6R38361400 Bracket	Buy now

Fuel 1




Ref	Part	
1	6R32431320 Pipe 3	Buy now
2	6R32437700 Pipe, joint 3	Buy now
3	9046511M10 Clamp	Buy now
5	6R32456000 Filter assembly	Buy now
6	6R32456300 Element, filter	Buy now
7	61N2452100 Cup, filter	Buy now
8	9321032738 O-ring(1wg)	Buy now
9	6E52456600 Bracket, filter	Buy now
10	9701306014 Bolt(gj3)	Buy now
11	9290306600 Washer, plain (646)	Buy now
12	9538008600 Nut (661)	Buy now
13	6E52431400 Pipe 4	Buy now
16	6E52441004 Fuel pump assembly	Buy now
17	6E52444401 Screw	Buy now
18	6E52441301 Body 2	Buy now

Fuel 1




Ref	Part	
19	6E52447101 Diaphragm	Buy now
20	6E52443501 Gasket, body 2	Buy now
21	6E52441101 Diaphragm	Buy now
22	6482442400 Seat, spring	Buy now
23	6E52442300 Spring, diaphragm	Buy now
24	6E52441211 Body 1	Buy now
25	6A02442101 Valve, check	Buy now
26	6A01432500 Screw, pan head	Buy now
27	9538003600 Nut (6g8)	Buy now
28	6E52449200 Bush, fuel pump	Buy now
29	6E52448600 O-ring	Buy now
30	65024431A0 Gasket, fuel pump	Buy now
31	9759506550 Bolt, hexagon w/w deep recess	Buy now
32	6G52431610 Pipe 6	Buy now
35	6E52437610 Pipe, joint 1	Buy now

Fuel 1



Ref	Part	
36	6G52431810 Hose (I90)	Buy now
37	6G52431910 Pipe 9	Buy now
40	9044615M07 Hose(6g4)	Buy now


Fuel 2




60X1300-3150


Ref	Part	
1	6YK2430742 Fuel pipe comp. 2 AP	Buy now
2	9045010M07 Hose, clamp AP	Buy now

Generator




Ref	Part	
1	6N78555001 Rotor assembly	Buy now
2	6N78551000 Stator assembly	Buy now
3	6N78558010 Coil, pulser	Buy now
4	9028005015 Key, woodruff	Buy now
5	9020121M18 Washer, plate (663)	Buy now
6	9017020137 Nut, hexagon(663)	Buy now
7	9701306065 Bolt(62j)	Buy now
8	9290306600 Washer, plain (646)	Buy now
9	6884161100 Retainer, magneto base 1	Buy now
10	6884161200 Retainer, magneto base 2	Buy now
11	9788006018 Screw, pan head(6e5)	Buy now
12	9046412M00 Clamp	Buy now
13	6E58133200 Plate, timing	Buy now
14	9798506210 Screw pan head	Buy now
15	6N78133700 Cover, flywheel	Buy now

Generator




Ref	Part	
16	9048012M11 Grommet (6a0)	Buy now
17	6638231701 Damper, ignition coil	Buy now
18	6E51448800 Label, caution	Buy now
19	6AH8199440 Label, safety	Buy now
20	6AH8199450 Label, safety	Buy now
21	6AH8199540 Label, warning	Buy now
22	6AH8199550 Label, warning	Buy now
23	6AG8199600 Mark	Buy now

Intake




Ref	Part	
1	6E51361000 Reed valve assembly	Buy now
2	6E5W000400 Reed set	Buy now
3	6E513621A1 Gasket, valve seat	Buy now
4	9788005025 Screw, panhead (a93)	Buy now
5	9299005600 Washer, plain (646)	Buy now
6	6E513641111S Manifold 1	Buy now
7	6E51355201 Nozzle	Buy now
8	6241448500 Pipe, joint	Buy now
9	6E51137001 Check valve assembly	Buy now
10	9044507M28 Hose (I200)	Buy now
11	9044507M24 Hose (I390)	Buy now
12	9044507M46 Hose (I390)	Buy now
13	9011606M30 Bolt, stud(6e5)	Buy now
14	6E513645A1 Gasket, manifold 1	Buy now
15	9011906MA3 Bolt, with washer	Buy now

Intake




Ref	Part	
16	9046506M86 Clamp	Buy now
17	9709506012 Bolt(gh1)	Buy now
18	9299506600 Washer, plain (646)	Buy now
19	6E514198A2 Gasket	Buy now
20	9017906M28 Nut(63v)	Buy now
21	6E54121701 Rod, accel. lever	Buy now
22	6E54125601 Rod, choke 1	Buy now
23	6614126202 Joint, choke lever	Buy now
24	6N74127101 Knob, choke	Buy now
25	6894127300 Grommet	Buy now
26	6N71444001 Silencer assembly, intake	Buy now
27	6E51441K00 Emblem 1	Buy now
28	9044507258 Hose (I390)	Buy now
29	6K71448300 Gasket	Buy now
30	9015906M14 Screw, with washer(6r3)	Buy now

Lower Casing & Drive 1




Ref	Part	
1	6E545300188D Lower unit assembly L(20.3"),RH	Buy now
2	6E545301078D Casing, lower	Buy now
3	93315628U9 Brg,cyl-cal roller (6e5)	Buy now
4	93332000U7 Brg,tapered roller 76mm (6e5)	Buy now
5	6E54556701 Shim (t:0.10mm) UR	Buy now
5	6E54556710 Shim (t:0.12mm) UR	Buy now
5	6E54556720 Shim (t:0.15mm) UR	Buy now
5	6E54556730 Shim (t:0.18mm) UR	Buy now
5	6E54556740 Shim (t:0.30mm) UR	Buy now
5	6E54556750 Shim (t:0.40mm) UR	Buy now
5	6E54556760 Shim (t:0.50mm) UR	Buy now
6	9034008002 Plug, straight screw	Buy now
7	6884534110 Plug, drain	Buy now
8	9043008020 Gasket	Buy now
9	6E54553600 Sleeve, drive shaft	Buy now

Lower Casing & Drive 1




Ref	Part	
10	6E54537800 Nipple, hose	Buy now
11	9044507ME8 Hose (I250) L(20.3")	Buy now
12	6E58355810 End, nipple	Buy now
13	6E54532100 Plate	Buy now
14	9321058144 O-ring(47x)	Buy now
15	9310609014 Oil seal	Buy now
16	9011906M10 Bolt, with washer	Buy now
17	6E54415003 Shift cam assembly	Buy now
18	9900108600 Circlip(2r6)	Buy now
19	61A4553800 Spacer, 1	Buy now
20	9020122M01 Washer, plate(61a)	Buy now
21	9020622M19 Washer, wave(61a)	Buy now
22	61A4552700 Collar, drive shaft	Buy now
23	61A4431101 Housing, water pump	Buy now
24	61A4432202 Insert, cartridge	Buy now

Lower Casing & Drive 1




Ref	Part	
25	9321086M38 O-ring (6e5)	Buy now
26	9321037160 O-ring (6g8)	Buy now
27	6E54435201 Impeller	Buy now
28	9028004M05 Key, woodruff (6e5)	Buy now
29	6E54432300 Outer plate, cartridge	Buy now
30	6E544315A0 Gasket,water pump	Buy now
31	9360612019 Pin, dowel (614)	Buy now
32	9011908M14 Bolt, with washer	Buy now
33	6E545331009S Housing, bearing	Buy now
34	9310128M16 Oil seal (6e5)	Buy now
35	93317330U2 Bearing, cylindrical(6k0)	Buy now
36	6E54558701 Shim (t:0.10mm) UR	Buy now
36	6E54558710 Shim (t:0.12mm) UR	Buy now
36	6E54558720 Shim (t:0.15mm) UR	Buy now
36	6E54558730 Shim (t:0.18mm) UR	Buy now

Lower Casing & Drive 1




Ref	Part	
36	6E54558740 Shim (t:0.30mm) UR	Buy now
36	6E54558750 Shim (t:0.40mm) UR	Buy now
36	6E54558760 Shim (t:0.50mm) UR	Buy now
37	93341930V2 Bearing, thrust(64d)	Buy now
38	9321055M14 O-ring (70e)	Buy now
39	6E54534400 Cover, oil seal	Buy now
40	9709508025 Bolt (62g)	Buy now
41	9299508600 Washer, plain (663)	Buy now
42	6E54550101 Drive shaft comp. L(20.3")	Buy now
43	6E54555102 Pinion	Buy now
44	9017016M01 Nut, hexagon (688)	Buy now
45	6E54556001 Gear 1 assembly	Buy now
46	93315425U7 Brg,cyl-cal roller (6e5)	Buy now
47	6E54561101 Shaft, propeller	Buy now
48	6E54563402 Slide, shift	Buy now

Lower Casing & Drive 1




Ref	Part	
49	9050116M37 Spring (6g5)	Buy now
50	9350732009 Ball (12r)	Buy now
51	9351132017 Ball (498)	Buy now
52	9350316003 Ball	Buy now
53	9025008M07 Pin, straight (6g5)	Buy now
54	6E54563101 Clutch, dog	Buy now
55	6E54563301 Ring, cross pin	Buy now
56	6E54533200CA Housing, bearing	Buy now
57	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
58	6E54557101 Gear 2	Buy now
59	6E54557600 Washer, thrust 2	Buy now
60	9331543061 Bearing	Buy now
61	9310130M17 Oil seal (6e5)	Buy now
62	9321086M39 O-ring (6e5)	Buy now
63	6L64557700 Shim (t:0.10mm) UR	Buy now

Lower Casing & Drive 1




Ref	Part	
63	6L64557710 Shim (t:0.12mm) UR	Buy now
63	6L64557720 Shim (t:0.15mm) UR	Buy now
63	6L64557730 Shim (t:0.18mm) UR	Buy now
63	6L64557740 Shim (t:0.30mm) UR	Buy now
63	6L64557750 Shim (t:0.40mm) UR	Buy now
63	6L64557760 Shim (t:0.50mm) UR	Buy now
64	9020130M92 Washer (6g5)	Buy now
65	9028204010 Key, strait(663)	Buy now
66	6884538302 Washer, claw	Buy now
67	6884538402 Nut	Buy now

Lower Casing & Drive 2




Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	6E54436100 Tube, water L(20.3")	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9707510045 Bolt(64d)	Buy now
6	9299510600 Washer, plate	Buy now
7	9011910M89 Bolt, with washer	Buy now
8	6634537600 Guide, seal damper	Buy now
9	6884537500 Damper, seal 2	Buy now
10	6884521402 Cover, water inlet	Buy now
11	6884521502 Cover, water inlet	Buy now
12	9015205M07 Screw, countersunk	Buy now
13	9018505002 Nut nylon (sus)(ex4)	Buy now
14	6E54537101 Trim tab	Buy now
15	9010510M00 Bolt, hexagon (663)	Buy now

Lower Casing & Drive 2




Ref	Part	
16	9044507MF0 Hose (I1160)	Buy now
17	6E58355800 End, nipple	Buy now
18	9046511M10 Clamp	Buy now
20	6E54431200 Cover, water pump housing	Buy now
21	6E54598701 Spacer 1	Buy now
22	6884599701 Spacer 2	Buy now
23	9299018200 Washer (6e5)	Buy now
24	9017118M04 Nut, castle (6e5)	Buy now
25	9149040030 Pin, cotter (663)	Buy now
26	6E54594100 Propeller (3x13x19-k) UR	Buy now
26	6E54594300 Propeller (3x12-5/8"x21"-k) UR	Buy now
26	6884593002 Propeller (3x13x17) UR	Buy now
26	6884593260 Propeller (3x13-1/2"x14"-k) UR	Buy now
26	6884597003 Propeller (3x13"x19"-k) UR	Buy now
26	6884597202 Propeller (3x13"x21"-k) UR	Buy now

Lower Casing & Drive 2




Ref	Part	
26	6884597402 Propeller (3x13"x23"-k) UR	Buy now
26	6884597601 Propeller (ss 3x13"x25"-k) UR	Buy now
26	6884597860 Propeller (3x13-1/2"x16"-k) UR	Buy now
26	6E54594501 Propeller (3x13-1/4x17-k) UR	Buy now
26	6E54594700 Propeller (3x13-1/2x15-k) UR	Buy now
26	6E54594900 Propeller (3x13-5/8"x13"-k) UR	Buy now
26	6E54595200 Propeller (3x13"x23"-k) UR	Buy now
26	6E54595400 Propeller (3x14"x11"-k) UR	Buy now
26	6E54595600 Propeller (3x13"x25"-k) UR	Buy now
27	6E54597010 Propeller (ss 3x14"x20"-p) UR	Buy now
27	6E54597210 Propeller (ss 3x14"x24"-p) UR	Buy now
27	6E54597410 Propeller (ss 3x14"x28"-p) UR	Buy now
27	6E54597610 Propeller assembly (3x14"x22"-p) UR	Buy now
27	6E54597810 Propeller assembly (3x14"x26"-p) UR	Buy now
28	6E54537110 Tab-trim	Buy now

Lower Casing & Drive 2




Ref	Part	
29	6E54599410 Plate, tooth	Buy now

Meter




Ref	Part	
1	6Y58350T91 Tachometer assembly AP	Buy now
2	9E45004533 Housing, f-4-w(5pcs) F-4-W	Buy now
3	9299004100 Ybs67-4 washer, spring	Buy now
4	9538004600 Nut,hex	Buy now
5	6Y58355XT1 Bracket, meter 1	Buy now
6	6Y583570S6 Speedometer assembly AP	Buy now
9	6Y583533T2 Grommet	Buy now
11	6Y587122S0 Cord assembly 1 AP	Buy now
12	6Y583553M0 Wire, lead (l=2.5m) AP	Buy now
13	1E68215100 Fuse (10a)	Buy now
14	6Y58211700 Wire, lead AP	Buy now
15	6Y58365330 Wire, lead AP 4P,8M	Buy now
16	6Y58355710 Tube (8m) AP	Buy now
17	9046511M10 Clamp AP	Buy now

Oil Pump




Ref	Part	
1	6N61320000 Oil injection pump assembly	Buy now
2	6R31347100 Screw	Buy now
3	6L21347500 Gasket, breather bolt	Buy now
4	9321019MA7 O-ring(6r0)	Buy now
5	9010906M40 Bolt(6h0)	Buy now
6	9010906M39 Bolt(6h0)	Buy now
7	6N71341600 Pipe, oil 1	Buy now
8	9046511M10 Clamp	Buy now
9	9044507M89 Hose (l390)	Buy now
10	9044507196 Hose (l200)	Buy now
11	9044507M72 Hose (l390)	Buy now
12	6R31318310 Valve, check	Buy now
13	9044507M87 Hose(62t)	Buy now
14	9046407M06 Clamp (6e5)	Buy now
15	9046807M02 Clip (6e5)	Buy now

Oil Pump




Ref	Part	
16	6R31153700 Gear, driven	Buy now
17	6R31311700 Collar, distance	Buy now
18	9321013M04 93210-13m04	Buy now
19	9020208M44 Washer, plate(6r3)	Buy now
20	6R34124100 Rod, link	Buy now
21	6H14123700 Joint, link	Buy now
22	9538005600 Nut, hexagon (663)	Buy now
23	6R54123700 Joint, link	Buy now
24	9046805M03 Clip(6j8)	Buy now
25	9020205088 Washer, plate (666)	Buy now
26	6E51427601 Lever	Buy now
27	9169030016 Pin, spring	Buy now

Oil Tank




Ref	Part	
1	61A2170820 Sub oil tank assembly.	Buy now
2	6E52173320 Sub tank, oil (10.5l)	Buy now
3	6E52177003 Oil tank cap assembly	Buy now
4	6E52432200 Pipe 11	Buy now
5	9046511M10 Clamp	Buy now
6	6462425102 Strainer 1	Buy now
7	6E52431901 Pipe, oil	Buy now
9	6E58190001 Oil feed pump assembly	Buy now
10	6E58192200 Grommet	Buy now
11	6E52432101 Pipe 10	Buy now
12	6E52437900 Pipe, joint 4	Buy now
13	9044511M26 Hose (l8000)	Buy now
15	6E58572006 Oil level gauge assembly	Buy now
16	6R38572180 Wire, lead (4P)	Buy now
17	9046513M11 Clamp (6e5)	Buy now

Oil Tank




Ref	Part	
18	6E5217340133 Holder, oil sub tank	Buy now
19	6E5217980133 Bracket, damper	Buy now
20	6E52174600 Damper	Buy now
21	9708006100 Bolt, hexagon	Buy now
22	9299006600 Washer, plain (646)	Buy now
23	9538006600 Nut(661)	Buy now
24	6E52175005 Oil tank assembly	Buy now
25	6E51344800 Cap, oil tank	Buy now
27	6G78573005 Oil level gauge assembly	Buy now
28	6E51341100 Strainer, oil	Buy now
29	6E51341400 Gasket, strainer cover	Buy now
30	9044505M02 Hose (I700)	Buy now
31	6A08231700 Damper, ignition coil	Buy now
32	9038706119 Collar	Buy now
33	9011906M65 Bolt, with washer	Buy now

Oil Tank




Ref	Part	
34	64E2432300 Pipe 12	Buy now
35	9044512207 Hose (I3000)	Buy now
40	9046413M34 Clamp(6r3)	Buy now
41	6N78574000 Control unit assembly	Buy now
45	60H13437A0 Mark, caution	Buy now
46	60H85711A0 Mark, caution	Buy now
47	656W281002 Tool kit AP	Buy now
48	6N62819978D0 Manual,owner's UR (NL)	Buy now
48	6N62819978E0 Manual,owner's UR (E)	Buy now
48	6N62819978F0 Manual,owner's UR (F)	Buy now
48	6N62819978G0 Manual,owner's UR (D)	Buy now
48	6N62819978H0 Manual,owner's UR (I)	Buy now
48	6N62819978S0 Manual,owner's UR (ES)	Buy now
49	6N6281998FK0 Manual,Owner's UR (DK)	Buy now
49	6N6281998FL0 Manual,Owner's UR (SF)	Buy now

Oil Tank




Ref	Part	
49	6N6281998FM0 Manual,Owner's UR (S)	Buy now
49	6N6281998FN0 Manual,Owner's UR (N)	Buy now
49	6N6281998FP0 Manual,Owner's UR (P)	Buy now
49	6N6281998FR0 Manual,Owner's UR (GR)	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
1	64E4380008 Power trim & tilt assembly	Buy now
2	64E4382503 Housing, trim & tilt	Buy now
3	6AW4388J00 Plug 2	Buy now
4	9321010M74 O-ring	Buy now
5	64E4381700 Filter 2	Buy now
6	64E4381002 Tilt piston sub assembly	Buy now
7	64E4381102 Screw, cylinder end	Buy now
8	64E4389800 Seal, dust 2	Buy now
9	64E4386700 O-ring 7	Buy now
10	64E4386600 O-ring 6	Buy now
11	6E54386200 O-ring 2	Buy now
12	64E4388300 O-ring 10	Buy now
13	6E54387200 Ring, back-up 2	Buy now
14	6E54381402 Piston, free	Buy now
16	64E4382003 Trim piston sub assembly	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
17	64E4382103 Screw, trim cylinder end	Buy now
18	64E4382200 Seal, trim dust	Buy now
19	64E4384J00 Seal, trim down	Buy now
20	6G54386400 O-ring 4	Buy now
21	6E54386400 O-ring 4	Buy now
22	6E54387401 Ring, back-up 4	Buy now
23	64E4382801 Body, reservoir	Buy now
24	64E4382901 Plug, reservoir	Buy now
25	64E4389700 O-ring	Buy now
26	64E4388E01 Bolt ,screw (l:14mm)	Buy now
27	64E4386900 O-ring 9	Buy now
28	64E4381G00 Pin 1	Buy now
29	6E54385800 Ball 1	Buy now
30	64E4382G00 Valve seat	Buy now
31	64E4384N00 Plug, Orifice	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
32	9020110060 Washer, plate	Buy now
33	9757510530 Bolt, with washer	Buy now
34	6BC4381800 Pin, lower shock mount	Buy now
35	9038622M98 Bush(61u)	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
1	64E4388E11 Bolt ,screw (l:34.7mm)	Buy now
2	64E4383100 Connector, shaft	Buy now
3	64E4386800 O-ring 8	Buy now
4	64E4383001 Gear pump assembly	Buy now
5	72X4385800 Ball	Buy now
6	64E4384300 Screw, valve lock	Buy now
7	6AW4384100 Piston, shuttle	Buy now
8	64E4380200 Valve sub assembly	Buy now
9	6E54389600 O-ring	Buy now
10	6G54386300 O-ring 3	Buy now
11	64E4385100 Seat, Relief Valve	Buy now
12	64E4385800 Ball	Buy now
13	64E4385900 Pin, Valve Support	Buy now
14	64E4385500 Spring, up relief	Buy now
15	64E4385000 Valve sub assembly	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
16	64E4386500 O-ring 10	Buy now
17	64E4381600 Filter 1	Buy now
18	6AW4385800 Ball	Buy now
19	64E4381711 Filter 2	Buy now
20	64E4386001 Manual valve sub-assembly	Buy now
21	72X85075L0 O-ring (nsd161)	Buy now
22	64E4382700 Ring set	Buy now
23	64E4387A00 O-ring	Buy now
24	64E4387300 Ring, back up	Buy now
25	6AW4387500 Ring, snap	Buy now
26	64E4387911 Screw, with washer	Buy now
27	64E4387901 Screw, with washer	Buy now
28	64E4388004 Motor assembly	Buy now
29	6H14386K10 Spring, brush	Buy now
30	64E4380J00 Holder Brush	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
31	64E4389100 Brush 1	Buy now
32	9760704310 Screw, pan head(6g8)	Buy now
33	64E4380F00 Holder, brush 2	Buy now
34	64E4389200 Breaker comp. (brush 2)	Buy now
35	6G54386501 O-ring	Buy now
36	9310208M43 Oil seal(6b0)	Buy now
37	64E4380501 Armature assembly	Buy now
38	64E4384310 Screw valve lock	Buy now

Repair Kit 1




Ref	Part	
1	6N6W0001A5 Power head gasket kit	Buy now
2	6K71448300 Gasket	Buy now
3	6E514198A2 Gasket	Buy now
4	6E511381A2 Gasket 1	Buy now
5	6E511181A2 Gasket, cylinder head 1	Buy now
6	6E511193A0 Gasket, head cover 1	Buy now
7	68812414A1 Gasket, cover	Buy now
8	6E541112A1 Gasket, exhaust inner cover	Buy now
9	6E541114A0 Gasket, exhaust inner cover	Buy now
10	9310240M14 Oil seal (61a)	Buy now
11	9321104001 O-ring	Buy now
12	9310235M13 Oil seal (6e5)	Buy now
13	9310122M15 Oil seal (6e5)	Buy now
14	9321074M35 O-ring (6e5)	Buy now
15	6E513621A1 Gasket, valve seat	Buy now

Repair Kit 1




Ref	Part	
16	6E513645A1 Gasket, manifold 1	Buy now
17	64D1438401 Gasket, float chamber	Buy now
18	6G545113A2 Gasket, upper casing	Buy now
19	65024431A0 Gasket, fuel pump	Buy now
20	6E5W009309 Carburetor repair kit	Buy now
21	6E51415900 Clip	Buy now
23	6E51454600 Valve, needle	Buy now
24	6E51438602 Pin, float	Buy now
25	64D1439400 Valve, drain	Buy now
27	6E51439801 Gasket	Buy now
28	6E51432801 Plug	Buy now
29	6E51497900 Gasket	Buy now
30	6J81499500 Gasket, drain screw	Buy now
31	61U1495900 Gasket	Buy now

Repair Kit 2




Ref	Part	
1	6E5W0001F1 Gasket kit, lower unit	Buy now
2	6E541134A0 Gasket, exhaust manifold	Buy now
3	6G545114A1 Gasket, upper casing	Buy now
4	6E54512300 Gasket, muffler	Buy now
5	6E541135A0 Gasket, exhaust manifold	Buy now
6	6E54436500 Damper, water seal 1	Buy now
7	6E54436600 Damper, water seal 2	Buy now
8	9043008020 Gasket	Buy now
9	9321058144 O-ring(47x)	Buy now
10	9310609014 Oil seal	Buy now
11	9321086M38 O-ring (6e5)	Buy now
12	9321037160 O-ring (6g8)	Buy now
13	6E544315A0 Gasket,water pump	Buy now
14	9310128M16 Oil seal (6e5)	Buy now
15	9321055M14 O-ring (70e)	Buy now

Repair Kit 2




Ref	Part	
16	9321086M39 O-ring (6e5)	Buy now
17	9310130M17 Oil seal (6e5)	Buy now
18	6N6W007802 Water pump repair kit	Buy now
19	61A4432202 Insert, cartridge	Buy now
22	6E54435201 Impeller	Buy now
23	6E54432300 Outer plate, cartridge	Buy now
25	9360612019 Pin, dowel (614)	Buy now
26	9011908M14 Bolt, with washer	Buy now
27	9028004M05 Key, woodruff (6e5)	Buy now
28	6E5W00783A Chrome pump kit	Buy now
29	6R34432242 Insert, cartridge	Buy now
30	6E54432340 Outer plate, cartridge	Buy now

Starting Motor




Ref	Part	
1	6N78180010 Starting motor assembly	Buy now
2	6N78185010 Armature assembly	Buy now
3	61A8180900 Washer kit	Buy now
4	61A8182400 Washer 2	Buy now
5	6N78181000 Stator assembly	Buy now
6	6K78182G10 Bush, terminal	Buy now
7	6N78184000 Brush holder assembly	Buy now
8	6N78180100 Brush set	Buy now
9	6N78181300 Spring, brush	Buy now
10	6N78182010 Rear bracket assembly	Buy now
11	6N78180700 Gear assembly, starting motor	Buy now
12	6N78185700 Pinion stopper set	Buy now
13	6N78183000 Front bracket assembly	Buy now
14	6K78182611 Bolt	Buy now
15	6E58182E10 Washer, spring	Buy now

Starting Motor



Ref	Part	
16	6E58182F10 Washer,plain	Buy now
17	6E58182A10 Nut	Buy now
18	6E58182K10 Nut	Buy now
19	6R3818220094 Bracket, starting motor	Buy now
20	9011908M76 Bolt, with washer(6e5)	Buy now
21	9011908M77 Bolt, with washer(6e5)	Buy now
22	9011908M57 Bolt, with washer	Buy now
23	9299008600 Washer, plain (663)	Buy now
24	9709508016 Bolt, hexagon deep recess	Buy now
25	9299508600 Washer, plain (663)	Buy now


Steering Guide



67H0100-9290


Ref	Part	
1	6E56135002 Steering guide attachment kit AP	Buy now
2	6E56135101 Rod, steering link	Buy now
3	9038710M61 Collar (6e5)	Buy now
4	9056012M01 Spacer (6e5)	Buy now
5	6E56135500 Bolt	Buy now
6	9018509M01 Nut, nylon (663)	Buy now
7	9020110M20 Washer, plate (663)	Buy now
8	6E54314501 Cap, clamp bracket	Buy now
9	9321016275 O-ring	Buy now

Top Cowling




Ref	Part	
1	6N64261000 Top Cowling assembly	Buy now
2	6R34264700 Holder, clamp band	Buy now
3	9299006100 Washer(6a1)	Buy now
4	9538006600 Nut(661)	Buy now
5	6R34266200 Damper	Buy now
6	6R34281400 Hook, clamp	Buy now
7	9709506012 Bolt(gh1)	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	6N74261900 Damper, form	Buy now
10	6N74262700 Damper, form	Buy now
11	6N74261500 Seal	Buy now
12	6N742613008D Molding, air duct	Buy now
13	9017906M24 Nut(6j8)	Buy now
14	6N74263600 Louver, 2	Buy now
15	9299004600 Washer, plain (646)	Buy now

Top Cowling




Ref	Part	
16	9778040520 Ybs83-420 screw,panh,tapping	Buy now
17	6N64268640 Emblem, front	Buy now
18	6N64268730 Emblem, rear	Buy now
19	6N74267510 Graphic, side 1	Buy now
20	6884268140 Mark, cowling	Buy now
21	6N74267610 Graphic, side 2	Buy now
23	6N74264700 Holder, clamp band	Buy now

Upper Casing



Ref	Part	
1	6E545111028D Casing, upper L(20.3")	Buy now
2	6E54515500 Cap	Buy now
3	6E54276900 Seal, rubber	Buy now
4	9589506010 Bolt, flange(7ht)	Buy now
5	9360812M05 Pin, dowel b (6e5)	Buy now
6	9011908078 Bolt, with washer	Buy now
7	6G54113711CA Guide, exhaust FLUSHING KIT	Buy now
8	6E54272400 Grommet	Buy now
9	6G51258100 Joint, hose	Buy now
11	6G545113A2 Gasket, upper casing	Buy now
12	9011908M79 Bolt, hexagon (fj1)	Buy now
13	9011908077 Bolt, with washer	Buy now
14	9709508045 Bolt, hexagon	Buy now
15	9299508600 Washer, plain (663)	Buy now
16	9538008700 Nut(661)	Buy now

Upper Casing



Ref	Part	
17	9299508100 Ybs67-8 washer, spring	Buy now
18	6H11137200 Nipple, hose FLUSHING KIT	Buy now
19	6G54113101CA Manifold, ext. 1	Buy now
20	6G545114A1 Gasket, upper casing	Buy now
21	9709508030 Bolt, hexagon (fj1)	Buy now
23	6E54113210CA Manifold, exhaust	Buy now
24	6E541134A0 Gasket, exhaust manifold	Buy now
27	6E51471101CA Muffler 1	Buy now
28	6E51473700 Damper, muffler	Buy now
29	9018305M02 Nut, spring (6e5)	Buy now
30	6E54512300 Gasket, muffler	Buy now
31	6E541135A0 Gasket, exhaust manifold	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.