



Yamaha 130BETO 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	7
BRACKET 2	10
CARBURETOR	13
CONTROL	15
CRANKSHAFT. PISTON	19
CYLINDER. CRANKCASE 1	22
CYLINDER. CRANKCASE 2	24
ELECTRICAL 1	26
ELECTRICAL 2	28
FUEL 1	31
FUEL 2	34
GENERATOR	35
INTAKE	37
LOWER CASING. DRIVE 1	39
LOWER CASING. DRIVE 2	45
METER	49
OIL PUMP	51
OIL TANK	53
POWER TRIM & TILT ASSY 1	56
POWER TRIM & TILT ASSY 2	59
REMOTE CONTROL ASSY	62
REMOTE CONTROL BOX	67
REPAIR KIT 1	68
REPAIR KIT 2	70
STARTING MOTOR	72
STEERING GUIDE	74
TOP COWLING	75
UPPER CASING	77


Bottom Cowling



D5

Ref	Part	
1	6N7-42711-43-8D Cowling, bottom	Buy now
2	90169-05M00 Screw truss head tapping	Buy now
3	6H4-42748-00 Grommet	Buy now
4	6N7-42815-01-8D Lever, clamp	Buy now
5	90386-13M88 Bush(6r3)	Buy now
6	90206-13M10 Washer, wave (6e5)	Buy now
7	90109-08M45 Bolt(6r3)	Buy now
8	92990-08200 Ybs66-8 washer, plain	Buy now
9	6E5-44391-00 Nipple, hose	Buy now
10	6N7-42725-30 Grommet	Buy now
11	6N7-42738-02-5B Plate, fitting	Buy now
12	97095-06016 Bolt, hexagon deep recess	Buy now
13	92995-06600 Washer, plain (646)	Buy now
14	6R3-42824-00 Base, clamp lever	Buy now
15	6R3-42811-01 Stay	Buy now

Bottom Cowling




6N62300-3151

D5

Ref	Part	
16	6R3-42816-00 Lever, clamp	Buy now
17	6N7-42850-00 Wire, complete	Buy now
18	6R3-42811-10 Stay	Buy now
19	6N7-42850-10 Wire, complete	Buy now
20	6N7-42850-20 Wire, complete	Buy now
21	6R3-42813-00 Spring, clamp lever	Buy now
24	6N7-42828-00 Plate, clamp	Buy now
25	6R3-42828-00 Plate, clamp	Buy now
26	97095-06010 Bolt	Buy now
28	688-42726-10 Grommet	Buy now
29	6N7-42741-01-8D Apron	Buy now
30	6R3-42771-01-8D Apron	Buy now
31	97095-06020 Bolt(7u8)	Buy now
33	90480-22M15 Grommet (6e5)	Buy now
34	90387-08M37 Coller (6e5)	Buy now

Bottom Cowling




6N62300-3151

D5

Ref	Part	
35	90201-08M54 Washer, plate (6e5)	Buy now
36	97075-08035 Bolt(70w)	Buy now
37	90119-08M22 Bolt, with washer	Buy now
40	6E5-24367-10 Clamp, fuel pipe 2	Buy now
41	90157-06M01 Screw (6e5)	Buy now
42	92990-06600 Washer, plain (646)	Buy now
43	6E5-42716-00 Seal	Buy now
44	6K7-82588-00 Plate	Buy now
45	6E5-82588-00 Plate	Buy now
48	688-82594-00 Clamp	Buy now
49	6E5-82594-00 Clamp	Buy now
50	90465-12M25 Clamp (6e5)	Buy now
51	97095-06012 Bolt(gh1)	Buy now
53	6R3Y125J70 Flushing kit	Buy now
54	6R31257200 Adapter	Buy now


Bottom Cowling



D5


Ref	Part	
55	6R31258000 Joint assembly	Buy now
56	9044511M35 Hose (I700)	Buy now
57	9046511M10 Clamp	Buy now
59	6G54279110 Mark 1	Buy now
59	6K74279100 Mark 1	Buy now
60	6A12817600 Label Caution	Buy now
61	6E38257H00 Plate Mark	Buy now

Bracket 1




Ref	Part	
1	64E-43111-02-8D Bracket, clamp	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06030 Bolt(jf7)	Buy now
5	92995-06100 Washer(6a1)	Buy now
6	6E5-82148-00 Wire, lead 5	Buy now
7	97095-06010 Bolt	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	64E-43112-02-8D Bracket, clamp	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	92990-06600 Washer, plain (646)	Buy now
13	93700-06M03 Nipple, grease(6a1)	Buy now
14	663-45119-00 Cap, grease nipple AP	Buy now
15	64E-43131-01 Bolt, clamp bracket	Buy now
16	97095-08020 Bolt, hexagon	Buy now

Bracket 1



Ref	Part	
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	90386-25M31 Bushing (6e5)	Buy now
19	90201-26M59 Washer, plate (6e5)	Buy now
20	90185-22M11 Nut, self-locking	Buy now
21	90465-11M10 Clamp	Buy now
22	64E-43311-10-8D Bracket, swivel L	Buy now
23	90465-08M63 Clamp(61u)	Buy now
26	6E5-82147-00 Wire, lead 5 L	Buy now
27	6G5-43144-00 Hook, spring	Buy now
29	6G5-43181-02 Lever, tilt stop 1	Buy now
30	6G5-43185-02 Lever, tilt stop 2	Buy now
31	90386-10M16 Bushing (688)	Buy now
32	6G5-43148-00 Collar, distance	Buy now
33	90249-06M19 Pin(6e5)	Buy now
34	90387-10M05 Collar(6e5)	Buy now

Bracket 1




6N60010-7160

E4


Ref	Part	
35	91690-30020 Pin, spring (6h4)	Buy now
36	90506-14M24 Spring, tension(6e5)	Buy now
37	64E-43126-00 Pin, upper shock mount	Buy now
38	90386-22M98 Bush(61u)	Buy now
39	93410-22M11 Circlip(61u)	Buy now
40	90101-12M03 Bolt (l:115mm)	Buy now
41	90201-13M01 Washer, plate(6e5)	Buy now
42	90201-12M05 Washe, plate(663)	Buy now
43	95380-12600 Nut (707)	Buy now

Bracket 2



Ref	Part	
1	64E-43139-02 Cam, trim sender (with screw)	Buy now
2	97780-60525 Screw, tapping(65j)	Buy now
3	64E-83672-02 Trim sender	Buy now
4	97885-06016 Screw, pan head(6b0)	Buy now
5	90465-11M10 Clamp	Buy now
6	93210-37MH7 O-ring(61u)	Buy now
7	90202-40M47 Washer, plate(61a)	Buy now
8	61A-43376-00 Bolt, thrust receiver	Buy now
9	95780-10300 Nut, nylon (6e5)	Buy now
10	6E5-42510-A1-8D Steering bracket assembly L	Buy now
11	90201-38M60 Washer, plate (6e5)	Buy now
12	90386-38M32 Bush(6e5)	Buy now
13	6G5-44551-01-8D Housing, lower mount rubber	Buy now
14	93410-37M04 Circlip (6e5)	Buy now
15	6E5-44575-00 Damper, lower mount rubber	Buy now


Bracket 2



E6


Ref	Part	
16	6E5-44555-00-94 Mount damper, lower side	Buy now
17	90202-32M19 Washer, plate (6e5)	Buy now
18	90201-16M55 Washer, plate (6e5)	Buy now
19	6E5-82149-00 Wire, lead 3	Buy now
20	90109-14M34 Bolt(6e5)	Buy now
21	90201-15M58 Washer, plate (6e5)	Buy now
22	95380-14800 Nut, crown (6e5)	Buy now
23	92995-14600 Washer (6e5)	Buy now
24	6E5-44552-01-94 Housing, lower mount rubber	Buy now
25	97095-10045 Bolt(64d)	Buy now
26	92995-10100 Ybs67-10 washer, spring	Buy now
27	6E5-44553-01-8D Cover, lower mount	Buy now
28	90501-16M28 Spring (6e5)	Buy now
30	90179-06066 Nut(663)	Buy now
31	6E5-44514-00-94 Mount damper, upper side	Buy now

Bracket 2




Ref	Part	
32	90201-26M57 Washer, plate (6e5)	Buy now
33	90202-26M18 Washer, plate (6e5)	Buy now
34	90201-14M56 Washer, plate (6e5)	Buy now
35	90109-12M37 Bolt	Buy now
36	90185-12M12 Nut, self-locking(6e5)	Buy now
37	663-44575-00 Damper, lower mount rubber	Buy now
38	6E5-44511-00-5B Cover, upper mount	Buy now

Carburetor




 FWD
6N60010-4060



B5

Ref	Part	
1	.GASKET -	Buy now
1	6E5-14301-16 Carburetor assembly 1	Buy now
1	6L1-14301-04 Carburetor assembly 1	Buy now
2	6E5-14302-16 Carburetor assembly 2	Buy now
2	6L1-14302-04 Carburetor assembly 2	Buy now
3	64D-14384-01 Gasket, float chamber	Buy now
4	64D-14381-00 Body, float chamber	Buy now
5	6E5-14385-02 Float	Buy now
6	6E5-14546-00 Valve, needle	Buy now
7	6E5-14159-00 Clip	Buy now
8	6E5-14386-02 Pin, float	Buy now
9	64D-1492F-39 Jet, air slow (#78)	Buy now
9	64D-1492F-41 Jet, air slow (#82)	Buy now
10	61U-14959-00 Gasket	Buy now
11	64D-14394-00 Valve, drain	Buy now


Carburetor



B5

Ref	Part	
12	64D-1492E-88 Jet, main (#176)	Buy now
12	64D-1492E-90 Jet, main (#180)	Buy now
14	61A-1492H-12 Jet, slow air (#60)	Buy now
15	61A-14383-01 Screw, drain	Buy now
16	6E5-14321-00 Screw, throttle #2	Buy now
17	6J8-14334-00 Spring, throttle #2	Buy now
18	6E5-14328-01 Plug	Buy now
19	6E5-14979-00 Gasket	Buy now
20	6E5-14323-03 Screw, air adjusting	Buy now
21	6E5-14223-00 Spring, air adjusting	Buy now
22	97980-05116 Screw, pan head	Buy now
23	6E5-14527-01 Plate	Buy now
24	97980-05108 Screw, with washer	Buy now
25	6E5-14324-00 Screw, flat head	Buy now
26	6J8-14959-00 Gasket, drin screw	Buy now


Control



6N60010-0151


E1

Ref	Part	
1	6E5-48531-00 Bracket, remote control	Buy now
2	6E5-48538-00 Clamp, cable	Buy now
3	91690-30012 Pin, spring	Buy now
4	97095-08020 Bolt, hexagon	Buy now
5	92995-08100 Ybs67-8 washer, spring	Buy now
6	6E5-41632-02-1S Lever, magneto control	Buy now
7	6E5-48344-00 Cable end, remote control	Buy now
8	92990-06200 Ybs66-6 washer, plain	Buy now
9	90185-06M07 Nut, self-locking(6e5)	Buy now
10	6E5-41631-01-1S Lever, magneto control	Buy now
11	90157-06013 Screw, pan head(697)	Buy now
12	90501-16M12 Spring, compression (688)	Buy now
13	95303-06600 Nut(661)	Buy now
14	688-44194-00 Cap	Buy now
15	97013-08045 Bolt	Buy now




E1

Ref	Part	
16	90201-08M23 Washer, plate (6e5)	Buy now
17	90386-12089 Bushing(663)	Buy now
18	90387-08M16 Collar	Buy now
19	90386-22M13 Bushing (688)	Buy now
20	90202-12092 Washer, plate(663)	Buy now
21	90201-08M13 Washer plate (682)	Buy now
22	90508-29M12 Spring (6e5)	Buy now
23	6E5-41636-01 Rod, magneto control	Buy now
24	95380-05600 Nut, hexagon (663)	Buy now
25	662-41237-01 Joint, link	Buy now
29	688-41636-00 Rod 1	Buy now
32	6E5-41213-00 Cam, accel.	Buy now
33	90387-06M29 Coller (6a0)	Buy now
34	90206-10M04 Washer, wave (676)	Buy now
35	97095-06025 Bolt	Buy now



E1


Ref	Part	
36	6E5-44117-00-1S Bracket	Buy now
37	90119-06MA2 Bolt, with washer	Buy now
38	68F-44121-00 Lever, shift rod	Buy now
39	6E5-44122-00 Bushing, shift rod lever	Buy now
40	90202-08M20 Washer, plate (6e5)	Buy now
41	90468-18008 Clip 620436610000	Buy now
43	90386-06M12 Bushing (688)	Buy now
44	6E5-44118-01-94 Bracket 2	Buy now
45	97013-08030 Bolt	Buy now
46	92903-08600 Washer, plain (663)	Buy now
47	93501-04M02 Ball (697)	Buy now
48	90501-12082 Spring 6484411600	Buy now
49	648-42715-00 Bushing 2	Buy now
50	93700-06M03 Nipple, grease(6a1)	Buy now
51	6E5-44120-03 Handle gear shift assembly L	Buy now



E1

Ref	Part	
52	93210-09165 O-ring	Buy now
53	90386-16M66 Bush(6e5)	Buy now
54	90202-16061 Washer, plate(663)	Buy now
55	93410-16006 Circlip	Buy now

Crankshaft. Piston




6N42100-403C

A6

Ref	Part	
1	6N7-11411-01 Crankshaft	Buy now
2	6E5-11447-00 Seal, ring	Buy now
3	6R3-15163-00-1S Housing, bearing 1	Buy now
4	93311-940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	93102-40M14 Oil seal(61a)	Buy now
6	93211-04001 O-ring	Buy now
7	90119-06MA2 Bolt, with washer	Buy now
8	93310-954U1 Bearing, cylindrical(64c)	Buy now
9	6R3-11536-00 Gear, drive	Buy now
10	93306-208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	93410-40M03 Circlip(n02)	Buy now
12	6G5-15359-00-94 Housing, oil seal	Buy now
13	93102-35M13 Oil seal (6e5)	Buy now
14	93101-22M15 Oil seal (6e5)	Buy now
15	93210-74M35 O-ring (6e5)	Buy now


Crankshaft. Piston



Ref	Part	
17	6R5-11631-11-93 Piston (std)	Buy now
17	6R5-11635-11 Piston (0.25mm o/s) AP	Buy now
17	6R5-11636-11 Piston (0.50mm o/s) AP	Buy now
18	64D-11603-01 Piston ring set (std)	Buy now
18	64D-11604-01 Piston ring set (0.25mm o/s) AP	Buy now
18	64D-11605-01 Piston ring set (0.50mm o/s) AP	Buy now
19	6R5-11642-11-93 Piston 2 (std)	Buy now
19	6R5-11645-11 Piston 2 (0.25mm o/s) AP	Buy now
19	6R5-11646-11 Piston 2 (0.50mm o/s) AP	Buy now
21	6R5-11633-10 Pin, piston	Buy now
22	6R5-11634-10 Clip, piston pin	Buy now
23	6R5-11650-10 Connecting kit	Buy now
24	90109-08022 Bolt	Buy now
25	93310-323V6 Bearing	Buy now
26	90201-23M01 Washer, plate(6g6)	Buy now


Crankshaft. Piston

Ref	Part	
27	93310-836U0 Bearing, cylindrical(61u)	Buy now



A6


Cylinder. Crankcase 1



A5

Ref	Part	
3	624-11379-00 Valve, check	Buy now
4	663-11518-01 Lock, bearing	Buy now
5	6E5-11372-01 Nipple, hose	Buy now
6	90340-14M00 Plug, straight screw(62y)	Buy now
7	90430-14115 Gasket (663)	Buy now
8	90384-06M07 Bush, bimetal formed(6r3)	Buy now
9	90384-14M09 Bush, bimetal formed(6r3)	Buy now
10	93608-12063 Pin, dowel (626)	Buy now
11	90105-10M20 Bolt (6e5)	Buy now
12	90119-08M94 Bolt, with washer	Buy now
13	90116-08M45 Bolt, stud (6e5)	Buy now
14	6E5-11325-00 Anode	Buy now
15	98780-04015 Screw, flat head(ga5)	Buy now
16	6E5-11119-01 Hanger, engine	Buy now
17	90119-08MA3 Bolt, with washer	Buy now

Cylinder. Crankcase 1




6N62300-3020

Ref	Part	
20	68F-44533-00 Damper, upper mount rubber	Buy now
21	90119-06MA2 Bolt, with washer	Buy now
23	6E5-11381-A2 Gasket 1	Buy now
25	90465-06M86 Clamp	Buy now

A5


Cylinder. Crankcase 2



B1


Ref	Part	
1	6E5-11111-10-1S Head, cylinder 1	Buy now
1	6L1-11111-00-1S Head, cylinder 1	Buy now
2	6E5-11181-A1 Gasket, cylinder head 1	Buy now
3	90119-08MA8 Bolt, with washer	Buy now
4	6E5-11191-01-1S Cover, cylinder head 1	Buy now
5	6E5-11193-A0 Gasket, head cover 1	Buy now
6	90119-06MA4 Bolt, with washer	Buy now
7	6E5-12411-30 Thermostat	Buy now
8	6G5-12413-00-1S Cover, thermostat	Buy now
9	688-12414-A1 Gasket, cover	Buy now
10	90119-06MA6 Bolt, with washer	Buy now
11	6E5-41111-00-1S Inner cover, exhaust	Buy now
11	6L1-41111-00-1S Inner cover, exhaust	Buy now
12	6E5-41112-A1 Gasket, exhaust inner cover	Buy now
14	6N7-41113-00-1S Outer cover, exhaust	Buy now

Cylinder. Crankcase 2



B1

Ref	Part	
15	650-24378-00 Pipe, joint 2	Buy now
16	6E5-24312-00 Pipe 2	Buy now
17	90467-08004 Clip, pipe 6162435600	Buy now
18	90119-06MA5 Bolt, with washer	Buy now
19	6G5-12416-00 Valve, pressure control	Buy now
20	90501-16M11 Spring, compression (688)	Buy now
21	90480-20M05 Grommet (688)	Buy now
22	6G5-11382-A1 Gasket 2	Buy now
23	6G5-11372-00-1S Cover, bypass 2	Buy now
24	90119-06MA2 Bolt, with washer	Buy now
25	6E5-12576-00 Hose 1	Buy now
26	90465-13M18 Clamp	Buy now
27	94702-00247 Plug, spark (br8hs-10)	Buy now
27	94702-00309 Plug, spark (br9hs-10)	Buy now




6N60010-4110

D1

Ref	Part	
1	6N7-85542-01-1S Bracket	Buy now
2	6A0-82317-00 Damper, ignition coil	Buy now
3	624-42542-00 Collar	Buy now
4	90119-06M59 Bolt, with washer	Buy now
5	6N7-85540-01 C.d.i. unit assembly	Buy now
6	97880-06020 Screw pan head	Buy now
7	92990-06600 Washer, plain (646)	Buy now
8	6N7-85537-00 Cover	Buy now
9	90159-06M11 Screw, with washer(612)	Buy now
10	6N7-81948-00-94 Bracket	Buy now
11	97013-06016 Bolt, hexagon deep recess	Buy now
12	92903-06600 Washer, plain (646)	Buy now
13	6R3-81960-00 Rectifier & regulator assembly	Buy now
14	97013-06025 Bolt(62y)	Buy now
16	6R3-81942-00 Cover	Buy now

Electrical 1


Ref	Part	
17	90159-06M08 Screw, with washer(6k7)	Buy now
18	97013-06012 Bolt(gh1)	Buy now



6N60010-4110

D1


Electrical 2



D2

Ref	Part	
1	6R3-85570-01 Ignition coil assembly	Buy now
2	97095-06020 Bolt(7u8)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	6G1-82370-21 Plug cap assembly	Buy now
5	662-82519-00 Wire, earth lead	Buy now
6	97095-06012 Bolt(gh1)	Buy now
8	61A-81941-00 Starter relay assembly	Buy now
9	689-81952-10 Holder, starter relay	Buy now
10	6E5-81950-00 Relay assembly	Buy now
11	6E5-8195A-00 Relay assembly	Buy now
12	6G5-87149-10 Connector	Buy now
13	6G5-82119-00 Cover, lead wire	Buy now
14	6E5-82116-00 Wire, minus lead	Buy now
15	6E5-81948-22 Bracket	Buy now
16	97095-06016 Bolt, hexagon deep recess	Buy now


Electrical 2




D2

Ref	Part	
18	6N7-83557-00 Tube I.DIA.) 22MM	Buy now
19	90465-13M18 Clamp	Buy now
20	6N7-86110-00 Solenoid	Buy now
21	6N7-86116-00 Wire, pull	Buy now
22	91609-30010 Pin, spring (663)	Buy now
23	97095-06030 Bolt(jf7)	Buy now
25	6N7-86112-00 Stay, solenoid	Buy now
26	93210-03261 O-ring (663)	Buy now
27	688-82560-10 Thermo switch assembly	Buy now
28	90465-05M87 Clamp	Buy now
29	90465-08M89 Clamp	Buy now
30	6N7-82590-14 Wire Harness assembly	Buy now
31	663-82151-00 Fuse	Buy now
32	705-82151-00 Fuse (30a)	Buy now
33	6G5-82152-00 Holder, fuse	Buy now

Electrical 2




Fuel 1



C4

Ref	Part	
1	6R3-24313-20 Pipe 3	Buy now
2	6R3-24377-00 Pipe, joint 3	Buy now
3	90465-11M10 Clamp	Buy now
5	6R3-24560-00 Filter assembly	Buy now
6	61N-24563-00 Element, filter	Buy now
7	61N-24521-00 Cup, filter	Buy now
8	93210-32738 O-ring(1wg)	Buy now
9	6E5-24566-00 Bracket, filter	Buy now
10	97013-06014 Bolt(gj3)	Buy now
11	92903-06100 Washer(6a1)	Buy now
12	95380-08600 Nut (661)	Buy now
13	6E5-24314-00 Pipe 4	Buy now
16	6E5-24410-03 Fuel pump assembly	Buy now
17	6E5-24444-00 Screw	Buy now
18	6E5-24413-00 Body 2	Buy now


Fuel 1



C4

Ref	Part	
19	6E5-24471-00 Diaphragm	Buy now
20	6E5-24435-00 Gasket, body 2	Buy now
21	6E5-24411-00 Diaphragm	Buy now
22	648-24424-00 Seat,spring	Buy now
23	6E5-24423-00 Spring, diaphragm	Buy now
24	6E5-24434-02 Gasket, body	Buy now
25	6A0-24421-01 Valve, check	Buy now
26	6A0-14325-00 Screw, pan head	Buy now
27	95380-03600 Nut (6g8)	Buy now
28	6E5-24412-10 Body 1	Buy now
29	650-24431-A0 Gasket,fuel pump	Buy now
30	97095-06050 Bolt(jf7)	Buy now
31	92995-06600 Washer, plain (646)	Buy now
32	6G5-24316-10 Pipe 6	Buy now
35	6E5-24376-10 Pipe, joint 1	Buy now


Fuel 1



Ref	Part	
36	6G5-24318-10 Hose (I90)	Buy now
37	6G5-24319-10 Pipe 9	Buy now
40	90446-15M07 Hose(6g4)	Buy now

C4

Fuel 2




6N61300-2100

C6

Ref	Part	
1	6YK-24307-42 Fuel pipe comp. 2 AP	Buy now
2	90450-10M07 Hose, clamp AP	Buy now


Generator



C7

Ref	Part	
1	6N7-85550-00 Rotor assembly	Buy now
2	6N7-85510-00 Stator assembly	Buy now
3	6E5-85580-00 Coil, pulser	Buy now
4	90280-05015 Key, woodruff	Buy now
5	90201-21M18 Washer, plate (663)	Buy now
6	90170-20137 Nut, hexagon(663)	Buy now
7	97013-06065 Bolt(62j)	Buy now
8	92903-06600 Washer, plain (646)	Buy now
9	688-41611-00 Retainer, magneto base 1	Buy now
10	688-41612-00 Retainer, magneto base 2	Buy now
11	97880-06018 Screw, pan head(6e5)	Buy now
12	90464-12M00 Clamp	Buy now
13	6E5-81332-00 Plate, timing	Buy now
14	97885-06010 Screw pan head	Buy now
15	92995-06600 Washer, plain (646)	Buy now

Generator




6N61300-2110

C7

Ref	Part	
16	6N7-81337-00 Cover, flywheel	Buy now
17	90480-12M11 Grommet (6a0)	Buy now
18	663-82317-01 Damper, ignition coil	Buy now
19	6A1-83625-51 Mark 5	Buy now
20	6A1-83625-41 Mark 5	Buy now
21	6E5-14488-00 Label, caution	Buy now


Intake



B3

Ref	Part	
1	6E5-13610-00 Reed valve assembly	Buy now
2	6E5-W0004-00 Reed set	Buy now
3	6E5-13621-A1 Gasket, valve seat	Buy now
4	97880-05025 Screw, panhead (a93)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
6	6E5-13641-11-1S Manifold 1	Buy now
7	6E5-13552-00 Nozzle	Buy now
8	624-14485-00 Pipe, joint	Buy now
9	6E5-11370-01 Check valve assembly	Buy now
10	90445-07M28 Hose (l200)	Buy now
11	90445-07M24 Hose (l390)	Buy now
12	90445-07M46 Hose (l390)	Buy now
13	90116-06M30 Bolt, stud(6e5)	Buy now
14	6E5-13645-A1 Gasket, manifold 1	Buy now
15	90119-06MA3 Bolt, with washer	Buy now


Intake



B3

Ref	Part	
16	90465-06M86 Clamp	Buy now
17	97095-06012 Bolt(gh1)	Buy now
18	92995-06600 Washer, plain (646)	Buy now
19	6E5-14198-A2 Gasket	Buy now
20	90179-06M28 Nut(63v)	Buy now
21	6E5-41217-01 Rod, accel. lever	Buy now
22	6E5-41256-01 Rod, choke 1	Buy now
23	661-41262-02 Joint, choke lever	Buy now
24	6N7-41271-00 Knob, choke	Buy now
25	689-41273-00 Grommet	Buy now
26	6N7-14440-01 Silencer assembly, intake	Buy now
27	6E5-1441K-00 Emblem 1	Buy now
28	90445-07258 Hose (I390)	Buy now
29	6K7-14483-00 Gasket	Buy now
30	90159-06M14 Screw, with washer(6r3)	Buy now


Lower Casing. Drive 1



F7

Ref	Part	
1	6E5-45300-17-8D Lower unit assembly L	Buy now
2	6E5-45301-05-8D Casing, lower	Buy now
3	93315-628U9 Brg,cyl-cal roller (6e5)	Buy now
4	93332-000U7 Brg,tapered roller 76mm (6e5)	Buy now
5	6E5-45567-01-10 Shim (t:0.10mm) UR	Buy now
5	6E5-45567-01-12 Shim (t:0.12mm) UR	Buy now
5	6E5-45567-01-15 Shim (t:0.15mm) UR	Buy now
5	6E5-45567-01-18 Shim (t:0.18mm) UR	Buy now
5	6E5-45567-01-30 Shim (t:0.30mm) UR	Buy now
5	6E5-45567-01-40 Shim (t:0.40mm) UR	Buy now
5	6E5-45567-01-50 Shim (t:0.50mm) UR	Buy now
6	90340-08002 Plug, straight screw	Buy now
7	688-45341-10 Plug, drain	Buy now
8	90430-08020 Gasket	Buy now
9	6E5-45536-00 Sleeve, drive shaft	Buy now


Lower Casing. Drive 1



F7


Ref	Part	
10	6E5-45378-00 Nipple, hose	Buy now
11	90445-07ME8 Hose (I250) L	Buy now
12	6E5-83558-10 End, nipple	Buy now
13	6E5-45321-00 Plate	Buy now
14	93210-58144 O-ring(47x)	Buy now
15	93106-09014 Oil seal	Buy now
16	90119-06M10 Bolt, with washer	Buy now
17	6E5-44150-02 Shift cam assembly	Buy now
18	99001-08600 Circlip(2r6)	Buy now
19	90501-11M10 Spring, compression (663)	Buy now
20	61A-45538-00 Spacer, 1	Buy now
21	90201-22M01 Washer, plate(61a)	Buy now
22	90206-22M19 Washer, wave(61a)	Buy now
23	61A-45527-00 Collar, drive shaft	Buy now
24	61A-44311-01 Housing, water pump	Buy now

Lower Casing. Drive 1




Ref	Part	
25	61A-44322-02 Insert, cartridge	Buy now
26	93210-86M38 O-ring (6e5)	Buy now
27	93210-37160 O-ring (6g8)	Buy now
28	6E5-44352-01 Impeller	Buy now
29	90280-04M05 Key, woodruff (6e5)	Buy now
30	6E5-44323-00 Outer plate, cartridge	Buy now
31	6E5-44315-A0 Gasket,water pump	Buy now
32	93606-12019 Pin, dowel (614)	Buy now
33	90119-08M14 Bolt, with washer	Buy now
34	6E5-45331-00-94 Housing, bearing	Buy now
35	93101-28M16 Oil seal (6e5)	Buy now
36	93317-330U2 Bearing, cylindrical(6k0)	Buy now
37	6E5-45587-01-10 Shim (t:0.10mm) UR	Buy now
37	6E5-45587-01-12 Shim (t:0.12mm) UR	Buy now
37	6E5-45587-01-15 Shim (t:0.15mm) UR	Buy now

Lower Casing. Drive 1



Ref	Part	
37	6E5-45587-01-18 Shim (t:0.18mm) UR	Buy now
37	6E5-45587-01-30 Shim (t:0.30mm) UR	Buy now
37	6E5-45587-01-40 Shim (t:0.40mm) UR	Buy now
37	6E5-45587-01-50 Shim (t:0.50mm) UR	Buy now
38	93341-930V2 Bearing, thrust(64d)	Buy now
39	93210-55M14 O-ring (70e)	Buy now
40	6E5-45344-00 Cover, oil seal	Buy now
41	97095-08025 Bolt (62g)	Buy now
42	92995-08600 Washer, plain (663)	Buy now
43	6E5-45501-01 Drive shaft comp. L	Buy now
44	6E5-45551-02 Pinion	Buy now
45	90170-16M01 Nut, hexagon (688)	Buy now
46	6E5-45560-01 Gear 1 assembly	Buy now
47	93315-425U7 Brg,cyl-cal roller (6e5)	Buy now
48	6E5-45611-01 Shaft, propeller	Buy now


Lower Casing. Drive 1



F7

Ref	Part	
49	6E5-45641-02 Shifter	Buy now
50	6E5-45634-01 Slide, shift	Buy now
51	90501-16M37 Spring (6g5)	Buy now
52	93507-32009 Ball (12r)	Buy now
53	93511-32017 Ball (498)	Buy now
54	93503-16003 Ball	Buy now
55	90250-08M07 Pin, straight (6g5)	Buy now
56	6E5-45631-01 Clutch, dog	Buy now
57	6E5-45633-01 Ring, cross pin	Buy now
58	6E5-45332-00-94 Housing, bearing	Buy now
59	93306-208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
60	6E5-45571-01 Gear 2	Buy now
61	6E5-45576-00 Washer, thrust 2	Buy now
62	93315-430U8 Bearing	Buy now
63	93101-30M17 Oil seal (6e5)	Buy now


Lower Casing. Drive 1



F7


Ref	Part	
64	93210-86M39 O-ring (6e5)	Buy now
65	6L6-45577-00-10 Shim (t:0.10mm) UR	Buy now
65	6L6-45577-00-12 Shim (t:0.12mm) UR	Buy now
65	6L6-45577-00-15 Shim (t:0.15mm) UR	Buy now
65	6L6-45577-00-18 Shim (t:0.18mm) UR	Buy now
65	6L6-45577-00-30 Shim (t:0.30mm) UR	Buy now
65	6L6-45577-00-40 Shim (t:0.40mm) UR	Buy now
65	6L6-45577-00-50 Shim (t:0.50mm) UR	Buy now
66	90201-30M92 Washer (6g5)	Buy now
67	90282-04010 Key, strait(663)	Buy now
68	688-45383-02 Washer, claw	Buy now
69	688-45384-00 Nut	Buy now

Lower Casing. Drive 2



Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	6E5-44361-00 Tube, water L	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97075-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	90119-10M89 Bolt, with washer	Buy now
8	663-45376-00-94 Guide, seal damper	Buy now
9	688-45375-00 Damper, seal 2	Buy now
10	688-45214-02 Cover, water inlet	Buy now
11	688-45215-02 Cover, water inlet	Buy now
12	90152-05M07 Screw, countersunk	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now
14	6E5-45371-01 Trim tab	Buy now
15	90105-10M00 Bolt, hexagon (663)	Buy now


Lower Casing. Drive 2



A7

Ref	Part	
16	90445-07MFO Hose (I1160)	Buy now
17	6E5-83558-00 End, nipple	Buy now
18	90465-11M10 Clamp	Buy now
20	6E5-44312-00 Cover, water pump housing	Buy now
21	6E5-45987-01 Spacer 1	Buy now
22	688-45997-01 Spacer 2	Buy now
23	92990-18200 Washer (6e5)	Buy now
24	90171-18M04 Nut, castle (6e5)	Buy now
25	91490-40030 Pin, cotter (663)	Buy now
26	6E5-45941-00-EL Propeller (3x13x19-k) UR	Buy now
26	6E5-45943-00-EL Propeller (3x12-5/8"x21"-k) UR	Buy now
26	688-45930-02-98 Propeller (3x13x17) UR	Buy now
26	688-45932-60-98 Propeller (3x13-1/2"x14"-k) UR	Buy now
26	688-45970-03-98 Propeller (3x13"x19"-k) UR	Buy now
26	688-45972-02-98 Propeller (3x13"x21"-k)	Buy now


Lower Casing. Drive 2



Ref	Part	
26	688-45974-02-98 Propeller (3x13"x23"-k) UR	Buy now
26	688-45976-01-98 Propeller (ss 3x13"x25"-k) UR	Buy now
26	688-45978-60-98 Propeller (3x13-1/2"x16"-k) UR	Buy now
26	6E5-45945-01-EL Propeller (3x13-1/4x17-k) UR	Buy now
26	6E5-45947-00-EL Propeller (3x13-1/2x15-k) UR	Buy now
26	6E5-45949-00-EL Propeller (3x13-5/8"x13"-k) UR	Buy now
26	6E5-45952-00-EL Propeller (3x13"x23"-k) UR	Buy now
26	6E5-45954-00-EL Propeller (3x14"x11"-k) UR	Buy now
26	6E5-45956-00-EL Propeller (3x13"x25"-k) UR	Buy now
27	6E5-45970-10 Propeller (ss 3x14"x20"-p) UR	Buy now
27	6E5-45972-10 Propeller (ss 3x14"x24"-p) UR	Buy now
27	6E5-45974-10 Propeller (ss 3x14"x28"-p) UR	Buy now
27	6E5-45976-10 Propellar assembly (3x14"x22"-p) UR	Buy now
27	6E5-45978-10 Propeller assembly (3x14"x26"-p) UR	Buy now
28	6E5-45371-10 Tab-trim	Buy now


Lower Casing. Drive 2

Ref	Part	
29	6E5-45994-10 Plate, tooth	Buy now




A7

Meter



Ref	Part	
1	6Y5-8350T-02 Digital tachometer assembly AP	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83500-S5 Meter assembly AP	Buy now
7	6Y5-83570-S5 Speedometer assembly	Buy now
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
20	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a)	Buy now
17	6Y5-82117-00 Wire, lead AP	Buy now

Meter




61A1700-2290

Ref	Part	
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now

B7


Oil Pump



B7

Ref	Part	
1	6N6-13200-00 Oil injection pump assembly	Buy now
1	6N7-13200-00 Oil injection pump assembly	Buy now
2	6R3-13471-00 Screw	Buy now
3	6L2-13475-00 Gasket, breather bolt	Buy now
4	93210-19MA7 O-ring(6r0)	Buy now
5	90109-06M40 Bolt(6h0)	Buy now
6	90109-06M39 Bolt(6h0)	Buy now
7	6N7-13416-00 Pipe, oil 1	Buy now
8	90465-11M10 Clamp	Buy now
9	90445-07M89 Hose (l390)	Buy now
10	90445-07196 Hose (l200)	Buy now
11	90445-07M72 Hose (l390)	Buy now
12	6R3-13183-10 Valve, check	Buy now
13	90445-07M87 Hose(62t)	Buy now
14	90464-07M06 Clamp (6e5)	Buy now


Oil Pump



Ref	Part	
15	90468-07M02 Clip (6e5)	Buy now
16	6R3-11537-00 Gear, driven	Buy now
17	6R3-13117-00 Collar, distance	Buy now
18	93210-13M04 93210-13m04	Buy now
19	90202-08M44 Washer, plate(6r3)	Buy now
20	6R3-41241-00 Rod, link	Buy now
21	6H1-41237-00 Joint, link	Buy now
22	95380-05600 Nut, hexagon (663)	Buy now
23	6R5-41237-00 Joint, link	Buy now
24	90468-05M03 Clip(6j8)	Buy now
25	90202-05088 Washer, plate (666)	Buy now
26	6E5-14276-01 Lever	Buy now
27	91690-30016 Pin, spring	Buy now

B7

Oil Tank




6N62300-3080

C2


Ref	Part	
1	61A-21708-20 Sub oil tank assembly.	Buy now
2	6E5-21733-20 Sub tank, oil (10.5l)	Buy now
3	6E5-21770-03 Oil tank cap assembly	Buy now
4	6E5-24322-00 Pipe 11	Buy now
5	90465-11M10 Clamp	Buy now
6	646-24251-02 Strainer 1	Buy now
7	6E5-24319-01 Pipe, oil	Buy now
9	6E5-81900-01 Oil feed pump assembly	Buy now
10	6E5-81922-00 Grommet	Buy now
11	6E5-24321-01 Pipe 10	Buy now
12	6E5-24379-00 Pipe, joint 4	Buy now
13	90445-11M26 Hose (I8000)	Buy now
15	6E5-85720-04 Oil level gauge assembly	Buy now
16	6R3-85721-80 Wire, lead	Buy now
17	90465-13M11 Clamp (6e5)	Buy now

Oil Tank



Ref	Part	
18	6E5-21734-01-33 Holder, oil sub tank	Buy now
19	6E5-21798-01-33 Bracket, damper	Buy now
20	6E5-21746-00 Damper	Buy now
21	97080-06100 Bolt, hexagon	Buy now
22	92990-06600 Washer, plain (646)	Buy now
23	95380-06600 Nut(661)	Buy now
24	6E5-21750-05 Oil tank assembly	Buy now
25	6E5-13448-00 Cap, oil tank	Buy now
27	6G7-85730-04 Oil level gauge assembly	Buy now
28	6E5-13411-00 Strainer, oil	Buy now
29	6E5-13414-00 Gasket, strainer cover	Buy now
30	90445-05M02 Hose (I700)	Buy now
31	6A0-82317-00 Damper, ignition coil	Buy now
32	624-42542-00 Collar	Buy now
33	90119-06M65 Bolt, with washer	Buy now


Oil Tank



Ref	Part	
34	64E-24323-00 Pipe 12	Buy now
35	90445-12207 Hose (I3000)	Buy now
40	90464-13M34 Clamp(6r3)	Buy now
41	6E5-85740-02 Control unit kit	Buy now
45	6E5-13437-62 Mark Caution	Buy now
46	6E5-85711-60 Mark Caution	Buy now
47	656-W2810-02 Tool kit	Buy now
48	64C-28199-78-A0 O/m 115c/130beto/150feto/l '03 UR (E,F,S)	Buy now
48	64C-28199-78-B0 O/m 115c/130beto/150feto/l '03 UR (D,NL,I)	Buy now
49	64C-28199-88-A0 O/m 115ceto/130beto/150fet '03 UR (DK,P,GR)	Buy now
49	64C-28199-88-B0 O/m 115ceto/130beto/150fet '03 UR (N,S,SS)	Buy now

C2


Power Trim & Tilt Assy 1



F1

Ref	Part	
1	64E-43800-02-4D Power trim & tilt assembly	Buy now
2	64E-43825-01 Housing Trim & Tilt	Buy now
3	64E-4388J-00 Plug 2	Buy now
4	93210-10M74 O-ring	Buy now
5	64E-43817-00 Filter 2	Buy now
6	64E-43810-00 Tilt piston sub assembly	Buy now
7	64E-43898-00 Seal, dust 2	Buy now
8	64E-43867-00 O-ring 7	Buy now
9	64E-43866-00 O-ring 6	Buy now
10	6E5-43862-00 O-ring 2	Buy now
11	64E-43883-00 O-ring 10	Buy now
12	6E5-43872-00 Ring, back-up 2	Buy now
13	6E5-43814-02 Piston, free	Buy now
15	64E-43820-00 Trim piston sub assembly	Buy now
16	64E-43821-00 Screw, trim cylinder end	Buy now

Power Trim & Tilt Assy 1




F1

Ref	Part	
17	64E-43822-00 Seal, trim dust	Buy now
18	64E-4384J-00 Seal, trim down	Buy now
19	6G5-43864-00 O-ring 4	Buy now
20	6E5-43864-00 O-ring 4	Buy now
21	6E5-43874-01 Ring, back-up 4	Buy now
22	64E-43828-00 Body, reservoir	Buy now
23	64E-43829-00 Plug, reservoir	Buy now
24	64E-43897-00 O-ring	Buy now
25	64E-4388E-00 Bolt ,screw (l:14mm)	Buy now
26	64E-43869-00 O-ring 9	Buy now
27	64E-4381G-00 Pin 1	Buy now
28	6E5-43858-00 Ball 1	Buy now
29	64E-4382G-00 Valve seat	Buy now
30	90201-08M14 Washer, plate	Buy now
31	97080-08016 Bolt	Buy now


Power Trim & Tilt Assy 1

Ref	Part	
32	64E-43818-01 Lower shock mount pin set	Buy now
33	90386-22M98 Bush(61u)	Buy now



F1


Power Trim & Tilt Assy 2



F3

Ref	Part	
1	64E-4388E-10 Bolt ,screw (l:34.7mm)	Buy now
2	64E-43831-00 Connector, shaft	Buy now
3	64E-43868-00 O-ring 8	Buy now
4	64E-43830-00 Gear pump assembly	Buy now
5	72X-43858-00 Ball	Buy now
6	64E-43843-00 Screw, valve lock	Buy now
7	64E-43841-00 Piston, shuttle	Buy now
8	64E-43802-00 Valve sub assembly	Buy now
9	6E5-43896-00 O-ring	Buy now
10	6G5-43863-00 O-ring 3	Buy now
11	64E-43851-00 Seat, Relief Valve	Buy now
12	64E-43858-00 Ball	Buy now
13	64E-43859-00 Pin, Valve Support	Buy now
14	64E-43855-00 Spring, up relief	Buy now
15	64E-43850-00 Valve sub assembly	Buy now


Power Trim & Tilt Assy 2



F3

Ref	Part	
16	64E-43865-00 O-ring 10	Buy now
17	64E-43816-00 Filter 1	Buy now
19	64E-43817-10 Filter 2	Buy now
20	64E-43860-00 Manual valve sub-assembly	Buy now
21	72X-85075-L0 O-ring (nsd161)	Buy now
22	64E-43827-00 Ring set	Buy now
23	64E-4387A-00 O-ring	Buy now
24	64E-43873-00 Ring, back up	Buy now
25	64E-43875-00 Ring, snap	Buy now
26	64E-43879-10 Screw, with washer	Buy now
27	64E-43879-00 Screw, with washer	Buy now
28	64E-43880-01 Motor assembly	Buy now
29	6H1-4386K-10 Spring, brush	Buy now
30	64E-4380J-00 Holder Brush	Buy now
31	64E-43891-00 Brush 1	Buy now


Power Trim & Tilt Assy 2



F3

Ref	Part	
32	97607-04310 Screw, pan head(6g8)	Buy now
33	64E-4380F-00 Holder, brush 2	Buy now
34	64E-43892-00 Breaker comp. (brush 2)	Buy now
35	6G5-43865-00 O-ring	Buy now
36	93102-08M43 Oil seal(6b0)	Buy now
37	64E-43805-00 Armature assembly	Buy now
38	64E-43843-10 Screw valve lock	Buy now


Remote Control Assy



B4

Ref	Part	
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	703-48261-01 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now
15	703-48243-00 Bushing 3	Buy now


Remote Control Assy



B4

Ref	Part	
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now
30	703-48219-00 Cover, lead	Buy now


Remote Control Assy



B4

Ref	Part	
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-43 Main switch assembly	Buy now
45	703-82577-00 Cap, key	Buy now


Remote Control Assy



B4

Ref	Part	
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-02 Buzzer	Buy now
52	703-48284-00 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-82563-02 Trim & tilt switch assembly WITH PT/T SW.	Buy now
56	703-48221-00 Grip	Buy now
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now


Remote Control Assy



B4

Ref	Part	
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now

Remote Control Box




67M0100-8280

B3

Ref	Part	
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	701-48320-00 Cable, Remote Control L=12F UR	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now
2	701-48320-60 Cable, Remote Control L=16F UR	Buy now
2	701-48320-80 Cable, Remote Control L=17F UR	Buy now
2	701-48350-00 Cable, Remote Control L=21F UR	Buy now
2	701-48350-20 Cable, Remote Control L=23F UR	Buy now


Repair Kit 1



C1

Ref	Part	
1	.GASKET -	Buy now
1	6N6-W0001-A5 Power head gasket kit	Buy now
2	6K7-14483-00 Gasket	Buy now
3	6E5-14198-A2 Gasket	Buy now
4	6E5-11381-A2 Gasket 1	Buy now
5	6E5-11181-A1 Gasket, cylinder head 1	Buy now
6	6E5-11193-A0 Gasket, head cover 1	Buy now
7	688-12414-A1 Gasket, cover	Buy now
8	6E5-41112-A1 Gasket, exhaust inner cover	Buy now
10	93102-40M14 Oil seal(61a)	Buy now
11	93211-04001 O-ring	Buy now
12	93102-35M13 Oil seal (6e5)	Buy now
13	93101-22M15 Oil seal (6e5)	Buy now
14	93210-74M35 O-ring (6e5)	Buy now
15	6E5-13621-A1 Gasket, valve seat	Buy now


Repair Kit 1



Ref	Part	
16	6E5-13645-A1 Gasket, manifold 1	Buy now
17	64D-14384-01 Gasket, float chamber	Buy now
18	6G5-45113-A1 Gasket, upper casing	Buy now
19	650-24431-A0 Gasket, fuel pump	Buy now
20	6N6-W0093-09 Carburetor repair kit	Buy now
21	6E5-14159-00 Clip	Buy now
23	6E5-14546-00 Valve, needle	Buy now
24	6E5-14386-02 Pin, float	Buy now
25	64D-14394-00 Valve, drain	Buy now
28	6E5-14328-01 Plug	Buy now
29	6E5-14979-00 Gasket	Buy now
30	6J8-14959-00 Gasket, drin screw	Buy now
31	6JU-14959-00 Gasket	Buy now

C1


Repair Kit 2



C3

Ref	Part	
1	6E5-W0001-F1 Gasket kit, lower unit	Buy now
2	6E5-41134-A0 Gasket, exhaust manifold	Buy now
3	6G5-45114-A1 Gasket, upper casing	Buy now
4	6E5-45123-00 Gasket, muffler	Buy now
5	6E5-41135-A0 Gasket, exhaust manifold	Buy now
6	6E5-44365-00 Damper, water seal 1	Buy now
7	6E5-44366-00 Damper, water seal 2	Buy now
8	90430-08020 Gasket	Buy now
9	93210-58144 O-ring(47x)	Buy now
10	93106-09014 Oil seal	Buy now
11	93210-86M38 O-ring (6e5)	Buy now
12	93210-37160 O-ring (6g8)	Buy now
13	6E5-44315-A0 Gasket,water pump	Buy now
14	93101-28M16 Oil seal (6e5)	Buy now
15	93210-55M14 O-ring (70e)	Buy now


Repair Kit 2



C3

Ref	Part	
16	93210-86M39 O-ring (6e5)	Buy now
17	93101-30M17 Oil seal (6e5)	Buy now
18	6F3-W0001-C1 Gasket kit, lower unit	Buy now
19	6G5-41134-A1 Gasket, exhaust manifold	Buy now
35	6N6-W0078-02 Water pump repair kit	Buy now
36	61A-44322-02 Insert, cartridge	Buy now
39	6E5-44352-01 Impeller	Buy now
40	6E5-44323-00 Outer plate, cartridge	Buy now
42	93606-12019 Pin, dowel (614)	Buy now
43	90119-08M14 Bolt, with washer	Buy now
44	90280-04M05 Key, woodruff (6e5)	Buy now
45	6E5-W0078-3A Chrome pump kit	Buy now
46	6R3-44322-42 Insert, cartridge	Buy now
47	6E5-44323-40 Outer plate, cartridge	Buy now


Starting Motor



D4

Ref	Part	
1	6N7-81800-10 Starting motor assembly	Buy now
2	6N7-81850-10 Armature assembly	Buy now
3	61A-81809-00 Washer kit	Buy now
4	61A-81824-00 Washer 2	Buy now
5	6N7-81810-00 Stator assembly	Buy now
6	6K7-8182G-10 Bush, terminal	Buy now
7	6N7-81840-00 Brush holder assembly	Buy now
8	6N7-81801-00 Brush set	Buy now
9	6N7-81813-00 Spring, brush	Buy now
10	6N7-81820-10 Rear bracket assembly	Buy now
11	6N7-81807-00 Gear assembly, starting motor	Buy now
12	6N7-81857-00 Pinion stopper set	Buy now
13	6N7-81830-00 Front bracket assembly	Buy now
14	6K7-81826-10 Bolt	Buy now
15	6E5-8182E-10 Washer, spring	Buy now


Starting Motor



D4

Ref	Part	
16	6E5-8182F-10 Washer,plain	Buy now
17	6E5-8182A-10 Nut	Buy now
18	6E5-8182K-10 Nut	Buy now
19	6R3-81822-00-94 Bracket, starting motor	Buy now
20	90119-08M76 Bolt, with washer(6e5)	Buy now
21	90119-08M77 Bolt, with washer(6e5)	Buy now
22	90119-08M57 Bolt, with washer	Buy now
23	92990-08600 Washer, plain (663)	Buy now
24	97095-08016 Bolt, hexagon deep recess	Buy now
25	92995-08600 Washer, plain (663)	Buy now

Steering Guide




67H0100-9290

B2

Ref	Part	
1	6E5-61350-02 Steering guide attachment kit AP	Buy now
2	6E5-61351-01 Rod, steering link	Buy now
3	90387-10M61 Collar (6e5)	Buy now
4	90560-12M01 Spacer (6e5)	Buy now
5	6E5-61355-00 Bolt	Buy now
6	90185-09M01 Nut, nylon (663)	Buy now
7	90201-10M20 Washer, plate (663)	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now


Top Cowling



A4

Ref	Part	
1	6N6-42610-60-4D Top Cowling assembly	Buy now
1	6N7-42610-60-4D Top Cowling assembly	Buy now
2	6R3-42647-00 Holder, clamp band	Buy now
3	92990-06100 Washer(6a1)	Buy now
4	95380-06600 Nut(661)	Buy now
5	6R3-42662-00 Damper	Buy now
6	6R3-42814-00 Hook, clamp	Buy now
7	97095-06012 Bolt(gh1)	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	6N7-42619-00 Damper, form	Buy now
10	6N7-42627-00 Damper, form	Buy now
11	6R3-42615-01 Seal	Buy now
12	6N7-42613-00-4D Molding, air duct	Buy now
13	90179-06M24 Nut(6j8)	Buy now
14	6N7-42636-00 Louver, 2	Buy now


Top Cowling



Ref	Part	
15	92990-04600 Washer, plain (646)	Buy now
16	97780-40520 Ybs83-420 screw,panh,tapping	Buy now
17	6N6-42686-40 Emblem, front	Buy now
17	6N7-42686-40 Emblem, front	Buy now
18	6N6-42687-30 Emblem, rear	Buy now
18	6N7-42687-30 Emblem, rear	Buy now
19	6N7-W0070-30 Graphic Set	Buy now
20	6N7-42681-30 Mark Cowling	Buy now
21	6N7-42682-30 Mark, Cowling	Buy now
22	6N7-42678-30 Graphic, Rear	Buy now
23	6N7-4267A-30 Graphic, Rear 2	Buy now

A4


Upper Casing



F5

Ref	Part	
1	6E5-45111-02-8D Casing, upper L	Buy now
2	6R3-42791-41 Mark 1	Buy now
3	6R3-42792-41 Mark	Buy now
4	6E5-45155-00 Cap	Buy now
5	6E5-42769-00 Seal, rubber	Buy now
6	97095-06010 Bolt	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	93608-12M05 Pin, dowel b (6e5)	Buy now
9	90119-08027 Bolt, with washer	Buy now
10	6G5-41137-11-94 Guide, exhaust FLUSHING KIT	Buy now
11	6E5-42724-00 Grommet	Buy now
12	6G5-12581-00 Joint, hose	Buy now
14	6G5-45113-A1 Gasket, upper casing	Buy now
15	90119-08M79 Bolt, hexagon (fj1)	Buy now
16	97095-08045 Bolt, hexagon	Buy now

Upper Casing




F5

Ref	Part	
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	95380-08700 Nut(661)	Buy now
20	6H1-11372-00 Nipple, hose FLUSHING KIT	Buy now
21	6G5-41131-01-5B Manifold, ext. 1	Buy now
22	6G5-45114-A1 Gasket, upper casing	Buy now
23	97095-08030 Bolt, hexagon (fj1)	Buy now
24	92995-08600 Washer, plain (663)	Buy now
25	6E5-41132-10-5B Manifold, exhaust	Buy now
25	6L1-41132-00-5B Manifold, exhaust	Buy now
26	6E5-41134-A0 Gasket, exhaust manifold	Buy now
26	6G5-41134-A1 Gasket, exhaust manifold	Buy now
29	6E5-14711-01-5B Muffler 1	Buy now
30	6E5-14737-00 Damper, muffler	Buy now
31	90183-05M02 Nut, spring (6e5)	Buy now
32	6E5-45123-00 Gasket, muffler	Buy now

Upper Casing

Ref	Part	
33	6E5-41135-A0 Gasket, exhaust manifold	Buy now



F5

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.