



# Yamaha 140AETOL 1996

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


|                                         |    |
|-----------------------------------------|----|
| <b>Bottom Cowling</b>                   | 3  |
| <b>Bracket 1</b>                        | 5  |
| <b>Bracket 2 (MANUAL TILT MODEL)</b>    | 9  |
| <b>C.d.i. Magneto</b>                   | 11 |
| <b>Carburetor</b>                       | 13 |
| <b>Control</b>                          | 15 |
| <b>Crankcase &amp; Cylinder</b>         | 19 |
| <b>Crankshaft &amp; Piston</b>          | 23 |
| <b>Electric Motor</b>                   | 25 |
| <b>Electric Parts 1</b>                 | 27 |
| <b>Electric Parts 2</b>                 | 29 |
| <b>Fuel 1</b>                           | 31 |
| <b>Fuel 2</b>                           | 33 |
| <b>Intake</b>                           | 34 |
| <b>Lower &amp; Drive 1</b>              | 37 |
| <b>Lower &amp; Drive 2</b>              | 42 |
| <b>Oil Pump</b>                         | 44 |
| <b>Oil Tank</b>                         | 46 |
| <b>Optional Parts 1</b>                 | 49 |
| <b>Optional Parts 2</b>                 | 51 |
| <b>Optional Parts 3</b>                 | 53 |
| <b>Optional Parts 4</b>                 | 55 |
| <b>Optional Parts 5</b>                 | 57 |
| <b>Power Trim &amp; Tilt</b>            | 58 |
| <b>Power Trim &amp; Tilt Assy</b>       | 59 |
| <b>Remote Control</b>                   | 64 |
| <b>Remote Control Assy 1 (703 TYPE)</b> | 65 |
| <b>Remote Control Assy 2 (704 TYPE)</b> | 69 |
| <b>Repair Kit</b>                       | 74 |
| <b>Steering Guide Attachment</b>        | 79 |
| <b>Top Cowling</b>                      | 81 |
| <b>Upper Casing</b>                     | 83 |

## Bottom Cowling




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 3   | <a href="#">688428160000</a><br>Lever, clamp 2            | <a href="#">Buy now</a> |
| 4   | <a href="#">9038613M3800</a><br>Bushing (697)             | <a href="#">Buy now</a> |
| 5   | <a href="#">9020613M1000</a><br>Washer, wave (6e5)        | <a href="#">Buy now</a> |
| 6   | <a href="#">973950601200</a><br>Bolt(gh1)                 | <a href="#">Buy now</a> |
| 7   | <a href="#">9020106M0200</a><br>Washer,plate (6k8)        | <a href="#">Buy now</a> |
| 8   | <a href="#">6E54281700EJ</a><br>Lever, Clamp              | <a href="#">Buy now</a> |
| 9   | <a href="#">6G5428160000</a><br>Lever, clamp 2            | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5428160100</a><br>Lever, clamp 2            | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5443910000</a><br>Nipple, hose              | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5427251100</a><br>Grommet                   | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5427380094</a><br>Plate, fitting            | <a href="#">Buy now</a> |
| 14  | <a href="#">973130601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 15  | <a href="#">929030660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 16  | <a href="#">9048022M1500</a><br>Grommet (6e5)             | <a href="#">Buy now</a> |
| 17  | <a href="#">9038708M3700</a><br>Coller (6e5)              | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 18  | <a href="#">9020108M5400</a><br>Washer, plate (6e5) | <a href="#">Buy now</a> |
| 19  | <a href="#">973950803500</a><br>Bolt(70w)           | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5427160000</a><br>Seal                | <a href="#">Buy now</a> |
| 23  | <a href="#">970800602000</a><br>Bolt(7u8)           | <a href="#">Buy now</a> |
| 24  | <a href="#">929900660000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 25  | <a href="#">688825940000</a><br>Clamp               | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5825940000</a><br>Clamp               | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5825880000</a><br>Plate               | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5243670100</a><br>Clamp, fuel pipe 2  | <a href="#">Buy now</a> |
| 31  | <a href="#">9015706M0100</a><br>Screw (6e5)         | <a href="#">Buy now</a> |
| 33  | <a href="#">9048013M2400</a><br>Grommet (6e9)       | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5243671000</a><br>Clamp, fuel pipe 2  | <a href="#">Buy now</a> |
| 35  | <a href="#">688427261000</a><br>Grommet             | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 2   | <a href="#">6E5452510000</a><br>Anode                   | <a href="#">Buy now</a> |
| 3   | <a href="#">973950602500</a><br>Bolt                    | <a href="#">Buy now</a> |
| 4   | <a href="#">929900660000</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5821480000</a><br>Wire, lead 5            | <a href="#">Buy now</a> |
| 7   | <a href="#">978850601200</a><br>Screw, pan head(62j)    | <a href="#">Buy now</a> |
| 9   | <a href="#">973951004500</a><br>Bolt(64d)               | <a href="#">Buy now</a> |
| 10  | <a href="#">929901010000</a><br>Ybs67-10 washer, spring | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5431310000</a><br>Bolt, clamp bracket     | <a href="#">Buy now</a> |
| 12  | <a href="#">9038625M3100</a><br>Bushing (6e5)           | <a href="#">Buy now</a> |
| 13  | <a href="#">9020126M5900</a><br>Washer, plate (6e5)     | <a href="#">Buy now</a> |
| 14  | <a href="#">901852200700</a><br>Nut, self-locking       | <a href="#">Buy now</a> |
| 15  | <a href="#">663431450000</a><br>Cap, clamp bracket      | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5431600000</a><br>Tilt rod ass'y          | <a href="#">Buy now</a> |
| 17  | <a href="#">688431650000</a><br>Stopper, tilt rod       | <a href="#">Buy now</a> |
| 18  | <a href="#">916903001400</a><br>Pin, spring (647)       | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 19  | <a href="#">9050220M0300</a><br>Spring (6e5)        | <a href="#">Buy now</a> |
| 20  | <a href="#">6E54331101E</a><br>Bracket, Swivel      | <a href="#">Buy now</a> |
| 21  | <a href="#">902690301000</a><br>Rivet (663)         | <a href="#">Buy now</a> |
| 22  | <a href="#">9370006M0300</a><br>Nipple, grease(6a1) | <a href="#">Buy now</a> |
| 23  | <a href="#">663451190000</a><br>Cap, grease nipple  | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5821470000</a><br>Wire, lead 5        | <a href="#">Buy now</a> |
| 26  | <a href="#">953801260000</a><br>Nut (707)           | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5431810000</a><br>Lever, Tilt Stop    | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5431850000</a><br>Lever, Tilt Stop    | <a href="#">Buy now</a> |
| 29  | <a href="#">663433180000</a><br>Cover               | <a href="#">Buy now</a> |
| 30  | <a href="#">9038610M1600</a><br>Bushing (688)       | <a href="#">Buy now</a> |
| 31  | <a href="#">9038710M3800</a><br>Collar (6e5)        | <a href="#">Buy now</a> |
| 32  | <a href="#">914903002500</a><br>Pin cotter          | <a href="#">Buy now</a> |
| 33  | <a href="#">9050110M2100</a><br>Spring (688)        | <a href="#">Buy now</a> |
| 34  | <a href="#">929901060000</a><br>Washer, plate       | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 35  | <a href="#">6E5431260000</a><br>Pin, upper shock mount     | <a href="#">Buy now</a> |
| 36  | <a href="#">9038618M4400</a><br>Bushing (6g5)              | <a href="#">Buy now</a> |
| 37  | <a href="#">9341018M0200</a><br>Circlip (6f2)              | <a href="#">Buy now</a> |
| 39  | <a href="#">9020138M6000</a><br>Washer, plate (6e5)        | <a href="#">Buy now</a> |
| 40  | <a href="#">9038638M8900</a><br>Bush(6e5)                  | <a href="#">Buy now</a> |
| 41  | <a href="#">9310938M0200</a><br>Oil seal (6e5)             | <a href="#">Buy now</a> |
| 43  | <a href="#">9341037M0400</a><br>Circlip (6e5)              | <a href="#">Buy now</a> |
| 44  | <a href="#">6E5445750000</a><br>Damper, lower mount rubber | <a href="#">Buy now</a> |
| 45  | <a href="#">6E5445550000</a><br>Mount damper, lower side   | <a href="#">Buy now</a> |
| 46  | <a href="#">9020232M1900</a><br>Washer, plate (6e5)        | <a href="#">Buy now</a> |
| 47  | <a href="#">9020116M5500</a><br>Washer, plate (6e5)        | <a href="#">Buy now</a> |
| 48  | <a href="#">6E5821490000</a><br>Wire, lead 3               | <a href="#">Buy now</a> |
| 49  | <a href="#">901011400300</a><br>Bolt                       | <a href="#">Buy now</a> |
| 50  | <a href="#">9020115M5800</a><br>Washer, plate (6e5)        | <a href="#">Buy now</a> |
| 51  | <a href="#">953801480000</a><br>Nut, crown (6e5)           | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 52  | <a href="#">929901460000</a><br>Washer (6e5)                | <a href="#">Buy now</a> |
| 53  | <a href="#">6E54455201CA</a><br>Housing, lower mount rubber | <a href="#">Buy now</a> |
| 57  | <a href="#">9050116M2800</a><br>Spring (6e5)                | <a href="#">Buy now</a> |
| 58  | <a href="#">923800601500</a><br>Screw pan head              | <a href="#">Buy now</a> |
| 59  | <a href="#">901790606600</a><br>Nut(663)                    | <a href="#">Buy now</a> |
| 61  | <a href="#">9020126M5700</a><br>Washer, plate (6e5)         | <a href="#">Buy now</a> |
| 62  | <a href="#">9020226M1800</a><br>Washer, plate (6e5)         | <a href="#">Buy now</a> |
| 63  | <a href="#">9020114M5600</a><br>Washer, plate (6e5)         | <a href="#">Buy now</a> |
| 64  | <a href="#">9010912M0900</a><br>Bolt                        | <a href="#">Buy now</a> |
| 65  | <a href="#">901851205800</a><br>Nut, nylon(663)             | <a href="#">Buy now</a> |
| 66  | <a href="#">663445750000</a><br>Damper, lower mount rubber  | <a href="#">Buy now</a> |
| 68  | <a href="#">970951004500</a><br>Bolt(64d)                   | <a href="#">Buy now</a> |
| 70  | <a href="#">9010112M6500</a><br>Bolt                        | <a href="#">Buy now</a> |
| 71  | <a href="#">929901220000</a><br>Ybs66-12 washer,plain       | <a href="#">Buy now</a> |

## Bracket 2 (Manual Tilt Model)




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 2   | <a href="#">9010906M0700</a><br>Bolt (6e5)                | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5436130000</a><br>Arm, tilt lock            | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5436140000</a><br>Plate, tilt lock 1        | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5436150000</a><br>Plate, Tilt Lock          | <a href="#">Buy now</a> |
| 6   | <a href="#">9024006M0700</a><br>Pin, Clevis               | <a href="#">Buy now</a> |
| 7   | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 8   | <a href="#">914902502000</a><br>Pin, cotter               | <a href="#">Buy now</a> |
| 9   | <a href="#">9050623M1000</a><br>Spring, Tension           | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5436590000</a><br>Shaft, Reverse Lock       | <a href="#">Buy now</a> |
| 11  | <a href="#">929900860000</a><br>Washer, plain (663)       | <a href="#">Buy now</a> |
| 12  | <a href="#">914902501500</a><br>Pin, cotter               | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5436790000</a><br>Stopper, Hook             | <a href="#">Buy now</a> |
| 14  | <a href="#">970950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 16  | <a href="#">903860803200</a><br>Bushing (650)             | <a href="#">Buy now</a> |
| 17  | <a href="#">9020208M0800</a><br>Washer, Plate             | <a href="#">Buy now</a> |

## Bracket 2 (Manual Tilt Model)




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 19  | <a href="#">914902001500</a><br>Pin, cotter (648)       | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5433170000</a><br>Grip                    | <a href="#">Buy now</a> |
| 21  | <a href="#">986800500800</a><br>Screw Flat Head(6J8)    | <a href="#">Buy now</a> |
| 22  | <a href="#">9050609M0900</a><br>Spring, Tension         | <a href="#">Buy now</a> |
| 23  | <a href="#">688431840000</a><br>Collar, anchor lever    | <a href="#">Buy now</a> |
| 24  | <a href="#">914903002500</a><br>Pin cotter              | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5436760000</a><br>Hook                    | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5436160000</a><br>Rod, tilt lock          | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5431240000</a><br>Pin, lower shock mount  | <a href="#">Buy now</a> |
| 30  | <a href="#">6E54317000EJ</a><br>Shock absorber assembly | <a href="#">Buy now</a> |

# C.d.i. Magneto




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 3   | <a href="#">6E5855101000</a><br>Stator Assembly               | <a href="#">Buy now</a> |
| 4   | <a href="#">9048006M1600</a><br>Grommet                       | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5855801200</a><br>Coil, Pulser                  | <a href="#">Buy now</a> |
| 6   | <a href="#">663855180000</a><br>Joint, ball                   | <a href="#">Buy now</a> |
| 8   | <a href="#">901702013700</a><br>Nut, hexagon(663)             | <a href="#">Buy now</a> |
| 10  | <a href="#">902800501500</a><br>Key, woodruff                 | <a href="#">Buy now</a> |
| 11  | <a href="#">975950655500</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 12  | <a href="#">929030660000</a><br>Washer, plain (646)           | <a href="#">Buy now</a> |
| 13  | <a href="#">688416110000</a><br>Retainer, magneto base 1      | <a href="#">Buy now</a> |
| 14  | <a href="#">688416120000</a><br>Retainer, magneto base 2      | <a href="#">Buy now</a> |
| 15  | <a href="#">978010601800</a><br>Screw, pan head(6e5)          | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5813320000</a><br>Plate, timing                 | <a href="#">Buy now</a> |
| 18  | <a href="#">978030601000</a><br>Screw pan head                | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5813370000</a><br>Cover, flywheel               | <a href="#">Buy now</a> |
| 21  | <a href="#">973130603000</a><br>Bolt                          | <a href="#">Buy now</a> |

# C.d.i. Magneto




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 22  | <a href="#">929950610000</a><br>Washer(6a1)           | <a href="#">Buy now</a> |
| 23  | <a href="#">9020106M6200</a><br>Washer, plate (6e5)   | <a href="#">Buy now</a> |
| 24  | <a href="#">663823170000</a><br>Damper, ignition coil | <a href="#">Buy now</a> |
| 25  | <a href="#">624425420000</a><br>Collar                | <a href="#">Buy now</a> |
| 26  | <a href="#">6G5823170000</a><br>Damper                | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 4   | <a href="#">978030501700</a><br>Screw panhead (669)    | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5143840200</a><br>Gasket, float chamber  | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5143860100</a><br>Pin, float             | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5143410300</a><br>Nozzle, Main           | <a href="#">Buy now</a> |
| 10  | <a href="#">1J2143980000</a><br>Packing                | <a href="#">Buy now</a> |
| 11  | <a href="#">6G4143424200</a><br>Jet, Pilot (#84)       | <a href="#">Buy now</a> |
| 12  | <a href="#">6G4143901700</a><br>Valve Seat Assembly    | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5143830000</a><br>Screw, Drain           | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5143980000</a><br>Gasket                 | <a href="#">Buy now</a> |
| 16  | <a href="#">985800402000</a><br>Screw, pan head (7h3)  | <a href="#">Buy now</a> |
| 17  | <a href="#">647143340000</a><br>Spring, air adjusting. | <a href="#">Buy now</a> |
| 18  | <a href="#">6G5143230000</a><br>Screw Air Adjusting    | <a href="#">Buy now</a> |
| 19  | <a href="#">650142230000</a><br>Spring, Drain Valve    | <a href="#">Buy now</a> |
| 20  | <a href="#">682412910000</a><br>Bushing                | <a href="#">Buy now</a> |
| 22  | <a href="#">6G5143280000</a><br>Screw, Pilot Stop      | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 23  | <a href="#">367141950000</a><br>Washer, valve seat   | <a href="#">Buy now</a> |
| 24  | <a href="#">989020401000</a><br>Screw, binding (m01) | <a href="#">Buy now</a> |
| 25  | <a href="#">6A4143940000</a><br>Valve, drain         | <a href="#">Buy now</a> |
| 26  | <a href="#">652143970000</a><br>Ring, o              | <a href="#">Buy now</a> |

## Control




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5485310000</a><br>Bracket, remote control   | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5485380000</a><br>Clamp, cable              | <a href="#">Buy now</a> |
| 3   | <a href="#">916903001200</a><br>Pin, spring               | <a href="#">Buy now</a> |
| 4   | <a href="#">973130802000</a><br>Bolt(6td)                 | <a href="#">Buy now</a> |
| 5   | <a href="#">929900810000</a><br>Ybs67-8 washer, spring    | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5416320194</a><br>Lever, magneto control    | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5483440000</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 8   | <a href="#">929900620000</a><br>Ybs66-6 washer, plain     | <a href="#">Buy now</a> |
| 9   | <a href="#">901850606200</a><br>Nut selflocking (656)     | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5416310194</a><br>Lever, magneto control    | <a href="#">Buy now</a> |
| 11  | <a href="#">9015706M1200</a><br>Screw, pan head(697)      | <a href="#">Buy now</a> |
| 12  | <a href="#">953030660000</a><br>Nut(661)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">9050116M1200</a><br>Spring, compression (688) | <a href="#">Buy now</a> |
| 14  | <a href="#">970130804500</a><br>Bolt                      | <a href="#">Buy now</a> |
| 15  | <a href="#">9020108M2300</a><br>Washer, plate (6e5)       | <a href="#">Buy now</a> |

# Control




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">903861208900</a><br>Bushing(663)         | <a href="#">Buy now</a> |
| 17  | <a href="#">9038708M1600</a><br>Collar               | <a href="#">Buy now</a> |
| 18  | <a href="#">9038622M1300</a><br>Bushing (688)        | <a href="#">Buy now</a> |
| 19  | <a href="#">902021209200</a><br>Washer, plate(663)   | <a href="#">Buy now</a> |
| 20  | <a href="#">9020108M1300</a><br>Washer plate (682)   | <a href="#">Buy now</a> |
| 21  | <a href="#">9050829M1200</a><br>Spring (6e5)         | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5416360100</a><br>Rod, magneto control | <a href="#">Buy now</a> |
| 23  | <a href="#">953800560000</a><br>Nut, hexagon (663)   | <a href="#">Buy now</a> |
| 24  | <a href="#">662412370100</a><br>Joint, link          | <a href="#">Buy now</a> |
| 25  | <a href="#">9015706M0000</a><br>Screw, pan head(6h4) | <a href="#">Buy now</a> |
| 26  | <a href="#">953800660000</a><br>Nut(661)             | <a href="#">Buy now</a> |
| 27  | <a href="#">688441940000</a><br>Cap                  | <a href="#">Buy now</a> |
| 28  | <a href="#">688416360000</a><br>Rod 1                | <a href="#">Buy now</a> |
| 31  | <a href="#">6E5412130000</a><br>Cam, accel.          | <a href="#">Buy now</a> |
| 32  | <a href="#">9038706M2900</a><br>Collar (6a0)         | <a href="#">Buy now</a> |

## Control




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 33  | <a href="#">9020610M0400</a><br>Washer, wave (676)       | <a href="#">Buy now</a> |
| 34  | <a href="#">973130602500</a><br>Bolt                     | <a href="#">Buy now</a> |
| 35  | <a href="#">6E54411700EJ</a><br>Bracket                  | <a href="#">Buy now</a> |
| 36  | <a href="#">970800602000</a><br>Bolt(7u8)                | <a href="#">Buy now</a> |
| 37  | <a href="#">929030660000</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 38  | <a href="#">6E5441210000</a><br>Lever, Shift Rod         | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5441220000</a><br>Bushing, shift rod lever | <a href="#">Buy now</a> |
| 40  | <a href="#">9020208M2000</a><br>Washer, plate (6e5)      | <a href="#">Buy now</a> |
| 41  | <a href="#">904681800800</a><br>Clip 620436610000        | <a href="#">Buy now</a> |
| 42  | <a href="#">9038606M1200</a><br>Bushing (688)            | <a href="#">Buy now</a> |
| 43  | <a href="#">6E5441180194</a><br>Bracket 2                | <a href="#">Buy now</a> |
| 44  | <a href="#">973130803000</a><br>Bolt                     | <a href="#">Buy now</a> |
| 45  | <a href="#">929901010000</a><br>Ybs67-10 washer, spring  | <a href="#">Buy now</a> |
| 46  | <a href="#">9350104M0200</a><br>Ball (697)               | <a href="#">Buy now</a> |
| 47  | <a href="#">905011208200</a><br>Spring 6484411600        | <a href="#">Buy now</a> |

## Control




| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 48  | <a href="#">648427150000</a><br>Bushing 2                  | <a href="#">Buy now</a> |
| 49  | <a href="#">6E5441202400</a><br>Handle gear shift assembly | <a href="#">Buy now</a> |
| 50  | <a href="#">932100916500</a><br>O-ring                     | <a href="#">Buy now</a> |
| 51  | <a href="#">9038616M6600</a><br>Bush(6e5)                  | <a href="#">Buy now</a> |
| 52  | <a href="#">902021606100</a><br>Washer, plate(663)         | <a href="#">Buy now</a> |
| 53  | <a href="#">934101600600</a><br>Circlip                    | <a href="#">Buy now</a> |

# Crankcase & Cylinder




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 2   | <a href="#">6F3151000494</a><br>Crankcase assembly (140a model) | <a href="#">Buy now</a> |
| 3   | <a href="#">624113790000</a><br>Valve, check                    | <a href="#">Buy now</a> |
| 4   | <a href="#">663115180100</a><br>Lock, bearing                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5113720000</a><br>Nipple, hose                    | <a href="#">Buy now</a> |
| 7   | <a href="#">9034014M0600</a><br>Plug, straight screw(62y)       | <a href="#">Buy now</a> |
| 8   | <a href="#">904301411500</a><br>Gasket (663)                    | <a href="#">Buy now</a> |
| 9   | <a href="#">936081206300</a><br>Pin, dowel (626)                | <a href="#">Buy now</a> |
| 10  | <a href="#">9011608M1400</a><br>Bolt, stud (6e5)                | <a href="#">Buy now</a> |
| 11  | <a href="#">9010510M2000</a><br>Bolt (6e5)                      | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5113250000</a><br>Anode                           | <a href="#">Buy now</a> |
| 14  | <a href="#">986800401600</a><br>Screw, flat head(ga5)           | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5111190000</a><br>Hanger, Engine                  | <a href="#">Buy now</a> |
| 16  | <a href="#">970130802000</a><br>Bolt(6td)                       | <a href="#">Buy now</a> |
| 17  | <a href="#">929030810000</a><br>Ybs67-8 washer, spring          | <a href="#">Buy now</a> |
| 18  | <a href="#">6E511371001S</a><br>Cover                           | <a href="#">Buy now</a> |

# Crankcase & Cylinder




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 19  | <a href="#">6E5113810000</a><br>Gasket 1                | <a href="#">Buy now</a> |
| 20  | <a href="#">973130602000</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 21  | <a href="#">929900660000</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5427610094</a><br>Stopper                 | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5427620094</a><br>Stopper                 | <a href="#">Buy now</a> |
| 24  | <a href="#">663445330000</a><br>Damper, upper mount     | <a href="#">Buy now</a> |
| 25  | <a href="#">970800602000</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 26  | <a href="#">929030660000</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5111110094</a><br>Head, cylinder 1        | <a href="#">Buy now</a> |
| 28  | <a href="#">6E511181A200</a><br>Gasket, cylinder head 1 | <a href="#">Buy now</a> |
| 29  | <a href="#">9011908M2100</a><br>Bolt, with washer(63v)  | <a href="#">Buy now</a> |
| 30  | <a href="#">6E511191019M</a><br>Cover, cylinder head 1  | <a href="#">Buy now</a> |
| 31  | <a href="#">6E511193A000</a><br>Gasket, head cover 1    | <a href="#">Buy now</a> |
| 32  | <a href="#">973130603000</a><br>Bolt                    | <a href="#">Buy now</a> |
| 34  | <a href="#">9048020M0500</a><br>Grommet (688)           | <a href="#">Buy now</a> |

# Crankcase & Cylinder




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 35  | <a href="#">60H124160000</a><br>Valve, pressure control     | <a href="#">Buy now</a> |
| 36  | <a href="#">9050116M1100</a><br>Spring, compression (688)   | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5124111000</a><br>Thermostat                  | <a href="#">Buy now</a> |
| 38  | <a href="#">6G512413001S</a><br>Cover, thermostat           | <a href="#">Buy now</a> |
| 39  | <a href="#">688124140000</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 40  | <a href="#">973130604000</a><br>Bolt (682)                  | <a href="#">Buy now</a> |
| 42  | <a href="#">6E541111009M</a><br>Inner cover, exhaust        | <a href="#">Buy now</a> |
| 43  | <a href="#">6E5411120000</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 44  | <a href="#">6N741113001S</a><br>Outer cover, exhaust        | <a href="#">Buy now</a> |
| 45  | <a href="#">650243780000</a><br>Pipe, joint 2               | <a href="#">Buy now</a> |
| 46  | <a href="#">6E5243120000</a><br>Pipe 2                      | <a href="#">Buy now</a> |
| 47  | <a href="#">904670800400</a><br>Clip, pipe 6162435600       | <a href="#">Buy now</a> |
| 48  | <a href="#">970140603500</a><br>Bolt(3rv)                   | <a href="#">Buy now</a> |
| 50  | <a href="#">6G5113820000</a><br>Gasket 2                    | <a href="#">Buy now</a> |
| 51  | <a href="#">6G511372001S</a><br>Cover, bypass 2             | <a href="#">Buy now</a> |

## Crankcase & Cylinder




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 54  | <a href="#">6G5125760000</a><br>Hose 1                 | <a href="#">Buy now</a> |
| 55  | <a href="#">9046513M3000</a><br>Clamp                  | <a href="#">Buy now</a> |
| 56  | <a href="#">947020024700</a><br>Plug, spark (br8hs-10) | <a href="#">Buy now</a> |
| 57  | <a href="#">9046508M0800</a><br>Clamp (6e5)            | <a href="#">Buy now</a> |
| 58  | <a href="#">9046508M0700</a><br>Clamp (1e6)            | <a href="#">Buy now</a> |

## Crankshaft & Piston




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 2   | <a href="#">9310240M1400</a><br>Oil seal(61a)                | <a href="#">Buy now</a> |
| 3   | <a href="#">9321104M3600</a><br>O-ring (705)                 | <a href="#">Buy now</a> |
| 4   | <a href="#">93311940U300</a><br>Brg,cyl-cal roller 36g (6e5) | <a href="#">Buy now</a> |
| 5   | <a href="#">970800602000</a><br>Bolt(7u8)                    | <a href="#">Buy now</a> |
| 6   | <a href="#">929030660000</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5114110100</a><br>Shaft, crank 1               | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5114470000</a><br>Seal, ring                   | <a href="#">Buy now</a> |
| 9   | <a href="#">93310954U100</a><br>Bearing, cylindrical(64c)    | <a href="#">Buy now</a> |
| 10  | <a href="#">93306208U000</a><br>Brg,r-b 6208 80mm 345g (6e5) | <a href="#">Buy now</a> |
| 11  | <a href="#">9341040M0300</a><br>Circlip(n02)                 | <a href="#">Buy now</a> |
| 12  | <a href="#">6G5116360000</a><br>Piston 2 O/s 0.50 (2Nd O.s.) | <a href="#">Buy now</a> |
| 13  | <a href="#">6G5116420093</a><br>Piston Std (Std)             | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5116101300</a><br>Piston Ring Set (1St O/S)    | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5116330100</a><br>Pin Piston                   | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5116340000</a><br>Clip, piston pin             | <a href="#">Buy now</a> |

## Crankshaft & Piston




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">936032111100</a><br>Pin, dowel(663)           | <a href="#">Buy now</a> |
| 18  | <a href="#">9020121M7500</a><br>Washer, plate (6f3)       | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5116500100</a><br>Rod, connecting assembly  | <a href="#">Buy now</a> |
| 20  | <a href="#">901090802200</a><br>Bolt                      | <a href="#">Buy now</a> |
| 21  | <a href="#">93310836V200</a><br>Brg, cyl-cal roller (6e5) | <a href="#">Buy now</a> |
| 22  | <a href="#">6G5153590094</a><br>Housing, oil seal         | <a href="#">Buy now</a> |
| 23  | <a href="#">9310235M1300</a><br>Oil seal (6e5)            | <a href="#">Buy now</a> |
| 24  | <a href="#">9310122M1500</a><br>Oil seal (6e5)            | <a href="#">Buy now</a> |
| 25  | <a href="#">9321074M3500</a><br>O-ring (6e5)              | <a href="#">Buy now</a> |
| 26  | <a href="#">973950602000</a><br>Bolt(7u8)                 | <a href="#">Buy now</a> |
| 27  | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |

# Electric Motor




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5818001100</a><br>Starting motor assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5818501000</a><br>Armature assembly       | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5818091000</a><br>Washer Kit              | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5818101000</a><br>Stator assembly         | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5818471000</a><br>O-ring                  | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5818011000</a><br>Brush ass'y             | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5818401000</a><br>Brush holder ass'y      | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5818201000</a><br>Rear Bracket assembly   | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5818201100</a><br>Rear Bracket assembly   | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5818071100</a><br>Pinion assembly         | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5818571000</a><br>Retainer                | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5818301000</a><br>Front Bracket assembly  | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5818261000</a><br>Bolt                    | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5818220198</a><br>Bracket, starting motor | <a href="#">Buy now</a> |
| 15  | <a href="#">973130802500</a><br>Bolt (682)              | <a href="#">Buy now</a> |

# Electric Motor




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 16  | <a href="#">929030860000</a><br>Washer, plain (663) | <a href="#">Buy now</a> |
| 17  | <a href="#">970130804500</a><br>Bolt                | <a href="#">Buy now</a> |
| 19  | <a href="#">973950801600</a><br>Bolt                | <a href="#">Buy now</a> |
| 20  | <a href="#">929900860000</a><br>Washer, plain (663) | <a href="#">Buy now</a> |

## Electric Parts 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 3   | <a href="#">9038706M0300</a><br>Collar (676)              | <a href="#">Buy now</a> |
| 4   | <a href="#">9011906M2800</a><br>Bolt, With Washer         | <a href="#">Buy now</a> |
| 5   | <a href="#">973950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 6   | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5855401200</a><br>Cdi unit assembly         | <a href="#">Buy now</a> |
| 8   | <a href="#">985800400800</a><br>Screw, pan head (713)     | <a href="#">Buy now</a> |
| 9   | <a href="#">929900420000</a><br>Ybs66-4 washer, plain     | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5855471000</a><br>Damper                    | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5855371000</a><br>Cover                     | <a href="#">Buy now</a> |
| 12  | <a href="#">978030501000</a><br>Screw, pan head(62x)      | <a href="#">Buy now</a> |
| 13  | <a href="#">929900560000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 14  | <a href="#">973130602500</a><br>Bolt                      | <a href="#">Buy now</a> |
| 15  | <a href="#">929030660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 17  | <a href="#">973130602000</a><br>Bolt(7u8)                 | <a href="#">Buy now</a> |
| 19  | <a href="#">688819610000</a><br>Cover                     | <a href="#">Buy now</a> |

## Electric Parts 1




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 20  | <a href="#">978030502500</a><br>Screw, panhead (a93) | <a href="#">Buy now</a> |
| 21  | <a href="#">929030560000</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |

## Electric Parts 2




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5855701000</a><br>Ignition coil assembly    | <a href="#">Buy now</a> |
| 2   | <a href="#">973130603000</a><br>Bolt                      | <a href="#">Buy now</a> |
| 3   | <a href="#">929030660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 4   | <a href="#">904650802800</a><br>Clamp (1e6)               | <a href="#">Buy now</a> |
| 5   | <a href="#">6G1823702000</a><br>Plug cap assembly         | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5819411100</a><br>Starter relay assembly    | <a href="#">Buy now</a> |
| 7   | <a href="#">689819521000</a><br>Holder, starter relay     | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5819481000</a><br>Bracket                   | <a href="#">Buy now</a> |
| 9   | <a href="#">973950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 11  | <a href="#">688825601000</a><br>Thermo switch assembly    | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5861160100</a><br>Wire, pull                | <a href="#">Buy now</a> |
| 14  | <a href="#">916093001000</a><br>Pin, spring (663)         | <a href="#">Buy now</a> |
| 15  | <a href="#">973130601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 17  | <a href="#">932100326100</a><br>O-ring (663)              | <a href="#">Buy now</a> |
| 19  | <a href="#">663821510000</a><br>Fuse                      | <a href="#">Buy now</a> |

## Electric Parts 2




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 20  | <a href="#">6E5821051100</a><br>Battery cable               | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5825190000</a><br>Wire, Earth Lead            | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5825311000</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 23  | <a href="#">973950601200</a><br>Bolt(gh1)                   | <a href="#">Buy now</a> |
| 24  | <a href="#">929900660000</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 25  | <a href="#">9046508M1200</a><br>Clamp (6e5)                 | <a href="#">Buy now</a> |
| 26  | <a href="#">9044610M0100</a><br>Tube (6e5)                  | <a href="#">Buy now</a> |
| 27  | <a href="#">9046512M2500</a><br>Clamp (6e5)                 | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5821170000</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5871490100</a><br>Connector                   | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5825630000</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |
| 31  | <a href="#">6E5825870000</a><br>Gasket                      | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5836140100</a><br>Bracket                     | <a href="#">Buy now</a> |
| 34  | <a href="#">9046513M1800</a><br>Clamp                       | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5243040094</a><br>Fuel pipe joint comp. 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">973130602000</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5243130000</a><br>Pipe 3                  | <a href="#">Buy now</a> |
| 4   | <a href="#">904651009800</a><br>Clamp                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5245600000</a><br>Filter assembly         | <a href="#">Buy now</a> |
| 7   | <a href="#">9321037M2500</a><br>O-ring (655)            | <a href="#">Buy now</a> |
| 8   | <a href="#">6F5245630000</a><br>Element, filter         | <a href="#">Buy now</a> |
| 9   | <a href="#">655245640000</a><br>Packing, filter         | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5245660000</a><br>Bracket, filter         | <a href="#">Buy now</a> |
| 11  | <a href="#">973130601400</a><br>Bolt(gj3)               | <a href="#">Buy now</a> |
| 12  | <a href="#">929950610000</a><br>Washer(6a1)             | <a href="#">Buy now</a> |
| 13  | <a href="#">953030860000</a><br>Nut(6I2)                | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5243140000</a><br>Pipe 4                  | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5244100300</a><br>Fuel pump assembly      | <a href="#">Buy now</a> |
| 16  | <a href="#">985030503500</a><br>Screw, pan head (686)   | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 17  | <a href="#">929030560000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5244130000</a><br>Body 2              | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5244710000</a><br>Diaphragm           | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5244350000</a><br>Gasket, body 2      | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5244110000</a><br>Diaphragm           | <a href="#">Buy now</a> |
| 22  | <a href="#">648244240000</a><br>Seat, spring        | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5244230000</a><br>Spring, diaphragm   | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5244340200</a><br>Gasket, body        | <a href="#">Buy now</a> |
| 25  | <a href="#">6A0244210100</a><br>Valve, check        | <a href="#">Buy now</a> |
| 27  | <a href="#">988130310000</a><br>Nut                 | <a href="#">Buy now</a> |
| 28  | <a href="#">650244310000</a><br>Gasket, fuel pump   | <a href="#">Buy now</a> |
| 29  | <a href="#">970130605000</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 30  | <a href="#">929030660000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 32  | <a href="#">6G5243760000</a><br>Pipe, joint 1       | <a href="#">Buy now</a> |
| 34  | <a href="#">6G5243190000</a><br>Pipe, Oil           | <a href="#">Buy now</a> |

Fuel 2




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 5   | <a href="#">6Y1246100000</a><br>Cap assembly            | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y1242600100</a><br>Fuel meter assembly     | <a href="#">Buy now</a> |
| 7   | <a href="#">6Y1242680000</a><br>Gasket, fuel meter      | <a href="#">Buy now</a> |
| 8   | <a href="#">6Y1243290000</a><br>Seal                    | <a href="#">Buy now</a> |
| 9   | <a href="#">9015705M1900</a><br>Screw, pan head         | <a href="#">Buy now</a> |
| 10  | <a href="#">6Y2243060300</a><br>Fuel pipe comp. 1       | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5243050000</a><br>Fuel pipe joint comp. 2 | <a href="#">Buy now</a> |
| 12  | <a href="#">932100828700</a><br>O-ring (655)            | <a href="#">Buy now</a> |
| 13  | <a href="#">6Y1243050100</a><br>Fuel pipe joint comp. 2 | <a href="#">Buy now</a> |
| 15  | <a href="#">9044513M3300</a><br>Hose (I2050)            | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5243515100</a><br>Band 1                  | <a href="#">Buy now</a> |
| 18  | <a href="#">6Y2243600000</a><br>Primer pump assembly    | <a href="#">Buy now</a> |
| 19  | <a href="#">6E0281000000</a><br>Tool kit                | <a href="#">Buy now</a> |

# Intake




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5144180000</a><br>Cover 2               | <a href="#">Buy now</a> |
| 2   | <a href="#">6E51441K0000</a><br>Emblem 1              | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5144160000</a><br>Gasket, air cleaner   | <a href="#">Buy now</a> |
| 4   | <a href="#">973130602000</a><br>Bolt(7u8)             | <a href="#">Buy now</a> |
| 5   | <a href="#">929900620000</a><br>Ybs66-6 washer, plain | <a href="#">Buy now</a> |
| 7   | <a href="#">624144850000</a><br>Pipe, joint           | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5144850000</a><br>Pipe, joint           | <a href="#">Buy now</a> |
| 9   | <a href="#">9044507M2300</a><br>Hose (I570)           | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5144830000</a><br>Gasket                | <a href="#">Buy now</a> |
| 11  | <a href="#">970800602000</a><br>Bolt(7u8)             | <a href="#">Buy now</a> |
| 12  | <a href="#">929030660000</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5141980000</a><br>Gasket                | <a href="#">Buy now</a> |
| 14  | <a href="#">953030660000</a><br>Nut(661)              | <a href="#">Buy now</a> |
| 15  | <a href="#">929950610000</a><br>Washer(6a1)           | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5136411094</a><br>Manifold 1            | <a href="#">Buy now</a> |

# Intake




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 18  | <a href="#">6E5113700000</a><br>Check valve assembly | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5135520000</a><br>Nozzle               | <a href="#">Buy now</a> |
| 20  | <a href="#">9044507MA300</a><br>Hose (I200)          | <a href="#">Buy now</a> |
| 21  | <a href="#">9044507M2400</a><br>Hose (I390)          | <a href="#">Buy now</a> |
| 22  | <a href="#">9044507M4600</a><br>Hose (I390)          | <a href="#">Buy now</a> |
| 23  | <a href="#">9011606M0800</a><br>Bolt, stud (689)     | <a href="#">Buy now</a> |
| 24  | <a href="#">973130602500</a><br>Bolt                 | <a href="#">Buy now</a> |
| 25  | <a href="#">929900660000</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5136450000</a><br>Gasket, manifold 1   | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5136100000</a><br>Reed valve assembly  | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5W00040000</a><br>Reed set             | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5136210000</a><br>Gasket, valve seat   | <a href="#">Buy now</a> |
| 30  | <a href="#">985800552500</a><br>Screw, panhead (a93) | <a href="#">Buy now</a> |
| 31  | <a href="#">929030560000</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5412710100</a><br>Knob, choke          | <a href="#">Buy now</a> |

# Intake




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 33  | <a href="#">689412730000</a><br>Grommet            | <a href="#">Buy now</a> |
| 34  | <a href="#">661412620200</a><br>Joint, choke lever | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5412560100</a><br>Rod, choke 1       | <a href="#">Buy now</a> |
| 36  | <a href="#">6E5412170000</a><br>Rod, accel. lever  | <a href="#">Buy now</a> |
| 37  | <a href="#">9046508M0700</a><br>Clamp (1e6)        | <a href="#">Buy now</a> |
| 38  | <a href="#">973130601200</a><br>Bolt(gh1)          | <a href="#">Buy now</a> |

## Lower & Drive 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">61U4530013EJ</a><br>Lower Unit assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">6E54530105EJ</a><br>Casing, Lower             | <a href="#">Buy now</a> |
| 4   | <a href="#">688453410000</a><br>Plug, drain               | <a href="#">Buy now</a> |
| 5   | <a href="#">904300802000</a><br>Gasket                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5453210000</a><br>Plate                     | <a href="#">Buy now</a> |
| 7   | <a href="#">932105867700</a><br>O-ring(47x)               | <a href="#">Buy now</a> |
| 8   | <a href="#">931060901400</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 9   | <a href="#">973950602000</a><br>Bolt(7u8)                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9020906M0400</a><br>Washer                    | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5441500200</a><br>Shift cam assembly        | <a href="#">Buy now</a> |
| 12  | <a href="#">934300800600</a><br>Circlip(2r6)              | <a href="#">Buy now</a> |
| 13  | <a href="#">9050111M1000</a><br>Spring, compression (663) | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5443110000</a><br>Housing, water pump       | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5443220000</a><br>Insert, cartridge         | <a href="#">Buy now</a> |
| 16  | <a href="#">9321086M3800</a><br>O-ring (6e5)              | <a href="#">Buy now</a> |

## Lower & Drive 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">932103716000</a><br>O-ring (6g8)              | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5443520000</a><br>Impeller                  | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5443230000</a><br>Outer plate, cartridge    | <a href="#">Buy now</a> |
| 20  | <a href="#">6E544315A000</a><br>Gasket, water pump        | <a href="#">Buy now</a> |
| 21  | <a href="#">936061201900</a><br>Pin, dowel (614)          | <a href="#">Buy now</a> |
| 22  | <a href="#">973950804500</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 23  | <a href="#">9020908M0200</a><br>Washer, plate (688)       | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5455010100</a><br>Drive shaft comp.         | <a href="#">Buy now</a> |
| 25  | <a href="#">9028004M0500</a><br>Key, woodruff (6e5)       | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5453310094</a><br>Housing, bearing          | <a href="#">Buy now</a> |
| 27  | <a href="#">9310128M1600</a><br>Oil seal (6e5)            | <a href="#">Buy now</a> |
| 28  | <a href="#">93315430V500</a><br>Bearing, cylindrical(6k0) | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5455876000</a><br>Shim (t:0.50mm)           | <a href="#">Buy now</a> |
| 31  | <a href="#">9321055M1400</a><br>O-ring (70e)              | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5453440000</a><br>Cover, oil seal           | <a href="#">Buy now</a> |

## Lower & Drive 1




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 33  | <a href="#">970950802500</a><br>Bolt (62g)                    | <a href="#">Buy now</a> |
| 34  | <a href="#">929900860000</a><br>Washer, plain (663)           | <a href="#">Buy now</a> |
| 35  | <a href="#">93315628U900</a><br>Brg,cyl-cal roller (6e5)      | <a href="#">Buy now</a> |
| 36  | <a href="#">6E5455360000</a><br>Sleeve, drive shaft           | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5455510200</a><br>Pinion                        | <a href="#">Buy now</a> |
| 38  | <a href="#">9017016M0100</a><br>Nut, hexagon (688)            | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5455676000</a><br>Shim (t:0.50mm)               | <a href="#">Buy now</a> |
| 40  | <a href="#">93332000U700</a><br>Brg,tapered roller 76mm (6e5) | <a href="#">Buy now</a> |
| 41  | <a href="#">6E5455600100</a><br>Gear 1 assembly               | <a href="#">Buy now</a> |
| 42  | <a href="#">93315425U700</a><br>Brg,cyl-cal roller (6e5)      | <a href="#">Buy now</a> |
| 44  | <a href="#">6E5456340100</a><br>Slide, shift                  | <a href="#">Buy now</a> |
| 45  | <a href="#">9050116M3700</a><br>Spring (6g5)                  | <a href="#">Buy now</a> |
| 46  | <a href="#">935073203100</a><br>Ball (12r)                    | <a href="#">Buy now</a> |
| 47  | <a href="#">935113201700</a><br>Ball (498)                    | <a href="#">Buy now</a> |
| 48  | <a href="#">935031600300</a><br>Ball                          | <a href="#">Buy now</a> |

## Lower & Drive 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 49  | <a href="#">9025008M0700</a><br>Pin, straight (6g5)          | <a href="#">Buy now</a> |
| 50  | <a href="#">9020130M9200</a><br>Washer (6g5)                 | <a href="#">Buy now</a> |
| 51  | <a href="#">6E5456310100</a><br>Clutch, dog                  | <a href="#">Buy now</a> |
| 52  | <a href="#">6E5456330100</a><br>Ring, cross pin              | <a href="#">Buy now</a> |
| 53  | <a href="#">6E5456110100</a><br>Shaft, propeller             | <a href="#">Buy now</a> |
| 54  | <a href="#">6E5455710100</a><br>Gear 2                       | <a href="#">Buy now</a> |
| 55  | <a href="#">6E5455770012</a><br>Shim (t:0.12mm)              | <a href="#">Buy now</a> |
| 56  | <a href="#">6E5455760000</a><br>Washer, thrust 2             | <a href="#">Buy now</a> |
| 57  | <a href="#">93306208U000</a><br>Brg,r-b 6208 80mm 345g (6e5) | <a href="#">Buy now</a> |
| 58  | <a href="#">9321086M3900</a><br>O-ring (6e5)                 | <a href="#">Buy now</a> |
| 59  | <a href="#">6E5453320094</a><br>Housing, bearing             | <a href="#">Buy now</a> |
| 60  | <a href="#">93315430U800</a><br>Bearing                      | <a href="#">Buy now</a> |
| 61  | <a href="#">9310130M1700</a><br>Oil seal (6e5)               | <a href="#">Buy now</a> |
| 62  | <a href="#">902820401000</a><br>Key, strait(663)             | <a href="#">Buy now</a> |
| 63  | <a href="#">688453830100</a><br>Washer, claw                 | <a href="#">Buy now</a> |

## Lower & Drive 1




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 64  | <a href="#">688453840000</a><br>Nut                    | <a href="#">Buy now</a> |
| 65  | <a href="#">6E5453780000</a><br>Nipple, hose           | <a href="#">Buy now</a> |
| 66  | <a href="#">9044507ME900</a><br>Hose (I250)            | <a href="#">Buy now</a> |
| 67  | <a href="#">6E5835581000</a><br>End, nipple            | <a href="#">Buy now</a> |
| 68  | <a href="#">6E5W00780A00</a><br>Water Pump Repair Kit  | <a href="#">Buy now</a> |
| 69  | <a href="#">6E5443224100</a><br>Insert, Cartridge      | <a href="#">Buy now</a> |
| 70  | <a href="#">6E5443234000</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |

## Lower & Drive 2




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">688452140100</a><br>Cover, water inlet        | <a href="#">Buy now</a> |
| 2   | <a href="#">688452150100</a><br>Cover, water inlet        | <a href="#">Buy now</a> |
| 3   | <a href="#">9014205M0300</a><br>Screw, countersunk        | <a href="#">Buy now</a> |
| 4   | <a href="#">901850500200</a><br>Nut nylon (sus)(ex4)      | <a href="#">Buy now</a> |
| 5   | <a href="#">663453760000</a><br>Guide, seal damper        | <a href="#">Buy now</a> |
| 6   | <a href="#">688453750000</a><br>Damper, seal 2            | <a href="#">Buy now</a> |
| 7   | <a href="#">9360812M0500</a><br>Pin, dowel b (6e5)        | <a href="#">Buy now</a> |
| 8   | <a href="#">970951004500</a><br>Bolt(64d)                 | <a href="#">Buy now</a> |
| 9   | <a href="#">929901010000</a><br>Ybs67-10 washer, spring   | <a href="#">Buy now</a> |
| 10  | <a href="#">973751007000</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5453710100</a><br>Trim tab                  | <a href="#">Buy now</a> |
| 13  | <a href="#">9010510M0000</a><br>Bolt, hexagon (663)       | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5443650000</a><br>Damper, water seal 1      | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5443120000</a><br>Cover, water pump housing | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5443660000</a><br>Damper, water seal 2      | <a href="#">Buy now</a> |

## Lower & Drive 2




| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 17  | <a href="#">6E5443610000</a><br>Tube, water                      | <a href="#">Buy now</a> |
| 19  | <a href="#">904651009800</a><br>Clamp                            | <a href="#">Buy now</a> |
| 20  | <a href="#">9044507MF000</a><br>Hose (11160)                     | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5835580000</a><br>End, nipple                      | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5459870000</a><br>Spacer 1                         | <a href="#">Buy now</a> |
| 23  | <a href="#">688459970000</a><br>Spacer 2                         | <a href="#">Buy now</a> |
| 24  | <a href="#">929901820000</a><br>Washer (6e5)                     | <a href="#">Buy now</a> |
| 25  | <a href="#">9017118M0400</a><br>Nut, castle (6e5)                | <a href="#">Buy now</a> |
| 26  | <a href="#">914904003000</a><br>Pin, cotter (663)                | <a href="#">Buy now</a> |
| 27  | <a href="#">688459786098</a><br>Propeller (3x13-1/2"x16"-k)      | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5459781000</a><br>Propeller assembly (3x14"x26"-p) | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5453711000</a><br>Tab-trim                         | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5459941000</a><br>Plate, tooth                     | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5132000000</a><br>Oil Injection Pump assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5134710000</a><br>Plug, Drain                 | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5134750000</a><br>Washer                      | <a href="#">Buy now</a> |
| 6   | <a href="#">9044512M6000</a><br>Hose                        | <a href="#">Buy now</a> |
| 7   | <a href="#">904651009800</a><br>Clamp                       | <a href="#">Buy now</a> |
| 8   | <a href="#">9044507M8500</a><br>Hose (I390)                 | <a href="#">Buy now</a> |
| 9   | <a href="#">9044507M8400</a><br>Hose (I200)                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5131320000</a><br>Joint                       | <a href="#">Buy now</a> |
| 11  | <a href="#">9046807M0200</a><br>Clip (6e5)                  | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5115360000</a><br>Gear, Driven                | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5115370000</a><br>Gear, Driven                | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5131170000</a><br>Collar, distance            | <a href="#">Buy now</a> |
| 15  | <a href="#">9020108M9300</a><br>Washer, plate (6g5)         | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5412410000</a><br>Rod, Link                   | <a href="#">Buy now</a> |
| 17  | <a href="#">953030560000</a><br>Nut, hexagon (663)          | <a href="#">Buy now</a> |

Oil Pump




| Ref | Part                                        |                         |
|-----|---------------------------------------------|-------------------------|
| 18  | <a href="#">6E9412370000</a><br>Joint, link | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5142760100</a><br>Lever       | <a href="#">Buy now</a> |
| 20  | <a href="#">916903001600</a><br>Pin, spring | <a href="#">Buy now</a> |
| 21  | <a href="#">662412370100</a><br>Joint, link | <a href="#">Buy now</a> |
| 22  | <a href="#">9044507M8700</a><br>Hose(62t)   | <a href="#">Buy now</a> |
| 23  | <a href="#">9046407M0600</a><br>Clamp (6e5) | <a href="#">Buy now</a> |

# Oil Tank




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5217080300</a><br>Lock assembly 2          | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5217330100</a><br>Sub tank, oil (10.5l)    | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5243220000</a><br>Pipe 11                  | <a href="#">Buy now</a> |
| 5   | <a href="#">9046513M1100</a><br>Clamp (6e5)              | <a href="#">Buy now</a> |
| 6   | <a href="#">646242510200</a><br>Strainer 1               | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5243190100</a><br>Pipe, oil                | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5819000100</a><br>Oil feed pump assembly   | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5819220000</a><br>Grommet                  | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5243210100</a><br>Pipe 10                  | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5243790000</a><br>Pipe, joint 4            | <a href="#">Buy now</a> |
| 13  | <a href="#">9044511M8800</a><br>Hose (I3000)             | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5857200200</a><br>Oil Level Gauge assembly | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5857210100</a><br>Wire, Lead               | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5217340133</a><br>Holder, oil sub tank     | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5217980133</a><br>Bracket, damper          | <a href="#">Buy now</a> |

# Oil Tank




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 19  | <a href="#">6E5217460000</a><br>Damper                   | <a href="#">Buy now</a> |
| 20  | <a href="#">973800610000</a><br>Bolt, hexagon            | <a href="#">Buy now</a> |
| 21  | <a href="#">929900660000</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 23  | <a href="#">6A0823170000</a><br>Damper, ignition coil    | <a href="#">Buy now</a> |
| 24  | <a href="#">624425420000</a><br>Collar                   | <a href="#">Buy now</a> |
| 25  | <a href="#">9020106M6200</a><br>Washer, plate (6e5)      | <a href="#">Buy now</a> |
| 26  | <a href="#">973130603000</a><br>Bolt                     | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5857301200</a><br>Oil Level Gauge assembly | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5857400100</a><br>Control unit kit         | <a href="#">Buy now</a> |
| 33  | <a href="#">6E5243230000</a><br>Pipe 12                  | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5244610000</a><br>Pipe, joint              | <a href="#">Buy now</a> |
| 35  | <a href="#">904651009800</a><br>Clamp                    | <a href="#">Buy now</a> |
| 36  | <a href="#">9044505M6100</a><br>Hose                     | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5825510100</a><br>Stop Switch assembly     | <a href="#">Buy now</a> |
| 38  | <a href="#">953800660000</a><br>Nut(661)                 | <a href="#">Buy now</a> |

# Oil Tank




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 39  | <a href="#">6E5813150000</a><br>Lead Wire Assembly | <a href="#">Buy now</a> |

## Optional Parts 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">688825401000</a><br>Neutral switch assembly     | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5825540000</a><br>Stay, neutral switch        | <a href="#">Buy now</a> |
| 3   | <a href="#">663825550100</a><br>Plate                       | <a href="#">Buy now</a> |
| 4   | <a href="#">688825411000</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 5   | <a href="#">970950601600</a><br>Bolt, hexagon deep recess   | <a href="#">Buy now</a> |
| 6   | <a href="#">929030610000</a><br>Washer(6a1)                 | <a href="#">Buy now</a> |
| 7   | <a href="#">688825701500</a><br>Panel switch assembly       | <a href="#">Buy now</a> |
| 8   | <a href="#">688825711100</a><br>Switch panel                | <a href="#">Buy now</a> |
| 9   | <a href="#">688825101100</a><br>Main switch assembly        | <a href="#">Buy now</a> |
| 10  | <a href="#">688825740000</a><br>Switch, choke               | <a href="#">Buy now</a> |
| 11  | <a href="#">688825750100</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 12  | <a href="#">682825560000</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 13  | <a href="#">663825810100</a><br>Stay, cord clamp            | <a href="#">Buy now</a> |
| 14  | <a href="#">983030400800</a><br>Screw, pan head (713)       | <a href="#">Buy now</a> |
| 15  | <a href="#">929010410000</a><br>Ybs67-4 washer, spring      | <a href="#">Buy now</a> |

## Optional Parts 1




| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 16  | <a href="#">688825350000</a><br>Plug(2gu)                      | <a href="#">Buy now</a> |
| 17  | <a href="#">989030502500</a><br>Screw, bind                    | <a href="#">Buy now</a> |
| 18  | <a href="#">953800560000</a><br>Nut, hexagon (663)             | <a href="#">Buy now</a> |
| 19  | <a href="#">929030510000</a><br>Ybs67-5 washer, spring         | <a href="#">Buy now</a> |
| 20  | <a href="#">929030560000</a><br>Washer, plain (646)            | <a href="#">Buy now</a> |
| 21  | <a href="#">6888258A1000</a><br>10p main harness mec 2m (7ft)  | <a href="#">Buy now</a> |
| 22  | <a href="#">6888258A3000</a><br>10p main harness mec 3m (10ft) | <a href="#">Buy now</a> |

## Optional Parts 2




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y5W00800000</a><br>Tachometer Kit               | <a href="#">Buy now</a> |
| 2   | <a href="#">6Y5835400000</a><br>Tachometer assembly          | <a href="#">Buy now</a> |
| 3   | <a href="#">688835160000</a><br>Bulb, pilot (t6.5, 12v-1.7w) | <a href="#">Buy now</a> |
| 4   | <a href="#">688835360000</a><br>Socket, meter                | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y5835230000</a><br>Damper                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y5835140000</a><br>Plate, fitting               | <a href="#">Buy now</a> |
| 8   | <a href="#">3FV835170000</a><br>Bulb (12v-1.7w) t6.5         | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y5835530000</a><br>Wire, lead (l=2.5m)          | <a href="#">Buy now</a> |
| 10  | <a href="#">1E6821510000</a><br>Fuse (10a)                   | <a href="#">Buy now</a> |
| 11  | <a href="#">6Y5W00812000</a><br>Speedometer Kit              | <a href="#">Buy now</a> |
| 17  | <a href="#">6Y5835571000</a><br>Tube (8m)                    | <a href="#">Buy now</a> |
| 18  | <a href="#">9046511M1000</a><br>Clamp                        | <a href="#">Buy now</a> |
| 19  | <a href="#">906013140200</a><br>021-58119-01 clip,nylon 14   | <a href="#">Buy now</a> |
| 20  | <a href="#">977804011600</a><br>Screw,panh.tapping           | <a href="#">Buy now</a> |
| 21  | <a href="#">6Y5W00880000</a><br>Water Pressure Meter Kit     | <a href="#">Buy now</a> |

## Optional Parts 2




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 22  | <a href="#">6Y5836600000</a><br>Water pressure meter assembly | <a href="#">Buy now</a> |
| 24  | <a href="#">6Y5835360000</a><br>Socket, meter                 | <a href="#">Buy now</a> |
| 25  | <a href="#">688836640000</a><br>Damper                        | <a href="#">Buy now</a> |
| 26  | <a href="#">688836650000</a><br>Plate, fitting                | <a href="#">Buy now</a> |
| 27  | <a href="#">688836670000</a><br>Sender                        | <a href="#">Buy now</a> |
| 28  | <a href="#">688836660000</a><br>Tube                          | <a href="#">Buy now</a> |
| 29  | <a href="#">663836680000</a><br>Nut, nipple                   | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y5W00883000</a><br>Hour meter kit                   | <a href="#">Buy now</a> |
| 2   | <a href="#">6Y5835040000</a><br>Hour meter kit                   | <a href="#">Buy now</a> |
| 3   | <a href="#">688836640000</a><br>Damper                           | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y5835180000</a><br>Bulb (12v-1.7w) t6.5             | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y5835360000</a><br>Socket, meter                    | <a href="#">Buy now</a> |
| 7   | <a href="#">66383553A000</a><br>Wire, lead                       | <a href="#">Buy now</a> |
| 8   | <a href="#">66383553Y000</a><br>Wire, lead                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y5W00881000</a><br>Water Temp. Meter Kit            | <a href="#">Buy now</a> |
| 10  | <a href="#">6Y5835900000</a><br>Water temperature assembly       | <a href="#">Buy now</a> |
| 14  | <a href="#">688836650000</a><br>Plate, fitting                   | <a href="#">Buy now</a> |
| 15  | <a href="#">688835910000</a><br>Thermo unit                      | <a href="#">Buy now</a> |
| 16  | <a href="#">904301411500</a><br>Gasket (663)                     | <a href="#">Buy now</a> |
| 19  | <a href="#">6Y5W00882000</a><br>Fuel meter kit                   | <a href="#">Buy now</a> |
| 20  | <a href="#">6Y5857500000</a><br>Fuel meter assembly              | <a href="#">Buy now</a> |
| 25  | <a href="#">688857520100</a><br>Sender unit assembly, fuel meter | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 28  | <a href="#">6Y5835030000</a><br>Voltmeter assembly | <a href="#">Buy now</a> |

## Optional Parts 4




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">688833831100</a><br>Buzzer               | <a href="#">Buy now</a> |
| 2   | <a href="#">977805011200</a><br>Screw, tapping(61a)  | <a href="#">Buy now</a> |
| 3   | <a href="#">688833731000</a><br>Lead, horn           | <a href="#">Buy now</a> |
| 5   | <a href="#">663843010000</a><br>Pilot lamp ass'y     | <a href="#">Buy now</a> |
| 6   | <a href="#">663843090000</a><br>Plate set            | <a href="#">Buy now</a> |
| 7   | <a href="#">954283131600</a><br>Screw, round tapping | <a href="#">Buy now</a> |
| 9   | <a href="#">977806012000</a><br>Screw, tapping(6k8)  | <a href="#">Buy now</a> |
| 10  | <a href="#">929030660000</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 11  | <a href="#">663825210900</a><br>Wire, Lead           | <a href="#">Buy now</a> |
| 12  | <a href="#">688825200000</a><br>Lamp switch assembly | <a href="#">Buy now</a> |
| 13  | <a href="#">688825260000</a><br>Switch, lamp         | <a href="#">Buy now</a> |
| 14  | <a href="#">688825631000</a><br>Trim & tilt switch   | <a href="#">Buy now</a> |
| 15  | <a href="#">688823880000</a><br>Plate                | <a href="#">Buy now</a> |
| 16  | <a href="#">977804011600</a><br>Screw,panh.tapping   | <a href="#">Buy now</a> |
| 17  | <a href="#">688821490000</a><br>Wire, lead 3         | <a href="#">Buy now</a> |

## Optional Parts 4




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 18  | <a href="#">6Y5821170000</a><br>Wire, lead          | <a href="#">Buy now</a> |
| 19  | <a href="#">688825210000</a><br>Wire, lead          | <a href="#">Buy now</a> |
| 20  | <a href="#">6Y5835530000</a><br>Wire, lead (l=2.5m) | <a href="#">Buy now</a> |
| 21  | <a href="#">1E6821510000</a><br>Fuse (10a)          | <a href="#">Buy now</a> |

## Optional Parts 5




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 2   | <a href="#">9050112M1300</a><br>Spring, compression (688) | <a href="#">Buy now</a> |
| 3   | <a href="#">688245540000</a><br>Shaft, cock               | <a href="#">Buy now</a> |
| 4   | <a href="#">688245590000</a><br>Cap                       | <a href="#">Buy now</a> |
| 5   | <a href="#">9321020M2800</a><br>O-ring (688)              | <a href="#">Buy now</a> |
| 6   | <a href="#">9321008M2700</a><br>O-ring                    | <a href="#">Buy now</a> |
| 7   | <a href="#">9020108M3200</a><br>Washer (688)              | <a href="#">Buy now</a> |
| 8   | <a href="#">987800401600</a><br>Screw, flat head(ga5)     | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y2243050100</a><br>Fuel pipe joint comp. 2   | <a href="#">Buy now</a> |
| 10  | <a href="#">932100828700</a><br>O-ring (655)              | <a href="#">Buy now</a> |
| 11  | <a href="#">9044513M3200</a><br>Hose (l2500)              | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5243510000</a><br>Band 1                    | <a href="#">Buy now</a> |

## Power Trim & Tilt




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 3   | <a href="#">901850805700</a><br>Nut, nylon (6j8)        | <a href="#">Buy now</a> |
| 4   | <a href="#">6Y5836700000</a><br>Trim Meter assembly     | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y5835180000</a><br>Bulb (12v-1.7w) t6.5    | <a href="#">Buy now</a> |
| 6   | <a href="#">688836640000</a><br>Damper                  | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5836720100</a><br>Trim sender             | <a href="#">Buy now</a> |
| 8   | <a href="#">985800601600</a><br>Screw pan head          | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y5835530000</a><br>Wire, lead (l=2.5m)     | <a href="#">Buy now</a> |
| 10  | <a href="#">1E6821510000</a><br>Fuse (10a)              | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5825531000</a><br>Extension, Wire Harness | <a href="#">Buy now</a> |
| 12  | <a href="#">9046511M1000</a><br>Clamp                   | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 2   | <a href="#">6E5438040000</a><br>Stator Assembly                    | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5438910000</a><br>Brush                              | <a href="#">Buy now</a> |
| 4   | <a href="#">9050105M5400</a><br>Spring (6e5)                       | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5438050000</a><br>Armature Assembly                  | <a href="#">Buy now</a> |
| 6   | <a href="#">9321071M7600</a><br>O-Ring (6E5)                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5438840000</a><br>Frame, Commutator End              | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5438850000</a><br>Grommet                            | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5438860000</a><br>Bolt                               | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5438670000</a><br>O-ring                             | <a href="#">Buy now</a> |
| 11  | <a href="#">9020105M0100</a><br>Washer                             | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5438100300</a><br>Piston Sub-Assembly (6E5-43810-02) | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5438610000</a><br>O-ring 1                           | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5438620000</a><br>O-ring 2                           | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5438720000</a><br>Ring, back-up 2                    | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5438140100</a><br>Piston, free                       | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 20  | <a href="#">6E5438290000</a><br>Plug, reservoir          | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5438630000</a><br>O-ring                   | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5438180000</a><br>Pin, lower shock mount   | <a href="#">Buy now</a> |
| 23  | <a href="#">9038618M1400</a><br>Bushing (6e5)            | <a href="#">Buy now</a> |
| 24  | <a href="#">9010106M8500</a><br>Bolt, with washer(6e5)   | <a href="#">Buy now</a> |
| 25  | <a href="#">9020906M0900</a><br>Washer                   | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5438200200</a><br>Piston sub assembly      | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5438640000</a><br>O-ring 4                 | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5438740100</a><br>Ring, back-up 4          | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5438210100</a><br>Screw, trim cylinder end | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5438220100</a><br>Seal, trim dust          | <a href="#">Buy now</a> |
| 31  | <a href="#">6E5438650000</a><br>O-ring 5                 | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5438020000</a><br>Valve Sub Assembly       | <a href="#">Buy now</a> |
| 33  | <a href="#">6E5438660000</a><br>O-ring                   | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5438410100</a><br>Piston, Shuttle          | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 36  | <a href="#">6E5438680000</a><br>O-Ring               | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5438690000</a><br>O-ring 9             | <a href="#">Buy now</a> |
| 38  | <a href="#">6E5438330100</a><br>Pipe 1               | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5438340100</a><br>Pipe 2               | <a href="#">Buy now</a> |
| 40  | <a href="#">6E5438350000</a><br>Pipe                 | <a href="#">Buy now</a> |
| 41  | <a href="#">6E5438510100</a><br>Seat, relief valve   | <a href="#">Buy now</a> |
| 42  | <a href="#">6E5438440200</a><br>Pin, Valve Support   | <a href="#">Buy now</a> |
| 43  | <a href="#">6E5438580000</a><br>Ball 1               | <a href="#">Buy now</a> |
| 44  | <a href="#">6E5438560000</a><br>Spring, down relief  | <a href="#">Buy now</a> |
| 45  | <a href="#">6E5438830000</a><br>O-ring 10            | <a href="#">Buy now</a> |
| 46  | <a href="#">6E5438430000</a><br>Screw, Valve Lock    | <a href="#">Buy now</a> |
| 47  | <a href="#">6E5438550000</a><br>Spring Up Relief     | <a href="#">Buy now</a> |
| 48  | <a href="#">6E5438590000</a><br>Pin, valve support   | <a href="#">Buy now</a> |
| 49  | <a href="#">6E5438770100</a><br>Ball 2               | <a href="#">Buy now</a> |
| 50  | <a href="#">6E5438950000</a><br>Seat, relief valve 2 | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 51  | <a href="#">6E5438960000</a><br>O-ring                 | <a href="#">Buy now</a> |
| 52  | <a href="#">6E5438161000</a><br>Filter 1               | <a href="#">Buy now</a> |
| 53  | <a href="#">6E5438171000</a><br>Filter 2               | <a href="#">Buy now</a> |
| 54  | <a href="#">9010906M2100</a><br>Bolt (6e5)             | <a href="#">Buy now</a> |
| 55  | <a href="#">6E5438970000</a><br>O-Ring                 | <a href="#">Buy now</a> |
| 56  | <a href="#">6E5438380000</a><br>Pipe, Intake           | <a href="#">Buy now</a> |
| 58  | <a href="#">6E5438880100</a><br>Bolt, socket           | <a href="#">Buy now</a> |
| 60  | <a href="#">6E5438310000</a><br>Connector, shaft       | <a href="#">Buy now</a> |
| 61  | <a href="#">6E5438300000</a><br>Gear Pump assembly     | <a href="#">Buy now</a> |
| 62  | <a href="#">9321007M7800</a><br>O-ring (6e5)           | <a href="#">Buy now</a> |
| 63  | <a href="#">6E5438470000</a><br>Seat, manual valve     | <a href="#">Buy now</a> |
| 64  | <a href="#">6E5438540100</a><br>Spring, manual release | <a href="#">Buy now</a> |
| 65  | <a href="#">6E54382A0000</a><br>Adaptor 1              | <a href="#">Buy now</a> |
| 66  | <a href="#">9321010M7400</a><br>O-ring                 | <a href="#">Buy now</a> |
| 67  | <a href="#">6E5438450100</a><br>Screw, manual release  | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 68  | <a href="#">9321018M7500</a><br>O-ring (6e5)         | <a href="#">Buy now</a> |
| 69  | <a href="#">6E5438750000</a><br>Ring, snap           | <a href="#">Buy now</a> |
| 70  | <a href="#">9020105M0000</a><br>Washer (6E5)         | <a href="#">Buy now</a> |
| 71  | <a href="#">6E54381A0000</a><br>Shaft                | <a href="#">Buy now</a> |
| 72  | <a href="#">6E5438490100</a><br>Pin, valve support   | <a href="#">Buy now</a> |
| 73  | <a href="#">6E5438240100</a><br>Spring Down Relief 2 | <a href="#">Buy now</a> |
| 74  | <a href="#">9321006M7700</a><br>O-Ring               | <a href="#">Buy now</a> |
| 75  | <a href="#">6E5438420000</a><br>Screw, valve seat    | <a href="#">Buy now</a> |

## Remote Control




| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703482011000</a><br>Remote control assembly (10p)              | <a href="#">Buy now</a> |
| 2   | <a href="#">703482031600</a><br>Remote control assembly (7p)               | <a href="#">Buy now</a> |
| 3   | <a href="#">704482051000</a><br>Remote Control assembly, Single Binn W/ptt | <a href="#">Buy now</a> |
| 4   | <a href="#">70448207R000</a><br>704 twin top mount (mec rc)                | <a href="#">Buy now</a> |
| 5   | <a href="#">MARCABLE11SC</a><br>Remote Control Cable 11' :ob               | <a href="#">Buy now</a> |
| 6   | <a href="#">703482900100</a><br>Twin attachment                            | <a href="#">Buy now</a> |

## Remote Control Assy 1 (703 Type)




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 1   | <a href="#">703482611000</a><br>Arm, throttle      | <a href="#">Buy now</a> |
| 3   | <a href="#">703481530000</a><br>Shaft, free accel. | <a href="#">Buy now</a> |
| 4   | <a href="#">702482350000</a><br>Bushing            | <a href="#">Buy now</a> |
| 5   | <a href="#">703482730000</a><br>Bushing            | <a href="#">Buy now</a> |
| 7   | <a href="#">703482680000</a><br>Spacer 3           | <a href="#">Buy now</a> |
| 8   | <a href="#">703482630000</a><br>Bushing            | <a href="#">Buy now</a> |
| 9   | <a href="#">703482640000</a><br>Throttle, friction | <a href="#">Buy now</a> |
| 10  | <a href="#">953800560000</a><br>Nut, hexagon (663) | <a href="#">Buy now</a> |
| 12  | <a href="#">703482650000</a><br>Shaft Friction     | <a href="#">Buy now</a> |
| 13  | <a href="#">934300602400</a><br>Circlip (701)      | <a href="#">Buy now</a> |
| 14  | <a href="#">703482450000</a><br>Plate, lock        | <a href="#">Buy now</a> |
| 15  | <a href="#">703482520000</a><br>Roller, cam        | <a href="#">Buy now</a> |
| 16  | <a href="#">701482480000</a><br>Roller, free accel | <a href="#">Buy now</a> |
| 17  | <a href="#">703481980000</a><br>Washer, wave 3     | <a href="#">Buy now</a> |
| 18  | <a href="#">703482430000</a><br>Bushing 3          | <a href="#">Buy now</a> |

## Remote Control Assy 1 (703 Type)




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 19  | <a href="#">703482360000</a><br>Bushing                     | <a href="#">Buy now</a> |
| 20  | <a href="#">703481890000</a><br>Retainer                    | <a href="#">Buy now</a> |
| 21  | <a href="#">703482340000</a><br>Roller, detent              | <a href="#">Buy now</a> |
| 22  | <a href="#">703483450000</a><br>Cable end, remote control 2 | <a href="#">Buy now</a> |
| 23  | <a href="#">701483580000</a><br>Anchor, cable               | <a href="#">Buy now</a> |
| 24  | <a href="#">703482440000</a><br>Spring, free accel.         | <a href="#">Buy now</a> |
| 25  | <a href="#">703482380000</a><br>Spring, detent              | <a href="#">Buy now</a> |
| 26  | <a href="#">703482460000</a><br>Spacer 1                    | <a href="#">Buy now</a> |
| 29  | <a href="#">703482260000</a><br>Plate, stopper              | <a href="#">Buy now</a> |
| 30  | <a href="#">703482220000</a><br>Grip, control lever         | <a href="#">Buy now</a> |
| 31  | <a href="#">703482230000</a><br>Lock, neutral               | <a href="#">Buy now</a> |
| 32  | <a href="#">703482250000</a><br>Cover                       | <a href="#">Buy now</a> |
| 33  | <a href="#">703482190000</a><br>Cover, lead                 | <a href="#">Buy now</a> |
| 34  | <a href="#">987800501200</a><br>Screw(617)                  | <a href="#">Buy now</a> |
| 35  | <a href="#">987800501600</a><br>Ybs53-516 screw,flat head   | <a href="#">Buy now</a> |

## Remote Control Assy 1 (703 Type)




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 36  | <a href="#">973800803000</a><br>Bolt, hexagon (fj1)         | <a href="#">Buy now</a> |
| 37  | <a href="#">929900860000</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |
| 38  | <a href="#">985800401000</a><br>Screw, pan head (e56)       | <a href="#">Buy now</a> |
| 39  | <a href="#">985800400600</a><br>Screw, pan head (7h3)       | <a href="#">Buy now</a> |
| 40  | <a href="#">985800501000</a><br>Screw, pan head(62x)        | <a href="#">Buy now</a> |
| 41  | <a href="#">985800301400</a><br>Screw, pan head (n151)      | <a href="#">Buy now</a> |
| 42  | <a href="#">926800609000</a><br>Screw                       | <a href="#">Buy now</a> |
| 43  | <a href="#">953800660000</a><br>Nut(661)                    | <a href="#">Buy now</a> |
| 44  | <a href="#">703482930000</a><br>Spacer, remote control      | <a href="#">Buy now</a> |
| 45  | <a href="#">701482870000</a><br>Washer 1                    | <a href="#">Buy now</a> |
| 46  | <a href="#">703482150000</a><br>Graphic                     | <a href="#">Buy now</a> |
| 48  | <a href="#">703825101800</a><br>Main Switch                 | <a href="#">Buy now</a> |
| 49  | <a href="#">703825740000</a><br>Switch, choke               | <a href="#">Buy now</a> |
| 50  | <a href="#">703825310000</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 51  | <a href="#">688825750200</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |

## Remote Control Assy 1 (703 Type)




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 52  | <a href="#">682825560000</a><br>Lanyard, stop switch          | <a href="#">Buy now</a> |
| 53  | <a href="#">6888258A2000</a><br>10p main harness mec 2m (6ft) | <a href="#">Buy now</a> |
| 54  | <a href="#">703825400000</a><br>Neutral switch assembly       | <a href="#">Buy now</a> |
| 55  | <a href="#">703833831100</a><br>Buzzer                        | <a href="#">Buy now</a> |
| 56  | <a href="#">703482840000</a><br>Grommet                       | <a href="#">Buy now</a> |
| 57  | <a href="#">703825910000</a><br>Band                          | <a href="#">Buy now</a> |
| 58  | <a href="#">80L263970000</a><br>Band                          | <a href="#">Buy now</a> |
| 59  | <a href="#">703482270000</a><br>Spring, neutral lock          | <a href="#">Buy now</a> |
| 60  | <a href="#">703482210000</a><br>Grip                          | <a href="#">Buy now</a> |

## Remote Control Assy 2 (704 Type)




| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">704482051000</a><br>Remote Control assembly, Single Binn W/ptt | <a href="#">Buy now</a> |
| 2   | <a href="#">EL8482510000</a><br>Plate, cam                                 | <a href="#">Buy now</a> |
| 3   | <a href="#">704482650000</a><br>Shaft, friction                            | <a href="#">Buy now</a> |
| 4   | <a href="#">701482460000</a><br>Spacer                                     | <a href="#">Buy now</a> |
| 5   | <a href="#">934300602400</a><br>Circlip (701)                              | <a href="#">Buy now</a> |
| 6   | <a href="#">929901060000</a><br>Washer, plate                              | <a href="#">Buy now</a> |
| 7   | <a href="#">EL8482590000</a><br>Circlip 1                                  | <a href="#">Buy now</a> |
| 8   | <a href="#">704482620000</a><br>Shaft, throttle                            | <a href="#">Buy now</a> |
| 9   | <a href="#">704482640000</a><br>Friction, throttle                         | <a href="#">Buy now</a> |
| 10  | <a href="#">704482660000</a><br>Spacer 2                                   | <a href="#">Buy now</a> |
| 11  | <a href="#">6XE825401000</a><br>Neutral switch assembly                    | <a href="#">Buy now</a> |
| 13  | <a href="#">EL8482810000</a><br>Screw 1                                    | <a href="#">Buy now</a> |
| 14  | <a href="#">704482150000</a><br>Graphic 1                                  | <a href="#">Buy now</a> |
| 15  | <a href="#">704482810000</a><br>Screw1                                     | <a href="#">Buy now</a> |
| 16  | <a href="#">978900502500</a><br>Screw, panhead (a93)                       | <a href="#">Buy now</a> |

## Remote Control Assy 2 (704 Type)




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 17  | <a href="#">704482610000</a><br>Arm, throttle               | <a href="#">Buy now</a> |
| 18  | <a href="#">EL8481910000</a><br>Washer 1                    | <a href="#">Buy now</a> |
| 19  | <a href="#">985800554000</a><br>Screw, panhead (eg9)        | <a href="#">Buy now</a> |
| 20  | <a href="#">973800601800</a><br>Bolt (fj0)                  | <a href="#">Buy now</a> |
| 21  | <a href="#">703483450000</a><br>Cable end, remote control 2 | <a href="#">Buy now</a> |
| 22  | <a href="#">704482870000</a><br>Washer 1                    | <a href="#">Buy now</a> |
| 23  | <a href="#">953800560000</a><br>Nut, hexagon (663)          | <a href="#">Buy now</a> |
| 24  | <a href="#">EL8482710000</a><br>Arm, shift                  | <a href="#">Buy now</a> |
| 25  | <a href="#">EL8481270000</a><br>Screw 1                     | <a href="#">Buy now</a> |
| 27  | <a href="#">EL8482310000</a><br>Housing, gear               | <a href="#">Buy now</a> |
| 28  | <a href="#">EL8482410000</a><br>Arm, drive                  | <a href="#">Buy now</a> |
| 29  | <a href="#">EL8482540000</a><br>Stopper Throttle Adjusting  | <a href="#">Buy now</a> |
| 30  | <a href="#">987800602000</a><br>Screw flat head             | <a href="#">Buy now</a> |
| 31  | <a href="#">EL8481580000</a><br>Spring 1                    | <a href="#">Buy now</a> |
| 32  | <a href="#">985800400600</a><br>Screw, pan head (7h3)       | <a href="#">Buy now</a> |

## Remote Control Assy 2 (704 Type)




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 33  | <a href="#">987800501800</a><br>Screw (704)                 | <a href="#">Buy now</a> |
| 34  | <a href="#">EL8482440000</a><br>Spring, free accel.         | <a href="#">Buy now</a> |
| 35  | <a href="#">EL8482450000</a><br>Plate, lock                 | <a href="#">Buy now</a> |
| 36  | <a href="#">703482630000</a><br>Bushing                     | <a href="#">Buy now</a> |
| 37  | <a href="#">704482220000</a><br>Grip, control lever         | <a href="#">Buy now</a> |
| 38  | <a href="#">704825940000</a><br>Clamp                       | <a href="#">Buy now</a> |
| 39  | <a href="#">704482280000</a><br>Holder, switch              | <a href="#">Buy now</a> |
| 40  | <a href="#">704825633100</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |
| 41  | <a href="#">704482290000</a><br>Grip, control lever 2       | <a href="#">Buy now</a> |
| 42  | <a href="#">929900530000</a><br>Washer, tooth               | <a href="#">Buy now</a> |
| 43  | <a href="#">953800660000</a><br>Nut(661)                    | <a href="#">Buy now</a> |
| 44  | <a href="#">701482480000</a><br>Roller, free accel          | <a href="#">Buy now</a> |
| 45  | <a href="#">703482380000</a><br>Spring, detent              | <a href="#">Buy now</a> |
| 46  | <a href="#">EL8482320000</a><br>Gear 1                      | <a href="#">Buy now</a> |
| 47  | <a href="#">EL8481640000</a><br>Pin 2                       | <a href="#">Buy now</a> |

## Remote Control Assy 2 (704 Type)



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 48  | <a href="#">704482420000</a><br>Shaft, drive         | <a href="#">Buy now</a> |
| 49  | <a href="#">704482250000</a><br>Cover                | <a href="#">Buy now</a> |
| 50  | <a href="#">704481920000</a><br>Washer 2             | <a href="#">Buy now</a> |
| 51  | <a href="#">978900601800</a><br>Screw, pan head(6e5) | <a href="#">Buy now</a> |
| 52  | <a href="#">929900630000</a><br>Washer, tooth        | <a href="#">Buy now</a> |
| 54  | <a href="#">EL8482790000</a><br>Circlip 2            | <a href="#">Buy now</a> |
| 55  | <a href="#">704481930000</a><br>Washer 3             | <a href="#">Buy now</a> |
| 56  | <a href="#">EL8482340000</a><br>Bushing 1            | <a href="#">Buy now</a> |
| 57  | <a href="#">704482190000</a><br>Cover, lead          | <a href="#">Buy now</a> |
| 59  | <a href="#">704481760000</a><br>Grommet              | <a href="#">Buy now</a> |
| 60  | <a href="#">703481920000</a><br>Washer 2             | <a href="#">Buy now</a> |
| 61  | <a href="#">EL8482330000</a><br>Gear 2               | <a href="#">Buy now</a> |
| 62  | <a href="#">702482350000</a><br>Bushing              | <a href="#">Buy now</a> |
| 63  | <a href="#">704482820000</a><br>Screw 2              | <a href="#">Buy now</a> |
| 65  | <a href="#">704481660000</a><br>Plug                 | <a href="#">Buy now</a> |

## Remote Control Assy 2 (704 Type)



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 66  | <a href="#">704482840000</a><br>Grommet                     | <a href="#">Buy now</a> |
| 67  | <a href="#">704819500000</a><br>Relay assembly              | <a href="#">Buy now</a> |
| 69  | <a href="#">704482291000</a><br>Grip, control lever 2       | <a href="#">Buy now</a> |
| 71  | <a href="#">704482281000</a><br>Holder, switch              | <a href="#">Buy now</a> |
| 72  | <a href="#">704481280000</a><br>Screw, pan head             | <a href="#">Buy now</a> |
| 73  | <a href="#">704481560000</a><br>Nut 1                       | <a href="#">Buy now</a> |
| 74  | <a href="#">704825632000</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |
| 75  | <a href="#">704482850000</a><br>Grommet 2                   | <a href="#">Buy now</a> |
| 76  | <a href="#">704482860000</a><br>Grommet 3                   | <a href="#">Buy now</a> |
| 77  | <a href="#">704481780000</a><br>Plate, shift                | <a href="#">Buy now</a> |

# Repair Kit

Fig. 32 REPAIR KIT

| Ref.No. | Parts No.    | Description              | Qty | Ref.No. | Parts No.    | Description                | Qty |
|---------|--------------|--------------------------|-----|---------|--------------|----------------------------|-----|
| 1       | 6E5-W0093-02 | CARBURETOR REPAIR SET    | 1   | 47      | 6E5-14384-02 | GASKET, float chamber      | 2   |
| 2       | 6E5-14483-00 | GASKET, plate            | 1   | 48      | 6E5-W0001-20 | LOWER UNIT GASKET KIT      | 1   |
| 3       | 6E5-14792-00 | GASKET                   | 2   | 49      | 6E5-41134-00 | GASKET, exhaust manifold 2 | 1   |
| 4       | 92020-05013  | SCREW, panhead           | 2   | 50      | 6E5-43114-00 | GASKET, upper casing 2     | 1   |
| 5       | 6E5-14384-01 | GASKET, float chamber    | 2   | 51      | 6E5-45123-00 | GASKET, muffler            | 1   |
| 6       | 6E5-14385-00 | FLAT ASS'Y               | 2   | 52      | 6E5-41135-00 | GASKET, exhaust manifold 3 | 1   |
| 7       | 6E5-14386-01 | PKR, float               | 2   | 53      | 6E5-44305-00 | RUBBER, water seal 1       | 1   |
| 8       | 122-14388-00 | GASKET                   | 4   | 54      | 6E5-44306-00 | RUBBER, water seal 2       | 1   |
| 9       | 604-14399-17 | VALVE SEAT ASS'Y         | 2   | 55      | 90430-00020  | GASKET                     | 2   |
| 10      | 6E5-14398-00 | GASKET                   | 2   | 56      | 93210-58144  | O-RING                     | 1   |
| 11      | 6E5-14323-00 | SCREW, air adjusting     | 4   | 57      | 93106-00014  | OIL SEAL                   | 1   |
| 12      | 68E-41291-00 | BUSHING                  | 1   | 58      | 93210-60408  | O-RING                     | 1   |
| 13      | 617-24565-00 | O-RING                   | 4   | 59      | 93210-37160  | O-RING                     | 1   |
| 14      | 367-14395-00 | GASKET                   | 2   | 60      | 6E5-44316-00 | GASKET, water pump         | 1   |
| 15      | 6E5-W0001-01 | POWER HEAD GASKET KIT    | 1   | 61      | 93101-30M16  | OIL SEAL                   | 2   |
| 16      | 6E5-14416-00 | GASKET, air cleaner      | 1   | 62      | 93210-55M14  | O-RING                     | 1   |
| 17      | 6E5-14483-00 | GASKET, plate            | 1   | 63      | 93210-60409  | O-RING                     | 1   |
| 18      | 6E5-14388-00 | GASKET                   | 2   | 64      | 93101-30M17  | OIL SEAL                   | 2   |
| 19      | 6E5-11381-00 | GASKET, cover            | 1   | 65      | 6F3-W0001-20 | LOWER UNIT GASKET KIT      | 1   |
| 20      | 6E5-11381-02 | GASKET, cylinder head    | 2   | 66      | 6E5-41134-00 | GASKET, exhaust manifold 2 | 1   |
| 21      | 6E5-11393-01 | GASKET, head cover       | 2   | 67      | 6E5-45114-00 | GASKET, upper casing 2     | 1   |
| 22      | 68E-12414-00 | GASKET, thermostat cover | 2   | 68      | 6E5-41135-00 | GASKET, exhaust manifold 3 | 1   |
| 23      | 6E5-41112-00 | GASKET, exhaust cover    | 2   | 69      | 90430-00020  | GASKET                     | 2   |
| 24      | 93102-40M14  | OIL SEAL                 | 1   | 70      | 6E5-45123-00 | GASKET, muffler            | 1   |
| 25      | 93211-60M36  | O-RING                   | 2   | 71      | 6E5-44305-00 | RUBBER, water seal 1       | 1   |
| 26      | 93102-35M13  | OIL SEAL                 | 1   | 72      | 6E5-44306-00 | RUBBER, water seal 2       | 1   |
| 27      | 93101-22M15  | OIL SEAL                 | 1   | 73      | 93210-58144  | O-RING                     | 1   |
| 28      | 93210-74M25  | O-RING                   | 1   | 74      | 93106-00014  | OIL SEAL                   | 1   |
| 29      | 6E5-45113-02 | GASKET, upper casing 1   | 1   | 75      | 93210-37160  | O-RING                     | 1   |
| 30      | 6F3-W0001-00 | POWER HEAD GASKET KIT    | 1   | 76      | 93210-60408  | O-RING                     | 1   |
| 31      | 93102-35M13  | OIL SEAL                 | 1   | 77      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 32      | 93101-22M15  | OIL SEAL                 | 1   | 78      | 93101-28M16  | OIL SEAL                   | 2   |
| 33      | 93210-74M25  | O-RING                   | 1   | 79      | 93210-55M14  | O-RING                     | 1   |
| 34      | 6E5-11381-00 | GASKET, cover            | 1   | 80      | 93210-60M39  | O-RING                     | 1   |
| 35      | 6E5-11381-02 | GASKET, cylinder head    | 2   | 81      | 93101-30M17  | OIL SEAL                   | 2   |
| 36      | 6E5-11393-01 | GASKET, head cover       | 2   | 82      | 6E5-W0078-00 | WATER PUMP REPAIR KIT      | 1   |
| 37      | 68E-12414-00 | GASKET, thermostat cover | 2   | 83      | 6E5-44322-00 | WASHER, cartridge          | 1   |
| 38      | 6E5-41112-00 | GASKET, exhaust cover    | 2   | 84      | 93210-60M39  | O-RING                     | 1   |
| 39      | 93102-40M14  | OIL SEAL                 | 1   | 85      | 93210-37160  | O-RING                     | 1   |
| 40      | 93211-60M36  | O-RING                   | 2   | 86      | 6E5-44352-00 | IMPELLER                   | 1   |
| 41      | 6E5-13621-00 | PACKING, valve seat      | 4   | 87      | 6E5-44323-00 | OUTER PLATE, cartridge     | 1   |
| 42      | 6E5-13645-00 | GASKET, intake manifold  | 1   | 88      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 43      | 6E5-14188-00 | GASKET                   | 2   | 89      | 93606-12019  | PIW, dowel 3               | 1   |
| 44      | 6E5-14483-00 | GASKET, plate            | 1   | 90      | 93395-00045  | BOLT                       | 4   |
| 45      | 6E5-14416-00 | GASKET, air cleaner      | 1   | 91      | 90259-00M02  | WASHER                     | 4   |
| 46      | 6E5-45113-00 | GASKET, upper casing     | 1   | 92      | 90260-04M05  | KEY, woodruff              | 1   |

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5W00930200</a><br>Carburetor repair set  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5144830000</a><br>Gasket                 | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5141980000</a><br>Gasket                 | <a href="#">Buy now</a> |
| 4   | <a href="#">978030501300</a><br>Screw, Pan Head        | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5143860100</a><br>Pin, float             | <a href="#">Buy now</a> |
| 8   | <a href="#">1J2143980000</a><br>Packing                | <a href="#">Buy now</a> |
| 9   | <a href="#">6G4143901700</a><br>Valve Seat Assembly    | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5143980000</a><br>Gasket                 | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5143230000</a><br>Screw, Air Adjusting   | <a href="#">Buy now</a> |
| 12  | <a href="#">682412910000</a><br>Bushing                | <a href="#">Buy now</a> |
| 14  | <a href="#">367141950000</a><br>Washer, valve seat     | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5W0001A100</a><br>Gasket Kit, Power Unit | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5144160000</a><br>Gasket, air cleaner    | <a href="#">Buy now</a> |
| 18  | <a href="#">6E514198A200</a><br>Gasket                 | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5113810000</a><br>Gasket 1               | <a href="#">Buy now</a> |

# Repair Kit

Fig. 32 REPAIR KIT

| Ref.No. | Parts No.    | Description              | Qty | Ref.No. | Parts No.    | Description                | Qty |
|---------|--------------|--------------------------|-----|---------|--------------|----------------------------|-----|
| 1       | 6E5-W0093-02 | CARBURETOR REPAIR SET    | 1   | 47      | 6E5-14304-02 | GASKET, float chamber      | 2   |
| 2       | 6E5-14483-00 | GASKET, plate            | 1   | 48      | 6E5-W0001-20 | LOWER UNIT GASKET KIT      | 1   |
| 3       | 6E5-14793-00 | GASKET                   | 2   | 49      | 6E5-41134-00 | GASKET, exhaust manifold 2 | 1   |
| 4       | 92020-00013  | SCREW, panhead           | 2   | 50      | 6E5-43114-00 | GASKET, upper casing 2     | 1   |
| 5       | 6E5-14304-01 | GASKET, float chamber    | 2   | 51      | 6E5-45123-00 | GASKET, muffler            | 1   |
| 6       | 6E5-14305-00 | FLAT ASS'Y               | 2   | 52      | 6E5-41135-00 | GASKET, exhaust manifold 3 | 1   |
| 7       | 6E5-14306-01 | PKR, float               | 2   | 53      | 6E5-44305-00 | RUBBER, water seal 1       | 1   |
| 8       | 120-14308-00 | GASKET                   | 4   | 54      | 6E5-44306-00 | RUBBER, water seal 2       | 1   |
| 9       | 604-14399-17 | VALVE SEAT ASS'Y         | 2   | 55      | 90430-00020  | GASKET                     | 2   |
| 10      | 6E5-14398-00 | GASKET                   | 2   | 56      | 93210-58144  | O-RING                     | 1   |
| 11      | 6E5-14323-00 | SCREW, air adjusting     | 4   | 57      | 93106-00014  | OIL SEAL                   | 1   |
| 12      | 68E-41291-00 | BUSHING                  | 1   | 58      | 93210-60408  | O-RING                     | 1   |
| 13      | 617-24565-00 | O-RING                   | 4   | 59      | 93210-37160  | O-RING                     | 1   |
| 14      | 367-14395-00 | GASKET                   | 2   | 60      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 15      | 6E5-W0001-01 | POWER HEAD GASKET KIT    | 1   | 61      | 93101-30M16  | OIL SEAL                   | 2   |
| 16      | 6E5-14416-00 | GASKET, air cleaner      | 1   | 62      | 93210-55M14  | O-RING                     | 1   |
| 17      | 6E5-14483-00 | GASKET, plate            | 1   | 63      | 93210-60408  | O-RING                     | 1   |
| 18      | 6E5-14398-00 | GASKET                   | 2   | 64      | 93101-30M17  | OIL SEAL                   | 2   |
| 19      | 6E5-11381-00 | GASKET, cover            | 1   | 65      | 6F3-W0001-20 | LOWER UNIT GASKET KIT      | 1   |
| 20      | 6E5-11381-02 | GASKET, cylinder head    | 2   | 66      | 6E5-41134-00 | GASKET, exhaust manifold 2 | 1   |
| 21      | 6E5-11393-01 | GASKET, head cover       | 2   | 67      | 6E5-45114-00 | GASKET, upper casing 2     | 1   |
| 22      | 608-12414-00 | GASKET, thermostat cover | 2   | 68      | 6E5-41135-00 | GASKET, exhaust manifold 3 | 1   |
| 23      | 6E5-41112-00 | GASKET, exhaust cover    | 2   | 69      | 90430-00020  | GASKET                     | 2   |
| 24      | 93102-40M14  | OIL SEAL                 | 1   | 70      | 6E5-45123-00 | GASKET, muffler            | 1   |
| 25      | 93211-60M36  | O-RING                   | 2   | 71      | 6E5-44305-00 | RUBBER, water seal 1       | 1   |
| 26      | 93100-35M13  | OIL SEAL                 | 1   | 72      | 6E5-44306-00 | RUBBER, water seal 2       | 1   |
| 27      | 93101-22M15  | OIL SEAL                 | 1   | 73      | 93210-58144  | O-RING                     | 1   |
| 28      | 93210-74M25  | O-RING                   | 1   | 74      | 93106-00014  | OIL SEAL                   | 1   |
| 29      | 6E5-45113-02 | GASKET, upper casing 1   | 1   | 75      | 93210-37160  | O-RING                     | 1   |
| 30      | 6F3-W0001-00 | POWER HEAD GASKET KIT    | 1   | 76      | 93210-60408  | O-RING                     | 1   |
| 31      | 93102-35M13  | OIL SEAL                 | 1   | 77      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 32      | 93101-22M15  | OIL SEAL                 | 1   | 78      | 93101-28M16  | OIL SEAL                   | 2   |
| 33      | 93210-74M25  | O-RING                   | 1   | 79      | 93210-55M14  | O-RING                     | 1   |
| 34      | 6E5-11381-00 | GASKET, cover            | 1   | 80      | 93210-60M36  | O-RING                     | 1   |
| 35      | 6E5-11381-02 | GASKET, cylinder head    | 2   | 81      | 93101-30M17  | OIL SEAL                   | 2   |
| 36      | 6E5-11393-01 | GASKET, head cover       | 2   | 82      | 6E5-W0078-00 | WATER PUMP REPAIR KIT      | 1   |
| 37      | 608-12414-00 | GASKET, thermostat cover | 2   | 83      | 6E5-44322-00 | WASHER, cartridge          | 1   |
| 38      | 6E5-41112-00 | GASKET, exhaust cover    | 2   | 84      | 93210-60M36  | O-RING                     | 1   |
| 39      | 93100-35M13  | OIL SEAL                 | 1   | 85      | 93210-37160  | O-RING                     | 1   |
| 40      | 93211-60M36  | O-RING                   | 2   | 86      | 6E5-44352-00 | IMPELLER                   | 1   |
| 41      | 6E5-13621-00 | PACKING, valve seat      | 4   | 87      | 6E5-44323-00 | OUTER PLATE, cartridge     | 1   |
| 42      | 6E5-13645-00 | GASKET, intake manifold  | 1   | 88      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 43      | 6E5-14188-00 | GASKET                   | 2   | 89      | 93606-12019  | PIW, dowel 3               | 1   |
| 44      | 6E5-14483-00 | GASKET, plate            | 1   | 90      | 93395-00045  | BOLT                       | 4   |
| 45      | 6E5-14416-00 | GASKET, air cleaner      | 1   | 91      | 90209-00M02  | WASHER                     | 4   |
| 46      | 6E5-45113-00 | GASKET, upper casing     | 1   | 92      | 90209-04M05  | KEY, woodruff              | 1   |

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 20  | <a href="#">6E511181A200</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5111930100</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 22  | <a href="#">688124140000</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5411120000</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 24  | <a href="#">9310240M3800</a><br>Oil seal(61a)               | <a href="#">Buy now</a> |
| 25  | <a href="#">9321104M3600</a><br>O-ring (705)                | <a href="#">Buy now</a> |
| 26  | <a href="#">9310235M1300</a><br>Oil seal (6e5)              | <a href="#">Buy now</a> |
| 27  | <a href="#">9310122M1500</a><br>Oil seal (6e5)              | <a href="#">Buy now</a> |
| 28  | <a href="#">9321074M3500</a><br>O-ring (6e5)                | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5451130200</a><br>Gasket, upper casing        | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5111810200</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 37  | <a href="#">68812414A100</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 39  | <a href="#">9310240M1400</a><br>Oil seal(61a)               | <a href="#">Buy now</a> |
| 40  | <a href="#">932110438400</a><br>O-ring (705)                | <a href="#">Buy now</a> |
| 41  | <a href="#">6E5136210000</a><br>Gasket, valve seat          | <a href="#">Buy now</a> |

# Repair Kit

Fig. 32 REPAIR KIT

| Ref.No. | Parts No.    | Description              | Qty | Ref.No. | Parts No.    | Description                | Qty |
|---------|--------------|--------------------------|-----|---------|--------------|----------------------------|-----|
| 1       | 6E5-W0093-02 | CARBURETOR REPAIR SET    | 1   | 47      | 6E5-14384-02 | GASKET, float chamber      | 2   |
| 2       | 6E5-14483-00 | GASKET, plate            | 1   | 48      | 6E5-W0001-20 | LOWER UNIT GASKET KIT      | 1   |
| 3       | 6E5-14792-00 | GASKET                   | 2   | 49      | 6E5-41134-00 | GASKET, exhaust manifold 2 | 1   |
| 4       | 92020-05013  | SCREW, panhead           | 2   | 50      | 6E5-43114-00 | GASKET, upper casing 2     | 1   |
| 5       | 6E5-14384-01 | GASKET, float chamber    | 2   | 51      | 6E5-45123-00 | GASKET, muffler            | 1   |
| 6       | 6E5-14385-00 | FLAT ASS'Y               | 2   | 52      | 6E5-41135-00 | GASKET, exhaust manifold 3 | 1   |
| 7       | 6E5-14386-01 | PIR, float               | 2   | 53      | 6E5-44365-00 | RUBBER, water seal 1       | 1   |
| 8       | 122-14388-00 | GASKET                   | 4   | 54      | 6E5-44366-00 | RUBBER, water seal 2       | 1   |
| 9       | 604-14399-17 | VALVE SEAT ASS'Y         | 2   | 55      | 90430-00020  | GASKET                     | 2   |
| 10      | 6E5-14398-00 | GASKET                   | 2   | 56      | 93210-58144  | O-RING                     | 1   |
| 11      | 6E5-14323-00 | SCREW, air adjusting     | 4   | 57      | 93106-00014  | OIL SEAL                   | 1   |
| 12      | 68E-41291-00 | BUSHING                  | 1   | 58      | 93210-86M38  | O-RING                     | 1   |
| 13      | 617-24565-00 | O-RING                   | 4   | 59      | 93210-37160  | O-RING                     | 1   |
| 14      | 367-14395-00 | GASKET                   | 2   | 60      | 6E5-44316-00 | GASKET, water pump         | 1   |
| 15      | 6E5-W0001-01 | POWER HEAD GASKET KIT    | 1   | 61      | 93101-30M16  | OIL SEAL                   | 2   |
| 16      | 6E5-14416-00 | GASKET, air cleaner      | 1   | 62      | 93210-55M14  | O-RING                     | 1   |
| 17      | 6E5-14483-00 | GASKET, plate            | 1   | 63      | 93210-86M38  | O-RING                     | 1   |
| 18      | 6E5-14388-00 | GASKET                   | 2   | 64      | 93101-30M17  | OIL SEAL                   | 2   |
| 19      | 6E5-11381-00 | GASKET, cover            | 1   | 65      | 6F3-W0001-20 | LOWER UNIT GASKET KIT      | 1   |
| 20      | 6E5-11381-02 | GASKET, cylinder head    | 2   | 66      | 6E5-41134-00 | GASKET, exhaust manifold 2 | 1   |
| 21      | 6E5-11393-01 | GASKET, head cover       | 2   | 67      | 6E5-45114-00 | GASKET, upper casing 2     | 1   |
| 22      | 68E-12414-00 | GASKET, thermostat cover | 2   | 68      | 6E5-41135-00 | GASKET, exhaust manifold 3 | 1   |
| 23      | 6E5-41112-00 | GASKET, exhaust cover    | 2   | 69      | 90430-00020  | GASKET                     | 2   |
| 24      | 93102-40M14  | OIL SEAL                 | 1   | 70      | 6E5-45123-00 | GASKET, muffler            | 1   |
| 25      | 93211-04M36  | O-RING                   | 2   | 71      | 6E5-44365-00 | RUBBER, water seal 1       | 1   |
| 26      | 93100-35M13  | OIL SEAL                 | 1   | 72      | 6E5-44366-00 | RUBBER, water seal 2       | 1   |
| 27      | 93101-22M15  | OIL SEAL                 | 1   | 73      | 93210-58144  | O-RING                     | 1   |
| 28      | 93210-74M25  | O-RING                   | 1   | 74      | 93106-00014  | OIL SEAL                   | 1   |
| 29      | 6E5-45113-02 | GASKET, upper casing 1   | 1   | 75      | 93210-37160  | O-RING                     | 1   |
| 30      | 6F3-W0001-00 | POWER HEAD GASKET KIT    | 1   | 76      | 93210-86M38  | O-RING                     | 1   |
| 31      | 93102-35M13  | OIL SEAL                 | 1   | 77      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 32      | 93101-22M15  | OIL SEAL                 | 1   | 78      | 93101-28M16  | OIL SEAL                   | 2   |
| 33      | 93210-74M25  | O-RING                   | 1   | 79      | 93210-55M14  | O-RING                     | 1   |
| 34      | 6E5-11381-00 | GASKET, cover            | 1   | 80      | 93210-86M38  | O-RING                     | 1   |
| 35      | 6E5-11381-02 | GASKET, cylinder head    | 2   | 81      | 93101-30M17  | OIL SEAL                   | 2   |
| 36      | 6E5-11393-01 | GASKET, head cover       | 2   | 82      | 6E5-W0078-00 | WATER PUMP REPAIR KIT      | 1   |
| 37      | 68E-12414-00 | GASKET, thermostat cover | 2   | 83      | 6E5-44322-00 | INSERT, cartridge          | 1   |
| 38      | 6E5-41112-00 | GASKET, exhaust cover    | 2   | 84      | 93210-65M38  | O-RING                     | 1   |
| 39      | 93100-35M13  | OIL SEAL                 | 1   | 85      | 93210-37160  | O-RING                     | 1   |
| 40      | 93211-04M36  | O-RING                   | 2   | 86      | 6E5-44352-00 | IMPELLER                   | 1   |
| 41      | 6E5-13621-00 | PACKING, valve seat      | 4   | 87      | 6E5-44323-00 | OUTER PLATE, cartridge     | 1   |
| 42      | 6E5-13645-00 | GASKET, intake manifold  | 1   | 88      | 6E5-44315-00 | GASKET, water pump         | 1   |
| 43      | 6E5-14188-00 | GASKET                   | 2   | 89      | 93606-12019  | PIW, dowel 3               | 1   |
| 44      | 6E5-14483-00 | GASKET, plate            | 1   | 90      | 93395-00045  | BOLT                       | 4   |
| 45      | 6E5-14416-00 | GASKET, air cleaner      | 1   | 91      | 90209-00M02  | WASHER                     | 4   |
| 46      | 6E5-45113-00 | GASKET, upper casing     | 1   | 92      | 90205-04M05  | KEY, woodruff              | 1   |

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 42  | <a href="#">6E513645A100</a><br>Gasket, manifold 1       | <a href="#">Buy now</a> |
| 46  | <a href="#">6G545113A200</a><br>Gasket, upper casing     | <a href="#">Buy now</a> |
| 47  | <a href="#">6E5143840200</a><br>Gasket, float chamber    | <a href="#">Buy now</a> |
| 48  | <a href="#">6E5W00012000</a><br>Gasket kit, lower unit   | <a href="#">Buy now</a> |
| 49  | <a href="#">6E5411340000</a><br>Gasket,exhaust manifold  | <a href="#">Buy now</a> |
| 50  | <a href="#">6E5451140000</a><br>Gasket, upper casing     | <a href="#">Buy now</a> |
| 51  | <a href="#">6E5451230000</a><br>Gasket, muffler          | <a href="#">Buy now</a> |
| 52  | <a href="#">6E5411350000</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 53  | <a href="#">6E5443650000</a><br>Damper, water seal 1     | <a href="#">Buy now</a> |
| 54  | <a href="#">6E5443660000</a><br>Damper, water seal 2     | <a href="#">Buy now</a> |
| 55  | <a href="#">904300802000</a><br>Gasket                   | <a href="#">Buy now</a> |
| 56  | <a href="#">932105814400</a><br>O-ring(47x)              | <a href="#">Buy now</a> |
| 57  | <a href="#">931060901400</a><br>Oil seal                 | <a href="#">Buy now</a> |
| 58  | <a href="#">9321086M3800</a><br>O-ring (6e5)             | <a href="#">Buy now</a> |
| 59  | <a href="#">932103716000</a><br>O-ring (6g8)             | <a href="#">Buy now</a> |

# Repair Kit

Fig. 32 REPAIR KIT

| Ref.No. | Parts No.    | Description                | Qty | Ref.No. | Parts No.    | Description                  | Qty |
|---------|--------------|----------------------------|-----|---------|--------------|------------------------------|-----|
| 1       | 6E5-W0093-02 | CARBURETOR REPAIR SET      | 1   | 47      | 6E5-14304-02 | . GASKET, float chamber      | 2   |
| 2       | 6E5-14483-00 | . GASKET, plate            | 1   | 48      | 6E5-W0001-20 | LOWER UNIT GASKET KIT        | 1   |
| 3       | 6E5-14792-00 | . GASKET                   | 2   | 49      | 6E5-41134-00 | . GASKET, exhaust manifold 2 | 1   |
| 4       | 92020-00013  | . SCREW, panhead           | 2   | 50      | 6E5-43114-00 | . GASKET, upper casing 2     | 1   |
| 5       | 6E5-14304-01 | . GASKET, float chamber    | 2   | 51      | 6E5-45123-00 | . GASKET, muffler            | 1   |
| 6       | 6E5-14305-00 | . FLOAT ASS'Y              | 2   | 52      | 6E5-41135-00 | . GASKET, exhaust manifold 3 | 1   |
| 7       | 6E5-14384-01 | . PDR, float               | 2   | 53      | 6E5-44305-00 | . RUBBER, water seal 1       | 1   |
| 8       | 122-14388-00 | . GASKET                   | 4   | 54      | 6E5-44306-00 | . RUBBER, water seal 2       | 1   |
| 9       | 604-14399-17 | . VALVE SEAT ASS'Y         | 2   | 55      | 90430-00020  | . GASKET                     | 2   |
| 10      | 6E5-14398-00 | . GASKET                   | 2   | 56      | 93210-58144  | . O-RING                     | 1   |
| 11      | 6E5-14323-00 | . SCREW, air adjusting     | 4   | 57      | 93106-00014  | . OIL SEAL                   | 1   |
| 12      | 68E-41291-00 | . BUSHING                  | 1   | 58      | 93210-60408  | . O-RING                     | 1   |
| 13      | 617-24565-00 | . O-RING                   | 4   | 59      | 93210-37160  | . O-RING                     | 1   |
| 14      | 367-14395-00 | . GASKET                   | 2   | 60      | 6E5-44316-00 | . GASKET, water pump         | 1   |
| 15      | 6E5-W0001-01 | POWER HEAD GASKET KIT      | 1   | 61      | 93101-30M16  | . OIL SEAL                   | 2   |
| 16      | 6E5-14416-00 | . GASKET, air cleaner      | 1   | 62      | 93210-55M14  | . O-RING                     | 1   |
| 17      | 6E5-14483-00 | . GASKET, plate            | 1   | 63      | 93210-60409  | . O-RING                     | 1   |
| 18      | 6E5-14388-00 | . GASKET                   | 2   | 64      | 93101-30M17  | . OIL SEAL                   | 2   |
| 19      | 6E5-11381-00 | . GASKET, cover            | 1   | 65      | 6F3-W0001-20 | LOWER UNIT GASKET KIT        | 1   |
| 20      | 6E5-11381-02 | . GASKET, cylinder head    | 2   | 66      | 6E5-41134-00 | . GASKET, exhaust manifold 2 | 1   |
| 21      | 6E5-11393-01 | . GASKET, head cover       | 2   | 67      | 6E5-45114-00 | . GASKET, upper casing 2     | 1   |
| 22      | 608-12414-00 | . GASKET, thermostat cover | 2   | 68      | 6E5-41135-00 | . GASKET, exhaust manifold 3 | 1   |
| 23      | 6E5-41112-00 | . GASKET, exhaust cover    | 2   | 69      | 90430-00020  | . GASKET                     | 2   |
| 24      | 93102-40M14  | . OIL SEAL                 | 1   | 70      | 6E5-45123-00 | . GASKET, muffler            | 1   |
| 25      | 93211-00M36  | . O-RING                   | 2   | 71      | 6E5-44305-00 | . RUBBER, water seal 1       | 1   |
| 26      | 93100-35M13  | . OIL SEAL                 | 1   | 72      | 6E5-44306-00 | . RUBBER, water seal 2       | 1   |
| 27      | 93101-22M15  | . OIL SEAL                 | 1   | 73      | 93210-58144  | . O-RING                     | 1   |
| 28      | 93210-74M25  | . O-RING                   | 1   | 74      | 93106-00014  | . OIL SEAL                   | 1   |
| 29      | 6E5-45113-02 | . GASKET, upper casing 1   | 1   | 75      | 93210-37160  | . O-RING                     | 1   |
| 30      | 6F3-W0001-00 | POWER HEAD GASKET KIT      | 1   | 76      | 93210-60408  | . O-RING                     | 1   |
| 31      | 93102-35M13  | . OIL SEAL                 | 1   | 77      | 6E5-44315-00 | . GASKET, water pump         | 1   |
| 32      | 93101-22M15  | . OIL SEAL                 | 1   | 78      | 93101-20M16  | . OIL SEAL                   | 2   |
| 33      | 93210-74M25  | . O-RING                   | 1   | 79      | 93210-55M14  | . O-RING                     | 1   |
| 34      | 6E5-11381-00 | . GASKET, cover            | 1   | 80      | 93210-60M39  | . O-RING                     | 1   |
| 35      | 6E5-11381-02 | . GASKET, cylinder head    | 2   | 81      | 93101-30M17  | . OIL SEAL                   | 2   |
| 36      | 6E5-11393-01 | . GASKET, head cover       | 2   | 82      | 6E5-W0078-00 | WATER PUMP REPAIR KIT        | 1   |
| 37      | 608-12414-00 | . GASKET, thermostat cover | 2   | 83      | 6E5-44322-00 | . INSERT, cartridge          | 1   |
| 38      | 6E5-41112-00 | . GASKET, exhaust cover    | 2   | 84      | 93210-60M39  | . O-RING                     | 1   |
| 39      | 93100-35M13  | . OIL SEAL                 | 1   | 85      | 93210-37160  | . O-RING                     | 1   |
| 40      | 93211-00M36  | . O-RING                   | 2   | 86      | 6E5-44352-00 | . IMPELLER                   | 1   |
| 41      | 6E5-13621-00 | . PACKING, valve seat      | 4   | 87      | 6E5-44323-00 | . OUTER PLATE, cartridge     | 1   |
| 42      | 6E5-13645-00 | . GASKET, intake manifold  | 1   | 88      | 6E5-44315-00 | . GASKET, water pump         | 1   |
| 43      | 6E5-14188-00 | . GASKET                   | 2   | 89      | 93606-12019  | . PIN, dowel 3               | 1   |
| 44      | 6E5-14483-00 | . GASKET, plate            | 1   | 90      | 97395-00M45  | . BOLT                       | 4   |
| 45      | 6E5-14416-00 | . GASKET, air cleaner      | 1   | 91      | 90209-00M02  | . WASHER                     | 4   |
| 46      | 6E5-45113-00 | . GASKET, upper casing     | 1   | 92      | 90209-04M05  | . KIT, woodruff              | 1   |

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 60  | <a href="#">6E5443150000</a><br>Gasket,water pump        | <a href="#">Buy now</a> |
| 61  | <a href="#">9310128M1600</a><br>Oil seal (6e5)           | <a href="#">Buy now</a> |
| 62  | <a href="#">9321055M1400</a><br>O-ring (70e)             | <a href="#">Buy now</a> |
| 63  | <a href="#">9321086M3900</a><br>O-ring (6e5)             | <a href="#">Buy now</a> |
| 64  | <a href="#">9310130M1700</a><br>Oil seal (6e5)           | <a href="#">Buy now</a> |
| 65  | <a href="#">6F3W00012000</a><br>Gasket kit, lower unit   | <a href="#">Buy now</a> |
| 68  | <a href="#">6E541135A000</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 75  | <a href="#">9321037M6700</a><br>O-ring (6g8)             | <a href="#">Buy now</a> |
| 82  | <a href="#">6E5W00780000</a><br>Water pump repair kit    | <a href="#">Buy now</a> |
| 83  | <a href="#">6E5443220000</a><br>Insert, cartridge        | <a href="#">Buy now</a> |
| 86  | <a href="#">6E5443520000</a><br>Impeller                 | <a href="#">Buy now</a> |
| 87  | <a href="#">6E5443230000</a><br>Outer plate, cartridge   | <a href="#">Buy now</a> |
| 89  | <a href="#">936061201900</a><br>Pin, dowel (614)         | <a href="#">Buy now</a> |
| 90  | <a href="#">973950804500</a><br>Bolt, hexagon            | <a href="#">Buy now</a> |
| 91  | <a href="#">9020908M0200</a><br>Washer, plate (688)      | <a href="#">Buy now</a> |


# Repair Kit

Fig. 32 REPAIR KIT

| Ref.No. | Parts No.    | Description                | Qty | Ref.No. | Parts No.    | Description                  | Qty |
|---------|--------------|----------------------------|-----|---------|--------------|------------------------------|-----|
| 1       | 6E5-W0093-02 | CARBURETOR REPAIR SET      | 1   | 47      | 6E5-14304-02 | . GASKET, float chamber      | 2   |
| 2       | 6E5-14483-00 | . GASKET, plate            | 1   | 48      | 6E5-W0001-20 | LOWER UNIT GASKET KIT        | 1   |
| 3       | 6E5-14792-00 | . GASKET                   | 2   | 49      | 6E5-41134-00 | . GASKET, exhaust manifold 2 | 1   |
| 4       | 92020-05013  | . SCREW, panhead           | 2   | 50      | 6E5-43114-00 | . GASKET, upper casing 2     | 1   |
| 5       | 6E5-14304-01 | . GASKET, float chamber    | 2   | 51      | 6E5-45123-00 | . GASKET, muffler            | 1   |
| 6       | 6E5-14305-00 | . FLOAT ASS'Y              | 2   | 52      | 6E5-41135-00 | . GASKET, exhaust manifold 3 | 1   |
| 7       | 6E5-14384-01 | . PIN, float               | 2   | 53      | 6E5-44305-00 | . RUBBER, water seal 1       | 1   |
| 8       | 122-14388-00 | . GASKET                   | 4   | 54      | 6E5-44306-00 | . RUBBER, water seal 2       | 1   |
| 9       | 604-14399-17 | . VALVE SEAT ASS'Y         | 2   | 55      | 90430-00020  | . GASKET                     | 2   |
| 10      | 6E5-14399-00 | . GASKET                   | 2   | 56      | 93210-58144  | . O-RING                     | 1   |
| 11      | 6E5-14323-00 | . SCREW, air adjusting     | 4   | 57      | 93106-09014  | . OIL SEAL                   | 1   |
| 12      | 68E-41291-00 | . BUSHING                  | 1   | 58      | 93210-86408  | . O-RING                     | 1   |
| 13      | 617-24565-00 | . O-RING                   | 4   | 59      | 93210-37160  | . O-RING                     | 1   |
| 14      | 367-14395-00 | . GASKET                   | 2   | 60      | 6E5-44315-00 | . GASKET, water pump         | 1   |
| 15      | 6E5-W0001-01 | POWER HEAD GASKET KIT      | 1   | 61      | 93101-20416  | . OIL SEAL                   | 2   |
| 16      | 6E5-14416-00 | . GASKET, air cleaner      | 1   | 62      | 93210-55014  | . O-RING                     | 1   |
| 17      | 6E5-14483-00 | . GASKET, plate            | 1   | 63      | 93210-86408  | . O-RING                     | 1   |
| 18      | 6E5-14388-00 | . GASKET                   | 2   | 64      | 93101-30417  | . OIL SEAL                   | 2   |
| 19      | 6E5-11381-00 | . GASKET, cover            | 1   | 65      | 6F3-W0001-20 | LOWER UNIT GASKET KIT        | 1   |
| 20      | 6E5-11381-02 | . GASKET, cylinder head    | 2   | 66      | 6E5-41134-00 | . GASKET, exhaust manifold 2 | 1   |
| 21      | 6E5-11393-01 | . GASKET, head cover       | 2   | 67      | 6E5-45114-00 | . GASKET, upper casing 2     | 1   |
| 22      | 608-12414-00 | . GASKET, thermostat cover | 2   | 68      | 6E5-41135-00 | . GASKET, exhaust manifold 3 | 1   |
| 23      | 6E5-41112-00 | . GASKET, exhaust cover    | 2   | 69      | 90430-00020  | . GASKET                     | 2   |
| 24      | 93102-40414  | . OIL SEAL                 | 1   | 70      | 6E5-45123-00 | . GASKET, muffler            | 1   |
| 25      | 93211-04036  | . O-RING                   | 2   | 71      | 6E5-44305-00 | . RUBBER, water seal 1       | 1   |
| 26      | 93102-35013  | . OIL SEAL                 | 1   | 72      | 6E5-44306-00 | . RUBBER, water seal 2       | 1   |
| 27      | 93101-22015  | . OIL SEAL                 | 1   | 73      | 93210-58144  | . O-RING                     | 1   |
| 28      | 93210-74025  | . O-RING                   | 1   | 74      | 93106-09014  | . OIL SEAL                   | 1   |
| 29      | 6E5-45113-02 | . GASKET, upper casing 1   | 1   | 75      | 93210-37160  | . O-RING                     | 1   |
| 30      | 6F3-W0001-00 | POWER HEAD GASKET KIT      | 1   | 76      | 93210-86408  | . O-RING                     | 1   |
| 31      | 93102-35013  | . OIL SEAL                 | 1   | 77      | 6E5-44315-00 | . GASKET, water pump         | 1   |
| 32      | 93101-22015  | . OIL SEAL                 | 1   | 78      | 93101-20416  | . OIL SEAL                   | 2   |
| 33      | 93210-74025  | . O-RING                   | 1   | 79      | 93210-55014  | . O-RING                     | 1   |
| 34      | 6E5-11381-00 | . GASKET, cover            | 1   | 80      | 93210-86408  | . O-RING                     | 1   |
| 35      | 6E5-11381-02 | . GASKET, cylinder head    | 2   | 81      | 93101-30417  | . OIL SEAL                   | 2   |
| 36      | 6E5-11393-01 | . GASKET, head cover       | 2   | 82      | 6E5-W0078-00 | WATER PUMP REPAIR KIT        | 1   |
| 37      | 608-12414-00 | . GASKET, thermostat cover | 2   | 83      | 6E5-44322-00 | . INSERT, cartridge          | 1   |
| 38      | 6E5-41112-00 | . GASKET, exhaust cover    | 2   | 84      | 93210-65038  | . O-RING                     | 1   |
| 39      | 93102-40414  | . OIL SEAL                 | 1   | 85      | 93210-37160  | . O-RING                     | 1   |
| 40      | 93211-04036  | . O-RING                   | 2   | 86      | 6E5-44352-00 | . IMPELLER                   | 1   |
| 41      | 6E5-13621-00 | . PACKING, valve seat      | 4   | 87      | 6E5-44323-00 | . OUTER PLATE, cartridge     | 1   |
| 42      | 6E5-13645-00 | . GASKET, intake manifold  | 1   | 88      | 6E5-44315-00 | . GASKET, water pump         | 1   |
| 43      | 6E5-14188-00 | . GASKET                   | 2   | 89      | 93606-17019  | . PIN, dowel 3               | 1   |
| 44      | 6E5-14483-00 | . GASKET, plate            | 1   | 90      | 93395-00045  | . BOLT                       | 4   |
| 45      | 6E5-14416-00 | . GASKET, air cleaner      | 1   | 91      | 90259-00402  | . WASHER                     | 4   |
| 46      | 6E5-45113-00 | . GASKET, upper casing     | 1   | 92      | 90200-04705  | . KEY, woodruff              | 1   |


| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 92  | <a href="#">9028004M0500</a><br>Key, woodruff (6e5) | <a href="#">Buy now</a> |

# Steering Guide Attachment




| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5613500100</a><br>Steering guide attachment kit  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5613510000</a><br>Rod, steering link             | <a href="#">Buy now</a> |
| 3   | <a href="#">9020110M2000</a><br>Washer, plate (663)            | <a href="#">Buy now</a> |
| 4   | <a href="#">9018509M0100</a><br>Nut, nylon (663)               | <a href="#">Buy now</a> |
| 5   | <a href="#">9056012M0100</a><br>Spacer (6e5)                   | <a href="#">Buy now</a> |
| 6   | <a href="#">9038710M6100</a><br>Collar (6e5)                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9010109M6600</a><br>Bolt                           | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5431450000</a><br>Cap, clamp bracket             | <a href="#">Buy now</a> |
| 9   | <a href="#">932101627500</a><br>O-ring                         | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5613010000</a><br>Tie bar assembly (l:600-800mm) | <a href="#">Buy now</a> |
| 13  | <a href="#">9010109M7000</a><br>Bolt (6e5)                     | <a href="#">Buy now</a> |
| 14  | <a href="#">9017009M0500</a><br>Nut, hexagon (6e5)             | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5613030000</a><br>Steering axle comp.            | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5613111000</a><br>Tie bar                        | <a href="#">Buy now</a> |
| 17  | <a href="#">953801470000</a><br>Nut (6e5)                      | <a href="#">Buy now</a> |

# Steering Guide Attachment




| Ref | Part                                       |                         |
|-----|--------------------------------------------|-------------------------|
| 18  | <a href="#">6E5613150000</a><br>Tie bar, 2 | <a href="#">Buy now</a> |
| 20  | <a href="#">9017014M0600</a><br>Nut (6e5)  | <a href="#">Buy now</a> |

## Top Cowling




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 5   | <a href="#">9018305M0100</a><br>Nut, spring (6a0)         | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5426860100</a><br>Emblem, Front             | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5426870100</a><br>Emblem, Rear              | <a href="#">Buy now</a> |
| 10  | <a href="#">973950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 11  | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5426150000</a><br>Seal                      | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5426470094</a><br>Holder, clamp band        | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5426490194</a><br>Holder, clamp band        | <a href="#">Buy now</a> |
| 15  | <a href="#">663426620000</a><br>Damper                    | <a href="#">Buy now</a> |
| 16  | <a href="#">9026606M0200</a><br>Rivet (697)               | <a href="#">Buy now</a> |
| 18  | <a href="#">688426520000</a><br>Hook 2                    | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5426520000</a><br>Hook 2                    | <a href="#">Buy now</a> |
| 20  | <a href="#">970950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5426170000</a><br>Damper 1                  | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5426190000</a><br>Damper, Form              | <a href="#">Buy now</a> |

## Top Cowling




| Ref | Part                                         |                         |
|-----|----------------------------------------------|-------------------------|
| 24  | <a href="#">6E5426270000</a><br>Damper, Form | <a href="#">Buy now</a> |

## Upper Casing



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 2   | <a href="#">6E5451550000</a><br>Cap                      | <a href="#">Buy now</a> |
| 3   | <a href="#">9360812M0500</a><br>Pin, dowel b (6e5)       | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5411370294</a><br>Guide, exhaust           | <a href="#">Buy now</a> |
| 5   | <a href="#">6G54113101CA</a><br>Manifold, ext. 1         | <a href="#">Buy now</a> |
| 6   | <a href="#">6E541132009M</a><br>Manifold, exhaust        | <a href="#">Buy now</a> |
| 7   | <a href="#">6G541134A100</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5451140000</a><br>Gasket, upper casing     | <a href="#">Buy now</a> |
| 9   | <a href="#">970950804500</a><br>Bolt, hexagon            | <a href="#">Buy now</a> |
| 10  | <a href="#">929900860000</a><br>Washer, plain (663)      | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5427240000</a><br>Grommet                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5451230000</a><br>Gasket, muffler          | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5411350000</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5147370000</a><br>Damper, muffler          | <a href="#">Buy now</a> |
| 18  | <a href="#">9018305M0200</a><br>Nut, spring (6e5)        | <a href="#">Buy now</a> |
| 19  | <a href="#">973950803000</a><br>Bolt, hexagon (fj1)      | <a href="#">Buy now</a> |

# Upper Casing



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 21  | <a href="#">970800803000</a><br>Bolt, hexagon (fj1)    | <a href="#">Buy now</a> |
| 22  | <a href="#">929900810000</a><br>Ybs67-8 washer, spring | <a href="#">Buy now</a> |
| 23  | <a href="#">953800870000</a><br>Nut(661)               | <a href="#">Buy now</a> |
| 25  | <a href="#">973950804500</a><br>Bolt, hexagon          | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5451130200</a><br>Gasket, upper casing   | <a href="#">Buy now</a> |
| 29  | <a href="#">901190807800</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5427690000</a><br>Seal, rubber           | <a href="#">Buy now</a> |
| 31  | <a href="#">973950601000</a><br>Bolt                   | <a href="#">Buy now</a> |
| 32  | <a href="#">929900660000</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 33  | <a href="#">6G5125810000</a><br>Joint, hose            | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5453180000</a><br>Bushing, drive shaft 3 | <a href="#">Buy now</a> |
| 35  | <a href="#">9342036M0100</a><br>Circlip (6a0)          | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.