



Yamaha 150TRB 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	9
CARBURETOR	12
CONTROL	15
CRANKSHAFT. PISTON	19
CYLINDER. CRANKCASE 1	21
CYLINDER. CRANKCASE 2	23
ELECTRICAL 1	25
ELECTRICAL 2	27
FUEL 1	31
FUEL 2	34
FUEL TANK	35
GENERATOR	36
INTAKE	38
LOWER CASING. DRIVE 1	41
LOWER CASING. DRIVE 2	47
LOWER CASING. DRIVE 3	49
LOWER CASING. DRIVE 4	55
METER	57
OIL PUMP	60
OIL TANK	62
POWER TRIM & TILT ASSY 1	65
POWER TRIM & TILT ASSY 2	68
REMOTE CONTROL ASSY 1	71
REMOTE CONTROL ASSY 2	76
REMOTE CONTROL BOX	82
REPAIR KIT 1	83
REPAIR KIT 2	85
STARTING MOTOR	87
STEERING GUIDE ATTACHMENT 1	89
STEERING GUIDE ATTACHMENT 2	90
SWITCH. PANEL	91
TOP COWLING	93
UPPER CASING	97


Bottom Cowling



E1

Ref	Part	
2	90169-05M00 Screw truss head tapping	Buy now
2	90480-06M19 Grommet (6e3) FOR CARIB,BRAZIL	Buy now
3	61A-42727-00 Grommet	Buy now
4	6H4-42748-00 Grommet	Buy now
7	64D-42835-00 Pin, set1	Buy now
8	97095-06040 Bolt (682)	Buy now
9	90201-06068 Washer,plate (6k8)	Buy now
10	90386-15M73 Bush(6l2)	Buy now
11	90206-15M18 Washer, wave(6l2)	Buy now
12	64D-42818-20 Lever, clamp	Buy now
13	64D-42818-30 Lever, clamp	Buy now
14	64D-43144-00 Hook, spring	Buy now
15	97090-06012 Bolt(gh1)	Buy now
16	92990-06600 Washer, plain (646)	Buy now
17	90506-16M34 Spring, tension(64d)	Buy now


Bottom Cowling



F1

Ref	Part	
18	<u>6E5-44391-00</u> Nipple, hose	Buy now
19	<u>64D-42725-20</u> Grommet EXCEPT FOR USA	Buy now
19	<u>64D-42725-30</u> Grommet FOR USA	Buy now
22	<u>97095-06016</u> Bolt, hexagon deep recess	Buy now
23	<u>92995-06600</u> Washer, plain (646)	Buy now
24	<u>90480-22M15</u> Grommet (6e5)	Buy now
25	<u>90387-08M37</u> Coller (6e5)	Buy now
26	<u>90201-08M54</u> Washer, plate (6e5)	Buy now
27	<u>97075-08035</u> Bolt(70w)	Buy now
28	<u>90119-08M22</u> Bolt, with washer	Buy now
29	<u>688-42726-10</u> Grommet	Buy now
30	<u>6E5-82588-00</u> Plate	Buy now
31	<u>97095-06020</u> Bolt(7u8)	Buy now
36	<u>64D-42717-00</u> Rubber Seal 2	Buy now
40	<u>6E5-42716-10</u> Rubber seal 1	Buy now


Bottom Cowling



E1


Ref	Part	
41	6R3Y125J70 Flushing kit	Buy now
42	6R31257200 Adapter	Buy now
43	6R31258000 Joint assembly	Buy now
44	9044511M35 Hose (I700)	Buy now
45	9046511M10 Clamp	Buy now
47	6E74279110 Mark 1	Buy now
47	6G54279110 Mark 1	Buy now

Bracket 1




Ref	Part	
1	64E-43111-02-8D Bracket, clamp	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06030 Bolt(jf7)	Buy now
5	92995-06100 Washer(6a1)	Buy now
6	6E5-82148-00 Wire, lead 5	Buy now
7	97095-06010 Bolt	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	64E-43112-02-8D Bracket, clamp	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	92990-06600 Washer, plain (646)	Buy now
13	93700-06M03 Nipple, grease(6a1)	Buy now
14	663-45119-00 Cap, grease nipple AP	Buy now
15	64E-43131-01 Bolt, clamp bracket	Buy now
16	97095-08020 Bolt, hexagon	Buy now

Bracket 1




Ref	Part	
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	90386-25M31 Bushing (6e5)	Buy now
19	90201-26M59 Washer, plate (6e5)	Buy now
20	90185-22M11 Nut, self-locking	Buy now
21	90465-11M10 Clamp	Buy now
22	64E-43311-10-8D Bracket, swivel L	Buy now
22	64E-43311-20-8D Bracket, swivel X	Buy now
23	90465-08M63 Clamp(61u)	Buy now
26	6E5-82147-00 Wire, lead 5 L	Buy now
26	6E5-82147-20 Wire, lead 5 X	Buy now
27	6G5-43144-00 Hook, spring	Buy now
29	6G5-43181-02 Lever, tilt stop 1	Buy now
30	6G5-43185-02 Lever, tilt stop 2	Buy now
31	90386-10M16 Bushing (688)	Buy now
32	6G5-43148-00 Collar, distance	Buy now

Bracket 1




Bracket 2



F1

Ref	Part	
1	64E-43139-02 Cam, trim sender (with screw)	Buy now
2	97780-60525 Screw, tapping(65j)	Buy now
3	64E-83672-02 Trim sender	Buy now
4	97885-06016 Screw, pan head(6b0)	Buy now
5	90465-11M10 Clamp	Buy now
6	93210-37MH7 O-ring(61u)	Buy now
7	90202-40M47 Washer, plate(61a)	Buy now
8	61A-43376-00 Bolt, thrust receiver	Buy now
9	95780-10300 Nut, nylon (6e5)	Buy now
11	90201-38M60 Washer, plate (6e5)	Buy now
12	90386-38M32 Bush(6e5)	Buy now
14	93410-37M04 Circlip (6e5)	Buy now
15	6E5-44575-00 Damper, lower mount rubber	Buy now
17	90202-32M19 Washer, plate (6e5)	Buy now
18	90201-16M55 Washer, plate (6e5)	Buy now


Bracket 2



F1


Ref	Part	
19	6E5-82149-00 Wire, lead 3	Buy now
20	90109-14M34 Bolt(6e5)	Buy now
21	90201-15M58 Washer, plate (6e5)	Buy now
22	95380-14800 Nut, crown (6e5)	Buy now
23	92995-14600 Washer (6e5)	Buy now
24	6E5-44552-01-94 Housing, lower mount rubber	Buy now
25	97095-10045 Bolt(64d)	Buy now
26	92995-10100 Ybs67-10 washer, spring	Buy now
28	90501-16M28 Spring (6e5)	Buy now
30	90179-06066 Nut(663)	Buy now
32	90201-26M57 Washer, plate (6e5)	Buy now
33	90202-26M18 Washer, plate (6e5)	Buy now
34	90201-14M56 Washer, plate (6e5)	Buy now
35	90109-12M37 Bolt	Buy now
36	90185-12M12 Nut, self-locking(6e5)	Buy now

Bracket 2



Ref	Part	
37	663-44575-00 Damper, lower mount rubber	Buy now
38	6E5-44511-00-5B Cover, upper mount	Buy now




Carburetor



B6

Ref	Part	
1	64C-14301-01 Carburetor assembly 1 FOR STD	Buy now
1	64C-14301-S1 Carburetor assembly 1 FOR SWS	Buy now
1	64D-14301-S1 Carburetor assembly 1 FOR SWS	Buy now
2	64C-14302-01 Carburetor assembly 2 FOR STD	Buy now
2	64C-14302-S1 Carburetor assembly 2 FOR SWS	Buy now
2	64D-14302-S1 Carburetor assembly 2 FOR SWS	Buy now
3	64C-14303-01 Carburetor assembly 3 (64c-03) FOR STD	Buy now
3	64C-14303-S1 Carburetor assembly 3 FOR SWS	Buy now
3	64D-14303-S1 Carburetor assembly 3 FOR SWS	Buy now
4	64D-14384-01 Gasket, float chamber	Buy now
5	64D-14381-00 Body, float chamber FOR STD	Buy now
5	64D-14381-10 Body, Float Chamber FOR SWS	Buy now
6	6E5-14385-02 Float	Buy now
7	6E5-14546-00 Valve, needle	Buy now
8	6E5-14159-00 Clip	Buy now

Carburetor





64F0010-6060

B6

Ref	Part	
9	6E5-14386-02 Pin, float	Buy now
10	64D-1492F-42 Jet, air slow	Buy now
11	61U-14959-00 Gasket	Buy now
12	64D-14394-00 Valve, drain	Buy now
13	64D-1492E-71 Jet, main FOR SWS	Buy now
13	64D-1492E-75 Jet, main FOR STD	Buy now
14	64D-1492E-77 Jet, main FOR STD	Buy now
15	64D-1492E-79 Jet, main FOR STD	Buy now
16	6E5-14398-01 Gasket	Buy now
17	61A-1492H-12 Jet, slow air (#60)	Buy now
18	61A-14383-01 Screw, drain	Buy now
19	6E5-14321-00 Screw, throttle #2	Buy now
20	6J8-14334-00 Spring, throttle #2	Buy now
21	6E5-14328-01 Plug	Buy now
22	6E5-14979-00 Gasket	Buy now

Carburetor




64F0010-6060



B6


Ref	Part	
23	6E5-14323-03 Screw, air adjusting	Buy now
24	6E5-14223-00 Spring, air adjusting	Buy now
25	97980-05116 Screw, pan head FOR STD	Buy now
26	6E5-14527-01 Plate	Buy now
27	97980-05108 Screw, with washer	Buy now
28	6E5-14324-00 Screw, flat head	Buy now
29	6J8-14959-00 Gasket, drin screw	Buy now



E3


Ref	Part	
1	64D-48531-00 Bracket, remote control 1	Buy now
2	64D-48532-00 Bracket, remote control 2	Buy now
3	6E5-48538-00 Clamp, cable	Buy now
4	91690-30012 Pin, spring	Buy now
5	97095-08020 Bolt, hexagon	Buy now
6	92995-08100 Ybs67-8 washer, spring	Buy now
8	6E5-48344-00 Cable end, remote control	Buy now
9	90468-18008 Clip 620436610000	Buy now
11	663-85518-00 Joint, ball	Buy now
12	90157-06013 Screw, pan head(697)	Buy now
13	90501-16M12 Spring, compression (688)	Buy now
14	95303-06600 Nut(661)	Buy now
15	688-44194-00 Cap	Buy now
16	97013-08045 Bolt	Buy now
17	90201-08M23 Washer, plate (6e5)	Buy now

Control




Ref	Part	
18	90386-12089 Bushing(663)	Buy now
19	90387-08M16 Collar	Buy now
20	90386-22M13 Bushing (688)	Buy now
21	90202-12092 Washer, plate(663)	Buy now
22	90201-08M13 Washer plate (682)	Buy now
23	90508-29M12 Spring (6e5)	Buy now
24	6G5-41636-01 Rod, magneto control	Buy now
25	95380-05600 Nut, hexagon (663)	Buy now
26	662-41237-01 Joint, link	Buy now
27	90157-06M00 Screw, pan head(6h4)	Buy now
30	6G5-41211-01 Link, accel	Buy now
33	6G5-41213-00 Cam, accel	Buy now
34	90387-06M29 Coller (6a0)	Buy now
35	90206-10M04 Washer, wave (676)	Buy now
36	97095-06025 Bolt	Buy now

Control



E3

Ref	Part	
37	6E5-44117-00-1S Bracket	Buy now
38	90119-06MA2 Bolt, with washer	Buy now
39	68F-44121-00 Lever, shift rod	Buy now
40	6E5-44122-00 Bushing, shift rod lever	Buy now
41	90202-08M20 Washer, plate (6e5)	Buy now
44	90386-06M12 Bushing (688)	Buy now
45	6E5-44118-01-94 Bracket 2	Buy now
46	97013-08030 Bolt	Buy now
47	92903-08600 Washer, plain (663)	Buy now
48	93501-04M02 Ball (697)	Buy now
49	90501-12082 Spring 6484411600	Buy now
50	648-42715-00 Bushing 2	Buy now
51	93700-06M03 Nipple, grease(6a1)	Buy now
52	6E5-44120-03 Handle gear shift assembly L	Buy now
52	6E5-44120-23 Handle gear shift assembly X	Buy now




64D0010-0150

E3

Ref	Part	
53	93210-09165 O-ring	Buy now
54	90386-16M66 Bush(6e5)	Buy now
55	90202-16061 Washer, plate(663)	Buy now
56	93410-16006 Circlip	Buy now


Crankshaft. Piston



A7


Ref	Part	
1	6G5-11411-02 Crankshaft	Buy now
2	6E5-11447-00 Seal, ring	Buy now
4	93311-940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	93102-40M14 Oil seal(61a)	Buy now
6	93211-04001 O-ring	Buy now
7	90119-06MA2 Bolt, with washer	Buy now
8	93310-954U1 Bearing, cylindrical(64c)	Buy now
9	6R3-11536-00 Gear, drive	Buy now
10	93306-208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	93410-40M03 Circlip(n02)	Buy now
13	93102-35M13 Oil seal (6e5)	Buy now
14	93101-22M15 Oil seal (6e5)	Buy now
15	93210-74M35 O-ring (6e5)	Buy now
17	64D-11631-02-90 Piston (std)	Buy now
17	64D-11635-02 Piston (0.25mm o/s) AP	Buy now

Crankshaft. Piston



Ref	Part	
17	64D-11636-02 Piston (0.50mm o/s) AP	Buy now
18	64D-11603-01 Piston ring set (std)	Buy now
18	64D-11604-01 Piston ring set (0.25mm o/s) AP	Buy now
18	64D-11605-01 Piston ring set (0.50mm o/s) AP	Buy now
19	64D-11642-02-90 Piston 2 (std)	Buy now
19	64D-11645-02 Piston 2 (0.25mm o/s) AP	Buy now
19	64D-11646-02 Piston 2 (0.50mm o/s) AP	Buy now
21	6R5-11633-10 Pin, piston	Buy now
22	6R5-11634-10 Clip, piston pin	Buy now
23	6R5-11650-10 Connecting kit	Buy now
24	90109-08022 Bolt	Buy now
25	93310-323V6 Bearing	Buy now
26	90201-23M01 Washer, plate(6g6)	Buy now
27	93310-836V2 Brg, cyl-cal roller (6e5)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
3	624-11379-00 Valve, check	Buy now
4	90384-06M07 Bush, bimetal formed(6r3)	Buy now
5	90384-14M09 Bush, bimetal formed(6r3)	Buy now
6	663-11518-01 Lock, bearing	Buy now
7	646-11370-01 Check valve assembly	Buy now
8	90340-14M00 Plug, straight screw(62y)	Buy now
9	90430-14115 Gasket (663)	Buy now
10	93608-12063 Pin, dowel (626)	Buy now
11	90105-10M20 Bolt (6e5)	Buy now
12	90119-08M94 Bolt, with washer	Buy now
13	90116-08M45 Bolt, stud (6e5)	Buy now
14	6E5-11325-00 Anode	Buy now
15	98780-04015 Screw, flat head(ga5)	Buy now
16	67H-11119-01 Hanger, engine	Buy now
17	90119-08MA3 Bolt, with washer	Buy now


Cylinder. Crankcase 1



Ref	Part	
18	6K7-11371-01-1S Cover	Buy now
19	6E5-11381-A2 Gasket 1	Buy now
20	90119-06MA2 Bolt, with washer	Buy now
23	68F-44533-00 Damper, upper mount rubber	Buy now

A6


Cylinder. Crankcase 2



B2

Ref	Part	
1	6G5-11111-04-1S Head, cylinder 1	Buy now
2	6G5-11181-A2 Gasket, cylinder head 1	Buy now
3	90119-08MA8 Bolt, with washer	Buy now
4	6G5-11191-00-1S Cover, cylinder head 1	Buy now
5	6G5-11193-A0 Gasket, head cover 1	Buy now
6	90119-06MA4 Bolt, with washer	Buy now
7	6E5-12411-30 Thermostat	Buy now
8	688-12413-00-1S Cover, thermostat	Buy now
9	688-12414-A1 Gasket, cover	Buy now
10	90119-06MA6 Bolt, with washer	Buy now
11	64D-41111-00-1S Inner cover, exhaust	Buy now
12	6G5-41112-A1 Gasket, exhaust inner cover	Buy now
13	6G5-41114-A0 Gasket, exhaust inner cover	Buy now
14	6R3-41113-00-1S Outer cover, exhaust	Buy now
15	650-24378-00 Pipe, joint 2	Buy now


Cylinder. Crankcase 2



Ref	Part	
16	90119-06MA5 Bolt, with washer	Buy now
17	90445-09097 Hose (I1500)	Buy now
18	6G5-12416-00 Valve, pressure control	Buy now
19	90501-16M11 Spring, compression (688)	Buy now
20	90480-20M05 Grommet (688)	Buy now
21	6G5-11382-A1 Gasket 2	Buy now
23	90119-06MA2 Bolt, with washer	Buy now
24	6G5-12576-00 Hose 1	Buy now
25	90465-13M18 Clamp	Buy now
26	90465-06M86 Clamp	Buy now
27	94702-00271 Plug, spark (br7hs-10)	Buy now
27	94702-00247 Plug, spark (br8hs-10)	Buy now

B2

Electrical 1




 64L1100-2120

D2

Ref	Part	
1	6R3-81960-10 Rectifier & regulator assembly	Buy now
2	6R3-82150-00 Fuse holder assembly	Buy now
3	705-82151-00 Fuse (30a)	Buy now
4	6G5-82152-00 Holder, fuse	Buy now
5	64D-81942-00 Cover	Buy now
6	90387-06M66 Collar (6h4)	Buy now
7	97013-06055 Bolt(64d)	Buy now
8	92903-06600 Washer, plain (646)	Buy now
9	97095-06012 Bolt(gh1)	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	90465-06M88 Clamp	Buy now
12	90464-15M11 Clamp (3y2)	Buy now
15	64D-85540-01 C.d.i. unit assembly	Buy now
16	97880-06020 Screw pan head	Buy now
17	92990-06600 Washer, plain (646)	Buy now

Electrical 1




 64L1100-2120

D2


Ref	Part	
18	90465-05M87 Clamp	Buy now
20	90387-06M03 Collar (676)	Buy now
21	90480-09M12 Grommet (6a0)	Buy now
22	90119-06M61 Bolt, with washer	Buy now
23	64D-85537-00 Cover	Buy now
24	90159-06M11 Screw, with washer(6l2)	Buy now
25	6R3-8259E-00 Switch assembly	Buy now
26	662-82519-00 Wire, earth lead	Buy now
27	6R3-82519-00 Wire, earth lead	Buy now
30	6E5-85711-40 9-	Buy now

Electrical 2



D4


Ref	Part	
1	6R3-85570-01 Ignition coil assembly	Buy now
2	6E3-82370-21 Plug cap assembly	Buy now
3	97095-06020 Bolt(7u8)	Buy now
4	92995-06600 Washer, plain (646)	Buy now
5	90480-25161 Grommet(656)	Buy now
6	6E5-82531-10 Wire, lead	Buy now
7	64D-82590-00 Wire harness assembly	Buy now
8	663-82151-00 Fuse	Buy now
9	705-82151-00 Fuse (30a)	Buy now
10	688-82594-00 Clamp	Buy now
11	90465-05M87 Clamp	Buy now
12	90465-08M89 Clamp	Buy now
13	97095-06012 Bolt(gh1)	Buy now
15	6K7-82588-00 Plate	Buy now
18	688-82560-10 Thermo switch assembly	Buy now



D4

Ref	Part	
19	61A-85790-00 Thermosensor assembly	Buy now
20	92990-10600 Washer, plate	Buy now
21	90465-06M86 Clamp	Buy now
24	64D-86110-00 Solenoid	Buy now
25	97095-06016 Bolt, hexagon deep recess	Buy now
27	93210-03261 O-ring (663)	Buy now
28	6R3-82563-00 Trim & tilt switch assembly	Buy now
29	6E5-82587-00 Gasket	Buy now
30	6R3-83614-00 Bracket	Buy now
32	61A-81941-00 Starter relay assembly	Buy now
33	689-81952-10 Holder, starter relay	Buy now
34	6E5-81950-00 Relay assembly	Buy now
35	6E5-8195A-00 Relay assembly	Buy now
36	6G5-87149-10 Connector	Buy now
37	6G5-82119-00 Cover, lead wire	Buy now


Electrical 2



D4

Ref	Part	
38	6E5-82116-00 Wire, minus lead	Buy now
39	6G5-81948-11 Bracket	Buy now
42	6E9-83557-70 Tube	Buy now
43	90465-13M18 Clamp	Buy now
44	64D-82105-00 Battery cable FOR USA	Buy now
44	6R3-82105-02 Battery cable EXCEPT FOR USA	Buy now
45	64D-81920-01 Terminal assembly FOR USA	Buy now
46	95380-08700 Nut(661) FOR USA	Buy now
47	92990-08100 Ybs67-8 washer, spring FOR USA	Buy now
48	95380-06700 Nut FOR USA	Buy now
49	92990-06100 Washer(6a1) FOR USA	Buy now
50	97095-06035 Bolt(j52) FOR USA	Buy now
51	92995-06100 Washer(6a1) FOR USA	Buy now
52	64D-82117-00 Wire, Lead FOR USA	Buy now
53	64D-82116-00 Wire, Minus Lead FOR USA	Buy now


Electrical 2



D4


Ref	Part	
54	6E5-82117-01 Wire, lead	Buy now
55	6E5-82588-00 Plate	Buy now
58	90465-12M25 Clamp (6e5)	Buy now
61	6G5-82152-00 Holder, fuse	Buy now

Fuel 1



Ref	Part	
1	6R3-24313-01 Pipe 3 FOR CARIB,BRAZIL	Buy now
1	6R3-24313-20 Pipe 3 FOR USA,OCEANIA	Buy now
2	6R3-24377-00 Pipe, joint 3 EXCEPT FOR USA	Buy now
2	6R3-24377-10 Pipe, joint 3 FOR USA	Buy now
3	90465-11M10 Clamp	Buy now
5	6R3-24560-00 Filter assembly	Buy now
6	61N-24563-00 Element, filter	Buy now
7	61N-24521-00 Cup, filter	Buy now
8	93210-32738 O-ring(1wg)	Buy now
9	648-24566-02 Bracket, filter	Buy now
10	97013-06014 Bolt(gj3)	Buy now
11	92903-06100 Washer(6a1)	Buy now
12	95380-08600 Nut (661)	Buy now
13	6G5-24314-00 Pipe 4	Buy now
16	6E5-24378-00 Pipe, joint 3	Buy now


Fuel 1



C5

Ref	Part	
17	6G5-24315-00 Pipe 5	Buy now
18	6E5-24315-00 Pipe 5	Buy now
20	6E5-24410-03 Fuel pump assembly	Buy now
21	6E5-24444-00 Screw	Buy now
22	6E5-24413-00 Body 2	Buy now
23	6E5-24471-00 Diaphragm	Buy now
24	6E5-24435-00 Gasket, body 2	Buy now
25	6E5-24411-00 Diaphragm	Buy now
26	648-24424-00 Seat,spring	Buy now
27	6E5-24423-00 Spring, diaphragm	Buy now
28	6E5-24434-02 Gasket, body	Buy now
29	6A0-24421-01 Valve, check	Buy now
30	6A0-14325-00 Screw, pan head	Buy now
31	95380-03600 Nut (6g8)	Buy now
32	6E5-24412-10 Body 1	Buy now


Fuel 1



C5

Ref	Part	
33	650-24431-A0 Gasket,fuel pump	Buy now
34	97095-06050 Bolt(jf7)	Buy now
35	92995-06600 Washer, plain (646)	Buy now
36	6G5-24316-10 Pipe 6	Buy now
39	6G5-24376-00 Pipe, joint 1	Buy now
40	6G5-24377-00 Pipe, joint 2	Buy now
41	6G5-24317-01 Pipe 7	Buy now
42	6G5-24318-10 Hose (I90)	Buy now
43	6G5-24319-10 Pipe 9	Buy now
46	90446-15M07 Hose(6g4)	Buy now

Fuel 2




64D2100-3100

Ref	Part	
1	6Y2-24307-41 Fuel pipe comp. 2 AP FOR OCEANIA	Buy now
2	90445-13M01 Hose (I2050)	Buy now
3	6E5-24351-51 Band 1	Buy now
4	90480-06M19 Grommet (6e3)	Buy now
5	6Y2-24360-52 Primer pump assembly	Buy now
6	6Y2-24306-42 Fuel pipe comp. 1 AP FOR CARIB	Buy now
9	90445-13M35 Hose (L250)	Buy now
11	6Y2-24305-04 Fuel pipe joint comp. 2	Buy now
12	93210-08287 O-ring (655)	Buy now

C7


Fuel Tank



C2

Ref	Part	
1	6YJ-24201-10 Fuel Tank assembly (24L) AP FOR CARIB,BRAZIL	Buy now
2	6YJ-24610-01 Cap assembly	Buy now
3	6Y1-24260-12 Fuel meter assembly WITH INDICATOR	Buy now
4	98586-05016 Screw, pan head	Buy now
5	6Y1-24329-00 Seal	Buy now
6	6Y1-24268-00 Gasket, fuel meter	Buy now
7	6YJ-24167-00 Strainer	Buy now
8	6Y2-24306-42 Fuel pipe comp. 1 AP FOR CARIB,BRAZIL	Buy now
9	90445-13M01 Hose (I2050)	Buy now
10	6E5-24351-51 Band 1	Buy now
11	90445-13M35 Hose (L250)	Buy now
12	6Y2-24360-52 Primer pump assembly	Buy now
13	6Y2-24305-04 Fuel pipe joint comp. 2	Buy now
14	93210-08287 O-ring (655)	Buy now

Generator




64D1100-2110



D1

Ref	Part	
1	64D-85550-02 Rotor assembly	Buy now
2	6R3-85510-00 Stator assembly	Buy now
3	64D-85580-00 Coil, pulser	Buy now
4	90465-06M86 Clamp	Buy now
5	6R5-85895-01 Crank position sender	Buy now
6	97885-05012 Screw,pan head (646)	Buy now
7	90464-15M11 Clamp (3y2)	Buy now
8	90280-05015 Key, woodruff	Buy now
9	90201-21M18 Washer, plate (663)	Buy now
10	90170-20137 Nut, hexagon(663)	Buy now
11	97013-06070 Bolt(62j)	Buy now
12	92903-06600 Washer, plain (646)	Buy now
13	688-41611-00 Retainer, magneto base 1	Buy now
14	688-41612-00 Retainer, magneto base 2	Buy now
15	97880-06018 Screw, pan head(6e5)	Buy now


Generator



D1

Ref	Part	
16	6E5-81332-00 Plate, timing	Buy now
17	97885-06010 Screw pan head	Buy now
18	92995-06600 Washer, plain (646)	Buy now
19	64D-81337-01 Cover, Flywheel FOR SWS	Buy now
19	64D-81337-10 Cover, flywheel FOR STD	Buy now
20	6G5-82317-00 Damper FOR STD	Buy now
20	90480-13M24 Grommet (6e9) FOR SWS	Buy now
21	663-82317-01 Damper, ignition coil	Buy now
22	6A1-83625-41 Mark 5	Buy now
23	6K1-83623-41 Mark 3	Buy now
24	6G5-14488-02 Label, caution	Buy now


Intake



B4

Ref	Part	
1	6E5-13610-00 Reed valve assembly	Buy now
2	6E5-W0004-00 Reed set	Buy now
3	6E5-13621-A1 Gasket, valve seat	Buy now
4	97880-05016 Screw, pan head(6b0)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
7	6E5-13552-01 Nozzle	Buy now
8	624-14485-00 Pipe, joint	Buy now
9	6E5-11370-01 Check valve assembly	Buy now
10	90445-07M28 Hose (l200)	Buy now
11	90445-07M45 Hose (l390)	Buy now
12	90445-07M46 Hose (l390)	Buy now
13	90445-07M09 Hose (l390)	Buy now
14	90445-07M59 Hose (l770)	Buy now
15	90464-07M05 Clamp (6g5)	Buy now
16	90465-10M91 Clamp	Buy now


Intake



B4

Ref	Part	
17	90116-06M30 Bolt, stud(6e5)	Buy now
18	6G5-13645-A2 Gasket, manifold 1	Buy now
19	90119-06MA3 Bolt, with washer	Buy now
20	6E5-14198-A2 Gasket	Buy now
21	90179-06M28 Nut(63v)	Buy now
22	6G5-41217-01 Rod, accel. lever	Buy now
23	6E5-41256-01 Rod, choke 1	Buy now
24	661-41262-02 Joint, choke lever	Buy now
25	6R3-41271-00 Knob, choke	Buy now
26	689-41273-00 Grommet	Buy now
27	6R3-14440-02 Silencer assembly, intake FOR STD	Buy now
27	64D-14440-00 Silencer assembly, Intake FOR SWS	Buy now
28	6G5-1441K-00 Emblem FOR STD	Buy now
29	90445-07MA3 Hose (I200)	Buy now
30	6K7-14483-00 Gasket	Buy now


Intake



Ref	Part	
31	90159-06M08 Screw, with washer(6k7) FOR SWS	Buy now
31	90159-06M14 Screw, with washer(6r3) FOR STD	Buy now


B4

Lower Casing. Drive 1




Ref	Part	
2	6J9-45301-05-8D Casing, lower	Buy now
3	93311-928U5 Bearing, needle (6g5)	Buy now
4	93332-000V3 Bearing, taper roller (6g5)	Buy now
6	90340-08002 Plug, straight screw	Buy now
7	688-45341-10 Plug, drain	Buy now
8	90430-08020 Gasket	Buy now
9	90206-22M19 Washer, wave(61a)	Buy now
10	90201-22M01 Washer, plate(61a)	Buy now
11	61A-45527-00 Collar, drive shaft	Buy now
12	61A-45538-00 Spacer, 1	Buy now
13	6G5-45536-01 Sleeve, drive shaft	Buy now
14	64D-45376-00-94 Guide, seal damper <i>X</i>	Buy now
14	663-45376-00-94 Guide, seal damper <i>L</i>	Buy now
15	688-45375-00 Damper, seal 2	Buy now
16	6E5-45378-00 Nipple, hose	Buy now

Lower Casing. Drive 1




Ref	Part	
17	90445-07ME8 Hose (I250) L	Buy now
17	90445-07ME9 Hose (I250) X	Buy now
18	6E5-83558-10 End, nipple	Buy now
19	6E5-45321-00 Plate	Buy now
20	93210-58144 O-ring(47x)	Buy now
21	93106-09014 Oil seal	Buy now
22	90119-06M10 Bolt, with washer	Buy now
23	6G5-44150-02 Shift cam assembly	Buy now
24	99001-08600 Circlip(2r6)	Buy now
25	90501-11M10 Spring, compression (663)	Buy now
26	61A-44311-01 Housing, water pump	Buy now
27	61A-44322-02 Insert, cartridge	Buy now
28	93210-86M38 O-ring (6e5)	Buy now
29	93210-37160 O-ring (6g8)	Buy now
30	6E5-44365-00 Damper, water seal 1	Buy now

Lower Casing. Drive 1




Ref	Part	
31	6E5-44312-00 Cover, water pump housing	Buy now
32	6E5-44352-01 Impeller	Buy now
33	90280-04M05 Key, woodruff (6e5)	Buy now
34	6G5-44323-00 Outer plate, cartridge	Buy now
35	6E5-44315-A0 Gasket,water pump	Buy now
36	93606-12019 Pin, dowel (614)	Buy now
37	90119-08M14 Bolt, with washer	Buy now
38	6E5-45331-00-94 Housing, bearing	Buy now
39	93101-28M16 Oil seal (6e5)	Buy now
40	93317-330U2 Bearing, cylindrical(6k0)	Buy now
41	6E5-45587-01-10 Shim (t:0.10mm) UR	Buy now
41	6E5-45587-01-12 Shim (t:0.12mm) UR	Buy now
41	6E5-45587-01-15 Shim (t:0.15mm) UR	Buy now
41	6E5-45587-01-18 Shim (t:0.18mm) UR	Buy now
41	6E5-45587-01-30 Shim (t:0.30mm) UR	Buy now

Lower Casing. Drive 1



Ref	Part	
41	6E5-45587-01-40 Shim (t:0.40mm) UR	Buy now
41	6E5-45587-01-50 Shim (t:0.50mm) UR	Buy now
42	93341-930V2 Bearing, thrust(64d)	Buy now
43	93210-55M14 O-ring (70e)	Buy now
44	6E5-45344-00 Cover, oil seal	Buy now
45	97095-08025 Bolt (62g)	Buy now
46	92995-08600 Washer, plain (663)	Buy now
47	6G5-45501-01 Drive shaft comp. L	Buy now
47	6G5-45501-21 Drive shaft comp. X	Buy now
48	6G5-45551-01 Pinion	Buy now
49	90170-16M01 Nut, hexagon (688)	Buy now
50	6G5-45560-01 Gear	Buy now
51	93315-425V3 Bearing, needle (6g5)	Buy now
52	6J9-45611-01 Shaft, propeller	Buy now
53	6E5-45641-02 Shifter	Buy now


Lower Casing. Drive 1



A5

Ref	Part	
54	6E5-45634-01 Slide, shift	Buy now
55	90501-16M37 Spring (6g5)	Buy now
56	93507-32009 Ball (12r)	Buy now
57	93511-32017 Ball (498)	Buy now
58	93503-16003 Ball	Buy now
59	90250-08M07 Pin, straight (6g5)	Buy now
60	6G5-45631-00 Clutch, dog	Buy now
61	6E5-45633-01 Ring, cross pin	Buy now
62	6J9-45332-00-94 Housing, bearing	Buy now
63	93306-209U0 Bearing (6g5)	Buy now
64	6G5-45571-02 Gear	Buy now
65	6G5-45576-10 Washer, thrust 2	Buy now
66	93315-430U8 Bearing	Buy now
67	93101-30M17 Oil seal (6e5)	Buy now
68	93210-97M55 O-ring (6g5)	Buy now


Lower Casing. Drive 1



Ref	Part	
70	90201-30M92 Washer (6g5)	Buy now
71	90282-04M00 Key, straight(6g5)	Buy now
72	6G5-45383-01 Washer, claw	Buy now
73	6G5-45384-00 Nut	Buy now

A5

Lower Casing. Drive 2




67H0100-1260

B2

Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	6E5-44361-00 Tube, water <i>L</i>	Buy now
2	6E5-44361-20 Tube, water <i>X</i>	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97075-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	90119-10M89 Bolt, with washer	Buy now
8	6J9-45214-00 Cover, water inlet	Buy now
9	6J9-45215-00 Cover, water inlet	Buy now
10	90152-05M08 Screw, countersunk	Buy now
11	90185-05002 Nut nylon (sus)(ex4)	Buy now
12	6J9-45371-01 Tab-trim	Buy now
13	90105-10M00 Bolt, hexagon (663)	Buy now
14	90445-07M33 Hose (L1080)	Buy now


Lower Casing. Drive 2



B2

Ref	Part	
15	6E5-83558-00 End, nipple	Buy now
16	90465-11M10 Clamp	Buy now
17	6E5-45987-01 Spacer 1	Buy now
18	688-45997-01 Spacer 2	Buy now
19	92990-18200 Washer (6e5)	Buy now
20	90171-18M04 Nut, castle (6e5)	Buy now
21	91490-40030 Pin, cotter (663)	Buy now
?	6R4-45970-A0 Propeller (3X15-1/4"X19"-M) UR	Buy now
?	6R4-45972-A0 Propeller (3X14-7/8"X21"-M) UR	Buy now
?	6R4-45974-A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
?	6R4-45976-A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
?	6R4-45978-A0 Propeller (3X15-1/4"X17"-M) UR	Buy now


Lower Casing. Drive 3



B4

Ref	Part	
2	6J9-45301-05-8D Casing, lower	Buy now
3	93311-928U5 Bearing, needle (6g5)	Buy now
4	93390-000U2 Bearing(6k0)	Buy now
5	93341-465U4 Bearing, thrust (6k0)	Buy now
7	90340-08002 Plug, straight screw	Buy now
8	688-45341-10 Plug, drain	Buy now
9	90430-08020 Gasket	Buy now
10	90206-22M19 Washer, wave(61a)	Buy now
11	90201-22M01 Washer, plate(61a)	Buy now
12	61A-45527-00 Collar, drive shaft	Buy now
13	61A-45538-00 Spacer, 1	Buy now
14	6G5-45536-01 Sleeve, drive shaft	Buy now
15	64D-45376-00-94 Guide, seal damper X	Buy now
16	688-45375-00 Damper, seal 2	Buy now
17	6J8-45378-00 Nipple, hose (plug)	Buy now


Lower Casing. Drive 3



B4


Ref	Part	
18	6E5-45321-00 Plate	Buy now
19	93210-58144 O-ring(47x)	Buy now
20	93106-09014 Oil seal	Buy now
21	90119-06M10 Bolt, with washer	Buy now
22	6K1-44150-01 Shift cam assembly	Buy now
23	99001-08600 Circlip(2r6)	Buy now
24	90501-11M10 Spring, compression (663)	Buy now
25	61A-44311-01 Housing, water pump	Buy now
26	61A-44322-02 Insert, cartridge	Buy now
27	93210-86M38 O-ring (6e5)	Buy now
28	93210-37160 O-ring (6g8)	Buy now
29	6E5-44365-00 Damper, water seal 1	Buy now
30	6E5-44312-00 Cover, water pump housing	Buy now
31	6E5-44352-01 Impeller	Buy now
32	90280-04M05 Key, woodruff (6e5)	Buy now

Lower Casing. Drive 3



Ref	Part	
33	6G5-44323-00 Outer plate, cartridge	Buy now
34	6E5-44315-A0 Gasket,water pump	Buy now
35	93606-12019 Pin, dowel (614)	Buy now
36	90119-08M14 Bolt, with washer	Buy now
37	6E5-45331-00-94 Housing, bearing	Buy now
38	93101-28M16 Oil seal (6e5)	Buy now
39	93317-330U2 Bearing, cylindrical(6k0)	Buy now
40	6E5-45587-01-10 Shim (t:0.10mm) UR	Buy now
40	6E5-45587-01-12 Shim (t:0.12mm) UR	Buy now
40	6E5-45587-01-15 Shim (t:0.15mm) UR	Buy now
40	6E5-45587-01-18 Shim (t:0.18mm) UR	Buy now
40	6E5-45587-01-30 Shim (t:0.30mm) UR	Buy now
40	6E5-45587-01-40 Shim (t:0.40mm) UR	Buy now
40	6E5-45587-01-50 Shim (t:0.50mm) UR	Buy now
41	93341-930V2 Bearing, thrust(64d)	Buy now


Lower Casing. Drive 3



B4

Ref	Part	
42	93210-55M14 O-ring (70e)	Buy now
43	6E5-45344-00 Cover, oil seal	Buy now
44	97095-08025 Bolt (62g)	Buy now
45	92995-08600 Washer, plain (663)	Buy now
46	6G5-45501-21 Drive shaft comp. X	Buy now
47	6G5-45551-01 Pinion	Buy now
48	90170-16M01 Nut, hexagon (688)	Buy now
49	6K1-45560-01 Gear	Buy now
50	93315-425V3 Bearing, needle (6g5)	Buy now
51	6K1-45611-10 Shaft, propeller	Buy now
52	6K1-45641-01 Shifter	Buy now
53	6E5-45634-01 Slide, shift	Buy now
54	90501-16M37 Spring (6g5)	Buy now
55	93507-32009 Ball (12r)	Buy now
56	93511-32017 Ball (498)	Buy now


Lower Casing. Drive 3



B4

Ref	Part	
57	93503-16003 Ball	Buy now
58	90250-08M07 Pin, straight (6g5)	Buy now
59	6G5-45631-00 Clutch, dog	Buy now
60	6E5-45633-01 Ring, cross pin	Buy now
61	6K1-45332-01-94 Housing, bearing	Buy now
62	93332-00048 Bearing(6k0)	Buy now
63	6K1-45570-01 Gear	Buy now
64	6K1-45576-00 Washer, thrust	Buy now
65	93341-440U5 Bearing, thrust (6k0)	Buy now
66	6K1-45578-01-10 Shim (t:0.10mm) UR	Buy now
66	6K1-45578-01-12 Shim (t:0.12mm) UR	Buy now
66	6K1-45578-01-15 Shim (t:0.15mm) UR	Buy now
66	6K1-45578-01-18 Shim (t:0.18mm) UR	Buy now
66	6K1-45578-01-30 Shim (t:0.30mm) UR	Buy now
66	6K1-45578-01-40 Shim (t:0.40mm)	Buy now


Lower Casing. Drive 3



B4

Ref	Part	
66	6K1-45578-01-50 Shim (t:0.50mm) UR	Buy now
67	93315-430U8 Bearing	Buy now
68	93101-30M17 Oil seal (6e5)	Buy now
69	93210-97M55 O-ring (6g5)	Buy now
71	90282-04M00 Key, straight(6g5)	Buy now
72	6G5-45383-01 Washer, claw	Buy now
73	6G5-45384-00 Nut	Buy now


Lower Casing. Drive 4



C1

Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	6E5-44361-20 Tube, water X	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97075-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	90119-10M89 Bolt, with washer	Buy now
8	6J9-45214-00 Cover, water inlet	Buy now
9	6J9-45215-00 Cover, water inlet	Buy now
10	90152-05M08 Screw, countersunk	Buy now
11	90185-05002 Nut nylon (sus)(ex4)	Buy now
12	6K1-45371-02 Tab-trim	Buy now
13	90105-10M00 Bolt, hexagon (663)	Buy now
14	6E5-45987-01 Spacer 1	Buy now
15	688-45997-01 Spacer 2	Buy now


Lower Casing. Drive 4



C1

Ref	Part	
16	92990-18200 Washer (6e5)	Buy now
17	90171-18M04 Nut, castle (6e5)	Buy now
18	91490-40030 Pin, cotter (663)	Buy now
19	6K1-45970-01-98 Propeller (3x15-1/4"x15"-ml) UR	Buy now
19	6K1-45972-01-98 Propeller (3x13-3/4"x21"-ml) UR	Buy now
19	6K1-45974-02-98 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
19	6K1-45978-02-98 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
19	6R1-45970-A0 Propeller, Ss (3 X 15-1/4" X 19"-Mi) UR	Buy now
19	6R1-45972-A0 Propeller (3X14-7/8"X21"-Mi) UR	Buy now
19	6R1-45974-A0 Propeller (3X14-1/2"X23"-Mi) UR	Buy now
19	6R1-45976-A0 Propeller (3X15-1/4"X15"-Mi) UR	Buy now
19	6R1-45978-A0 Propeller (3X15-1/4"x17"-Mi) UR	Buy now


Meter



D5


Ref	Part	
1	6Y5-8350T-01 Digital tachometer assembly AP	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83500-S5 Meter assembly AP	Buy now
7	6Y5-83570-S5 Speedometer assembly	Buy now
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
22	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a) FOR 6Y5-83553-M0	Buy now

Meter



Ref	Part	
17	6Y5-82117-00 Wire, lead AP	Buy now
18	6R3-82521-70 Wire, lead (for tacho., 7m) AP FOR CARIB,	Buy now
18	6R3-82521-80 Wire, lead (for tacho., 8m) AP FOR CARIB 8M	Buy now
19	68F-82553-80 Extension, wire lead (8m) AP FOR OCEANIA	Buy now
19	68F-82553-90 Extension, wire lead (9m) AP FOR OCEANIA	Buy now
19	6R3-82553-70 Extension, wire lead (for trim AP FOR CARIB,	Buy now
19	6R3-82553-80 Wire, lead AP FOR CARIB 4P,8M	Buy now
20	6R3-82553-30 Wire, lead AP FOR CARIB	Buy now
21	6Y5-83557-00 Tube (8m) AP FOR CARIB,BRAZIL	Buy now
21	6Y5-83557-10 Tube (8m) AP FOR OCEANIA	Buy now
23	6Y5-8350F-00 Fuel meter movement assembly AP FOR OCEANIA	Buy now
25	6Y5-83553-F1 Wire, lead AP FOR OCEANIA	Buy now
26	6Y5-85752-01 Sender unit assembly, fuel meter AP FOR OCEANIA	Buy now
27	90158-06002 33 – AP FOR OCEANIA	Buy now
29	703-82531-00 Wire, lead AP FOR OCEANIA	Buy now


Oil Pump



C1

Ref	Part	
1	6E5-14276-01 Lever	Buy now
2	91690-30016 Pin, spring	Buy now
3	6R4-13200-00 Oil injection pump assembly	Buy now
4	6R3-13471-00 Screw	Buy now
5	6L2-13475-00 Gasket, breather bolt	Buy now
6	93210-19MA7 O-ring(6r0)	Buy now
7	90109-06M40 Bolt(6h0)	Buy now
8	6R3-13416-00 Pipe, oil 1	Buy now
9	90465-11M10 Clamp	Buy now
10	90445-07M72 Hose (l390)	Buy now
11	90445-07M89 Hose (l390)	Buy now
12	90445-07M83 Hose (l200)	Buy now
13	6R3-13183-10 Valve, check	Buy now
14	90445-07M87 Hose(62t)	Buy now
15	90445-07M96 Hose(62t)	Buy now


Oil Pump



Ref	Part	
16	90464-07M05 Clamp (6g5)	Buy now
17	90468-07M02 Clip (6e5)	Buy now
18	90465-10M91 Clamp	Buy now
19	6R3-11537-00 Gear, driven	Buy now
20	6R3-13117-00 Collar, distance	Buy now
21	93210-13M04 93210-13m04	Buy now
22	90202-08M44 Washer, plate(6r3)	Buy now
23	6R3-41241-00 Rod, link	Buy now
24	6H1-41237-00 Joint, link	Buy now
25	95380-05600 Nut, hexagon (663)	Buy now
26	6R5-41237-00 Joint, link	Buy now
27	90468-05M03 Clip(6j8)	Buy now
28	90202-05088 Washer, plate (666)	Buy now

C1

Oil Tank




64D2100-3080

C3

Ref	Part	
1	61A-21708-20 Sub oil tank assembly. FOR OCEANIA	Buy now
1	6E5-21708-10 Sub oil tank assembly FOR CARIB,BRAZIL	Buy now
1	6K1-21708-10 Sub oil tank assembly. FOR CARIB	Buy now
2	6E5-21733-20 Sub tank, oil (10.5l)	Buy now
3	6E5-21770-03 Oil tank cap assembly	Buy now
4	6E5-24322-00 Pipe 11	Buy now
5	90465-11M10 Clamp	Buy now
6	646-24251-02 Strainer 1	Buy now
7	6E5-24319-01 Pipe, oil	Buy now
9	6E5-81900-01 Oil feed pump assembly	Buy now
10	6E5-81922-00 Grommet	Buy now
11	6E5-24321-01 Pipe 10	Buy now
12	6E5-24379-00 Pipe, joint 4	Buy now
13	90445-11M00 Hose (l8000) FOR 6K1-21708-10	Buy now
13	90445-11M26 Hose (l8000) FOR 61A-21708-20	Buy now


Oil Tank



C3

Ref	Part	
13	90445-11M81 Hose (I3000) FOR 6E5-21708-10	Buy now
15	6E5-85720-04 Oil level gauge assembly	Buy now
16	6R3-85721-30 Wire, lead FOR 6E5-21708-10	Buy now
16	6R3-85721-80 Wire, lead	Buy now
17	90465-13M11 Clamp (6e5) FOR OCEANIA	Buy now
18	6E5-21734-01-33 Holder, oil sub tank	Buy now
19	6E5-21798-01-33 Bracket, damper	Buy now
20	6E5-21746-00 Damper	Buy now
21	97080-06100 Bolt, hexagon	Buy now
22	92990-06600 Washer, plain (646)	Buy now
23	95380-06600 Nut(661)	Buy now
24	6E5-21750-05 Oil tank assembly	Buy now
25	6E5-13448-00 Cap, oil tank	Buy now
27	6R3-85730-03 Oil level gauge assembly	Buy now
28	6E5-13411-00 Strainer, oil	Buy now


Oil Tank



C3

Ref	Part	
29	6E5-13414-00 Gasket, strainer cover	Buy now
30	90445-05M02 Hose (L700)	Buy now
31	6A0-82317-00 Damper, ignition coil	Buy now
32	624-42542-00 Collar	Buy now
33	90119-06M65 Bolt, with washer	Buy now
34	64E-24323-00 Pipe 12	Buy now
35	90445-12207 Hose (L3000) FOR USA,OCEANIA	Buy now
35	90445-12M13 Hose (L880) FOR CARIB,BRAZIL	Buy now
40	90464-13M34 Clamp(6r3)	Buy now
41	6E5-13437-43 Mark, Caution FOR USA,OCEANIA	Buy now
41	6E5-13437-62 Mark Caution FOR CARIB,BRAZIL	Buy now
42	656-W2810-02 Tool kit FOR CARIB,BRAZIL	Buy now


Power Trim & Tilt Assy 1



F3

Ref	Part	
2	64E-43825-01 Housing Trim & Tilt	Buy now
3	64E-4388J-00 Plug 2	Buy now
4	93210-10M74 O-ring	Buy now
5	64E-43817-00 Filter 2	Buy now
6	64E-43810-00 Tilt piston sub assembly	Buy now
7	64E-43898-00 Seal, dust 2	Buy now
8	64E-43867-00 O-ring 7	Buy now
9	64E-43866-00 O-ring 6	Buy now
10	6E5-43862-00 O-ring 2	Buy now
11	64E-43883-00 O-ring 10	Buy now
12	6E5-43872-00 Ring, back-up 2	Buy now
13	6E5-43814-02 Piston, free	Buy now
15	64E-43820-00 Trim piston sub assembly	Buy now
16	64E-43821-00 Screw, trim cylinder end	Buy now
17	64E-43822-00 Seal, trim dust	Buy now

Power Trim & Tilt Assy 1




F3

Ref	Part	
18	64E-4384J-00 Seal, trim down	Buy now
19	6G5-43864-00 O-ring 4	Buy now
20	6E5-43864-00 O-ring 4	Buy now
21	6E5-43874-01 Ring, back-up 4	Buy now
22	64E-43828-00 Body, reservoir	Buy now
23	64E-43829-00 Plug, reservoir	Buy now
24	64E-43897-00 O-ring	Buy now
25	64E-4388E-00 Bolt ,screw (l:14mm)	Buy now
26	64E-43869-00 O-ring 9	Buy now
27	64E-4381G-00 Pin 1	Buy now
28	6E5-43858-00 Ball 1	Buy now
29	64E-4382G-00 Valve seat	Buy now
30	90201-08M14 Washer, plate	Buy now
31	97080-08016 Bolt	Buy now
32	64E-43818-01 Lower shock mount pin set	Buy now


Power Trim & Tilt Assy 1

Ref	Part	
33	90386-22M98 Bush(61u)	Buy now



F3


Power Trim & Tilt Assy 2



F5

Ref	Part	
1	64E-4388E-10 Bolt ,screw (l:34.7mm)	Buy now
2	64E-43831-00 Connector, shaft	Buy now
3	64E-43868-00 O-ring 8	Buy now
4	64E-43830-00 Gear pump assembly	Buy now
5	72X-43858-00 Ball	Buy now
6	64E-43843-00 Screw, valve lock	Buy now
7	64E-43841-00 Piston, shuttle	Buy now
8	64E-43802-00 Valve sub assembly	Buy now
9	6E5-43896-00 O-ring	Buy now
10	6G5-43863-00 O-ring 3	Buy now
11	64E-43851-00 Seat, Relief Valve	Buy now
12	64E-43858-00 Ball	Buy now
13	64E-43859-00 Pin, Valve Support	Buy now
14	64E-43855-00 Spring, up relief	Buy now
15	64E-43850-00 Valve sub assembly	Buy now


Power Trim & Tilt Assy 2



F5

Ref	Part	
16	64E-43865-00 O-ring 10	Buy now
17	64E-43816-00 Filter 1	Buy now
19	64E-43817-10 Filter 2	Buy now
20	64E-43860-00 Manual valve sub-assembly	Buy now
21	72X-85075-L0 O-ring (nsd161)	Buy now
22	64E-43827-00 Ring set	Buy now
23	64E-4387A-00 O-ring	Buy now
24	64E-43873-00 Ring, back up	Buy now
25	64E-43875-00 Ring, snap	Buy now
26	64E-43879-10 Screw, with washer	Buy now
27	64E-43879-00 Screw, with washer	Buy now
28	64E-43880-01 Motor assembly	Buy now
29	6H1-4386K-10 Spring, brush	Buy now
30	64E-4380J-00 Holder Brush	Buy now
31	64E-43891-00 Brush 1	Buy now


Power Trim & Tilt Assy 2



F5

Ref	Part	
32	97607-04310 Screw, pan head(6g8)	Buy now
33	64E-4380F-00 Holder, brush 2	Buy now
34	64E-43892-00 Breaker comp. (brush 2)	Buy now
35	6G5-43865-00 O-ring	Buy now
36	93102-08M43 Oil seal(6b0)	Buy now
37	64E-43805-00 Armature assembly	Buy now
38	64E-43843-10 Screw valve lock	Buy now


Remote Control Assy 1



C6

Ref	Part	
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	703-48261-01 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now
15	703-48243-00 Bushing 3	Buy now


Remote Control Assy 1



C6

Ref	Part	
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now
30	703-48219-00 Cover, lead	Buy now


Remote Control Assy 1



C6

Ref	Part	
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-43 Main switch assembly	Buy now
45	703-82577-00 Cap, key	Buy now


Remote Control Assy 1



C6

Ref	Part	
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-02 Buzzer	Buy now
52	703-48284-00 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-82563-02 Trim & tilt switch assembly WITH PT/T SW.	Buy now
56	703-48221-00 Grip	Buy now
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now


Remote Control Assy 1



Ref	Part	
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now

C6


Remote Control Assy 2



D2

Ref	Part	
1	704-48207-23 Remote Control assembly AP WITH PT/T SW.	Buy now
2	97890-05016 Screw, pan head(6b0)	Buy now
3	EL8-48251-00 Plate, cam	Buy now
4	704-48265-00 Shaft, friction	Buy now
5	701-48246-00 Spacer	Buy now
6	93430-06024 Circlip (701)	Buy now
7	EL8-48259-00 Circlip 1	Buy now
8	704-48262-00 Shaft, throttle	Buy now
9	704-48264-00 Friction, throttle	Buy now
10	704-48266-00 Spacer 2	Buy now
11	704-82540-10 Neutral switch assembly	Buy now
12	6A5-48129-10 Screw, pan head (n151)	Buy now
13	EL8-48281-00 Screw 1	Buy now
14	704-48215-10 Graphic 1	Buy now
15	704-48281-00 Screw1	Buy now


Remote Control Assy 2



D2

Ref	Part	
16	97890-05025 Screw, panhead (a93)	Buy now
17	704-48261-00 Arm, throttle	Buy now
18	EL8-48191-00 Washer 1	Buy now
19	704-48283-00 Screw,panhead (eg9)	Buy now
20	97380-06018 Bolt (fj0)	Buy now
21	703-48345-01 Cable end, remote control 2	Buy now
22	704-48287-00 Washer 1	Buy now
23	95380-05600 Nut, hexagon (663)	Buy now
24	EL8-48271-00 Arm, shift	Buy now
25	EL8-48127-00 Screw 1	Buy now
26	703-48358-00 Anchor, cable	Buy now
27	EL8-48231-00 Housing, gear	Buy now
28	EL8-48241-00 Arm, drive	Buy now
29	EL8-48254-00 Stopper Throttle Adjusting	Buy now
30	92780-06020 Screw flat head	Buy now


Remote Control Assy 2



D2

Ref	Part	
31	EL8-48158-00 Spring 1	Buy now
32	98580-04006 Screw, pan head (7h3)	Buy now
33	98780-05018 Screw (704)	Buy now
34	EL8-48244-00 Spring, free accel.	Buy now
35	EL8-48245-00 Plate, lock	Buy now
36	704-48222-00 Grip, control lever	Buy now
37	704-82594-00 Clamp	Buy now
38	704-48228-00 Holder, switch	Buy now
39	704-82563-31 Trim & tilt switch assembly	Buy now
40	704-48229-00 Grip, control lever 2	Buy now
41	92990-05300 Washer, tooth	Buy now
42	95380-06600 Nut(661)	Buy now
43	701-48248-00 Roller, free accel	Buy now
44	703-48238-00 Spring, detent	Buy now
45	EL8-48232-00 Gear 1	Buy now


Remote Control Assy 2



D2

Ref	Part	
46	EL8-48164-00 Pin 2	Buy now
47	704-48242-00 Shaft, drive	Buy now
48	704-48225-00 Cover	Buy now
49	704-48192-00 Washer 2	Buy now
50	97890-06018 Screw, pan head(6e5)	Buy now
51	92990-06300 Washer, tooth	Buy now
52	702-48263-00 Bushing 4	Buy now
53	EL8-48279-00 Circlip 2	Buy now
54	704-48193-00 Washer 3	Buy now
55	EL8-48234-00 Bushing 1	Buy now
56	704-48219-00 Cover, lead	Buy now
57	704-48144-00 Plate, stopper 2	Buy now
58	704-48176-10 Grommet	Buy now
59	703-48192-00 Washer 2	Buy now
60	EL8-48233-00 Gear 2	Buy now


Remote Control Assy 2



D2

Ref	Part	
61	703-48235-00 Bushing	Buy now
62	704-48282-00 Screw 2	Buy now
63	EL8-48153-10 Shaft, free accel.	Buy now
64	704-48166-00 Plug	Buy now
65	704-48284-00 Grommet	Buy now
66	704-81950-00 Relay assembly	Buy now
67	704-82590-10 Wireharness assembly	Buy now
68	704-48229-10 Grip, control lever 2	Buy now
69	704-82563-E0 Trim & tilt switch assembly	Buy now
70	704-48228-10 Holder, switch	Buy now
71	704-48128-00 Screw, pan head	Buy now
72	704-48156-00 Nut 1	Buy now
73	704-82563-F0 Trim & tilt switch assembly	Buy now
74	704-48285-00 Grommet 2	Buy now
75	704-48286-00 Grommet 3	Buy now


Remote Control Assy 2



D2

Ref	Part	
76	704-48178-00 Plate, shift	Buy now
77	704-48221-00 Lever control	Buy now
78	704-48119-20 Cover	Buy now

Remote Control Box




67H0100-9310

C5

Ref	Part	
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	704-48207-23 Remote Control assembly AP WITH PT/T SW.	Buy now
3	701-48320-50 Cable, Remote Control L=15F UR	Buy now
3	701-48320-60 Cable, Remote Control L=16F UR	Buy now
3	701-48320-80 Cable, Remote Control L=17F UR	Buy now
3	701-48350-00 Cable, Remote Control L=21F UR	Buy now
3	701-48350-20 Cable, Remote Control L=23F UR	Buy now


Repair Kit 1



E1

Ref	Part	
1	64D-W0001-00 Power head gasket kit	Buy now
2	6E5-11381-A2 Gasket 1	Buy now
3	6G5-11181-A2 Gasket, cylinder head 1	Buy now
4	6G5-11193-A0 Gasket, head cover 1	Buy now
5	688-12414-A1 Gasket, cover	Buy now
6	6G5-41112-A1 Gasket, exhaust inner cover	Buy now
7	6G5-41114-A0 Gasket, exhaust inner cover	Buy now
8	6G5-11382-A1 Gasket 2	Buy now
9	93102-40M14 Oil seal(61a)	Buy now
10	93211-04001 O-ring	Buy now
11	93102-35M13 Oil seal (6e5)	Buy now
12	93101-22M15 Oil seal (6e5)	Buy now
13	93210-74M35 O-ring (6e5)	Buy now
14	6E5-13621-A1 Gasket, valve seat	Buy now
15	6G5-13645-A2 Gasket, manifold 1	Buy now


Repair Kit 1



E1

Ref	Part	
16	6E5-14198-A2 Gasket	Buy now
17	6K7-14483-00 Gasket	Buy now
18	650-24431-A0 Gasket,fuel pump	Buy now
19	6G5-45113-A1 Gasket, upper casing	Buy now
20	64D-W0093-01 Carburetor repair kit	Buy now
21	64D-14384-01 Gasket, float chamber	Buy now
22	6E5-14546-00 Valve, needle	Buy now
23	6E5-14159-00 Clip	Buy now
24	6E5-14386-02 Pin, float	Buy now
25	61U-14959-00 Gasket	Buy now
26	64D-14394-00 Valve, drain	Buy now
27	6E5-14398-01 Gasket	Buy now
28	6E5-14328-01 Plug	Buy now
29	6E5-14979-00 Gasket	Buy now
30	6J8-14959-00 Gasket, drin screw	Buy now


Repair Kit 2



E3

Ref	Part	
1	6G5-W0001-C1 Lower unit gasket kit	Buy now
2	6G5-41134-A1 Gasket, exhaust manifold	Buy now
3	6G5-45114-A1 Gasket, upper casing	Buy now
4	6E5-41135-A0 Gasket, exhaust manifold	Buy now
5	90430-08020 Gasket	Buy now
6	6E5-45123-00 Gasket, muffler	Buy now
7	6E5-44365-00 Damper, water seal 1	Buy now
8	6E5-44366-00 Damper, water seal 2	Buy now
9	93210-58144 O-ring(47x)	Buy now
10	93106-09014 Oil seal	Buy now
11	93210-86M38 O-ring (6e5)	Buy now
12	93210-37160 O-ring (6g8)	Buy now
13	6E5-44315-A0 Gasket,water pump	Buy now
14	93101-28M16 Oil seal (6e5)	Buy now
15	93210-55M14 O-ring (70e)	Buy now

Repair Kit 2




64D0010-4240

Ref	Part	
16	93210-97M55 O-ring (6g5)	Buy now
17	93101-30M17 Oil seal (6e5)	Buy now
18	61A-W0078-A3 Water pump repair kit	Buy now
19	61A-44322-02 Insert, cartridge	Buy now
22	6E5-44352-01 Impeller	Buy now
23	6G5-44323-00 Outer plate, cartridge	Buy now
25	93606-12019 Pin, dowel (614)	Buy now
26	90119-08M14 Bolt, with washer	Buy now
27	90280-04M05 Key, woodruff (6e5)	Buy now
28	61A-W0078-2A Chrome pump kit	Buy now
29	6R3-44322-42 Insert, cartridge	Buy now
30	6G5-44323-40 Outer plate, cartridge	Buy now

E3


Starting Motor



D7

Ref	Part	
1	6N7-81800-10 Starting motor assembly	Buy now
2	6N7-81850-10 Armature assembly	Buy now
3	61A-81809-00 Washer kit	Buy now
4	61A-81824-00 Washer 2	Buy now
5	6N7-81810-00 Stator assembly	Buy now
6	6K7-8182G-10 Bush, terminal	Buy now
7	6N7-81840-00 Brush holder assembly	Buy now
8	6N7-81801-00 Brush set	Buy now
9	6N7-81813-00 Spring, brush	Buy now
10	6N7-81820-10 Rear bracket assembly	Buy now
11	6N7-81807-00 Gear assembly, starting motor	Buy now
12	6N7-81857-00 Pinion stopper set	Buy now
13	6N7-81830-00 Front bracket assembly	Buy now
14	6K7-81826-10 Bolt	Buy now
15	6E5-8182E-10 Washer, spring	Buy now


Starting Motor



D7

Ref	Part	
16	6E5-8182F-10 Washer,plain	Buy now
17	6E5-8182A-10 Nut	Buy now
18	6E5-8182K-10 Nut	Buy now
19	6R3-81822-00-94 Bracket, starting motor	Buy now
20	90119-08M76 Bolt, with washer(6e5)	Buy now
21	90119-08M77 Bolt, with washer(6e5)	Buy now
22	90119-08M57 Bolt, with washer	Buy now
23	92990-08600 Washer, plain (663)	Buy now
24	97095-08016 Bolt, hexagon deep recess	Buy now
25	92995-08600 Washer, plain (663)	Buy now

Steering Guide Attachment 1




67H0100-9290

C3

Ref	Part	
1	6E5-61350-02 Steering guide attachment kit AP "L150"—EXCEPT	Buy now
2	6E5-61351-01 Rod, steering link	Buy now
3	90387-10M61 Collar (6e5)	Buy now
4	90560-12M01 Spacer (6e5)	Buy now
5	6E5-61355-00 Bolt	Buy now
6	90185-09M01 Nut, nylon (663)	Buy now
7	90201-10M20 Washer, plate (663)	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now

Steering Guide Attachment 2




67H0100-0300

C4


Ref	Part	
1	6E5-61301-01 Tie bar assembly (l:600-800mm) AP	Buy now
2	6E5-61313-00 Adjuster	Buy now
3	6E5-61311-11 Tie bar	Buy now
4	6E5-61315-00 Tie bar, 2	Buy now
5	6E5-61303-00 Steering axle comp.	Buy now
6	90170-14M06 Nut (6e5)	Buy now
7	95380-14700 Nut (6e5)	Buy now
8	90201-10M76 Washer, plate (6e5)	Buy now
9	90101-09M70 Bolt (6e5)	Buy now
10	90170-09M05 Nut, hexagon (6e5)	Buy now
11	90185-09M01 Nut, nylon (663)	Buy now

Switch. Panel



Ref	Part	
1	6K1-82570-07 Panel switch assembly AP	Buy now
2	6K1-82571-01 Plate, panel switch	Buy now
3	6K1-82510-06 Main switch assembly	Buy now
4	703-82577-00 Cap, key	Buy now
5	6K1-82575-00 Engine stop switch assembly	Buy now
6	682-82556-00 Lanyard, stop switch	Buy now
7	6K1-83614-01 Bracket	Buy now
8	98980-05010 Screw, bind(6k1)	Buy now
23	92990-05100 Ybs67-5 washer, spring AP	Buy now
21	95380-05600 Nut, hexagon (663) AP	Buy now
11	688-83383-11 Buzzer	Buy now
12	6K1-85830-01 Control unit assembly	Buy now
13	98980-06020 Screw, bind (j17)	Buy now
14	95380-06600 Nut(661)	Buy now
15	92990-06100 Washer(6a1)	Buy now


Switch. Panel



D7

Ref	Part	
16	92990-06600 Washer, plain (646)	Buy now
17	6K1-81980-00 Diode assembly	Buy now
18	6K1-8258A-40 Extension, wire harness AP	Buy now
19	61B-8258A-01 Extension, wire harness AP EXCEPT	Buy now
20	90149-05M05 Screw(6k0) AP	Buy now
22	92990-05600 Washer, plain (646) AP	Buy now


Top Cowling



A4


Ref	Part	
2	6R3-42647-00 Holder, clamp band	Buy now
3	92990-06100 Washer(6a1)	Buy now
4	95380-06600 Nut(661)	Buy now
5	64D-42662-00 Damper	Buy now
6	64D-42814-00 Hook, clamp	Buy now
7	97095-06012 Bolt(gh1)	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	64D-42615-00 Seal	Buy now
11	90179-06M24 Nut(6j8)	Buy now
12	64C-42677-40 Graphic, front FOR SWS	Buy now
12	64C-42677-50 Graphic, front FOR CARIB,BRAZIL	Buy now
12	64C-42677-60 Graphic, front FOR USA	Buy now
12	64D-42677-40 Graphic, front FOR SWS	Buy now
13	64C-42677-80 Graphic, front FOR USA	Buy now
13	64D-42677-80 Graphic, front FOR SWS	Buy now

Top Cowling



Ref	Part	
14	64D-42677-50 Graphic, Front FOR SWS	Buy now
15	64C-42687-00 Emblem Rear FOR SWS	Buy now
15	64C-42687-30 Emblem, Rear FOR CARIB,BRAZIL	Buy now
15	64C-42687-40 Emblem, Rear FOR USA	Buy now
15	64D-42687-00 Emblem, rear FOR SWS	Buy now
16	64C-W0070-50 1- FOR USA	Buy now
16	64D-W0070-30 Graphic Set FOR CARIB,BRAZIL	Buy now
16	64D-W0070-50 1- FOR SWS	Buy now
17	64C-42681-30 Mark, cowling FOR CARIB,BRAZIL	Buy now
17	64C-42681-50 Mark, Cowling FOR USA	Buy now
17	64D-42681-40 Mark, cowling FOR SWS	Buy now
18	64C-42682-30 Mark, cowling FOR CARIB,BRAZIL	Buy now
18	64C-42682-50 Mark, cowling FOR USA	Buy now
18	64D-42682-40 Mark, cowling FOR SWS	Buy now
19	64D-4267A-30 Graphic, rear 2 FOR CARIB,BRAZIL	Buy now


Top Cowling



A4


Ref	Part	
19	64D-4267A-S0 Graphic, Rear 2 FOR SWS	Buy now
20	64D-42678-30 Graphic, Rear FOR CARIB,BRAZIL	Buy now

Upper Casing



Ref	Part	
1	6E5-45111-02-8D Casing, upper L	Buy now
1	6E5-45111-23-8D Casing, upper X	Buy now
2	6R3-42791-41 Mark 1	Buy now
3	6R3-42792-41 Mark	Buy now
4	6E5-45155-00 Cap	Buy now
5	6E5-42769-00 Seal, rubber	Buy now
6	97095-06010 Bolt	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	93608-12M05 Pin, dowel b (6e5)	Buy now
9	90119-08027 Bolt, with washer	Buy now
10	6G5-41137-02-94 Guide, exhaust FOR CARIB,BRAZIL	Buy now
10	6G5-41137-11-94 Guide, exhaust FLUSHING KIT	Buy now
11	6E5-42724-00 Grommet	Buy now
12	6G5-12581-00 Joint, hose	Buy now
14	6G5-45113-A1 Gasket, upper casing	Buy now


Upper Casing



F7

Ref	Part	
15	90119-08M79 Bolt, hexagon (fj1)	Buy now
16	97095-08045 Bolt, hexagon	Buy now
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	95380-08700 Nut(661)	Buy now
20	6H1-11372-00 Nipple, hose FLUSHING KIT	Buy now
22	6G5-45114-A1 Gasket, upper casing	Buy now
23	97095-08030 Bolt, hexagon (fj1)	Buy now
24	92995-08600 Washer, plain (663)	Buy now
25	64D-41132-00-5B Manifold, exhaust	Buy now
26	6G5-41134-A1 Gasket, exhaust manifold	Buy now
29	6E5-14711-01-5B Muffler 1	Buy now
30	6E5-14737-00 Damper, muffler	Buy now
31	90183-05M02 Nut, spring (6e5)	Buy now
32	6E5-45123-00 Gasket, muffler	Buy now
33	6E5-41135-A0 Gasket, exhaust manifold	Buy now

Upper Casing



Ref	Part	
36	6E5-45318-00 Bushing, drive shaft 3 X	Buy now
37	93420-36M01 Circlip (6a0) X	Buy now
39	64D-45123-00 Gasket, muffler X	Buy now
40	64D-45375-00 Damper, seal X	Buy now

F7

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.