



Yamaha 225GETO 1999

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM	3
BOTTOM COWLING	5
BRACKET 1	7
BRACKET 2	10
CONTROL	13
CRANKSHAFT.	17
CRANKSHAFT. PISTON	19
CYLINDER. CRANKCASE	20
CYLINDER. CRANKCASE 1	23
ELECTRICAL 1	24
ELECTRICAL 2	26
ELECTRICAL 3	28
ELECTRICAL 4	30
ELECTRICAL3	31
FUEL	33
FUEL INJECTION NOZZLE	37
FUEL INJECTION PUMP	39
GENERATOR	42
INTAKE	44
LOWER	46
LOWER CASING. DRIVE 1	48
LOWER CASING. DRIVE 2	51
METER	52
OIL PUMP	53
OIL TANK	55
POWER	58
POWER TRIM & TILT ASSY 1	60
POWER TRIM & TILT ASSY 2	61
POWERTRIM & TILT ASSY2	62
REMOTE	64
REMOTE CONTROL	67
REMOTE CONTROL ASSY	68
REPAIR KIT 2	70
REPAIRKIT1	72
STARTING	74
STEERING GUIDE	76
TOP COWLING	77
UPPER CASING	79

Bottom




D2

FL
REF
NC
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
FWD

Ref	Part	
2	9016905M00 Screw truss head tapping FLUSHING KIT	Buy now
4	9038613M88 Bush(6r3)	Buy now
6	9020106M30 Washer, plate (6a1)	Buy now
7	9010906M50 Bolt(61a)	Buy now
8	6R34282400 Base, clamp lever	Buy now
9	6R34281101 Stay	Buy now
10	6R34281600 Lever, clamp	Buy now
11	6R34285010 Wire, complete	Buy now
12	6R34281110 Stay	Buy now
13	61A4285001 Wire Complete	Buy now
14	61A4285020 Wire, complete	Buy now
15	6824411700 Bracket 1	Buy now
16	6 - i	Buy now
17	9709506016 Bolt, hexagon deep recess	Buy now
18	9299506600 Washer, plain (646)	Buy now


Bottom



D2


Ref	Part	
19	6N74282800 Plate, clamp	Buy now
20	6R34282800 Plate, clamp	Buy now
21	9709506010 Bolt	Buy now
23	6N74284100 Mark, Clamp	Buy now
24	66KUS8110 52 92995-06600	Buy now
24	6E54439100 Nipple, hose	Buy now
27	61A42738025B Plate, fitting	Buy now
55	GR31258000 Joint assembly FLUSHING KIT	Buy now
56	9044511M36 Hose (I700) FLUSHING KIT	Buy now
57	573 -	Buy now
57	9046511M10 Clamp FLUSHING KIT	Buy now

Bottom Cowling



Ref	Part	
28	64D427381058 Plate, Fitting	Buy now
29	9709506016 Bolt, hexagon deep recess	Buy now
30	9299506600 Washer, plain (646)	Buy now
31	9709506012 Bolt(gh1)	Buy now
32	9209506600 9-25	Buy now
33	9048022M15 Grommet (6e5)	Buy now
34	9038708M37 Coller (6e5)	Buy now
35	9020108M54 Washer, plate (6e5)	Buy now
36	9707508035 Bolt(70w)	Buy now
37	272610 -	Buy now
37	9011908M22 Bolt, with washer	Buy now
39	6H44272600 Grommet	Buy now
40	61A4271600 Rubber seal 1	Buy now
41	61A4271700 Rubber, seal 2	Buy now
42	61A4272700 Grommet	Buy now


Bottom Cowling



D3


Ref	Part	
45	<u>9709506030</u> Bolt(jf7)	Buy now
47	<u>9709506020</u> Bolt(7u8)	Buy now
49	<u>6E58259400</u> Clamp	Buy now
50	<u>BE58258800</u> Plate	Buy now
51	<u>66KUS8110</u> 52 92995-06600	Buy now
54	<u>6R31257200</u> Adapter FLUSHING KIT	Buy now

Bracket 1




Ref	Part	
2	6G54525101 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506030 Bolt(jf7)	Buy now
5	9299506100 Washer(6a1)	Buy now
7	9709506010 Bolt	Buy now
8	9299506600 Washer, plain (646)	Buy now
10	6E58214800 Wire, lead 5	Buy now
12	9299006600 Washer, plain (646)	Buy now
13	9370008M03 Nipple, Grease	Buy now
14	6634511900 Cap, grease nipple AP	Buy now
15	64E4313101 Bolt, clamp bracket	Buy now
16	97095-08020 Bolt, hexagon i	Buy now
17	9299508100 Ybs67-8 washer, spring	Buy now
18	9038625M31 Bushing (6e5)	Buy now
19	9020126M59 Washer, plate (6e5)	Buy now

Bracket 1




Ref	Part	
20	9018522M11 Nut, self-locking	Buy now
21	9046511170 Clamp i	Buy now
23	9046508M63 Clamp(61u)	Buy now
24	66KUS8120 25 663-45119-00	Buy now
24	9370006M03 Nipple, grease(6a1)	Buy now
26	66K82140 Wire, (Ead3 ~ ~ ~ ~ ~)	Buy now
27	6G54314400 Hook, spring	Buy now
29	6G54318102 Lever, tilt stop 1	Buy now
30	6G54318502 Lever, tilt stop 2	Buy now
31	9038610M16 Bushing (688)	Buy now
32	6G54314800 Collar, distance	Buy now
33	9024906M19 Pin(6e5)	Buy now
34	9038710M05 Collar(6e5)	Buy now
35	9169030020 Pin, spring (6h4)	Buy now
36	9050614M24 Spring, tension(6e5)	Buy now

Bracket 1




Ref	Part	
37	64E4312600 Pin, upper shock mount	Buy now
38	9038622M98 Bush(61u)	Buy now
39	9341022M11 Circlip(61u)	Buy now
40	9010112M05 Bolt (l:130mm)	Buy now
41	9020113M01 Washer, plate(6e5)	Buy now
42	9020112M05 Washe, plate(663)	Buy now
43	95380-12600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	64E4313900 Cam, trim sender (with screw)	Buy now
2	9778060525 Screw, tapping(65j)	Buy now
3	64E8367200 Trim sender	Buy now
4	9788506016 Screw, pan head(6b0)	Buy now
5	9046511M10 Clamp	Buy now
6	9321037MH7 O-ring(61u)	Buy now
7	9020240M47 Washer, plate(61a)	Buy now
8	B4E4337600 Bolt, Thrust Receiver	Buy now
9	9578010300 Nut, nylon (6e5)	Buy now
10	66K42510008D Steering bracket assembly	Buy now
11	9020138M60 Washer, plate (6e5)	Buy now
12	9038638M32 Bush(6e5)	Buy now
13	66K44551008D Housing, lower mount rubber	Buy now
14	9341037M04 Circlip (6e5)	Buy now
15	6E54457500 Damper, lower mount rubber	Buy now

Bracket 2



Ref	Part	
16	61A445550194 Mount damper, lower side	Buy now
17	9020232M19 Washer, plate (6e5)	Buy now
18	9020116M55 Washer, plate (6e5)	Buy now
19	9010914M80 Bolt	Buy now
20	9020115M58 Washer, plate (6e5)	Buy now
22	9299514600 Washer (6e5)	Buy now
23	66KUS8130 25 65N-43155-N0	Buy now
23	9010110M70 Bolt(6j9)	Buy now
27	61A445140094 Mount Damper, Upper Side	Buy now
28	9020116M01 Washer, plate(61a)	Buy now
29	9020228M46 Washer, plate(61a)	Buy now
30	9020128M01 Washer, plate(61a)	Buy now
31	9010914M10 Bolt	Buy now
32	9018514M00 Nut, self-locking(61a)	Buy now
34	61A445110094 Cover, upper mount	Buy now

Bracket 2



Ref	Part	
35	9709510045 Bolt(64d)	Buy now
36	9299510600 Washer, plate	Buy now

Control





FIG.
REF.
NO.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59

E6

Ref	Part	
?	65L4853100 Bracket Remote Control 1	Buy now
2	6634853800 Clamp, cable 1	Buy now
3	9169030010 Pin, spring (663)	Buy now
4	9709508020 Bolt, hexagon	Buy now
5	9299508100 Ybs67-8 washer, spring	Buy now
6	65L4163200 Lever, Magneto Control	Buy now
7	6E54834400 Cable end, remote control	Buy now
8	9046818008 Clip 620436610000	Buy now
9	9701308045 Bolt	Buy now
10	9299008200 Ybs66-8 washer, plain	Buy now
11	9020612M00 Washer, wave (676)	Buy now
12	9038708M16 Collar	Buy now
13	61A4123700 Joint, link	Buy now
14	9538005600 Nut, hexagon (663)	Buy now
15	6824123700 Joint, link 2	Buy now

Control




E6

FIGURE NO. 1

Ref	Part	
16	66K4121300 Cam, Accel	Buy now
17	9038706M29 Coller (6a0)	Buy now
18	9020610M04 Washer, wave (676)	Buy now
19	9011908M75 Bolt, With Washer	Buy now
20	61A44117008D Bracket	Buy now
21	9709506016 Bolt, hexagon deep recess	Buy now
22	9299506600 Washer, plain (646)	Buy now
23	61A44176008D Bracket	Buy now
24	650US7151 25 90386-12069 BUSH	Buy now
24	9038708M09 Collar(61a)	Buy now
24	9370006M01 Nipple, grease(61a)	Buy now
27	9709508035 Bolt(70w)	Buy now
28	9299508200 Ybs66-8 washer, plain	Buy now
29	9050820M31 Spring, torsion(61a)	Buy now
30	61A8259F00 Switch assembly	Buy now

Control



Ref	Part	
31	61A8258800 Plate	Buy now
32	9788504016 Screw, panhead (796)	Buy now
33	9299504100 Ybs67-4 washer, spring	Buy now
34	61A4412100 Lever, shift rod	Buy now
35	6E54412200 Bushing, shift rod lever	Buy now
36	9020208M20 Washer, plate (6e5)	Buy now
39	9020206007 Washer plate 626441880000	Buy now
40	61A44118008D Bracket	Buy now
41	9370006M03 Nipple, grease(6a1)	Buy now
42	61A4411600 Spring	Buy now
44	9299506100 Washer(6a1)	Buy now
46	66K4412000 Handle Gear Shift assembly	Buy now
47	9321009165 O-ring	Buy now
48	61A4411200 Stay, handle gear shift	Buy now
49	9701306012 Bolt(gh1)	Buy now

Control





Fig. Ref. No.

E6


Ref	Part	
50	9290306100 Washer(6a1)	Buy now
51	65JUS7151 52 95313-08600	Buy now
51	9290308600 Washer, plain (663)	Buy now
54	9149020012 Pin, cotter (648)	Buy now
57	61A4272400 Grommet	Buy now
58	61A4413800 Washer	Buy now
59	9788506008 Screw, pan head(6a3)	Buy now
65	9020100M02 Washer, Plate	Buy now
66	61A1531500 Seal, crankcase	Buy now

Crankshaft.




Ref	Part	
1	61A1141100 Crankshaft	Buy now
2	61A1144700 Seal, crank	Buy now
3	933119400 Bearing	Buy now
4	9310240M38 Oil seal(61a)	Buy now
5	9321054M54 O-ring (6g1)	Buy now
6	9330620901 Brg,r-b 6209rsh2-c2 85mm 412g	Buy now
7	9331095000 Bearing	Buy now
8	61A1153600 Gear, drive	Buy now
9	93306308U0 Bearing(61a)	Buy now
10	9341040M03 Circlip(n02)	Buy now
11	B1A1158601 Pulley, Crankshaft Balance i	Buy now
12	61A1155501 Nut, crankshaft 1	Buy now
13	9310422M07 Oil seal(61a)	Buy now
14	61A153590094 Housing, oil seal	Buy now
15	9310240M36 Oil seal	Buy now

Crankshaft.




Ref	Part	
16	93420-61M07 Circlip(61a)	Buy now
17	9321081MA6 O-ring(61a)	Buy now
18	9709506020 Bolt(7u8)	Buy now
19	9299506100 Washer(6a1)	Buy now
20	66X116310085 Piston (std)	Buy now
20	66X1163600 Piston (0.50mm o/s) AP	Buy now
21	66X116420085 Piston 2 (std)	Buy now
23	64D1160401 Piston ring set (0.25mm o/s) AP	Buy now
23	64D160301 Piston Ring Set std)"	Buy now

Crankshaft. Piston




Ref	Part	
22	<u>64D1160501</u> Piston ring set (0.50mm o/s) AP	Buy now
23	<u>61A1163302</u> Pin, piston	Buy now
24	<u>61A1163400</u> Clip, piston pin	Buy now
25	<u>66K1165000</u> Connecting rod kit	Buy now
26	<u>9010909M62</u> Bolt	Buy now
27	<u>93310326V4</u> Bearing, cylindrical(61a)	Buy now
28	<u>9020126M03</u> Washer, plate(61a)	Buy now
29	<u>61AJA7030</u> —E	Buy now
29	<u>93310840U1</u> Bearing	Buy now

Cylinder. Crankcase




Ref	Part	
4	6241448500 Pipe, joint	Buy now
5	9038406M07 Bush, bimetal formed(6r3)	Buy now
6	9038316M01 Bush, Formed	Buy now
7	6F61137200 Nipple, hose	Buy now
8	6501137200 Nipple, hose	Buy now
9	6E51137200 Nipple, hose	Buy now
11	9360812063 Pin, dowel (626)	Buy now
12	9044507M11 Hose (I770)	Buy now
13	9010510M62 Bolt, washer based(61a)	Buy now
14	9010510M75 Bolt, washer based(65j)	Buy now
16	9044507Mdd Hose (I200)	Buy now
17	9044507M40 Hose (I390)	Buy now
18	9044507TMAG Hose	Buy now
19	9044507TMA6 Hose	Buy now
21	61A1132500 Anode	Buy now

Cylinder. Crankcase




Ref	Part	
22	6H31132800 Grommet, anode	Buy now
23	6H3113270094 Cover, anode	Buy now
24	9701306016 Bolt, hexagon deep recess	Buy now
26	9034014M000 Plug, Straight Screw	Buy now
1	62J111110194 Head, cylinder 1	Buy now
2	61A11181A1 Gasket, cylinder head 1	Buy now
3	9011908M61 Bolt (6f5)	Buy now
4	9011908M35 Bolt, with washer a7	Buy now
5	61A11191008M Cover, Cylinder Head 1	Buy now
6	61A11193A1 Gasket, head cover 1	Buy now
7	9701306035 Bolt(3rv)	Buy now
8	9290306600 Washer, plain (646)	Buy now
9	6J81132500 Anode	Buy now
14	61A41113009M Outer cover, exhaust	Buy now
15	6502437800 Pipe, joint 2	Buy now

Cylinder. Crankcase




Ref	Part	
16	61A41112A0 Gasket, exhaust inner cover	Buy now
17	9701306025 Bolt(62y)	Buy now
19	9044509M25 Hose (I1500)	Buy now
20	9046708004 Clip, pipe 6162435600	Buy now
22	9050116M11 Spring, compression (688)	Buy now
23	9048020M05 Grommet (688)	Buy now
24	6G511382A1 Gasket 2	Buy now
24	85LNV7020 25 6G5-11372-00-58	Buy now

Cylinder. Crankcase 1



Ref	Part	
2	Fr Sn	Buy now
27	9043014115 Gasket (663)	Buy now
29	9701308020 Bolt(6td)	Buy now
31	61A1137100SM Cover	Buy now
32	9046508M07 Clamp (1e6)	Buy now
33	61A11381A0 Gasket 1	Buy now
40	9701306035 Bolt(3rv)	Buy now
41	9290306600 Washer, plain (646)	Buy now
42	6E5427610094 Stopper	Buy now
43	9701306020 Bolt(62y)	Buy now
43	di item_description	Buy now
44	0200308500 Washer, Plate	Buy now
45	6634453300 Damper, upper mount	Buy now

A5



Ref	Part	
1	61A856420194 Bracket	Buy now
1	COVER -	Buy now
2	9048009M12 Grommet (6a0)	Buy now
3	9038706M03 Collar (676)	Buy now
4	9011906M28 Bolt, With Washer	Buy now
5	9701306016 Bolt, hexagon deep recess	Buy now
7	66K8554000 C.d.i. Unit Assembly	Buy now
8	9701306025 Bolt(62y)	Buy now
9	9290306600 Washer, plain (646)	Buy now
10	61A8554800 Holder	Buy now
12	9709506016 Bolt, hexagon deep recess	Buy now
13	9299506600 Washer, plain (646)	Buy now
14	9701306014 Bolt(gj3)	Buy now
15	9200306600 Washer, Plate	Buy now
17	9046511M52 Clamp(6e7)	Buy now

Electrical 1





FIGURE NO. 1

B5


Ref	Part	
18	61A8553700 Cover	Buy now
19	9015906M03 Screw (6g5)	Buy now
20	61A8251900 Wire, Earth Lead	Buy now
21	6G08251900 Wire, earth lead	Buy now
22	9701306012 Bolt(gh1)	Buy now
23	65JUs7221 Rondelle, Grower	Buy now
23	9290306100 Washer(6a1)	Buy now

Electrical 2



Ref	Part	
1	61A8557000 Ignition coil assembly	Buy now
2	9701306020 Bolt(62y)	Buy now
3	9290306600 Washer, plain (646)	Buy now
4	6E38237020 Plug cap assembly	Buy now
5	65L8507000 Resistor assembly	Buy now
7	9299505600 Washer, plain (646)	Buy now
8	65L8191500 Plate, Regulator Fitting	Buy now
9	9011906M65 Bolt, with washer	Buy now
10	9038706M60 Collar (6h3)	Buy now
13	9015906M03 Screw (6g5)	Buy now
14	9046419M45 Clamp(65j)	Buy now
15	61A8253100 Wire, lead	Buy now
17	9290306100 Washer(6a1)	Buy now
18	66K8250000 Wire Harness assembly	Buy now
19	7058215100 Fuse (30a)	Buy now


Electrical 2



Front view diagram showing the front panel and internal wiring assembly. The diagram is labeled 'B6' in the bottom right corner.


Ref	Part	
20	9046510M14 Clamp	Buy now
21	9046508M33 Clamp(6t4) A A EE FT	Buy now
23	65L8259M00 Wire Harness assembly 2	Buy now
24	65L8250N00 26- 24	Buy now
24	66KUS8230 Pra	Buy now
27	9046513M18 Clamp	Buy now
28	61A8210500 Battery cable	Buy now
29	9046511M10 Clamp	Buy now
31	61A8256300 Trim & tilt switch assembly	Buy now
32	6E58258700 Gasket	Buy now
33	61A8361400 Bracket	Buy now
34	9709506012 Bolt(gh1)	Buy now
35	6H58192000 Terminal assembly	Buy now
36	66K8255300 Extension, Wire Lead	Buy now
37	6G58211910 Cover, lead wire	Buy now

Electrical 3




Ref	Part	
28	9046708004 Clip, pipe 6162435600	Buy now
29	65L8194200 Cover	Buy now
30	9016905M00 Screw truss head tapping	Buy now
31	61A8215401 Case	Buy now
32	61A8217600 Damper	Buy now
33	61 -	Buy now
34	65L8195000 Relay assembly	Buy now
35	9778060625 Screw, tapping(65j)	Buy now
36	65L8238000 Sensor, pressure	Buy now
38	65L.8588600 Thermosensor	Buy now
39	9017012M36 Nut	Buy now
40	9020112M34 Washer (692)	Buy now
41	65L8592A00 Sensor	Buy now
42	65L1139500 Holder	Buy now
43	90119-06M74 Bolt, with washer(63m)	Buy now

Electrical 3



Ref	Part	
44	9046513M18 Clamp	Buy now
45	6518563200 Case, Under	Buy now
46	65L1135400 Gasket	Buy now
47	65L1131N00 Gasket, holder	Buy now
48	B5L1139600 Gasket, Holder	Buy now
49	65L1135300 Joint	Buy now
50	65L1135700 Seal, cylinder	Buy now
51	66KUS8240 52 92995-06100 WASHER, SPRING	Buy now
51	9709506030 Bolt(jf7)	Buy now
54	66K8251900 Wire, Earth Lead	Buy now




65JUS-7250


C3

FIGURE NO.
1
2
3
4
5
6
7
8
9
10

Ref	Part	
1	61A8578000 Sensor, knock	Buy now
2	61A8579000 Thermosensor assembly	Buy now
3	9299010600 Washer, plate	Buy now
4	9046412M48 Clamp	Buy now
6	9788505012 Screw,pan head (646)	Buy now
7	9046409M47 Clamp(65j)	Buy now
8	61A8256000 Thermo switch assembly	Buy now
9	61A8252U00 Cover	Buy now
10	9708006012 Bolt(gh1)	Buy now




Ref	Part	
1	65L8194800 Bracket	Buy now
2	6244254200 Collar	Buy now
3	6A08231700 Damper, ignition coil	Buy now
4	9011906M65 Bolt, with washer	Buy now
5	9701306014 Bolt(gj3)	Buy now
6	61A8714900 Connector	Buy now
7	61A8195000 Relay assembly	Buy now
8	9701306030 Bolt	Buy now
9	9290306600 Washer, plain (646)	Buy now
10	9046418M46 Clamp(65j)	Buy now
11	61A8194910 Wire, lead	Buy now
12	61A8194900 Wire, lead	Buy now
13	61A8194100 Starter relay assembly	Buy now
13	61A8195200 Holder, relay	Buy now
13	61A8196001 Rectifier & regulator assembly	Buy now



C1


Ref	Part	
13	61A8215000 Fuse holder assembly	Buy now
13	61A8215100 Fuse(12v-80a)	Buy now
13	61A8215300 Stay, fuse holder	Buy now
13	66KUS8240 52 92995-06100 BOLT	Buy now
13	6G58211900 Cover, lead wire	Buy now
13	9044509224 Hose (I1500)	Buy now
13	9701306025 Bolt(62y)	Buy now
13	9778050612 Screw, tapping(61a)	Buy now



B6

Ref	Part	
28	66K1397100 Pipe, fuel 1	Buy now
29	65L2438700 Clip	Buy now
30	65L1397200 Pipe, Fuel 2	Buy now
31	6512438700 Clip	Buy now
32	65L4121700 Rod, accel. lever	Buy now
1	9046511M10 Clamp	Buy now
2	9044513M17 Hose(l2700)	Buy now
3	6R32437700 Pipe, joint 3	Buy now
4	9046413M34 Clamp(6r3)	Buy now
5	61A2431300 Pipe 3	Buy now
8	BR52440800 Fuel Feed assembly	Buy now
9	61A2431100 Pipe, fuel 1	Buy now
12	65L2456000 Filter assembly	Buy now
17	65L2456300 Element, filter	Buy now
18	61A2446900 Float, water level	Buy now

Fuel



B6

Ref	Part	
19	<u>65L2455800</u> Holder, filter	Buy now
20	<u>9759506416</u> Bolt, with washer(62x)	Buy now
21	<u>9020106068</u> Washer,plate (6k8)	Buy now
22	<u>61A2456600</u> Bracket, filter	Buy now
23	<u>9759506514</u> Bolt(gj3)	Buy now
24	<u>66KNV9090</u> 25 92995-06600 WASHER	Buy now
24	<u>9709506016</u> Bolt, hexagon deep recess	Buy now
28	<u>6G52431701</u> Pipe 7	Buy now
30	<u>6E52437800</u> Pipe, joint 3	Buy now
31	<u>6E52431500</u> Pipe 5	Buy now
33	<u>6G52431500</u> Pipe 5	Buy now
36	<u>6E52441008</u> Fuel Pump assembly.	Buy now
37	<u>9850305035</u> Screw, pan head (686)	Buy now
38	<u>9290305600</u> Washer, plain (646) EE IT I A a	Buy now
39	<u>6E52441300</u> Body 2	Buy now




FIGURE
REF. NO.
28
29
30
31
32
33

B6

Ref	Part	
40	6482442400 Seat,spring	Buy now
40	65024431A0 Gasket,fuel pump	Buy now
40	6A01432500 Screw, pan head	Buy now
40	6A02442101 Valve, check	Buy now
40	6E52441100 Diaphragm	Buy now
40	6E52442300 Spring, diaphragm	Buy now
40	6E52443500 Gasket, body 2	Buy now
40	6E52447100 Diaphragm	Buy now
40	9709508050 Bolt (62k)	Buy now
40	B86KNV9090 92995-06600 WASHER	Buy now
40	BE52441202 Body 1	Buy now
40	BES52443402 Gasket, Body	Buy now
55	6G52431610 Pipe 6	Buy now
56	9044513M14 Hose (l90)	Buy now
59	6E52431300 Pipe 3	Buy now

Fuel





FIGURE NO.
28
29
30
31
32
33

B6


Ref	Part	
61	6E98355770 Tube	Buy now
62	65L8355700 Tube	Buy now
63	6YK2430740 Fuel pipe comp. 2	Buy now

Fuel Injection Nozzle



Ref	Part	
1	66K1375100 Body, Throttle 1	Buy now
2	65L1452700 Plate	Buy now
3	65L1456500 Screw	Buy now
4	65L1433400 Spring, air adjusting	Buy now
5	65L1452300 Screw, stop	Buy now
7	9020105552 Washer, plate(65j)	Buy now
8	65L1457800 Collar	Buy now
9	65L1393800 Pipe	Buy now
10	65L1389800 Plate 4	Buy now
13	65L1399500 Washer	Buy now
14	65L1376100 Injector assembly	Buy now
15	65L1376900 O-ring	Buy now
17	65L1376600 Rubber, injector	Buy now
18	61A8588500 Throttle sensor assembly	Buy now
19	6K78588600 Bracket	Buy now


Fuel Injection Nozzle



B5

Ref	Part	
20	9798505212 Screw, with washer(6g7)	Buy now
22	9048010M23 Grommet(6k7)	Buy now
23	65L1459600 Washer	Buy now
24	66XUS8051 25 65L-14573-00 LEVER	Buy now
24	9798505330 Screw, with washer(61b)	Buy now
24	B5L1457900 Spring	Buy now
27	65L1399600 Insert	Buy now

Fuel Injection Pump



Ref	Part	
1	66K1418200 Cover, float chamber	Buy now
1	66K1498000 Body, float chamber	Buy now
3	65L1454600 Valve, needle	Buy now
4	66K1498500 Float	Buy now
5	66K1454800 Pin, Float Arm	Buy now
6	66K1498400 Gasket, float chamber	Buy now
7	65L1412500 Screw	Buy now
8	66K1390600 Regulator, pressure	Buy now
12	66K1416300 Spacer	Buy now
13	65L1390500 Filter comp	Buy now
14	65L1496600 Cap	Buy now
15	65L2448600 O-ring	Buy now
17	66K1390700 Fuel pump comp.	Buy now
18	65L1422700 Washer	Buy now
22	66K1384400 Plate 2	Buy now

Fuel Injection Pump





FIGURE
REF. NO.
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

B3

Ref	Part	
23	66K1391500 Filter	Buy now
24	65L1416A00 O-ring	Buy now
24	66KNV9040 25 66K-14271-00 INSULATOR	Buy now
28	65L8182E00 Washer	Buy now
29	65L8182F00 Washer	Buy now
30	66K1384300 Plate 1	Buy now
31	65L1414700 O-ring	Buy now
32	65L1427400 Connector	Buy now
34	B6K2448900 O-Ring	Buy now
35	65L1439700 O-ring	Buy now
36	65L1499200 Screw, drain	Buy now
39	65L2439700 Collar	Buy now
40	65L2457600 Washer	Buy now
41	66K2457900 Washer 2	Buy now
42	65L2459200 Bolt	Buy now

Fuel Injection Pump




66KNV-9040

Ref	Part	
44	65L8250700 Wire, Lead	Buy now
45	66K1354200 Hose, vacuum sensing 1	Buy now
46	66K1354400 Hose, Vacuum Sensing 2	Buy now
47	66K~1353200 Hose, vacuum sensing 3	Buy now
48	65L2446100 Pipe.joint 4	Buy now
49	66K1353300 Hose, vacuum sensing 4	Buy now
50	66K1389800 Holder	Buy now
51	65L1456500 Screw	Buy now
87	65L1499700 Seal	Buy now


B3

Generator



Ref	Part	
1	61A8555001 Rotor assembly	Buy now
2	61A8551002 Stator assembly	Buy now
3	61A8558000 Coil, pulser	Buy now
4	61A8372100 Cover	Buy now
5	61A8133701 Cover, flywheel	Buy now
5	65L8133800 Clamp, Lead	Buy now
5	6638231701 Damper, ignition coil	Buy now
5	6E58133200 Plate, timing	Buy now
5	9017024M22 Nut(61a)	Buy now
5	9020126M02 Washer, Plate	Buy now
5	9028005015 Key, woodruff	Buy now
5	9209505600 Washer	Buy now
5	9290306600 Washer, plain (646)	Buy now
5	9299505100 Ybs67-5 washer, spring	Buy now
5	9701306025 Bolt(62y)	Buy now

Generator




65JUS-7200

FIGURE
REF.
NO.
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22

B3

Ref	Part	
5	9701306035 Bolt(3rv)	Buy now
5	9788505030 Ybs86-530 screw,panhead	Buy now
5	9788506010 Screw pan head	Buy now

Intake




B7

Front View
Right View
Number

Ref	Part	
1	65L1361001 Reed valve assembly	Buy now
2	65JW000401 Reed set	Buy now
3	61A13621A0 Gasket, valve seat	Buy now
4	9788005016 Screw, pan head(6b0)	Buy now
5	9299005600 Washer, plain (646)	Buy now
7	6F61137200 Nipple, hose	Buy now
8	9044507M03 Hose (I200)	Buy now
9	9701306030 Bolt	Buy now
10	9290306600 Washer, plain (646) PLATE 2	Buy now
12	65L1364500 Gasket, manifold 1	Buy now
13	9701306060 Bolt, hexagon	Buy now
15	9567006655 Bolt, Stud	Buy now
16	9017906M24 Nut(6j8)	Buy now
17	65L1444000 Silencer assembly, intake	Buy now
18	65L1448300 Gasket	Buy now


Intake



B7

Ref	Part	
19	9044507M44 Hose (I390)	Buy now
20	9015906M16 Screw, with washer(61a)	Buy now


Lower



A7

Ref	Part	
42	9299508600 Washer, plain (663)	Buy now
44	61A4555103 Pinion	Buy now
46	9017016M19 Nut(6t5)	Buy now
47	6 -	Buy now
48	61A4561102 Shaft, propeller	Buy now
49	B1A4564101 Shifter	Buy now
50	61A4563401 Slide, shift	Buy now
51	61A4563200 Pin, cross	Buy now
53	61A4563300 Ring, cross pin	Buy now
54	6H14566800 Shaft, free 1	Buy now
55	61A4563500 Plunger, shift	Buy now
56	0020102M00 Washer, Plate	Buy now
58	00S0110M77 Spring, Compression	Buy now
59	9350104011 Ball	Buy now
60	61A453320294 Housing, bearing	Buy now


Lower



A7


Ref	Part	
61	9330621000 Bearing	Buy now
63	61A455770030 Shim (t:0.30mm)	Buy now
63	9020131M00 Washer, plate(61a)	Buy now

Lower Casing. Drive 1




Ref	Part	
3	93311832v2 Bearing	Buy now
4	93332000W1 Bearing(61a)	Buy now
5	1 6YF-82580-C0	Buy now
5	61A455670012 Shim (t:0.12mm) UR	Buy now
5	61A455670015 Shim (t:0.15mm) UR	Buy now
5	61A455670018 Shim (t:0.18mm) UR	Buy now
5	61A455670030 Shim (t:0.30mm) UR	Buy now
6	6634436600 Damper, water seal 2	Buy now
7	9034008M04 Plug, straight screw	Buy now
8	6884534100 Plug, drain	Buy now
11	61A4532101 Plate	Buy now
12	9321064488 93210-64488	Buy now
13	9310609014 Oil seal	Buy now
14	9011906Mi0 Bolt, With Washer	Buy now
15	61A4415001 Shift cam assembly	Buy now

Lower Casing. Drive 1




Ref	Part	
16	9343008006 Circlip(2r6)	Buy now
20	9321086M38 O-ring (6e5)	Buy now
20	9020622M19 Washer, wave(61a)	Buy now
21	9321037160 O-ring (6g8)	Buy now
25	9028004M05 Key, Woodruff	Buy now
26	61A4553800 Spacer, 1	Buy now
27	61A4552700 Collar, drive shaft	Buy now
28	9020122M01 Washer, Plate	Buy now
30	6G54432300 Outer plate, cartridge	Buy now
31	6E544315A0 Gasket,water pump i	Buy now
32	9360612019 Pin, dowel (614)	Buy now
33	9011908M14 Bolt, with washer	Buy now
34	61A453310094 Housing, bearing	Buy now
35	9310128M16 Oil seal (6e5)	Buy now
36	0331733002 Bearing	Buy now

Lower Casing. Drive 1



Ref	Part	
37	61A455670010 Shim (t:0.10mm) UR	Buy now
37	61A455870012 Shim (t:0.12mm) UR	Buy now
37	61A455870040 Shim (t:0.40mm) UR	Buy now
37	61A455870050 Shim (t:0.50mm) UR	Buy now
38	93341930U9 Bearing	Buy now
41	9709508025 Bolt (62g)	Buy now
65	93317330U5 Bearing	Buy now
66	9310130M17 Oil seal (6e5)	Buy now
67	9010508M48 Bolt, Flange	Buy now
67	9321104384 O-ring (705)	Buy now
69	9370009M00 Nipple, grease(6t4)	Buy now
70	61A453610158 Cap, Lower Casing	Buy now
71	9759508520 Bolt(6td)	Buy now


Lower Casing. Drive 2



Ref	Part	
1	61A4521400 Cover, water inlet	Buy now
2	61A4521500 Cover, water inlet	Buy now
3	9014205M04 Screw, countersunk	Buy now
4	9018505002 Nut nylon (sus)(ex4)	Buy now
5	61A4537500 Damper, seal	Buy now
6	9360812M05 Pin, dowel b (6e5)	Buy now
7	9010110M70 Bolt(6j9)	Buy now
8	9011910MA2 Bolt, with washer	Buy now
14	6E54598701 Spacer 1	Buy now
17	9017118M04 Nut, castle (6e5)	Buy now
18	9149040030 Pin, cotter (663)	Buy now
19	66K45970B0 Propeller (3X14-1/2"x27") AP	Buy now

B2


Meter



65NNV-9270

Ref	Part	
1	6Y583500T1 Digital tachometer assembly	Buy now
2	9E45004433 Housing, connector (m-4-w)	Buy now
3	6Y583500S4 Meter assembly	Buy now
4	6Y583670S4 29- 4	Buy now
5	6Y58356731 Tube	Buy now
7	9046511M10 Clamp	Buy now
8	6Y583553M0 Wire, lead (l=2.5m)	Buy now
9	6Y58211700 Wire, lead	Buy now
10	6R38252170 Wire, lead (for tacho., 7m)	Buy now
12	6Y58355700 Tube (8m)	Buy now

Oil Pump




 FWD
65LNV-7070

C1

Ref	Part	
1	65L1320000 Oil injection pump assembly	Buy now
2	9321019M82 O-ring(6j8)	Buy now
3	6A31347100 Plug, Drain	Buy now
4	6121347500 Gasket	Buy now
5	9010906M40 Bolt(6h0)	Buy now
6	61A1341600 Pipe Oil 1	Buy now
7	9048511M10 Clamp	Buy now
8	65L1318300 Valve, check	Buy now
9	65L2437800 Pipe, joint 4	Buy now
10	9044509220 Hose (I1500)	Buy now
11	9044609M69 Hose(65j)	Buy now
12	9046511M10 Clamp	Buy now
13	9044507M02 Hose (I200)	Buy now
14	9044507M03 Hose (I200)	Buy now
15	9046807M02 Clip (6e5)	Buy now

Oil Pump




C1

Fig. 22-100 Oil Pump Assembly


Ref	Part	
17	9020109Mo1 'Washer, Plate	Buy now
18	61A1311700 Collar, distance	Buy now
19	9321018MA9 O-ring(61a)	Buy now
20	2410 Rod, Link	Buy now
20	6R54123700 Joint, link	Buy now
22	9538005600 Nut, hexagon (663)	Buy now
23	6H14123700 Joint, link	Buy now
24	65LNV7070 - 90202-05088 WASHER, PLATE	Buy now
24	9149012012 Pin, cotter (6g8)	Buy now

Oil Tank




Ref	Part	
1	61A2175000 Oil tank assembly	Buy now
2	61A8573000 Oil level gauge assembly	Buy now
3	61A1341100 Strainer, oil	Buy now
4	6E51341400 Gasket, strainer cover	Buy now
5	9044505M07 Hose (l700)	Buy now
6	6A08231700 Damper, ignition coil	Buy now
7	6244254200 Collar	Buy now
8	9011906M65 Bolt, with washer	Buy now
9	6R38259E00 Switch assembly	Buy now
10	6E52437900 Pipe, joint 4	Buy now
12	9046511M10 Clamp	Buy now
13	6E52432300 Pipe 12	Buy now
16	90464-13M34 Clamp(6r3)	Buy now
17	61A2170803 Sub oil tank assembly. <i>AP</i>	Buy now
18	6E52173302 Sub tank, oil (10.5l)	Buy now

Oil Tank




Ref	Part	
19	6E52177003 Oil tank cap assembly	Buy now
20	6E52432200 Pipe 11	Buy now
22	6462425102 Strainer 1	Buy now
23	6E52431901 Pipe, oil	Buy now
25	65JUS7081 leux	Buy now
25	6E58190001 Oil feed pump assembly	Buy now
25	6E58192200 Grommet I EE	Buy now
27	6E52432101 Pipe 10	Buy now
29	9044511M26 Hose (I8000)	Buy now
31	6E58572004 Oil Level Gauge assembly	Buy now
32	6R38572180 Wire, lead	Buy now
33	of item_description AP	Buy now
35	BE52174600 Damper AP	Buy now
36	9708006100 Bolt, hexagon AP	Buy now
37	9299006600 Washer, plain (646) AP	Buy now

Oil Tank



Ref	Part	
38	<u>9531</u> - AP	<u>Buy now</u>
39	<u>9046513M1</u> Clamp AP	<u>Buy now</u>
40	<u>656W281002</u> Tool kit	<u>Buy now</u>

Power



Ref	Part	
3	64E4388J00 Plug 2	Buy now
4	9321010M74 O-ring	Buy now
5	64E4381700 Filter 2 Try	Buy now
6	64E4381000 Tilt piston sub assembly	Buy now
7	64E4389800 Seal, dust 2	Buy now
8	B4E4386700 O-Ring	Buy now
9	64E4386600 O-ring 6	Buy now
10	6ES4386200 O-Ring	Buy now
11	64E4388300 O-ring 10	Buy now
12	6E54387200 Ring, back-up 2	Buy now
13	6E54381402 Piston, free	Buy now
14	382000 -	Buy now
14	6E54386200 O-ring 2	Buy now
16	64E4382100 Screw, trim cylinder end	Buy now
17	64E4382200 Seal, trim dust	Buy now

Power





FIG.
REF.
NO.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
26

Ref	Part	
18	64E4384J00 Seal, trim down	Buy now
19	6G54386400 O-ring 4	Buy now
21	6E54387401 Ring, back-up 4	Buy now
26	64E4386900 O-ring 9	Buy now


Power Trim & Tilt Assy 1

Ref	Part	
31	64E4381800 Lower shock mount pin set MOUNT 1	Buy now
32	9038622M98 Bush(61u)	Buy now



E3


Power Trim & Tilt Assy 2



E5

Ref	Part	
28	6H14386K10 Spring, brush	Buy now
29	64E4389100 Brush 1	Buy now
30	9850704010 Screw, pan head(6g8)	Buy now
31	64E4389200 Breaker comp. (brush 2)	Buy now
32	6G54386500 O-ring	Buy now
34	64E4384310 Screw valve lock	Buy now


Powertrim & Tilt Assy2



Front Right
Front Left
Rear Right
Rear Left


Ref	Part	
1	64E4388E00 Bolt ,screw (l:14mm)	Buy now
2	G4E4383100 Connector, Shaft	Buy now
3	64E4386800 O-ring 8	Buy now
4	G4E4383000 Gear Pump assembly	Buy now
5	72X4385800 Ball	Buy now
6	64E43843-00 Screw, valve lock	Buy now
7	64E4384100 Piston, shuttle	Buy now
8	64E4380200 Valve sub assembly	Buy now
9	6E54389600 O-ring	Buy now
10	6G54386300 O-ring 3	Buy now
11	64E4385100 Seat, Relief Valve {	Buy now
12	64E4385800 Ball	Buy now
13	64E4385900 Pin, Valve Support	Buy now
14	64E4385500 Spring, up relief	Buy now
23	64DJA8140 25 Gme-4To-10	Buy now

Powertrim & Tilt Assy2



E4


Ref	Part	
23	64E4386200 Ring set	Buy now
27	64E4388000 Motor assembly	Buy now



F5


Ref	Part	
28	7034822300 Lock, neutral	Buy now
29	7034822500 Cover	Buy now
30	7034821900 Cover, lead	Buy now
31	7034828100 Screw, flat head	Buy now
32	7034628200 Screw	Buy now
33	9709508030 Bolt, hexagon (fj1)	Buy now
34	9299008600 Washer, plain (663)	Buy now
35	9858004010 Screw, pan head (e56) SINGLE	Buy now
36	9858004006 Screw, pan head (7h3)	Buy now
37	9856005010 Screw, Pan Head	Buy now
39	7034829110 Screw	Buy now
40	9538006600 Nut(661)	Buy now
41	7034820310 Remote control assembly (7p) SINGLE	Buy now
44	7024821700 Mark	Buy now
45	7038251011 Main switch assembly	Buy now

Remote



Ref	Part	
46	7038253100 Wire, lead	Buy now
47	6888257501 Engine stop switch assembly	Buy now
49	6888258A20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	7038254000 Neutral switch assembly	Buy now
51	70383383A0 Buzzer	Buy now
52	7034828400 Grommet	Buy now
52	00KNV9190 'Passe-Fil	Buy now
53	7038250100 © C Band	Buy now
54	7038250200 19- 54	Buy now
55	7038256301 Trim & tilt switch assembly	Buy now
56	7034822100 Grip	Buy now
57	7034815200 Knob, free accel	Buy now
58	7034821200 Rear housing	Buy now
59	7034821300 Back, panel	Buy now
61	7034821101 Housing,1	Buy now


Remote



F5

Ref	Part	
62	7034823200 Drive gear	Buy now
63	9343006024 Circlip (701)	Buy now
64	7038254200 Cap	Buy now

Remote Control




66MNV-8200

F3


Ref	Part	
1	70348205A2 Remote control assembly (10p, ptt)	Buy now
2	7014832050 Cable, Remote Control L=15F UR	Buy now
2	7014832060 Cable, Remote Control L=16F UR	Buy now
2	7014832080 Cable, Remote Control L=17F UR	Buy now
2	7014835000 Cable, Remote Control L=21F UR	Buy now

Remote Control Assy



Ref	Part	
1	70348205A2 Remote control assembly (10p, ptt)	Buy now
2	7034826101 Arm, throttle	Buy now
3	7034815300 Shaft, free accel.	Buy now
4	7034823500 Bushing	Buy now
5	7034826800 Spacer 3	Buy now
6	7034826400 Throttle, friction	Buy now
7	9538005600 Nut, hexagon (663)	Buy now
8	9738005025 Bolt	Buy now
9	7034826500 Shaft Friction	Buy now
10	9343006024 Circlip (701)	Buy now
12	7034825200 Roller, cam	Buy now
13	7014824800 Roller, free accel	Buy now
14	7034819800 Washer, wave 3	Buy now
21	7034824300 Bushing 3 <i>i</i>	Buy now
16	7034823600 Bushing	Buy now


Remote Control Assy



F4


Ref	Part	
17	7034818900 Retainer	Buy now
19	7034834501 Cable end, remote control 2	Buy now
20	7034835800 Anchor, cable	Buy now
22	7034823800 Spring, detent	Buy now
23	7034824600 Spacer 1	Buy now
24	66KNV9190 Sn	Buy now
24	7034822600 Plate, stopper I	Buy now
24	7034822700 Spring, neutral lock	Buy now
27	7034822200 Grip, control lever SINGLE	Buy now

Repair Kit 2




Ref	Part	
1	B6KW000120 Lower Unit Gasket Kit	Buy now
2	61A41134A0 Gasket, exhaust manifold	Buy now
4	9043008020 Gasket	Buy now
5	66K4512300 Gasket, muffler	Buy now
6	6E54436500 Damper, water seal 1	Buy now
8	9321064488 93210-64488	Buy now
9	61A4432201 Insert, cartridge	Buy now
9	65JUS7270 Boi EC RONDELLE	Buy now
9	65L.W0078A0 Water pump repair kit	Buy now
9	6E544315A0 Gasket,water pump	Buy now
9	6G54432300 Outer plate, cartridge	Buy now
9	9011908M140 Bolt, with washer	Buy now
9	9310128M16 Oil seal (6e5)	Buy now
9	9310609014 Oil seal	Buy now
9	9321055M14 O-ring (70e)	Buy now


Repair Kit 2



Ref	Part	
9	9321086M38 O-ring (6e5)	Buy now
9	9321104384 O-ring (705)	Buy now
9	9360612019 Pin, dowel (614)	Buy now




Ref	Part	
1	65LW000100 Power head gasket kit	Buy now
2	61A11381A0 Gasket 1	Buy now
4	61A11183A1 (Gasket, Head Cover 1)	Buy now
5	61A12414A0 Gasket, cover	Buy now
6	GA , EXHAUST OVER	Buy now
7	6G511382A1 Gasket 2	Buy now
8	9310240M38 Oil seal(61a)	Buy now
9	9321054M54 O-ring (6g1)	Buy now
10	9310422M07 Oil seal(61a)	Buy now
11	9310240M36 Oil seal	Buy now
12	9321081MA6 O-ring(61a)	Buy now
13	65L1364500 Gasket, manifold 1	Buy now
14	61A45113A0 Gasket, upper casing	Buy now
15	65L1364600 Gasket, manifold 2	Buy now
16	65024431A0 Gasket,fuel pump	Buy now



Ref	Part	
17	61A13621A0 Gasket, valve seat	Buy now
18	65JUS7260 So	Buy now
18	65L1448300 Gasket	Buy now

C5

Starting



B4

FIGURE
REF.
NO.
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25

Ref	Part	
1	61A8180001 Starting motor assembly	Buy now
2	61A8185001 Armature assembly	Buy now
3	61A8182400 Washer 2	Buy now
4	61A8180900 Washer kit	Buy now
5	6K78181010 Stator assembly	Buy now
6	6K78180110 Brush Set	Buy now
7	61A8184000 Brush holder assembly	Buy now
8	6E58181310 Spring Brush	Buy now
9	61A8182000 Rear Bracket assembly	Buy now
10	61A8180700 Gear assembly Starting Motor	Buy now
12	61A8183000 Front Bracket assembly	Buy now
13	6K78182610 Bolt	Buy now
14	6E58182E10 Washer, spring	Buy now
17	6E58182K10 Nut	Buy now
18	61A818220094 Bracket, starting motor	Buy now

Starting




FIGURE
REF.
NO.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25

B4

Ref	Part	
19	9011908M76 Bolt, with washer(6e5)	Buy now
20	9011908M77 Bolt, with washer(6e5)	Buy now
22	9299508600 Washer, plain (663)	Buy now
23	9709506012 Bolt(gh1)	Buy now
24	9299506600 Washer, plain (646)	Buy now
25	61AJA4200 Bride	Buy now
25	9046508M07 Clamp (1e6)	Buy now

Steering Guide





Fig.
Ref.
No.

65NNV-9160

F2

Ref	Part	
1	6E56135002 Steering guide attachment kit AP	Buy now
2	6E56135101 Rod, steering link	Buy now
3	9038710M61 Collar (6e5)	Buy now
4	9056012M01 Spacer (6e5)	Buy now
5	6E56135500 Bolt	Buy now
7	9020110M20 Washer, plate (663)	Buy now
8	6E54314500 Cap, clamp bracket	Buy now
9	9321016275 O-ring	Buy now

Top Cowling



C7

FIGURE
REF. NO.
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30

Ref	Part	
2	BR34264700 Holder, Clamp Band	Buy now
3	9299006100 Washer(6a1)	Buy now
4	9538006600 Nut(661)	Buy now
5	6R34266200 Damper	Buy now
6	6R34281400 Hook, clamp	Buy now
7	9709506012 Bolt(gh1)	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	61A4261902 Damper, Form	Buy now
10	61A4262702 Damper Form	Buy now
11	61A4261501 Seal	Buy now
12	66K4266200 Damper	Buy now
13	66K4261300NA Molding, Air Duct	Buy now
14	9038504M05S Bush	Buy now
15	9017906M24 Nut(6j8)	Buy now
16	61A4262600 Louver, 1	Buy now

Top Cowling





FIGURE
REF. NO.
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30

C7


Ref	Part	
17	66K4263600NA Louver 2	Buy now
18	9299005200 Ybs66-5 washer, plain	Buy now
19	9778050616 Screw, pan head tapping (ak5)	Buy now
20	66K42686NO Emblem, Front	Buy now
22	66KWO0070NO Graphic Set	Buy now
23	66K42681NO Mark, Cowling	Buy now
24	66K42682NO Mark, Cowling	Buy now
24	66KUS8101 25 66K-4267A-No	Buy now
26	B6K42883N1 Mark, Cowling	Buy now
27	66K42684N1 Mark, Cowling	Buy now
28	9299004600 Washer, plain (646)	Buy now
29	9778040520 Ybs83-420 screw,panh,tapping	Buy now
30	66K4262800 Seal	Buy now

Upper Casing



Ref	Part	
1	66K45111008D Casing, Upper	Buy now
2	6N94279140 Mark 1	Buy now
3	6N94279240 Mark 2	Buy now
4	61A4515500 Cap	Buy now
6	9360812M05 Pin, dowel b (6e5)	Buy now
6	9759506510 Bolt, hexagon w/w deep recess	Buy now
7	9011908M78 Bolt, with washer	Buy now
8	66K4537800 Nipple, hose	Buy now
9	9011906M17 Bolt, with washer	Buy now
10	9360612019 Pin, dowel (614)	Buy now
12	6E58355800 End, nipple	Buy now
13	9046511M10 Clamp	Buy now
14	61A45114A0 Gasket, upper casing	Buy now
15	61A411310058 Manifold, Ext. 1	Buy now
15	61A411320158 Manifold, Exhaust	Buy now

Upper Casing



F7

Ref	Part	
15	61A41134A0 Gasket, exhaust manifold	Buy now
15	61A411371194 Guide, Exhaust FLUSHING KIT	Buy now
15	61A45113A0 Gasket, upper casing	Buy now
15	66KUS8171 2 66K-14711-00-58 MUFFLER 1	Buy now
15	9011908M79 Bolt, hexagon (fj1)	Buy now
15	9759508535 Bolt, hexagon w/w deep recess	Buy now
15	9759508550 Bolt, With Washer	Buy now
26	4512300 Gasket, Muffler	Buy now
27	9011908M74 Bolt, with washer(61a)	Buy now
28	6H11137200 Nipple, hose FLUSHING KIT	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.