



Yamaha 225GETO 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	7
BRACKET 2	10
CONTROL	13
CRANKSHAFT. PISTON	18
CYLINDER. CRANKCASE 1	21
CYLINDER. CRANKCASE 2	24
ELECTRICAL 1	26
ELECTRICAL 2	28
ELECTRICAL 3	31
ELECTRICAL 4	35
FUEL 1	36
FUEL 2	40
FUEL INJECTION NOZZLE	41
FUEL INJECTION PUMP	44
GENERATOR	48
INTAKE	50
LOWER CASING. DRIVE 1	52
LOWER CASING. DRIVE 2	58
METER	60
OIL PUMP	62
OIL TANK	64
POWER TRIM & TILT ASSY 1	67
POWER TRIM & TILT ASSY 2	70
REMOTE CONTROL ASSY	73
REMOTE CONTROL BOX	78
REPAIR KIT 1	79
REPAIR KIT 2	81
STARTING MOTOR	83
STEERING GUIDE	85
TOP COWLING	86
UPPER CASING	88


Bottom Cowling




E5

Ref	Part	
1	61A-42711-05-8D Cowling, Bottom 1	Buy now
2	90169-05M00 Screw truss head tapping FLUSHING KIT	Buy now
3	61A-42815-01-8D Lever, Clamp	Buy now
4	90386-13M88 Bush(6r3)	Buy now
5	90206-13M10 Washer, wave (6e5)	Buy now
6	90201-06M30 Washer, plate (6a1)	Buy now
7	90109-06M50 Bolt(61a)	Buy now
8	6R3-42824-00 Base, clamp lever	Buy now
9	6R3-42811-01 Stay	Buy now
10	6R3-42816-00 Lever, clamp	Buy now
11	6R3-42850-10 Wire, complete	Buy now
12	61A-42850-01 Wire Complete	Buy now
13	6R3-42811-10 Stay	Buy now
14	61A-42850-20 Wire, complete	Buy now
15	682-44117-00 Bracket 1	Buy now

Bottom Cowling




Bottom Cowling



E5

Ref	Part	
35	90201-08M54 Washer, plate (6e5)	Buy now
36	97075-08035 Bolt(70w)	Buy now
37	90119-08M22 Bolt, with washer	Buy now
38	688-42726-10 Grommet	Buy now
39	6H4-42726-00 Grommet	Buy now
40	61A-42716-00 Rubber seal 1	Buy now
41	61A-42717-00 Rubber, seal 2	Buy now
42	61A-42727-00 Grommet	Buy now
43	61A-42741-01-8D Apron	Buy now
44	61A-42771-01-8D Apron	Buy now
45	97095-06030 Bolt(jf7)	Buy now
47	97095-06020 Bolt(7u8)	Buy now
49	6E5-82594-00 Clamp	Buy now
50	6E5-82588-00 Plate	Buy now
53	688-82594-00 Clamp	Buy now


Bottom Cowling



E5

Ref	Part	
54	<u>6R3-12572-00</u> Adapter FLUSHING KIT	Buy now
55	<u>6R3-12580-00</u> Joint assembly FLUSHING KIT	Buy now
56	<u>90445-11M36</u> Hose (I700) FLUSHING KIT	Buy now
57	<u>90465-11M10</u> Clamp FLUSHING KIT	Buy now
58	<u>68F-42753-00</u> Fastner	Buy now
59	<u>90464-20258</u> Clamp	Buy now
60	<u>6K7-42791-00</u> Mark 1	Buy now
61	<u>6A1-28176-00</u> Label Caution	Buy now
62	<u>65L-2415E-60</u> Label, Caution	Buy now
63	<u>6E3-8257H-00</u> Plate Mark	Buy now


Bracket 1



F4

Ref	Part	
1	64E-43111-02-8D Bracket, clamp	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06030 Bolt(jf7)	Buy now
5	92995-06100 Washer(6a1)	Buy now
6	6E5-82148-00 Wire, lead 5	Buy now
7	97095-06010 Bolt	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	64E-43112-02-8D Bracket, clamp	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	92990-06600 Washer, plain (646)	Buy now
13	93700-06M03 Nipple, grease(6a1)	Buy now
14	663-45119-00 Cap, grease nipple AP	Buy now
15	64E-43131-01 Bolt, clamp bracket	Buy now
16	97095-08020 Bolt, hexagon	Buy now


Bracket 1



F4

Ref	Part	
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	90386-25M31 Bushing (6e5)	Buy now
19	90201-26M59 Washer, plate (6e5)	Buy now
20	90185-22M11 Nut, self-locking	Buy now
21	90465-11M10 Clamp	Buy now
22	64E-43311-10-8D Bracket, swivel	Buy now
23	90465-08M63 Clamp(61u)	Buy now
26	66K-82149-00 Wire, lead 3	Buy now
27	6G5-43144-00 Hook, spring	Buy now
29	6G5-43181-02 Lever, tilt stop 1	Buy now
30	6G5-43185-02 Lever, tilt stop 2	Buy now
31	90386-10M16 Bushing (688)	Buy now
32	6G5-43148-00 Collar, distance	Buy now
33	90249-06M19 Pin(6e5)	Buy now
34	90387-10M05 Collar(6e5)	Buy now


Bracket 1



F4

Ref	Part	
35	91690-30020 Pin, spring (6h4)	Buy now
36	90506-14M24 Spring, tension(6e5)	Buy now
37	64E-43126-00 Pin, upper shock mount	Buy now
38	90386-22M98 Bush(61u)	Buy now
39	93410-22M11 Circlip(61u)	Buy now
40	90101-12M05 Bolt (l:130mm)	Buy now
41	90201-13M01 Washer, plate(6e5)	Buy now
42	90201-12M05 Washe, plate(663)	Buy now
43	95380-12600 Nut (707)	Buy now


Bracket 2



F6

Ref	Part	
1	64E-43139-02 Cam, trim sender (with screw)	Buy now
2	97780-60525 Screw, tapping(65j)	Buy now
3	64E-83672-02 Trim sender	Buy now
4	97885-06016 Screw, pan head(6b0)	Buy now
5	90465-11M10 Clamp	Buy now
6	93210-37MH7 O-ring(61u)	Buy now
7	90202-40M47 Washer, plate(61a)	Buy now
8	64E-43376-00 Bolt, thrust receiver	Buy now
9	95780-10300 Nut, nylon (6e5)	Buy now
10	66K-42510-00-8D Steering bracket assembly	Buy now
11	90201-38M60 Washer, plate (6e5)	Buy now
12	90386-38M32 Bush(6e5)	Buy now
13	66K-44551-00-8D Housing, lower mount rubber	Buy now
14	93410-37M04 Circlip (6e5)	Buy now
15	6E5-44575-00 Damper, lower mount rubber	Buy now


Bracket 2



F6


Ref	Part	
16	66K-44555-00-94 Mount damper, lower side	Buy now
17	90202-32M19 Washer, plate (6e5)	Buy now
18	90201-16M55 Washer, plate (6e5)	Buy now
19	90109-14M80 Bolt	Buy now
20	90201-15M58 Washer, plate (6e5)	Buy now
21	95380-14800 Nut, crown (6e5)	Buy now
22	92995-14600 Washer (6e5)	Buy now
23	90101-10M70 Bolt(6j9)	Buy now
24	66K-44553-00-NA Cover, lower mount	Buy now
25	65N-43155-N0 Mark 1	Buy now
26	65N-43156-N0 Mark 2	Buy now
27	66K-44514-00-94 Mount damper, upper side	Buy now
28	90201-16M01 Washer, plate(61a)	Buy now
29	90202-28M46 Washer, plate(61a)	Buy now
30	90201-28M01 Washer, plate(61a)	Buy now

Bracket 2



Ref	Part	
31	90109-14M10 Bolt	Buy now
32	90185-14M00 Nut, self-locking(61a)	Buy now
34	61A-44511-00-94 Cover, upper mount	Buy now
35	97095-10045 Bolt(64d)	Buy now
36	92995-10600 Washer, plate	Buy now


F6



F1


Ref	Part	
1	65L-48531-00 Bracket Remote Control 1	Buy now
2	663-48538-00 Clamp, cable 1	Buy now
3	91690-30010 Pin, spring (663)	Buy now
4	97095-08020 Bolt, hexagon	Buy now
5	92995-08100 Ybs67-8 washer, spring	Buy now
6	65L-41632-01 Lever, magneto control	Buy now
7	6E5-48344-00 Cable end, remote control	Buy now
8	90468-18008 Clip 620436610000	Buy now
9	97013-08045 Bolt	Buy now
10	92990-08200 Ybs66-8 washer, plain	Buy now
11	90206-12M00 Washer, wave (676)	Buy now
12	90387-08M16 Collar	Buy now
13	61A-41237-00 Joint, link	Buy now
14	95380-05600 Nut, hexagon (663)	Buy now
15	682-41237-00 Joint, link 2	Buy now

Control




F1

Ref	Part	
16	66K-41213-00 Cam, Accel	Buy now
17	90201-06M31 Washer (6a0)	Buy now
18	90387-06M29 Coller (6a0)	Buy now
19	90206-10M04 Washer, wave (676)	Buy now
20	97013-06030 Bolt	Buy now
21	92903-06600 Washer, plain (646)	Buy now
22	61A-44117-01-1S Bracket	Buy now
23	90159-05M25 Screw,pan head (646)	Buy now
24	97095-06020 Bolt(7u8)	Buy now
25	69L-42744-00 Stay	Buy now
26	688-44194-00 Cap	Buy now
27	95380-06600 Nut(661)	Buy now
28	90157-06M11 Screw, pan head(697)	Buy now
29	61A-44176-00-1S Bracket	Buy now
30	93700-06M01 Nipple, grease(61a)	Buy now



F1


Ref	Part	
31	90386-12069 Bush(666)	Buy now
32	90387-08M09 Collar(61a)	Buy now
33	97095-08035 Bolt(70w)	Buy now
34	92995-08200 Ybs66-8 washer, plain	Buy now
35	90508-20M31 Spring, torsion(61a)	Buy now
36	61A-8259F-00 Switch assembly	Buy now
37	61A-82588-00 Plate	Buy now
38	97885-04016 Screw, panhead (796)	Buy now
39	92995-04100 Ybs67-4 washer, spring	Buy now
40	61A-44121-00 Lever, shift rod	Buy now
41	6E5-44122-00 Bushing, shift rod lever	Buy now
42	90202-08M20 Washer, plate (6e5)	Buy now
45	90202-06007 Washer plate 626441880000	Buy now
46	61A-44118-00-8D Bracket	Buy now
47	93700-06M03 Nipple, grease(6a1)	Buy now



F1

Ref	Part	
48	61A-44116-00 Spring	Buy now
49	97095-06030 Bolt(jf7)	Buy now
50	92995-06100 Washer(6a1)	Buy now
51	92995-06600 Washer, plain (646)	Buy now
52	66K-44120-00 Handle Gear Shift assembly	Buy now
53	93210-09165 O-ring	Buy now
54	61A-44112-00 Stay, handle gear shift	Buy now
55	97013-06012 Bolt(gh1)	Buy now
56	92903-06100 Washer(6a1)	Buy now
58	95313-08600 Nut(6l2)	Buy now
59	90386-90M90 Bush(61a)	Buy now
60	91490-20012 Pin, cotter (648)	Buy now
61	90201-09M02 Washer, plate(61a)	Buy now
62	61A-15315-00 Seal, crankcase	Buy now
63	61A-42724-00 Grommet	Buy now


Control



F-1

Ref	Part	
64	61A-44138-00 Washer	Buy now
65	97885-06008 Screw, pan head(6a3)	Buy now


Crankshaft. Piston



B1


Ref	Part	
1	61A-11411-00 Crankshaft	Buy now
2	61A-11447-00 Seal, crank	Buy now
3	93311-940V0 Bearing, cylindrical(61a)	Buy now
4	93102-40M38 Oil seal(61a)	Buy now
5	93210-54M54 O-ring (6g1)	Buy now
6	93306-209U1 Bearing(61a)	Buy now
7	93310-959U0 Bearing, cylindrical(61a)	Buy now
8	61A-11536-00 Gear, drive	Buy now
9	93306-308U0 Bearing(61a)	Buy now
10	93410-40M03 Circlip(n02)	Buy now
11	61A-11586-01 Pulley, crankshaft balance	Buy now
12	61A-11555-01 Nut, crankshaft 1	Buy now
13	93104-22M07 Oil seal(61a)	Buy now
14	61A-15359-00-94 Housing, oil seal	Buy now
15	93102-40M36 Oil seal	Buy now

Crankshaft. Piston



Ref	Part	
16	93420-61M07 Circlip(61a)	Buy now
17	93210-81MA6 O-ring(61a)	Buy now
18	97095-06020 Bolt(7u8)	Buy now
19	92995-06100 Washer(6a1)	Buy now
20	69L-11631-00-85 Piston (std)	Buy now
20	69L-11635-00 Piston (0.25mm o/s) AP	Buy now
20	69L-11636-00 Piston (0.50mm o/s) AP	Buy now
21	69L-11642-00-85 Piston 2 (std)	Buy now
21	69L-11645-00 Piston 2 (0.25mm o/s) AP	Buy now
21	69L-11646-00 Piston 2 (0.50mm o/s) AP	Buy now
22	64D-11603-01 Piston ring set (std)	Buy now
22	64D-11604-01 Piston ring set (0.25mm o/s) AP	Buy now
22	64D-11605-01 Piston ring set (0.50mm o/s) AP	Buy now
23	61A-11633-02 Pin, piston	Buy now
24	61A-11634-00 Clip, piston pin	Buy now


Crankshaft. Piston



B1

Ref	Part	
25	66K-11650-00 Connecting rod kit	Buy now
26	90109-09001 Bolt	Buy now
27	93310-326V4 Bearing, cylindrical(61a)	Buy now
28	90201-26M03 Washer, plate(61a)	Buy now
29	93310-840U1 Bearing	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
3	6E5-11372-00 Nipple, hose	Buy now
4	624-14485-00 Pipe, joint	Buy now
5	90384-06M07 Bush, bimetal formed(6r3)	Buy now
6	90383-16M01 Bush, formed(61a)	Buy now
7	6F6-11372-00 Nipple, hose	Buy now
8	650-11372-00 Nipple, hose	Buy now
10	663-11518-01 Lock, bearing	Buy now
11	93608-12063 Pin, dowel (626)	Buy now
12	90445-07M11 Hose (I770)	Buy now
13	90105-10M62 Bolt, washer based(61a)	Buy now
14	90105-10M75 Bolt, washer based(65j)	Buy now
15	90119-06M13 Bolt, with washer (682)	Buy now
16	90445-07M44 Hose (I390)	Buy now
17	90445-07M40 Hose (I390)	Buy now
18	90445-07MA6 Hose (I200)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
20	6G5-12581-00 Joint, hose	Buy now
21	61A-11325-00 Anode	Buy now
22	6H3-11328-00 Grommet, anode	Buy now
24	97013-06016 Bolt, hexagon deep recess	Buy now
25	92903-06600 Washer, plain (646)	Buy now
26	90340-14M00 Plug, straight screw(62y)	Buy now
27	90430-14115 Gasket (663)	Buy now
28	6E5-11119-01 Hanger, engine	Buy now
29	90119-08MA3 Bolt, with washer	Buy now
30	61A-11371-00-1S Cover	Buy now
31	90465-06M86 Clamp	Buy now
32	61A-11381-A0 Gasket 1	Buy now
33	90119-06MA2 Bolt, with washer	Buy now
34	6E5-12411-20 Thermostat	Buy now
35	61A-12413-00-1S Cover, thermostat	Buy now


Cylinder. Crankcase 1



Ref	Part	
36	61A-12413-10-1S Cover, thermostat	Buy now
37	61A-12414-A0 Gasket, cover	Buy now
38	90119-06MA5 Bolt, with washer	Buy now
39	6E5-42761-00-1S Stopper	Buy now
41	68F-44533-00 Damper, upper mount rubber	Buy now

A6


Cylinder. Crankcase 2



B3

Ref	Part	
1	62J-11111-01-1S Head, cylinder 1	Buy now
2	69L-11181-00 Gasket, cylinder head 1	Buy now
3	90119-08MA5 Bolt, with washer	Buy now
4	90119-08M99 Bolt, with washer	Buy now
5	61A-11191-00-1S Cover, cylinder head 1	Buy now
6	61A-11193-A1 Gasket, head cover 1	Buy now
7	90119-06MA5 Bolt, with washer	Buy now
8	6J8-11325-00 Anode	Buy now
9	6H3-11328-00 Grommet, anode	Buy now
10	6H3-11327-00-1S Cover, anode	Buy now
11	97013-06016 Bolt, hexagon deep recess	Buy now
12	92903-06600 Washer, plain (646)	Buy now
13	61A-41113-00-1S Outer cover, exhaust	Buy now
14	650-24378-00 Pipe, joint 2	Buy now
15	61A-41112-A0 Gasket, exhaust inner cover	Buy now


Cylinder. Crankcase 2



Ref	Part	
16	90119-06MA3 Bolt, with washer	Buy now
17	90445-09M25 Hose (I1500)	Buy now
18	90467-08004 Clip, pipe 6162435600	Buy now
19	6G5-12416-00 Valve, pressure control	Buy now
20	90501-16M11 Spring, compression (688)	Buy now
21	90480-20M05 Grommet (688)	Buy now
22	6G5-11382-A1 Gasket 2	Buy now
23	6G5-11372-00-1S Cover, bypass 2	Buy now
24	90119-06MA2 Bolt, with washer	Buy now
25	61A-12576-00 Hose 1	Buy now
26	90465-13M18 Clamp	Buy now
27	94702-00309 Plug, spark (br9hs-10)	Buy now

B3


Electrical 1



D4


Ref	Part	
1	61A-85542-01-94 Bracket	Buy now
2	90480-09M12 Grommet (6a0)	Buy now
3	90387-06M03 Collar (676)	Buy now
4	90119-06M28 Bolt, With Washer	Buy now
5	97013-06016 Bolt, hexagon deep recess	Buy now
6	92903-06600 Washer, plain (646)	Buy now
7	66K-85540-01 C.d.i. Unit assembly	Buy now
8	97013-06025 Bolt(62y)	Buy now
10	61A-85548-00 Holder	Buy now
11	61A-85525-00 Cover	Buy now
12	97095-06016 Bolt, hexagon deep recess	Buy now
13	92995-06100 Washer(6a1)	Buy now
14	92995-06600 Washer, plain (646)	Buy now
15	97013-06014 Bolt(gj3)	Buy now
17	90464-15M11 Clamp (3y2)	Buy now

Electrical 1




Ref	Part	
18	90465-11M52 Clamp(6e7)	Buy now
19	61A-85537-00 Cover	Buy now
20	90159-06M03 Screw (6g5)	Buy now
21	61A-82519-00 Wire, Earth Lead	Buy now
22	6G0-82519-00 Wire, earth lead	Buy now
23	97095-06012 Bolt(gh1)	Buy now

D4



D5

Ref	Part	
1	61A-85570-00 Ignition coil assembly	Buy now
2	97013-06020 Bolt(62y)	Buy now
3	92903-06600 Washer, plain (646)	Buy now
4	6E3-82370-21 Plug cap assembly	Buy now
5	65L-85370-00 Resistor assembly	Buy now
6	97885-05010 Screw, pan head(62x)	Buy now
7	92995-05600 Washer, plain (646)	Buy now
8	65L-81915-00-94 Plate, Regulator Fitting	Buy now
9	90119-06M65 Bolt, with washer	Buy now
10	90387-06M60 Collar (6h3)	Buy now
11	90480-10M23 Grommet(6k7)	Buy now
12	65L-81916-00 Cover, Terminal	Buy now
13	90159-06M03 Screw (6g5)	Buy now
14	90464-19M45 Clamp(65j)	Buy now
15	61A-82531-00 Wire, lead	Buy now




D5


Ref	Part	
16	97095-06012 Bolt(gh1)	Buy now
17	92995-06600 Washer, plain (646)	Buy now
18	66K-82590-10 14 -	Buy now
19	705-82151-00 Fuse (30a)	Buy now
20	90465-08M89 Clamp	Buy now
21	90465-05M87 Clamp	Buy now
23	65L-8259M-00 Wire Harness assembly 2	Buy now
24	65L-8259N-01 Wire Harness assembly 3	Buy now
25	90465-11M10 Clamp	Buy now
26	90465-11M52 Clamp(6e7)	Buy now
27	90465-13M18 Clamp	Buy now
28	66K-82105-00 Battery Cable	Buy now
31	61A-82563-00 Trim & tilt switch assembly	Buy now
32	6E5-82587-00 Gasket	Buy now
33	61A-83614-00 Bracket	Buy now

Electrical 2

Ref	Part	
35	65L-83625-50 Mark 5	Buy now




D5



D7


Ref	Part	
1	65L-81948-00 Bracket	Buy now
2	624-42542-00 Collar	Buy now
3	6A0-82317-00 Damper, ignition coil	Buy now
4	90119-06M65 Bolt, with washer	Buy now
5	97013-06014 Bolt(gj3)	Buy now
6	61A-87149-00 Connector	Buy now
7	61A-81950-00 Relay assembly	Buy now
8	97013-06030 Bolt	Buy now
9	92903-06600 Washer, plain (646)	Buy now
10	90464-18M46 Clamp(65j)	Buy now
11	61A-81949-10 Wire, lead	Buy now
12	61A-81949-00 Wire, lead	Buy now
13	6G5-82119-00 Cover, lead wire	Buy now
14	61A-81941-00 Starter relay assembly	Buy now
15	61A-81952-00 Holder, relay	Buy now

Electrical 3




D7

Ref	Part	
16	97780-50612 Screw, tapping(61a)	Buy now
17	61A-82150-00 Fuse holder assembly	Buy now
18	61A-82151-00 Fuse(12v-80a)	Buy now
19	61A-82153-00 Stay, fuse holder	Buy now
20	66K-81949-10 Wire, Lead	Buy now
21	61A-81960-02 Rectifier & regulator assembly	Buy now
22	69J-81975-A0 Plate, rectifier fitting	Buy now
23	69J-81972-01-1S Cover, rectifier	Buy now
24	97013-06025 Bolt(62y)	Buy now
28	90445-09224 Hose (I1500)	Buy now
29	90467-08004 Clip, pipe 6162435600	Buy now
30	65L-81942-00 Cover	Buy now
31	90169-05M00 Screw truss head tapping	Buy now
32	61A-82154-01 Case	Buy now
33	61A-82176-00 Damper	Buy now




D7

Ref	Part	
34	61A-82117-00 Wire, lead	Buy now
35	65L-81950-00 Relay assembly	Buy now
36	97780-60625 Screw, tapping(65j)	Buy now
37	67H-82380-00 Sensor, pressure	Buy now
39	65L-85886-00 Thermosensor	Buy now
40	90170-12M36 Nut	Buy now
41	90201-12M34 Washer (692)	Buy now
42	65L-8592A-01 Sensor	Buy now
43	69L-11395-00 Holder	Buy now
44	93210-17003 O-ring	Buy now
45	69L-11397-00 Gasket	Buy now
46	90119-06M74 Bolt, with washer(63m)	Buy now
47	90465-13M18 Clamp	Buy now
48	65L-85832-00 Case, under	Buy now
49	65L-11354-00 Gasket	Buy now



Ref	Part	
50	65L-1131N-00 Gasket, holder	Buy now
51	65L-11396-00 Gasket, holder	Buy now
52	65L-11353-11 Joint	Buy now
53	69L-11357-00 Seal, cylinder 3	Buy now
54	97095-06030 Bolt(jf7)	Buy now
55	92995-06100 Washer(6a1)	Buy now
56	92995-06600 Washer, plain (646)	Buy now
57	66K-82519-00 Wire, Earth Lead	Buy now
58	65L-81919-00 Graphic, Regulator	Buy now
59	61A-81919-00 Graphic Regulator	Buy now
60	65L-83625-50 Mark 5	Buy now
61	68F-81949-00 Wire, lead AP	Buy now

D7




65J0010-7150

E3

Ref	Part	
1	61A-85780-00 Sensor, knock	Buy now
2	61A-85790-00 Thermosensor assembly	Buy now
3	92990-10600 Washer, plate	Buy now
4	90464-12M48 Clamp	Buy now
5	61A-85895-00 Crank position sender	Buy now
6	97885-05012 Screw,pan head (646)	Buy now
7	90464-09M47 Clamp(65j)	Buy now
8	61A-82560-00 Thermo switch assembly	Buy now
9	61A-8252U-00 Cover	Buy now
10	97080-06012 Bolt(gh1)	Buy now

Fuel 1




66X1100-2101

C6

Ref	Part	
1	90465-11M10 Clamp	Buy now
2	90445-13M17 Hose(l2700)	Buy now
3	6R3-24377-00 Pipe, joint 3	Buy now
4	90464-13M34 Clamp(6r3)	Buy now
5	61A-24313-00 Pipe 3	Buy now
8	6R5-24408-00 Fuel feed assembly	Buy now
9	61A-24311-00 Pipe, fuel 1	Buy now
11	65L-24560-00 Filter assembly	Buy now
12	61A-24521-00 Cup, filter	Buy now
13	65L-24531-01 Nut	Buy now
14	61A-24564-00 O-ring	Buy now
15	65L-24577-00 Spring	Buy now
16	65L-24563-00 Element, filter	Buy now
17	61A-24469-00 Float, water level	Buy now
18	65L-24564-00 Gasket	Buy now


Fuel 1




C6

Ref	Part	
19	65L-24558-00 Holder, filter	Buy now
20	97095-06016 Bolt, hexagon deep recess	Buy now
21	92995-06100 Washer(6a1)	Buy now
22	90201-06068 Washer,plate (6k8)	Buy now
23	61A-24566-00 Bracket, filter	Buy now
24	97095-06014 Bolt(gj3)	Buy now
25	92995-06600 Washer, plain (646)	Buy now
30	6G5-24317-01 Pipe 7	Buy now
32	6E5-24378-00 Pipe, joint 3	Buy now
33	6E5-24315-00 Pipe 5	Buy now
35	6G5-24315-00 Pipe 5	Buy now
38	6E5-24410-03 Fuel pump assembly	Buy now
39	98503-05035 Screw, pan head (686)	Buy now
40	92903-05600 Washer, plain (646)	Buy now
41	6E5-24413-00 Body 2	Buy now

Fuel 1



Fuel 1




66X1100-2101

C6

Ref	Part	
61	6E5-24313-00 Pipe 3	Buy now
63	6E9-83557-70 Tube	Buy now
64	65L-83557-00 Tube	Buy now

Fuel 2


Ref	Part	
1	6YK-24307-42 Fuel pipe comp. 2 AP	Buy now
2	90450-10M07 Hose, clamp AP	Buy now



68J1100-2140

D2


Fuel Injection Nozzle



B7

Ref	Part	
1	67H-13751-00 Body, throttle 1	Buy now
2	65L-14527-00 Plate	Buy now
3	65L-14565-00 Screw	Buy now
4	6K5-14592-00 Screw	Buy now
5	90201-05552 Washer, plate(65j)	Buy now
6	65L-14334-00 Spring, air adjusting	Buy now
7	65L-14523-00 Screw, stop	Buy now
8	65L-14578-00 Collar	Buy now
9	67H-13938-00 Pipe	Buy now
10	67H-13898-00 Holder	Buy now
12	65L-13573-00 Bolt 1	Buy now
13	65L-13995-00 Washer	Buy now
14	65L-13761-00 Injector assembly	Buy now
15	65L-13769-00 O-ring	Buy now
16	65L-13764-00 Gasket	Buy now

Fuel Injection Nozzle




B7

Ref	Part	
17	65L-13766-00 Rubber, injector	Buy now
18	61A-85885-00 Throttle sensor assembly	Buy now
19	6K7-85886-00 Bracket	Buy now
20	97985-05212 Screw, with washer(6g7)	Buy now
21	90387-05M00 Collar(6k7)	Buy now
22	90480-10M23 Grommet(6k7)	Buy now
23	65L-14596-00 Washer	Buy now
24	97985-05330 Screw, with washer(61b)	Buy now
25	65L-14573-00 Lever	Buy now
26	65L-14579-00 Spring	Buy now
27	65L-13996-00 Insert	Buy now
28	66K-13971-00 Pipe, fuel 1	Buy now
29	65L-24387-00 Clip	Buy now
30	67H-13972-00 Pipe, fuel 2	Buy now
32	65L-41217-00 Rod, accel. lever	Buy now


Fuel Injection Nozzle

Ref	Part	
33	90464-04M12 Clamp (6h3)	Buy now



B7


Fuel Injection Pump



B4

Ref	Part	
1	66K-14980-00 Body, float chamber	Buy now
2	67H-14182-00 Cover, float chamber	Buy now
3	65L-14546-00 Valve, needle	Buy now
4	66K-14985-00 Float	Buy now
5	66K-14548-01 Pin, float arm	Buy now
6	66K-14984-00 Gasket, float chamber	Buy now
7	65L-14125-00 Screw	Buy now
8	66K-13906-00 Regulator, pressure	Buy now
9	66K-14255-00 Plate	Buy now
10	66K-14239-00 Seal	Buy now
11	66K-14325-01 Screw, pan head	Buy now
12	66K-14163-00 Spacer	Buy now
13	65L-13905-00 Filter comp	Buy now
14	65L-14966-00 Cap	Buy now
15	65L-24486-00 O-ring	Buy now


Fuel Injection Pump



B4

Ref	Part	
16	66K-14245-00 Screw, guide	Buy now
17	67H-13907-00 Fuel pump comp.	Buy now
18	65L-14227-00 Washer	Buy now
19	65L-14194-00 Washer	Buy now
20	65L-14159-00 Clip	Buy now
21	66K-13781-00 Damper, pump	Buy now
22	66K-13844-00 Plate 2	Buy now
23	66K-13915-00 Filter	Buy now
24	65L-1416A-00 O-ring	Buy now
25	66K-14271-00 Insulator	Buy now
26	65L-8182A-00 Nut	Buy now
27	65L-8182K-00 Nut	Buy now
28	65L-8182E-00 Washer	Buy now
29	65L-8182F-00 Washer	Buy now
30	66K-13843-00 Plate 1	Buy now


Fuel Injection Pump



B4

Ref	Part	
31	65L-14147-00 O-ring	Buy now
32	65L-14274-00 Connector	Buy now
33	66K-24376-00 Pipe, joint 1	Buy now
34	66K-24489-00 O-ring	Buy now
35	65L-14397-00 O-ring	Buy now
36	65L-14992-00 Screw, drain	Buy now
37	65L-14997-00 Seal	Buy now
38	65L-24375-00 Grommet	Buy now
39	65L-24397-00 Collar	Buy now
40	65L-24576-00 Washer	Buy now
41	66K-24579-00 Washer 2	Buy now
42	65L-24592-00 Bolt	Buy now
43	65L-24169-00 Washer, lock	Buy now
44	67H-82507-00 Wire, Lead	Buy now
45	67H-13490-00 Relief valve assembly	Buy now

Fuel Injection Pump




67H1010-2050

B4

Ref	Part	
46	66K-13542-00 Hose, vacuum sensing 1	Buy now
47	67H-13544-00 Hose, Vacuum Sensing 2	Buy now
48	66K-13532-00 Hose, vacuum sensing 3	Buy now
49	65L-24461-00 Pipe.joint 4	Buy now
50	66K-13533-00 Hose, vacuum sensing 4	Buy now
51	67H-13534-00 Hose, Vacuum Sensing 5	Buy now
52	67H-13183-00 Valve, Check	Buy now
53	66K-13898-00 Holder	Buy now
54	6G1-14966-00 Cap	Buy now
55	65L-14565-00 Screw	Buy now


Generator



D3

Ref	Part	
1	61A-85550-01 Rotor assembly	Buy now
2	65L-85510-10 Stator assembly	Buy now
3	61A-85580-01 Coil, pulser	Buy now
4	61A-83721-00 Cover	Buy now
5	97013-06035 Bolt(3rv)	Buy now
6	92903-06100 Washer(6a1)	Buy now
7	92903-06600 Washer, plain (646)	Buy now
8	97885-05030 Ybs86-530 screw,panhead	Buy now
9	92995-05100 Ybs67-5 washer, spring	Buy now
10	92995-05600 Washer, plain (646)	Buy now
11	90280-05015 Key, woodruff	Buy now
12	90170-24M22 Nut(61a)	Buy now
13	90201-25M02 Washer, plate(61a)	Buy now
14	6E5-81332-00 Plate, timing	Buy now
15	97885-06010 Screw pan head	Buy now


Generator



D3

Ref	Part	
16	92995-06600 Washer, plain (646)	Buy now
17	61A-81337-01 Cover, flywheel	Buy now
18	65L-81338-00-1S Clamp, Lead	Buy now
19	97013-06025 Bolt(62y)	Buy now
21	90464-18M46 Clamp(65j)	Buy now
22	663-82317-01 Damper, ignition coil	Buy now
23	65L-14488-00 Label, Caution	Buy now
24	6A1-83625-51 Mark 5	Buy now
25	6A1-83625-41 Mark 5	Buy now


Intake



C2

Ref	Part	
1	65L-13610-01 Reed valve assembly	Buy now
2	65J-W0004-01 Reed set	Buy now
3	61A-13621-A0 Gasket, valve seat	Buy now
4	97880-05016 Screw, pan head(6b0)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
6	65L-13624-01-1S Plate, Reed Valve	Buy now
7	6F6-11372-00 Nipple, hose	Buy now
8	90445-07M03 Hose (I200)	Buy now
9	90105-06028 Bolt, washer based	Buy now
10	65L-13646-00 Gasket, manifold 2	Buy now
11	65L-13645-00 Gasket, manifold 1	Buy now
12	97013-06060 Bolt, hexagon	Buy now
13	92903-06600 Washer, plain (646)	Buy now
14	95670-06655 Bolt, Stud	Buy now
15	90179-06M24 Nut(6j8)	Buy now


Intake



C2


Ref	Part	
16	65L-14440-00 Silencer assembly, intake	Buy now
17	65L-14483-00 Gasket	Buy now
18	90445-07M44 Hose (I390)	Buy now
19	90159-06M16 Screw, with washer(61a)	Buy now

Lower Casing. Drive 1



Ref	Part	
1	66K-45300-10-NA Lower unit assembly	Buy now
2	61A-45301-03-NA Casing, Lower	Buy now
3	93311-832V2 Ball bearing	Buy now
4	93332-000W1 Bearing(61a)	Buy now
5	61A-45567-00-10 Shim (t:0.10mm) UR	Buy now
5	61A-45567-00-12 Shim (t:0.12mm) UR	Buy now
5	61A-45567-00-15 Shim (t:0.15mm) UR	Buy now
5	61A-45567-00-18 Shim (t:0.18mm) UR	Buy now
5	61A-45567-00-30 Shim (t:0.30mm) UR	Buy now
5	61A-45567-00-40 Shim (t:0.40mm) UR	Buy now
5	61A-45567-00-50 Shim (t:0.50mm) UR	Buy now
6	663-44366-00 Damper, water seal 2	Buy now
7	90340-08002 Plug, straight screw	Buy now
8	688-45341-10 Plug, drain	Buy now
9	90430-08020 Gasket	Buy now


Lower Casing. Drive 1



B3

Ref	Part	
10	61A-45376-00-94 Guide, seal damper	Buy now
11	61A-45321-01 Plate	Buy now
12	93210-64488 93210-64488	Buy now
13	93106-09014 Oil seal	Buy now
14	90119-06M10 Bolt, with washer	Buy now
15	61A-44150-01 Shift cam assembly	Buy now
16	99001-08600 Circlip(2r6)	Buy now
17	90501-11M10 Spring, compression (663)	Buy now
18	61A-44311-01 Housing, water pump	Buy now
19	61A-44322-02 Insert, cartridge	Buy now
20	93210-86M38 O-ring (6e5)	Buy now
21	93210-37160 O-ring (6g8)	Buy now
22	6E5-44365-00 Damper, water seal 1	Buy now
23	6E5-44312-00 Cover, water pump housing	Buy now
24	6E5-44352-01 Impeller	Buy now


Lower Casing. Drive 1



B3

Ref	Part	
25	90280-04M05 Key, woodruff (6e5)	Buy now
26	61A-45538-00 Spacer, 1	Buy now
27	61A-45527-00 Collar, drive shaft	Buy now
28	90201-22M01 Washer, plate(61a)	Buy now
29	90206-22M19 Washer, wave(61a)	Buy now
30	6G5-44323-00 Outer plate, cartridge	Buy now
31	6E5-44315-A0 Gasket,water pump	Buy now
32	93606-12019 Pin, dowel (614)	Buy now
33	90119-08M14 Bolt, with washer	Buy now
34	61A-45331-00-94 Housing, bearing	Buy now
35	93101-28M16 Oil seal (6e5)	Buy now
36	93317-330U2 Bearing, cylindrical(6k0)	Buy now
37	61A-45587-00-10 Shim (t:0.10mm) UR	Buy now
37	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now
37	61A-45587-00-15 Shim (t:0.15mm)	Buy now


Lower Casing. Drive 1



B3

Ref	Part	
37	61A-45587-00-18 Shim (t:0.18mm) UR	Buy now
37	61A-45587-00-30 Shim (t:0.30mm) UR	Buy now
37	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now
37	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
38	93341-930U9 Bearing	Buy now
39	93210-55M14 O-ring (70e)	Buy now
40	6E5-45344-00 Cover, oil seal	Buy now
41	97095-08025 Bolt (62g)	Buy now
42	92995-08600 Washer, plain (663)	Buy now
43	66K-45501-00 Drive shaft comp.	Buy now
44	61A-45551-03 Pinion	Buy now
45	90201-16M00 Washer, plate(6t5)	Buy now
46	90170-16M19 Nut(6t5)	Buy now
47	61A-45560-03 Gear	Buy now
48	61A-45611-02 Shaft, propeller	Buy now


Lower Casing. Drive 1



B3


Ref	Part	
49	61A-45641-01 Shifter	Buy now
50	61A-45634-01 Slide, shift	Buy now
51	61A-45632-00 Pin, cross	Buy now
52	61A-45631-03 Clutch, dog	Buy now
53	61A-45633-00 Ring, cross pin	Buy now
54	6H1-45668-00 Shaft, free 1	Buy now
55	61A-45635-00 Plunger, shift	Buy now
56	90201-02M00 Washer, plate(61a)	Buy now
57	90183-02M03 Nut, spring (6h1)	Buy now
58	90501-10M77 Spring, compression(61a)	Buy now
59	93501-04011 Ball	Buy now
60	61A-45332-02-94 Housing, bearing	Buy now
61	93306-210U0 Bearing(61a)	Buy now
62	61A-45571-00 Gear	Buy now
63	90201-31M00 Washer, plate(61a)	Buy now

Lower Casing. Drive 1



Ref	Part	
64	61A-45577-00-10 Shim (t:0.10mm) UR	Buy now
64	61A-45577-00-12 Shim (t:0.12mm) UR	Buy now
64	61A-45577-00-15 Shim (t:0.15mm) UR	Buy now
64	61A-45577-00-18 Shim (t:0.18mm) UR	Buy now
64	61A-45577-00-30 Shim (t:0.30mm) UR	Buy now
64	61A-45577-00-40 Shim (t:0.40mm) UR	Buy now
64	61A-45577-00-50 Shim (t:0.50mm) UR	Buy now
65	93317-330U5 Bearing	Buy now
66	93101-30M17 Oil seal (6e15)	Buy now
67	93211-04384 O-ring (705)	Buy now
68	90105-08M48 Bolt, Flange	Buy now
69	93700-09M00 Nipple, grease(6t4)	Buy now
70	61A-45361-01-5B Cap, lower casing	Buy now
71	97095-08020 Bolt, hexagon	Buy now

Lower Casing. Drive 2




66X1100-2260

B7

Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	66K-44361-00 Tube, water	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	90101-10M70 Bolt(6j9)	Buy now
6	90119-10MA2 Bolt, with washer	Buy now
7	61A-45375-00 Damper, seal	Buy now
8	61A-45214-00 Cover, water inlet	Buy now
9	61A-45215-00 Cover, water inlet	Buy now
10	90152-05M08 Screw, countersunk	Buy now
11	90185-05002 Nut nylon (sus)(ex4)	Buy now
12	69L-45371-00 Tab-trim	Buy now
13	90105-10M00 Bolt, hexagon (663)	Buy now
14	6E5-45987-01 Spacer 1	Buy now
15	688-45997-01 Spacer 2	Buy now

Lower Casing. Drive 2




66X1100-2260

B7


Ref	Part	
16	92990-18200 Washer (6e5)	Buy now
17	90171-18M04 Nut, castle (6e5)	Buy now
18	91490-40030 Pin, cotter (663)	Buy now
19	66K-45970-B0 Propeller (3X14-1/2"x27") UR	Buy now
19	66K-45972-B0 Prop (3X14-1/2"X25"-M2) UR	Buy now

Meter



Ref	Part	
1	6Y5-8350T-01 Digital tachometer assembly AP	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83500-S5 Meter assembly AP	Buy now
7	6Y5-83570-S5 Speedometer assembly	Buy now
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
20	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a)	Buy now
17	6Y5-82117-00 Wire, lead AP	Buy now

Meter




61A1700-2290

C6

Ref	Part	
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now

Oil Pump




 65J0010-7080

C3

Ref	Part	
1	65L-13200-00 Oil injection pump assembly	Buy now
2	93210-19M82 O-ring(6j8)	Buy now
3	6R3-13471-00 Screw	Buy now
4	6L2-13475-00 Gasket, breather bolt	Buy now
5	90109-06M40 Bolt(6h0)	Buy now
6	61A-13416-00 Pipe Oil 1	Buy now
7	90465-11M10 Clamp	Buy now
8	65L-13183-00 Valve, check	Buy now
9	65L-24378-00 Pipe, joint 4	Buy now
10	90445-09220 Hose (l1500)	Buy now
11	90446-09M69 Hose(65j)	Buy now
13	90445-07M02 Hose (l200)	Buy now
14	90445-07M03 Hose (l200)	Buy now
15	90468-07M02 Clip (6e5)	Buy now
16	61A-11537-00 Gear, driven	Buy now

Oil Pump




65J0010-7080

C3

Ref	Part	
17	90201-09M01 Washer, plate(61b)	Buy now
18	61A-13117-00 Collar, distance	Buy now
19	93210-18MA9 O-ring(61a)	Buy now
20	6R5-41237-00 Joint, link	Buy now
21	65L-41241-00 Rod, Link	Buy now
22	95380-05600 Nut, hexagon (663)	Buy now
23	6H1-41237-00 Joint, link	Buy now
24	91490-12012 Pin, cotter (6g8)	Buy now
25	90202-05088 Washer, plate (666)	Buy now


Oil Tank



C4

Ref	Part	
1	61A-21750-00 Oil tank assembly	Buy now
2	61A-85730-01 Oil level gauge assembly	Buy now
3	61A-13411-00 Strainer, oil	Buy now
4	6E5-13414-00 Gasket, strainer cover	Buy now
5	90445-05M07 Hose (I700)	Buy now
6	6A0-82317-00 Damper, ignition coil	Buy now
7	624-42542-00 Collar	Buy now
8	90119-06M65 Bolt, with washer	Buy now
9	6R3-8259E-00 Switch assembly	Buy now
10	6E5-24379-00 Pipe, joint 4	Buy now
11	90445-12M04 Hose (I3000)	Buy now
12	90465-11M10 Clamp	Buy now
13	6E5-24323-00 Pipe 12	Buy now
16	90464-13M34 Clamp(6r3)	Buy now
17	61A-21708-03 Sub oil tank assembly.	Buy now


Oil Tank



C4

Ref	Part	
18	6E5-21733-02 Sub tank, oil (10.5l)	Buy now
19	6E5-21770-03 Oil tank cap assembly	Buy now
20	6E5-24322-00 Pipe 11	Buy now
22	646-24251-02 Strainer 1	Buy now
23	6E5-24319-01 Pipe, oil	Buy now
25	6E5-81900-01 Oil feed pump assembly	Buy now
26	6E5-81922-00 Grommet	Buy now
27	6E5-24321-01 Pipe 10	Buy now
29	90445-11M26 Hose (l8000)	Buy now
31	90480-06M19 Grommet (6e3)	Buy now
32	6E5-85720-04 Oil level gauge assembly	Buy now
33	6R3-85721-80 Wire, lead	Buy now
34	6E5-21734-01-33 Holder, oil sub tank	Buy now
35	6E5-21798-01-33 Bracket, damper	Buy now
36	6E5-21746-00 Damper	Buy now


Oil Tank



C4


Ref	Part	
37	97080-06100 Bolt, hexagon	Buy now
38	92990-06600 Washer, plain (646)	Buy now
39	95380-06600 Nut(661)	Buy now
40	90465-13M11 Clamp (6e5)	Buy now
41	6E5-85711-60 Mark Caution	Buy now
42	6E5-13437-62 Mark Caution	Buy now
43	656-W2810-02 Tool kit	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
1	68F-43800-01-4D Power trim & tilt assembly	Buy now
2	64E-43825-01 Housing Trim & Tilt	Buy now
3	64E-4388J-00 Plug 2	Buy now
4	93210-10M74 O-ring	Buy now
5	64E-43817-00 Filter 2	Buy now
6	64E-43810-00 Tilt piston sub assembly	Buy now
7	64E-43898-00 Seal, dust 2	Buy now
8	64E-43867-00 O-ring 7	Buy now
9	64E-43866-00 O-ring 6	Buy now
10	6E5-43862-00 O-ring 2	Buy now
11	64E-43883-00 O-ring 10	Buy now
12	6E5-43872-00 Ring, back-up 2	Buy now
13	6E5-43814-02 Piston, free	Buy now
15	64E-43820-00 Trim piston sub assembly	Buy now
16	64E-43821-00 Screw, trim cylinder end	Buy now

Power Trim & Tilt Assy 1




A4

Ref	Part	
17	64E-43822-00 Seal, trim dust	Buy now
18	64E-4384J-00 Seal, trim down	Buy now
19	6G5-43864-00 O-ring 4	Buy now
20	6E5-43864-00 O-ring 4	Buy now
21	6E5-43874-01 Ring, back-up 4	Buy now
22	64E-43828-00 Body, reservoir	Buy now
23	64E-43829-00 Plug, reservoir	Buy now
24	64E-43897-00 O-ring	Buy now
25	64E-4388E-00 Bolt ,screw (l:14mm)	Buy now
26	64E-43869-00 O-ring 9	Buy now
27	64E-4381G-00 Pin 1	Buy now
28	6E5-43858-00 Ball 1	Buy now
29	64E-4382G-00 Valve seat	Buy now
30	90201-08M14 Washer, plate	Buy now
31	97080-08016 Bolt	Buy now


Power Trim & Tilt Assy 1

Ref	Part	
32	64E-43818-01 Lower shock mount pin set	Buy now
33	90386-22M98 Bush(61u)	Buy now



A4


Power Trim & Tilt Assy 2



A6


Ref	Part	
1	64E-4388E-10 Bolt ,screw (l:34.7mm)	Buy now
2	64E-43831-00 Connector, shaft	Buy now
3	64E-43868-00 O-ring 8	Buy now
4	64E-43830-00 Gear pump assembly	Buy now
5	72X-43858-00 Ball	Buy now
6	64E-43843-00 Screw, valve lock	Buy now
7	64E-43841-00 Piston, shuttle	Buy now
8	64E-43802-00 Valve sub assembly	Buy now
9	6E5-43896-00 O-ring	Buy now
10	6G5-43863-00 O-ring 3	Buy now
11	64E-43851-00 Seat, Relief Valve	Buy now
12	64E-43858-00 Ball	Buy now
13	64E-43859-00 Pin, Valve Support	Buy now
14	64E-43855-00 Spring, up relief	Buy now
15	64E-43850-00 Valve sub assembly	Buy now

Power Trim & Tilt Assy 2



Ref	Part	
16	64E-43865-00 O-ring 10	Buy now
17	64E-43816-00 Filter 1	Buy now
19	64E-43817-10 Filter 2	Buy now
20	64E-43860-00 Manual valve sub-assembly	Buy now
21	72X-85075-L0 O-ring (nsd161)	Buy now
22	64E-43827-00 Ring set	Buy now
23	64E-4387A-00 O-ring	Buy now
24	64E-43873-00 Ring, back up	Buy now
25	64E-43875-00 Ring, snap	Buy now
26	64E-43879-10 Screw, with washer	Buy now
27	64E-43879-00 Screw, with washer	Buy now
28	67H-43880-01 Motor assembly	Buy now
29	6H1-4386K-10 Spring, brush	Buy now
30	64E-4380J-00 Holder Brush	Buy now
31	64E-43891-00 Brush 1	Buy now


Power Trim & Tilt Assy 2



A6

Ref	Part	
32	97607-04310 Screw, pan head(6g8)	Buy now
33	64E-4380F-00 Holder, brush 2	Buy now
34	64E-43892-00 Breaker comp. (brush 2)	Buy now
35	6G5-43865-00 O-ring	Buy now
36	93102-08M43 Oil seal(6b0)	Buy now
37	64E-43805-00 Armature assembly	Buy now
38	64E-43843-10 Screw valve lock	Buy now


Remote Control Assy



C3

Ref	Part	
1	703-48205-A4 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	703-48261-01 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now
15	703-48243-00 Bushing 3	Buy now


Remote Control Assy



C3

Ref	Part	
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now
30	703-48219-00 Cover, lead	Buy now


Remote Control Assy



Ca

Ref	Part	
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-12 Main switch assembly FOR PRIME START	Buy now
45	676-82577-00 Cap, key	Buy now


Remote Control Assy



C3

Ref	Part	
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-A0 Buzzer	Buy now
52	703-48284-00 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-82563-02 Trim & tilt switch assembly	Buy now
56	703-48221-00 Grip	Buy now
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now


Remote Control Assy



C3

Ref	Part	
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now
63	703-82542-00 Cap	Buy now
64	703-48218-00 Graphic	Buy now

Remote Control Box




67M0100-8280

C2

Ref	Part	
1	703-48205-A4 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now
2	701-48320-60 Cable, Remote Control L=16F UR	Buy now
2	701-48320-80 Cable, Remote Control L=17F UR	Buy now
2	701-48350-00 Cable, Remote Control L=21F UR	Buy now
2	701-48350-20 Cable, Remote Control L=23F UR	Buy now


Repair Kit 1



C7

Ref	Part	
1	65L-W0001-02 Power head gasket kit	Buy now
2	61A-11381-A0 Gasket 1	Buy now
3	69L-11181-00 Gasket, cylinder head 1	Buy now
4	61A-11193-A1 Gasket, head cover 1	Buy now
5	61A-12414-A0 Gasket, cover	Buy now
6	61A-41112-A0 Gasket, exhaust inner cover	Buy now
7	6G5-11382-A1 Gasket 2	Buy now
8	93102-40M38 Oil seal(61a)	Buy now
9	93210-54M54 O-ring (6g1)	Buy now
10	93104-22M07 Oil seal(61a)	Buy now
11	93102-40M36 Oil seal	Buy now
12	93210-81MA6 O-ring(61a)	Buy now
13	65L-13645-00 Gasket, manifold 1	Buy now
14	61A-45113-A0 Gasket, upper casing	Buy now
15	65L-13646-00 Gasket, manifold 2	Buy now


Repair Kit 1



Ref	Part	
16	650-24431-A0 Gasket,fuel pump	Buy now
17	61A-13621-A0 Gasket, valve seat	Buy now
18	65L-14483-00 Gasket	Buy now


C7

Repair Kit 2



Ref	Part	
1	66K-W0001-20 Lower unit gasket kit	Buy now
2	61A-41134-A0 Gasket, exhaust manifold	Buy now
3	61A-45114-A0 Gasket, upper casing	Buy now
4	90430-08020 Gasket	Buy now
5	66K-45123-00 Gasket, muffler	Buy now
6	6E5-44365-00 Damper, water seal 1	Buy now
7	6E5-44366-00 Damper, water seal 2	Buy now
8	93210-64488 93210-64488	Buy now
9	93106-09014 Oil seal	Buy now
10	93210-86M38 O-ring (6e5)	Buy now
11	93210-37160 O-ring (6g8)	Buy now
12	6E5-44315-A0 Gasket, water pump	Buy now
13	93101-28M16 Oil seal (6e5)	Buy now
14	93210-55M14 O-ring (70e)	Buy now
15	93211-04384 O-ring (705)	Buy now


Repair Kit 2



D1

Ref	Part	
16	93101-30M17 Oil seal (6e5)	Buy now
17	61A-W0078-A3 Water pump repair kit	Buy now
18	61A-44322-02 Insert, cartridge	Buy now
21	6E5-44352-01 Impeller	Buy now
22	6G5-44323-00 Outer plate, cartridge	Buy now
24	93606-12019 Pin, dowel (614)	Buy now
25	90119-08M14 Bolt, with washer	Buy now
26	90280-04M05 Key, woodruff (6e5)	Buy now


Starting Motor



E4

Ref	Part	
1	61A-81800-01 Starting motor assembly	Buy now
2	61A-81850-01 Armature assembly	Buy now
3	61A-81824-00 Washer 2	Buy now
4	61A-81809-00 Washer kit	Buy now
5	6K7-81810-10 Stator assembly	Buy now
6	6K7-81801-10 Brush Set	Buy now
7	61A-81840-00 Brush holder assembly	Buy now
8	6E5-81813-10 Spring Brush	Buy now
9	61A-81820-00 Rear Bracket assembly	Buy now
10	61A-81807-00 Gear assembly Starting Motor	Buy now
11	61H-81857-00 Retainer	Buy now
12	61A-81830-00 Front Bracket assembly	Buy now
13	6K7-81826-10 Bolt	Buy now
14	6E5-8182E-10 Washer, spring	Buy now
15	6E5-8182F-10 Washer,plain	Buy now


Starting Motor



Ref	Part	
16	6E5-8182A-10 Nut	Buy now
17	6E5-8182K-10 Nut	Buy now
18	6K7-8182G-10 Bush, terminal	Buy now
19	61A-81822-00-94 Bracket, starting motor	Buy now
20	90119-08M76 Bolt, with washer(6e5)	Buy now
21	90119-08M77 Bolt, with washer(6e5)	Buy now
22	97095-08016 Bolt, hexagon deep recess	Buy now
23	92995-08600 Washer, plain (663)	Buy now
24	97095-06012 Bolt(gh1)	Buy now
25	92995-06600 Washer, plain (646)	Buy now
26	90465-06M86 Clamp	Buy now

E4

Steering Guide




67H0100-9290

C1

Ref	Part	
1	6E5-61350-02 Steering guide attachment kit AP	Buy now
2	6E5-61351-01 Rod, steering link	Buy now
3	90387-10M61 Collar (6e5)	Buy now
4	90560-12M01 Spacer (6e5)	Buy now
5	6E5-61355-00 Bolt	Buy now
6	90185-09M01 Nut, nylon (663)	Buy now
7	90201-10M20 Washer, plate (663)	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now


Top Cowling



A4

Ref	Part	
2	6R3-42647-00 Holder, clamp band	Buy now
3	92990-06100 Washer(6a1)	Buy now
4	95380-06600 Nut(661)	Buy now
5	6R3-42662-00 Damper	Buy now
6	6R3-42814-00 Hook, clamp	Buy now
7	97095-06012 Bolt(gh1)	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	61A-42619-02 Damper, Form	Buy now
10	61A-42627-02 Damper Form	Buy now
11	61A-42615-01 Seal	Buy now
12	66K-42662-00 Damper	Buy now
14	90385-04M05 Bush(6r2)	Buy now
15	90179-06M24 Nut(6j8)	Buy now
16	61A-42626-00 Louver, 1	Buy now
18	92990-05200 Ybs66-5 washer, plain	Buy now


Top Cowling



A4

Ref	Part	
19	97780-50616 Screw, pan head tapping (ak5)	Buy now
20	66K-42686-P0 Emblem, Front	Buy now
21	66K-42687-N0 Emblem, Rear	Buy now
22	66K-W0070-N0 Graphic set	Buy now
23	66K-42681-N0 Mark, cowling	Buy now
24	66K-42682-N0 Mark Cowling	Buy now
25	66K-4267A-N0 Graphic, Rear 2	Buy now
26	66K-42683-N1 Mark, Cowling	Buy now
27	66K-42684-N1 Mark, Cowling	Buy now
28	92990-04600 Washer, plain (646)	Buy now
29	97780-40520 Ybs83-420 screw,panh,tapping	Buy now
30	66K-42628-00 Seal	Buy now

Upper Casing




66X0010-9231

B1

Ref	Part	
1	66K-45111-00-8D Casing, Upper	Buy now
2	6N9-42791-40 Mark 1	Buy now
3	6N9-42792-40 Mark 2	Buy now
4	61A-45155-00 Cap	Buy now
5	97095-06010 Bolt	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	93608-12M05 Pin, dowel b (6e5)	Buy now
8	90119-08027 Bolt, with washer	Buy now
9	66K-45378-00 Nipple, hose	Buy now
10	90119-06M17 Bolt, with washer	Buy now
11	93606-12019 Pin, dowel (614)	Buy now
12	90445-07MF0 Hose (l1160)	Buy now
13	6E5-83558-00 End, nipple	Buy now
14	90465-11M10 Clamp	Buy now
15	61A-45114-A0 Gasket, upper casing	Buy now

Upper Casing



B1

Ref	Part	
16	61A-41137-12-94 Guide, Exhaust FLUSHING KIT	Buy now
18	61A-45113-A0 Gasket, upper casing	Buy now
19	90119-08M79 Bolt, hexagon (fj1)	Buy now
20	97095-08035 Bolt(70w)	Buy now
21	92995-08600 Washer, plain (663)	Buy now
22	6H1-11372-00 Nipple, hose FLUSHING KIT	Buy now
23	61A-41131-00-5B Manifold, ext. 1	Buy now
26	61A-41132-01-5B Manifold, exhaust	Buy now
27	61A-41134-A0 Gasket, exhaust manifold	Buy now
28	97095-08050 Bolt (62k)	Buy now
30	66K-14711-00-5B Muffler 1	Buy now
31	66K-45123-00 Gasket, muffler	Buy now
32	90119-08M74 Bolt, with washer(61a)	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.