



# Yamaha 25NEMO 1990

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


|                                   |    |
|-----------------------------------|----|
| <b>Alternate 1</b>                | 3  |
| <b>Alternate 2</b>                | 4  |
| <b>Bottom Cowling</b>             | 6  |
| <b>Bracket 1</b>                  | 8  |
| <b>Bracket 2</b>                  | 11 |
| <b>Carburetor</b>                 | 13 |
| <b>Control</b>                    | 15 |
| <b>Crankshaft &amp; Piston</b>    | 18 |
| <b>Cylinder &amp; Crankcase</b>   | 20 |
| <b>Electrical 1</b>               | 23 |
| <b>Fuel</b>                       | 25 |
| <b>Intake</b>                     | 27 |
| <b>Lower Casing &amp; Drive 1</b> | 29 |
| <b>Lower Casing &amp; Drive 2</b> | 32 |
| <b>Magneto</b>                    | 34 |
| <b>Oil Pump</b>                   | 36 |
| <b>Optional Parts 1</b>           | 39 |
| <b>Optional Parts 2</b>           | 40 |
| <b>Optional Parts 3</b>           | 42 |
| <b>Optional Parts 4</b>           | 44 |
| <b>Remo Con Attachment</b>        | 46 |
| <b>Remote Control</b>             | 48 |
| <b>Remote Control Assy 1</b>      | 49 |
| <b>Repair Kit 1</b>               | 53 |
| <b>Repair Kit 2</b>               | 55 |
| <b>Starter</b>                    | 56 |
| <b>Steering</b>                   | 59 |
| <b>Steering Guide</b>             | 62 |
| <b>Top Cowling</b>                | 64 |
| <b>Upper Casing</b>               | 65 |

## Alternate 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2818001000</a><br>Starting motor assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2818501000</a><br>Armature assembly       | <a href="#">Buy now</a> |
| 3   | <a href="#">682818091000</a><br>Washer kit              | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2818331000</a><br>Ring, stop              | <a href="#">Buy now</a> |
| 6   | <a href="#">6L2818201000</a><br>Rear bracket assembly   | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2818401000</a><br>Brush holder assembly   | <a href="#">Buy now</a> |
| 8   | <a href="#">682818131000</a><br>Spring, brush           | <a href="#">Buy now</a> |
| 9   | <a href="#">6L2818111000</a><br>Brush 1                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2818121000</a><br>Brush 2                 | <a href="#">Buy now</a> |
| 11  | <a href="#">682818321000</a><br>Pinion assembly         | <a href="#">Buy now</a> |
| 13  | <a href="#">682818261000</a><br>Bolt                    | <a href="#">Buy now</a> |
| 14  | <a href="#">682818471000</a><br>O-ring                  | <a href="#">Buy now</a> |
| 15  | <a href="#">682818341000</a><br>Ring                    | <a href="#">Buy now</a> |
| 16  | <a href="#">970130802500</a><br>Bolt (682)              | <a href="#">Buy now</a> |
| 17  | <a href="#">929900860000</a><br>Washer, plain (663)     | <a href="#">Buy now</a> |

## Alternate 2




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G1819411000</a><br>Starter relay         | <a href="#">Buy now</a> |
| 2   | <a href="#">6G1819520000</a><br>Holder, relay         | <a href="#">Buy now</a> |
| 3   | <a href="#">6L2819450000</a><br>Plate, switch fitting | <a href="#">Buy now</a> |
| 4   | <a href="#">970130601200</a><br>Bolt(gh1)             | <a href="#">Buy now</a> |
| 5   | <a href="#">929950610000</a><br>Washer(6a1)           | <a href="#">Buy now</a> |
| 6   | <a href="#">6G1821050000</a><br>Battery cable         | <a href="#">Buy now</a> |
| 7   | <a href="#">6G1821170000</a><br>Wire, lead            | <a href="#">Buy now</a> |
| 8   | <a href="#">6G1821190000</a><br>Cover, Lead Wire      | <a href="#">Buy now</a> |
| 9   | <a href="#">6L2427255000</a><br>Grommet               | <a href="#">Buy now</a> |
| 10  | <a href="#">6G1819706100</a><br>Rectifier assembly    | <a href="#">Buy now</a> |
| 11  | <a href="#">6G1821510000</a><br>Fuse (10a)            | <a href="#">Buy now</a> |
| 12  | <a href="#">985030502500</a><br>Screw, panhead (a93)  | <a href="#">Buy now</a> |
| 13  | <a href="#">929900560000</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 14  | <a href="#">6G5821520000</a><br>Holder, fuse          | <a href="#">Buy now</a> |
| 15  | <a href="#">6L2861110000</a><br>Coil, solenoid        | <a href="#">Buy now</a> |

## Alternate 2




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">682861170000</a><br>Hook, wire pull       | <a href="#">Buy now</a> |
| 17  | <a href="#">6L2861150000</a><br>Holder, solenoid      | <a href="#">Buy now</a> |
| 18  | <a href="#">985800500800</a><br>Screw, pan head (7g3) | <a href="#">Buy now</a> |
| 20  | <a href="#">904801015500</a><br>Grommet(664)          | <a href="#">Buy now</a> |
| 21  | <a href="#">985800400800</a><br>Screw, pan head (713) | <a href="#">Buy now</a> |
| 22  | <a href="#">929900420000</a><br>Ybs66-4 washer, plain | <a href="#">Buy now</a> |
| 23  | <a href="#">6L2861120000</a><br>Stay, solenoid        | <a href="#">Buy now</a> |
| 26  | <a href="#">932100326100</a><br>O-ring (663)          | <a href="#">Buy now</a> |
| 28  | <a href="#">929900610000</a><br>Washer(6a1)           | <a href="#">Buy now</a> |
| 29  | <a href="#">6L2825900000</a><br>Wire harness assembly | <a href="#">Buy now</a> |
| 30  | <a href="#">6K3835570000</a><br>Tube                  | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 3   | <a href="#">9038612M4500</a><br>Bushing (6g1)        | <a href="#">Buy now</a> |
| 4   | <a href="#">6E0428160000</a><br>Lever, clamp         | <a href="#">Buy now</a> |
| 5   | <a href="#">902061205200</a><br>Washer, wave (666)   | <a href="#">Buy now</a> |
| 6   | <a href="#">978900603500</a><br>Screw, pan head(6h4) | <a href="#">Buy now</a> |
| 7   | <a href="#">957800630000</a><br>Nut, nylon (6g1)     | <a href="#">Buy now</a> |
| 8   | <a href="#">6L242719A000</a><br>Panel, front lower   | <a href="#">Buy now</a> |
| 9   | <a href="#">689412730000</a><br>Grommet              | <a href="#">Buy now</a> |
| 10  | <a href="#">6J8412740000</a><br>Grommet 2            | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2427250000</a><br>Grommet              | <a href="#">Buy now</a> |
| 12  | <a href="#">6G1427240000</a><br>Grommet              | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2427260100</a><br>Grommet              | <a href="#">Buy now</a> |
| 14  | <a href="#">6G1427270000</a><br>Grommet              | <a href="#">Buy now</a> |
| 15  | <a href="#">6L2427480100</a><br>Grommet              | <a href="#">Buy now</a> |
| 16  | <a href="#">6L2427160000</a><br>Rubber seal 1        | <a href="#">Buy now</a> |
| 17  | <a href="#">9033805M0300</a><br>Plug (6h1)           | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 18  | <a href="#">9048015M3100</a><br>Grommet (6g1)                   | <a href="#">Buy now</a> |
| 19  | <a href="#">9038706M5200</a><br>Collar (6g1)                    | <a href="#">Buy now</a> |
| 20  | <a href="#">9010506M1500</a><br>Bolt (6e0)                      | <a href="#">Buy now</a> |
| 21  | <a href="#">6L2427380100</a><br>Plate, fitting                  | <a href="#">Buy now</a> |
| 22  | <a href="#">6BL443910000</a><br>Nipple, hose                    | <a href="#">Buy now</a> |
| 23  | <a href="#">689825750200</a><br>Engine stop switch assembly     | <a href="#">Buy now</a> |
| 24  | <a href="#">682825560000</a><br>Lanyard, stop switch            | <a href="#">Buy now</a> |
| 25  | <a href="#">682843810000</a><br>2p concent 1                    | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8854100000</a><br>Emergency signal light assembly | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 3   | <a href="#">6E5821480000</a><br>Wire, lead 5          | <a href="#">Buy now</a> |
| 4   | <a href="#">978950600800</a><br>Screw, pan head(6a3)  | <a href="#">Buy now</a> |
| 5   | <a href="#">6164311800EJ</a><br>Handle, transom clamp | <a href="#">Buy now</a> |
| 6   | <a href="#">9024304M0000</a><br>Pin(6a9)              | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2431160000</a><br>Screw, transom clamp  | <a href="#">Buy now</a> |
| 8   | <a href="#">648431140100</a><br>Pad, transom clamp    | <a href="#">Buy now</a> |
| 9   | <a href="#">6J8431310100</a><br>Bolt, clamp bracket   | <a href="#">Buy now</a> |
| 10  | <a href="#">9038622M6700</a><br>Bush(6a9)             | <a href="#">Buy now</a> |
| 11  | <a href="#">902012242800</a><br>Washer, plate(64j)    | <a href="#">Buy now</a> |
| 12  | <a href="#">901852204300</a><br>Nut, self-locking     | <a href="#">Buy now</a> |
| 13  | <a href="#">6G5431450100</a><br>Cap, clamp bracket    | <a href="#">Buy now</a> |
| 14  | <a href="#">6J8431130100</a><br>Plate, clamp bracket  | <a href="#">Buy now</a> |
| 16  | <a href="#">937000600400</a><br>Nipple, grease(6a1)   | <a href="#">Buy now</a> |
| 17  | <a href="#">663451190000</a><br>Cap, grease nipple    | <a href="#">Buy now</a> |
| 18  | <a href="#">6H4425280000</a><br>Piece, friction       | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 19  | <a href="#">689433730100</a><br>Seal, damper             | <a href="#">Buy now</a> |
| 20  | <a href="#">9010506M1800</a><br>Bolt (689)               | <a href="#">Buy now</a> |
| 22  | <a href="#">6X3441910000</a><br>Indicator, shift         | <a href="#">Buy now</a> |
| 23  | <a href="#">9011610M2800</a><br>Bolt, stud               | <a href="#">Buy now</a> |
| 24  | <a href="#">929901060000</a><br>Washer, plate            | <a href="#">Buy now</a> |
| 25  | <a href="#">901851005100</a><br>Nut, self-locking        | <a href="#">Buy now</a> |
| 27  | <a href="#">9038630M7500</a><br>Bush(6I2)                | <a href="#">Buy now</a> |
| 28  | <a href="#">9020130M0000</a><br>Washer, plate(6h1)       | <a href="#">Buy now</a> |
| 29  | <a href="#">932102937500</a><br>O-ring (j10)             | <a href="#">Buy now</a> |
| 30  | <a href="#">9038630M6000</a><br>Bush(6j8)                | <a href="#">Buy now</a> |
| 32  | <a href="#">6L2445140000</a><br>Mount damper, upper side | <a href="#">Buy now</a> |
| 33  | <a href="#">6L2443650000</a><br>Damper, water seal 1     | <a href="#">Buy now</a> |
| 34  | <a href="#">973950602000</a><br>Bolt(7u8)                | <a href="#">Buy now</a> |
| 35  | <a href="#">929900660000</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 36  | <a href="#">6L2445140100</a><br>Mount damper, upper side | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 37  | <a href="#">975150625000</a><br>Bolt, With Washer         | <a href="#">Buy now</a> |
| 38  | <a href="#">975150624000</a><br>Bolt (682)                | <a href="#">Buy now</a> |
| 39  | <a href="#">9010108M0900</a><br>Bolt(612)                 | <a href="#">Buy now</a> |
| 40  | <a href="#">9020108M0100</a><br>Washer, plate(612)        | <a href="#">Buy now</a> |
| 41  | <a href="#">6L2445260000</a><br>Plate                     | <a href="#">Buy now</a> |
| 42  | <a href="#">957800830000</a><br>Nut, nylon (6j8)          | <a href="#">Buy now</a> |
| 45  | <a href="#">9360410M0300</a><br>Pin, dowel (688)          | <a href="#">Buy now</a> |
| 46  | <a href="#">973950808500</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 47  | <a href="#">929900860000</a><br>Washer, plain (663)       | <a href="#">Buy now</a> |
| 48  | <a href="#">6L2445550000</a><br>Mount damper, lower side  | <a href="#">Buy now</a> |
| 49  | <a href="#">6L2445570000</a><br>Mount damper, lower front | <a href="#">Buy now</a> |
| 51  | <a href="#">970950804500</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 53  | <a href="#">973950807000</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 54  | <a href="#">953800860000</a><br>Nut (661)                 | <a href="#">Buy now</a> |

Bracket 2




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 2   | <a href="#">975150621000</a><br>Bolt                         | <a href="#">Buy now</a> |
| 3   | <a href="#">6L2431600000</a><br>Tilt rod assembly            | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2436300000</a><br>Tilt lever assembly          | <a href="#">Buy now</a> |
| 5   | <a href="#">682433180100</a><br>Cover                        | <a href="#">Buy now</a> |
| 6   | <a href="#">903860803200</a><br>Bushing (650)                | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2436820100</a><br>Lever, shallow water drive 2 | <a href="#">Buy now</a> |
| 8   | <a href="#">973950501000</a><br>Bolt (682)                   | <a href="#">Buy now</a> |
| 9   | <a href="#">929900560000</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2431910100</a><br>Shaft, stopper               | <a href="#">Buy now</a> |
| 11  | <a href="#">990800560000</a><br>Circlip(22k)                 | <a href="#">Buy now</a> |
| 12  | <a href="#">9050620M2700</a><br>Spring, tension(6I2)         | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2433500100</a><br>Receiver assembly            | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2436310000</a><br>Lever, tilt                  | <a href="#">Buy now</a> |
| 15  | <a href="#">6L2431880000</a><br>Spring                       | <a href="#">Buy now</a> |
| 16  | <a href="#">6L2436331000</a><br>Cover, tilt lever            | <a href="#">Buy now</a> |

## Bracket 2




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 17  | <a href="#">6L2436110000</a><br>Shaft, tilt lock     | <a href="#">Buy now</a> |
| 18  | <a href="#">6L2436410000</a><br>Lever, tilt          | <a href="#">Buy now</a> |
| 19  | <a href="#">6L2436590000</a><br>Shaft, reverse lock  | <a href="#">Buy now</a> |
| 21  | <a href="#">6L2436170000</a><br>Rod, tilt lock       | <a href="#">Buy now</a> |
| 22  | <a href="#">6L2436130000</a><br>Arm, tilt lock       | <a href="#">Buy now</a> |
| 24  | <a href="#">6L2436240000</a><br>Plate, tilt rock     | <a href="#">Buy now</a> |
| 25  | <a href="#">6L2433360000</a><br>Pin                  | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8436110100</a><br>Shaft, tilt lock     | <a href="#">Buy now</a> |
| 28  | <a href="#">6L2436140000</a><br>Plate, tilt lock     | <a href="#">Buy now</a> |
| 29  | <a href="#">9050812M2800</a><br>Spring, torsion(6l2) | <a href="#">Buy now</a> |
| 30  | <a href="#">9050812M2900</a><br>Spring, torsion(6l2) | <a href="#">Buy now</a> |
| 31  | <a href="#">6L2436150000</a><br>Plate, tilt lock     | <a href="#">Buy now</a> |
| 32  | <a href="#">9050623M1100</a><br>Spring, tension(6l2) | <a href="#">Buy now</a> |
| 33  | <a href="#">6L2436570000</a><br>Spring, lock         | <a href="#">Buy now</a> |
| 34  | <a href="#">6L2436760000</a><br>Hook                 | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2143010100</a><br>Carburetor assembly 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2143020100</a><br>Carburetor assembly 2 | <a href="#">Buy now</a> |
| 3   | <a href="#">6L2143830000</a><br>Body, float chamber   | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2143840000</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2143850000</a><br>Float                 | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5143860100</a><br>Pin, float            | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2143920000</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 8   | <a href="#">985800401000</a><br>Screw, pan head (e56) | <a href="#">Buy now</a> |
| 9   | <a href="#">6L2141570000</a><br>Cover, mixing         | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2143990000</a><br>Gasket                | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2143410000</a><br>Nozzle, main          | <a href="#">Buy now</a> |
| 12  | <a href="#">30X143436300</a><br>Jet, main             | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2143423000</a><br>Jet, pilot (#60)      | <a href="#">Buy now</a> |
| 14  | <a href="#">50M143550000</a><br>Plug                  | <a href="#">Buy now</a> |
| 15  | <a href="#">6L2143230000</a><br>Screw, air adjusting  | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">646142120100</a><br>Spring, pilot adjusting | <a href="#">Buy now</a> |
| 17  | <a href="#">985800401400</a><br>Screw, pan head(ga5)    | <a href="#">Buy now</a> |
| 20  | <a href="#">677143830100</a><br>Screw, drain            | <a href="#">Buy now</a> |
| 21  | <a href="#">6L2143980000</a><br>Gasket                  | <a href="#">Buy now</a> |
| 22  | <a href="#">677244440000</a><br>Screw                   | <a href="#">Buy now</a> |
| 23  | <a href="#">989800400600</a><br>Screw, bind(6l2)        | <a href="#">Buy now</a> |
| 24  | <a href="#">6A0244210100</a><br>Valve, check            | <a href="#">Buy now</a> |
| 25  | <a href="#">953800360000</a><br>Nut (6g8)               | <a href="#">Buy now</a> |
| 26  | <a href="#">6E7143250000</a><br>Screw, pan head         | <a href="#">Buy now</a> |
| 27  | <a href="#">6L2244350000</a><br>Gasket, body 2          | <a href="#">Buy now</a> |
| 28  | <a href="#">6L2244130000</a><br>Body 2                  | <a href="#">Buy now</a> |
| 29  | <a href="#">682244120100</a><br>Body, pump              | <a href="#">Buy now</a> |
| 30  | <a href="#">677244110200</a><br>Diaphragm               | <a href="#">Buy now</a> |
| 31  | <a href="#">677244340200</a><br>Gasket, pump 1          | <a href="#">Buy now</a> |
| 32  | <a href="#">6L2145780000</a><br>Collar & stopper set    | <a href="#">Buy now</a> |

## Control




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2144970000</a><br>Stay, throttle wire           | <a href="#">Buy now</a> |
| 2   | <a href="#">973130602000</a><br>Bolt(7u8)                     | <a href="#">Buy now</a> |
| 3   | <a href="#">953800670000</a><br>Nut                           | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2412130000</a><br>Cam, accel.                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2412830000</a><br>Lever, free accel.            | <a href="#">Buy now</a> |
| 6   | <a href="#">6L2416310000</a><br>Lever, magneto control        | <a href="#">Buy now</a> |
| 7   | <a href="#">6J8421670000</a><br>Spring 1                      | <a href="#">Buy now</a> |
| 8   | <a href="#">6L2421670000</a><br>Spring 1                      | <a href="#">Buy now</a> |
| 9   | <a href="#">973950607500</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 10  | <a href="#">929900660000</a><br>Washer, plain (646)           | <a href="#">Buy now</a> |
| 11  | <a href="#">9038706M1800</a><br>Collar(6L2)                   | <a href="#">Buy now</a> |
| 12  | <a href="#">689421690100</a><br>Joint                         | <a href="#">Buy now</a> |
| 13  | <a href="#">6H1412370000</a><br>Joint, link                   | <a href="#">Buy now</a> |
| 14  | <a href="#">953800560000</a><br>Nut, hexagon (663)            | <a href="#">Buy now</a> |
| 15  | <a href="#">6L2441210000</a><br>Lever, shift rod              | <a href="#">Buy now</a> |

# Control




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 16  | <a href="#">6G1416620194</a><br>Bracket                  | <a href="#">Buy now</a> |
| 17  | <a href="#">970800602000</a><br>Bolt(7u8)                | <a href="#">Buy now</a> |
| 19  | <a href="#">6G1441160100</a><br>Spring                   | <a href="#">Buy now</a> |
| 20  | <a href="#">973950601200</a><br>Bolt(gh1)                | <a href="#">Buy now</a> |
| 22  | <a href="#">6L2441230000</a><br>Arm, shift rod           | <a href="#">Buy now</a> |
| 23  | <a href="#">916903031800</a><br>Pin, spring (6h3)        | <a href="#">Buy now</a> |
| 24  | <a href="#">6L2441430000</a><br>Rod, shift               | <a href="#">Buy now</a> |
| 25  | <a href="#">901700601500</a><br>Connector, shift rod     | <a href="#">Buy now</a> |
| 26  | <a href="#">6L2143680000</a><br>Diaphragm assembly 1     | <a href="#">Buy now</a> |
| 27  | <a href="#">973130600800</a><br>Bolt (fj1)               | <a href="#">Buy now</a> |
| 28  | <a href="#">6L2441220000</a><br>Bushing, shift rod lever | <a href="#">Buy now</a> |
| 30  | <a href="#">6L2421920000</a><br>Rod 2                    | <a href="#">Buy now</a> |
| 31  | <a href="#">902020508800</a><br>Washer, plate (666)      | <a href="#">Buy now</a> |
| 32  | <a href="#">914902001000</a><br>Pin, cotter              | <a href="#">Buy now</a> |
| 33  | <a href="#">6L2441410100</a><br>Link, shift rod          | <a href="#">Buy now</a> |

## Control




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 34  | <a href="#">9010906M2800</a><br>Bolt(6j8)           | <a href="#">Buy now</a> |
| 35  | <a href="#">6L2412120000</a><br>Arm, accel.         | <a href="#">Buy now</a> |
| 36  | <a href="#">6L2441411094</a><br>Link, shift rod     | <a href="#">Buy now</a> |
| 38  | <a href="#">929900560000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 39  | <a href="#">6L2412370000</a><br>Joint, link         | <a href="#">Buy now</a> |
| 40  | <a href="#">6L2412380000</a><br>Joint, link         | <a href="#">Buy now</a> |
| 41  | <a href="#">953800570000</a><br>Nut (656)           | <a href="#">Buy now</a> |

## Crankshaft & Piston




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2114001000</a><br>Crankshaft assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2114120000</a><br>Crank 1                   | <a href="#">Buy now</a> |
| 3   | <a href="#">6L2114220000</a><br>Crank 2                   | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2114320000</a><br>Crank 3                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2114420000</a><br>Crank 4                   | <a href="#">Buy now</a> |
| 6   | <a href="#">93313628U000</a><br>Bearing, Cylinder#13      | <a href="#">Buy now</a> |
| 8   | <a href="#">932104215900</a><br>O-ring (647)              | <a href="#">Buy now</a> |
| 9   | <a href="#">93306305U500</a><br>Bearing(6j8)              | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2116510000</a><br>Rod, connecting           | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2116810000</a><br>Pin, crank 1              | <a href="#">Buy now</a> |
| 12  | <a href="#">93310424W900</a><br>Bearing, cylindrical(6l2) | <a href="#">Buy now</a> |
| 13  | <a href="#">9020924M1500</a><br>Washer(6l2)               | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2115150000</a><br>Seal, labyrinth 1         | <a href="#">Buy now</a> |
| 15  | <a href="#">916903001000</a><br>Pin, spring (663)         | <a href="#">Buy now</a> |
| 16  | <a href="#">6J8115360000</a><br>Gear, drive               | <a href="#">Buy now</a> |

## Crankshaft & Piston




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">902015030600</a><br>Washer plate 648115870000 | <a href="#">Buy now</a> |
| 18  | <a href="#">6L2116360000</a><br>Piston (0.50mm o/s)       | <a href="#">Buy now</a> |
| 19  | <a href="#">6L2116100000</a><br>Piston ring set (std)     | <a href="#">Buy now</a> |
| 20  | <a href="#">648116330000</a><br>Pin,piston                | <a href="#">Buy now</a> |
| 21  | <a href="#">9360218M1200</a><br>Pin, dowel(612)           | <a href="#">Buy now</a> |
| 22  | <a href="#">934502002600</a><br>Clip 6041163400           | <a href="#">Buy now</a> |
| 23  | <a href="#">902011852200</a><br>Washer (656)              | <a href="#">Buy now</a> |
| 24  | <a href="#">6L21539600CA</a><br>Housing, Oil Seal         | <a href="#">Buy now</a> |
| 25  | <a href="#">931022514200</a><br>Oil seal (24.8x38x7-662)  | <a href="#">Buy now</a> |
| 26  | <a href="#">9310113M3700</a><br>Oil seal(6a4)             | <a href="#">Buy now</a> |
| 27  | <a href="#">9321056M8000</a><br>O-ring(6j8)               | <a href="#">Buy now</a> |
| 28  | <a href="#">973950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 29  | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |

## Cylinder & Crankcase




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2W009010EJ</a><br>Crank Cylinder assembly   | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2151001094</a><br>Crankcase assembly        | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5113720000</a><br>Nipple, hose              | <a href="#">Buy now</a> |
| 4   | <a href="#">9044507M1500</a><br>Hose (I390)               | <a href="#">Buy now</a> |
| 5   | <a href="#">904670601600</a><br>Clip (655)                | <a href="#">Buy now</a> |
| 6   | <a href="#">9360410M0300</a><br>Pin, dowel (688)          | <a href="#">Buy now</a> |
| 7   | <a href="#">956120864500</a><br>Bolt, stud(6I2)           | <a href="#">Buy now</a> |
| 8   | <a href="#">902010808600</a><br>Washer (1t1)              | <a href="#">Buy now</a> |
| 9   | <a href="#">953330860000</a><br>Nut(6I2)                  | <a href="#">Buy now</a> |
| 10  | <a href="#">9011908M0700</a><br>Bolt, with washer(63v)    | <a href="#">Buy now</a> |
| 11  | <a href="#">9011906M1400</a><br>Bolt, with washer (677)   | <a href="#">Buy now</a> |
| 12  | <a href="#">6J8113250000</a><br>Anode                     | <a href="#">Buy now</a> |
| 13  | <a href="#">6H3113270094</a><br>Cover, anode              | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3113280000</a><br>Grommet, anode            | <a href="#">Buy now</a> |
| 15  | <a href="#">973130601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |

## Cylinder & Crankcase




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">929900660000</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 17  | <a href="#">6L2111110094</a><br>Head, cylinder 1            | <a href="#">Buy now</a> |
| 18  | <a href="#">6L2111810000</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 19  | <a href="#">6L211191009M</a><br>Cover, cylinder head 1      | <a href="#">Buy now</a> |
| 20  | <a href="#">6L211193A100</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 21  | <a href="#">9011908M2000</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5124110100</a><br>Thermostat                  | <a href="#">Buy now</a> |
| 25  | <a href="#">6H412413001S</a><br>Cover, thermostat           | <a href="#">Buy now</a> |
| 26  | <a href="#">6H4124140000</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 27  | <a href="#">973130602500</a><br>Bolt                        | <a href="#">Buy now</a> |
| 29  | <a href="#">6L241111001S</a><br>Inner cover, exhaust        | <a href="#">Buy now</a> |
| 30  | <a href="#">6L2411120000</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 31  | <a href="#">6L241113009M</a><br>Outer cover, exhaust        | <a href="#">Buy now</a> |
| 32  | <a href="#">676113720000</a><br>Nipple, hose                | <a href="#">Buy now</a> |
| 33  | <a href="#">6L2411140000</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |

## Cylinder & Crankcase




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 34  | <a href="#">970800603000</a><br>Bolt(jf7)              | <a href="#">Buy now</a> |
| 36  | <a href="#">9044510M4000</a><br>Hose (l400)            | <a href="#">Buy now</a> |
| 37  | <a href="#">6L2451130000</a><br>Gasket, upper casing   | <a href="#">Buy now</a> |
| 38  | <a href="#">947020027100</a><br>Plug, spark (br7hs-10) | <a href="#">Buy now</a> |

# Electrical 1




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2855401000</a><br>Cdi Unit Assembly      | <a href="#">Buy now</a> |
| 2   | <a href="#">929900620000</a><br>Ybs66-6 washer, plain  | <a href="#">Buy now</a> |
| 3   | <a href="#">973950603000</a><br>Bolt(jf7)              | <a href="#">Buy now</a> |
| 4   | <a href="#">929900610000</a><br>Washer(6a1)            | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2855420194</a><br>Bracket                | <a href="#">Buy now</a> |
| 6   | <a href="#">970800603000</a><br>Bolt(jf7)              | <a href="#">Buy now</a> |
| 7   | <a href="#">929900660000</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 8   | <a href="#">9010106M1600</a><br>Bolt(6l2)              | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2855701000</a><br>Ignition Coil Assembly | <a href="#">Buy now</a> |
| 11  | <a href="#">973130603000</a><br>Bolt                   | <a href="#">Buy now</a> |
| 14  | <a href="#">904802516100</a><br>Grommet(656)           | <a href="#">Buy now</a> |
| 15  | <a href="#">904650802800</a><br>Clamp (1e6)            | <a href="#">Buy now</a> |
| 16  | <a href="#">970130601200</a><br>Bolt(gh1)              | <a href="#">Buy now</a> |
| 18  | <a href="#">6G1823702000</a><br>Plug cap assembly      | <a href="#">Buy now</a> |
| 19  | <a href="#">970800601200</a><br>Bolt(gh1)              | <a href="#">Buy now</a> |

# Electrical 1




| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 21  | <a href="#">689825600000</a><br>Thermo switch assembly         | <a href="#">Buy now</a> |
| 22  | <a href="#">6J8819600000</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 23  | <a href="#">973950601600</a><br>Bolt, hexagon deep recess      | <a href="#">Buy now</a> |
| 25  | <a href="#">6J8821051000</a><br>Battery cable                  | <a href="#">Buy now</a> |

# Fuel




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 4   | <a href="#">6Y1242600200</a><br>Fuel meter assembly     | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y1242680000</a><br>Gasket, fuel meter      | <a href="#">Buy now</a> |
| 6   | <a href="#">985860501600</a><br>Screw, pan head         | <a href="#">Buy now</a> |
| 7   | <a href="#">6Y1243290000</a><br>Seal                    | <a href="#">Buy now</a> |
| 8   | <a href="#">6Y1246100000</a><br>Cap assembly            | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y1241670000</a><br>Strainer                | <a href="#">Buy now</a> |
| 11  | <a href="#">6Y1243060500</a><br>Fuel pipe comp. 1       | <a href="#">Buy now</a> |
| 12  | <a href="#">9044511M8100</a><br>Hose (I3000)            | <a href="#">Buy now</a> |
| 13  | <a href="#">6Y1243600200</a><br>Primer pump assembly    | <a href="#">Buy now</a> |
| 14  | <a href="#">9044511M0500</a><br>Hose (I1000)            | <a href="#">Buy now</a> |
| 15  | <a href="#">650243515100</a><br>Band 1                  | <a href="#">Buy now</a> |
| 16  | <a href="#">6G1243050000</a><br>Fuel pipe joint comp. 2 | <a href="#">Buy now</a> |
| 17  | <a href="#">932100828700</a><br>O-ring (655)            | <a href="#">Buy now</a> |
| 18  | <a href="#">6Y1243050100</a><br>Fuel pipe joint comp. 2 | <a href="#">Buy now</a> |
| 20  | <a href="#">6G1243040200</a><br>Fuel pipe joint comp. 1 | <a href="#">Buy now</a> |

Fuel




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 21  | <a href="#">973950602000</a><br>Bolt(7u8)              | <a href="#">Buy now</a> |
| 22  | <a href="#">929900660000</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 23  | <a href="#">6H4243110000</a><br>Pipe 1                 | <a href="#">Buy now</a> |
| 24  | <a href="#">9044509M2500</a><br>Hose (l1500)           | <a href="#">Buy now</a> |
| 25  | <a href="#">904670800400</a><br>Clip, pipe 6162435600  | <a href="#">Buy now</a> |
| 26  | <a href="#">61N245601000</a><br>Filter assembly        | <a href="#">Buy now</a> |
| 27  | <a href="#">6F5245630000</a><br>Element, filter        | <a href="#">Buy now</a> |
| 28  | <a href="#">9321037M2500</a><br>O-ring (655)           | <a href="#">Buy now</a> |
| 30  | <a href="#">6L2245660000</a><br>Bracket, filter        | <a href="#">Buy now</a> |
| 31  | <a href="#">970130601200</a><br>Bolt(gh1)              | <a href="#">Buy now</a> |
| 32  | <a href="#">988800810000</a><br>Nut, hex.              | <a href="#">Buy now</a> |
| 33  | <a href="#">929900810000</a><br>Ybs67-8 washer, spring | <a href="#">Buy now</a> |
| 34  | <a href="#">656W28100100</a><br>Tool kit               | <a href="#">Buy now</a> |

# Intake




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2136100000</a><br>Reed valve assembly   | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2W00040000</a><br>Reed set              | <a href="#">Buy now</a> |
| 3   | <a href="#">985800501600</a><br>Screw, pan head(6b0)  | <a href="#">Buy now</a> |
| 4   | <a href="#">929900560000</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2136411000</a><br>Manifold 1            | <a href="#">Buy now</a> |
| 6   | <a href="#">676144850000</a><br>Pipe, joint           | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2136210000</a><br>Gasket, valve seat    | <a href="#">Buy now</a> |
| 8   | <a href="#">9010106M2700</a><br>Bolt                  | <a href="#">Buy now</a> |
| 9   | <a href="#">929900660000</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 10  | <a href="#">904450906100</a><br>Hose (L65)            | <a href="#">Buy now</a> |
| 11  | <a href="#">904670800400</a><br>Clip, pipe 6162435600 | <a href="#">Buy now</a> |
| 12  | <a href="#">6L2141980000</a><br>Gasket                | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2144170000</a><br>Cover 1               | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2144760000</a><br>Seal                  | <a href="#">Buy now</a> |
| 15  | <a href="#">9321035M8600</a><br>O-ring(6I2)           | <a href="#">Buy now</a> |

Intake




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">973130501200</a><br>Bolt, hexagon        | <a href="#">Buy now</a> |
| 18  | <a href="#">973900608500</a><br>Bolt, with washer    | <a href="#">Buy now</a> |
| 20  | <a href="#">6L2144761100</a><br>Seal                 | <a href="#">Buy now</a> |
| 21  | <a href="#">6L2144180000</a><br>Cover 2              | <a href="#">Buy now</a> |
| 22  | <a href="#">978860501600</a><br>Screw, pan head(6b0) | <a href="#">Buy now</a> |
| 24  | <a href="#">6J8412590000</a><br>Rod, choke 3         | <a href="#">Buy now</a> |
| 25  | <a href="#">661412620200</a><br>Joint, choke lever   | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8412710100</a><br>Knob, choke          | <a href="#">Buy now</a> |
| 27  | <a href="#">6L2412570000</a><br>Rod, choke 2         | <a href="#">Buy now</a> |
| 28  | <a href="#">6L2412170000</a><br>Rod, accel. lever    | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 3   | <a href="#">933320000500</a><br>Brg,cyl-cal roller 0.19g nt | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2455670010</a><br>Shim (t:1.0mm)              | <a href="#">Buy now</a> |
| 5   | <a href="#">93315220V900</a><br>Bearing, cylindrical(6l2)   | <a href="#">Buy now</a> |
| 6   | <a href="#">6L2455360000</a><br>Sleeve, drive shaft         | <a href="#">Buy now</a> |
| 7   | <a href="#">9034008M0400</a><br>Plug, straight screw        | <a href="#">Buy now</a> |
| 8   | <a href="#">903400800200</a><br>Plug, straight screw        | <a href="#">Buy now</a> |
| 9   | <a href="#">6L2443110000</a><br>Housing, water pump         | <a href="#">Buy now</a> |
| 10  | <a href="#">932104516100</a><br>O-ring                      | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2443220000</a><br>Insert, cartridge           | <a href="#">Buy now</a> |
| 12  | <a href="#">6L2443230000</a><br>Outer plate, cartridge      | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2443520000</a><br>Impeller                    | <a href="#">Buy now</a> |
| 14  | <a href="#">973950604000</a><br>Bolt (682)                  | <a href="#">Buy now</a> |
| 15  | <a href="#">929900660000</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 16  | <a href="#">6L2443280000</a><br>Plate                       | <a href="#">Buy now</a> |
| 17  | <a href="#">6L245331005B</a><br>Housing, bearing            | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 18  | <a href="#">933152200400</a><br>Brg,cyl-cal roller 21g nt | <a href="#">Buy now</a> |
| 19  | <a href="#">931022048400</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 20  | <a href="#">6L2441470000</a><br>Boot, shift rod           | <a href="#">Buy now</a> |
| 21  | <a href="#">9360410M0300</a><br>Pin, dowel (688)          | <a href="#">Buy now</a> |
| 22  | <a href="#">6L2453150000</a><br>Packing,lower casing      | <a href="#">Buy now</a> |
| 23  | <a href="#">970800602000</a><br>Bolt(7u8)                 | <a href="#">Buy now</a> |
| 25  | <a href="#">6L2453750000</a><br>Damper, seal              | <a href="#">Buy now</a> |
| 26  | <a href="#">6L2455101000</a><br>Drive shaft assembly      | <a href="#">Buy now</a> |
| 27  | <a href="#">902800302400</a><br>Key, woodruff(662)        | <a href="#">Buy now</a> |
| 28  | <a href="#">6L2455510100</a><br>Pinion                    | <a href="#">Buy now</a> |
| 29  | <a href="#">9017910M1400</a><br>Nut(6j8)                  | <a href="#">Buy now</a> |
| 30  | <a href="#">93341320U000</a><br>Bearing, thrust (6l2)     | <a href="#">Buy now</a> |
| 31  | <a href="#">6L2455871000</a><br>Shim (t:1.6mm)            | <a href="#">Buy now</a> |
| 32  | <a href="#">6L2455600000</a><br>Gear                      | <a href="#">Buy now</a> |
| 33  | <a href="#">6L2455710000</a><br>Gear                      | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 34  | <a href="#">902012041700</a><br>Washer, plate(663)             | <a href="#">Buy now</a> |
| 35  | <a href="#">6L2455773000</a><br>Shim (t:1.3mm)                 | <a href="#">Buy now</a> |
| 36  | <a href="#">6L2456110000</a><br>Shaft, propeller               | <a href="#">Buy now</a> |
| 37  | <a href="#">905011006500</a><br>Spring compression648456360000 | <a href="#">Buy now</a> |
| 38  | <a href="#">6L2456310000</a><br>Clutch, dog                    | <a href="#">Buy now</a> |
| 39  | <a href="#">902500501000</a><br>Pin straight 648456320000      | <a href="#">Buy now</a> |
| 40  | <a href="#">648456330000</a><br>Ring, cross pin                | <a href="#">Buy now</a> |
| 43  | <a href="#">933060061200</a><br>Bearing(2hr)                   | <a href="#">Buy now</a> |
| 44  | <a href="#">9321060MA300</a><br>O-ring(6j8)                    | <a href="#">Buy now</a> |
| 46  | <a href="#">9310120M0700</a><br>Oil seal                       | <a href="#">Buy now</a> |
| 47  | <a href="#">973950602000</a><br>Bolt(7u8)                      | <a href="#">Buy now</a> |
| 49  | <a href="#">6L2441500000</a><br>Shift cam assembly             | <a href="#">Buy now</a> |

## Lower Casing & Drive 2




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2443680000</a><br>Rubber, water seal 4      | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2443610000</a><br>Tube, water               | <a href="#">Buy now</a> |
| 3   | <a href="#">6L2443660000</a><br>Damper, water seal 2      | <a href="#">Buy now</a> |
| 4   | <a href="#">9360410M0300</a><br>Pin, dowel (688)          | <a href="#">Buy now</a> |
| 5   | <a href="#">9010510M1200</a><br>Bolt (689)                | <a href="#">Buy now</a> |
| 6   | <a href="#">929901060000</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 7   | <a href="#">664453710100</a><br>Tab-trim                  | <a href="#">Buy now</a> |
| 8   | <a href="#">9010508M0200</a><br>Bolt hexagon              | <a href="#">Buy now</a> |
| 9   | <a href="#">6L2443670000</a><br>Damper, water seal 3      | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2452140000</a><br>Cover, water inlet        | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2452150000</a><br>Cover, water inlet        | <a href="#">Buy now</a> |
| 12  | <a href="#">986800503000</a><br>Ybs53-530 screw,flat head | <a href="#">Buy now</a> |
| 13  | <a href="#">901850500200</a><br>Nut nylon (sus)(ex4)      | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2459870100</a><br>Spacer                    | <a href="#">Buy now</a> |
| 15  | <a href="#">689459970000</a><br>Spacer                    | <a href="#">Buy now</a> |

## Lower Casing & Drive 2




| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 16  | <a href="#">929901420000</a><br>Washer, plain                  | <a href="#">Buy now</a> |
| 17  | <a href="#">901711401300</a><br>Nut(664)                       | <a href="#">Buy now</a> |
| 18  | <a href="#">914903003000</a><br>Pin, cotter                    | <a href="#">Buy now</a> |
| 19  | <a href="#">664459720000</a><br>Propeller (3x9-1/8 x12 -f)     | <a href="#">Buy now</a> |
| 20  | <a href="#">6J8W459100EL</a><br>Propeller (3x10-5/8"x8-1/4"-f) | <a href="#">Buy now</a> |
| 21  | <a href="#">6J8459861000</a><br>Ring, deflector                | <a href="#">Buy now</a> |

# Magneto




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 7   | <a href="#">985010501000</a><br>Screw, pan head(62x)     | <a href="#">Buy now</a> |
| 8   | <a href="#">978850501000</a><br>Screw, pan head(62x)     | <a href="#">Buy now</a> |
| 9   | <a href="#">985030502500</a><br>Screw, panhead (a93)     | <a href="#">Buy now</a> |
| 10  | <a href="#">929900510000</a><br>Ybs67-5 washer, spring   | <a href="#">Buy now</a> |
| 11  | <a href="#">6G1855487000</a><br>Cord, clamp              | <a href="#">Buy now</a> |
| 12  | <a href="#">978020400800</a><br>Screw, pan head (713)    | <a href="#">Buy now</a> |
| 13  | <a href="#">929020410000</a><br>Ybs67-4 washer, spring   | <a href="#">Buy now</a> |
| 14  | <a href="#">663855180000</a><br>Joint, ball              | <a href="#">Buy now</a> |
| 15  | <a href="#">902800501300</a><br>Key, woodruff            | <a href="#">Buy now</a> |
| 16  | <a href="#">9017912M0400</a><br>Nut, flange              | <a href="#">Buy now</a> |
| 17  | <a href="#">9020113M4200</a><br>Washer (694)             | <a href="#">Buy now</a> |
| 18  | <a href="#">6G1416110000</a><br>Retainer, magneto base 1 | <a href="#">Buy now</a> |
| 19  | <a href="#">695416130000</a><br>Plate, base friction     | <a href="#">Buy now</a> |
| 20  | <a href="#">970130601200</a><br>Bolt(gh1)                | <a href="#">Buy now</a> |
| 21  | <a href="#">929900660000</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |

# Magneto




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 22  | <a href="#">6G1416120000</a><br>Retainer, magneto base | <a href="#">Buy now</a> |
| 23  | <a href="#">979850521000</a><br>Screw, With Washer     | <a href="#">Buy now</a> |
| 24  | <a href="#">6L2813320000</a><br>Plate, timing          | <a href="#">Buy now</a> |
| 26  | <a href="#">6L2825990000</a><br>Cover, connector       | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">9020108M9300</a><br>Washer, plate (6g5)         | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2115370000</a><br>Gear, driven                | <a href="#">Buy now</a> |
| 3   | <a href="#">6J8131170000</a><br>Collar, distance            | <a href="#">Buy now</a> |
| 4   | <a href="#">932101359500</a><br>93210-13m04                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2132000000</a><br>Oil injection pump assembly | <a href="#">Buy now</a> |
| 6   | <a href="#">6L2134710000</a><br>Plug, drain                 | <a href="#">Buy now</a> |
| 7   | <a href="#">1YU131870000</a><br>Gasket, breather bolt       | <a href="#">Buy now</a> |
| 8   | <a href="#">9321019M8200</a><br>O-ring(6j8)                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9010905M3300</a><br>Bolt                        | <a href="#">Buy now</a> |
| 11  | <a href="#">9044507M5100</a><br>Hose (l200)                 | <a href="#">Buy now</a> |
| 12  | <a href="#">9046807M0200</a><br>Clip (6e5)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6E9131837000</a><br>Valve check                 | <a href="#">Buy now</a> |
| 14  | <a href="#">9044507M0400</a><br>Hose(62t)                   | <a href="#">Buy now</a> |
| 16  | <a href="#">9044507M1600</a><br>Hose(62t)                   | <a href="#">Buy now</a> |
| 17  | <a href="#">682412375000</a><br>Joint, link 2               | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 18  | <a href="#">6H1412370000</a><br>Joint, link            | <a href="#">Buy now</a> |
| 19  | <a href="#">953800570000</a><br>Nut (656)              | <a href="#">Buy now</a> |
| 20  | <a href="#">902020508800</a><br>Washer, plate (666)    | <a href="#">Buy now</a> |
| 21  | <a href="#">9046805M0300</a><br>Clip(6j8)              | <a href="#">Buy now</a> |
| 22  | <a href="#">6L2217070100</a><br>Oil tank comp.         | <a href="#">Buy now</a> |
| 23  | <a href="#">6H4217700000</a><br>Oil tank cap assembly  | <a href="#">Buy now</a> |
| 24  | <a href="#">6L2217580000</a><br>Washer, special 2      | <a href="#">Buy now</a> |
| 26  | <a href="#">6H1217570000</a><br>Washer, special 1      | <a href="#">Buy now</a> |
| 27  | <a href="#">6J8134110000</a><br>Strainer, oil          | <a href="#">Buy now</a> |
| 28  | <a href="#">6J8134140000</a><br>Gasket, strainer cover | <a href="#">Buy now</a> |
| 29  | <a href="#">6L2134160000</a><br>Pipe, oil 1            | <a href="#">Buy now</a> |
| 30  | <a href="#">904670800400</a><br>Clip, pipe 6162435600  | <a href="#">Buy now</a> |
| 31  | <a href="#">9046711M0800</a><br>Clip(72x)              | <a href="#">Buy now</a> |
| 32  | <a href="#">9044511M1500</a><br>Hose (I360)            | <a href="#">Buy now</a> |
| 33  | <a href="#">9044511M0700</a><br>Hose (I70)             | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 34  | <a href="#">6J8217440000</a><br>Breather                  | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5243761000</a><br>Pipe, joint 1             | <a href="#">Buy now</a> |
| 36  | <a href="#">9046710M0400</a><br>Clip, pipe 1 (6e9)        | <a href="#">Buy now</a> |
| 37  | <a href="#">9046411M2400</a><br>Clamp(6h1)                | <a href="#">Buy now</a> |
| 38  | <a href="#">9044610M0200</a><br>Tube (6e5)                | <a href="#">Buy now</a> |
| 39  | <a href="#">6A0823170000</a><br>Damper, ignition coil     | <a href="#">Buy now</a> |
| 40  | <a href="#">624425420000</a><br>Collar                    | <a href="#">Buy now</a> |
| 41  | <a href="#">9011906M9500</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 42  | <a href="#">6L2217980000</a><br>Bracket, damper           | <a href="#">Buy now</a> |
| 43  | <a href="#">973130601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 44  | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 45  | <a href="#">6L2857200200</a><br>Oil level gauge assembly  | <a href="#">Buy now</a> |

## Optional Parts 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">689825500100</a><br>Stop switch assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">689825751200</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 3   | <a href="#">682825560000</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 4   | <a href="#">689825532000</a><br>Extension, wire lead        | <a href="#">Buy now</a> |
| 5   | <a href="#">689427254000</a><br>Grommet                     | <a href="#">Buy now</a> |
| 6   | <a href="#">689825501100</a><br>Stop switch assembly        | <a href="#">Buy now</a> |
| 9   | <a href="#">6G1819706100</a><br>Rectifier assembly          | <a href="#">Buy now</a> |
| 10  | <a href="#">6G1821510000</a><br>Fuse (10a)                  | <a href="#">Buy now</a> |
| 11  | <a href="#">985030502500</a><br>Screw, panhead (a93)        | <a href="#">Buy now</a> |
| 12  | <a href="#">929900560000</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 13  | <a href="#">663819101000</a><br>Voltage Regulator assembly  | <a href="#">Buy now</a> |

## Optional Parts 2




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">689825701500</a><br>Panel switch assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">689825100000</a><br>Main switch assembly        | <a href="#">Buy now</a> |
| 3   | <a href="#">703825740000</a><br>Switch, choke               | <a href="#">Buy now</a> |
| 4   | <a href="#">688825750200</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 5   | <a href="#">682825560000</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 6   | <a href="#">689825710200</a><br>Panel, Switch               | <a href="#">Buy now</a> |
| 7   | <a href="#">663825810100</a><br>Stay, cord clamp            | <a href="#">Buy now</a> |
| 8   | <a href="#">983030400800</a><br>Screw, pan head (713)       | <a href="#">Buy now</a> |
| 9   | <a href="#">929010410000</a><br>Ybs67-4 washer, spring      | <a href="#">Buy now</a> |
| 10  | <a href="#">9014905M0500</a><br>Screw(6k0)                  | <a href="#">Buy now</a> |
| 11  | <a href="#">953800560000</a><br>Nut, hexagon (663)          | <a href="#">Buy now</a> |
| 12  | <a href="#">929900510000</a><br>Ybs67-5 washer, spring      | <a href="#">Buy now</a> |
| 13  | <a href="#">929900560000</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 14  | <a href="#">688825865000</a><br>Extension, wire harness     | <a href="#">Buy now</a> |
| 15  | <a href="#">688825861100</a><br>Extension, wire harness     | <a href="#">Buy now</a> |

## Optional Parts 2




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">688825401200</a><br>Neutral switch assembly | <a href="#">Buy now</a> |
| 17  | <a href="#">6L2825540000</a><br>Stay, neutral switch    | <a href="#">Buy now</a> |
| 18  | <a href="#">970130601200</a><br>Bolt(gh1)               | <a href="#">Buy now</a> |
| 19  | <a href="#">929900610000</a><br>Washer(6a1)             | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 2   | <a href="#">6Y5835401200</a><br>Tachometer assembly                | <a href="#">Buy now</a> |
| 3   | <a href="#">688835160000</a><br>Bulb, pilot (t6.5, 12v-1.7w)       | <a href="#">Buy now</a> |
| 4   | <a href="#">688835360000</a><br>Socket, meter                      | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y5835230000</a><br>Damper                             | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y5835140000</a><br>Plate, fitting                     | <a href="#">Buy now</a> |
| 7   | <a href="#">6Y5835530000</a><br>Wire, lead (l=2.5m)                | <a href="#">Buy now</a> |
| 8   | <a href="#">1E6821510000</a><br>Fuse (10a)                         | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y5W00814000</a><br>Speedometer Kit                    | <a href="#">Buy now</a> |
| 10  | <a href="#">6Y5835103000</a><br>Speedometer assembly (km/h,knots,m | <a href="#">Buy now</a> |
| 12  | <a href="#">6Y5835361000</a><br>Socket, meter                      | <a href="#">Buy now</a> |
| 15  | <a href="#">688835570000</a><br>Tube (8m)                          | <a href="#">Buy now</a> |
| 16  | <a href="#">904651009800</a><br>Clamp                              | <a href="#">Buy now</a> |
| 17  | <a href="#">688835560100</a><br>Sender (with hose l:6m/d:4mm)      | <a href="#">Buy now</a> |
| 18  | <a href="#">906013140200</a><br>021-58119-01 clip,nylon 14         | <a href="#">Buy now</a> |
| 19  | <a href="#">977804011600</a><br>Screw,panh.tapping                 | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 20  | <a href="#">6Y5W00883100</a><br>Hour meter kit                   | <a href="#">Buy now</a> |
| 21  | <a href="#">6Y5835040100</a><br>Hour meter assembly              | <a href="#">Buy now</a> |
| 22  | <a href="#">688836640000</a><br>Damper                           | <a href="#">Buy now</a> |
| 23  | <a href="#">6Y5835770000</a><br>Plate, fitting                   | <a href="#">Buy now</a> |
| 24  | <a href="#">3FV835170000</a><br>Bulb (12v-1.7w) t6.5             | <a href="#">Buy now</a> |
| 25  | <a href="#">6Y5835360000</a><br>Socket, meter                    | <a href="#">Buy now</a> |
| 26  | <a href="#">66383553A000</a><br>Wire, lead                       | <a href="#">Buy now</a> |
| 27  | <a href="#">66383553Y000</a><br>Wire, lead                       | <a href="#">Buy now</a> |
| 28  | <a href="#">6Y5W00882000</a><br>Fuel meter kit                   | <a href="#">Buy now</a> |
| 33  | <a href="#">6Y5835440000</a><br>Plate, fitting                   | <a href="#">Buy now</a> |
| 34  | <a href="#">688857520100</a><br>Sender unit assembly, fuel meter | <a href="#">Buy now</a> |

## Optional Parts 4




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">688833831100</a><br>Buzzer                       | <a href="#">Buy now</a> |
| 2   | <a href="#">977806051600</a><br>Screw, panhead tapping (j20) | <a href="#">Buy now</a> |
| 3   | <a href="#">929900560000</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |
| 4   | <a href="#">688833731000</a><br>Lead, horn                   | <a href="#">Buy now</a> |
| 6   | <a href="#">663843010100</a><br>Pilot lamp ass'y             | <a href="#">Buy now</a> |
| 7   | <a href="#">663843090000</a><br>Plate set                    | <a href="#">Buy now</a> |
| 8   | <a href="#">954283131600</a><br>Screw, round tapping         | <a href="#">Buy now</a> |
| 10  | <a href="#">977806052000</a><br>Screw, tapping(6k8)          | <a href="#">Buy now</a> |
| 11  | <a href="#">929900660000</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |
| 12  | <a href="#">663825210900</a><br>Wire, Lead                   | <a href="#">Buy now</a> |
| 13  | <a href="#">688825200000</a><br>Lamp switch assembly         | <a href="#">Buy now</a> |
| 14  | <a href="#">688825260000</a><br>Switch, lamp                 | <a href="#">Buy now</a> |
| 15  | <a href="#">6Y5821490000</a><br>Wire, lead 3                 | <a href="#">Buy now</a> |
| 16  | <a href="#">6Y5821170000</a><br>Wire, lead                   | <a href="#">Buy now</a> |
| 17  | <a href="#">6Y5825210000</a><br>Wire, lead                   | <a href="#">Buy now</a> |

## Optional Parts 4




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 18  | <a href="#">6Y5835530000</a><br>Wire, lead (l=2.5m) | <a href="#">Buy now</a> |
| 19  | <a href="#">1E6821510000</a><br>Fuse (10a)          | <a href="#">Buy now</a> |

## Remo Con Attachment




| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2485011100</a><br>Remote cont. attachment assembly. | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2485440100</a><br>Lever, shiftcontrol               | <a href="#">Buy now</a> |
| 3   | <a href="#">6L2485340100</a><br>Throttle lever, control           | <a href="#">Buy now</a> |
| 4   | <a href="#">903861000900</a><br>Bushing 6484418600                | <a href="#">Buy now</a> |
| 5   | <a href="#">957800830000</a><br>Nut, nylon (6j8)                  | <a href="#">Buy now</a> |
| 6   | <a href="#">6L2421540100</a><br>Lever, throttle control           | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2421910100</a><br>Rod 1                             | <a href="#">Buy now</a> |
| 8   | <a href="#">6L2421922000</a><br>Rod 2                             | <a href="#">Buy now</a> |
| 10  | <a href="#">914902001000</a><br>Pin, cotter                       | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2485310000</a><br>Bracket, remote control 1         | <a href="#">Buy now</a> |
| 12  | <a href="#">682485385000</a><br>Clamp, cable                      | <a href="#">Buy now</a> |
| 13  | <a href="#">916903001200</a><br>Pin, spring                       | <a href="#">Buy now</a> |
| 14  | <a href="#">9010506M2300</a><br>Bolt (6g1)                        | <a href="#">Buy now</a> |
| 15  | <a href="#">6G8263630000</a><br>End, wire 1                       | <a href="#">Buy now</a> |
| 16  | <a href="#">6G8263640000</a><br>End, wire 2                       | <a href="#">Buy now</a> |

## Remo Con Attachment




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">6L2485110000</a><br>Hook, steering            | <a href="#">Buy now</a> |
| 18  | <a href="#">901851002700</a><br>Nut, self-locking         | <a href="#">Buy now</a> |
| 19  | <a href="#">929901060000</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 20  | <a href="#">973951004000</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |

## Remote Control




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703482301100</a><br>Remote control assembly (7p) | <a href="#">Buy now</a> |
| 2   | <a href="#">703482201100</a><br>Remote control assembly (7p) | <a href="#">Buy now</a> |
| 3   | <a href="#">701483200000</a><br>Cable, Remote Control L=12F  | <a href="#">Buy now</a> |
| 4   | <a href="#">703482900100</a><br>Twin attachment              | <a href="#">Buy now</a> |

## Remote Control Assy 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703482301100</a><br>Remote control assembly (7p) | <a href="#">Buy now</a> |
| 2   | <a href="#">703482611000</a><br>Arm, throttle                | <a href="#">Buy now</a> |
| 3   | <a href="#">703481530000</a><br>Shaft, free accel.           | <a href="#">Buy now</a> |
| 4   | <a href="#">703482350000</a><br>Bushing                      | <a href="#">Buy now</a> |
| 5   | <a href="#">703482730000</a><br>Bushing                      | <a href="#">Buy now</a> |
| 7   | <a href="#">703482680000</a><br>Spacer 3                     | <a href="#">Buy now</a> |
| 8   | <a href="#">703482630000</a><br>Bushing                      | <a href="#">Buy now</a> |
| 9   | <a href="#">703482640000</a><br>Throttle, friction           | <a href="#">Buy now</a> |
| 10  | <a href="#">953800560000</a><br>Nut, hexagon (663)           | <a href="#">Buy now</a> |
| 12  | <a href="#">703482650000</a><br>Shaft Friction               | <a href="#">Buy now</a> |
| 13  | <a href="#">934300602400</a><br>Circlip (701)                | <a href="#">Buy now</a> |
| 14  | <a href="#">703482450000</a><br>Plate, lock                  | <a href="#">Buy now</a> |
| 15  | <a href="#">703482520000</a><br>Roller, cam                  | <a href="#">Buy now</a> |
| 16  | <a href="#">701482480000</a><br>Roller, free accel           | <a href="#">Buy now</a> |
| 17  | <a href="#">703481980000</a><br>Washer, wave 3               | <a href="#">Buy now</a> |

## Remote Control Assy 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 19  | <a href="#">703482360000</a><br>Bushing                     | <a href="#">Buy now</a> |
| 20  | <a href="#">703481890000</a><br>Retainer                    | <a href="#">Buy now</a> |
| 21  | <a href="#">703482340000</a><br>Roller, detent              | <a href="#">Buy now</a> |
| 22  | <a href="#">703483450100</a><br>Cable end, remote control 2 | <a href="#">Buy now</a> |
| 23  | <a href="#">703483580000</a><br>Anchor, cable               | <a href="#">Buy now</a> |
| 24  | <a href="#">703482440000</a><br>Spring, free accel.         | <a href="#">Buy now</a> |
| 25  | <a href="#">703482380000</a><br>Spring, detent              | <a href="#">Buy now</a> |
| 26  | <a href="#">703482460000</a><br>Spacer 1                    | <a href="#">Buy now</a> |
| 27  | <a href="#">703482270000</a><br>Spring, neutral lock        | <a href="#">Buy now</a> |
| 28  | <a href="#">703825940000</a><br>Clamp                       | <a href="#">Buy now</a> |
| 29  | <a href="#">703482260000</a><br>Plate, stopper              | <a href="#">Buy now</a> |
| 30  | <a href="#">703482220000</a><br>Grip, control lever         | <a href="#">Buy now</a> |
| 31  | <a href="#">703482230000</a><br>Lock, neutral               | <a href="#">Buy now</a> |
| 32  | <a href="#">703482250000</a><br>Cover                       | <a href="#">Buy now</a> |
| 33  | <a href="#">703482190000</a><br>Cover, lead                 | <a href="#">Buy now</a> |

## Remote Control Assy 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 34  | <a href="#">987800501200</a><br>Screw(617)                | <a href="#">Buy now</a> |
| 35  | <a href="#">987800501600</a><br>Ybs53-516 screw,flat head | <a href="#">Buy now</a> |
| 36  | <a href="#">973950803000</a><br>Bolt, hexagon (fj1)       | <a href="#">Buy now</a> |
| 37  | <a href="#">929900860000</a><br>Washer, plain (663)       | <a href="#">Buy now</a> |
| 38  | <a href="#">985800401000</a><br>Screw, pan head (e56)     | <a href="#">Buy now</a> |
| 39  | <a href="#">985800400600</a><br>Screw, pan head (7h3)     | <a href="#">Buy now</a> |
| 40  | <a href="#">985800501000</a><br>Screw, pan head(62x)      | <a href="#">Buy now</a> |
| 41  | <a href="#">985800301400</a><br>Screw, pan head (n151)    | <a href="#">Buy now</a> |
| 42  | <a href="#">926800609000</a><br>Screw                     | <a href="#">Buy now</a> |
| 43  | <a href="#">953800660000</a><br>Nut(661)                  | <a href="#">Buy now</a> |
| 44  | <a href="#">703482931000</a><br>Spacer, remote control    | <a href="#">Buy now</a> |
| 45  | <a href="#">701482870000</a><br>Washer 1                  | <a href="#">Buy now</a> |
| 46  | <a href="#">703482150000</a><br>Graphic                   | <a href="#">Buy now</a> |
| 48  | <a href="#">703825101800</a><br>Main Switch               | <a href="#">Buy now</a> |
| 49  | <a href="#">703825310000</a><br>Wire, lead                | <a href="#">Buy now</a> |

## Remote Control Assy 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 50  | <a href="#">703825740000</a><br>Switch, choke               | <a href="#">Buy now</a> |
| 51  | <a href="#">688825750100</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 52  | <a href="#">682825560000</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 53  | <a href="#">688825862100</a><br>Extension, wire harness     | <a href="#">Buy now</a> |
| 54  | <a href="#">703825400000</a><br>Neutral switch assembly     | <a href="#">Buy now</a> |
| 55  | <a href="#">703833830100</a><br>Buzzer                      | <a href="#">Buy now</a> |
| 56  | <a href="#">703482840000</a><br>Grommet                     | <a href="#">Buy now</a> |
| 57  | <a href="#">904651316900</a><br>Band                        | <a href="#">Buy now</a> |
| 58  | <a href="#">80L263970000</a><br>Band                        | <a href="#">Buy now</a> |
| 59  | <a href="#">703482240000</a><br>Cover, control lever        | <a href="#">Buy now</a> |
| 60  | <a href="#">703482210000</a><br>Grip                        | <a href="#">Buy now</a> |

# Repair Kit 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2W00010100</a><br>Gasket kit                  | <a href="#">Buy now</a> |
| 2   | <a href="#">931022514200</a><br>Oil seal (24.8x38x7-662)    | <a href="#">Buy now</a> |
| 3   | <a href="#">9310113M3700</a><br>Oil seal(6a4)               | <a href="#">Buy now</a> |
| 4   | <a href="#">9321056M8000</a><br>O-ring(6j8)                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2111810000</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 6   | <a href="#">6L211193A100</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 7   | <a href="#">6H4124140000</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 8   | <a href="#">6L2411140000</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |
| 9   | <a href="#">6L241112A300</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 10  | <a href="#">9310226M2700</a><br>Oil seal(6j8)               | <a href="#">Buy now</a> |
| 11  | <a href="#">932104215900</a><br>O-ring (647)                | <a href="#">Buy now</a> |
| 12  | <a href="#">6L2136210000</a><br>Gasket, valve seat          | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2143840000</a><br>Gasket, float chamber       | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2141980000</a><br>Gasket                      | <a href="#">Buy now</a> |
| 15  | <a href="#">9321037M2500</a><br>O-ring (655)                | <a href="#">Buy now</a> |

## Repair Kit 1




| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6L2451130000</a><br>Gasket, upper casing       | <a href="#">Buy now</a> |
| 17  | <a href="#">6L2411330000</a><br>Gasket, exhaust manifold 1 | <a href="#">Buy now</a> |
| 18  | <a href="#">6L2W00930000</a><br>Carburetor repair kit      | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5143860100</a><br>Pin, float                 | <a href="#">Buy now</a> |
| 23  | <a href="#">6L2143920000</a><br>Valve, needle              | <a href="#">Buy now</a> |
| 24  | <a href="#">6L2143990000</a><br>Gasket                     | <a href="#">Buy now</a> |
| 25  | <a href="#">985800401200</a><br>Screw, pan head (686)      | <a href="#">Buy now</a> |
| 26  | <a href="#">929030410000</a><br>Ybs67-4 washer, spring     | <a href="#">Buy now</a> |
| 27  | <a href="#">6L2143980000</a><br>Gasket                     | <a href="#">Buy now</a> |

## Repair Kit 2




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2W00012200</a><br>Gasket kit               | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2411340000</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 3   | <a href="#">904300802000</a><br>Gasket                   | <a href="#">Buy now</a> |
| 4   | <a href="#">932104516100</a><br>O-ring                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6L2443670000</a><br>Damper, water seal 3     | <a href="#">Buy now</a> |
| 6   | <a href="#">931012004800</a><br>Oil seal (20x30x6-648)   | <a href="#">Buy now</a> |
| 7   | <a href="#">6L245315A000</a><br>Packing, lower casing    | <a href="#">Buy now</a> |
| 8   | <a href="#">9321060MA300</a><br>O-ring(6j8)              | <a href="#">Buy now</a> |
| 9   | <a href="#">9310120M0700</a><br>Oil seal                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6L2W00780000</a><br>Water pump repair kit    | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2443230000</a><br>Outer plate, cartridge   | <a href="#">Buy now</a> |
| 13  | <a href="#">6L2443520000</a><br>Impeller                 | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2443220000</a><br>Insert, cartridge        | <a href="#">Buy now</a> |
| 15  | <a href="#">973950604000</a><br>Bolt (682)               | <a href="#">Buy now</a> |
| 16  | <a href="#">902800302400</a><br>Key, woodruff(662)       | <a href="#">Buy now</a> |

# Starter




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6L2157100100</a><br>Starter assembly          | <a href="#">Buy now</a> |
| 2   | <a href="#">6L2157110094</a><br>Case, starter             | <a href="#">Buy now</a> |
| 3   | <a href="#">916904001400</a><br>Pin, spring (6f2)         | <a href="#">Buy now</a> |
| 4   | <a href="#">6L2157580094</a><br>Guide, rope               | <a href="#">Buy now</a> |
| 5   | <a href="#">970950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 6   | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 7   | <a href="#">6L2157620000</a><br>Seal, rubber 2            | <a href="#">Buy now</a> |
| 8   | <a href="#">689157550100</a><br>Handle, starter           | <a href="#">Buy now</a> |
| 9   | <a href="#">6F5157790200</a><br>Cover                     | <a href="#">Buy now</a> |
| 11  | <a href="#">6J8157140000</a><br>Drum, sheave              | <a href="#">Buy now</a> |
| 12  | <a href="#">9051008M0400</a><br>Spring, spiral (677)      | <a href="#">Buy now</a> |
| 13  | <a href="#">677157170100</a><br>Shaft                     | <a href="#">Buy now</a> |
| 14  | <a href="#">902010606000</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 15  | <a href="#">973130602500</a><br>Bolt                      | <a href="#">Buy now</a> |
| 16  | <a href="#">953800670000</a><br>Nut                       | <a href="#">Buy now</a> |

# Starter




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">676157410300</a><br>Pawl, drive               | <a href="#">Buy now</a> |
| 18  | <a href="#">9343006M0200</a><br>Circlip (689)             | <a href="#">Buy now</a> |
| 19  | <a href="#">6J8157050000</a><br>Spring, drive pawl        | <a href="#">Buy now</a> |
| 20  | <a href="#">6A0157890000</a><br>Damper                    | <a href="#">Buy now</a> |
| 21  | <a href="#">970800603500</a><br>Bolt(j52)                 | <a href="#">Buy now</a> |
| 23  | <a href="#">973950602500</a><br>Bolt                      | <a href="#">Buy now</a> |
| 25  | <a href="#">995101011400</a><br>Pin, dowel(3vd)           | <a href="#">Buy now</a> |
| 26  | <a href="#">656157480000</a><br>Plunger, starter stop     | <a href="#">Buy now</a> |
| 27  | <a href="#">905011022700</a><br>Spring, compreshion(656)  | <a href="#">Buy now</a> |
| 28  | <a href="#">6L2157700000</a><br>Cable comp., starter stop | <a href="#">Buy now</a> |
| 29  | <a href="#">6L2157460000</a><br>Arm                       | <a href="#">Buy now</a> |
| 30  | <a href="#">9038706M5100</a><br>Collar (6g0)              | <a href="#">Buy now</a> |
| 31  | <a href="#">970800602000</a><br>Bolt(7u8)                 | <a href="#">Buy now</a> |
| 32  | <a href="#">929900610000</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 33  | <a href="#">6L2157470000</a><br>Link                      | <a href="#">Buy now</a> |

# Starter




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 34  | <a href="#">6L2157740000</a><br>Stay 4              | <a href="#">Buy now</a> |
| 35  | <a href="#">9020106M6200</a><br>Washer, plate (6e5) | <a href="#">Buy now</a> |
| 36  | <a href="#">661412620200</a><br>Joint, choke lever  | <a href="#">Buy now</a> |
| 37  | <a href="#">6L2157720094</a><br>Stay 2              | <a href="#">Buy now</a> |
| 38  | <a href="#">973130602000</a><br>Bolt(7u8)           | <a href="#">Buy now</a> |
| 42  | <a href="#">970270801200</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 3   | <a href="#">9020635M1100</a><br>Washer, wave(6j8)         | <a href="#">Buy now</a> |
| 4   | <a href="#">9020235M2400</a><br>Washer (6g1)              | <a href="#">Buy now</a> |
| 5   | <a href="#">9038634M4000</a><br>Bushing (6g1)             | <a href="#">Buy now</a> |
| 6   | <a href="#">9038643M7900</a><br>Bush(6l5)                 | <a href="#">Buy now</a> |
| 7   | <a href="#">6G1421310100</a><br>Cover, handle steering    | <a href="#">Buy now</a> |
| 8   | <a href="#">973950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 9   | <a href="#">6G1421250100</a><br>Bolt, friction adjusting  | <a href="#">Buy now</a> |
| 10  | <a href="#">6G1421260000</a><br>Piece, friction           | <a href="#">Buy now</a> |
| 11  | <a href="#">914901601000</a><br>Pin, cotter               | <a href="#">Buy now</a> |
| 12  | <a href="#">664421190000</a><br>Grip, steering handle     | <a href="#">Buy now</a> |
| 13  | <a href="#">6G1421770000</a><br>Rubber, handle            | <a href="#">Buy now</a> |
| 14  | <a href="#">6L2421370000</a><br>Indicator, throttle       | <a href="#">Buy now</a> |
| 15  | <a href="#">9026902M0900</a><br>Rivet(6l5)                | <a href="#">Buy now</a> |
| 16  | <a href="#">905012321500</a><br>Spring (655)              | <a href="#">Buy now</a> |
| 17  | <a href="#">929901060000</a><br>Washer, plate             | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 18  | <a href="#">9014905M0600</a><br>Screw, countersunk        | <a href="#">Buy now</a> |
| 20  | <a href="#">6G1421380100</a><br>Lever, throttle           | <a href="#">Buy now</a> |
| 21  | <a href="#">6E0421590200</a><br>Stay                      | <a href="#">Buy now</a> |
| 22  | <a href="#">973950501200</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 24  | <a href="#">6L2441110094</a><br>Handle, gear shift        | <a href="#">Buy now</a> |
| 25  | <a href="#">9038615M7300</a><br>Bush(6I2)                 | <a href="#">Buy now</a> |
| 26  | <a href="#">9020615M1800</a><br>Washer, wave(6I2)         | <a href="#">Buy now</a> |
| 27  | <a href="#">9020215M3700</a><br>Washer, plate(6I2)        | <a href="#">Buy now</a> |
| 28  | <a href="#">9038612M7200</a><br>Bush(6I2)                 | <a href="#">Buy now</a> |
| 29  | <a href="#">6L2441250000</a><br>Lever, shift rod          | <a href="#">Buy now</a> |
| 30  | <a href="#">970800602000</a><br>Bolt(7u8)                 | <a href="#">Buy now</a> |
| 31  | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 32  | <a href="#">902020600900</a><br>Washer plate 626427510000 | <a href="#">Buy now</a> |
| 33  | <a href="#">914902001000</a><br>Pin, cotter               | <a href="#">Buy now</a> |
| 34  | <a href="#">6L2441240000</a><br>Link, shift rod           | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 35  | <a href="#">6L2263630000</a><br>End, cable          | <a href="#">Buy now</a> |
| 36  | <a href="#">953800670000</a><br>Nut                 | <a href="#">Buy now</a> |
| 37  | <a href="#">902020508800</a><br>Washer, plate (666) | <a href="#">Buy now</a> |
| 38  | <a href="#">9020205M3800</a><br>Washer, plate(6l2)  | <a href="#">Buy now</a> |
| 39  | <a href="#">9046805M0300</a><br>Clip(6j8)           | <a href="#">Buy now</a> |

# Steering Guide




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">689613500200</a><br>Steering guide attachment kit | <a href="#">Buy now</a> |
| 2   | <a href="#">689613510100</a><br>Rod, steering                 | <a href="#">Buy now</a> |
| 3   | <a href="#">9020110M2000</a><br>Washer, plate (663)           | <a href="#">Buy now</a> |
| 4   | <a href="#">9018509M0100</a><br>Nut, nylon (663)              | <a href="#">Buy now</a> |
| 5   | <a href="#">9017009M0300</a><br>Nut (689)                     | <a href="#">Buy now</a> |
| 6   | <a href="#">9038710M4200</a><br>Collar (688)                  | <a href="#">Buy now</a> |
| 7   | <a href="#">9010109M6600</a><br>Bolt                          | <a href="#">Buy now</a> |
| 8   | <a href="#">9020110M6300</a><br>Washer, plate                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5431450000</a><br>Cap, clamp bracket            | <a href="#">Buy now</a> |
| 10  | <a href="#">932101627500</a><br>O-ring                        | <a href="#">Buy now</a> |
| 11  | <a href="#">688613010100</a><br>Twin kit                      | <a href="#">Buy now</a> |
| 12  | <a href="#">9020110M7600</a><br>Washer, plate (6e5)           | <a href="#">Buy now</a> |
| 13  | <a href="#">9017009M0500</a><br>Nut, hexagon (6e5)            | <a href="#">Buy now</a> |
| 14  | <a href="#">9010109M7000</a><br>Bolt (6e5)                    | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5613030000</a><br>Steering axle comp.           | <a href="#">Buy now</a> |

# Steering Guide




| Ref | Part                                       |                         |
|-----|--------------------------------------------|-------------------------|
| 17  | <a href="#">6E5613150000</a><br>Tie bar, 2 | <a href="#">Buy now</a> |
| 18  | <a href="#">953801470000</a><br>Nut (6e5)  | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5613130000</a><br>Adjuster   | <a href="#">Buy now</a> |
| 20  | <a href="#">688613111100</a><br>Tie bar    | <a href="#">Buy now</a> |
| 21  | <a href="#">9017014M0600</a><br>Nut (6e5)  | <a href="#">Buy now</a> |

## Top Cowling



| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 2   | <a href="#">6L2426150000</a><br>Seal                      | <a href="#">Buy now</a> |
| 3   | <a href="#">6G1426517100</a><br>Hook                      | <a href="#">Buy now</a> |
| 4   | <a href="#">6G1426470000</a><br>Holder, clamp band        | <a href="#">Buy now</a> |
| 5   | <a href="#">9026604M0000</a><br>Rivet 2 (662)             | <a href="#">Buy now</a> |
| 7   | <a href="#">973950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 8   | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |

## Upper Casing



| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 3   | <a href="#">6L2451150000</a><br>Gasket, upper casing       | <a href="#">Buy now</a> |
| 4   | <a href="#">9015906M1100</a><br>Screw, with washer(6l2)    | <a href="#">Buy now</a> |
| 5   | <a href="#">9360410M0300</a><br>Pin, dowel (688)           | <a href="#">Buy now</a> |
| 6   | <a href="#">6L2821270000</a><br>Wire, lead 2               | <a href="#">Buy now</a> |
| 7   | <a href="#">9015706M0600</a><br>Screw, pan head(6m7)       | <a href="#">Buy now</a> |
| 8   | <a href="#">970800803000</a><br>Bolt, hexagon (fj1)        | <a href="#">Buy now</a> |
| 9   | <a href="#">929900860000</a><br>Washer, plain (663)        | <a href="#">Buy now</a> |
| 10  | <a href="#">6L34113100CA</a><br>Manifold, ext. 1           | <a href="#">Buy now</a> |
| 11  | <a href="#">6L2411340000</a><br>Gasket, exhaust manifold   | <a href="#">Buy now</a> |
| 12  | <a href="#">6L2451230000</a><br>Gasket, muffler            | <a href="#">Buy now</a> |
| 13  | <a href="#">6L241133A000</a><br>Gasket, exhaust manifold 1 | <a href="#">Buy now</a> |
| 14  | <a href="#">973950602000</a><br>Bolt(7u8)                  | <a href="#">Buy now</a> |
| 15  | <a href="#">929900660000</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.