



# Yamaha 25NMHO 2003

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

<b>BOTTOM COWLING</b>	3
<b>BRACKET 1</b>	6
<b>BRACKET 2</b>	10
<b>CARBURETOR</b>	13
<b>CONTROL 1</b>	16
<b>CONTROL 2</b>	19
<b>CRANKSHAFT. PISTON</b>	21
<b>CYLINDER. CRANKCASE</b>	24
<b>ELECTRICAL 1</b>	26
<b>ELECTRICAL 2</b>	28
<b>FUEL</b>	30
<b>FUEL TANK</b>	32
<b>GENERATOR</b>	33
<b>INTAKE</b>	35
<b>LOWER CASING. DRIVE 1</b>	37
<b>LOWER CASING. DRIVE 2</b>	41
<b>OIL PUMP</b>	43
<b>REMOTE CONTROL ASSY</b>	46
<b>REMOTE CONTROL BOX</b>	51
<b>REPAIR KIT 1</b>	52
<b>REPAIR KIT 2</b>	54
<b>STARTER</b>	56
<b>STARTING MOTOR</b>	59
<b>STEERING</b>	61
<b>STEERING GUIDE</b>	64
<b>TOP COWLING</b>	65
<b>UPPER CASING</b>	67


# Bottom Cowling



D3

Ref	Part	
1	<a href="#">6L2-42711-03-4D</a> Cowling, bottom 1	<a href="#">Buy now</a>
2	<a href="#">6L2-42815-01-4D</a> Lever, clamp	<a href="#">Buy now</a>
3	<a href="#">90386-12M45</a> Bushing (6g1)	<a href="#">Buy now</a>
4	<a href="#">6L2-42816-00</a> Lever, clamp	<a href="#">Buy now</a>
5	<a href="#">90206-12052</a> Washer, wave (666)	<a href="#">Buy now</a>
6	<a href="#">97880-06035</a> Screw, pan head(6h4)	<a href="#">Buy now</a>
7	<a href="#">95780-06300</a> Nut, nylon (6g1)	<a href="#">Buy now</a>
8	<a href="#">6L2-42719-A0</a> Panel, front lower	<a href="#">Buy now</a>
9	<a href="#">689-41273-00</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">6J8-41274-00</a> Grommet 2	<a href="#">Buy now</a>
11	<a href="#">6L2-42725-00</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">6L2-42725-50</a> Grommet	<a href="#">Buy now</a>
12	<a href="#">6G1-42724-00</a> Grommet	<a href="#">Buy now</a>
13	<a href="#">6L2-42726-01</a> Grommet	<a href="#">Buy now</a>
13	<a href="#">6L2-42726-10</a> Grommet	<a href="#">Buy now</a>


# Bottom Cowling



D3

Ref	Part	
14	<a href="#">6G1-42727-00</a> Grommet	<a href="#">Buy now</a>
15	<a href="#">6L2-42748-01</a> Grommet	<a href="#">Buy now</a>
16	<a href="#">6L2-42716-00</a> Rubber seal 1	<a href="#">Buy now</a>
17	<a href="#">90338-05M03</a> Plug (6h1)	<a href="#">Buy now</a>
18	<a href="#">90480-15M31</a> Grommet (6g1)	<a href="#">Buy now</a>
19	<a href="#">90387-06M52</a> Collar (6g1)	<a href="#">Buy now</a>
20	<a href="#">95895-06020</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
21	<a href="#">6L2-42738-01</a> Plate, fitting	<a href="#">Buy now</a>
22	<a href="#">6H3-44391-01</a> Nipple, hose	<a href="#">Buy now</a>
23	<a href="#">6E5-82588-00</a> Plate	<a href="#">Buy now</a>
24	<a href="#">95895-06016</a> Bolt, flange deep recess	<a href="#">Buy now</a>
25	<a href="#">6L2-82575-00</a> Engine stop switch assembly	<a href="#">Buy now</a>
26	<a href="#">682-82556-00</a> Lanyard, stop switch	<a href="#">Buy now</a>
27	<a href="#">689-8257Y-00</a> Cap	<a href="#">Buy now</a>
28	<a href="#">6J8-85410-00</a> Emergency signal light assembly	<a href="#">Buy now</a>


## Bottom Cowling



Ref	Part	
29	<a href="#">682-84381-00</a> 2p concent 1	<a href="#">Buy now</a>
30	<a href="#">6E7-42791-10</a> Mark 1	<a href="#">Buy now</a>
31	<a href="#">6A1-28176-00</a> Label Caution	<a href="#">Buy now</a>
32	<a href="#">6E3-8257H-00</a> Plate Mark	<a href="#">Buy now</a>

D3


# Bracket 1



E3


Ref	Part	
1	<a href="#">6L2-43111-04-4D</a> Bracket, clamp 1	<a href="#">Buy now</a>
2	<a href="#">6L2-43112-05-4D</a> Bracket, clamp 2	<a href="#">Buy now</a>
3	<a href="#">6E5-82148-00</a> Wire, lead 5	<a href="#">Buy now</a>
4	<a href="#">97885-06008</a> Screw, pan head(6a3)	<a href="#">Buy now</a>
5	<a href="#">6E0-43118-01</a> Handle, transom clamp	<a href="#">Buy now</a>
6	<a href="#">90243-04M01</a> Pin(6a1)	<a href="#">Buy now</a>
7	<a href="#">6L2-43116-00</a> Screw, transom clamp	<a href="#">Buy now</a>
8	<a href="#">648-43114-01</a> Pad, transom clamp	<a href="#">Buy now</a>
9	<a href="#">6J8-43131-01</a> Bolt, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">90386-22M67</a> Bush(6a9)	<a href="#">Buy now</a>
11	<a href="#">90201-22M03</a> Washer, plate(64j)	<a href="#">Buy now</a>
12	<a href="#">90185-22043</a> Nut, self-locking	<a href="#">Buy now</a>
13	<a href="#">6G5-43145-01</a> Cap, clamp bracket	<a href="#">Buy now</a>
14	<a href="#">6J8-43113-01</a> Plate, clamp bracket	<a href="#">Buy now</a>
15	<a href="#">6L2-43311-05-4D</a> Bracket, swivel 1	<a href="#">Buy now</a>

# Bracket 1



Ref	Part	
16	<a href="#">93700-06M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
17	<a href="#">663-45119-00</a> Cap, grease nipple AP	<a href="#">Buy now</a>
18	<a href="#">6H4-42528-00</a> Piece, friction	<a href="#">Buy now</a>
19	<a href="#">689-43373-01</a> Seal, damper	<a href="#">Buy now</a>
20	<a href="#">90105-06M18</a> Bolt (689)	<a href="#">Buy now</a>
21	<a href="#">6L2-42121-02-4D</a> Bracket	<a href="#">Buy now</a>
22	<a href="#">6E0-44191-11</a> Indicator, shift	<a href="#">Buy now</a>
23	<a href="#">90116-10M28</a> Bolt, stud	<a href="#">Buy now</a>
24	<a href="#">92995-10600</a> Washer, plate	<a href="#">Buy now</a>
25	<a href="#">90185-10051</a> Nut, self-locking	<a href="#">Buy now</a>
26	<a href="#">6L2-42510-01-4D</a> Steering bracket assembly	<a href="#">Buy now</a>
27	<a href="#">90386-30M75</a> Bush(6l2)	<a href="#">Buy now</a>
28	<a href="#">90201-30M00</a> Washer, plate(6h1)	<a href="#">Buy now</a>
29	<a href="#">93210-29375</a> O-ring (j10)	<a href="#">Buy now</a>
30	<a href="#">90386-30M60</a> Bush(6j8)	<a href="#">Buy now</a>


# Bracket 1



E3

Ref	Part	
31	<a href="#">6L2-44512-00-4D</a> Cover, upper mount	<a href="#">Buy now</a>
32	<a href="#">6L2-45114-A1</a> Gasket, upper casing	<a href="#">Buy now</a>
33	<a href="#">6L2-44365-00</a> Damper, water seal 1	<a href="#">Buy now</a>
34	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
35	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
36	<a href="#">6L2-44514-01</a> Mount damper, upper side	<a href="#">Buy now</a>
37	<a href="#">90119-06M04</a> Bolt, with washer(6l2)	<a href="#">Buy now</a>
38	<a href="#">90119-06M05</a> Bolt, with washer(6l2)	<a href="#">Buy now</a>
39	<a href="#">90101-08M09</a> Bolt(6l2)	<a href="#">Buy now</a>
40	<a href="#">90201-08M01</a> Washer, plate(6l2)	<a href="#">Buy now</a>
41	<a href="#">6L2-44526-00</a> Plate	<a href="#">Buy now</a>
42	<a href="#">90185-08057</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
43	<a href="#">6L2-44551-01-4D</a> Housing, lower mount rubber 1	<a href="#">Buy now</a>
44	<a href="#">6L2-44552-01-4D</a> Housing, lower mount rubber 2	<a href="#">Buy now</a>
45	<a href="#">93604-12M07</a> Pin, dowel (688)	<a href="#">Buy now</a>


## Bracket 1



Ref	Part	
46	<a href="#">97095-08085</a> Bolt, with washer	<a href="#">Buy now</a>
47	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
48	<a href="#">6L2-44555-00</a> Mount damper, lower side	<a href="#">Buy now</a>
49	<a href="#">6L2-44557-00</a> Mount damper, lower front	<a href="#">Buy now</a>
50	<a href="#">6L2-44553-01-4D</a> Cover, lower mount	<a href="#">Buy now</a>
51	<a href="#">97095-08045</a> Bolt, hexagon	<a href="#">Buy now</a>
53	<a href="#">97095-08070</a> Bolt, hexagon	<a href="#">Buy now</a>
54	<a href="#">95380-08600</a> Nut (661)	<a href="#">Buy now</a>

E3


## Bracket 2



E6

Ref	Part	
1	<a href="#">6L2-43165-01</a> Plate, tilt lock	<a href="#">Buy now</a>
2	<a href="#">97090-06010</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">92990-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">6L2-43160-00</a> Tilt rod assembly	<a href="#">Buy now</a>
5	<a href="#">6L2-43630-01</a> Tilt lever assembly	<a href="#">Buy now</a>
6	<a href="#">682-43318-01</a> Cover	<a href="#">Buy now</a>
7	<a href="#">90386-08032</a> Bushing (650)	<a href="#">Buy now</a>
8	<a href="#">6L2-43682-01</a> Lever, shallow water drive 2	<a href="#">Buy now</a>
9	<a href="#">97095-05010</a> Bolt (682)	<a href="#">Buy now</a>
10	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">6L2-43191-01</a> Shaft, stopper	<a href="#">Buy now</a>
12	<a href="#">99080-05600</a> Circlip(22k)	<a href="#">Buy now</a>
13	<a href="#">90506-20M27</a> Spring, tension(6l2)	<a href="#">Buy now</a>
14	<a href="#">6L2-43350-02</a> Receiver assembly	<a href="#">Buy now</a>
15	<a href="#">68-43611-01</a> Shaft, tilt lock	<a href="#">Buy now</a>

## Bracket 2




6L20300-1180

E6

Ref	Part	
17	<a href="#">6L2-43614-00</a> Plate, tilt lock	<a href="#">Buy now</a>
18	<a href="#">90508-12M28</a> Spring, torsion(6l2)	<a href="#">Buy now</a>
19	<a href="#">90508-12M29</a> Spring, torsion(6l2)	<a href="#">Buy now</a>
20	<a href="#">6L2-43615-00</a> Plate, tilt lock	<a href="#">Buy now</a>
21	<a href="#">6L2-43657-00</a> Spring, lock	<a href="#">Buy now</a>
22	<a href="#">6L2-43676-00</a> Hook	<a href="#">Buy now</a>
23	<a href="#">6L2-43631-00</a> Lever, tilt	<a href="#">Buy now</a>
24	<a href="#">6L2-43188-00</a> Spring	<a href="#">Buy now</a>
25	<a href="#">6L2-43633-10</a> Cover, tilt lever	<a href="#">Buy now</a>
26	<a href="#">6L2-43611-00</a> Shaft, tilt lock	<a href="#">Buy now</a>
27	<a href="#">6L2-43641-00</a> Lever, tilt	<a href="#">Buy now</a>
28	<a href="#">6L2-43659-00</a> Shaft, reverse lock	<a href="#">Buy now</a>
30	<a href="#">6L2-43617-00</a> Rod, tilt lock	<a href="#">Buy now</a>
31	<a href="#">6L2-43613-00</a> Arm, tilt lock	<a href="#">Buy now</a>
33	<a href="#">6L2-43624-00</a> Plate, tilt rock	<a href="#">Buy now</a>


## Bracket 2



Ref	Part	
34	<a href="#">6L2-43336-00</a> Pin	<a href="#">Buy now</a>
35	<a href="#">90506-23M11</a> Spring, tension(6l2)	<a href="#">Buy now</a>

E6

# Carburetor




6L21010-2050

B4

Ref	Part	
1	<a href="#">6L2-14301-01</a> Carburetor assembly 1 #1	<a href="#">Buy now</a>
1	<a href="#">6L3-14301-00</a> Carburetor assembly 1 #1	<a href="#">Buy now</a>
2	<a href="#">6L2-14302-01</a> Carburetor assembly 2 #2	<a href="#">Buy now</a>
2	<a href="#">6L3-14302-00</a> Carburetor assembly 2 #2	<a href="#">Buy now</a>
3	<a href="#">6L2-14381-00</a> Body, float chamber #1	<a href="#">Buy now</a>
3	<a href="#">6L2-14383-00</a> Body, float chamber #2	<a href="#">Buy now</a>
4	<a href="#">6L2-14384-00</a> Gasket, float chamber	<a href="#">Buy now</a>
5	<a href="#">6L2-14385-00</a> Float	<a href="#">Buy now</a>
6	<a href="#">6E5-14386-01</a> Pin, float	<a href="#">Buy now</a>
7	<a href="#">6L2-14392-00</a> Valve, needle	<a href="#">Buy now</a>
8	<a href="#">97880-04010</a> Screw, pan head (e56)	<a href="#">Buy now</a>
9	<a href="#">92900-04100</a> Ybs67-4 washer, spring	<a href="#">Buy now</a>
10	<a href="#">6L2-14157-00</a> Cover, mixing	<a href="#">Buy now</a>
11	<a href="#">6L2-14399-00</a> Gasket	<a href="#">Buy now</a>
12	<a href="#">6L2-14341-00</a> Nozzle, main	<a href="#">Buy now</a>


# Carburetor



**B4**

Ref	Part	
13	<a href="#">30X-14343-63</a> Jet, main	<a href="#">Buy now</a>
14	<a href="#">6L2-14342-30</a> Jet, pilot (#60)	<a href="#">Buy now</a>
15	<a href="#">50M-14355-00</a> Plug	<a href="#">Buy now</a>
16	<a href="#">6L2-14323-00</a> Screw, air adjusting	<a href="#">Buy now</a>
17	<a href="#">646-14212-01</a> Spring, pilot adjusting	<a href="#">Buy now</a>
18	<a href="#">664-14321-01</a> Screw, throttle	<a href="#">Buy now</a>
19	<a href="#">97980-04112</a> Screw, pan head (686)	<a href="#">Buy now</a>
20	<a href="#">677-14383-00</a> Screw, drain	<a href="#">Buy now</a>
21	<a href="#">6L2-14398-00</a> Gasket	<a href="#">Buy now</a>
22	<a href="#">677-24444-01</a> Screw	<a href="#">Buy now</a>
23	<a href="#">98980-04006</a> Screw, bind(6l2)	<a href="#">Buy now</a>
24	<a href="#">6A0-24421-01</a> Valve, check	<a href="#">Buy now</a>
25	<a href="#">95380-03600</a> Nut (6g8)	<a href="#">Buy now</a>
26	<a href="#">6E7-14325-00</a> Screw, pan head	<a href="#">Buy now</a>
27	<a href="#">6L2-24435-00</a> Gasket, body 2	<a href="#">Buy now</a>


# Carburetor



Ref	Part	
28	<a href="#">6L2-24413-00</a> Body 2	<a href="#">Buy now</a>
29	<a href="#">682-24412-01</a> Body, pump	<a href="#">Buy now</a>
30	<a href="#">677-24411-02</a> Diaphragm	<a href="#">Buy now</a>
31	<a href="#">677-24434-02</a> Gasket, pump 1	<a href="#">Buy now</a>
32	<a href="#">6L2-14578-00</a> Collar & stopper set #2	<a href="#">Buy now</a>

**B4**


# Control 1



D7

Ref	Part	
1	<a href="#">6L2-14497-00</a> Stay, throttle wire	<a href="#">Buy now</a>
2	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
3	<a href="#">95380-06700</a> Nut	<a href="#">Buy now</a>
4	<a href="#">6L2-41213-00</a> Cam, accel.	<a href="#">Buy now</a>
5	<a href="#">6L2-41283-00</a> Lever, free accel.	<a href="#">Buy now</a>
6	<a href="#">6L2-41631-00</a> Lever, magneto control	<a href="#">Buy now</a>
7	<a href="#">6J8-42167-00</a> Spring 1	<a href="#">Buy now</a>
8	<a href="#">6L2-42167-00</a> Spring 1	<a href="#">Buy now</a>
9	<a href="#">97095-06075</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
10	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">90387-06M18</a> Collar(6L2)	<a href="#">Buy now</a>
12	<a href="#">689-42169-01</a> Joint	<a href="#">Buy now</a>
13	<a href="#">662-41237-01</a> Joint, link	<a href="#">Buy now</a>
14	<a href="#">95380-05600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
15	<a href="#">6L2-44122-00</a> Bushing, shift rod lever	<a href="#">Buy now</a>


# Control 1



D7

Ref	Part	
16	<a href="#">90254-03M04</a> Pin, spring (6h3)	<a href="#">Buy now</a>
17	<a href="#">6L2-42192-00</a> Rod 2	<a href="#">Buy now</a>
18	<a href="#">90202-05088</a> Washer, plate (666)	<a href="#">Buy now</a>
19	<a href="#">91490-20010</a> Pin, cotter	<a href="#">Buy now</a>
20	<a href="#">6L2-44141-02</a> Link, shift rod	<a href="#">Buy now</a>
21	<a href="#">6L2-44141-10-94</a> Link, shift rod	<a href="#">Buy now</a>
22	<a href="#">6L2-44121-00</a> Lever, shift rod	<a href="#">Buy now</a>
23	<a href="#">6L2-41212-00</a> Arm, accel.	<a href="#">Buy now</a>
24	<a href="#">90109-06M28</a> Bolt(6j8)	<a href="#">Buy now</a>
25	<a href="#">97013-05016</a> Bolt	<a href="#">Buy now</a>
26	<a href="#">92903-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
27	<a href="#">6L2-41237-00</a> Joint, link	<a href="#">Buy now</a>
28	<a href="#">6L2-41238-00</a> Joint, link	<a href="#">Buy now</a>
29	<a href="#">95380-05700</a> Nut (656)	<a href="#">Buy now</a>
30	<a href="#">6G1-41662-01-94</a> Bracket	<a href="#">Buy now</a>

## Control 1




6L20010-0150

D7

Ref	Part	
31	<a href="#">97013-06020</a> Bolt(62y)	<a href="#">Buy now</a>
32	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
33	<a href="#">618-44116-00</a> Spring	<a href="#">Buy now</a>
34	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
36	<a href="#">6L2-44123-00</a> Arm, shift rod	<a href="#">Buy now</a>
38	<a href="#">6L2-44143-00</a> Rod, shift	<a href="#">Buy now</a>
39	<a href="#">90170-06015</a> Connector, shift rod	<a href="#">Buy now</a>
40	<a href="#">6L2-14368-00</a> Diaphragm assembly 1	<a href="#">Buy now</a>
41	<a href="#">97095-06008</a> Bolt (fj1)	<a href="#">Buy now</a>

## Control 2





6L22300-3160

E2

Ref	Part	
1	<a href="#">6L2-48544-01</a> Lever, shiftcontrol	<a href="#">Buy now</a>
2	<a href="#">6L2-48534-01</a> Throttle lever, control	<a href="#">Buy now</a>
3	<a href="#">90386-10009</a> Bushing 6484418600	<a href="#">Buy now</a>
4	<a href="#">95780-08300</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
5	<a href="#">6L2-42154-01</a> Lever, throttle control	<a href="#">Buy now</a>
6	<a href="#">6L2-42191-01</a> Rod 1	<a href="#">Buy now</a>
7	<a href="#">6L2-42192-20</a> Rod 2	<a href="#">Buy now</a>
8	<a href="#">90202-05088</a> Washer, plate (666)	<a href="#">Buy now</a>
9	<a href="#">91490-20010</a> Pin, cotter	<a href="#">Buy now</a>
10	<a href="#">6L2-48531-00</a> Bracket, remote control 1	<a href="#">Buy now</a>
11	<a href="#">682-48538-50</a> Clamp, cable	<a href="#">Buy now</a>
12	<a href="#">91690-30012</a> Pin, spring	<a href="#">Buy now</a>
13	<a href="#">90105-06M23</a> Bolt (6g1)	<a href="#">Buy now</a>
14	<a href="#">6G8-26363-00</a> End, wire 1	<a href="#">Buy now</a>
15	<a href="#">6G8-26364-00</a> End, wire 2	<a href="#">Buy now</a>

## Control 2


Ref	Part	
16	<a href="#">6J8-48511-01-4D</a> Hook, steering	<a href="#">Buy now</a>



6L22300-3160

E2


# Crankshaft. Piston



A7

Ref	Part	
1	<a href="#">6L2-11400-10</a> Crankshaft assembly O/I	<a href="#">Buy now</a>
2	<a href="#">6L2-11412-00</a> Crank 1	<a href="#">Buy now</a>
3	<a href="#">6L2-11422-00</a> Crank 2	<a href="#">Buy now</a>
4	<a href="#">6L2-11432-00</a> Crank 3	<a href="#">Buy now</a>
5	<a href="#">6L2-11442-00</a> Crank 4	<a href="#">Buy now</a>
6	<a href="#">93311-632U7</a> Bearing, cylindrical(6j8)	<a href="#">Buy now</a>
7	<a href="#">93102-26M27</a> Oil seal(6j8)	<a href="#">Buy now</a>
8	<a href="#">93210-42159</a> O-ring (647)	<a href="#">Buy now</a>
9	<a href="#">93306-305U3</a> Bearing(6j8)	<a href="#">Buy now</a>
10	<a href="#">6L2-11651-00</a> Rod, connecting	<a href="#">Buy now</a>
11	<a href="#">6L2-11681-00</a> Pin, crank 1	<a href="#">Buy now</a>
12	<a href="#">93310-424W9</a> Bearing, cylindrical(6l2)	<a href="#">Buy now</a>
13	<a href="#">90209-24M15</a> Washer(6l2)	<a href="#">Buy now</a>
14	<a href="#">6L2-11515-00</a> Seal, labyrinth 1	<a href="#">Buy now</a>
15	<a href="#">91690-30010</a> Pin, spring (663)	<a href="#">Buy now</a>


# Crankshaft. Piston



A7

Ref	Part	
16	<a href="#">6J8-11536-00</a> Gear, drive O/I	<a href="#">Buy now</a>
17	<a href="#">90387-28M00</a> Collar (6j8)	<a href="#">Buy now</a>
18	<a href="#">90201-50306</a> Washer plate 648115870000	<a href="#">Buy now</a>
19	<a href="#">6L2-11631-00-97</a> Piston (std)	<a href="#">Buy now</a>
19	<a href="#">6L2-11635-00</a> Piston (0.25mm o/s) AP	<a href="#">Buy now</a>
19	<a href="#">6L2-11636-00</a> Piston (0.50mm o/s) AP	<a href="#">Buy now</a>
20	<a href="#">6L2-11610-00</a> Piston ring set (std)	<a href="#">Buy now</a>
20	<a href="#">6L2-11610-10</a> Piston ring set (1st o/s) AP	<a href="#">Buy now</a>
20	<a href="#">6L2-11610-20</a> Piston ring set (2nd o/s) AP	<a href="#">Buy now</a>
21	<a href="#">648-11633-00</a> Pin,piston	<a href="#">Buy now</a>
22	<a href="#">93602-18M12</a> Pin, dowel(6l2)	<a href="#">Buy now</a>
23	<a href="#">93450-20026</a> Clip 6041163400	<a href="#">Buy now</a>
24	<a href="#">90201-18522</a> Washer (656)	<a href="#">Buy now</a>
25	<a href="#">6L2-15396-00-1S</a> Housing, oil seal	<a href="#">Buy now</a>
26	<a href="#">93102-25142</a> Oil seal (24.8x38x7-662)	<a href="#">Buy now</a>


## Crankshaft. Piston



Ref	Part	
27	<a href="#">93101-13M37</a> Oil seal(6a4)	<a href="#">Buy now</a>
28	<a href="#">93210-56M80</a> O-ring(6j8)	<a href="#">Buy now</a>
29	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
30	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>

A7


# Cylinder. Crankcase



A5

Ref	Part	
3	<a href="#">6E5-11372-01</a> Nipple, hose	<a href="#">Buy now</a>
4	<a href="#">90445-07M15</a> Hose (I390)	<a href="#">Buy now</a>
5	<a href="#">90467-06016</a> Clip (655)	<a href="#">Buy now</a>
6	<a href="#">93604-12M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
7	<a href="#">95617-08645</a> Bolt, stud(6l2)	<a href="#">Buy now</a>
8	<a href="#">90201-08086</a> Washer (1t1)	<a href="#">Buy now</a>
9	<a href="#">95333-08600</a> Nut(6l2)	<a href="#">Buy now</a>
10	<a href="#">90119-08M65</a> Bolt, with washer	<a href="#">Buy now</a>
11	<a href="#">90119-06M14</a> Bolt, with washer (677)	<a href="#">Buy now</a>
12	<a href="#">6J8-11325-00</a> Anode	<a href="#">Buy now</a>
14	<a href="#">6H3-11328-00</a> Grommet, anode	<a href="#">Buy now</a>
15	<a href="#">97013-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
16	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">6L2-11181-A2</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
20	<a href="#">6L2-11193-A1</a> Gasket, head cover 1	<a href="#">Buy now</a>


# Cylinder. Crankcase



Ref	Part	
21	<a href="#">90119-08M91</a> Bolt, with washer	<a href="#">Buy now</a>
22	<a href="#">90119-06023</a> Bolt, with washer	<a href="#">Buy now</a>
23	<a href="#">6E5-12411-30</a> Thermostat	<a href="#">Buy now</a>
25	<a href="#">6J8-12414-A0</a> Gasket, cover	<a href="#">Buy now</a>
26	<a href="#">90119-06MA3</a> Bolt, with washer	<a href="#">Buy now</a>
28	<a href="#">6L2-41112-A1</a> Gasket, exhaust inner cover	<a href="#">Buy now</a>
29	<a href="#">6L2-41113-00-1S</a> Outer cover, exhaust	<a href="#">Buy now</a>
30	<a href="#">676-11372-00</a> Nipple, hose	<a href="#">Buy now</a>
31	<a href="#">6L2-41114-A1</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
32	<a href="#">90119-06MA4</a> Bolt, with washer	<a href="#">Buy now</a>
33	<a href="#">90445-10M40</a> Hose (I400)	<a href="#">Buy now</a>
34	<a href="#">6L2-45113-A1</a> Gasket, upper casing	<a href="#">Buy now</a>
35	<a href="#">94702-00271</a> Plug, spark (br7hs-10)	<a href="#">Buy now</a>

A5


# Electrical 1



**C6**


Ref	Part	
1	<a href="#">6L2-85540-23</a> C.d.i. unit assembly	<a href="#">Buy now</a>
2	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
3	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">6L2-85542-02-94</a> Bracket	<a href="#">Buy now</a>
5	<a href="#">97075-06030</a> Bolt(jf7)	<a href="#">Buy now</a>
7	<a href="#">90101-06M16</a> Bolt(6l2)	<a href="#">Buy now</a>
8	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">61N-85570-00</a> Ignition coil assembly	<a href="#">Buy now</a>
11	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>
12	<a href="#">90464-08M07</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">90480-25161</a> Grommet(656)	<a href="#">Buy now</a>
14	<a href="#">90465-06M86</a> Clamp	<a href="#">Buy now</a>
15	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
17	<a href="#">6G1-82370-21</a> Plug cap assembly	<a href="#">Buy now</a>
20	<a href="#">689-82560-00</a> Thermo switch assembly	<a href="#">Buy now</a>

## Electrical 1



Ref	Part	
21	<a href="#">6J8-81960-00</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
22	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>


C6



**C7**

Ref	Part	
1	<a href="#">6G1-81941-10</a> Starter relay	<a href="#">Buy now</a>
2	<a href="#">6G1-81952-00</a> Holder, relay	<a href="#">Buy now</a>
3	<a href="#">6L2-81945-00</a> Plate, switch fitting	<a href="#">Buy now</a>
4	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
5	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>
6	<a href="#">6G1-82105-01</a> Battery cable	<a href="#">Buy now</a>
7	<a href="#">6G1-82117-00</a> Wire, lead	<a href="#">Buy now</a>
8	<a href="#">6G1-81970-61</a> Rectifier assembly	<a href="#">Buy now</a>
9	<a href="#">6G1-82151-00</a> Fuse (10a)	<a href="#">Buy now</a>
10	<a href="#">97880-05025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
11	<a href="#">92990-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">6G5-82152-00</a> Holder, fuse	<a href="#">Buy now</a>
13	<a href="#">6L2-86111-00</a> Coil, solenoid	<a href="#">Buy now</a>
14	<a href="#">682-86117-00</a> Hook, wire pull	<a href="#">Buy now</a>
15	<a href="#">6L2-86115-00</a> Holder, solenoid	<a href="#">Buy now</a>


## Electrical 2



6L21100-2110

Ref	Part	
16	<a href="#">97880-05008</a> Screw, with washer	<a href="#">Buy now</a>
18	<a href="#">90480-10155</a> Grommet(664)	<a href="#">Buy now</a>
19	<a href="#">97880-04008</a> Screw, pan head (713)	<a href="#">Buy now</a>
20	<a href="#">92990-04600</a> Washer, plain (646)	<a href="#">Buy now</a>
21	<a href="#">6L2-86112-00</a> Stay, solenoid	<a href="#">Buy now</a>
24	<a href="#">93210-03261</a> O-ring (663)	<a href="#">Buy now</a>
27	<a href="#">6L2-82590-00</a> Wire harness assembly	<a href="#">Buy now</a>
28	<a href="#">6K3-83557-00</a> Tube	<a href="#">Buy now</a>


**C7**



C1

Ref	Part	
1	<a href="#">6G1-24304-02</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
3	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">6H4-24311-00</a> Pipe 1	<a href="#">Buy now</a>
5	<a href="#">6L2-24311-00</a> Pipe, fuel 1	<a href="#">Buy now</a>
6	<a href="#">90467-08004</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
7	<a href="#">61N-24560-00</a> Filter assembly	<a href="#">Buy now</a>
8	<a href="#">61N-24563-00</a> Element, filter	<a href="#">Buy now</a>
9	<a href="#">61N-24521-00</a> Cup, filter	<a href="#">Buy now</a>
10	<a href="#">93210-32738</a> O-ring(1wg)	<a href="#">Buy now</a>
11	<a href="#">6L2-24566-00</a> Bracket, filter	<a href="#">Buy now</a>
12	<a href="#">97013-06014</a> Bolt(gj3)	<a href="#">Buy now</a>
13	<a href="#">95380-08600</a> Nut (661)	<a href="#">Buy now</a>
14	<a href="#">656-W2810-02</a> Tool kit	<a href="#">Buy now</a>
15	<a href="#">6L3-28199-75-A0</a> Om 20d, 25n, 30d UR (E,F,S)	<a href="#">Buy now</a>


# Fuel



Ref	Part	
15	<a href="#">6L3-28199-75-B0</a> Om 20d, 25n, 30d UR (D,NL,I)	<a href="#">Buy now</a>
16	<a href="#">6L3-28199-86-A0</a> O/m 20dmho/dwo/25nmho/30de '03 UR (DK,P,GR)	<a href="#">Buy now</a>
16	<a href="#">6L3-28199-86-B0</a> O/m 20dmho/dwo/25nmho/30de '03 UR (N,S,SS)	<a href="#">Buy now</a>

**C1**


## Fuel Tank



F7

Ref	Part	
1	<a href="#">6YK-24201-01</a> Fuel Tank assembly (25L) AP PLASTIC, 25L	<a href="#">Buy now</a>
2	<a href="#">6YL-24268-01</a> Gasket, fuel meter	<a href="#">Buy now</a>
3	<a href="#">6YK-24610-00</a> Cap assembly WITH INDICATOR	<a href="#">Buy now</a>
4	<a href="#">6YL-24641-00</a> Gasket, cap 1	<a href="#">Buy now</a>
5	<a href="#">6YK-24260-01</a> Fuel meter assembly	<a href="#">Buy now</a>
6	<a href="#">90157-05M16</a> Screw, pan head	<a href="#">Buy now</a>
7	<a href="#">6YL-24329-00</a> Seal	<a href="#">Buy now</a>
8	<a href="#">6YL-24306-52</a> Fuel pipe comp. 1 AP	<a href="#">Buy now</a>


# Generator



**C4**

Ref	Part	
1	<a href="#">6L2-85550-00</a> Rotor assembly	<a href="#">Buy now</a>
1	<a href="#">6L2-85550-10</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">6L2-85560-10</a> Base assembly	<a href="#">Buy now</a>
3	<a href="#">6L2-85520-11</a> Coil, charge	<a href="#">Buy now</a>
4	<a href="#">6L2-85533-10</a> Coil, lighting	<a href="#">Buy now</a>
5	<a href="#">6L2-85580-10</a> Coil, pulser	<a href="#">Buy now</a>
6	<a href="#">6L2-85580-20</a> Coil, pulser	<a href="#">Buy now</a>
7	<a href="#">97607-04110</a> Screw, pan head with washer (s)	<a href="#">Buy now</a>
8	<a href="#">97607-06125</a> Screw, pan head (76t)	<a href="#">Buy now</a>
9	<a href="#">97802-04006</a> Screw, pan head(3xp)	<a href="#">Buy now</a>
10	<a href="#">6E9-81328-70</a> Clamp	<a href="#">Buy now</a>
11	<a href="#">6L2-85561-10</a> Base, magneto	<a href="#">Buy now</a>
12	<a href="#">61N-85537-00</a> Cover	<a href="#">Buy now</a>
13	<a href="#">663-85518-00</a> Joint, ball	<a href="#">Buy now</a>
14	<a href="#">90280-05013</a> Key, woodruff	<a href="#">Buy now</a>


# Generator



Ref	Part	
15	<a href="#">90179-12M04</a> Nut, flange	<a href="#">Buy now</a>
16	<a href="#">90201-13M42</a> Washer (694)	<a href="#">Buy now</a>
17	<a href="#">6G1-41611-00</a> Retainer, magneto base 1	<a href="#">Buy now</a>
18	<a href="#">695-41613-00</a> Plate, base friction	<a href="#">Buy now</a>
19	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
20	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
21	<a href="#">6G1-41612-00</a> Retainer, magneto base	<a href="#">Buy now</a>
22	<a href="#">97885-05010</a> Screw, pan head(62x)	<a href="#">Buy now</a>
23	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
24	<a href="#">6L2-81332-00</a> Plate, timing	<a href="#">Buy now</a>
27	<a href="#">6L2-82599-01</a> Cover, connector	<a href="#">Buy now</a>

C4


# Intake



**B2**

Ref	Part	
1	<a href="#">6L2-13610-00</a> Reed valve assembly	<a href="#">Buy now</a>
2	<a href="#">6L2-W0004-00</a> Reed set	<a href="#">Buy now</a>
3	<a href="#">97880-05016</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
4	<a href="#">92990-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">6L2-13641-10-94</a> Manifold 1 O/I	<a href="#">Buy now</a>
6	<a href="#">676-14485-00</a> Pipe, joint	<a href="#">Buy now</a>
7	<a href="#">6L2-13621-00</a> Gasket, valve seat	<a href="#">Buy now</a>
8	<a href="#">97013-06025</a> Bolt(62y)	<a href="#">Buy now</a>
9	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">90445-09012</a> Hose (I1500)	<a href="#">Buy now</a>
11	<a href="#">90467-08004</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
12	<a href="#">6L2-14198-00</a> Gasket	<a href="#">Buy now</a>
13	<a href="#">6L2-14417-00-94</a> Cover 1	<a href="#">Buy now</a>
14	<a href="#">6L2-14476-00</a> Seal	<a href="#">Buy now</a>
15	<a href="#">93210-35M86</a> O-ring(6l2)	<a href="#">Buy now</a>


# Intake



**B2**


Ref	Part	
16	<a href="#">97013-05012</a> Bolt, hexagon	<a href="#">Buy now</a>
17	<a href="#">92903-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">97513-06585</a> Bolt, with washer	<a href="#">Buy now</a>
19	<a href="#">6L2-14476-11</a> Seal	<a href="#">Buy now</a>
20	<a href="#">6L2-14418-00</a> Cover 2	<a href="#">Buy now</a>
23	<a href="#">6J8-41259-00</a> Rod, choke 3	<a href="#">Buy now</a>
24	<a href="#">661-41262-02</a> Joint, choke lever	<a href="#">Buy now</a>
25	<a href="#">6J8-41271-01</a> Knob, choke	<a href="#">Buy now</a>
26	<a href="#">6L2-41257-00</a> Rod, choke 2	<a href="#">Buy now</a>
27	<a href="#">6L2-41217-00</a> Rod, accel. lever	<a href="#">Buy now</a>
28	<a href="#">6A1-83625-41</a> Mark 5	<a href="#">Buy now</a>
29	<a href="#">6A1-83625-51</a> Mark 5	<a href="#">Buy now</a>

# Lower Casing. Drive 1



Ref	Part	
1	<a href="#">6L2-45300-02-4D</a> Lower unit assembly <b>S</b>	<a href="#">Buy now</a>
1	<a href="#">6L2-45300-12-4D</a> Lower unit assembly <b>L</b>	<a href="#">Buy now</a>
2	<a href="#">6L2-45311-02-4D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93332-00005</a> Brg,cyl-cal roller 0.19g nt	<a href="#">Buy now</a>
4	<a href="#">6L2-45567-00-10</a> Shim (t:1.0mm) <b>UR</b>	<a href="#">Buy now</a>
4	<a href="#">6L2-45567-00-11</a> Shim (t:1.1mm) <b>UR</b>	<a href="#">Buy now</a>
4	<a href="#">6L2-45567-00-12</a> Shim (t:1.2mm) <b>UR</b>	<a href="#">Buy now</a>
4	<a href="#">6L2-45567-00-13</a> Shim (t:1.3mm) <b>UR</b>	<a href="#">Buy now</a>
4	<a href="#">6L2-45567-00-14</a> Shim (t:1.4mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">93315-220V9</a> Bearing, cylindrical(6l2)	<a href="#">Buy now</a>
6	<a href="#">6L2-45536-00</a> Sleeve, drive shaft	<a href="#">Buy now</a>
7	<a href="#">90340-08002</a> Plug, straight screw	<a href="#">Buy now</a>
8	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>
9	<a href="#">6L2-44311-00</a> Housing, water pump	<a href="#">Buy now</a>
10	<a href="#">93210-45161</a> O-ring	<a href="#">Buy now</a>


# Lower Casing. Drive 1



F2

Ref	Part	
11	<a href="#">6L2-44322-00</a> Insert, cartridge	<a href="#">Buy now</a>
12	<a href="#">6L2-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
13	<a href="#">6L2-44352-00</a> Impeller	<a href="#">Buy now</a>
14	<a href="#">97095-06040</a> Bolt (682)	<a href="#">Buy now</a>
15	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
16	<a href="#">6L2-44328-00</a> Plate	<a href="#">Buy now</a>
17	<a href="#">6L2-45331-00-5B</a> Housing, bearing	<a href="#">Buy now</a>
18	<a href="#">93315-22004</a> Brg,cyl-cal roller 21g nt	<a href="#">Buy now</a>
19	<a href="#">93101-20048</a> Oil seal (20x30x6-648)	<a href="#">Buy now</a>
20	<a href="#">6L2-44147-00</a> Boot, shift rod	<a href="#">Buy now</a>
21	<a href="#">93604-12M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
22	<a href="#">6L2-45315-A0</a> Packing,lower casing	<a href="#">Buy now</a>
23	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
25	<a href="#">6L2-45375-00</a> Damper, seal	<a href="#">Buy now</a>
26	<a href="#">6L2-45510-00</a> Drive shaft assembly S	<a href="#">Buy now</a>


# Lower Casing. Drive 1



F2

Ref	Part	
26	<a href="#">6L2-45510-10</a> Drive shaft assembly L	<a href="#">Buy now</a>
27	<a href="#">90280-03024</a> Key, woodruff(662)	<a href="#">Buy now</a>
28	<a href="#">6L2-45551-01</a> Pinion	<a href="#">Buy now</a>
29	<a href="#">90179-10M14</a> Nut(6j8)	<a href="#">Buy now</a>
30	<a href="#">93341-320U0</a> Bearing, thrust (6l2)	<a href="#">Buy now</a>
31	<a href="#">6L2-45587-00-15</a> Shim (t:1.5mm) UR	<a href="#">Buy now</a>
31	<a href="#">6L2-45587-00-16</a> Shim (t:1.6mm) UR	<a href="#">Buy now</a>
32	<a href="#">6L2-45560-00</a> Gear	<a href="#">Buy now</a>
33	<a href="#">6L2-45571-00</a> Gear	<a href="#">Buy now</a>
34	<a href="#">90201-20417</a> Washer, plate(663)	<a href="#">Buy now</a>
35	<a href="#">6L2-45577-00-10</a> Shim (t:1.0mm) UR	<a href="#">Buy now</a>
35	<a href="#">6L2-45577-00-11</a> Shim (t:1.1mm) UR	<a href="#">Buy now</a>
35	<a href="#">6L2-45577-00-12</a> Shim (t:1.2mm) UR	<a href="#">Buy now</a>
35	<a href="#">6L2-45577-00-13</a> Shim (t:1.3mm) UR	<a href="#">Buy now</a>
36	<a href="#">6L2-45611-00</a> Shaft, propeller	<a href="#">Buy now</a>


# Lower Casing. Drive 1



F2


Ref	Part	
37	<a href="#">90501-10065</a> Spring compression 648456360000	<a href="#">Buy now</a>
38	<a href="#">6L2-45631-00</a> Clutch, dog	<a href="#">Buy now</a>
39	<a href="#">90250-05010</a> Pin straight 648456320000	<a href="#">Buy now</a>
40	<a href="#">648-45633-00</a> Ring, cross pin	<a href="#">Buy now</a>
41	<a href="#">648-45635-00</a> Plunger,shift	<a href="#">Buy now</a>
42	<a href="#">6L2-45361-03-4D</a> Cap, lower casing	<a href="#">Buy now</a>
43	<a href="#">93306-00612</a> Bearing(2hr)	<a href="#">Buy now</a>
44	<a href="#">93210-60MA3</a> O-ring(6j8)	<a href="#">Buy now</a>
46	<a href="#">93101-20M07</a> Oil seal	<a href="#">Buy now</a>
49	<a href="#">93210-60M99</a> O-ring(6t3)	<a href="#">Buy now</a>
50	<a href="#">6L2-44150-00</a> Shift cam assembly S	<a href="#">Buy now</a>
50	<a href="#">6L2-44150-10</a> Shift cam assembly L	<a href="#">Buy now</a>
51	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>

## Lower Casing. Drive 2




Ref	Part	
1	<a href="#">6L2-44368-00</a> Rubber, water seal 4	<a href="#">Buy now</a>
2	<a href="#">6L2-44361-00</a> Tube, water <b>S</b>	<a href="#">Buy now</a>
2	<a href="#">6L2-44361-10</a> Tube, water <b>L</b>	<a href="#">Buy now</a>
3	<a href="#">6L2-44366-00</a> Damper, water seal 2	<a href="#">Buy now</a>
4	<a href="#">93604-12M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
5	<a href="#">90105-10M12</a> Bolt (689)	<a href="#">Buy now</a>
6	<a href="#">92995-10600</a> Washer, plate	<a href="#">Buy now</a>
7	<a href="#">664-45371-01</a> Tab-trim	<a href="#">Buy now</a>
8	<a href="#">90105-08M02</a> Bolt hexagon	<a href="#">Buy now</a>
9	<a href="#">6L2-44367-00</a> Damper, water seal 3	<a href="#">Buy now</a>
10	<a href="#">6L2-45214-00</a> Cover, water inlet	<a href="#">Buy now</a>
11	<a href="#">6L2-45215-00</a> Cover, water inlet	<a href="#">Buy now</a>
12	<a href="#">90151-05M05</a> Screw, countersunk	<a href="#">Buy now</a>
13	<a href="#">90185-05002</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
14	<a href="#">6L2-45987-01</a> Spacer	<a href="#">Buy now</a>

## Lower Casing. Drive 2



Ref	Part	
15	<a href="#">689-45997-00</a> Spacer	<a href="#">Buy now</a>
16	<a href="#">92990-14200</a> Washer, plain	<a href="#">Buy now</a>
17	<a href="#">90171-14013</a> Nut(664)	<a href="#">Buy now</a>
18	<a href="#">91490-30022</a> Pin, cotter	<a href="#">Buy now</a>
19	<a href="#">664-45941-01-EL</a> Propeller (3x9-7/8"x9"-f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45943-01-EL</a> Propeller (3x9-7/8 x8 -f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45945-00-EL</a> Propeller (3x9-7/8 x10-1/2 -f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45947-01-EL</a> Propeller (3x9-7/8 x11-1/4 -f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45949-02-EL</a> Propeller (3x9-7/8 x13 -f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45952-00-EL</a> Propeller (3x9-7/8 x14 -f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45954-01-EL</a> Propeller (3x9-7/8 x12 -f) UR	<a href="#">Buy now</a>
19	<a href="#">664-45970-00-98</a> Propeller (3x9-1/8 x13 -f) UR STAINLESS	<a href="#">Buy now</a>
19	<a href="#">664-45972-00-98</a> Propeller (3x9-1/8 x12 -f) UR STAINLESS	<a href="#">Buy now</a>
20	<a href="#">618-W4591-00-EL</a> Propeller (3x10-5/8"x8-1/4"-f) DUAL THRUST PROP.	<a href="#">Buy now</a>
21	<a href="#">618-45986-10-98</a> Ring, deflector	<a href="#">Buy now</a>

# Oil Pump




6L20300-4060

**B6**

Ref	Part	
1	<a href="#">90201-08M93</a> Washer, plate (6g5)	<a href="#">Buy now</a>
2	<a href="#">6L2-11537-00</a> Gear, driven	<a href="#">Buy now</a>
3	<a href="#">6J8-13117-00</a> Collar, distance	<a href="#">Buy now</a>
4	<a href="#">93210-13M04</a> 93210-13m04	<a href="#">Buy now</a>
5	<a href="#">6L2-13200-00</a> Oil injection pump assembly	<a href="#">Buy now</a>
6	<a href="#">6L2-13471-00</a> Plug, drain	<a href="#">Buy now</a>
7	<a href="#">6L2-13475-00</a> Gasket, breather bolt	<a href="#">Buy now</a>
8	<a href="#">93210-19M82</a> O-ring(6j8)	<a href="#">Buy now</a>
9	<a href="#">97513-05518</a> Bolt, with washer	<a href="#">Buy now</a>
10	<a href="#">90109-05M33</a> Bolt	<a href="#">Buy now</a>
11	<a href="#">90445-07M32</a> Hose (l200)	<a href="#">Buy now</a>
12	<a href="#">90468-07M02</a> Clip (6e5)	<a href="#">Buy now</a>
13	<a href="#">6E9-13183-70</a> Valve check	<a href="#">Buy now</a>
14	<a href="#">90445-07M04</a> Hose(62t)	<a href="#">Buy now</a>
16	<a href="#">90445-07M16</a> Hose(62t)	<a href="#">Buy now</a>

# Oil Pump




6L20300-4060

**B6**

Ref	Part	
17	<a href="#">682-41237-50</a> Joint, link 2	<a href="#">Buy now</a>
18	<a href="#">6H1-41237-00</a> Joint, link	<a href="#">Buy now</a>
19	<a href="#">95380-05700</a> Nut (656)	<a href="#">Buy now</a>
20	<a href="#">90202-05088</a> Washer, plate (666)	<a href="#">Buy now</a>
21	<a href="#">90468-05M03</a> Clip(6j8)	<a href="#">Buy now</a>
22	<a href="#">6L2-21707-01</a> Oil tank comp.	<a href="#">Buy now</a>
23	<a href="#">6H4-21770-00</a> Oil tank cap assembly	<a href="#">Buy now</a>
24	<a href="#">6L2-21758-00</a> Washer, special 2	<a href="#">Buy now</a>
25	<a href="#">6H1-24633-00</a> Chain, Ball	<a href="#">Buy now</a>
26	<a href="#">6H1-21757-00</a> Washer, special 1	<a href="#">Buy now</a>
27	<a href="#">6J8-13411-00</a> Strainer, oil	<a href="#">Buy now</a>
28	<a href="#">6J8-13414-00</a> Gasket, strainer cover	<a href="#">Buy now</a>
29	<a href="#">6L2-13416-00</a> Pipe, oil 1	<a href="#">Buy now</a>
30	<a href="#">90467-08004</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
31	<a href="#">90467-11M08</a> Clip(72x)	<a href="#">Buy now</a>

# Oil Pump




6L20300-4060



**B6**

Ref	Part	
32	<a href="#">90445-11M03</a> Hose (I360)	<a href="#">Buy now</a>
33	<a href="#">90445-11M07</a> Hose (I70)	<a href="#">Buy now</a>
34	<a href="#">6J8-21744-00</a> Breather	<a href="#">Buy now</a>
35	<a href="#">6E5-24376-10</a> Pipe, joint 1	<a href="#">Buy now</a>
36	<a href="#">90467-10M04</a> Clip, pipe 1 (6e9)	<a href="#">Buy now</a>
37	<a href="#">90464-11M24</a> Clamp(6h1)	<a href="#">Buy now</a>
38	<a href="#">90446-10M02</a> Tube (6e5)	<a href="#">Buy now</a>
39	<a href="#">6A0-82317-00</a> Damper, ignition coil	<a href="#">Buy now</a>
40	<a href="#">624-42542-00</a> Collar	<a href="#">Buy now</a>
41	<a href="#">90119-06M65</a> Bolt, with washer	<a href="#">Buy now</a>
42	<a href="#">6L2-21798-00</a> Bracket, damper	<a href="#">Buy now</a>
43	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
44	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
45	<a href="#">6L2-85720-01</a> Oil level gauge assembly	<a href="#">Buy now</a>


# Remote Control Assy



A6

Ref	Part	
1	<a href="#">703-48230-15</a> Remote control assembly (7p) AP	<a href="#">Buy now</a>
2	<a href="#">703-48261-11</a> Arm, throttle	<a href="#">Buy now</a>
3	<a href="#">703-48153-00</a> Shaft, free accel.	<a href="#">Buy now</a>
4	<a href="#">703-48235-00</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">703-48268-00</a> Spacer 3	<a href="#">Buy now</a>
6	<a href="#">703-48264-00</a> Throttle, friction	<a href="#">Buy now</a>
7	<a href="#">95380-05600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
8	<a href="#">97380-05025</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">703-48265-00</a> Shaft Friction	<a href="#">Buy now</a>
10	<a href="#">93430-06024</a> Circlip (701)	<a href="#">Buy now</a>
11	<a href="#">703-48245-00</a> Plate, lock	<a href="#">Buy now</a>
12	<a href="#">703-48252-00</a> Roller, cam	<a href="#">Buy now</a>
13	<a href="#">701-48248-00</a> Roller, free accel	<a href="#">Buy now</a>
14	<a href="#">703-48198-00</a> Washer, wave 3	<a href="#">Buy now</a>
15	<a href="#">703-48243-00</a> Bushing 3	<a href="#">Buy now</a>


## Remote Control Assy



A6

Ref	Part	
16	<a href="#">703-48236-00</a> Bushing	<a href="#">Buy now</a>
17	<a href="#">703-48189-00</a> Retainer	<a href="#">Buy now</a>
18	<a href="#">703-48234-00</a> Roller, detent	<a href="#">Buy now</a>
19	<a href="#">703-48345-01</a> Cable end, remote control 2	<a href="#">Buy now</a>
20	<a href="#">703-48358-00</a> Anchor, cable	<a href="#">Buy now</a>
21	<a href="#">703-48244-00</a> Spring, free accel.	<a href="#">Buy now</a>
22	<a href="#">703-48238-00</a> Spring, detent	<a href="#">Buy now</a>
23	<a href="#">703-48246-00</a> Spacer 1	<a href="#">Buy now</a>
24	<a href="#">703-48227-00</a> Spring, neutral lock	<a href="#">Buy now</a>
25	<a href="#">703-48226-00</a> Plate, stopper	<a href="#">Buy now</a>
26	<a href="#">703-48222-00</a> Grip, control lever <b>SINGLE</b>	<a href="#">Buy now</a>
27	<a href="#">703-48223-00</a> Lock, neutral	<a href="#">Buy now</a>
28	<a href="#">703-48225-00</a> Cover	<a href="#">Buy now</a>
29	<a href="#">703-48219-00</a> Cover, lead	<a href="#">Buy now</a>
30	<a href="#">703-48281-00</a> Screw, flat head	<a href="#">Buy now</a>


# Remote Control Assy



A6

Ref	Part	
31	<a href="#">703-48282-00</a> Screw	<a href="#">Buy now</a>
32	<a href="#">97380-08030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
33	<a href="#">92990-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
34	<a href="#">98580-04010</a> Screw, pan head (e56)	<a href="#">Buy now</a>
35	<a href="#">98580-04006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
36	<a href="#">98580-05010</a> Screw, pan head(62x)	<a href="#">Buy now</a>
37	<a href="#">98580-03015</a> Screw, pan head (n151)	<a href="#">Buy now</a>
38	<a href="#">703-48291-10</a> Screw	<a href="#">Buy now</a>
39	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
40	<a href="#">703-48293-10</a> Spacer, remote control SINGLE	<a href="#">Buy now</a>
41	<a href="#">701-48287-00</a> Washer 1	<a href="#">Buy now</a>
42	<a href="#">703-48215-00</a> Graphic	<a href="#">Buy now</a>
43	<a href="#">703-82510-33</a> Main switch assembly	<a href="#">Buy now</a>
44	<a href="#">703-82577-00</a> Cap, key	<a href="#">Buy now</a>
45	<a href="#">703-82531-00</a> Wire, lead	<a href="#">Buy now</a>

## Remote Control Assy




---

Af



Ref	Part	
46	<u><a href="#">688-82575-01</a></u> Engine stop switch assembly	<a href="#">Buy now</a>
47	<u><a href="#">682-82556-00</a></u> Lanyard, stop switch	<a href="#">Buy now</a>
48	<u><a href="#">688-82586-21</a></u> Extension, wire harness L)5M (7P)	<a href="#">Buy now</a>
49	<u><a href="#">703-82540-00</a></u> Neutral switch assembly	<a href="#">Buy now</a>
50	<u><a href="#">703-83383-02</a></u> Buzzer	<a href="#">Buy now</a>
51	<u><a href="#">703-48284-00</a></u> Grommet	<a href="#">Buy now</a>
52	<u><a href="#">703-82591-00</a></u> Band	<a href="#">Buy now</a>
53	<u><a href="#">703-82592-00</a></u> Band	<a href="#">Buy now</a>
54	<u><a href="#">703-48224-00</a></u> Cover, control lever WITHOUT PT/T SW.	<a href="#">Buy now</a>
55	<u><a href="#">703-48221-00</a></u> Grip	<a href="#">Buy now</a>
56	<u><a href="#">703-48152-00</a></u> Knob, free accel	<a href="#">Buy now</a>
57	<u><a href="#">703-48212-00</a></u> Rear housing	<a href="#">Buy now</a>
58	<u><a href="#">703-48213-00</a></u> Back, panel	<a href="#">Buy now</a>
59	<u><a href="#">703-48271-00</a></u> Arm, shift	<a href="#">Buy now</a>
60	<u><a href="#">703-48211-01</a></u> Housing,1	<a href="#">Buy now</a>

# Remote Control Assy

Ref	Part	
61	<a href="#">703-48232-00</a> Drive gear	<a href="#">Buy now</a>



## Remote Control Box




67M0100-8280

A5

Ref	Part	
1	<a href="#">703-48230-15</a> Remote control assembly (7p) AP	<a href="#">Buy now</a>
2	<a href="#">701-48310-90</a> Cable, Remote Control L=11F UR	<a href="#">Buy now</a>
2	<a href="#">701-48320-00</a> Cable, Remote Control L=12F UR	<a href="#">Buy now</a>
2	<a href="#">701-48320-20</a> Cable, Remote Control L=13F UR	<a href="#">Buy now</a>
2	<a href="#">701-48320-50</a> Cable, Remote Control L=15F UR	<a href="#">Buy now</a>

# Repair Kit 1




6L20100-4260

**B2**

Ref	Part	
1	<a href="#">6L2-W0001-03</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">93102-25142</a> Oil seal (24.8x38x7-662)	<a href="#">Buy now</a>
3	<a href="#">93101-13M37</a> Oil seal(6a4)	<a href="#">Buy now</a>
4	<a href="#">93210-56M80</a> O-ring(6j8)	<a href="#">Buy now</a>
5	<a href="#">6L2-11181-A2</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
6	<a href="#">6L2-11193-A1</a> Gasket, head cover 1	<a href="#">Buy now</a>
7	<a href="#">6J8-12414-A0</a> Gasket, cover	<a href="#">Buy now</a>
8	<a href="#">6L2-41114-A1</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
9	<a href="#">6L2-41112-A1</a> Gasket, exhaust inner cover	<a href="#">Buy now</a>
10	<a href="#">93102-26M27</a> Oil seal(6j8)	<a href="#">Buy now</a>
11	<a href="#">93210-42159</a> O-ring (647)	<a href="#">Buy now</a>
12	<a href="#">6L2-13621-00</a> Gasket, valve seat	<a href="#">Buy now</a>
13	<a href="#">6L2-14384-00</a> Gasket, float chamber	<a href="#">Buy now</a>
14	<a href="#">6L2-14198-00</a> Gasket	<a href="#">Buy now</a>
15	<a href="#">93210-32738</a> O-ring(1wg)	<a href="#">Buy now</a>


# Repair Kit 1



Ref	Part	
16	<a href="#">6L2-45113-A1</a> Gasket, upper casing	<a href="#">Buy now</a>
17	<a href="#">6L2-41133-A1</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
18	<a href="#">6L2-W0093-00</a> Carburetor repair kit	<a href="#">Buy now</a>
21	<a href="#">6L2-14385-00</a> Float	<a href="#">Buy now</a>
22	<a href="#">6E5-14386-01</a> Pin, float	<a href="#">Buy now</a>
23	<a href="#">6L2-14392-00</a> Valve, needle	<a href="#">Buy now</a>
24	<a href="#">6L2-14399-00</a> Gasket	<a href="#">Buy now</a>
25	<a href="#">97980-04112</a> Screw, pan head (686)	<a href="#">Buy now</a>
26	<a href="#">6L2-14398-00</a> Gasket	<a href="#">Buy now</a>

B2

## Repair Kit 2




**B3**

Ref	Part	
1	<a href="#">6L2-W0001-C3</a> Gasket kit	<a href="#">Buy now</a>
2	<a href="#">6L2-41134-00</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
3	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">93210-45161</a> O-ring	<a href="#">Buy now</a>
5	<a href="#">6L2-44367-00</a> Damper, water seal 3	<a href="#">Buy now</a>
6	<a href="#">93101-20048</a> Oil seal (20x30x6-648)	<a href="#">Buy now</a>
7	<a href="#">6L2-45315-A0</a> Packing, lower casing	<a href="#">Buy now</a>
8	<a href="#">93210-60MA3</a> O-ring(6j8)	<a href="#">Buy now</a>
9	<a href="#">93101-20M07</a> Oil seal	<a href="#">Buy now</a>
10	<a href="#">93210-60M99</a> O-ring(6t3)	<a href="#">Buy now</a>
11	<a href="#">6L2-W0078-00</a> Water pump repair kit	<a href="#">Buy now</a>
12	<a href="#">6L2-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
14	<a href="#">6L2-44352-00</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">6L2-44322-00</a> Insert, cartridge	<a href="#">Buy now</a>
16	<a href="#">97095-06040</a> Bolt (682)	<a href="#">Buy now</a>


## Repair Kit 2

Ref	Part	
17	<a href="#">90280-03024</a> Key, woodruff(662)	<a href="#">Buy now</a>



**B3**


# Starter



**C2**

Ref	Part	
1	<a href="#">6L2-15710-02</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">6L2-15711-00-94</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">91690-40014</a> Pin, spring (6f2)	<a href="#">Buy now</a>
4	<a href="#">6L2-15758-01-94</a> Guide, rope	<a href="#">Buy now</a>
5	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
6	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
7	<a href="#">6L2-15762-00</a> Seal, rubber 2	<a href="#">Buy now</a>
8	<a href="#">689-15755-01</a> Handle, starter	<a href="#">Buy now</a>
9	<a href="#">6F5-15779-02</a> Cover	<a href="#">Buy now</a>
10	* item_description	<a href="#">Buy now</a>
11	<a href="#">6J8-15714-00</a> Drum, sheave	<a href="#">Buy now</a>
12	<a href="#">90510-08M04</a> Spring, spiral (677)	<a href="#">Buy now</a>
13	<a href="#">677-15717-01</a> Shaft	<a href="#">Buy now</a>
14	<a href="#">90201-06060</a> Washer, plate	<a href="#">Buy now</a>
15	<a href="#">97013-06025</a> Bolt(62y)	<a href="#">Buy now</a>


# Starter



**C2**

Ref	Part	
16	<a href="#">95303-06700</a> Nut	<a href="#">Buy now</a>
17	<a href="#">676-15741-03</a> Pawl, drive	<a href="#">Buy now</a>
18	<a href="#">93430-06M02</a> Circlip (689)	<a href="#">Buy now</a>
19	<a href="#">6J8-15705-00</a> Spring, drive pawl	<a href="#">Buy now</a>
20	<a href="#">6A0-15789-00</a> Damper	<a href="#">Buy now</a>
21	<a href="#">97095-06035</a> Bolt(j52)	<a href="#">Buy now</a>
23	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">99530-10014</a> Pin, dowel	<a href="#">Buy now</a>
26	<a href="#">656-15748-00</a> Plunger, starter stop	<a href="#">Buy now</a>
27	<a href="#">90501-10227</a> Spring, comprression(656)	<a href="#">Buy now</a>
28	<a href="#">6L2-15770-00</a> Cable comp., starter stop	<a href="#">Buy now</a>
29	<a href="#">6L2-15746-00</a> Arm	<a href="#">Buy now</a>
30	<a href="#">90387-06M51</a> Collar (6g0)	<a href="#">Buy now</a>
31	<a href="#">90119-06M53</a> Bolt, with washer(6l2)	<a href="#">Buy now</a>
32	<a href="#">6L2-15747-00</a> Link	<a href="#">Buy now</a>


# Starter



**C2**

Ref	Part	
33	<a href="#">6L2-15774-00</a> Stay 4	<a href="#">Buy now</a>
34	<a href="#">661-41262-02</a> Joint, choke lever	<a href="#">Buy now</a>
35	<a href="#">6L2-15772-00-94</a> Stay 2	<a href="#">Buy now</a>
36	<a href="#">97013-06020</a> Bolt(62y)	<a href="#">Buy now</a>
37	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
38	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
39	<a href="#">6L2-15723-01</a> Pulley, starter	<a href="#">Buy now</a>
40	<a href="#">90105-08M10</a> Bolt (6a0)	<a href="#">Buy now</a>
41	<a href="#">6L2-13437-21</a> Mark, caution	<a href="#">Buy now</a>

# Starting Motor




6L20010-4120

D2

Ref	Part	
1	<a href="#">6L2-81800-20</a> Starting motor assembly	<a href="#">Buy now</a>
2	<a href="#">6L2-81850-20</a> Armature assembly	<a href="#">Buy now</a>
3	<a href="#">682-81809-10</a> Washer kit	<a href="#">Buy now</a>
4	<a href="#">6L2-81833-10</a> Ring, stop	<a href="#">Buy now</a>
5	<a href="#">682-81810-11</a> Stator assembly	<a href="#">Buy now</a>
6	<a href="#">6L2-81820-20</a> Rear bracket assembly	<a href="#">Buy now</a>
7	<a href="#">6L2-81840-20</a> Brush holder assembly	<a href="#">Buy now</a>
8	<a href="#">682-81813-10</a> Spring, brush	<a href="#">Buy now</a>
9	<a href="#">6L2-81811-20</a> Brush 1	<a href="#">Buy now</a>
10	<a href="#">6L2-81812-20</a> Brush 2	<a href="#">Buy now</a>
11	<a href="#">682-81832-20</a> Clutch, over run	<a href="#">Buy now</a>
12	<a href="#">682-81830-11</a> Front bracket assembly	<a href="#">Buy now</a>
13	<a href="#">682-81831-00</a> Metal, front	<a href="#">Buy now</a>
14	<a href="#">682-81826-10</a> Bolt	<a href="#">Buy now</a>
15	<a href="#">682-81847-10</a> O-ring	<a href="#">Buy now</a>


# Starting Motor



Ref	Part	
16	<a href="#">682-81834-10</a> Ring	<a href="#">Buy now</a>
17	<a href="#">97013-08025</a> Bolt (682)	<a href="#">Buy now</a>
18	<a href="#">92903-08600</a> Washer, plain (663)	<a href="#">Buy now</a>

D2

# Steering




6L21100-2140

D5

Ref	Part	
3	<a href="#">90206-36M21</a> Washer, wave(63v)	<a href="#">Buy now</a>
4	<a href="#">90202-36M55</a> Washer, plate(63v)	<a href="#">Buy now</a>
5	<a href="#">90386-33M96</a> Bush(63v)	<a href="#">Buy now</a>
6	<a href="#">90386-34M97</a> Bush(63v)	<a href="#">Buy now</a>
7	<a href="#">6G1-42131-01</a> Cover, handle steering	<a href="#">Buy now</a>
8	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
9	<a href="#">6G1-42125-01</a> Bolt, friction adjusting	<a href="#">Buy now</a>
10	<a href="#">6G1-42126-00</a> Piece, friction	<a href="#">Buy now</a>
11	<a href="#">91490-16010</a> Pin, cotter	<a href="#">Buy now</a>
12	<a href="#">664-42119-00</a> Grip, steering handle	<a href="#">Buy now</a>
13	<a href="#">6F6-42177-A0</a> Rubber, handle	<a href="#">Buy now</a>
14	<a href="#">6L2-42137-00</a> Indicator, throttle	<a href="#">Buy now</a>
15	<a href="#">90269-02M09</a> Rivet(615)	<a href="#">Buy now</a>
16	<a href="#">90501-23215</a> Spring (655)	<a href="#">Buy now</a>
17	<a href="#">92903-10600</a> Washer, plate	<a href="#">Buy now</a>

# Steering




 6L21100-2140

D5

Ref	Part	
18	<a href="#">90149-05M13</a> Screw, countersunk	<a href="#">Buy now</a>
19	<a href="#">90386-08032</a> Bushing (650)	<a href="#">Buy now</a>
20	<a href="#">6G1-42138-01</a> Lever, throttle	<a href="#">Buy now</a>
21	<a href="#">6E0-42159-02</a> Stay	<a href="#">Buy now</a>
22	<a href="#">97885-05012</a> Screw,pan head (646)	<a href="#">Buy now</a>
23	<a href="#">6L2-26301-00</a> Throttle cable assembly	<a href="#">Buy now</a>
25	<a href="#">90386-15M73</a> Bush(6l2)	<a href="#">Buy now</a>
26	<a href="#">90206-15M18</a> Washer, wave(6l2)	<a href="#">Buy now</a>
27	<a href="#">90202-15M37</a> Washer, plate(6l2)	<a href="#">Buy now</a>
28	<a href="#">90386-12M72</a> Bush(6l2)	<a href="#">Buy now</a>
29	<a href="#">6L2-44125-00-94</a> Lever, shift rod	<a href="#">Buy now</a>
31	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
32	<a href="#">90202-06009</a> Washer plate 626427510000	<a href="#">Buy now</a>
33	<a href="#">91490-20010</a> Pin, cotter	<a href="#">Buy now</a>
34	<a href="#">6L2-44124-00</a> Link, shift rod	<a href="#">Buy now</a>

# Steering




6L21100-2140

D5

Ref	Part	
35	<a href="#">6L2-26363-00</a> End, cable	<a href="#">Buy now</a>
36	<a href="#">95380-06700</a> Nut	<a href="#">Buy now</a>
37	<a href="#">90202-05088</a> Washer, plate (666)	<a href="#">Buy now</a>
38	<a href="#">90202-05M38</a> Washer, plate(6l2)	<a href="#">Buy now</a>
39	<a href="#">90468-05M03</a> Clip(6j8)	<a href="#">Buy now</a>
40	<a href="#">6E0-83627-41</a> Label, caution 7	<a href="#">Buy now</a>
41	<a href="#">6E0-83627-51</a> Label, Caution 7	<a href="#">Buy now</a>

# Steering Guide




6J83100-2290

A4

Ref	Part	
1	<a href="#">689-61350-02</a> Steering guide attachment kit AP	<a href="#">Buy now</a>
2	<a href="#">689-61351-01</a> Rod, steering	<a href="#">Buy now</a>
3	<a href="#">90201-10M20</a> Washer, plate (663)	<a href="#">Buy now</a>
4	<a href="#">90185-09M01</a> Nut, nylon (663)	<a href="#">Buy now</a>
5	<a href="#">90170-09M03</a> Nut (689)	<a href="#">Buy now</a>
6	<a href="#">90387-10M42</a> Coller (688)	<a href="#">Buy now</a>
7	<a href="#">6E5-61355-00</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">90201-10M63</a> Washer, plate	<a href="#">Buy now</a>
9	<a href="#">6E5-43145-01</a> Cap, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">93210-16275</a> O-ring	<a href="#">Buy now</a>

# Top Cowling




 6L21300-2010

A4

Ref	Part	
1	<a href="#">6L2-42610-30-4D</a> Top Cowling assembly	<a href="#">Buy now</a>
1	<a href="#">6L3-42610-30-4D</a> Top Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">6L2-42615-00</a> Seal	<a href="#">Buy now</a>
3	<a href="#">6G1-42651-71</a> Hook	<a href="#">Buy now</a>
4	<a href="#">6L2-42647-00</a> Holder, clamp band	<a href="#">Buy now</a>
5	<a href="#">90266-04M00</a> Rivet 2 (662)	<a href="#">Buy now</a>
6	<a href="#">6L2-42613-01-4D</a> Molding, air duct	<a href="#">Buy now</a>
7	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
8	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">6L2-W0070-13</a> Graphic Set	<a href="#">Buy now</a>
10	<a href="#">6L2-42677-20</a> Graphic, rear	<a href="#">Buy now</a>
10	<a href="#">6L3-42677-20</a> Graphic, front	<a href="#">Buy now</a>
11	<a href="#">6L2-42678-11</a> Graphic, rear	<a href="#">Buy now</a>
11	<a href="#">6L3-42678-11</a> Graphic, front	<a href="#">Buy now</a>
12	<a href="#">90266-04M04</a> Rivet(6e7)	<a href="#">Buy now</a>

## Top Cowling


Ref	Part	
13	<a href="#">6L2-13437-00</a> Mark, Caution	<a href="#">Buy now</a>



 6L21300-2010

A4

## Upper Casing




F1

Ref	Part	
1	<a href="#">6L2-45111-02-4D</a> Casing, upper S	<a href="#">Buy now</a>
1	<a href="#">6L2-45111-12-4D</a> Casing, upper L	<a href="#">Buy now</a>
2	<a href="#">6L2-45151-01-4D</a> Cover, upper casing	<a href="#">Buy now</a>
3	<a href="#">6L2-45115-00</a> Gasket, upper casing	<a href="#">Buy now</a>
4	<a href="#">90159-06M11</a> Screw, with washer(6l2)	<a href="#">Buy now</a>
5	<a href="#">93604-12M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
6	<a href="#">6L2-82127-00</a> Wire, lead 2	<a href="#">Buy now</a>
7	<a href="#">90157-06M06</a> Screw, pan head(6m7)	<a href="#">Buy now</a>
8	<a href="#">97075-08030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
9	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
10	<a href="#">6L2-41131-00-5B</a> Manifold, ext. 1	<a href="#">Buy now</a>
10	<a href="#">6L3-41131-00-5B</a> Manifold, ext. 1	<a href="#">Buy now</a>
11	<a href="#">6L2-41134-00</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
12	<a href="#">6L2-45123-01</a> Gasket, muffler	<a href="#">Buy now</a>
13	<a href="#">6L2-41133-A1</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>

## Upper Casing

Ref	Part	
14	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
15	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>



**F1**

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.