



# Yamaha 2BMH 1988

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Bracket 1</b> .....	3
<b>Carburetor</b> .....	5
<b>Cowling &amp; Fuel</b> .....	7
<b>Cylinder &amp; Crankcase</b> .....	11
<b>Generator</b> .....	14
<b>Lower Casing &amp; Drive</b> .....	15
<b>Repair Kit</b> .....	18
<b>Starter</b> .....	21
<b>Upper Casing</b> .....	22

## Bracket 1




Ref	Part	
2	<a href="#">6E0431160000</a> Screw, transom clamp	<a href="#">Buy now</a>
3	<a href="#">6E0431180000</a> Handle, transom clamp	<a href="#">Buy now</a>
4	<a href="#">9025404M0000</a> Pin(6a1)	<a href="#">Buy now</a>
5	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
6	<a href="#">901010821700</a> Bolt 6464313100	<a href="#">Buy now</a>
7	<a href="#">902020802200</a> Washer 6464313202	<a href="#">Buy now</a>
8	<a href="#">6A1431130000</a> Plate, clamp bracket	<a href="#">Buy now</a>
9	<a href="#">953800860000</a> Nut (661)	<a href="#">Buy now</a>
12	<a href="#">646425370100</a> Bushing, pivot shaft	<a href="#">Buy now</a>
13	<a href="#">932104604400</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">973950604500</a> Bolt, hexagon	<a href="#">Buy now</a>
15	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
16	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
17	<a href="#">663451190000</a> Cap, grease nipple	<a href="#">Buy now</a>
18	<a href="#">937000600400</a> Nipple, grease(6a1)	<a href="#">Buy now</a>

## Bracket 1




Ref	Part	
19	<a href="#">646425280000</a> Piece, friction	<a href="#">Buy now</a>
20	<a href="#">901220600400</a> Bolt, wing (646)	<a href="#">Buy now</a>
21	<a href="#">905011227200</a> Spring 6464252401	<a href="#">Buy now</a>
22	<a href="#">6A1433510000</a> Receiver, thrust	<a href="#">Buy now</a>
23	<a href="#">6A1433710000</a> Bolt, receiver	<a href="#">Buy now</a>
24	<a href="#">902010604000</a> Washer 6464337400	<a href="#">Buy now</a>
25	<a href="#">901750600800</a> Nut, Wing	<a href="#">Buy now</a>
26	<a href="#">916902000600</a> Pin, spring (647)	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
1	<a href="#">6A1143010000</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">6A1143810000</a> Body, Float Chamber	<a href="#">Buy now</a>
3	<a href="#">646143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
5	<a href="#">646143870000</a> Arm, Diaphragm	<a href="#">Buy now</a>
6	<a href="#">646143860000</a> Pin, float	<a href="#">Buy now</a>
7	<a href="#">646143434800</a> Jet Main (# 96)	<a href="#">Buy now</a>
9	<a href="#">985800401000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
10	<a href="#">6A1144480000</a> Lever, choke valve	<a href="#">Buy now</a>
11	<a href="#">6A1142170000</a> Valve, Choke	<a href="#">Buy now</a>
12	<a href="#">646143570000</a> Washer	<a href="#">Buy now</a>
13	<a href="#">6A1143560000</a> Washer	<a href="#">Buy now</a>
14	<a href="#">646143580000</a> Nut	<a href="#">Buy now</a>
15	<a href="#">6A1143900000</a> Needle Valve Assembly	<a href="#">Buy now</a>
19	<a href="#">646142110200</a> Screw, pilot adjusting	<a href="#">Buy now</a>
20	<a href="#">646142120100</a> Spring, pilot adjusting	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
21	<a href="#">646143120800</a> Valve, throttle	<a href="#">Buy now</a>
22	<a href="#">6A1141160000</a> Needle	<a href="#">Buy now</a>
23	<a href="#">646141370000</a> Clip	<a href="#">Buy now</a>
24	<a href="#">646141360000</a> Seat, spring	<a href="#">Buy now</a>
25	<a href="#">646143310100</a> Spring,throttle valve	<a href="#">Buy now</a>
26	<a href="#">646141580000</a> Top, mixing chamber	<a href="#">Buy now</a>
27	<a href="#">6A1144970000</a> Stay, throttle wire	<a href="#">Buy now</a>
28	<a href="#">646143210000</a> Screw, throttle	<a href="#">Buy now</a>
30	<a href="#">6A1143140000</a> Bar, throttle	<a href="#">Buy now</a>
31	<a href="#">6A1141630000</a> Spacer	<a href="#">Buy now</a>
32	<a href="#">646142290100</a> O-ring	<a href="#">Buy now</a>
33	<a href="#">6A1141270000</a> Clip	<a href="#">Buy now</a>
34	<a href="#">646141250100</a> Screw	<a href="#">Buy now</a>
36	<a href="#">6A1143940000</a> Screw, drain	<a href="#">Buy now</a>
37	<a href="#">6A1143980000</a> Gasket	<a href="#">Buy now</a>

# Cowling & Fuel




Ref	Part	
1	<a href="#">6A1144410200</a> Silencer, intake 2	<a href="#">Buy now</a>
2	<a href="#">9017305M0000</a> Nut, square (6a1)	<a href="#">Buy now</a>
3	<a href="#">6A1426770100</a> Graphic Front	<a href="#">Buy now</a>
4	<a href="#">6A1144420000</a> Spacer 1	<a href="#">Buy now</a>
6	<a href="#">6A1412710000</a> Knob, choke	<a href="#">Buy now</a>
7	<a href="#">9321008M2900</a> O-ring (6a1)	<a href="#">Buy now</a>
8	<a href="#">6A1241100100</a> Fuel tank assembly	<a href="#">Buy now</a>
9	<a href="#">6A1241980000</a> Seat, rubber	<a href="#">Buy now</a>
10	<a href="#">6A1246100200</a> Cap assembly	<a href="#">Buy now</a>
11	<a href="#">6A1246310000</a> Screw, air	<a href="#">Buy now</a>
12	<a href="#">904300400500</a> Gasket 6112463200	<a href="#">Buy now</a>
13	<a href="#">904301411700</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">646246150100</a> Gasket, Plate 1	<a href="#">Buy now</a>
15	<a href="#">905011037400</a> Spring, Compression	<a href="#">Buy now</a>
16	<a href="#">929900420000</a> Ybs66-4 washer, plain	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
17	<a href="#">905011026000</a> Spring, safety 6152463500	<a href="#">Buy now</a>
18	<a href="#">646242410000</a> Indicator	<a href="#">Buy now</a>
19	<a href="#">973130601800</a> Bolt, hexagon	<a href="#">Buy now</a>
20	<a href="#">953030660000</a> Nut(661)	<a href="#">Buy now</a>
21	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>
22	<a href="#">9020106M3000</a> Washer, plate (6a1)	<a href="#">Buy now</a>
23	<a href="#">6A1241810000</a> Damper, locating	<a href="#">Buy now</a>
24	<a href="#">6A1245000200</a> Fuel cock assembly 1	<a href="#">Buy now</a>
25	<a href="#">6A1243110000</a> Pipe 1	<a href="#">Buy now</a>
26	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
27	<a href="#">656W28100100</a> Tool kit	<a href="#">Buy now</a>
30	<a href="#">6A1241535000</a> Indicator, Cock	<a href="#">Buy now</a>
31	<a href="#">6A1241545000</a> Indicator, Shift	<a href="#">Buy now</a>
33	<a href="#">987800501200</a> Screw(617)	<a href="#">Buy now</a>
34	<a href="#">9018305M0000</a> Nut, spring (6a1)	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
35	<a href="#">985800501200</a> Screw,pan head (646)	<a href="#">Buy now</a>
36	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
37	<a href="#">925800604000</a> Screw pan head	<a href="#">Buy now</a>
39	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
40	<a href="#">925800602500</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
41	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
43	<a href="#">6A1427920100</a> Mark (100:1)	<a href="#">Buy now</a>
44	<a href="#">6A1412120100</a> Arm, accel.	<a href="#">Buy now</a>
45	<a href="#">6A1412110000</a> Link,accel	<a href="#">Buy now</a>
46	<a href="#">929900510000</a> Ybs67-5 washer, spring	<a href="#">Buy now</a>
47	<a href="#">973130501000</a> Bolt, hexagon	<a href="#">Buy now</a>
48	<a href="#">6A1143650000</a> Pin, clevis	<a href="#">Buy now</a>
49	<a href="#">990010460000</a> Circlip (eu0)	<a href="#">Buy now</a>
50	<a href="#">6A1416370000</a> Knob, magneto control	<a href="#">Buy now</a>
52	<a href="#">6A1412230000</a> Washer, lock 1	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
53	<a href="#">985030502500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
54	<a href="#">9050112M1600</a> Spring (6a1)	<a href="#">Buy now</a>
55	<a href="#">6A1825500200</a> Stop switch assembly	<a href="#">Buy now</a>
56	<a href="#">6A1825410000</a> Wire, Lead	<a href="#">Buy now</a>
57	<a href="#">953800870000</a> Nut(661)	<a href="#">Buy now</a>
58	<a href="#">985800501000</a> Screw, pan head(62x)	<a href="#">Buy now</a>
59	<a href="#">6A1823751000</a> Cover, Plug Cap	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
2	<a href="#">6A1151006094</a> Crank case assembly	<a href="#">Buy now</a>
3	<a href="#">903360600100</a> Plug, blind 6551131300	<a href="#">Buy now</a>
4	<a href="#">650144850200</a> Pipe, joint	<a href="#">Buy now</a>
5	<a href="#">624113790000</a> Valve, check	<a href="#">Buy now</a>
6	<a href="#">970950604000</a> Bolt (682)	<a href="#">Buy now</a>
7	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">995301001400</a> Pin, dowel	<a href="#">Buy now</a>
9	<a href="#">6A1111110194</a> Head, cylinder 1	<a href="#">Buy now</a>
10	<a href="#">6A111181A100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
11	<a href="#">973950602500</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">6A1114000000</a> Crankshaft assembly	<a href="#">Buy now</a>
14	<a href="#">646114120100</a> Crank 1	<a href="#">Buy now</a>
15	<a href="#">6A1114220000</a> Crank 2	<a href="#">Buy now</a>
16	<a href="#">646116810000</a> Pin, crank 1	<a href="#">Buy now</a>
17	<a href="#">933103143900</a> Brg,cyl-cal roller 5g tm	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
18	<a href="#">646116510200</a> Rod, connecting	<a href="#">Buy now</a>
19	<a href="#">933060040900</a> Brg,r-b 6004 42mm 69g nk	<a href="#">Buy now</a>
20	<a href="#">933063020400</a> Brg,r-b 6302 42mm 82g nk	<a href="#">Buy now</a>
21	<a href="#">93310210M000</a> Bearing (27v)	<a href="#">Buy now</a>
22	<a href="#">931022010800</a> Oil seal	<a href="#">Buy now</a>
23	<a href="#">902013530000</a> Washer, Plate	<a href="#">Buy now</a>
24	<a href="#">931021508500</a> Oil seal(6a1)	<a href="#">Buy now</a>
25	<a href="#">646116360100</a> Piston (0.50Mm O/s)	<a href="#">Buy now</a>
26	<a href="#">646116010100</a> Piston Ring Set (Std)	<a href="#">Buy now</a>
27	<a href="#">646116330000</a> Pin,piston	<a href="#">Buy now</a>
28	<a href="#">934501102100</a> Circlip 101116340000	<a href="#">Buy now</a>
29	<a href="#">9044507MA300</a> Hose (I200)	<a href="#">Buy now</a>
30	<a href="#">904670601600</a> Clip (655)	<a href="#">Buy now</a>
31	<a href="#">6A1136100000</a> Reed valve assembly	<a href="#">Buy now</a>
32	<a href="#">6A1W00040000</a> Reed set	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
33	<a href="#">6A1136210000</a> Gasket, valve seat	<a href="#">Buy now</a>
34	<a href="#">6A1241410000</a> Protector, fuel tank	<a href="#">Buy now</a>
35	<a href="#">9010506M2300</a> Bolt (6g1)	<a href="#">Buy now</a>
37	<a href="#">904650802800</a> Clamp (1e6)	<a href="#">Buy now</a>
39	<a href="#">6A1157710000</a> Stay 1	<a href="#">Buy now</a>
40	<a href="#">973130606000</a> Bolt, hexagon	<a href="#">Buy now</a>

# Generator




Ref	Part	
2	<a href="#">6A1813112000</a> Coil, Ignition 1	<a href="#">Buy now</a>
3	<a href="#">901590504000</a> Screw, pan head(4my)	<a href="#">Buy now</a>
4	<a href="#">806813212000</a> Contact breaker assembly (l.h)	<a href="#">Buy now</a>
5	<a href="#">985070401000</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
6	<a href="#">624813252000</a> Condenser	<a href="#">Buy now</a>
7	<a href="#">116813312000</a> Lubricator	<a href="#">Buy now</a>
8	<a href="#">110813462100</a> Screw, pan head	<a href="#">Buy now</a>
11	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
12	<a href="#">6A1813620000</a> Cover, hole 1	<a href="#">Buy now</a>
13	<a href="#">953141060000</a> Nut(3bm)	<a href="#">Buy now</a>
14	<a href="#">929901010000</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
15	<a href="#">973130603000</a> Bolt	<a href="#">Buy now</a>
16	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>
17	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">6G1823702000</a> Plug cap assembly	<a href="#">Buy now</a>

# Lower Casing & Drive




Ref	Part	
1	<a href="#">6A14530001EK</a> Lower Unit assembly	<a href="#">Buy now</a>
4	<a href="#">931031105100</a> Oil seal (11x21x8-646)	<a href="#">Buy now</a>
5	<a href="#">933060000100</a> Brg,r-b 6000 26mm 19g ky	<a href="#">Buy now</a>
6	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
7	<a href="#">903400800200</a> Plug, straight screw	<a href="#">Buy now</a>
8	<a href="#">936051506500</a> Pin, dowel	<a href="#">Buy now</a>
9	<a href="#">973950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
10	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">6GDG43250000</a> Protector, oil seal	<a href="#">Buy now</a>
13	<a href="#">931031005200</a> Oil seal (10x21x10-646)	<a href="#">Buy now</a>
14	<a href="#">932104210100</a> O-ring (183)	<a href="#">Buy now</a>
15	<a href="#">973900601400</a> Bolt(gj3)	<a href="#">Buy now</a>
17	<a href="#">999990212900</a> Cover, water pump housing	<a href="#">Buy now</a>
19	<a href="#">932101912300</a> O-ring (646)	<a href="#">Buy now</a>
20	<a href="#">936040906800</a> Pin,dowel (646)	<a href="#">Buy now</a>

# Lower Casing & Drive




Ref	Part	
21	<a href="#">646443660100</a> Damper, water seal 2	<a href="#">Buy now</a>
22	<a href="#">646443520100</a> Impeller	<a href="#">Buy now</a>
23	<a href="#">936040906600</a> Pin, dowel	<a href="#">Buy now</a>
24	<a href="#">646443230000</a> Outer plate,cartridge	<a href="#">Buy now</a>
25	<a href="#">646443220000</a> Insert, cartridge	<a href="#">Buy now</a>
26	<a href="#">973900501600</a> Bolt, with washer	<a href="#">Buy now</a>
27	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
28	<a href="#">6A1443610000</a> Tube, water	<a href="#">Buy now</a>
29	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
30	<a href="#">6A1455100100</a> Drive shaft assembly	<a href="#">Buy now</a>
31	<a href="#">9020111M4900</a> Washer, plate (6e0)	<a href="#">Buy now</a>
33	<a href="#">646455510000</a> Pinion	<a href="#">Buy now</a>
34	<a href="#">990010660000</a> Circlip(53l)	<a href="#">Buy now</a>
35	<a href="#">646455600000</a> Gear	<a href="#">Buy now</a>
36	<a href="#">646455672000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
37	<a href="#">902500300200</a> Pin, straight(6a1)	<a href="#">Buy now</a>
38	<a href="#">914903004500</a> Pin, cotter (am5)	<a href="#">Buy now</a>
39	<a href="#">6A1459430000</a> Propeller assembly (3x7-1/4"x4"-a)	<a href="#">Buy now</a>

# Repair Kit



Ref	Part	
1	<a href="#">6A1W00010000</a> Gasket kit, power unit	<a href="#">Buy now</a>
2	<a href="#">9321008M2900</a> O-ring (6a1)	<a href="#">Buy now</a>
3	<a href="#">646111810100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
4	<a href="#">6GDE36210000</a> Gasket, valve seat	<a href="#">Buy now</a>
5	<a href="#">931022007000</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">9310215M3200</a> Oil seal(6a1)	<a href="#">Buy now</a>
7	<a href="#">646146230100</a> Gasket, exhaust	<a href="#">Buy now</a>
8	<a href="#">6A1146130100</a> Gasket, exhaust 1	<a href="#">Buy now</a>
9	<a href="#">652143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
10	<a href="#">6A1W00930100</a> Carburetor Repair Kit	<a href="#">Buy now</a>
11	<a href="#">646143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
13	<a href="#">646143860000</a> Pin, float	<a href="#">Buy now</a>
14	<a href="#">985800401000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
15	<a href="#">6A1143900000</a> Needle Valve Assembly	<a href="#">Buy now</a>
17	<a href="#">646142110200</a> Screw, pilot adjusting	<a href="#">Buy now</a>

# Repair Kit




186A1171E109


Ref	Part	
18	<a href="#">6A1141160000</a> Needle	<a href="#">Buy now</a>
19	<a href="#">646141370000</a> Clip	<a href="#">Buy now</a>
21	<a href="#">646142290100</a> O-ring	<a href="#">Buy now</a>
22	<a href="#">6A1143980000</a> Gasket	<a href="#">Buy now</a>
24	<a href="#">904300800300</a> Gasket	<a href="#">Buy now</a>
25	<a href="#">931031105100</a> Oil seal (11x21x8-646)	<a href="#">Buy now</a>
26	<a href="#">932101912300</a> O-ring (646)	<a href="#">Buy now</a>
27	<a href="#">932104210100</a> O-ring (183)	<a href="#">Buy now</a>
28	<a href="#">6A1W00780100</a> Water pump repair kit	<a href="#">Buy now</a>
29	<a href="#">936040906800</a> Pin,dowel (646)	<a href="#">Buy now</a>
32	<a href="#">646443230000</a> Outer plate,cartridge	<a href="#">Buy now</a>
33	<a href="#">646443520100</a> Impeller	<a href="#">Buy now</a>
34	<a href="#">646443220000</a> Insert, cartridge	<a href="#">Buy now</a>
35	<a href="#">6GDG43250000</a> Protector, oil seal	<a href="#">Buy now</a>
36	<a href="#">973900501600</a> Bolt, with washer	<a href="#">Buy now</a>

# Repair Kit

Ref	Part	
37	<a href="#">646443660100</a> Damper, water seal 2	<a href="#">Buy now</a>




# Starter



\* CUT FROM 50M ROLLS, PART NO. 9089044372, CUTTING LENGTH 1.3M


Ref	Part	
1	<a href="#">6A1157100000</a> Starter ass'y	<a href="#">Buy now</a>
2	<a href="#">6A1157110000</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">6A1157140000</a> Drum, sheave	<a href="#">Buy now</a>
4	<a href="#">6A1157670000</a> Spring, return	<a href="#">Buy now</a>
5	<a href="#">6A1157410000</a> Pawl, drive	<a href="#">Buy now</a>
6	<a href="#">6A1157130000</a> Spring, starter	<a href="#">Buy now</a>
7	<a href="#">7G5157160000</a> Plate, drive	<a href="#">Buy now</a>
8	<a href="#">6A1157050000</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">970130601200</a> Bolt(gh1)	<a href="#">Buy now</a>
10	<a href="#">6A1157550100</a> Handle, Starter	<a href="#">Buy now</a>
12	<a href="#">973130601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
13	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">6A1157230094</a> Pulley, starter	<a href="#">Buy now</a>
15	<a href="#">927800601400</a> Screw flat head	<a href="#">Buy now</a>

# Upper Casing



Ref	Part	
1	<a href="#">6A14511101EK</a> Casing, Upper	<a href="#">Buy now</a>
3	<a href="#">936051506500</a> Pin, dowel	<a href="#">Buy now</a>
4	<a href="#">973950602500</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">6A1451510000</a> Cover, upper casing	<a href="#">Buy now</a>
7	<a href="#">6A1451150000</a> Gasket, upper casing	<a href="#">Buy now</a>
8	<a href="#">925800601600</a> Screw pan head	<a href="#">Buy now</a>
10	<a href="#">6A141137009M</a> Guide, exhaust	<a href="#">Buy now</a>
11	<a href="#">6A1146130100</a> Gasket, exhaust 1	<a href="#">Buy now</a>
12	<a href="#">64614623A100</a> Gasket, exhaust	<a href="#">Buy now</a>
13	<a href="#">932101912300</a> O-ring (646)	<a href="#">Buy now</a>
14	<a href="#">973950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
17	<a href="#">646421190200</a> Grip, steering handle	<a href="#">Buy now</a>
18	<a href="#">902010911700</a> Washer 1 6154367300	<a href="#">Buy now</a>
19	<a href="#">929900820000</a> Ybs66-8 washer, plain	<a href="#">Buy now</a>

## Upper Casing



Ref	Part	
20	<a href="#">929900810000</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
22	<a href="#">988800810000</a> Nut, hex.	<a href="#">Buy now</a>
23	<a href="#">646425910000</a> Holder, shear pin	<a href="#">Buy now</a>
24	<a href="#">6464211200EK</a> Handle, Steering	<a href="#">Buy now</a>
26	<a href="#">973950605500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
27	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.