



# Yamaha 2BMH 1997

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Bracket 1</b> .....	3
<b>Carburetor</b> .....	5
<b>Cowling &amp; Fuel</b> .....	8
<b>Cylinder &amp; Crankcase</b> .....	12
<b>Generator</b> .....	15
<b>Lower Casing &amp; Drive 1</b> .....	17
<b>Repair Kit</b> .....	20
<b>Starter</b> .....	23
<b>Upper Casing</b> .....	24

## Bracket 1




Ref	Part	
1	<a href="#">6A143111034D</a> Bracket, clamp	<a href="#">Buy now</a>
2	<a href="#">6A143112004D</a> Bracket, clamp	<a href="#">Buy now</a>
3	<a href="#">6A1431910000</a> Shaft, stopper	<a href="#">Buy now</a>
4	<a href="#">6A1431920000</a> Knob, stopper	<a href="#">Buy now</a>
5	<a href="#">916903001400</a> Pin, spring (647)	<a href="#">Buy now</a>
6	<a href="#">6E0431160100</a> Screw, transom clamp	<a href="#">Buy now</a>
7	<a href="#">6E0431180100</a> Handle, transom clamp	<a href="#">Buy now</a>
8	<a href="#">9024304M0100</a> Pin(6a1)	<a href="#">Buy now</a>
9	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
10	<a href="#">901010821700</a> Bolt 6464313100	<a href="#">Buy now</a>
11	<a href="#">902020802200</a> Washer 6464313202	<a href="#">Buy now</a>
12	<a href="#">6A1431130100</a> Plate, clamp bracket	<a href="#">Buy now</a>
13	<a href="#">953800860000</a> Nut (661)	<a href="#">Buy now</a>
14	<a href="#">6A143311028D</a> Bracket, Swivel 1	<a href="#">Buy now</a>
15	<a href="#">6A143312004D</a> Bracket, swivel 2	<a href="#">Buy now</a>

## Bracket 1



Ref	Part	
16	<a href="#">646425370100</a> Bushing, pivot shaft	<a href="#">Buy now</a>
17	<a href="#">932104604400</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9011906M9800</a> Bolt, with washer	<a href="#">Buy now</a>
19	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
20	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
21	<a href="#">646425280000</a> Piece, friction	<a href="#">Buy now</a>
22	<a href="#">901220600400</a> Bolt, wing (646)	<a href="#">Buy now</a>
23	<a href="#">905011227200</a> Spring 6464252401	<a href="#">Buy now</a>
24	<a href="#">6A1433510000</a> Receiver, thrust	<a href="#">Buy now</a>
25	<a href="#">6A1433710000</a> Bolt, receiver	<a href="#">Buy now</a>
26	<a href="#">902010604000</a> Washer 6464337400	<a href="#">Buy now</a>
27	<a href="#">901750600800</a> Nut, Wing	<a href="#">Buy now</a>
28	<a href="#">916902000600</a> Pin, spring (647)	<a href="#">Buy now</a>


# Carburetor



1V6A1100E102


Ref	Part	
1	<a href="#">6A1143010300</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">646141580000</a> Top, mixing chamber	<a href="#">Buy now</a>
3	<a href="#">6A1144970000</a> Stay, throttle wire	<a href="#">Buy now</a>
4	<a href="#">646143210000</a> Screw, throttle	<a href="#">Buy now</a>
6	<a href="#">6A1143140000</a> Bar, throttle	<a href="#">Buy now</a>
7	<a href="#">6A1141630000</a> Spacer	<a href="#">Buy now</a>
8	<a href="#">646142290100</a> O-ring	<a href="#">Buy now</a>
9	<a href="#">6A1143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
10	<a href="#">6A1143410100</a> Nozzle, main	<a href="#">Buy now</a>
11	<a href="#">6A1143434800</a> Jet Main (#96)	<a href="#">Buy now</a>
12	<a href="#">6A1143810200</a> Body, float chamber	<a href="#">Buy now</a>
13	<a href="#">978900500600</a> Screw,panhead (eg9)	<a href="#">Buy now</a>
14	<a href="#">646141980100</a> Gasket	<a href="#">Buy now</a>
15	<a href="#">6A1141161000</a> Needle	<a href="#">Buy now</a>
16	<a href="#">646141370000</a> Clip	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
17	<a href="#">646141360000</a> Seat, spring	<a href="#">Buy now</a>
18	<a href="#">646143310100</a> Spring, throttle valve	<a href="#">Buy now</a>
19	<a href="#">646143120800</a> Valve, throttle	<a href="#">Buy now</a>
20	<a href="#">646141250100</a> Screw	<a href="#">Buy now</a>
21	<a href="#">6A1141270100</a> Clip	<a href="#">Buy now</a>
22	<a href="#">6A1143580100</a> Nut	<a href="#">Buy now</a>
23	<a href="#">6A1142120000</a> Spring, Pilot Adjusting	<a href="#">Buy now</a>
24	<a href="#">646142110200</a> Screw, pilot adjusting	<a href="#">Buy now</a>
25	<a href="#">979800411000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
26	<a href="#">6A1143920000</a> Valve, needle	<a href="#">Buy now</a>
27	<a href="#">6A1143860000</a> Pin, float	<a href="#">Buy now</a>
28	<a href="#">6A1143850000</a> Float	<a href="#">Buy now</a>
29	<a href="#">985800300600</a> Screw, pan head(78g)	<a href="#">Buy now</a>
30	<a href="#">646143580000</a> Nut	<a href="#">Buy now</a>
31	<a href="#">6A1143560000</a> Washer	<a href="#">Buy now</a>

## Carburetor




Ref	Part	
32	<a href="#">646143570000</a> Washer	<a href="#">Buy now</a>
33	<a href="#">6A1144480000</a> Lever, choke valve	<a href="#">Buy now</a>
34	<a href="#">6A1142170100</a> Valve Choke	<a href="#">Buy now</a>
35	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>

# Cowling & Fuel




Ref	Part	
1	<a href="#">6A1144410200</a> Silencer, intake 2	<a href="#">Buy now</a>
2	<a href="#">9017305M0000</a> Nut, square (6a1)	<a href="#">Buy now</a>
3	<a href="#">6A1426770100</a> Graphic Front	<a href="#">Buy now</a>
4	<a href="#">6A1144420000</a> Spacer 1	<a href="#">Buy now</a>
6	<a href="#">6A1412710000</a> Knob, choke	<a href="#">Buy now</a>
7	<a href="#">9321008M2900</a> O-ring (6a1)	<a href="#">Buy now</a>
8	<a href="#">6A1241100100</a> Fuel tank assembly	<a href="#">Buy now</a>
9	<a href="#">6A1241980000</a> Seat, rubber	<a href="#">Buy now</a>
10	<a href="#">6A1246100100</a> Cap assembly	<a href="#">Buy now</a>
11	<a href="#">6A1246310000</a> Screw, air	<a href="#">Buy now</a>
12	<a href="#">904300400500</a> Gasket 6112463200	<a href="#">Buy now</a>
13	<a href="#">904301411700</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">646246150100</a> Gasket, Plate 1	<a href="#">Buy now</a>
15	<a href="#">905011037400</a> Spring, Compression	<a href="#">Buy now</a>
16	<a href="#">929070420000</a> Washer(6e1)	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
17	<a href="#">905011026000</a> Spring, safety 6152463500	<a href="#">Buy now</a>
18	<a href="#">646242410000</a> Indicator	<a href="#">Buy now</a>
19	<a href="#">970800601800</a> Bolt (fj0)	<a href="#">Buy now</a>
20	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
21	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
22	<a href="#">9020106M3000</a> Washer, plate (6a1)	<a href="#">Buy now</a>
23	<a href="#">6A1241810000</a> Damper, locating	<a href="#">Buy now</a>
24	<a href="#">6A1245000200</a> Fuel cock assembly 1	<a href="#">Buy now</a>
25	<a href="#">6A1243110000</a> Pipe 1	<a href="#">Buy now</a>
26	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
27	<a href="#">656W28100200</a> Tool kit	<a href="#">Buy now</a>
28	<a href="#">6A1427411100</a> Apron	<a href="#">Buy now</a>
29	<a href="#">6A1W00701300</a> Graphic Set	<a href="#">Buy now</a>
30	<a href="#">6A1241535000</a> Indicator, Cock	<a href="#">Buy now</a>
31	<a href="#">6A1241545000</a> Indicator, Shift	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
32	<a href="#">6A1427711100</a> Apron	<a href="#">Buy now</a>
33	<a href="#">987800501200</a> Screw(617)	<a href="#">Buy now</a>
34	<a href="#">9018305M0000</a> Nut, spring (6a1)	<a href="#">Buy now</a>
35	<a href="#">985800501000</a> Screw, pan head(62x)	<a href="#">Buy now</a>
36	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
37	<a href="#">985800654000</a> Screw pan head	<a href="#">Buy now</a>
39	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
40	<a href="#">978850602500</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
43	<a href="#">6A1427920100</a> Mark (100:1)	<a href="#">Buy now</a>
44	<a href="#">6A1412120100</a> Arm, accel.	<a href="#">Buy now</a>
45	<a href="#">6A1412110000</a> Link,accel	<a href="#">Buy now</a>
46	<a href="#">929900510000</a> Ybs67-5 washer, spring	<a href="#">Buy now</a>
47	<a href="#">970950501000</a> Bolt (682)	<a href="#">Buy now</a>
48	<a href="#">6A1143650000</a> Pin, clevis	<a href="#">Buy now</a>
49	<a href="#">990800460000</a> Circlip (eu0)	<a href="#">Buy now</a>

# Cowling & Fuel




Ref	Part	
50	<a href="#">6A1416370000</a> Knob, magneto control	<a href="#">Buy now</a>
51	<a href="#">987800301000</a> Screw, flat head (e56)	<a href="#">Buy now</a>
52	<a href="#">6A1412230000</a> Washer, lock 1	<a href="#">Buy now</a>
53	<a href="#">978850502500</a> Screw, pan head(62j)	<a href="#">Buy now</a>
54	<a href="#">9050112M1600</a> Spring (6a1)	<a href="#">Buy now</a>
55	<a href="#">6A1825500200</a> Stop switch assembly	<a href="#">Buy now</a>
56	<a href="#">6A1825410000</a> Wire, Lead	<a href="#">Buy now</a>
57	<a href="#">953800870000</a> Nut(661)	<a href="#">Buy now</a>
58	<a href="#">979800510800</a> Screw, with washer	<a href="#">Buy now</a>
59	<a href="#">6A1823751100</a> Cover, plug cap	<a href="#">Buy now</a>

# Cylinder & Crankcase



Ref	Part	
1	<a href="#">6A1W00901300</a> Crank Cylinder Assembly	<a href="#">Buy now</a>
2	<a href="#">6A1151006194</a> Crankcase Assembly	<a href="#">Buy now</a>
3	<a href="#">903360600100</a> Plug, blind 6551131300	<a href="#">Buy now</a>
4	<a href="#">650144850200</a> Pipe, joint	<a href="#">Buy now</a>
5	<a href="#">624113790000</a> Valve, check	<a href="#">Buy now</a>
6	<a href="#">970950604000</a> Bolt (682)	<a href="#">Buy now</a>
7	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">995301001400</a> Pin, dowel	<a href="#">Buy now</a>
9	<a href="#">6A111111021S</a> Head, cylinder 1	<a href="#">Buy now</a>
10	<a href="#">6A111181A100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
11	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">6GDE14000000</a> Crankshaft assembly	<a href="#">Buy now</a>
14	<a href="#">933060040900</a> Brg,r-b 6004 42mm 69g nk	<a href="#">Buy now</a>
15	<a href="#">933063020400</a> Brg,r-b 6302 42mm 82g nk	<a href="#">Buy now</a>
16	<a href="#">93310210V100</a> Bearing (27v)	<a href="#">Buy now</a>


# Cylinder & Crankcase




Ref	Part	
17	<a href="#">931022081400</a> Oil seal	<a href="#">Buy now</a>
18	<a href="#">902013530000</a> Washer, Plate	<a href="#">Buy now</a>
19	<a href="#">9310215M3200</a> Oil seal(6a1)	<a href="#">Buy now</a>
20	<a href="#">646116360100</a> Piston (0.50Mm O/s)	<a href="#">Buy now</a>
21	<a href="#">646116010100</a> Piston Ring Set (Std)	<a href="#">Buy now</a>
22	<a href="#">646116330000</a> Pin,piston	<a href="#">Buy now</a>
23	<a href="#">934501102100</a> Circlip 101116340000	<a href="#">Buy now</a>
25	<a href="#">904670601600</a> Clip (655)	<a href="#">Buy now</a>
26	<a href="#">6A1136100000</a> Reed valve assembly	<a href="#">Buy now</a>
27	<a href="#">6A1W00040000</a> Reed set	<a href="#">Buy now</a>
28	<a href="#">6A113621A000</a> Gasket, valve seat	<a href="#">Buy now</a>
29	<a href="#">6A1241410000</a> Protector, fuel tank	<a href="#">Buy now</a>
30	<a href="#">958800601000</a> Bolt, flange(7ht)	<a href="#">Buy now</a>
32	<a href="#">904650802800</a> Clamp (1e6)	<a href="#">Buy now</a>
34	<a href="#">6A1157710000</a> Stay 1	<a href="#">Buy now</a>

## Cylinder & Crankcase

Ref	Part	
35	<a href="#">970130606000</a> Bolt, hexagon	<a href="#">Buy now</a>




# Generator




Ref	Part	
1	<a href="#">6A185500000</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">6A1855600000</a> Base assembly	<a href="#">Buy now</a>
3	<a href="#">6A1855200000</a> Coil, charge	<a href="#">Buy now</a>
4	<a href="#">978850502000</a> Screw, pan head (e22)	<a href="#">Buy now</a>
5	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
6	<a href="#">6A1813620000</a> Cover, hole 1	<a href="#">Buy now</a>
7	<a href="#">9017010M3300</a> Nut(6a1)	<a href="#">Buy now</a>
8	<a href="#">929901010000</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
9	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
10	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
11	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">6G1823702100</a> Plug cap assembly	<a href="#">Buy now</a>
13	<a href="#">6A1855400000</a> C.d.i. unit assembly	<a href="#">Buy now</a>
14	<a href="#">978850601600</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
17	<a href="#">6A1855700000</a> Ignition coil assembly	<a href="#">Buy now</a>

# Generator




Ref	Part	
18	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
20	<a href="#">904651814700</a> Clamp	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
1	<a href="#">6A145300034D</a> Lower unit assembly	<a href="#">Buy now</a>
2	<a href="#">6A145181004D</a> Plate	<a href="#">Buy now</a>
3	<a href="#">6A145311024D</a> Casing Lower	<a href="#">Buy now</a>
4	<a href="#">6L5452510200</a> Anode	<a href="#">Buy now</a>
5	<a href="#">958950601200</a> Bolt, flange deep recess	<a href="#">Buy now</a>
6	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
7	<a href="#">931031105100</a> Oil seal (11x21x8-646)	<a href="#">Buy now</a>
8	<a href="#">933060000100</a> Brg,r-b 6000 26mm 19g ky	<a href="#">Buy now</a>
9	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
10	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
11	<a href="#">9360518M0400</a> Pin, dowel b (6a1)	<a href="#">Buy now</a>
12	<a href="#">970800603000</a> Bolt(jf7)	<a href="#">Buy now</a>
13	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">6A1443250000</a> Protector, oil seal	<a href="#">Buy now</a>
15	<a href="#">6A145361014D</a> Cap, lower casing	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
16	<a href="#">931031005200</a> Oil seal (10x21x10-646)	<a href="#">Buy now</a>
17	<a href="#">932104210100</a> O-ring (183)	<a href="#">Buy now</a>
18	<a href="#">970950601400</a> Bolt(gj3)	<a href="#">Buy now</a>
20	<a href="#">6A1443120194</a> Cover,water pump housing	<a href="#">Buy now</a>
21	<a href="#">9310111M4400</a> Oil seal(6a1)	<a href="#">Buy now</a>
22	<a href="#">932101912300</a> O-ring (646)	<a href="#">Buy now</a>
23	<a href="#">936040906800</a> Pin,dowel (646)	<a href="#">Buy now</a>
24	<a href="#">646443660100</a> Damper, water seal 2	<a href="#">Buy now</a>
25	<a href="#">646443520100</a> Impeller	<a href="#">Buy now</a>
26	<a href="#">936040906600</a> Pin, dowel	<a href="#">Buy now</a>
27	<a href="#">646443230000</a> Outer plate,cartridge	<a href="#">Buy now</a>
28	<a href="#">646443220000</a> Insert, cartridge	<a href="#">Buy now</a>
29	<a href="#">970950501600</a> Bolt(6a1)	<a href="#">Buy now</a>
30	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
31	<a href="#">6A1443610000</a> Tube, water	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
32	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
33	<a href="#">6A1455100100</a> Drive shaft assembly	<a href="#">Buy now</a>
34	<a href="#">9020111M4900</a> Washer, plate (6e0)	<a href="#">Buy now</a>
36	<a href="#">646455510000</a> Pinion	<a href="#">Buy now</a>
37	<a href="#">990010660000</a> Circlip(53l)	<a href="#">Buy now</a>
38	<a href="#">646455600000</a> Gear	<a href="#">Buy now</a>
39	<a href="#">646455672000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>
40	<a href="#">9025003M1000</a> Pin, straight(6a1)	<a href="#">Buy now</a>
41	<a href="#">914903004500</a> Pin, cotter (am5)	<a href="#">Buy now</a>
42	<a href="#">6464594401EL</a> Propeller (3x7-1/4 x4-1/2 -a)	<a href="#">Buy now</a>

# Repair Kit




Ref	Part	
1	<a href="#">6A1W00010200</a> Gasket kit, power unit	<a href="#">Buy now</a>
2	<a href="#">932101912300</a> O-ring (646)	<a href="#">Buy now</a>
3	<a href="#">6A11181A100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
4	<a href="#">6GDE36210000</a> Gasket, valve seat	<a href="#">Buy now</a>
5	<a href="#">9310215M3200</a> Oil seal(6a1)	<a href="#">Buy now</a>
6	<a href="#">931022010800</a> Oil seal	<a href="#">Buy now</a>
7	<a href="#">6A114613A000</a> Gasket, exhaust 1	<a href="#">Buy now</a>
8	<a href="#">64614623A100</a> Gasket, exhaust	<a href="#">Buy now</a>
9	<a href="#">6A1143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
10	<a href="#">6A1W00930300</a> Carburetor repair kit	<a href="#">Buy now</a>
12	<a href="#">6A1143850000</a> Float	<a href="#">Buy now</a>
13	<a href="#">6A1143860000</a> Pin, float	<a href="#">Buy now</a>
14	<a href="#">985800401000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
15	<a href="#">6A1143920000</a> Valve, needle	<a href="#">Buy now</a>
16	<a href="#">646142110200</a> Screw, pilot adjusting	<a href="#">Buy now</a>

# Repair Kit




Ref	Part	
17	<a href="#">6A1141161000</a> Needle	<a href="#">Buy now</a>
18	<a href="#">646141370000</a> Clip	<a href="#">Buy now</a>
20	<a href="#">646142290100</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">646141980100</a> Gasket	<a href="#">Buy now</a>
22	<a href="#">6A1W00012300</a> Lower unit gasket kit	<a href="#">Buy now</a>
23	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
24	<a href="#">931031105100</a> Oil seal (11x21x8-646)	<a href="#">Buy now</a>
26	<a href="#">932104210100</a> O-ring (183)	<a href="#">Buy now</a>
28	<a href="#">931031005200</a> Oil seal (10x21x10-646)	<a href="#">Buy now</a>
29	<a href="#">6A1W00780200</a> Water pump repair kit	<a href="#">Buy now</a>
30	<a href="#">936040906800</a> Pin,dowel (646)	<a href="#">Buy now</a>
32	<a href="#">9310111M4400</a> Oil seal(6a1)	<a href="#">Buy now</a>
33	<a href="#">646443230000</a> Outer plate,cartridge	<a href="#">Buy now</a>
34	<a href="#">646443520100</a> Impeller	<a href="#">Buy now</a>
35	<a href="#">6GDG43220000</a> Insert, cartridge	<a href="#">Buy now</a>

# Repair Kit




Ref	Part	
36	<a href="#">6A1443250000</a> Protector, oil seal	<a href="#">Buy now</a>
37	<a href="#">970950501600</a> Bolt(6a1)	<a href="#">Buy now</a>
38	<a href="#">646443660100</a> Damper, water seal 2	<a href="#">Buy now</a>

# Starter



Ref	Part	
1	<a href="#">6A1157100000</a> Starter ass'y	<a href="#">Buy now</a>
2	<a href="#">6A1157110000</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">6A1157140000</a> Drum, sheave	<a href="#">Buy now</a>
4	<a href="#">6A1157670000</a> Spring, return	<a href="#">Buy now</a>
5	<a href="#">6A1157410000</a> Pawl, drive	<a href="#">Buy now</a>
6	<a href="#">6A1157130000</a> Spring, starter	<a href="#">Buy now</a>
7	<a href="#">7G5157160000</a> Plate, drive	<a href="#">Buy now</a>
8	<a href="#">6A1157050000</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">970130601200</a> Bolt(gh1)	<a href="#">Buy now</a>
10	<a href="#">6A1157550100</a> Handle, Starter	<a href="#">Buy now</a>
12	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
13	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">6A1157230094</a> Pulley, starter	<a href="#">Buy now</a>
15	<a href="#">987030601200</a> Screw, flat head(6a1)	<a href="#">Buy now</a>


# Upper Casing



1V6A1100E106

Ref	Part	
1	<a href="#">6A145111024D</a> Casing, upper	<a href="#">Buy now</a>
2	<a href="#">6A1451130000</a> Pipe	<a href="#">Buy now</a>
3	<a href="#">936051506500</a> Pin, dowel	<a href="#">Buy now</a>
4	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">6A1451510000</a> Cover, upper casing	<a href="#">Buy now</a>
7	<a href="#">6A1451150000</a> Gasket, upper casing	<a href="#">Buy now</a>
8	<a href="#">985800601600</a> Screw pan head	<a href="#">Buy now</a>
10	<a href="#">6A141137005B</a> Guide,exhaust	<a href="#">Buy now</a>
11	<a href="#">6A114613A000</a> Gasket,exhaust 1	<a href="#">Buy now</a>
12	<a href="#">64614623A100</a> Gasket, exhaust	<a href="#">Buy now</a>
13	<a href="#">932101912300</a> O-ring (646)	<a href="#">Buy now</a>
14	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
16	<a href="#">6A142111004D</a> Handle, steering	<a href="#">Buy now</a>
17	<a href="#">646421190200</a> Grip, steering handle	<a href="#">Buy now</a>

## Upper Casing



1V6A1100E106

Ref	Part	
18	<a href="#">6A1421810000</a> Washer	<a href="#">Buy now</a>
19	<a href="#">902010911700</a> Washer 1 6154367300	<a href="#">Buy now</a>
20	<a href="#">929900820000</a> Ybs66-8 washer, plain	<a href="#">Buy now</a>
21	<a href="#">929900810000</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
22	<a href="#">9010108M1100</a> Bolt(6a1)	<a href="#">Buy now</a>
23	<a href="#">988800810000</a> Nut, hex.	<a href="#">Buy now</a>
24	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
26	<a href="#">646425910000</a> Holder, shear pin	<a href="#">Buy now</a>
28	<a href="#">973950605500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.