



Yamaha 2BMH 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BRACKET	3
CARBURETOR	5
COWLING . FUEL	8
CYLINDER. CRANKCASE	13
GENERATOR	16
LOWER CASING. DRIVE	18
REPAIR KIT	22
STARTER	25
UPPER CASING	26

Bracket




6A11300-2060

B6

Ref	Part	
1	6A143111034D Bracket, clamp	Buy now
2	6A143112004D Bracket, clamp	Buy now
3	6A14319100 Shaft, stopper	Buy now
4	6A14319200 Knob, stopper	Buy now
5	91690--30014 Pin, spring (647)	Buy now
6	6E0--43116--01 Screw, transom clamp	Buy now
7	6E0--43118--01 Handle, transom clamp	Buy now
8	90243--04M01 Pin(6a1)	Buy now
9	620--43114--00 Pad, transom clamp	Buy now
10	9010108217 Bolt 6464313100	Buy now
11	90202--08022 Washer 6464313202	Buy now
12	6A1--43113--01 Plate, clamp bracket	Buy now
13	95380--08600 Nut (661)	Buy now
14	6A143311024D Bracket, swivel 1	Buy now
15	6A143312004D Bracket, swivel 2	Buy now

Bracket




6A11300-2060

B6

Ref	Part	
16	6464253701 Bushing, pivot shaft	Buy now
17	93210-46044 O-ring	Buy now
18	9011906M98 Bolt, with washer	Buy now
19	95380-06600 Nut(661)	Buy now
20	93700-06M03 Nipple, grease(6a1)	Buy now
21	6464252800 Piece, friction	Buy now
22	9012206004 Bolt, wing (646)	Buy now
23	9050112272 Spring 6464252401	Buy now
24	6A14335100 Receiver, thrust	Buy now
25	6A14337100 Bolt, receiver	Buy now
26	90201-06040 Washer 6464337400	Buy now
27	9017506008 Nut, Wing	Buy now
28	9169020006 Pin, spring (647)	Buy now

Carburetor




6A10010-4030

B2

Ref	Part	
1	6A11430103 Carburetor assembly 1	Buy now
2	6461415800 Top, mixing chamber	Buy now
3	6A11449700 Stay, throttle wire	Buy now
4	6461432100 Screw, throttle	Buy now
5	6461416900 -	Buy now
6	6A11431400 Bar, throttle	Buy now
7	6A11416300 Spacer	Buy now
8	6461422901 O-ring	Buy now
9	6A11438400 Gasket, float chamber	Buy now
10	6A11434101 Nozzle, main	Buy now
11	6A11434348 Jet Main (#96)	Buy now
12	6A11438102 Body, float chamber	Buy now
13	97890--05006 Screw,panhead (eg9)	Buy now
14	646--14198--01 Gasket	Buy now
15	6A11411610 Needle	Buy now

Carburetor




6A10010-4030

B2

Ref	Part	
16	6461413700 Clip	Buy now
17	6461413600 Seat, spring	Buy now
18	6461433101 Spring,throttle valve	Buy now
19	6461431208 Valve, throttle	Buy now
20	6A11412501 -	Buy now
21	6A11412701 Clip	Buy now
22	6A11435801 Nut	Buy now
23	6A11421200 Spring, Pilot Adjusting	Buy now
24	6461421102 Screw, pilot adjusting	Buy now
25	97980-04110 Screw, pan head (e56)	Buy now
26	6A11439200 Valve, needle	Buy now
27	6A1-14386-00 Pin, float	Buy now
28	6A11438500 Float	Buy now
29	98580-03005 Screw, pan head(78g)	Buy now
30	6461435800 Nut	Buy now


Carburetor



Ref	Part	
31	6A11435600 Washer	Buy now
32	6461435700 Washer	Buy now
33	6A11444800 Lever, choke valve	Buy now
34	6A11421701 Valve Choke	Buy now
35	92990--05600 Washer, plain (646)	Buy now

B2


Cowling . Fuel



A4

Ref	Part	
1	6A11444102 Silencer, intake 2	Buy now
2	9017305M00 Nut, square (6a1)	Buy now
3	6A14267710 Graphic Front	Buy now
4	6A11444200 Spacer 1	Buy now
5	9015104M04 Screw, countersunk	Buy now
6	6A14127100 Knob, choke	Buy now
7	9321008M29 O-ring (6a1)	Buy now
8	6A12411001 Fuel tank assembly	Buy now
9	6A12419800 Seat, rubber	Buy now
10	6A12461001 Cap assembly	Buy now
11	6A12463100 Screw, air	Buy now
12	9043004005 Gasket 6112463200	Buy now
13	9043014117 Gasket	Buy now
14	6462461501 Gasket, Plate 1	Buy now
15	9050110374 Spring, Compression	Buy now


Cowling . Fuel



A4

Ref	Part	
16	9290704200 Washer(6e1)	Buy now
17	90501--10260 Spring, safety 6152463500	Buy now
18	6462424100 Indicator	Buy now
19	97095--06018 Bolt (fj0)	Buy now
20	95380--06600 Nut(661)	Buy now
21	92995--06100 Washer(6a1)	Buy now
22	90201--06M30 Washer, plate (6a1)	Buy now
23	6A12418100 Damper, locating	Buy now
24	6A12450002 Fuel cock assembly 1	Buy now
25	6A1-24311--00 Pipe 1	Buy now
26	90467--08004 Clip, pipe 6162435600	Buy now
27	656-W2810-02 Tool kit	Buy now
28	6A14274111 Apron	Buy now
29	6A1W007014 Graphic set	Buy now
30	6A12415350 Indicator, Cock	Buy now


Cowling . Fuel



A4

Ref	Part	
31	6A12415450 Indicator, Shift	Buy now
32	6A14277111 Apron	Buy now
33	9878005012 Screw(617)	Buy now
34	9018305M00 Nut, spring (6a1)	Buy now
35	97880-05010 Screw, pan head(62x)	Buy now
36	92990-05600 Washer, plain (646)	Buy now
37	97880-06040 Screw pan head	Buy now
38	92990-06100 Washer(6a1)	Buy now
39	92990-06600 Washer, plain (646)	Buy now
40	97880-06025 Screw, pan head(6b0)	Buy now
43	6A14279201 Mark (100:1)	Buy now
44	6A1-28176-00 Label Caution	Buy now
45	6A14121201 Arm, accel.	Buy now
46	6A14121100 Link,accel	Buy now
47	92990-05100 Ybs67-5 washer, spring	Buy now

Cowling . Fuel




A4

Ref	Part	
48	97095-05010 Bolt (682)	Buy now
49	6A11436500 Pin, clevis	Buy now
50	9343004003 Circlip (eu0)	Buy now
51	6A14163700 Knob, magneto control	Buy now
52	9878003010 Screw, flat head (e56)	Buy now
53	6A14122300 Washer, lock 1	Buy now
54	97885-05025 Screw, pan head(62j)	Buy now
55	90501-12M16 Spring (6a1)	Buy now
56	6A18255002 Stop switch assembly	Buy now
57	6A18254100 Wire, Lead	Buy now
58	95380-08700 Nut(661)	Buy now
59	97880-05008 Screw, with washer	Buy now
60	6A18237511 Cover, plug cap	Buy now
62	97880-05012 Screw,pan head (646)	Buy now
64	6A1-83625-41 Mark 5	Buy now


Cowling . Fuel

Ref	Part	
65	6A1-83625-51 Mark 5	Buy now



A4


Cylinder. Crankcase



A7

Ref	Part	
3	9033606001 Plug, blind 6551131300	Buy now
4	6501448502 Pipe, joint	Buy now
5	624--11379--00 Valve, check	Buy now
6	97013--06040 Bolt (682)	Buy now
7	92903--06600 Washer, plain (646)	Buy now
8	99530--10014 Pin, dowel	Buy now
10	6A11181A1 Gasket, cylinder head 1	Buy now
11	97095--06025 Bolt	Buy now
12	92995--06600 Washer, plain (646)	Buy now
13	6A11140000 Crankshaft assembly	Buy now
14	6461141201 Crank 1	Buy now
15	6A11142200 Crank 2	Buy now
16	6461168100 Pin, crank 1	Buy now
17	9331031439 Brg,cyl-cal roller 5g tm	Buy now
18	6461165102 Rod, connecting	Buy now


Cylinder. Crankcase



A7

Ref	Part	
19	9330600409 Brg,r-b 6004 42mm 69g nk	Buy now
20	9330630204 Brg,r-b 6302 42mm 82g nk	Buy now
21	93310210V1 Bearing (27v)	Buy now
22	9310220070 Oil seal	Buy now
23	9020135300 Washer, Plate	Buy now
24	6461163501 2- AP	Buy now
24	6461163601 Piston (0.50Mm O/s) AP	Buy now
24	9310215M32 Oil seal(6a1)	Buy now
26	6461160101 Piston Ring Set (Std)	Buy now
26	6461160111 Piston Ring Set(1Sto/S) AP	Buy now
26	6461160121 2- AP	Buy now
27	6461163300 Pin,piston	Buy now
28	9345011021 Circlip 101116340000	Buy now
29	9044507254 Hose (I200)	Buy now
30	90467-06016 Clip (655)	Buy now


Cylinder. Crankcase



Ref	Part	
31	6A11361000 Reed valve assembly	Buy now
32	6A1W000400 Reed set	Buy now
33	6A113621A0 Gasket, valve seat	Buy now
34	6A12414100 Protector, fuel tank	Buy now
35	95895--06010 Bolt, flange(7ht)	Buy now
36	9470200249 Plug Spark (Br5Hs)	Buy now
37	90465--06M86 Clamp	Buy now
38	6A14267812 Graphic, rear	Buy now
39	6A11577101 Stay 1	Buy now
40	97013--06060 Bolt, hexagon	Buy now
41	6784279110 Mark 1	Buy now

A7


Generator



B5

Ref	Part	
1	6A18555000 Rotor assembly	Buy now
2	6A18556000 Base assembly	Buy now
3	6A18552000 Coil, charge	Buy now
4	9788505020 Screw, pan head (e22)	Buy now
5	90280--04M06 Key, woodruff(6a1)	Buy now
6	6A18136200 Cover, hole 1	Buy now
7	90170--10M33 Nut(6a1)	Buy now
8	9290310100 Ybs67-10 washer, spring	Buy now
9	97013--06030 Bolt	Buy now
10	92903--06100 Washer(6a1)	Buy now
11	92903--06600 Washer, plain (646)	Buy now
12	6G1--82370--21 Plug cap assembly	Buy now
13	6A18554001 C.d.i. unit assembly	Buy now
14	97885--06016 Screw, pan head(6b0)	Buy now
15	92995--06100 Washer(6a1)	Buy now

Generator




6A10010-5050

Ref	Part	
16	92995-06600 Washer, plain (646)	Buy now
17	6A18557000 Ignition coil assembly	Buy now
18	97095-06020 Bolt(7u8)	Buy now
20	90464-08M07 Clamp	Buy now


B5

Lower Casing. Drive




Ref	Part	
1	6A145300034D Lower unit assembly	Buy now
2	6A145181004D Plate	Buy now
3	6A145311024D Casing Lower	Buy now
4	6L54525102 Anode	Buy now
5	95895-06012 Bolt, flange deep recess	Buy now
6	92990-06300 Washer, tooth	Buy now
7	9310311051 Oil seal (11x21x8-646)	Buy now
8	9330600001 Brg,r-b 6000 26mm 19g ky	Buy now
9	90430-08020 Gasket	Buy now
10	90340-08002 Plug, straight screw	Buy now
11	9360518M04 Pin, dowel b (6a1)	Buy now
12	97095-06030 Bolt(jf7)	Buy now
13	92995-06600 Washer, plain (646)	Buy now
14	6A14432500 Protector, oil seal	Buy now
15	6A145361014D Cap, lower casing	Buy now

Lower Casing. Drive



Ref	Part	
16	9310310052 Oil seal (10x21x10-646)	Buy now
17	9321042101 O-ring (183)	Buy now
18	9709006014 Bolt(gj3)	Buy now
19	92990-06600 Washer, plain (646)	Buy now
20	6A1443120194 Cover,water pump housing	Buy now
21	9310111M44 Oil seal(6a1)	Buy now
22	93210-19123 O-ring (646)	Buy now
23	9360409068 Pin,dowel (646)	Buy now
24	6464436601 Damper, water seal 2	Buy now
25	6464435201 Impeller	Buy now
26	93604-09066 Pin, dowel	Buy now
27	6464432300 Outer plate,cartridge	Buy now
28	6464432200 Insert, cartridge	Buy now
29	97095-05016 Bolt(6a1)	Buy now
30	92995-05600 Washer, plain (646)	Buy now


Lower Casing. Drive



C3

Ref	Part	
31	6A14436100 Tube, water	Buy now
32	646-44365-00 Damper, water seal 1	Buy now
33	6A14551001 Drive shaft assembly	Buy now
34	90201-11M49 Washer, plate (6e0)	Buy now
35	646455340003 Shim (T)0.30Mm UR	Buy now
35	646455340004 Shim (T)0.40Mm UR	Buy now
35	646455340005 Shim (T)0.50Mm UR	Buy now
36	6464555100 Pinion	Buy now
37	9343006005 Circlip(53l)	Buy now
38	6464556000 Gear	Buy now
39	646455670003 Shim (t:0.30mm) UR	Buy now
39	646455670004 Shim (t:0.40mm) UR	Buy now
39	646455670005 Shim (t:0.50mm) UR	Buy now
40	9025003M10 Pin, straight(6a1)	Buy now
41	9149030040 Pin, cotter (am5)	Buy now


Lower Casing. Drive



Ref	Part	
42	6464594201EL Propeller (3x7-1/4 x5-1/2 -a) UR	Buy now
42	6464594401EL Propeller (3x7-1/4 x4-1/2 -a) UR	Buy now
42	6A14594300 Propeller assembly (3x7-1/4"x4"-a) UR	Buy now
43	6462819300 Plug, Water Check AP	Buy now

C3


Repair Kit



C5

Ref	Part	
1	6A1W0001A2 Gasket kit, power unit	Buy now
2	9321008M29 O-ring (6a1)	Buy now
3	6A111181A1 Gasket, cylinder head 1	Buy now
4	6A113621A0 Gasket, valve seat	Buy now
5	9310215M32 Oil seal(6a1)	Buy now
6	9310220070 Oil seal	Buy now
7	6A114613A0 Gasket, exhaust 1	Buy now
8	64614623A1 Gasket, exhaust	Buy now
9	6A11438400 Gasket, float chamber	Buy now
10	6A1W009303 Carburetor repair kit	Buy now
12	6A11438500 Float	Buy now
13	6A1-14386-00 Pin, float	Buy now
14	97980-04110 Screw, pan head (e56)	Buy now
15	6A11439200 Valve, needle	Buy now
16	6461421102 Screw, pilot adjusting	Buy now


Repair Kit



C5

Ref	Part	
17	6A11411610 Needle	Buy now
18	6461413700 Clip	Buy now
19	6461416900 -	Buy now
20	6461422901 O-ring	Buy now
21	646-14198-01 Gasket	Buy now
22	6A1W000123 Lower unit gasket kit	Buy now
23	90430-08020 Gasket	Buy now
24	9310311051 Oil seal (11x21x8-646)	Buy now
25	93210-19123 O-ring (646)	Buy now
26	9321042101 O-ring (183)	Buy now
27	9310111M44 Oil seal(6a1)	Buy now
28	9310310052 Oil seal (10x21x10-646)	Buy now
29	6A1W007802 Water pump repair kit	Buy now
30	9360409068 Pin,dowel (646)	Buy now
33	6464432300 Outer plate,cartridge	Buy now


Repair Kit



Ref	Part	
34	6464435201 Impeller	Buy now
35	6464432200 Insert, cartridge	Buy now
36	6A14432500 Protector, oil seal	Buy now
37	97095-05016 Bolt(6a1)	Buy now
38	6464436601 Damper, water seal 2	Buy now

C5


Starter



B4

Ref	Part	
1	6A11571000 Starter ass'y	Buy now
2	6A11571100 Case, starter	Buy now
3	6A11571400 Drum, sheave	Buy now
4	6A11576700 Spring, return	Buy now
5	6A11574100 Pawl, drive	Buy now
6	6A11571300 Spring, starter	Buy now
7	6A11571700 Plate, drive	Buy now
8	6A11570500 Spring, drive pawl	Buy now
9	9732206012 Bolt(gh1)	Buy now
10	6A11575502 Handle, starter	Buy now
11	* item_description	Buy now
12	97095--06016 Bolt, hexagon deep recess	Buy now
13	92995--06600 Washer, plain (646)	Buy now
14	6A1157230094 Pulley, starter	Buy now
15	9870306012 Screw, flat head(6a1)	Buy now

Upper Casing




6A11100-2070

C1

Ref	Part	
1	6A145111024D Casing, upper	Buy now
2	6A14511300 Pipe	Buy now
3	9360515065 Pin, dowel	Buy now
4	97095--06025 Bolt	Buy now
5	92995--06600 Washer, plain (646)	Buy now
6	6A14515100 Cover, upper casing	Buy now
7	6A14511500 Gasket, upper casing	Buy now
8	97880--06016 Screw pan head	Buy now
9	92990--06600 Washer, plain (646)	Buy now
10	6A141137005B Guide,exhaust	Buy now
11	6A114613A0 Gasket,exhaust 1	Buy now
12	64614623A1 Gasket, exhaust	Buy now
13	93210--19123 O-ring (646)	Buy now
14	97095--06030 Bolt(jf7)	Buy now
16	6A142111004D Handle, steering	Buy now

Upper Casing



C1

Ref	Part	
17	6464211902 Grip, steering handle	Buy now
18	6A14218100 Washer	Buy now
19	9020109117 Washer 1 6154367300	Buy now
20	92990--08200 Ybs66-8 washer, plain	Buy now
21	92990--08100 Ybs67-8 washer, spring	Buy now
22	9010108M11 Bolt(6a1)	Buy now
23	95380--08600 Nut (661)	Buy now
24	97095--06010 Bolt	Buy now
25	92995--06100 Washer(6a1)	Buy now
26	6464259100 Holder, shear pin	Buy now
27	646421210094 Bracket Carrying AP	Buy now
28	97095--06055 Bolt, hexagon w/w deep recess AP	Buy now
29	92990--06100 Washer(6a1) AP	Buy now
30	6A1--2415A--41 Label, caution	Buy now
31	6A1--2415A--51 Label Caution	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.