



# Yamaha 30DETO 2007

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

|                                   |    |
|-----------------------------------|----|
| <b>BOTTOM COWLING</b>             | 3  |
| <b>BRACKET 1</b>                  | 6  |
| <b>BRACKET 2</b>                  | 10 |
| <b>BRACKET 3</b>                  | 13 |
| <b>BRACKET 4</b>                  | 16 |
| <b>CARBURETOR</b>                 | 19 |
| <b>CONTROL 1</b>                  | 22 |
| <b>CONTROL 2</b>                  | 25 |
| <b>CRANKSHAFT &amp; PISTON</b>    | 26 |
| <b>CYLINDER &amp; CRANKCASE</b>   | 28 |
| <b>ELECTRICAL 1</b>               | 31 |
| <b>ELECTRICAL 2</b>               | 33 |
| <b>ELECTRICAL 3</b>               | 35 |
| <b>FUEL</b>                       | 38 |
| <b>FUEL TANK</b>                  | 41 |
| <b>GENERATOR</b>                  | 42 |
| <b>INTAKE</b>                     | 44 |
| <b>LOWER CASING &amp; DRIVE 1</b> | 46 |
| <b>LOWER CASING &amp; DRIVE 2</b> | 52 |
| <b>OIL PUMP</b>                   | 55 |
| <b>POWER TRIM &amp; TILT ASSY</b> | 59 |
| <b>REMO CON ATTACHMENT</b>        | 64 |
| <b>REMOTE CONTROL ASSY</b>        | 66 |
| <b>REMOTE CONTROL BOX</b>         | 71 |
| <b>REPAIR KIT 1</b>               | 72 |
| <b>REPAIR KIT 2</b>               | 74 |
| <b>STARTER</b>                    | 76 |
| <b>STARTING MOTOR</b>             | 79 |
| <b>STEERING</b>                   | 82 |
| <b>STEERING GUIDE</b>             | 85 |
| <b>TOP COWLING</b>                | 86 |
| <b>UPPER CASING</b>               | 88 |


## Bottom Cowling



**D3**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J842711034D</a><br>Cowling, bottom 1      | <a href="#">Buy now</a> |
| 2   | <a href="#">6884272610</a><br>Grommet                  | <a href="#">Buy now</a> |
| 2   | <a href="#">6H44272600</a><br>Grommet                  | <a href="#">Buy now</a> |
| 3   | <a href="#">6J842815004D</a><br>Lever, clamp           | <a href="#">Buy now</a> |
| 4   | <a href="#">9020212M25</a><br>Washer, plate(6j8)       | <a href="#">Buy now</a> |
| 5   | <a href="#">9020612052</a><br>Washer, wave (666)       | <a href="#">Buy now</a> |
| 6   | <a href="#">9038612M61</a><br>Bush(6j8)                | <a href="#">Buy now</a> |
| 7   | <a href="#">6J84281600</a><br>Lever, clamp             | <a href="#">Buy now</a> |
| 8   | <a href="#">9589506012</a><br>Bolt, flange deep recess | <a href="#">Buy now</a> |
| 9   | <a href="#">6J84272801</a><br>Cap                      | <a href="#">Buy now</a> |
| 10  | <a href="#">6J84283100</a><br>Bushing                  | <a href="#">Buy now</a> |
| 11  | <a href="#">6G14272700</a><br>Grommet                  | <a href="#">Buy now</a> |
| 12  | <a href="#">6J84272400</a><br>Grommet                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6J84272600</a><br>Grommet                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6J84272610</a><br>Grommet                  | <a href="#">Buy now</a> |


## Bottom Cowling



**D3**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 14  | <a href="#">6J84272501</a><br>Grommet                  | <a href="#">Buy now</a> |
| 15  | <a href="#">6H34439101</a><br>Nipple, hose             | <a href="#">Buy now</a> |
| 16  | <a href="#">6J84271600</a><br>Rubber seal 1            | <a href="#">Buy now</a> |
| 17  | <a href="#">9048009M21</a><br>Grommet (6e9)            | <a href="#">Buy now</a> |
| 18  | <a href="#">9038706M41</a><br>Collar (6e9)             | <a href="#">Buy now</a> |
| 19  | <a href="#">9011906M61</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 20  | <a href="#">6J84274101</a><br>Apron                    | <a href="#">Buy now</a> |
| 21  | <a href="#">9016406M01</a><br>Screw (6f5)              | <a href="#">Buy now</a> |
| 22  | <a href="#">6J84272301</a><br>Cover, bottom            | <a href="#">Buy now</a> |
| 22  | <a href="#">6J84272351</a><br>Cover, bottom (dbn:gray) | <a href="#">Buy now</a> |
| 23  | <a href="#">6J84273500</a><br>Protector                | <a href="#">Buy now</a> |
| 24  | <a href="#">6J84271920</a><br>Panel, front lower       | <a href="#">Buy now</a> |
| 25  | <a href="#">9046409M51</a><br>Clamp                    | <a href="#">Buy now</a> |
| 26  | <a href="#">9010906M86</a><br>Bolt                     | <a href="#">Buy now</a> |
| 27  | <a href="#">6J84284600</a><br>Screw                    | <a href="#">Buy now</a> |


## Bottom Cowling



**D3**

| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 28  | <a href="#">6J84272620</a><br>Grommet                         | <a href="#">Buy now</a> |
| 29  | <a href="#">6898257504</a><br>Engine stop switch assembly     | <a href="#">Buy now</a> |
| 30  | <a href="#">6828255600</a><br>Lanyard, stop switch            | <a href="#">Buy now</a> |
| 31  | <a href="#">6898257Y00</a><br>Cap                             | <a href="#">Buy now</a> |
| 32  | <a href="#">9046513M76</a><br>Clamp                           | <a href="#">Buy now</a> |
| 33  | <a href="#">6828438100</a><br>2p concent 1                    | <a href="#">Buy now</a> |
| 34  | <a href="#">6J88438700</a><br>Holder                          | <a href="#">Buy now</a> |
| 35  | <a href="#">6638255700</a><br>Nut                             | <a href="#">Buy now</a> |
| 36  | <a href="#">6J88255300</a><br>Extension, wire lead            | <a href="#">Buy now</a> |
| 37  | <a href="#">6J88541000</a><br>Emergency signal light assembly | <a href="#">Buy now</a> |
| 38  | <a href="#">6E74279110</a><br>Mark 1                          | <a href="#">Buy now</a> |
| 39  | <a href="#">6A12817600</a><br>Label Caution                   | <a href="#">Buy now</a> |
| 40  | <a href="#">6E38257H00</a><br>Plate Mark                      | <a href="#">Buy now</a> |


# Bracket 1



**E4**


| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6H443111054D</a><br>Bracket, clamp 1    | <a href="#">Buy now</a> |
| 2   | <a href="#">6H443112044D</a><br>Bracket, clamp 2    | <a href="#">Buy now</a> |
| 3   | <a href="#">6E58214800</a><br>Wire, lead 5          | <a href="#">Buy now</a> |
| 4   | <a href="#">9788506008</a><br>Screw, pan head(6a3)  | <a href="#">Buy now</a> |
| 5   | <a href="#">6E04311801</a><br>Handle, transom clamp | <a href="#">Buy now</a> |
| 6   | <a href="#">9024304M01</a><br>Pin(6a1)              | <a href="#">Buy now</a> |
| 7   | <a href="#">9014914M12</a><br>Screw(6h4)            | <a href="#">Buy now</a> |
| 8   | <a href="#">6484311401</a><br>Pad, transom clamp    | <a href="#">Buy now</a> |
| 9   | <a href="#">6J84313101</a><br>Bolt, clamp bracket   | <a href="#">Buy now</a> |
| 10  | <a href="#">9038622M69</a><br>Bush(6k9)             | <a href="#">Buy now</a> |
| 11  | <a href="#">9020122M03</a><br>Washer, plate(64j)    | <a href="#">Buy now</a> |
| 12  | <a href="#">6J84311301</a><br>Plate, clamp bracket  | <a href="#">Buy now</a> |
| 13  | <a href="#">9018522043</a><br>Nut, self-locking     | <a href="#">Buy now</a> |
| 14  | <a href="#">6G54314501</a><br>Cap, clamp bracket    | <a href="#">Buy now</a> |
| 15  | <a href="#">9010108339</a><br>Bolt, hexagon (656)   | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 16  | <a href="#">9038708M03</a><br>Collar                      | <a href="#">Buy now</a> |
| 17  | <a href="#">9299008600</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |
| 18  | <a href="#">9538008600</a><br>Nut (661)                   | <a href="#">Buy now</a> |
| 19  | <a href="#">6J843311044D</a><br>Bracket, swivel           | <a href="#">Buy now</a> |
| 20  | <a href="#">9370006M03</a><br>Nipple, grease(6a1)         | <a href="#">Buy now</a> |
| 21  | <a href="#">6634511900</a><br>Cap, grease nipple<br>AP    | <a href="#">Buy now</a> |
| 22  | <a href="#">6J84252800</a><br>Plate, friction             | <a href="#">Buy now</a> |
| 23  | <a href="#">6894337301</a><br>Seal, damper                | <a href="#">Buy now</a> |
| 24  | <a href="#">9010506M18</a><br>Bolt (689)                  | <a href="#">Buy now</a> |
| 25  | <a href="#">6J842510034D</a><br>Steering bracket assembly | <a href="#">Buy now</a> |
| 26  | <a href="#">9038630M77</a><br>Bush(6h0)                   | <a href="#">Buy now</a> |
| 27  | <a href="#">9038630M78</a><br>Bush(6h0)                   | <a href="#">Buy now</a> |
| 28  | <a href="#">9020130M00</a><br>Washer, plate(6h1)          | <a href="#">Buy now</a> |
| 29  | <a href="#">9321029M94</a><br>O-ring(6h1)                 | <a href="#">Buy now</a> |
| 30  | <a href="#">9038630M60</a><br>Bush(6j8)                   | <a href="#">Buy now</a> |

# Bracket 1



| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 31  | <a href="#">6H444551024D</a><br>Housing, lower mount rubber 1 | <a href="#">Buy now</a> |
| 32  | <a href="#">9341028M06</a><br>Circlip (688)                   | <a href="#">Buy now</a> |
| 33  | <a href="#">6J842121034D</a><br>Bracket                       | <a href="#">Buy now</a> |
| 34  | <a href="#">9011610M28</a><br>Bolt, stud                      | <a href="#">Buy now</a> |
| 35  | <a href="#">9299510600</a><br>Washer, plate                   | <a href="#">Buy now</a> |
| 36  | <a href="#">9018510051</a><br>Nut, self-locking               | <a href="#">Buy now</a> |
| 37  | <a href="#">6H44455700</a><br>Mount, lower front<br>S(16.7")  | <a href="#">Buy now</a> |
| 37  | <a href="#">6H44455710</a><br>Mount, lower front<br>L(21.5")  | <a href="#">Buy now</a> |
| 38  | <a href="#">6H44455301</a><br>Cover, lower mount              | <a href="#">Buy now</a> |
| 39  | <a href="#">9709508025</a><br>Bolt (62g)                      | <a href="#">Buy now</a> |
| 40  | <a href="#">9299508600</a><br>Washer, plain (663)             | <a href="#">Buy now</a> |
| 41  | <a href="#">9709510060</a><br>Bolt, hexagon                   | <a href="#">Buy now</a> |
| 43  | <a href="#">6H48212700</a><br>Wire, lead 2                    | <a href="#">Buy now</a> |
| 44  | <a href="#">6H44451400</a><br>Mount, upper side               | <a href="#">Buy now</a> |
| 45  | <a href="#">9010908M26</a><br>Bolt(6j8)                       | <a href="#">Buy now</a> |


# Bracket 1



**E4**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 46  | <a href="#">9020109425</a><br>Washer, plate (663)    | <a href="#">Buy now</a> |
| 47  | <a href="#">9018508045</a><br>Nut, self-locking      | <a href="#">Buy now</a> |
| 48  | <a href="#">6J844511004D</a><br>Cover, upper mount   | <a href="#">Buy now</a> |
| 49  | <a href="#">9707508035</a><br>Bolt(70w)              | <a href="#">Buy now</a> |
| 50  | <a href="#">9299508100</a><br>Ybs67-8 washer, spring | <a href="#">Buy now</a> |
| 51  | <a href="#">6J848511014D</a><br>Hook, steering       | <a href="#">Buy now</a> |
| 52  | <a href="#">9010110M58</a><br>Bolt                   | <a href="#">Buy now</a> |
| 54  | <a href="#">9020112426</a><br>Washer, plate(663)     | <a href="#">Buy now</a> |
| 55  | <a href="#">9538010600</a><br>Nut(624)               | <a href="#">Buy now</a> |


## Bracket 2



**E7**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H44316001</a><br>Tilt rod assembly            | <a href="#">Buy now</a> |
| 2   | <a href="#">6764316500</a><br>Stopper plate, titl lock rod | <a href="#">Buy now</a> |
| 3   | <a href="#">9169030010</a><br>Pin, spring (663)            | <a href="#">Buy now</a> |
| 4   | <a href="#">9050210M04</a><br>Spring, conical(6f5)         | <a href="#">Buy now</a> |
| 5   | <a href="#">6J84318101</a><br>Lever, tilt stop 1           | <a href="#">Buy now</a> |
| 6   | <a href="#">6824331801</a><br>Cover                        | <a href="#">Buy now</a> |
| 7   | <a href="#">9050612M25</a><br>Spring, tension(6h4)         | <a href="#">Buy now</a> |
| 8   | <a href="#">9024912M28</a><br>Pin(6h4)                     | <a href="#">Buy now</a> |
| 9   | <a href="#">9343010M00</a><br>Circlip                      | <a href="#">Buy now</a> |
| 10  | <a href="#">9020212031</a><br>Washer, plate 6484412600     | <a href="#">Buy now</a> |
| 11  | <a href="#">6J84362700</a><br>Stopper                      | <a href="#">Buy now</a> |
| 12  | <a href="#">9024912M27</a><br>Pin(6f6)                     | <a href="#">Buy now</a> |
| 15  | <a href="#">9020612M16</a><br>Washer, wave(6j8)            | <a href="#">Buy now</a> |
| 16  | <a href="#">6J84361400</a><br>Plate, tilt lock             | <a href="#">Buy now</a> |
| 17  | <a href="#">6J84361500</a><br>Plate, tilt lock             | <a href="#">Buy now</a> |


## Bracket 2



**E7**

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 18  | <a href="#">6J84361301</a><br>Arm, tilt lock       | <a href="#">Buy now</a> |
| 19  | <a href="#">6H44365900</a><br>Shaft, reverse lock  | <a href="#">Buy now</a> |
| 20  | <a href="#">6J84361101</a><br>Shaft, tilt lock     | <a href="#">Buy now</a> |
| 21  | <a href="#">9038707M64</a><br>Collar (6h4)         | <a href="#">Buy now</a> |
| 22  | <a href="#">9343006M02</a><br>Circlip (689)        | <a href="#">Buy now</a> |
| 23  | <a href="#">9908005600</a><br>Circlip(22k)         | <a href="#">Buy now</a> |
| 24  | <a href="#">9050632M22</a><br>Spring, tension(6j8) | <a href="#">Buy now</a> |
| 25  | <a href="#">9149020010</a><br>Pin, cotter          | <a href="#">Buy now</a> |
| 26  | <a href="#">6J84363100</a><br>Lever, tilt          | <a href="#">Buy now</a> |
| 27  | <a href="#">6J84363300</a><br>Cover, tilt lever    | <a href="#">Buy now</a> |
| 28  | <a href="#">9050818M23</a><br>Spring, torsion(6h4) | <a href="#">Buy now</a> |
| 29  | <a href="#">6H44361600</a><br>Rod, tilt lock 1     | <a href="#">Buy now</a> |
| 30  | <a href="#">6J84364100</a><br>Lever, tilt          | <a href="#">Buy now</a> |
| 31  | <a href="#">9024906M24</a><br>Pin(6h4)             | <a href="#">Buy now</a> |
| 32  | <a href="#">6J84361700</a><br>Rod, tilt lock       | <a href="#">Buy now</a> |


## Bracket 2



**E7**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 34  | <a href="#">6J84368101</a><br>Lever, shallow water drive | <a href="#">Buy now</a> |
| 35  | <a href="#">6J84367300</a><br>Washer 1                   | <a href="#">Buy now</a> |
| 36  | <a href="#">6J84363110</a><br>Lever, tilt                | <a href="#">Buy now</a> |
| 40  | <a href="#">6J84361710</a><br>Rod, tilt lock             | <a href="#">Buy now</a> |
| 41  | <a href="#">6J84318600</a><br>Lever                      | <a href="#">Buy now</a> |
| 42  | <a href="#">6J84318700</a><br>Lever 2                    | <a href="#">Buy now</a> |
| 43  | <a href="#">9050825M21</a><br>Spring, torsion(6h4)       | <a href="#">Buy now</a> |
| 44  | <a href="#">9024907M25</a><br>Pin(6h4)                   | <a href="#">Buy now</a> |
| 46  | <a href="#">6J84126200</a><br>Joint, choke lever         | <a href="#">Buy now</a> |
| 47  | <a href="#">6J84361610</a><br>Rod, tilt lock             | <a href="#">Buy now</a> |
| 48  | <a href="#">9050820M22</a><br>Spring, torsion(6h4)       | <a href="#">Buy now</a> |

## Bracket 3




  
6J8N700-F200

**F2**

| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6K943111104D</a><br>Bracket, clamp 1             | <a href="#">Buy now</a> |
| 2   | <a href="#">6K943112104D</a><br>Bracket, clamp               | <a href="#">Buy now</a> |
| 3   | <a href="#">9046510M77</a><br>Clamp                          | <a href="#">Buy now</a> |
| 4   | <a href="#">9759506510</a><br>Bolt, hexagon w/w deep recess  | <a href="#">Buy now</a> |
| 5   | <a href="#">65W4319200</a><br>Knob, stopper                  | <a href="#">Buy now</a> |
| 6   | <a href="#">65W4319100</a><br>Shaft, stopper                 | <a href="#">Buy now</a> |
| 7   | <a href="#">9169030018</a><br>926-51502-00 pin, spring (700) | <a href="#">Buy now</a> |
| 8   | <a href="#">9038614MA1</a><br>Bush                           | <a href="#">Buy now</a> |
| 9   | <a href="#">6K94313101</a><br>Bolt, clamp bracket            | <a href="#">Buy now</a> |
| 10  | <a href="#">9709508020</a><br>Bolt, hexagon                  | <a href="#">Buy now</a> |
| 11  | <a href="#">9299508100</a><br>Ybs67-8 washer, spring         | <a href="#">Buy now</a> |
| 12  | <a href="#">9038622M15</a><br>Bushing (688)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">9020122M03</a><br>Washer, plate(64j)             | <a href="#">Buy now</a> |
| 14  | <a href="#">9018522M11</a><br>Nut, self-locking              | <a href="#">Buy now</a> |
| 15  | <a href="#">6G54314501</a><br>Cap, clamp bracket             | <a href="#">Buy now</a> |

## Bracket 3




6J8N700-F200

**F2**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">6K943311014D</a><br>Bracket, swivel        | <a href="#">Buy now</a> |
| 17  | <a href="#">9370006M03</a><br>Nipple, grease(6a1)      | <a href="#">Buy now</a> |
| 18  | <a href="#">6634511900</a><br>Cap, grease nipple<br>AP | <a href="#">Buy now</a> |
| 19  | <a href="#">9038612MA0</a><br>Bush, solid              | <a href="#">Buy now</a> |
| 20  | <a href="#">9038612M98</a><br>Bush                     | <a href="#">Buy now</a> |
| 21  | <a href="#">9024912M38</a><br>Pin                      | <a href="#">Buy now</a> |
| 22  | <a href="#">9343010M00</a><br>Circlip                  | <a href="#">Buy now</a> |
| 23  | <a href="#">9046513M11</a><br>Clamp (6e5)              | <a href="#">Buy now</a> |
| 24  | <a href="#">65W4525100</a><br>Anode                    | <a href="#">Buy now</a> |
| 25  | <a href="#">9046511M10</a><br>Clamp                    | <a href="#">Buy now</a> |
| 26  | <a href="#">9010106020</a><br>Bolt                     | <a href="#">Buy now</a> |
| 27  | <a href="#">6H18214800</a><br>Wire, lead               | <a href="#">Buy now</a> |
| 28  | <a href="#">6U08212700</a><br>Wire, lead 5             | <a href="#">Buy now</a> |
| 29  | <a href="#">9709506014</a><br>Bolt(gj3)                | <a href="#">Buy now</a> |
| 30  | <a href="#">9299506600</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |

## Bracket 3




  
6J8N700-F200

**F2**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 31  | <a href="#">9708008016</a><br>Bolt                      | <a href="#">Buy now</a> |
| 32  | <a href="#">9020108M00</a><br>Washer, plate(6e0)        | <a href="#">Buy now</a> |
| 33  | <a href="#">9038618M44</a><br>Bushing (6g5)             | <a href="#">Buy now</a> |
| 34  | <a href="#">9038618MA0</a><br>Bush                      | <a href="#">Buy now</a> |
| 35  | <a href="#">9024918M35</a><br>Pin, lower shock mount    | <a href="#">Buy now</a> |
| 36  | <a href="#">9011010M02</a><br>Bolt, hexagon socket head | <a href="#">Buy now</a> |
| 37  | <a href="#">9299510600</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 38  | <a href="#">9018510M13</a><br>Nut, self-locking         | <a href="#">Buy now</a> |
| 39  | <a href="#">9010112M65</a><br>Bolt                      | <a href="#">Buy now</a> |
| 40  | <a href="#">9299512200</a><br>Ybs66-12 washer,plain     | <a href="#">Buy now</a> |
| 41  | <a href="#">9020112426</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 42  | <a href="#">9538012600</a><br>Nut (707)                 | <a href="#">Buy now</a> |

## Bracket 4




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6K94313901</a><br>Cam, trim sender (with screw)   | <a href="#">Buy now</a> |
| 2   | <a href="#">9778060525</a><br>Screw, tapping(65j)             | <a href="#">Buy now</a> |
| 3   | <a href="#">6J84252800</a><br>Plate, friction                 | <a href="#">Buy now</a> |
| 4   | <a href="#">6894337301</a><br>Seal, damper                    | <a href="#">Buy now</a> |
| 5   | <a href="#">9010506M18</a><br>Bolt (689)                      | <a href="#">Buy now</a> |
| 6   | <a href="#">64E8367202</a><br>Trim sender                     | <a href="#">Buy now</a> |
| 7   | <a href="#">9788506016</a><br>Screw, pan head(6b0)            | <a href="#">Buy now</a> |
| 8   | <a href="#">9046508M63</a><br>Clamp(61u)                      | <a href="#">Buy now</a> |
| 9   | <a href="#">6J842510034D</a><br>Steering bracket assembly     | <a href="#">Buy now</a> |
| 10  | <a href="#">9038630M77</a><br>Bush(6h0)                       | <a href="#">Buy now</a> |
| 11  | <a href="#">9038630M78</a><br>Bush(6h0)                       | <a href="#">Buy now</a> |
| 12  | <a href="#">9020130M00</a><br>Washer, plate(6h1)              | <a href="#">Buy now</a> |
| 13  | <a href="#">9321029M94</a><br>O-ring(6h1)                     | <a href="#">Buy now</a> |
| 14  | <a href="#">9038630M60</a><br>Bush(6j8)                       | <a href="#">Buy now</a> |
| 15  | <a href="#">6H444551024D</a><br>Housing, lower mount rubber 1 | <a href="#">Buy now</a> |

## Bracket 4



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 16  | <a href="#">9341028M06</a><br>Circlip (688)                  | <a href="#">Buy now</a> |
| 17  | <a href="#">9011610M28</a><br>Bolt, stud                     | <a href="#">Buy now</a> |
| 18  | <a href="#">9299510600</a><br>Washer, plate                  | <a href="#">Buy now</a> |
| 19  | <a href="#">9018510051</a><br>Nut, self-locking              | <a href="#">Buy now</a> |
| 20  | <a href="#">6H44455710</a><br>Mount, lower front<br>L(21.5") | <a href="#">Buy now</a> |
| 21  | <a href="#">6H44455301</a><br>Cover, lower mount             | <a href="#">Buy now</a> |
| 22  | <a href="#">9709508025</a><br>Bolt (62g)                     | <a href="#">Buy now</a> |
| 23  | <a href="#">9299508600</a><br>Washer, plain (663)            | <a href="#">Buy now</a> |
| 24  | <a href="#">9709510060</a><br>Bolt, hexagon                  | <a href="#">Buy now</a> |
| 26  | <a href="#">6H48212700</a><br>Wire, lead 2                   | <a href="#">Buy now</a> |
| 27  | <a href="#">6H44451400</a><br>Mount, upper side              | <a href="#">Buy now</a> |
| 28  | <a href="#">9010908M26</a><br>Bolt(6j8)                      | <a href="#">Buy now</a> |
| 29  | <a href="#">9020109425</a><br>Washer, plate (663)            | <a href="#">Buy now</a> |
| 30  | <a href="#">9018508045</a><br>Nut, self-locking              | <a href="#">Buy now</a> |
| 31  | <a href="#">6j844511004D</a><br>Cover, upper mount           | <a href="#">Buy now</a> |

## Bracket 4




  
6J80010-9220

**F4**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 32  | <a href="#">9707508035</a><br>Bolt(70w)              | <a href="#">Buy now</a> |
| 33  | <a href="#">9299508100</a><br>Ybs67-8 washer, spring | <a href="#">Buy now</a> |
| 34  | <a href="#">6J848511514D</a><br>Hook, steering       | <a href="#">Buy now</a> |


# Carburetor



**B2**


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J81430111</a><br>Carburetor assembly 1      | <a href="#">Buy now</a> |
| 2   | <a href="#">6J81430201</a><br>Carburetor assembly 2      | <a href="#">Buy now</a> |
| 3   | <a href="#">6J81430301</a><br>Carburetor assembly 3      | <a href="#">Buy now</a> |
| 4   | <a href="#">6J81498400</a><br>Gasket, float chamber      | <a href="#">Buy now</a> |
| 5   | <a href="#">6J81498000</a><br>Body Float Chamber<br>#1,3 | <a href="#">Buy now</a> |
| 6   | <a href="#">6J81499100</a><br>Screw, drain               | <a href="#">Buy now</a> |
| 7   | <a href="#">6J81499500</a><br>Gasket, drin screw         | <a href="#">Buy now</a> |
| 8   | <a href="#">6J81498500</a><br>Float                      | <a href="#">Buy now</a> |
| 9   | <a href="#">6J81454600</a><br>Valve, needle              | <a href="#">Buy now</a> |
| 10  | <a href="#">6J81415900</a><br>Clip                       | <a href="#">Buy now</a> |
| 11  | <a href="#">6J81454800</a><br>Pin, float arm             | <a href="#">Buy now</a> |
| 12  | <a href="#">6J81492F26</a><br>Jet Air Slow (#50)         | <a href="#">Buy now</a> |
| 13  | <a href="#">6J81496600</a><br>Plug                       | <a href="#">Buy now</a> |
| 14  | <a href="#">6J81492E51</a><br>Jet, main (#102)           | <a href="#">Buy now</a> |
| 15  | <a href="#">6J81412600</a><br>Plug                       | <a href="#">Buy now</a> |

# Carburetor



| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6J81411800</a><br>Plug                         | <a href="#">Buy now</a> |
| 17  | <a href="#">6J81452701</a><br>Plate                        | <a href="#">Buy now</a> |
| 18  | <a href="#">6J81492300</a><br>Screw, pilot                 | <a href="#">Buy now</a> |
| 19  | <a href="#">6J81455500</a><br>Spring                       | <a href="#">Buy now</a> |
| 20  | <a href="#">9798004110</a><br>Screw, pan head (e56)        | <a href="#">Buy now</a> |
| 21  | <a href="#">9798004112</a><br>Screw, pan head (686)        | <a href="#">Buy now</a> |
| 22  | <a href="#">9878005008</a><br>Screw Flat Head(6J8)         | <a href="#">Buy now</a> |
| 23  | <a href="#">6J81459201</a><br>Screw                        | <a href="#">Buy now</a> |
| 24  | <a href="#">9299005600</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |
| 25  | <a href="#">6J81452300</a><br>Screw, stop<br>#1            | <a href="#">Buy now</a> |
| 26  | <a href="#">6J81433400</a><br>Spring, throttle<br>#1       | <a href="#">Buy now</a> |
| 27  | <a href="#">6J81498100</a><br>Body, Float Chamber<br>#2    | <a href="#">Buy now</a> |
| 28  | <a href="#">6J82447100</a><br>Diaphragm<br>#2              | <a href="#">Buy now</a> |
| 29  | <a href="#">6J82441500</a><br>Body comp (with valve)<br>#2 | <a href="#">Buy now</a> |
| 30  | <a href="#">6J82443200</a><br>Gasket, fuel pump 2<br>#2    | <a href="#">Buy now</a> |

# Carburetor




FWD  
6J80010-9050

B2

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 31  | <a href="#">6J82445200</a><br>Cover<br>#2                   | <a href="#">Buy now</a> |
| 32  | <a href="#">9798003122</a><br>Screw, with washer(6j8)<br>#2 | <a href="#">Buy now</a> |
| 33  | <a href="#">9798004124</a><br>Screw, with washer(6j8)<br>#2 | <a href="#">Buy now</a> |
| 34  | <a href="#">6J81457800</a><br>Collar<br>#2                  | <a href="#">Buy now</a> |
| 35  | <a href="#">6J81492A00</a><br>Nozzle, main                  | <a href="#">Buy now</a> |

# Control 1




6J8L300-F160

**D7**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J81449700</a><br>Stay, throttle wire    | <a href="#">Buy now</a> |
| 2   | <a href="#">6J84121300</a><br>Cam, accel.            | <a href="#">Buy now</a> |
| 3   | <a href="#">9010906M28</a><br>Bolt(6j8)              | <a href="#">Buy now</a> |
| 4   | <a href="#">9788006025</a><br>Screw, pan head(6b0)   | <a href="#">Buy now</a> |
| 5   | <a href="#">9530306600</a><br>Nut(661)               | <a href="#">Buy now</a> |
| 6   | <a href="#">6J84216700</a><br>Spring 1               | <a href="#">Buy now</a> |
| 7   | <a href="#">6J84163102</a><br>Lever, magneto control | <a href="#">Buy now</a> |
| 8   | <a href="#">6894216901</a><br>Joint                  | <a href="#">Buy now</a> |
| 9   | <a href="#">6824123700</a><br>Joint, link 2          | <a href="#">Buy now</a> |
| 10  | <a href="#">9538005600</a><br>Nut, hexagon (663)     | <a href="#">Buy now</a> |
| 11  | <a href="#">6J84412300</a><br>Arm, shift rod         | <a href="#">Buy now</a> |
| 12  | <a href="#">9025403M04</a><br>Pin, spring (6h3)      | <a href="#">Buy now</a> |
| 13  | <a href="#">9299006200</a><br>Ybs66-6 washer, plain  | <a href="#">Buy now</a> |
| 14  | <a href="#">9149020012</a><br>Pin, cotter (648)      | <a href="#">Buy now</a> |
| 15  | <a href="#">6J84412100</a><br>Lever, shift rod       | <a href="#">Buy now</a> |

# Control 1




6J6L300-F160

**D7**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">6G1416620194</a><br>Bracket                 | <a href="#">Buy now</a> |
| 17  | <a href="#">9701306020</a><br>Bolt(62y)                 | <a href="#">Buy now</a> |
| 18  | <a href="#">9290306600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 19  | <a href="#">6J84411600</a><br>Spring                    | <a href="#">Buy now</a> |
| 20  | <a href="#">9589506012</a><br>Bolt, flange deep recess  | <a href="#">Buy now</a> |
| 21  | <a href="#">6J84414300</a><br>Rod, shift                | <a href="#">Buy now</a> |
| 22  | <a href="#">9299005600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 23  | <a href="#">9149016010</a><br>Pin, cotter               | <a href="#">Buy now</a> |
| 24  | <a href="#">9017006015</a><br>Connector, shift rod      | <a href="#">Buy now</a> |
| 25  | <a href="#">6894337301</a><br>Seal, damper              | <a href="#">Buy now</a> |
| 26  | <a href="#">6J84219200</a><br>Rod 2                     | <a href="#">Buy now</a> |
| 29  | <a href="#">6J84215401</a><br>Lever, throttle control   | <a href="#">Buy now</a> |
| 30  | <a href="#">9020210024</a><br>Washer plate 648441880000 | <a href="#">Buy now</a> |
| 31  | <a href="#">9578008300</a><br>Nut, nylon (6j8)          | <a href="#">Buy now</a> |
| 32  | <a href="#">6J84414200</a><br>Joint                     | <a href="#">Buy now</a> |

# Control 1



| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 34  | <a href="#">6824272600</a><br>Grommet 3           | <a href="#">Buy now</a> |
| 35  | <a href="#">9020212M17</a><br>Washer, plate (6e0) | <a href="#">Buy now</a> |

## Control 2




  
6J80010-9180

**E2**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J84853400</a><br>Throttle lever, control   | <a href="#">Buy now</a> |
| 2   | <a href="#">9299008100</a><br>Ybs67-8 washer, spring    | <a href="#">Buy now</a> |
| 3   | <a href="#">6J84854401</a><br>Lever, shiftcontrol       | <a href="#">Buy now</a> |
| 4   | <a href="#">6J84417700</a><br>Washer                    | <a href="#">Buy now</a> |
| 5   | <a href="#">9025403M03</a><br>Pin, spring               | <a href="#">Buy now</a> |
| 6   | <a href="#">6J84417302</a><br>Lever, shift control      | <a href="#">Buy now</a> |
| 7   | <a href="#">6J84216901</a><br>Joint                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6J84853100</a><br>Bracket, remote control   | <a href="#">Buy now</a> |
| 9   | <a href="#">6J84853200</a><br>Bracket, remote control 2 | <a href="#">Buy now</a> |
| 10  | <a href="#">6824853850</a><br>Clamp, cable              | <a href="#">Buy now</a> |
| 11  | <a href="#">9169030012</a><br>Pin, spring               | <a href="#">Buy now</a> |
| 12  | <a href="#">9010906M29</a><br>Bolt(6j8)                 | <a href="#">Buy now</a> |
| 13  | <a href="#">9017906M24</a><br>Nut(6j8)                  | <a href="#">Buy now</a> |
| 14  | <a href="#">6G82636300</a><br>End, wire 1               | <a href="#">Buy now</a> |
| 15  | <a href="#">6G82636400</a><br>End, wire 2               | <a href="#">Buy now</a> |

# Crankshaft & Piston




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J81140011</a><br>Crankshaft assembly             | <a href="#">Buy now</a> |
| 2   | <a href="#">6J81153600</a><br>Gear, drive                     | <a href="#">Buy now</a> |
| 3   | <a href="#">93311632U7</a><br>Bearing, cylindrical(6j8)       | <a href="#">Buy now</a> |
| 4   | <a href="#">9310226M27</a><br>Oil seal(6j8)                   | <a href="#">Buy now</a> |
| 5   | <a href="#">9321042159</a><br>O-ring (647)                    | <a href="#">Buy now</a> |
| 6   | <a href="#">93306305U3</a><br>Bearing(6j8)                    | <a href="#">Buy now</a> |
| 7   | <a href="#">9020150306</a><br>Washer plate 648115870000       | <a href="#">Buy now</a> |
| 8   | <a href="#">6J8116310297</a><br>Piston (std)                  | <a href="#">Buy now</a> |
| 8   | <a href="#">6J81163502</a><br>Piston (0.25mm o/s)<br>AP       | <a href="#">Buy now</a> |
| 8   | <a href="#">6J81163602</a><br>Piston (0.50mm o/s)<br>AP       | <a href="#">Buy now</a> |
| 9   | <a href="#">6J81160101</a><br>Piston ring set (std)           | <a href="#">Buy now</a> |
| 9   | <a href="#">6J81160111</a><br>Piston ring set (1st o/s)<br>AP | <a href="#">Buy now</a> |
| 9   | <a href="#">6J81160121</a><br>Piston ring set (2nd o/s)<br>AP | <a href="#">Buy now</a> |
| 10  | <a href="#">6J81163300</a><br>Pin, piston                     | <a href="#">Buy now</a> |
| 11  | <a href="#">9360216M10</a><br>Pin, dowel(6j8)                 | <a href="#">Buy now</a> |

# Crankshaft & Piston



| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 12  | <a href="#">9020116379</a><br>Washer plate        | <a href="#">Buy now</a> |
| 13  | <a href="#">9345017129</a><br>Circlip(1ar)        | <a href="#">Buy now</a> |
| 14  | <a href="#">6J815396005B</a><br>Housing, oil seal | <a href="#">Buy now</a> |
| 15  | <a href="#">9310125M28</a><br>Oil seal(6j8)       | <a href="#">Buy now</a> |
| 16  | <a href="#">9310416M04</a><br>Oil seal(6a8)       | <a href="#">Buy now</a> |
| 17  | <a href="#">9321056M80</a><br>O-ring(6j8)         | <a href="#">Buy now</a> |
| 18  | <a href="#">9011906023</a><br>Bolt, with washer   | <a href="#">Buy now</a> |


# Cylinder & Crankcase



**A5**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J8W0090431S</a><br>Crank cylinder assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6J815100111S</a><br>Crankcase assembly      | <a href="#">Buy now</a> |
| 3   | <a href="#">6501137001</a><br>Check valve assembly      | <a href="#">Buy now</a> |
| 4   | <a href="#">6241448500</a><br>Pipe, joint               | <a href="#">Buy now</a> |
| 5   | <a href="#">9011908019</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 6   | <a href="#">9011906MA4</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 7   | <a href="#">9360612019</a><br>Pin, dowel (614)          | <a href="#">Buy now</a> |
| 8   | <a href="#">6F51111900</a><br>Hanger, engine            | <a href="#">Buy now</a> |
| 9   | <a href="#">9010108001</a><br>Bolt                      | <a href="#">Buy now</a> |
| 10  | <a href="#">6J81132500</a><br>Anode                     | <a href="#">Buy now</a> |
| 11  | <a href="#">6H311327001S</a><br>Cover, anode            | <a href="#">Buy now</a> |
| 12  | <a href="#">6H31132800</a><br>Grommet, anode            | <a href="#">Buy now</a> |
| 13  | <a href="#">9011906023</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 14  | <a href="#">9044507M29</a><br>Hose (1200)               | <a href="#">Buy now</a> |
| 15  | <a href="#">9046706016</a><br>Clip (655)                | <a href="#">Buy now</a> |

# Cylinder & Crankcase




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 16  | <a href="#">6J81111001S</a><br>Head, cylinder 1           | <a href="#">Buy now</a> |
| 17  | <a href="#">6J811181A1</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 18  | <a href="#">6J811191001S</a><br>Cover, cylinder head 1    | <a href="#">Buy now</a> |
| 19  | <a href="#">6J811193A1</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 20  | <a href="#">9011908MA8</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 21  | <a href="#">6881241111</a><br>Thermostat                  | <a href="#">Buy now</a> |
| 22  | <a href="#">6881241200</a><br>Seal, thermostat            | <a href="#">Buy now</a> |
| 23  | <a href="#">6H412413001S</a><br>Cover, thermostat         | <a href="#">Buy now</a> |
| 24  | <a href="#">6J812414A0</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 25  | <a href="#">9011906MA3</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 26  | <a href="#">6J841113001S</a><br>Outer cover, exhaust      | <a href="#">Buy now</a> |
| 27  | <a href="#">6761137200</a><br>Nipple, hose                | <a href="#">Buy now</a> |
| 28  | <a href="#">6J841111001S</a><br>Inner cover, exhaust      | <a href="#">Buy now</a> |
| 29  | <a href="#">6J841114A0</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |
| 30  | <a href="#">6J81111J00</a><br>Pipe 1                      | <a href="#">Buy now</a> |

# Cylinder & Crankcase




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 31  | <a href="#">9011906MA5</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 33  | <a href="#">6J845113A0</a><br>Gasket, upper casing   | <a href="#">Buy now</a> |
| 34  | <a href="#">9470200271</a><br>Plug, spark (br7hs-10) | <a href="#">Buy now</a> |

# Electrical 1



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J885540H2</a><br>C.d.i. unit assembly           | <a href="#">Buy now</a> |
| 2   | <a href="#">9709506025</a><br>Bolt                           | <a href="#">Buy now</a> |
| 3   | <a href="#">9299506600</a><br>Washer, plain (646)            | <a href="#">Buy now</a> |
| 4   | <a href="#">9046415M11</a><br>Clamp (3y2)                    | <a href="#">Buy now</a> |
| 5   | <a href="#">9709506012</a><br>Bolt(gh1)                      | <a href="#">Buy now</a> |
| 7   | <a href="#">6J88253100</a><br>Wire, lead                     | <a href="#">Buy now</a> |
| 10  | <a href="#">6J88557021</a><br>Ignition coil assembly         | <a href="#">Buy now</a> |
| 11  | <a href="#">9709506020</a><br>Bolt(7u8)                      | <a href="#">Buy now</a> |
| 12  | <a href="#">9299506100</a><br>Washer(6a1)                    | <a href="#">Buy now</a> |
| 13  | <a href="#">9046405M16</a><br>Clamp(6j8)                     | <a href="#">Buy now</a> |
| 14  | <a href="#">6G18237021</a><br>Plug cap assembly              | <a href="#">Buy now</a> |
| 15  | <a href="#">6898256000</a><br>Thermo switch assembly         | <a href="#">Buy now</a> |
| 16  | <a href="#">6J88196000</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 17  | <a href="#">6J88197500</a><br>Plate, rectifier fitting       | <a href="#">Buy now</a> |
| 18  | <a href="#">6894419400</a><br>Cap                            | <a href="#">Buy now</a> |


# Electrical 1



**C4**


| Ref | Part                                       |                         |
|-----|--------------------------------------------|-------------------------|
| 21  | <a href="#">9048025161</a><br>Grommet(656) | <a href="#">Buy now</a> |

## Electrical 2



| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G18194110</a><br>Starter relay             | <a href="#">Buy now</a> |
| 2   | <a href="#">6G18195200</a><br>Holder, relay             | <a href="#">Buy now</a> |
| 3   | <a href="#">6J88194500</a><br>Plate, switch fitting     | <a href="#">Buy now</a> |
| 4   | <a href="#">9701306016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 5   | <a href="#">9290306600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 6   | <a href="#">6F58211700</a><br>Wire, lead                | <a href="#">Buy now</a> |
| 7   | <a href="#">6G18197061</a><br>Rectifier assembly        | <a href="#">Buy now</a> |
| 8   | <a href="#">6G18215100</a><br>Fuse (10a)                | <a href="#">Buy now</a> |
| 9   | <a href="#">9788005025</a><br>Screw, panhead (a93)      | <a href="#">Buy now</a> |
| 10  | <a href="#">9299005600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 11  | <a href="#">6J88191610</a><br>Cover, terminal           | <a href="#">Buy now</a> |
| 12  | <a href="#">9046513M18</a><br>Clamp                     | <a href="#">Buy now</a> |
| 13  | <a href="#">9046518147</a><br>Clamp                     | <a href="#">Buy now</a> |
| 14  | <a href="#">9015905M26</a><br>Screw, with washer(6g7)   | <a href="#">Buy now</a> |
| 15  | <a href="#">6E98355770</a><br>Tube                      | <a href="#">Buy now</a> |


## Electrical 2



**C5**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">6H38215100</a><br>Fuse (10a)              | <a href="#">Buy now</a> |
| 17  | <a href="#">6J88611000</a><br>Solenoid                | <a href="#">Buy now</a> |
| 18  | <a href="#">6J88611600</a><br>Wire, pull              | <a href="#">Buy now</a> |
| 19  | <a href="#">6828611700</a><br>Hook, wire pull         | <a href="#">Buy now</a> |
| 22  | <a href="#">9321003261</a><br>O-ring (663)            | <a href="#">Buy now</a> |
| 23  | <a href="#">6J88258000</a><br>Wire harness assembly 2 | <a href="#">Buy now</a> |
| 24  | <a href="#">6J84272450</a><br>Grommet                 | <a href="#">Buy now</a> |
| 25  | <a href="#">6898210513</a><br>Battery cable           | <a href="#">Buy now</a> |
| 26  | <a href="#">9046415M11</a><br>Clamp (3y2)             | <a href="#">Buy now</a> |

## Electrical 3




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G18194110</a><br>Starter relay             | <a href="#">Buy now</a> |
| 2   | <a href="#">6G18195200</a><br>Holder, relay             | <a href="#">Buy now</a> |
| 3   | <a href="#">6J88194500</a><br>Plate, switch fitting     | <a href="#">Buy now</a> |
| 4   | <a href="#">9701306016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 5   | <a href="#">9290306600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 6   | <a href="#">6F58211700</a><br>Wire, lead                | <a href="#">Buy now</a> |
| 7   | <a href="#">6G18197061</a><br>Rectifier assembly        | <a href="#">Buy now</a> |
| 8   | <a href="#">6G18215100</a><br>Fuse (10a)                | <a href="#">Buy now</a> |
| 9   | <a href="#">9788005025</a><br>Screw, panhead (a93)      | <a href="#">Buy now</a> |
| 10  | <a href="#">9299005600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 11  | <a href="#">6J88191610</a><br>Cover, terminal           | <a href="#">Buy now</a> |
| 12  | <a href="#">9046513M18</a><br>Clamp                     | <a href="#">Buy now</a> |
| 13  | <a href="#">9046518147</a><br>Clamp                     | <a href="#">Buy now</a> |
| 14  | <a href="#">9015905M26</a><br>Screw, with washer(6g7)   | <a href="#">Buy now</a> |
| 15  | <a href="#">6E98355770</a><br>Tube                      | <a href="#">Buy now</a> |

## Electrical 3



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">6H38215100</a><br>Fuse (10a)              | <a href="#">Buy now</a> |
| 17  | <a href="#">6J88611000</a><br>Solenoid                | <a href="#">Buy now</a> |
| 18  | <a href="#">6J88611600</a><br>Wire, pull              | <a href="#">Buy now</a> |
| 19  | <a href="#">6828611700</a><br>Hook, wire pull         | <a href="#">Buy now</a> |
| 22  | <a href="#">9321003261</a><br>O-ring (663)            | <a href="#">Buy now</a> |
| 23  | <a href="#">6J88258010</a><br>Wire harness assembly 2 | <a href="#">Buy now</a> |
| 24  | <a href="#">6J84272460</a><br>Grommet                 | <a href="#">Buy now</a> |
| 25  | <a href="#">6898210513</a><br>Battery cable           | <a href="#">Buy now</a> |
| 26  | <a href="#">9046415M11</a><br>Clamp (3y2)             | <a href="#">Buy now</a> |
| 27  | <a href="#">6J88195000</a><br>Relay assembly          | <a href="#">Buy now</a> |
| 28  | <a href="#">9038706M03</a><br>Collar (676)            | <a href="#">Buy now</a> |
| 29  | <a href="#">9011906M17</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 30  | <a href="#">9046508M12</a><br>Clamp (6e5)             | <a href="#">Buy now</a> |
| 31  | <a href="#">9044614M88</a><br>Hose                    | <a href="#">Buy now</a> |
| 32  | <a href="#">6H58192000</a><br>Terminal assembly       | <a href="#">Buy now</a> |


## Electrical 3



**C6**

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 33  | <a href="#">9709506014</a><br>Bolt(gj3)           | <a href="#">Buy now</a> |
| 34  | <a href="#">9299506600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 35  | <a href="#">9709506012</a><br>Bolt(gh1)           | <a href="#">Buy now</a> |
| 37  | <a href="#">6828211901</a><br>Cover, lead wire    | <a href="#">Buy now</a> |


# Fuel



**B6**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G12430402</a><br>Fuel pipe joint comp. 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">9709506025</a><br>Bolt                    | <a href="#">Buy now</a> |
| 3   | <a href="#">9299506600</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 4   | <a href="#">9046708004</a><br>Clip, pipe 6162435600   | <a href="#">Buy now</a> |
| 5   | <a href="#">9044509M00</a><br>Hose (1180)             | <a href="#">Buy now</a> |
| 6   | <a href="#">61N2456000</a><br>Filter assembly         | <a href="#">Buy now</a> |
| 7   | <a href="#">61N2456300</a><br>Element, filter         | <a href="#">Buy now</a> |
| 8   | <a href="#">61N2452100</a><br>Cup, filter             | <a href="#">Buy now</a> |
| 9   | <a href="#">9321032738</a><br>O-ring(1wg)             | <a href="#">Buy now</a> |
| 10  | <a href="#">9017908M15</a><br>Nut(6j8)                | <a href="#">Buy now</a> |
| 11  | <a href="#">6E52431200</a><br>Pipe 2                  | <a href="#">Buy now</a> |
| 12  | <a href="#">9046409M21</a><br>Clamp(6j8)              | <a href="#">Buy now</a> |
| 13  | <a href="#">6882431300</a><br>Pipe, fuel 2            | <a href="#">Buy now</a> |
| 14  | <a href="#">6J82431100</a><br>Pipe, fuel 2            | <a href="#">Buy now</a> |
| 16  | <a href="#">61H2819R31</a><br>Tag Warning             | <a href="#">Buy now</a> |

# Fuel



| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 17  | <a href="#">656W281002</a><br>Tool kit                           | <a href="#">Buy now</a> |
| 18  | <a href="#">6J82817000</a><br>Tool, holder                       | <a href="#">Buy now</a> |
| 19  | <a href="#">6G12811G00</a><br>Band                               | <a href="#">Buy now</a> |
| 20  | <a href="#">9709508016</a><br>Bolt, hexagon deep recess          | <a href="#">Buy now</a> |
| 21  | <a href="#">9299508600</a><br>Washer, plain (663)                | <a href="#">Buy now</a> |
| 22  | <a href="#">9046412M17</a><br>Clamp(6j8)                         | <a href="#">Buy now</a> |
| 23  | <a href="#">9046518147</a><br>Clamp                              | <a href="#">Buy now</a> |
| 24  | <a href="#">6E0281930094</a><br>Plug, water check<br>AP D)12.5MM | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82819972E0</a><br>O/m 30d '07<br>UR (E)            | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82819972F0</a><br>O/m 30d '07<br>UR (F)            | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82819972S0</a><br>O/m 30d '07<br>UR (ES)           | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82819972D0</a><br>O/m 30d '07<br>UR (NL)           | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82819972G0</a><br>O/m 30d '07<br>UR (D)            | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82819972H0</a><br>O/m 30d '07<br>UR (I)            | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8281998DK0</a><br>O/m 30d '07<br>UR (DK)           | <a href="#">Buy now</a> |


# Fuel



**B6**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 26  | <a href="#">6J8281998DL0</a><br>O/m 30d '07<br>UR (SF) | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8281998DM0</a><br>O/m 30d '07<br>UR (S)  | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8281998DN0</a><br>O/m 30d '07<br>UR (N)  | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8281998DP0</a><br>O/m 30d '07<br>UR (P)  | <a href="#">Buy now</a> |
| 26  | <a href="#">6J8281998DR0</a><br>O/m 30d '07<br>UR (GR) | <a href="#">Buy now</a> |


# Fuel Tank



**B4**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YK2420102</a><br>-<br>AP                 | <a href="#">Buy now</a> |
| 2   | <a href="#">6YL2426801</a><br>Gasket, fuel meter      | <a href="#">Buy now</a> |
| 3   | <a href="#">6YK2461001</a><br>Cap assembly            | <a href="#">Buy now</a> |
| 4   | <a href="#">6YK2426001</a><br>Fuel meter assembly     | <a href="#">Buy now</a> |
| 5   | <a href="#">9015705M16</a><br>Screw, pan head         | <a href="#">Buy now</a> |
| 6   | <a href="#">6YL2432900</a><br>Seal                    | <a href="#">Buy now</a> |
| 7   | <a href="#">6YL2430654</a><br>Fuel pipe comp. 1<br>AP | <a href="#">Buy now</a> |


# Generator



**C3**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H485533A1</a><br>Coil, lighting          | <a href="#">Buy now</a> |
| 2   | <a href="#">6J885550A1</a><br>Rotor assembly          | <a href="#">Buy now</a> |
| 2   | <a href="#">6J885550F1</a><br>Rotor assembly          | <a href="#">Buy now</a> |
| 3   | <a href="#">6H485510F1</a><br>Stator assembly         | <a href="#">Buy now</a> |
| 3   | <a href="#">6J885510A1</a><br>Stator assembly         | <a href="#">Buy now</a> |
| 4   | <a href="#">6H48552001</a><br>Coil, charge            | <a href="#">Buy now</a> |
| 4   | <a href="#">6J88552001</a><br>Coil, charge            | <a href="#">Buy now</a> |
| 5   | <a href="#">9790206120</a><br>Screw, with washer      | <a href="#">Buy now</a> |
| 6   | <a href="#">9790204112</a><br>Screw, with washer      | <a href="#">Buy now</a> |
| 7   | <a href="#">9790204106</a><br>Screw, with washer      | <a href="#">Buy now</a> |
| 8   | <a href="#">9E47109205</a><br>Housing,m-9-b 5pcs(61a) | <a href="#">Buy now</a> |
| 9   | <a href="#">6H48554800</a><br>Clamp, cord             | <a href="#">Buy now</a> |
| 10  | <a href="#">9790205408</a><br>Screw, with washer      | <a href="#">Buy now</a> |
| 11  | <a href="#">6638551800</a><br>Joint, ball             | <a href="#">Buy now</a> |
| 12  | <a href="#">9028005013</a><br>Key, woodruff           | <a href="#">Buy now</a> |


# Generator



**C3**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 13  | <a href="#">9017916M05</a><br>Nut (689)              | <a href="#">Buy now</a> |
| 14  | <a href="#">9020116M44</a><br>Washer (689)           | <a href="#">Buy now</a> |
| 15  | <a href="#">6H44161110</a><br>Retainer, magneto base | <a href="#">Buy now</a> |
| 16  | <a href="#">6J84161500</a><br>Stopper, magneto base  | <a href="#">Buy now</a> |
| 17  | <a href="#">6J84161800</a><br>Washer, magneto        | <a href="#">Buy now</a> |
| 18  | <a href="#">9788006012</a><br>Screw, pan head(62j)   | <a href="#">Buy now</a> |
| 19  | <a href="#">6J88554800</a><br>Holder                 | <a href="#">Buy now</a> |
| 20  | <a href="#">9010106M00</a><br>Bolt(682)              | <a href="#">Buy now</a> |
| 21  | <a href="#">9038706M81</a><br>Collar                 | <a href="#">Buy now</a> |
| 22  | <a href="#">6J88133200</a><br>Plate, timing          | <a href="#">Buy now</a> |
| 23  | <a href="#">9788505010</a><br>Screw, pan head(62x)   | <a href="#">Buy now</a> |
| 24  | <a href="#">9299505600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |


# Intake



**B1**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J81361000</a><br>Reed Valve assembly    | <a href="#">Buy now</a> |
| 2   | <a href="#">6J8W000400</a><br>Reed set               | <a href="#">Buy now</a> |
| 3   | <a href="#">9788005016</a><br>Screw, pan head(6b0)   | <a href="#">Buy now</a> |
| 4   | <a href="#">9299005600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 5   | <a href="#">6J8136411094</a><br>Manifold 1           | <a href="#">Buy now</a> |
| 6   | <a href="#">6761448500</a><br>Pipe, joint            | <a href="#">Buy now</a> |
| 7   | <a href="#">6J81362100</a><br>Gasket, valve seat     | <a href="#">Buy now</a> |
| 8   | <a href="#">9011906MA3</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 9   | <a href="#">6J81419800</a><br>Gasket                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9011906M32</a><br>Bolt, with washer(6j8) | <a href="#">Buy now</a> |
| 11  | <a href="#">6J81441700</a><br>Cover 1                | <a href="#">Buy now</a> |
| 12  | <a href="#">6J81441800</a><br>Cover 2                | <a href="#">Buy now</a> |
| 13  | <a href="#">6J81447600</a><br>Seal                   | <a href="#">Buy now</a> |
| 14  | <a href="#">9011905M31</a><br>Bolt, with washer(6j8) | <a href="#">Buy now</a> |
| 15  | <a href="#">6J814483A1</a><br>Gasket                 | <a href="#">Buy now</a> |


# Intake



**B1**


| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 16  | <a href="#">9788005040</a><br>Screw,panhead (eg9) | <a href="#">Buy now</a> |
| 18  | <a href="#">6J84125900</a><br>Rod, choke 3        | <a href="#">Buy now</a> |
| 19  | <a href="#">6614126202</a><br>Joint, choke lever  | <a href="#">Buy now</a> |
| 20  | <a href="#">6J84127101</a><br>Knob, choke         | <a href="#">Buy now</a> |
| 21  | <a href="#">6J84125700</a><br>Rod, choke 2        | <a href="#">Buy now</a> |
| 22  | <a href="#">6J84126200</a><br>Joint, choke lever  | <a href="#">Buy now</a> |
| 23  | <a href="#">6894127300</a><br>Grommet             | <a href="#">Buy now</a> |
| 24  | <a href="#">6J84127400</a><br>Grommet 2           | <a href="#">Buy now</a> |
| 25  | <a href="#">6J84121700</a><br>Rod, accel. lever   | <a href="#">Buy now</a> |
| 26  | <a href="#">6A18362541</a><br>Mark 5              | <a href="#">Buy now</a> |
| 27  | <a href="#">6A18362551</a><br>Mark 5              | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J845300044D</a><br>Lower unit assembly<br>S(16.7") | <a href="#">Buy now</a> |
| 1   | <a href="#">6J845300144D</a><br>Lower unit assembly<br>L(21.5") | <a href="#">Buy now</a> |
| 2   | <a href="#">6J845301024D</a><br>Casing, lower                   | <a href="#">Buy now</a> |
| 3   | <a href="#">93315220V7</a><br>Bearing, cylindrical(6j8)         | <a href="#">Buy now</a> |
| 4   | <a href="#">6J84553600</a><br>Sleeve, drive shaft               | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558701</a><br>Shim (t:0.10mm)<br>UR             | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558710</a><br>Shim (t:0.12mm)<br>UR             | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558720</a><br>Shim (t:0.15mm)<br>UR             | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558730</a><br>Shim (t:0.18mm)<br>UR             | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558740</a><br>Shim (t:0.30mm)<br>UR             | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558750</a><br>Shim (t:0.40mm)<br>UR             | <a href="#">Buy now</a> |
| 5   | <a href="#">6634558760</a><br>Shim (t:0.50mm)<br>UR             | <a href="#">Buy now</a> |
| 6   | <a href="#">9333200001</a><br>Brg, tapered roller (409)         | <a href="#">Buy now</a> |
| 7   | <a href="#">6E54537800</a><br>Nipple, hose                      | <a href="#">Buy now</a> |
| 8   | <a href="#">9044507M31</a><br>Hose (I200)<br>L(21.5")           | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 8   | <a href="#">9044507ME9</a><br>Hose (I250)<br>S(16.7")        | <a href="#">Buy now</a> |
| 9   | <a href="#">6E58355800</a><br>End, nipple                    | <a href="#">Buy now</a> |
| 10  | <a href="#">9046511M10</a><br>Clamp                          | <a href="#">Buy now</a> |
| 11  | <a href="#">9034008002</a><br>Plug, straight screw           | <a href="#">Buy now</a> |
| 12  | <a href="#">9043008020</a><br>Gasket                         | <a href="#">Buy now</a> |
| 13  | <a href="#">6824417600</a><br>Bracket                        | <a href="#">Buy now</a> |
| 14  | <a href="#">9778050510</a><br>Screw, tapping(6u1)            | <a href="#">Buy now</a> |
| 15  | <a href="#">6J84415000</a><br>Shift cam assembly<br>S(16.7") | <a href="#">Buy now</a> |
| 15  | <a href="#">6J84415010</a><br>Shift cam assembly<br>L(21.5") | <a href="#">Buy now</a> |
| 16  | <a href="#">6824414700</a><br>Boot, shift rod                | <a href="#">Buy now</a> |
| 17  | <a href="#">9538006700</a><br>Nut                            | <a href="#">Buy now</a> |
| 18  | <a href="#">6J84431100</a><br>Housing, water pump            | <a href="#">Buy now</a> |
| 19  | <a href="#">6634432200</a><br>Insert, cartridge              | <a href="#">Buy now</a> |
| 20  | <a href="#">6H44435202</a><br>Impeller                       | <a href="#">Buy now</a> |
| 21  | <a href="#">66344315A0</a><br>Gasket,water pump 1            | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 22  | <a href="#">6634436600</a><br>Damper, water seal 2          | <a href="#">Buy now</a> |
| 23  | <a href="#">9028003024</a><br>Key, woodruff(662)            | <a href="#">Buy now</a> |
| 24  | <a href="#">663443410094</a><br>Housing, water pump         | <a href="#">Buy now</a> |
| 25  | <a href="#">9310123070</a><br>Oil seal (663)                | <a href="#">Buy now</a> |
| 26  | <a href="#">9321041042</a><br>O-ring (132)                  | <a href="#">Buy now</a> |
| 27  | <a href="#">66344316A0</a><br>Gasket,water pump 2           | <a href="#">Buy now</a> |
| 28  | <a href="#">6634432300</a><br>Outer plate, cartridge        | <a href="#">Buy now</a> |
| 29  | <a href="#">66344324A0</a><br>Gasket,cartridge outer plate  | <a href="#">Buy now</a> |
| 30  | <a href="#">9360408062</a><br>Pin,dowel (626)               | <a href="#">Buy now</a> |
| 31  | <a href="#">9011908M13</a><br>Bolt, with washer(6h0)        | <a href="#">Buy now</a> |
| 32  | <a href="#">9011908M34</a><br>Bolt, with washer(6j8)        | <a href="#">Buy now</a> |
| 33  | <a href="#">6J84550100</a><br>Drive shaft comp.<br>S(16.7") | <a href="#">Buy now</a> |
| 33  | <a href="#">6J84550110</a><br>Drive shaft comp.<br>L(21.5") | <a href="#">Buy now</a> |
| 34  | <a href="#">6J84555100</a><br>Pinion                        | <a href="#">Buy now</a> |
| 35  | <a href="#">9017910M14</a><br>Nut(6j8)                      | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 36  | <a href="#">6J84556000</a><br>Gear                           | <a href="#">Buy now</a> |
| 37  | <a href="#">93332000V6</a><br>Bearing(6j8)                   | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556701</a><br>Shim (t:0.10mm)<br>UR          | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556710</a><br>Shim (t:0.12mm)<br>UR          | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556720</a><br>Shim, thrust (0.15t)<br>UR     | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556730</a><br>Shim (t:0.18mm)<br>UR          | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556740</a><br>Shim, thrust (0.3t)<br>UR      | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556750</a><br>Shim, thrust (0.4t)<br>UR      | <a href="#">Buy now</a> |
| 38  | <a href="#">6J84556760</a><br>Shim, thrust (0.5t)<br>UR      | <a href="#">Buy now</a> |
| 39  | <a href="#">6J84561100</a><br>Shaft, propeller               | <a href="#">Buy now</a> |
| 40  | <a href="#">9050110065</a><br>Spring compression648456360000 | <a href="#">Buy now</a> |
| 41  | <a href="#">6J84563100</a><br>Clutch, dog                    | <a href="#">Buy now</a> |
| 42  | <a href="#">9025005010</a><br>Pin straight 648456320000      | <a href="#">Buy now</a> |
| 43  | <a href="#">6484563300</a><br>Ring, cross pin                | <a href="#">Buy now</a> |
| 44  | <a href="#">6J84563500</a><br>Plunger, shift                 | <a href="#">Buy now</a> |

## Lower Casing & Drive 1



| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 45  | <a href="#">9020120417</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 46  | <a href="#">6J84557100</a><br>Gear                      | <a href="#">Buy now</a> |
| 47  | <a href="#">689453310194</a><br>Housing, bearing        | <a href="#">Buy now</a> |
| 48  | <a href="#">9330600612</a><br>Bearing(2hr)              | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557701</a><br>Shim (t:0.10mm)<br>UR     | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557710</a><br>Shim (t:0.12mm)<br>UR     | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557720</a><br>Shim (t:0.15mm)<br>UR     | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557730</a><br>Shim (t:0.18mm)<br>UR     | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557740</a><br>Shim (t:0.30mm)<br>UR     | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557750</a><br>Shim (t:0.40mm)<br>UR     | <a href="#">Buy now</a> |
| 49  | <a href="#">6644557760</a><br>Shim (t:0.50mm)<br>UR     | <a href="#">Buy now</a> |
| 50  | <a href="#">6644557600</a><br>Washer, thrust 2          | <a href="#">Buy now</a> |
| 51  | <a href="#">9321060MA3</a><br>O-ring(6j8)               | <a href="#">Buy now</a> |
| 52  | <a href="#">9331522004</a><br>Brg,cyl-cal roller 21g nt | <a href="#">Buy now</a> |
| 53  | <a href="#">9310120M07</a><br>Oil seal                  | <a href="#">Buy now</a> |


## Lower Casing & Drive 1



**A6**

| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 54  | <a href="#">9021445M02</a><br>Washer, claw(6a9) | <a href="#">Buy now</a> |
| 55  | <a href="#">6644538400</a><br>Nut               | <a href="#">Buy now</a> |
| 56  | <a href="#">9028204010</a><br>Key, strait(663)  | <a href="#">Buy now</a> |


## Lower Casing & Drive 2



**B2**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J84436100</a><br>Tube, water<br>S(16.7")   | <a href="#">Buy now</a> |
| 1   | <a href="#">6J84436110</a><br>Tube, water<br>L(21.5")   | <a href="#">Buy now</a> |
| 2   | <a href="#">6J84436600</a><br>Damper, water seal        | <a href="#">Buy now</a> |
| 3   | <a href="#">6634436700</a><br>Damper, water seal 3      | <a href="#">Buy now</a> |
| 4   | <a href="#">663453760094</a><br>Guide, seal damper      | <a href="#">Buy now</a> |
| 5   | <a href="#">6884537500</a><br>Damper, seal 2            | <a href="#">Buy now</a> |
| 6   | <a href="#">6J84522410</a><br>Cover, water inlet 3      | <a href="#">Buy now</a> |
| 7   | <a href="#">9788006012</a><br>Screw, pan head(62j)      | <a href="#">Buy now</a> |
| 8   | <a href="#">9360612019</a><br>Pin, dowel (614)          | <a href="#">Buy now</a> |
| 9   | <a href="#">9707510040</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 10  | <a href="#">9299510100</a><br>Ybs67-10 washer, spring   | <a href="#">Buy now</a> |
| 11  | <a href="#">9299510600</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 12  | <a href="#">9011908M92</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 13  | <a href="#">6894521401</a><br>Cover, water inlet 1      | <a href="#">Buy now</a> |
| 14  | <a href="#">6J84521500</a><br>Cover, water inlet        | <a href="#">Buy now</a> |


## Lower Casing & Drive 2



**B2**

| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 15  | <a href="#">9015205M04</a><br>Screw, countersunk                     | <a href="#">Buy now</a> |
| 16  | <a href="#">9018505002</a><br>Nut nylon (sus)(ex4)                   | <a href="#">Buy now</a> |
| 17  | <a href="#">6644537101</a><br>Tab-trim                               | <a href="#">Buy now</a> |
| 18  | <a href="#">9707508020</a><br>Bolt, hexagon                          | <a href="#">Buy now</a> |
| 19  | <a href="#">9299508100</a><br>Ybs67-8 washer, spring                 | <a href="#">Buy now</a> |
| 20  | <a href="#">9299508600</a><br>Washer, plain (663)                    | <a href="#">Buy now</a> |
| 21  | <a href="#">6L24598701</a><br>Spacer                                 | <a href="#">Buy now</a> |
| 22  | <a href="#">6894599700</a><br>Spacer                                 | <a href="#">Buy now</a> |
| 23  | <a href="#">9299014200</a><br>Washer, plain                          | <a href="#">Buy now</a> |
| 24  | <a href="#">9017114013</a><br>Nut(664)                               | <a href="#">Buy now</a> |
| 25  | <a href="#">9149030022</a><br>Pin, cotter                            | <a href="#">Buy now</a> |
| 26  | <a href="#">6644594101EL</a><br>Propeller (3x9-7/8"x9"-f)<br>UR      | <a href="#">Buy now</a> |
| 26  | <a href="#">6644594301EL</a><br>Propeller (3x9-7/8 x8 -f)<br>UR      | <a href="#">Buy now</a> |
| 26  | <a href="#">6644594500EL</a><br>Propeller (3x9-7/8 x10-1/2 -f)<br>UR | <a href="#">Buy now</a> |
| 26  | <a href="#">6644594701EL</a><br>Propeller (3x9-7/8 x11-1/4 -f)<br>UR | <a href="#">Buy now</a> |


## Lower Casing & Drive 2



**B2**


| Ref | Part                                                                      |                         |
|-----|---------------------------------------------------------------------------|-------------------------|
| 26  | <a href="#">6644594902EL</a><br>Propeller (3x9-7/8 x13 -f)<br>UR          | <a href="#">Buy now</a> |
| 26  | <a href="#">6644595200EL</a><br>Propeller (3x9-7/8 x14 -f)<br>UR          | <a href="#">Buy now</a> |
| 26  | <a href="#">6644595401EL</a><br>Propeller (3x9-7/8 x12 -f)<br>UR          | <a href="#">Buy now</a> |
| 26  | <a href="#">664459700098</a><br>Propeller (3x9-1/8 x13 -f)<br>UR WEEDLESS | <a href="#">Buy now</a> |
| 27  | <a href="#">6J8W459100EL</a><br>Propeller (3x10-5/8"x8-1/4"-f)            | <a href="#">Buy now</a> |
| 28  | <a href="#">6J8459861098</a><br>Ring, deflector                           | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">9020108M93</a><br>Washer, plate (6g5)         | <a href="#">Buy now</a> |
| 2   | <a href="#">6J81153700</a><br>Gear, driven                | <a href="#">Buy now</a> |
| 3   | <a href="#">6J81311700</a><br>Collar, distance            | <a href="#">Buy now</a> |
| 4   | <a href="#">9321013M04</a><br>93210-13m04                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6J81320001</a><br>Oil injection pump assembly | <a href="#">Buy now</a> |
| 6   | <a href="#">9321019MA7</a><br>O-ring(6r0)                 | <a href="#">Buy now</a> |
| 7   | <a href="#">9010905M32</a><br>Bolt                        | <a href="#">Buy now</a> |
| 8   | <a href="#">9010905M33</a><br>Bolt                        | <a href="#">Buy now</a> |
| 9   | <a href="#">9044507M08</a><br>Hose (l390)                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9044507M32</a><br>Hose (l200)                 | <a href="#">Buy now</a> |
| 12  | <a href="#">9046807M02</a><br>Clip (6e5)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">9046407M05</a><br>Clamp (6g5)                 | <a href="#">Buy now</a> |
| 14  | <a href="#">6E91318370</a><br>Valve check                 | <a href="#">Buy now</a> |
| 15  | <a href="#">9044507M04</a><br>Hose(62t)                   | <a href="#">Buy now</a> |
| 16  | <a href="#">9044511M08</a><br>Hose (l70)                  | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 18  | <a href="#">6J81315500</a><br>Lever, control        | <a href="#">Buy now</a> |
| 19  | <a href="#">9709506025</a><br>Bolt                  | <a href="#">Buy now</a> |
| 20  | <a href="#">9038706M60</a><br>Collar (6h3)          | <a href="#">Buy now</a> |
| 21  | <a href="#">6J84123800</a><br>Joint, link           | <a href="#">Buy now</a> |
| 22  | <a href="#">6J84123700</a><br>Joint, link           | <a href="#">Buy now</a> |
| 23  | <a href="#">9020205088</a><br>Washer, plate (666)   | <a href="#">Buy now</a> |
| 24  | <a href="#">9046805M03</a><br>Clip(6j8)             | <a href="#">Buy now</a> |
| 25  | <a href="#">6824123700</a><br>Joint, link 2         | <a href="#">Buy now</a> |
| 26  | <a href="#">9538005700</a><br>Nut (656)             | <a href="#">Buy now</a> |
| 27  | <a href="#">6J82170711</a><br>Oil tank comp.        | <a href="#">Buy now</a> |
| 27  | <a href="#">6J82170701</a><br>Oil tank comp.        | <a href="#">Buy now</a> |
| 28  | <a href="#">6J82173M00</a><br>Seal 3                | <a href="#">Buy now</a> |
| 29  | <a href="#">6H42177000</a><br>Oil tank cap assembly | <a href="#">Buy now</a> |
| 30  | <a href="#">6H12175700</a><br>Washer, special 1     | <a href="#">Buy now</a> |
| 31  | <a href="#">6H12463300</a><br>Chain, Ball           | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 32  | <a href="#">6J82175800</a><br>Washer, special 2      | <a href="#">Buy now</a> |
| 33  | <a href="#">6J81341100</a><br>Strainer, oil          | <a href="#">Buy now</a> |
| 34  | <a href="#">6J81341400</a><br>Gasket, strainer cover | <a href="#">Buy now</a> |
| 35  | <a href="#">6J81341600</a><br>Pipe, oil 1            | <a href="#">Buy now</a> |
| 36  | <a href="#">9046711M08</a><br>Clip(72x)              | <a href="#">Buy now</a> |
| 37  | <a href="#">9046708004</a><br>Clip, pipe 6162435600  | <a href="#">Buy now</a> |
| 38  | <a href="#">9044511M03</a><br>Hose (l360)            | <a href="#">Buy now</a> |
| 39  | <a href="#">9044610M01</a><br>Tube (6e5)             | <a href="#">Buy now</a> |
| 40  | <a href="#">9044511M07</a><br>Hose (l70)             | <a href="#">Buy now</a> |
| 41  | <a href="#">63D2174400</a><br>Breather               | <a href="#">Buy now</a> |
| 42  | <a href="#">9044511M02</a><br>Hose (l100)            | <a href="#">Buy now</a> |
| 43  | <a href="#">9044511M04</a><br>Hose (l600)            | <a href="#">Buy now</a> |
| 44  | <a href="#">6E52437800</a><br>Pipe, joint 3          | <a href="#">Buy now</a> |
| 45  | <a href="#">9046710M04</a><br>Clip, pipe 1 (6e9)     | <a href="#">Buy now</a> |
| 46  | <a href="#">6A08231700</a><br>Damper, ignition coil  | <a href="#">Buy now</a> |

# Oil Pump



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 47  | <a href="#">9038706119</a><br>Collar                   | <a href="#">Buy now</a> |
| 48  | <a href="#">9011906M65</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 49  | <a href="#">6J88572001</a><br>Oil level gauge assembly | <a href="#">Buy now</a> |


## Power Trim & Tilt Assy



**F6**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">65W43800024D</a><br>Power trim & tilt assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">65W4388000</a><br>Motor assembly (hitachi)     | <a href="#">Buy now</a> |
| 3   | <a href="#">65W4380400</a><br>Stator assembly              | <a href="#">Buy now</a> |
| 4   | <a href="#">65W4380500</a><br>Armature assembly            | <a href="#">Buy now</a> |
| 5   | <a href="#">65W4386900</a><br>O-ring                       | <a href="#">Buy now</a> |
| 6   | <a href="#">65W4388100</a><br>Frame, End                   | <a href="#">Buy now</a> |
| 7   | <a href="#">65W4386K00</a><br>Spring, brush                | <a href="#">Buy now</a> |
| 8   | <a href="#">65W4388200</a><br>Oil seal                     | <a href="#">Buy now</a> |
| 9   | <a href="#">65W4389200</a><br>Brush 2                      | <a href="#">Buy now</a> |
| 10  | <a href="#">65W4389100</a><br>Brush 1                      | <a href="#">Buy now</a> |
| 11  | <a href="#">65W4380F00</a><br>Plate, brush holder          | <a href="#">Buy now</a> |
| 12  | <a href="#">65W4387900</a><br>Screw, with washer           | <a href="#">Buy now</a> |
| 13  | <a href="#">65W4388700</a><br>Bolt, screw                  | <a href="#">Buy now</a> |
| 14  | <a href="#">65W4388E00</a><br>Bolt                         | <a href="#">Buy now</a> |
| 15  | <a href="#">65W4384000</a><br>Power tilt assembly          | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy



**F6**

| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 16  | <a href="#">65W4380K00</a><br>Cylinder, tilt sub assembly       | <a href="#">Buy now</a> |
| 17  | <a href="#">65W4381000</a><br>Tilt piston sub assembly          | <a href="#">Buy now</a> |
| 18  | <a href="#">65W4381200</a><br>Seal, dust                        | <a href="#">Buy now</a> |
| 19  | <a href="#">65W4386500</a><br>O-ring                            | <a href="#">Buy now</a> |
| 20  | <a href="#">6H14386110</a><br>O-ring                            | <a href="#">Buy now</a> |
| 21  | <a href="#">65W4387100</a><br>Ring, back up                     | <a href="#">Buy now</a> |
| 22  | <a href="#">65W4381B00</a><br>Free piston sub assembly          | <a href="#">Buy now</a> |
| 24  | <a href="#">9321011368</a><br>O-ring (2h7)                      | <a href="#">Buy now</a> |
| 25  | <a href="#">6H14381600</a><br>Filter 1                          | <a href="#">Buy now</a> |
| 26  | <a href="#">93210064A5</a><br>O-ring(61a)                       | <a href="#">Buy now</a> |
| 27  | <a href="#">65W4380L00</a><br>Housing, trim & tilt sub assembly | <a href="#">Buy now</a> |
| 28  | <a href="#">65W4388800</a><br>Bolt, hexagon socket head(1jk)    | <a href="#">Buy now</a> |
| 29  | <a href="#">9321050768</a><br>O-ring                            | <a href="#">Buy now</a> |
| 30  | <a href="#">6T44380203</a><br>Valve sub assembly                | <a href="#">Buy now</a> |
| 31  | <a href="#">6H14386600</a><br>O-ring                            | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy



**F6**

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 32  | <a href="#">9321010M74</a><br>O-ring                | <a href="#">Buy now</a> |
| 33  | <a href="#">6H14386700</a><br>O-ring                | <a href="#">Buy now</a> |
| 34  | <a href="#">62X4384100</a><br>Piston, shuttle       | <a href="#">Buy now</a> |
| 35  | <a href="#">9321009165</a><br>O-ring                | <a href="#">Buy now</a> |
| 36  | <a href="#">65W4383100</a><br>Connector, shaft      | <a href="#">Buy now</a> |
| 37  | <a href="#">65W4383000</a><br>Gear pump assembly    | <a href="#">Buy now</a> |
| 38  | <a href="#">6T44385300</a><br>Spring, main valve    | <a href="#">Buy now</a> |
| 39  | <a href="#">9131804025</a><br>Bolt(62x)             | <a href="#">Buy now</a> |
| 40  | <a href="#">65W4381700</a><br>Filter 2              | <a href="#">Buy now</a> |
| 41  | <a href="#">65W4386100</a><br>O-ring                | <a href="#">Buy now</a> |
| 42  | <a href="#">65W4386200</a><br>O-ring                | <a href="#">Buy now</a> |
| 43  | <a href="#">6H14387500</a><br>Ring, snap            | <a href="#">Buy now</a> |
| 44  | <a href="#">6H14384500</a><br>Screw, manual release | <a href="#">Buy now</a> |
| 45  | <a href="#">9321018397</a><br>O-ring (6g5)          | <a href="#">Buy now</a> |
| 46  | <a href="#">6H14384700</a><br>Seat, manual valve    | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy




65W7100-F251

**F6**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 47  | <a href="#">65W4385400</a><br>Spring, manual release | <a href="#">Buy now</a> |
| 48  | <a href="#">65W4382A00</a><br>Adaptor 1              | <a href="#">Buy now</a> |
| 49  | <a href="#">65W4384400</a><br>Pin, valve support     | <a href="#">Buy now</a> |
| 50  | <a href="#">65W4385100</a><br>Seat, relief valve     | <a href="#">Buy now</a> |
| 51  | <a href="#">9321008006</a><br>O-ring                 | <a href="#">Buy now</a> |
| 52  | <a href="#">9321003478</a><br>O-ring(31m)            | <a href="#">Buy now</a> |
| 53  | <a href="#">65W4385500</a><br>Spring, up relief      | <a href="#">Buy now</a> |
| 54  | <a href="#">9321011073</a><br>O-ring (p95)           | <a href="#">Buy now</a> |
| 55  | <a href="#">65W4384300</a><br>Screw, valve lock      | <a href="#">Buy now</a> |
| 56  | <a href="#">6H14385610</a><br>Spring, down relief    | <a href="#">Buy now</a> |
| 57  | <a href="#">6H14384410</a><br>Pin, valve support     | <a href="#">Buy now</a> |
| 58  | <a href="#">6H14384F10</a><br>Seal, main valve       | <a href="#">Buy now</a> |
| 59  | <a href="#">65W4386A00</a><br>Pin, absorber valve    | <a href="#">Buy now</a> |
| 60  | <a href="#">9350108001</a><br>Ball                   | <a href="#">Buy now</a> |
| 61  | <a href="#">65W4385300</a><br>Spring, absorber valve | <a href="#">Buy now</a> |



## Power Trim & Tilt Assy





**F6**

| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 62  | <a href="#">6H14382900</a><br>Plug, reservoir    | <a href="#">Buy now</a> |
| 63  | <a href="#">62X4387800</a><br>Bolt, socket       | <a href="#">Buy now</a> |
| 65  | <a href="#">6T44380800</a><br>Seat valve comp. 1 | <a href="#">Buy now</a> |

## Remo Con Attachment





6J86100-9200





**E3**

| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J848501034D</a><br>Remocon attachment assembly<br>AP | <a href="#">Buy now</a> |
| 1   | <a href="#">6J84850111</a><br>Attachment kit<br>AP                | <a href="#">Buy now</a> |
| 2   | <a href="#">9299008100</a><br>Ybs67-8 washer, spring              | <a href="#">Buy now</a> |
| 3   | <a href="#">6J84853400</a><br>Throttle lever, control             | <a href="#">Buy now</a> |
| 4   | <a href="#">6J84854401</a><br>Lever, shiftcontrol                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6J84417700</a><br>Washer                              | <a href="#">Buy now</a> |
| 6   | <a href="#">9025403M03</a><br>Pin, spring                         | <a href="#">Buy now</a> |
| 7   | <a href="#">6J84417302</a><br>Lever, shift control                | <a href="#">Buy now</a> |
| 8   | <a href="#">6J84216901</a><br>Joint                               | <a href="#">Buy now</a> |
| 9   | <a href="#">6J84853100</a><br>Bracket, remote control             | <a href="#">Buy now</a> |
| 10  | <a href="#">6J84853200</a><br>Bracket, remote control 2           | <a href="#">Buy now</a> |
| 11  | <a href="#">6824853850</a><br>Clamp, cable                        | <a href="#">Buy now</a> |
| 12  | <a href="#">9169030012</a><br>Pin, spring                         | <a href="#">Buy now</a> |
| 13  | <a href="#">9010906M29</a><br>Bolt(6j8)                           | <a href="#">Buy now</a> |
| 14  | <a href="#">9017906M24</a><br>Nut(6j8)                            | <a href="#">Buy now</a> |

## Remo Con Attachment




6J86100-9200



**E3**

| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 15  | <a href="#">6G82636300</a><br>End, wire 1                         | <a href="#">Buy now</a> |
| 16  | <a href="#">6G82636400</a><br>End, wire 2                         | <a href="#">Buy now</a> |
| 17  | <a href="#">6J84272351</a><br>Cover, bottom (dbn:gray)            | <a href="#">Buy now</a> |
| 18  | <a href="#">6J84284600</a><br>Screw                               | <a href="#">Buy now</a> |
| 19  | <a href="#">6J84272410</a><br>Grommet                             | <a href="#">Buy now</a> |
| 20  | <a href="#">6J848511014D</a><br>Hook, steering<br>AP              | <a href="#">Buy now</a> |
| 21  | <a href="#">6G84851100</a><br>Hook, steering<br>AP ROPE TYPE      | <a href="#">Buy now</a> |
| 22  | <a href="#">9709506016</a><br>Bolt, hexagon deep recess<br>AP     | <a href="#">Buy now</a> |
| 23  | <a href="#">9299506600</a><br>Washer, plain (646)<br>AP           | <a href="#">Buy now</a> |
| 24  | <a href="#">6G84851110</a><br>Hook, steering<br>AP BALL POST TYPE | <a href="#">Buy now</a> |


# Remote Control Assy



**B7**

| Ref | Part                                                                                 |                         |
|-----|--------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">7034823015</a><br>Remote control assembly (7p)<br>AP WITHOUT PT/T SW.    | <a href="#">Buy now</a> |
| 1   | <a href="#">7034825017</a><br>Remote control assembly (10p, ptt)<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">7034826111</a><br>Arm, throttle                                          | <a href="#">Buy now</a> |
| 3   | <a href="#">7034815300</a><br>Shaft, free accel.                                     | <a href="#">Buy now</a> |
| 4   | <a href="#">7034823500</a><br>Bushing                                                | <a href="#">Buy now</a> |
| 5   | <a href="#">7034826800</a><br>Spacer 3                                               | <a href="#">Buy now</a> |
| 6   | <a href="#">7034826400</a><br>Throttle, friction                                     | <a href="#">Buy now</a> |
| 7   | <a href="#">9538005600</a><br>Nut, hexagon (663)                                     | <a href="#">Buy now</a> |
| 8   | <a href="#">9738005025</a><br>Bolt                                                   | <a href="#">Buy now</a> |
| 9   | <a href="#">7034826500</a><br>Shaft Friction                                         | <a href="#">Buy now</a> |
| 10  | <a href="#">9343006024</a><br>Circlip (701)                                          | <a href="#">Buy now</a> |
| 11  | <a href="#">7034824500</a><br>Plate, lock                                            | <a href="#">Buy now</a> |
| 12  | <a href="#">7034825200</a><br>Roller, cam                                            | <a href="#">Buy now</a> |
| 13  | <a href="#">7014824800</a><br>Roller, free accel                                     | <a href="#">Buy now</a> |
| 14  | <a href="#">7034819800</a><br>Washer, wave 3                                         | <a href="#">Buy now</a> |


# Remote Control Assy



**B7**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 15  | <a href="#">7034824300</a><br>Bushing 3                     | <a href="#">Buy now</a> |
| 16  | <a href="#">7034823600</a><br>Bushing                       | <a href="#">Buy now</a> |
| 17  | <a href="#">7034818900</a><br>Retainer                      | <a href="#">Buy now</a> |
| 18  | <a href="#">7034823400</a><br>Roller, detent                | <a href="#">Buy now</a> |
| 19  | <a href="#">7034834501</a><br>Cable end, remote control 2   | <a href="#">Buy now</a> |
| 20  | <a href="#">7034835800</a><br>Anchor, cable                 | <a href="#">Buy now</a> |
| 21  | <a href="#">7034824400</a><br>Spring, free accel.           | <a href="#">Buy now</a> |
| 22  | <a href="#">7034823800</a><br>Spring, detent                | <a href="#">Buy now</a> |
| 23  | <a href="#">7034824600</a><br>Spacer 1                      | <a href="#">Buy now</a> |
| 24  | <a href="#">7034822700</a><br>Spring, neutral lock          | <a href="#">Buy now</a> |
| 25  | <a href="#">7038259400</a><br>Clamp<br>WITH PT/T SW.        | <a href="#">Buy now</a> |
| 26  | <a href="#">7034822600</a><br>Plate, stopper                | <a href="#">Buy now</a> |
| 27  | <a href="#">7034822200</a><br>Grip, control lever<br>SINGLE | <a href="#">Buy now</a> |
| 28  | <a href="#">7034822300</a><br>Lock, neutral                 | <a href="#">Buy now</a> |
| 29  | <a href="#">7034822500</a><br>Cover                         | <a href="#">Buy now</a> |


# Remote Control Assy



**B7**

| Ref | Part                                                                  |                         |
|-----|-----------------------------------------------------------------------|-------------------------|
| 30  | <a href="#">7034821900</a><br>Cover, lead                             | <a href="#">Buy now</a> |
| 31  | <a href="#">7034828100</a><br>Screw, flat head                        | <a href="#">Buy now</a> |
| 32  | <a href="#">7034828200</a><br>Screw                                   | <a href="#">Buy now</a> |
| 33  | <a href="#">9738008030</a><br>Bolt, hexagon (fj1)                     | <a href="#">Buy now</a> |
| 34  | <a href="#">9299008600</a><br>Washer, plain (663)                     | <a href="#">Buy now</a> |
| 35  | <a href="#">9858004010</a><br>Screw, pan head (e56)                   | <a href="#">Buy now</a> |
| 36  | <a href="#">9858004006</a><br>Screw, pan head (7h3)                   | <a href="#">Buy now</a> |
| 37  | <a href="#">9858005010</a><br>Screw, pan head(62x)                    | <a href="#">Buy now</a> |
| 38  | <a href="#">9858003015</a><br>Screw, pan head (n151)                  | <a href="#">Buy now</a> |
| 39  | <a href="#">7034829110</a><br>Screw                                   | <a href="#">Buy now</a> |
| 40  | <a href="#">9538006600</a><br>Nut(661)                                | <a href="#">Buy now</a> |
| 41  | <a href="#">7034829310</a><br>Spacer, remote control<br><b>SINGLE</b> | <a href="#">Buy now</a> |
| 42  | <a href="#">7014828700</a><br>Washer 1                                | <a href="#">Buy now</a> |
| 43  | <a href="#">7034821500</a><br>Graphic                                 | <a href="#">Buy now</a> |
| 44  | <a href="#">7038251033</a><br>Main switch assembly                    | <a href="#">Buy now</a> |


# Remote Control Assy



**B7**

| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 44  | <a href="#">7038251043</a><br>Main switch assembly                         | <a href="#">Buy now</a> |
| 45  | <a href="#">7038257700</a><br>Cap, key                                     | <a href="#">Buy now</a> |
| 46  | <a href="#">7038253100</a><br>Wire, lead                                   | <a href="#">Buy now</a> |
| 47  | <a href="#">6888257501</a><br>Engine stop switch assembly                  | <a href="#">Buy now</a> |
| 48  | <a href="#">6828255600</a><br>Lanyard, stop switch                         | <a href="#">Buy now</a> |
| 49  | <a href="#">6888258621</a><br>Extension, wire harness<br>(7P)              | <a href="#">Buy now</a> |
| 49  | <a href="#">6888258A20</a><br>10p main harness mec 2m (6ft)<br>(10P)       | <a href="#">Buy now</a> |
| 50  | <a href="#">7038254000</a><br>Neutral switch assembly                      | <a href="#">Buy now</a> |
| 51  | <a href="#">7038338302</a><br>Buzzer                                       | <a href="#">Buy now</a> |
| 52  | <a href="#">7034828400</a><br>Grommet                                      | <a href="#">Buy now</a> |
| 53  | <a href="#">7038259100</a><br>Band                                         | <a href="#">Buy now</a> |
| 54  | <a href="#">7038259200</a><br>Band                                         | <a href="#">Buy now</a> |
| 55  | <a href="#">7034822400</a><br>Cover, control lever<br>WITHOUT PT/T SW.     | <a href="#">Buy now</a> |
| 55  | <a href="#">7038256302</a><br>Trim & tilt switch assembly<br>WITH PT/T SW. | <a href="#">Buy now</a> |
| 56  | <a href="#">7034822100</a><br>Grip                                         | <a href="#">Buy now</a> |



## Remote Control Assy



**B7**

| Ref | Part                                           |                         |
|-----|------------------------------------------------|-------------------------|
| 57  | <a href="#">7034815200</a><br>Knob, free accel | <a href="#">Buy now</a> |
| 58  | <a href="#">7034821200</a><br>Rear housing     | <a href="#">Buy now</a> |
| 59  | <a href="#">7034821300</a><br>Back, panel      | <a href="#">Buy now</a> |
| 60  | <a href="#">7034827100</a><br>Arm, shift       | <a href="#">Buy now</a> |
| 61  | <a href="#">7034821101</a><br>Housing,1        | <a href="#">Buy now</a> |
| 62  | <a href="#">7034823200</a><br>Drive gear       | <a href="#">Buy now</a> |

# Remote Control Box




  
67M0100-8280

**B6**


| Ref | Part                                                                                 |                         |
|-----|--------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">7034823015</a><br>Remote control assembly (7p)<br>AP WITHOUT PT/T SW.    | <a href="#">Buy now</a> |
| 1   | <a href="#">7034825017</a><br>Remote control assembly (10p, ptt)<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">7014831080</a><br>Cable, Remote Control L=10F<br>UR                      | <a href="#">Buy now</a> |
| 2   | <a href="#">7014831090</a><br>Cable, Remote Control L=11F<br>UR                      | <a href="#">Buy now</a> |
| 2   | <a href="#">7014832000</a><br>Cable, Remote Control L=12F<br>UR                      | <a href="#">Buy now</a> |

# Repair Kit 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J8W000103</a><br>Powerhead gasket kit        | <a href="#">Buy now</a> |
| 2   | <a href="#">9310125M28</a><br>Oil seal(6j8)               | <a href="#">Buy now</a> |
| 3   | <a href="#">9310416M04</a><br>Oil seal(6a8)               | <a href="#">Buy now</a> |
| 4   | <a href="#">9321056M80</a><br>O-ring(6j8)                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6J811181A1</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 6   | <a href="#">6J811193A1</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 7   | <a href="#">6J812414A0</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 8   | <a href="#">6J841114A0</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |
| 9   | <a href="#">9310226M27</a><br>Oil seal(6j8)               | <a href="#">Buy now</a> |
| 10  | <a href="#">6J81362100</a><br>Gasket, valve seat          | <a href="#">Buy now</a> |
| 11  | <a href="#">6J81498400</a><br>Gasket, float chamber       | <a href="#">Buy now</a> |
| 12  | <a href="#">6J81419800</a><br>Gasket                      | <a href="#">Buy now</a> |
| 13  | <a href="#">9321032738</a><br>O-ring(1wg)                 | <a href="#">Buy now</a> |
| 14  | <a href="#">6J845113A0</a><br>Gasket, upper casing        | <a href="#">Buy now</a> |
| 15  | <a href="#">9321042159</a><br>O-ring (647)                | <a href="#">Buy now</a> |

# Repair Kit 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 16  | <a href="#">6J8W009300</a><br>Carburetor rerair kit | <a href="#">Buy now</a> |
| 19  | <a href="#">6J81499500</a><br>Gasket, drin screw    | <a href="#">Buy now</a> |
| 20  | <a href="#">6J81498500</a><br>Float                 | <a href="#">Buy now</a> |
| 21  | <a href="#">6J81454600</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 22  | <a href="#">6J81415900</a><br>Clip                  | <a href="#">Buy now</a> |
| 23  | <a href="#">6J81454800</a><br>Pin, float arm        | <a href="#">Buy now</a> |
| 24  | <a href="#">6J81496600</a><br>Plug                  | <a href="#">Buy now</a> |
| 25  | <a href="#">6J81412600</a><br>Plug                  | <a href="#">Buy now</a> |
| 26  | <a href="#">6J81411800</a><br>Plug                  | <a href="#">Buy now</a> |
| 27  | <a href="#">9798004112</a><br>Screw, pan head (686) | <a href="#">Buy now</a> |

## Repair Kit 2



| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J8W0001C2</a><br>Gasket kit                   | <a href="#">Buy now</a> |
| 2   | <a href="#">6J845114A1</a><br>Gasket, upper casing         | <a href="#">Buy now</a> |
| 3   | <a href="#">9043008020</a><br>Gasket                       | <a href="#">Buy now</a> |
| 4   | <a href="#">66344315A0</a><br>Gasket,water pump 1          | <a href="#">Buy now</a> |
| 5   | <a href="#">9310123070</a><br>Oil seal (663)               | <a href="#">Buy now</a> |
| 6   | <a href="#">9321041042</a><br>O-ring (132)                 | <a href="#">Buy now</a> |
| 7   | <a href="#">66344316A0</a><br>Gasket,water pump 2          | <a href="#">Buy now</a> |
| 8   | <a href="#">66344324A0</a><br>Gasket,cartridge outer plate | <a href="#">Buy now</a> |
| 9   | <a href="#">9321060MA3</a><br>O-ring(6j8)                  | <a href="#">Buy now</a> |
| 10  | <a href="#">9310120M07</a><br>Oil seal                     | <a href="#">Buy now</a> |
| 11  | <a href="#">6J8W0078A2</a><br>Water pump repair kit        | <a href="#">Buy now</a> |
| 12  | <a href="#">6634432200</a><br>Insert, cartridge            | <a href="#">Buy now</a> |
| 13  | <a href="#">6H44435202</a><br>Impeller                     | <a href="#">Buy now</a> |
| 15  | <a href="#">6634432300</a><br>Outer plate, cartridge       | <a href="#">Buy now</a> |
| 18  | <a href="#">9011908M13</a><br>Bolt, with washer(6h0)       | <a href="#">Buy now</a> |


## Repair Kit 2



**C4**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 19  | <a href="#">9011908M34</a><br>Bolt, with washer(6j8) | <a href="#">Buy now</a> |
| 20  | <a href="#">6H4W00780A</a><br>Chrome pump kit        | <a href="#">Buy now</a> |
| 21  | <a href="#">6704432201</a><br>Insert, cartridge      | <a href="#">Buy now</a> |
| 22  | <a href="#">6704432100</a><br>Inner plate, cartridge | <a href="#">Buy now</a> |
| 23  | <a href="#">6704432300</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |

# Starter



6J8A300-C080


\*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.95M

\*1: A PRELEVER SUR BOBINE 50M, REFERENCE 90890-44373, LONGUEUR DE COUPE 1.95M

**C1**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J815710024D</a><br>Starter assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">6J8157110094</a><br>Case, starter           | <a href="#">Buy now</a> |
| 3   | <a href="#">9169040014</a><br>Pin, spring (6f2)         | <a href="#">Buy now</a> |
| 4   | <a href="#">6J8157580194</a><br>Guide, Rope             | <a href="#">Buy now</a> |
| 5   | <a href="#">9709506016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 6   | <a href="#">9299506600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 7   | <a href="#">6J81576200</a><br>Seal, rubber 2            | <a href="#">Buy now</a> |
| 8   | <a href="#">6A01578900</a><br>Damper                    | <a href="#">Buy now</a> |
| 9   | <a href="#">6F51575200</a><br>Roller, wire              | <a href="#">Buy now</a> |
| 10  | <a href="#">6F51575300</a><br>Bushing 1                 | <a href="#">Buy now</a> |
| 11  | <a href="#">9709506025</a><br>Bolt                      | <a href="#">Buy now</a> |
| 12  | <a href="#">9538006600</a><br>Nut(661)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6J81578700</a><br>Adaptor                   | <a href="#">Buy now</a> |
| 14  | <a href="#">6891575501</a><br>Handle, starter           | <a href="#">Buy now</a> |
| 15  | <a href="#">6F51577902</a><br>Cover                     | <a href="#">Buy now</a> |

# Starter



6J8A300-C080


\*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.95M

\*1: A PRELEVER SUR BOBINE 50M, REFERENCE 90890-44373, LONGUEUR DE COUPE 1.95M

**C1**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">*<br/>item_description<br/>*1</a>           | <a href="#">Buy now</a> |
| 17  | <a href="#">6J81571400</a><br>Drum, sheave              | <a href="#">Buy now</a> |
| 18  | <a href="#">9051008M04</a><br>Spring, spiral (677)      | <a href="#">Buy now</a> |
| 19  | <a href="#">6771571701</a><br>Shaft                     | <a href="#">Buy now</a> |
| 20  | <a href="#">9020106060</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 22  | <a href="#">9538006700</a><br>Nut                       | <a href="#">Buy now</a> |
| 23  | <a href="#">6761574103</a><br>Pawl, drive               | <a href="#">Buy now</a> |
| 24  | <a href="#">9343006M02</a><br>Circlip (689)             | <a href="#">Buy now</a> |
| 25  | <a href="#">6J81570500</a><br>Spring, drive pawl        | <a href="#">Buy now</a> |
| 26  | <a href="#">9709506035</a><br>Bolt(j52)                 | <a href="#">Buy now</a> |
| 30  | <a href="#">9953010014</a><br>Pin, dowel                | <a href="#">Buy now</a> |
| 31  | <a href="#">6561574800</a><br>Plunger, starter stop     | <a href="#">Buy now</a> |
| 32  | <a href="#">9050110227</a><br>Spring, comprreshion(656) | <a href="#">Buy now</a> |
| 33  | <a href="#">6J81577000</a><br>Cable comp., starter stop | <a href="#">Buy now</a> |
| 34  | <a href="#">6J81574601</a><br>Arm                       | <a href="#">Buy now</a> |

Starter



| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 35  | <a href="#">9038706M29</a><br>Coller (6a0)        | <a href="#">Buy now</a> |
| 38  | <a href="#">6J81574700</a><br>Link                | <a href="#">Buy now</a> |
| 39  | <a href="#">6J81577401</a><br>Stay 4              | <a href="#">Buy now</a> |
| 40  | <a href="#">6J8157710094</a><br>Stay 1            | <a href="#">Buy now</a> |
| 41  | <a href="#">6J8157720094</a><br>Stay 2            | <a href="#">Buy now</a> |
| 42  | <a href="#">9701306020</a><br>Bolt(62y)           | <a href="#">Buy now</a> |
| 43  | <a href="#">9290306600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 44  | <a href="#">9010106024</a><br>Bolt                | <a href="#">Buy now</a> |
| 47  | <a href="#">6614126202</a><br>Joint, choke lever  | <a href="#">Buy now</a> |
| 48  | <a href="#">6J81572300</a><br>Pulley, starter     | <a href="#">Buy now</a> |
| 49  | <a href="#">9701308014</a><br>Bolt(692)           | <a href="#">Buy now</a> |
| 50  | <a href="#">9290308600</a><br>Washer, plain (663) | <a href="#">Buy now</a> |
| 51  | <a href="#">6J81343791</a><br>Mark, caution       | <a href="#">Buy now</a> |


# Starting Motor



**D1**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6F58180011</a><br>Starting motor assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6898185711</a><br>Pinion stopper set      | <a href="#">Buy now</a> |
| 3   | <a href="#">6898180712</a><br>Pinion assembly         | <a href="#">Buy now</a> |
| 4   | <a href="#">6F58183011</a><br>Front cover assembly    | <a href="#">Buy now</a> |
| 5   | <a href="#">6898183100</a><br>Metal, front            | <a href="#">Buy now</a> |
| 6   | <a href="#">6898184711</a><br>O-ring                  | <a href="#">Buy now</a> |
| 7   | <a href="#">6898180911</a><br>Washer kit              | <a href="#">Buy now</a> |
| 8   | <a href="#">6898185012</a><br>Armature assembly       | <a href="#">Buy now</a> |
| 9   | <a href="#">6898181011</a><br>Stator ass'y            | <a href="#">Buy now</a> |
| 10  | <a href="#">6898184011</a><br>Brush holder assembly   | <a href="#">Buy now</a> |
| 11  | <a href="#">6898181111</a><br>Brush 1                 | <a href="#">Buy now</a> |
| 12  | <a href="#">6898181211</a><br>Brush 2                 | <a href="#">Buy now</a> |
| 13  | <a href="#">6898181310</a><br>Spring, brush           | <a href="#">Buy now</a> |
| 14  | <a href="#">6898182011</a><br>Rear cover ass'y        | <a href="#">Buy now</a> |
| 15  | <a href="#">6898182610</a><br>Bolt                    | <a href="#">Buy now</a> |


## Starting Motor



**D1**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">9701308016</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 17  | <a href="#">9290308600</a><br>Washer, plain (663)       | <a href="#">Buy now</a> |
| 18  | <a href="#">9701308030</a><br>Bolt                      | <a href="#">Buy now</a> |
| 19  | <a href="#">9290308100</a><br>Ybs67-8 washer, spring    | <a href="#">Buy now</a> |
| 21  | <a href="#">6j8818220194</a><br>Bracket, starting motor | <a href="#">Buy now</a> |
| 22  | <a href="#">9046403M15</a><br>Clamp(6j8)                | <a href="#">Buy now</a> |
| 23  | <a href="#">9701308035</a><br>Bolt                      | <a href="#">Buy now</a> |
| 25  | <a href="#">9701308055</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 27  | <a href="#">6j88133710</a><br>Cover, flywheel           | <a href="#">Buy now</a> |
| 28  | <a href="#">9048014M17</a><br>Grommet(6j8)              | <a href="#">Buy now</a> |
| 29  | <a href="#">9048010M16</a><br>Grommet(6j8)              | <a href="#">Buy now</a> |
| 30  | <a href="#">9169050022</a><br>Pin, spring (676)         | <a href="#">Buy now</a> |
| 31  | <a href="#">6j88133800</a><br>Clamp, lead               | <a href="#">Buy now</a> |
| 32  | <a href="#">6j815723E1</a><br>Pulley, starter           | <a href="#">Buy now</a> |
| 33  | <a href="#">6j881365A0</a><br>Gasket, hole cover        | <a href="#">Buy now</a> |


# Starting Motor



**D1**


| Ref | Part                                        |                         |
|-----|---------------------------------------------|-------------------------|
| 34  | <a href="#">9701308014</a><br>Bolt(692)     | <a href="#">Buy now</a> |
| 36  | <a href="#">6J81343781</a><br>Mark, caution | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J8W0084114D</a><br>Handle steering assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6G142111124D</a><br>Handle, steering         | <a href="#">Buy now</a> |
| 3   | <a href="#">6E04419111</a><br>Indicator, shift           | <a href="#">Buy now</a> |
| 4   | <a href="#">9020636M21</a><br>Washer, wave(63v)          | <a href="#">Buy now</a> |
| 5   | <a href="#">9020236M55</a><br>Washer, plate(63v)         | <a href="#">Buy now</a> |
| 6   | <a href="#">9038633M96</a><br>Bush(63v)                  | <a href="#">Buy now</a> |
| 7   | <a href="#">9038634M97</a><br>Bush(63v)                  | <a href="#">Buy now</a> |
| 8   | <a href="#">6G14213102</a><br>Cover, handle steering     | <a href="#">Buy now</a> |
| 9   | <a href="#">9011608016</a><br>Bolt, stud                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9018508057</a><br>Nut, nylon (6j8)           | <a href="#">Buy now</a> |
| 11  | <a href="#">6G14212501</a><br>Bolt, friction adjusting   | <a href="#">Buy now</a> |
| 12  | <a href="#">6G14212600</a><br>Piece, friction            | <a href="#">Buy now</a> |
| 13  | <a href="#">9149016010</a><br>Pin, cotter                | <a href="#">Buy now</a> |
| 14  | <a href="#">6644211900</a><br>Grip, steering handle      | <a href="#">Buy now</a> |
| 15  | <a href="#">6F642177A0</a><br>Rubber, handle             | <a href="#">Buy now</a> |

# Steering



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">6J84213700</a><br>Indicator, throttle     | <a href="#">Buy now</a> |
| 17  | <a href="#">9026902M09</a><br>Rivet(6I5)              | <a href="#">Buy now</a> |
| 18  | <a href="#">9050123215</a><br>Spring (655)            | <a href="#">Buy now</a> |
| 19  | <a href="#">9020110M02</a><br>Washer, plate(6g9)      | <a href="#">Buy now</a> |
| 20  | <a href="#">9014905M13</a><br>Screw, countersunk      | <a href="#">Buy now</a> |
| 21  | <a href="#">9038608032</a><br>Bushing (650)           | <a href="#">Buy now</a> |
| 22  | <a href="#">6G14213801</a><br>Lever, throttle         | <a href="#">Buy now</a> |
| 23  | <a href="#">6E04215902</a><br>Stay                    | <a href="#">Buy now</a> |
| 24  | <a href="#">9788505012</a><br>Screw,pan head (646)    | <a href="#">Buy now</a> |
| 25  | <a href="#">6J82630100</a><br>Throttle cable assembly | <a href="#">Buy now</a> |
| 26  | <a href="#">6J844111014D</a><br>Handle, gear shift    | <a href="#">Buy now</a> |
| 27  | <a href="#">6J84412500</a><br>Lever, shift rod        | <a href="#">Buy now</a> |
| 28  | <a href="#">6824413200</a><br>Bushing                 | <a href="#">Buy now</a> |
| 29  | <a href="#">9025403M04</a><br>Pin, spring (6h3)       | <a href="#">Buy now</a> |
| 30  | <a href="#">9038606M12</a><br>Bushing (688)           | <a href="#">Buy now</a> |

# Steering




  
6J8L300-F150

**D5**

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 31  | <a href="#">6J84412400</a><br>Link, shift rod       | <a href="#">Buy now</a> |
| 32  | <a href="#">9299006200</a><br>Ybs66-6 washer, plain | <a href="#">Buy now</a> |
| 33  | <a href="#">9149020012</a><br>Pin, cotter (648)     | <a href="#">Buy now</a> |
| 34  | <a href="#">6E08362741</a><br>Label, caution 7      | <a href="#">Buy now</a> |
| 35  | <a href="#">6E08362751</a><br>-                     | <a href="#">Buy now</a> |

# Steering Guide




6J83100-2290

**B5**


| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6896135002</a><br>Steering guide attachment kit<br>AP | <a href="#">Buy now</a> |
| 2   | <a href="#">6896135101</a><br>Rod, steering                       | <a href="#">Buy now</a> |
| 3   | <a href="#">9020110M20</a><br>Washer, plate (663)                 | <a href="#">Buy now</a> |
| 4   | <a href="#">9018509M01</a><br>Nut, nylon (663)                    | <a href="#">Buy now</a> |
| 5   | <a href="#">9017009M03</a><br>Nut (689)                           | <a href="#">Buy now</a> |
| 6   | <a href="#">9038710M42</a><br>Collar (688)                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6E56135500</a><br>Bolt                                | <a href="#">Buy now</a> |
| 8   | <a href="#">9020110M63</a><br>Washer, plate                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6E54314501</a><br>Cap, clamp bracket                  | <a href="#">Buy now</a> |
| 10  | <a href="#">9321016275</a><br>O-ring                              | <a href="#">Buy now</a> |

## Top Cowling



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J842610B04D</a><br>Top cowling assembly | <a href="#">Buy now</a> |
| 1   | <a href="#">6J842610D04D</a><br>Top Cowling assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6J84261500</a><br>Seal                   | <a href="#">Buy now</a> |
| 3   | <a href="#">6J84265103</a><br>Hook                   | <a href="#">Buy now</a> |
| 4   | <a href="#">6J84265200</a><br>Hook                   | <a href="#">Buy now</a> |
| 5   | <a href="#">9026604M00</a><br>Rivet 2 (662)          | <a href="#">Buy now</a> |
| 6   | <a href="#">6J842613004D</a><br>Molding, air duct    | <a href="#">Buy now</a> |
| 6   | <a href="#">6J842613104D</a><br>Molding, air duct    | <a href="#">Buy now</a> |
| 7   | <a href="#">9017906M24</a><br>Nut(6j8)               | <a href="#">Buy now</a> |
| 8   | <a href="#">6J84267740</a><br>Graphic, rear          | <a href="#">Buy now</a> |
| 9   | <a href="#">6J84267810</a><br>Graphic, rear          | <a href="#">Buy now</a> |
| 10  | <a href="#">6J8W007014</a><br>Graphic set            | <a href="#">Buy now</a> |
| 11  | <a href="#">6J84268111</a><br>Mark, cowling          | <a href="#">Buy now</a> |
| 12  | <a href="#">6J84268212</a><br>Mark, cowling          | <a href="#">Buy now</a> |
| 13  | <a href="#">6J81343640</a><br>Mark                   | <a href="#">Buy now</a> |

## Top Cowling




6J83300-2010

**A4**

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 14  | <a href="#">6J82177H00</a><br>Disk cap 2          | <a href="#">Buy now</a> |
| 15  | <a href="#">9016103M01</a><br>Screw, tapping(6j8) | <a href="#">Buy now</a> |
| 16  | <a href="#">6J82173200</a><br>Seal 1              | <a href="#">Buy now</a> |
| 17  | <a href="#">6J82173500</a><br>Seal 2              | <a href="#">Buy now</a> |

## Upper Casing



  
6J80100-9250

**A5**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6J845111014D</a><br>Casing, upper<br>S(16.7") | <a href="#">Buy now</a> |
| 1   | <a href="#">6J845111114D</a><br>Casing, upper<br>L(21.5") | <a href="#">Buy now</a> |
| 2   | <a href="#">9360612019</a><br>Pin, dowel (614)            | <a href="#">Buy now</a> |
| 3   | <a href="#">9011908M31</a><br>Bolt, with washer(6j8)      | <a href="#">Buy now</a> |
| 4   | <a href="#">6J8411370194</a><br>Guide, exhaust            | <a href="#">Buy now</a> |
| 5   | <a href="#">6J845114A1</a><br>Gasket, upper casing        | <a href="#">Buy now</a> |
| 6   | <a href="#">6J841131005B</a><br>Manifold, ext. 1          | <a href="#">Buy now</a> |
| 7   | <a href="#">6J81473700</a><br>Damper, muffler             | <a href="#">Buy now</a> |
| 8   | <a href="#">9033807M00</a><br>Plug(6j8)                   | <a href="#">Buy now</a> |
| 10  | <a href="#">9757508550</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 11  | <a href="#">9707508030</a><br>Bolt, hexagon (fj1)         | <a href="#">Buy now</a> |
| 12  | <a href="#">9299508600</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.