



Yamaha 3AMH 1989

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


| | |
|-----------------------------------------|----|
| Control | 3 |
| Cowling & Fuel | 6 |
| Cylinder & Crankcase | 8 |
| Electrical 1 | 11 |
| Generator | 12 |
| Intake | 14 |
| Lower Casing & Drive 1 | 18 |
| Repair Kit | 22 |
| Starter | 25 |
| Upper Casing & Bracket | 27 |

Control




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 2 | 9020635M1100 Washer, wave(6j8) | Buy now |
| 3 | 9020235M2400 Washer (6g1) | Buy now |
| 4 | 9038643M7900 Bush(6l5) | Buy now |
| 5 | 9038634M4000 Bushing (6g1) | Buy now |
| 6 | 6G1421310100 Cover, handle steering | Buy now |
| 7 | 970950601600 Bolt, hexagon deep recess | Buy now |
| 8 | 664421190000 Grip, steering handle | Buy now |
| 9 | 6G1421770000 Rubber, handle | Buy now |
| 10 | 6L5421370000 Indicator, throttle | Buy now |
| 11 | 902690200100 Rivet(6l5) | Buy now |
| 12 | 905012321500 Spring (655) | Buy now |
| 13 | 929901060000 Washer, plate | Buy now |
| 14 | 9014905M0600 Screw, countersunk | Buy now |
| 15 | 9020908M1700 Washer(6l5) | Buy now |
| 16 | 903860803200 Bushing (650) | Buy now |

Control




| Ref | Part | |
|-----|--------------------------------------------------------------|-------------------------|
| 17 | 6G1421380100 Lever, throttle | Buy now |
| 18 | 6E0421590200 Stay | Buy now |
| 19 | 985800501200 Screw,pan head (646) | Buy now |
| 20 | 6L5421250000 Bolt, friction adjusting | Buy now |
| 21 | 6G1421260000 Piece, friction | Buy now |
| 22 | 990800360000 Circlip(615) | Buy now |
| 23 | 6GEF63010000 Throttle cable assembly | Buy now |
| 24 | 6L5441110000 Handle, gear shift | Buy now |
| 25 | 932101232700 O-ring(3ld) | Buy now |
| 26 | 6L5441962000 Indicator 3 | Buy now |
| 27 | 6L5441972000 Indicator 4 | Buy now |
| 28 | 935051602400 Ball | Buy now |
| 29 | 905011227400 Spring 6554411600 | Buy now |
| 30 | 6L5441210000 Lever, shift rod | Buy now |
| 31 | 977804052000 Ybs83-420 screw,panh,tapping | Buy now |

Control




| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 32 | 929900460000 Washer, plain (646) | Buy now |
| 33 | 6L5441430000 Rod, shift | Buy now |
| 34 | 929900560000 Washer, plain (646) | Buy now |
| 35 | 914901601000 Pin, cotter | Buy now |
| 36 | 6E0441450000 Connector, shift rod 1 | Buy now |
| 37 | 6E0441460000 Connector, shift rod 2 | Buy now |
| 39 | 6L5441441000 Rod, shift | Buy now |
| 40 | 916092501400 Pin, Spring | Buy now |
| 42 | 6L5427352000 Protector | Buy now |
| 43 | 9016104M0200 Screw, tapping (676) | Buy now |
| 44 | 973950602000 Bolt(7u8) | Buy now |
| 45 | 929900660000 Washer, plain (646) | Buy now |

Cowling & Fuel




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 6 | 6L5427740000 Stay, apron 1 | Buy now |
| 7 | 985800501000 Screw, pan head(62x) | Buy now |
| 8 | 970950601600 Bolt, hexagon deep recess | Buy now |
| 9 | 929900660000 Washer, plain (646) | Buy now |
| 10 | 6L5426470000 Holder, clamp band | Buy now |
| 11 | 6L5428230000 Plate, stop | Buy now |
| 12 | 9016703M0200 Screw, tapping(615) | Buy now |
| 14 | 6L5245910000 Emblem, Fuel Cock | Buy now |
| 15 | 6L5241110000 Tank, fuel | Buy now |
| 16 | 6L5246102000 Cap assembly | Buy now |
| 17 | 6A0823170000 Damper, ignition coil | Buy now |
| 18 | 624425420000 Collar | Buy now |
| 19 | 9020106M0800 Washer, plate(6e3) | Buy now |
| 20 | 973130603000 Bolt | Buy now |
| 21 | 6L5246410000 Gasket, cap 1 | Buy now |

Cowling & Fuel




| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 22 | 6L5245006000 Fuel cock assembly 1 | Buy now |
| 23 | 9015906M1000 Screw, with washer(6l5) | Buy now |
| 24 | 6L5441962000 Indicator 3 | Buy now |
| 25 | 6L5441972000 Indicator 4 | Buy now |
| 26 | 6A4243120000 Pipe, fuel 2 | Buy now |
| 27 | 904670800400 Clip, pipe 6162435600 | Buy now |
| 28 | 6L5243120000 Pipe 2 | Buy now |
| 29 | 9046513M1100 Clamp (6e5) | Buy now |
| 30 | 656W28100100 Tool kit | Buy now |

Cylinder & Crankcase




| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 1 | 6L5W009000EJ Crank cylinder assembly | Buy now |
| 2 | 6L5151000094 Crankcase assembly | Buy now |
| 3 | 624144850000 Pipe, joint | Buy now |
| 4 | 6E5113720000 Nipple, hose | Buy now |
| 5 | 9044507M2900 Hose (I200) | Buy now |
| 6 | 904670601600 Clip (655) | Buy now |
| 7 | 936061201900 Pin, dowel (614) | Buy now |
| 8 | 9010506M1600 Bolt (6e0) | Buy now |
| 9 | 9010506M4000 Bolt, washer based(6l5) | Buy now |
| 10 | 6L5153960094 Housing, oil seal | Buy now |
| 11 | 9310120M2900 Oil seal(6j1) | Buy now |
| 12 | 9310109M4200 Oil seal(6l5) | Buy now |
| 13 | 6L515369A000 Gasket, oil seal housing | Buy now |
| 14 | 973950602000 Bolt(7u8) | Buy now |
| 15 | 929900660000 Washer, plain (646) | Buy now |

Cylinder & Crankcase




| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 16 | 6L5111110094 Head, cylinder 1 | Buy now |
| 17 | 6L5111810000 Gasket, cylinder head 1 | Buy now |
| 18 | 970800602000 Bolt(7u8) | Buy now |
| 20 | 6L511191009M Cover, cylinder head 1 | Buy now |
| 21 | 6L511193A100 Gasket, head cover | Buy now |
| 22 | 973130602000 Bolt(7u8) | Buy now |
| 24 | 970130605000 Bolt, hexagon | Buy now |
| 26 | 6E5124110100 Thermostat | Buy now |
| 27 | 6L512413001S Cover, thermostat | Buy now |
| 28 | 6L5124140000 Gasket, cover | Buy now |
| 31 | 6L5114000000 Crankshaft assembly | Buy now |
| 32 | 6L5114120000 Crank 1 | Buy now |
| 33 | 6L5114220000 Crank 2 | Buy now |
| 34 | 6L5116510000 Rod, connecting | Buy now |
| 35 | 6L5116810000 Pin, crank 1 | Buy now |

Cylinder & Crankcase




| Ref | Part | |
|-----|--------------------------------------------------------------|-------------------------|
| 36 | 93310416F700 Brg,needle | Buy now |
| 37 | 93306204U000 Bearing(6e0) | Buy now |
| 39 | 9020132M0000 Washer, plate(6l5) | Buy now |
| 40 | 9020132M0100 Washer, plate(6l5) | Buy now |
| 41 | 6L5116310096 Piston (std) | Buy now |
| 42 | 6L5116102000 Piston ring set (0.50mm o/s) | Buy now |
| 43 | 93310112U000 Bearing, cylindrical(6l5) | Buy now |
| 44 | 6L5116330000 Pin, piston | Buy now |
| 45 | 934501302200 Circlip 132116340000 | Buy now |
| 46 | 6L5451130000 Gasket, upper casing | Buy now |
| 47 | 947020027400 Plug, spark (br6hs-10) | Buy now |

Electrical 1




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 1 | 6G1823702000 Plug cap assembly | Buy now |
| 2 | 6L5823160000 Bracket, ignition coil | Buy now |
| 3 | 970950601600 Bolt, hexagon deep recess | Buy now |
| 4 | 929900660000 Washer, plain (646) | Buy now |
| 5 | 6L585570N000 Ignition coil assembly | Buy now |
| 6 | 925030601500 Screw, pan | Buy now |
| 8 | 6L585540M000 C.d.i. unit assembly | Buy now |
| 9 | 973130601600 Bolt, hexagon deep recess | Buy now |
| 11 | 904651814700 Clamp | Buy now |
| 12 | 6A0825500100 Stop switch assembly | Buy now |
| 13 | 973130601200 Bolt(gh1) | Buy now |

Generator




| Ref | Part | |
|-----|-------------------------------------------------------|-------------------------|
| 1 | 6L585550M000 Rotor assembly | Buy now |
| 2 | 6L585560M100 Base assembly | Buy now |
| 3 | 6E0855207000 Charge coil ass'y | Buy now |
| 4 | 6L585595M000 Coil, pulser | Buy now |
| 5 | 6L585592M000 Pulser coil assembly | Buy now |
| 6 | 6E0813367000 Grommet | Buy now |
| 7 | 6E0813287000 Clamp | Buy now |
| 8 | 985070501600 Screw, pan head(jj6) | Buy now |
| 9 | 976070521200 Screw,w/washer | Buy now |
| 10 | 985070401000 Screw, pan head(6g8) | Buy now |
| 12 | 6L5157710100 Stay 1 | Buy now |
| 13 | 9044610M0100 Tube (6e5) | Buy now |
| 14 | 985800500800 Screw, pan head (7g3) | Buy now |
| 15 | 9046510M3400 Clamp(6l5) | Buy now |
| 16 | 9010506M1400 Bolt (6e0) | Buy now |

Generator




| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 17 | 9028004M0600 Key, woodruff(6a1) | Buy now |
| 18 | 901701011300 Nut, crank shaft (650) | Buy now |
| 19 | 90201102G900 Washer, plate (26h) | Buy now |

Intake




| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 1 | 6L5136100000 Reed valve assembly | Buy now |
| 2 | 6L5W00040100 Reed set | Buy now |
| 3 | 6L5136210000 Gasket, valve seat | Buy now |
| 4 | 9010506M1400 Bolt (6e0) | Buy now |
| 6 | 679149230000 Screw, pilot | Buy now |
| 7 | 697145550000 Spring | Buy now |
| 8 | 6G1149660000 Cap | Buy now |
| 9 | 6G1145270000 Plate | Buy now |
| 10 | 6G1141260000 Packing | Buy now |
| 11 | 6L5149480300 Jet (#40) | Buy now |
| 12 | 676149660000 Rubber cap | Buy now |
| 13 | 985800401000 Screw, pan head (e56) | Buy now |
| 14 | 929030410000 Ybs67-4 washer, spring | Buy now |
| 15 | 905011032600 Spring coil(663)(carb) | Buy now |
| 16 | 663145230000 Screw, stop | Buy now |

Intake



| Ref | Part | |
|-----|-------------------------------------------------------|-------------------------|
| 17 | 6G1149840000 Gasket, float chamber | Buy now |
| 18 | 6G1149800100 Body, float chamber | Buy now |
| 19 | 6L5149470100 Jet, needle | Buy now |
| 20 | 676149431400 Jet, main (#68) | Buy now |
| 21 | 979800411400 Screw, pan head(ga5) | Buy now |
| 22 | 6G1143980000 Washer | Buy now |
| 23 | 6G1149920000 Screw, drain | Buy now |
| 24 | 6G1149850000 Float comp. | Buy now |
| 25 | 6G1145460100 Valve, needle | Buy now |
| 26 | 676141860000 Pin, valve | Buy now |
| 27 | 663141590000 Clip | Buy now |
| 28 | 985010400800 Screw, pan head (713) | Buy now |
| 29 | 688145480000 Pin, arm | Buy now |
| 30 | 989070300600 Screw, binding | Buy now |
| 31 | 901790347800 Nut(7h6) | Buy now |


Intake




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 32 | 985800402500 Screw, pan head | Buy now |
| 34 | 6G1244520000 Cover, pump | Buy now |
| 35 | 6G1244320000 Packing | Buy now |
| 36 | 6G1244710000 Diaphragm | Buy now |
| 37 | 6G1244120100 Body 1 | Buy now |
| 38 | 6G1244110000 Diaphragm | Buy now |
| 39 | 6G1244310000 Gasket, fuel pump 1 | Buy now |
| 40 | 6L5244210000 Valve, check | Buy now |
| 41 | 6L5141980000 Gasket | Buy now |
| 42 | 6L5144400000 Silencer assembly, intake | Buy now |
| 43 | 977804031600 Screw, Tapping | Buy now |
| 45 | 6L5412712000 Knob, choke | Buy now |
| 46 | 6L5412520000 Lever, choke 1 | Buy now |
| 47 | 916904004800 Pin, spring (689) | Buy now |
| 48 | 689412730000 Grommet | Buy now |

Intake

| Ref | Part | |
|-----|-------------------------------------------|-------------------------|
| 49 | 6J8412740000 Grommet 2 | Buy now |




Lower Casing & Drive 1




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 3 | 6L5452510100 Anode | Buy now |
| 4 | 973950603000 Bolt(jf7) | Buy now |
| 5 | 929900660000 Washer, plain (646) | Buy now |
| 6 | 9310309M4100 Oil seal | Buy now |
| 7 | 93316003U000 Bearing, cylindrical(6l5) | Buy now |
| 8 | 6L5455670000 Shim | Buy now |
| 9 | 9360410M0300 Pin, dowel (688) | Buy now |
| 10 | 970800603000 Bolt(jf7) | Buy now |
| 12 | 9034008M0400 Plug, straight screw | Buy now |
| 13 | 904300802000 Gasket | Buy now |
| 14 | 6L54532100EJ Plate | Buy now |
| 15 | 6L545315A000 Packing,lower casing | Buy now |
| 16 | 6L2441470000 Boot, shift rod | Buy now |
| 17 | 6L54536100EJ Cap, lower casing | Buy now |
| 18 | 931011380000 Oil seal | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 19 | 932104821400 O-ring | Buy now |
| 20 | 973950601600 Bolt, hexagon deep recess | Buy now |
| 22 | 6L5443110000 Housing, water pump | Buy now |
| 23 | 9321033M8500 O-ring(6l5) | Buy now |
| 24 | 6L5443220000 Insert, cartridge | Buy now |
| 25 | 6L5443230000 Outer plate, cartridge | Buy now |
| 26 | 6E0443660000 Damper, water seal 2 | Buy now |
| 27 | 6L5443520000 Impeller | Buy now |
| 28 | 9360407M1300 Pin, dowel(6l5) | Buy now |
| 29 | 973950604000 Bolt (682) | Buy now |
| 30 | 936041808000 Pin. dowel. (647) | Buy now |
| 31 | 6L5443280000 Plate | Buy now |
| 32 | 6L5443610000 Water tube assembly | Buy now |
| 33 | 646443650000 Damper, water seal 1 | Buy now |
| 34 | 6L5455111000 Shaft, Drive | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|----------------------------------------------------------------|-------------------------|
| 35 | 9046707M1200 Clip(6l5) | Buy now |
| 36 | 6L5455510000 Pinion | Buy now |
| 37 | 990010660000 Circlip(53l) | Buy now |
| 38 | 6L545533000 Shim (t:2.3mm) | Buy now |
| 39 | 6L5455600000 Gear | Buy now |
| 40 | 6L5456110000 Shaft, propeller | Buy now |
| 41 | 905011006400 Spring, compression 6164563600 | Buy now |
| 42 | 6EGG56350000 Plunger, shift | Buy now |
| 43 | 6L5456310000 Clutch, dog | Buy now |
| 44 | 6L5459870000 Spacer 1 | Buy now |
| 45 | 902011319800 Washer 6474556600 | Buy now |
| 46 | 6EEG56160000 Nut, propeller | Buy now |
| 47 | 914902503000 Pin, cotter(6l5) | Buy now |
| 48 | 9020108M5400 Washer, plate (6e5) | Buy now |
| 49 | 6L5459470000 Propeller (3x7-1/4"x8-1/4"-bs) | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|------------------------------------------------------|-------------------------|
| 51 | 6L5453180000 Bushing, drive shaft | Buy now |
| 52 | 9342022M0300 Cir clip (6e0) | Buy now |
| 53 | 9010106M1800 Bolt(6l5) | Buy now |

Repair Kit




| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 1 | 6L5W00010000 Power Head Gsk.kit | Buy now |
| 2 | 9310120M2900 Oil seal(6j1) | Buy now |
| 3 | 9310109M4200 Oil seal(6i5) | Buy now |
| 4 | 6L5153690000 Gasket, oil seal housing | Buy now |
| 5 | 6L511181A200 Gasket, cylinder head 1 | Buy now |
| 6 | 6L5111930000 Gasket, head cover | Buy now |
| 7 | 6L5124140000 Gasket, cover | Buy now |
| 8 | 9310120M3400 Oil seal(6j1) | Buy now |
| 9 | 6L513621A200 Gasket, valve seat | Buy now |
| 10 | 6L5141980000 Gasket | Buy now |
| 11 | 6G1143980000 Washer | Buy now |
| 12 | 6GEG51130000 Gasket, upper casing | Buy now |
| 13 | 646443650000 Damper, water seal 1 | Buy now |
| 14 | 6G1W00930000 Carburetor repair kit | Buy now |
| 15 | 679149230000 Screw, pilot | Buy now |

Repair Kit




| Ref | Part | |
|-----|-------------------------------------------------------|-------------------------|
| 16 | 6G1149660000 Cap | Buy now |
| 17 | 6G1141260000 Packing | Buy now |
| 18 | 679149660000 Rubber cap | Buy now |
| 19 | 6G1149840000 Gasket, float chamber | Buy now |
| 20 | 979800411400 Screw, pan head(ga5) | Buy now |
| 21 | 6G1149850000 Float comp. | Buy now |
| 22 | 6G1145460000 Valve, needle | Buy now |
| 23 | 676141860000 Pin, valve | Buy now |
| 24 | 688145480000 Pin, arm | Buy now |
| 26 | 9310309M4100 Oil seal | Buy now |
| 27 | 904300802000 Gasket | Buy now |
| 28 | 6L5453150000 Packing, lower casing | Buy now |
| 29 | 931011380000 Oil seal | Buy now |
| 30 | 932104821400 O-ring | Buy now |
| 31 | 6L5W00780000 Water pump repair kit | Buy now |

Repair Kit




| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 32 | 9321033M8500 O-ring(615) | Buy now |
| 33 | 6L5443220000 Insert, cartridge | Buy now |
| 34 | 6L5443230000 Outer plate, cartridge | Buy now |
| 35 | 6E0443660000 Damper, water seal 2 | Buy now |
| 36 | 6L5443520000 Impeller | Buy now |
| 37 | 973950604000 Bolt (682) | Buy now |
| 38 | 936041808000 Pin. dowel. (647) | Buy now |
| 39 | 6L5443280000 Plate | Buy now |

Starter



| Ref | Part | |
|-----|----------------------------------------------------|-------------------------|
| 1 | 6L5157100000 Starter assembly | Buy now |
| 2 | 6L5157110000 Case, starter | Buy now |
| 3 | 9038706M7000 Collar (6h5) | Buy now |
| 4 | 6L5157140000 Drum, sheave | Buy now |
| 5 | 6L5157410000 Pawl, drive | Buy now |
| 6 | 6L5157130000 Spring, starter | Buy now |
| 7 | 6L5157160000 Plate, drive | Buy now |
| 8 | 6A1157050000 Spring, drive pawl | Buy now |
| 9 | 973130601200 Bolt(gh1) | Buy now |
| 10 | 6A1157670000 Spring, return | Buy now |
| 12 | 9010506M1500 Bolt (6e0) | Buy now |
| 13 | 9010506M1600 Bolt (6e0) | Buy now |
| 14 | 6L5157580098 Guide, rope | Buy now |
| 15 | 9010506M1400 Bolt (6e0) | Buy now |
| 16 | 6L5157610000 Seal, rubber 1 | Buy now |


Starter



| Ref | Part | |
|-----|-------------------------------------------------|-------------------------|
| 17 | 6L5426771000 Graphic, front | Buy now |
| 18 | 6L5157550000 Handle, starter | Buy now |
| 19 | 6L5157790000 Cover | Buy now |
| 20 | 6L5157890000 Damper | Buy now |




Upper Casing & Bracket




| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 2 | 9360410M0300 Pin, dowel (688) | Buy now |
| 3 | 973950603000 Bolt(jf7) | Buy now |
| 4 | 929900660000 Washer, plain (646) | Buy now |
| 5 | 937000600400 Nipple, grease(6a1) | Buy now |
| 6 | 6L5451520000 Cover, upper casing 2 | Buy now |
| 7 | 6L545115A000 Gasket,upper casing 3 | Buy now |
| 8 | 9014905M0800 Ybs53-525 screw,flat head | Buy now |
| 9 | 647451510100 Cover, upper casing | Buy now |
| 12 | 648431140100 Pad, transom clamp | Buy now |
| 13 | 6E0431160000 Screw, transom clamp | Buy now |
| 14 | 6EEG31180000 Handle, transom cl | Buy now |
| 15 | 9025404M0000 Pin(6a1) | Buy now |
| 16 | 9010108M1000 Bolt(615) | Buy now |
| 17 | 6G1431360000 Piece, friction | Buy now |
| 18 | 6L5421210000 Bracket | Buy now |

Upper Casing & Bracket



| Ref | Part | |
|-----|------------------------------------------------------|-------------------------|
| 19 | 9050816M3000 Spring, torsion(6l5) | Buy now |
| 20 | 901850805700 Nut, nylon (6j8) | Buy now |
| 21 | 6A1431130000 Plate, clamp bracket | Buy now |
| 22 | 9038706M1100 Collar | Buy now |
| 23 | 901010633500 Bolt, hexagon (624) | Buy now |
| 25 | 953800660000 Nut(661) | Buy now |
| 29 | 973950603500 Bolt(j52) | Buy now |
| 31 | 6E0433130094 Bracket, swivel 3 | Buy now |
| 32 | 620431890000 Bushing | Buy now |
| 34 | 6L5431810000 Lever, tilt stop 1 | Buy now |
| 35 | 6L5441962000 Indicator 3 | Buy now |
| 36 | 6L5441972000 Indicator 4 | Buy now |
| 37 | 905081602000 Spring 6474319800 | Buy now |
| 38 | 905081602100 Spring 6474318800 | Buy now |
| 39 | 6L5431600000 Tilt rod assembly | Buy now |

Upper Casing & Bracket



| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 40 | 6L5436140000 Plate, tilt lock | Buy now |
| 41 | 9050808M2600 Spring, torsion(6l5) | Buy now |
| 42 | 9050808M2700 Spring, torsion(6l5) | Buy now |
| 43 | 6L5436590000 Shaft, reverse lock | Buy now |
| 44 | 990800560000 Circlip(22k) | Buy now |
| 45 | 6L5425370000 Bushing, pivot shaft | Buy now |
| 46 | 6L5425380000 Bushing, pivot shaft | Buy now |
| 47 | 6L5425390000 Bushing, pivot shaft | Buy now |
| 48 | 6L5425490000 Bushing, pivot shaft | Buy now |
| 49 | 6E0425280300 Plate, friction | Buy now |
| 50 | 6L5425290100 Screw, friction piece | Buy now |
| 51 | 6L5425610000 Knob, steering lock | Buy now |
| 52 | 9026604M0500 Rivet(6l5) | Buy now |
| 56 | 9015906M1000 Screw, with washer(6l5) | Buy now |
| 57 | 6A1427920100 Mark (100:1) | Buy now |

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.