



# Yamaha 3AMH 1990

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Control</b> .....	3
<b>Cowling &amp; Fuel</b> .....	6
<b>Cylinder &amp; Crankcase</b> .....	8
<b>Electrical 1</b> .....	11
<b>Generator</b> .....	12
<b>Intake</b> .....	14
<b>Lower Casing &amp; Drive 1</b> .....	18
<b>Repair Kit</b> .....	21
<b>Starter</b> .....	24
<b>Upper Casing &amp; Bracket</b> .....	26

# Control




Ref	Part	
2	<a href="#">9020635M1100</a> Washer, wave(6j8)	<a href="#">Buy now</a>
3	<a href="#">9020235M2400</a> Washer (6g1)	<a href="#">Buy now</a>
4	<a href="#">9038643M7900</a> Bush(6l5)	<a href="#">Buy now</a>
5	<a href="#">9038634M4000</a> Bushing (6g1)	<a href="#">Buy now</a>
6	<a href="#">6G1421310100</a> Cover, handle steering	<a href="#">Buy now</a>
8	<a href="#">664421190000</a> Grip, steering handle	<a href="#">Buy now</a>
9	<a href="#">6G1421770000</a> Rubber, handle	<a href="#">Buy now</a>
11	<a href="#">9026902M0900</a> Rivet(6l5)	<a href="#">Buy now</a>
12	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>
13	<a href="#">929901060000</a> Washer, plate	<a href="#">Buy now</a>
14	<a href="#">9014905M0600</a> Screw, countersunk	<a href="#">Buy now</a>
15	<a href="#">9020908M1700</a> Washer(6l5)	<a href="#">Buy now</a>
16	<a href="#">903860803200</a> Bushing (650)	<a href="#">Buy now</a>
17	<a href="#">6G1421380100</a> Lever, throttle	<a href="#">Buy now</a>
18	<a href="#">6E0421590200</a> Stay	<a href="#">Buy now</a>

# Control




Ref	Part	
19	<a href="#">978850501200</a> Screw,pan head (646)	<a href="#">Buy now</a>
20	<a href="#">6L5421250000</a> Bolt, friction adjusting	<a href="#">Buy now</a>
21	<a href="#">6G1421260000</a> Piece, friction	<a href="#">Buy now</a>
22	<a href="#">990800360000</a> Circlip(6l5)	<a href="#">Buy now</a>
23	<a href="#">6GEF63010000</a> Throttle cable assembly	<a href="#">Buy now</a>
24	<a href="#">6L5441110000</a> Handle, gear shift	<a href="#">Buy now</a>
25	<a href="#">932101232700</a> O-ring(3ld)	<a href="#">Buy now</a>
26	<a href="#">6L5441962000</a> Indicator 3	<a href="#">Buy now</a>
27	<a href="#">6L5441972000</a> Indicator 4	<a href="#">Buy now</a>
28	<a href="#">935051602400</a> Ball	<a href="#">Buy now</a>
29	<a href="#">905011227400</a> Spring 6554411600	<a href="#">Buy now</a>
30	<a href="#">6L5441210000</a> Lever, shift rod	<a href="#">Buy now</a>
31	<a href="#">977804052000</a> Ybs83-420 screw,panh,tapping	<a href="#">Buy now</a>
32	<a href="#">929900460000</a> Washer, plain (646)	<a href="#">Buy now</a>
33	<a href="#">6L5441430000</a> Rod, shift	<a href="#">Buy now</a>

## Control




Ref	Part	
34	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
35	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
36	<a href="#">6E0441450000</a> Connector, shift rod 1	<a href="#">Buy now</a>
37	<a href="#">6E0441460000</a> Connector, shift rod 2	<a href="#">Buy now</a>
39	<a href="#">6L5441441000</a> Rod, shift	<a href="#">Buy now</a>
40	<a href="#">916092501400</a> Pin, Spring	<a href="#">Buy now</a>
42	<a href="#">6L5427352000</a> Protector	<a href="#">Buy now</a>
43	<a href="#">9016104M0200</a> Screw, tapping (676)	<a href="#">Buy now</a>
44	<a href="#">973950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
45	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
6	<a href="#">6L5427740000</a> Stay, apron 1	<a href="#">Buy now</a>
7	<a href="#">985800501000</a> Screw, pan head(62x)	<a href="#">Buy now</a>
8	<a href="#">973950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
9	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">6L5426470000</a> Holder, clamp band	<a href="#">Buy now</a>
11	<a href="#">6EGG28230000</a> Plate, stop	<a href="#">Buy now</a>
12	<a href="#">9016703M0200</a> Screw, tapping(615)	<a href="#">Buy now</a>
14	<a href="#">6L5245910000</a> Emblem, Fuel Cock	<a href="#">Buy now</a>
15	<a href="#">6L5241110200</a> Tank, fuel	<a href="#">Buy now</a>
16	<a href="#">6L5246102000</a> Cap assembly	<a href="#">Buy now</a>
17	<a href="#">6A0823170000</a> Damper, ignition coil	<a href="#">Buy now</a>
18	<a href="#">903870611900</a> Collar	<a href="#">Buy now</a>
19	<a href="#">9011906M6500</a> Bolt, with washer	<a href="#">Buy now</a>
20	<a href="#">6L5246410000</a> Gasket, cap 1	<a href="#">Buy now</a>
21	<a href="#">6L5245006000</a> Fuel cock assembly 1	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
22	<a href="#">9015906M1000</a> Screw, with washer(6l5)	<a href="#">Buy now</a>
23	<a href="#">6L5441962000</a> Indicator 3	<a href="#">Buy now</a>
24	<a href="#">6L5441972000</a> Indicator 4	<a href="#">Buy now</a>
25	<a href="#">6A4243120000</a> Pipe, fuel 2	<a href="#">Buy now</a>
26	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
27	<a href="#">6L5243120000</a> Pipe 2	<a href="#">Buy now</a>
28	<a href="#">9046513M1100</a> Clamp (6e5)	<a href="#">Buy now</a>
29	<a href="#">656W28100100</a> Tool kit	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
1	<a href="#">6L5W009000EJ</a> Crank cylinder assembly	<a href="#">Buy now</a>
2	<a href="#">6L5151000094</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">624144850000</a> Pipe, joint	<a href="#">Buy now</a>
4	<a href="#">6E5113720000</a> Nipple, hose	<a href="#">Buy now</a>
5	<a href="#">9044507M2900</a> Hose (I200)	<a href="#">Buy now</a>
6	<a href="#">904670601600</a> Clip (655)	<a href="#">Buy now</a>
7	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
8	<a href="#">9010506M1600</a> Bolt (6e0)	<a href="#">Buy now</a>
9	<a href="#">9010506M4000</a> Bolt, washer based(6l5)	<a href="#">Buy now</a>
10	<a href="#">6L5153960094</a> Housing, oil seal	<a href="#">Buy now</a>
11	<a href="#">9310120M2900</a> Oil seal(6j1)	<a href="#">Buy now</a>
12	<a href="#">9310109M4200</a> Oil seal(6l5)	<a href="#">Buy now</a>
13	<a href="#">6L5153960000</a> Housing, oil seal	<a href="#">Buy now</a>
14	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
15	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
16	<a href="#">6L5111110094</a> Head, cylinder 1	<a href="#">Buy now</a>
17	<a href="#">6L5111810000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
18	<a href="#">975130663000</a> Bolt, With Washer(64T)	<a href="#">Buy now</a>
20	<a href="#">6L511191009M</a> Cover, cylinder head 1	<a href="#">Buy now</a>
21	<a href="#">6L511193A100</a> Gasket, head cover	<a href="#">Buy now</a>
22	<a href="#">973130602000</a> Bolt(7u8)	<a href="#">Buy now</a>
24	<a href="#">970130605000</a> Bolt, hexagon	<a href="#">Buy now</a>
26	<a href="#">6E5124110100</a> Thermostat	<a href="#">Buy now</a>
27	<a href="#">6L512413001S</a> Cover, thermostat	<a href="#">Buy now</a>
28	<a href="#">6L5124140000</a> Gasket, cover	<a href="#">Buy now</a>
31	<a href="#">6L5114000000</a> Crankshaft assembly	<a href="#">Buy now</a>
32	<a href="#">6L5114120000</a> Crank 1	<a href="#">Buy now</a>
33	<a href="#">6L5114220000</a> Crank 2	<a href="#">Buy now</a>
34	<a href="#">6L5116510000</a> Rod, connecting	<a href="#">Buy now</a>
35	<a href="#">6L5116810000</a> Pin, crank 1	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
36	<a href="#">93310416F700</a> Brg,needle	<a href="#">Buy now</a>
37	<a href="#">93306204U000</a> Bearing(6e0)	<a href="#">Buy now</a>
39	<a href="#">9020132M0000</a> Washer, plate(6l5)	<a href="#">Buy now</a>
40	<a href="#">9020132M0100</a> Washer, plate(6l5)	<a href="#">Buy now</a>
41	<a href="#">6L5116310096</a> Piston (std)	<a href="#">Buy now</a>
42	<a href="#">6L5116102000</a> Piston ring set (0.50mm o/s)	<a href="#">Buy now</a>
43	<a href="#">93310112U000</a> Bearing, cylindrical(6l5)	<a href="#">Buy now</a>
44	<a href="#">6L5116330000</a> Pin, piston	<a href="#">Buy now</a>
45	<a href="#">934501302200</a> Circlip 132116340000	<a href="#">Buy now</a>
46	<a href="#">6L5451130000</a> Gasket, upper casing	<a href="#">Buy now</a>
47	<a href="#">947020027400</a> Plug, spark (br6hs-10)	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
1	<a href="#">6G1823702000</a> Plug cap assembly	<a href="#">Buy now</a>
2	<a href="#">6L5823160000</a> Bracket, ignition coil	<a href="#">Buy now</a>
3	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
4	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">6L585570M000</a> Ignition coil assembly	<a href="#">Buy now</a>
6	<a href="#">925030601500</a> Screw, pan	<a href="#">Buy now</a>
8	<a href="#">6L585540M000</a> C.d.i. unit assembly	<a href="#">Buy now</a>
9	<a href="#">973130601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
11	<a href="#">904651814700</a> Clamp	<a href="#">Buy now</a>
12	<a href="#">6A0825500100</a> Stop switch assembly	<a href="#">Buy now</a>
13	<a href="#">970130601200</a> Bolt(gh1)	<a href="#">Buy now</a>

# Generator




Ref	Part	
1	<a href="#">6L585550M000</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">6L585560M100</a> Base assembly	<a href="#">Buy now</a>
3	<a href="#">6E0855207000</a> Charge coil ass'y	<a href="#">Buy now</a>
4	<a href="#">6L585595M000</a> Coil, pulser	<a href="#">Buy now</a>
5	<a href="#">6L585592M000</a> Pulser coil assembly	<a href="#">Buy now</a>
6	<a href="#">6E0813367000</a> Grommet	<a href="#">Buy now</a>
7	<a href="#">6E0813287000</a> Clamp	<a href="#">Buy now</a>
8	<a href="#">985070501600</a> Screw, pan head(jj6)	<a href="#">Buy now</a>
9	<a href="#">976070521200</a> Screw,w/washer	<a href="#">Buy now</a>
10	<a href="#">985070401000</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
12	<a href="#">6L5157710100</a> Stay 1	<a href="#">Buy now</a>
13	<a href="#">9044610M0100</a> Tube (6e5)	<a href="#">Buy now</a>
14	<a href="#">985800500800</a> Screw, pan head (7g3)	<a href="#">Buy now</a>
15	<a href="#">9046510M3400</a> Clamp(6l5)	<a href="#">Buy now</a>
16	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>

## Generator




Ref	Part	
17	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
18	<a href="#">901701011300</a> Nut, crank shaft (650)	<a href="#">Buy now</a>
19	<a href="#">90201102G900</a> Washer, plate (26h)	<a href="#">Buy now</a>

# Intake




Ref	Part	
1	<a href="#">6L5136100100</a> Reed valve assembly	<a href="#">Buy now</a>
2	<a href="#">6L5W00040100</a> Reed set	<a href="#">Buy now</a>
3	<a href="#">6L5136210000</a> Gasket, valve seat	<a href="#">Buy now</a>
4	<a href="#">958800601600</a> Bolt, flange(jl8)	<a href="#">Buy now</a>
5	<a href="#">6L5143010300</a> Carburetor assembly 1	<a href="#">Buy now</a>
6	<a href="#">679149230000</a> Screw, pilot	<a href="#">Buy now</a>
7	<a href="#">679145550000</a> Spring	<a href="#">Buy now</a>
8	<a href="#">6G1149660000</a> Cap	<a href="#">Buy now</a>
9	<a href="#">6G1145270000</a> Plate	<a href="#">Buy now</a>
10	<a href="#">6G1141260000</a> Packing	<a href="#">Buy now</a>
11	<a href="#">6L5149480300</a> Jet (#40)	<a href="#">Buy now</a>
12	<a href="#">676149660000</a> Rubber cap	<a href="#">Buy now</a>
13	<a href="#">985800401000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
14	<a href="#">929900410000</a> Ybs67-4 washer, spring	<a href="#">Buy now</a>
15	<a href="#">905011032600</a> Spring coil(663)(carb)	<a href="#">Buy now</a>

# Intake




Ref	Part	
16	<a href="#">663145230000</a> Screw, stop	<a href="#">Buy now</a>
17	<a href="#">6G1149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
18	<a href="#">6G1149800100</a> Body, float chamber	<a href="#">Buy now</a>
19	<a href="#">6L5149470100</a> Jet, needle	<a href="#">Buy now</a>
20	<a href="#">676149431400</a> Jet, main (#68)	<a href="#">Buy now</a>
21	<a href="#">979800411400</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
22	<a href="#">6G1143980000</a> Washer	<a href="#">Buy now</a>
23	<a href="#">65W149920000</a> Screw, drain	<a href="#">Buy now</a>
24	<a href="#">6G1149850000</a> Float comp.	<a href="#">Buy now</a>
25	<a href="#">6G1145460000</a> Valve, needle	<a href="#">Buy now</a>
26	<a href="#">676141860000</a> Pin, valve	<a href="#">Buy now</a>
27	<a href="#">663141590000</a> Clip	<a href="#">Buy now</a>
28	<a href="#">985800400800</a> Screw, pan head (713)	<a href="#">Buy now</a>
29	<a href="#">688145480000</a> Pin, arm	<a href="#">Buy now</a>
30	<a href="#">985800300800</a> Screw, pan head (j10)	<a href="#">Buy now</a>

# Intake




Ref	Part	
31	<a href="#">953800360000</a> Nut (6g8)	<a href="#">Buy now</a>
32	<a href="#">979800412500</a> Screw, with washer	<a href="#">Buy now</a>
33	<a href="#">6G1244520000</a> Cover, pump	<a href="#">Buy now</a>
34	<a href="#">6G1244320000</a> Packing	<a href="#">Buy now</a>
35	<a href="#">6G1244710000</a> Diaphragm	<a href="#">Buy now</a>
36	<a href="#">6G1244120100</a> Body 1	<a href="#">Buy now</a>
37	<a href="#">6G1244110000</a> Diaphragm	<a href="#">Buy now</a>
38	<a href="#">6G1244310100</a> Gasket, fuel pump 1	<a href="#">Buy now</a>
39	<a href="#">6G1244210000</a> Valve, check	<a href="#">Buy now</a>
40	<a href="#">6L5141980100</a> Gasket	<a href="#">Buy now</a>
41	<a href="#">6L5144400000</a> Silencer assembly, intake	<a href="#">Buy now</a>
42	<a href="#">977804031600</a> Screw, Tapping	<a href="#">Buy now</a>
43	<a href="#">958950609500</a> Bolt, flange deep recess	<a href="#">Buy now</a>
44	<a href="#">6L5412712000</a> Knob, choke	<a href="#">Buy now</a>
45	<a href="#">6L5412520000</a> Lever, choke 1	<a href="#">Buy now</a>

## Intake




Ref	Part	
46	<a href="#">916904004800</a> Pin, spring (689)	<a href="#">Buy now</a>
47	<a href="#">689412730000</a> Grommet	<a href="#">Buy now</a>
48	<a href="#">6J8412740000</a> Grommet 2	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
3	<a href="#">6L5452510200</a> Anode	<a href="#">Buy now</a>
4	<a href="#">973950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">9310309M4100</a> Oil seal	<a href="#">Buy now</a>
7	<a href="#">93316003U000</a> Bearing, cylindrical(615)	<a href="#">Buy now</a>
8	<a href="#">6L5455670000</a> Shim	<a href="#">Buy now</a>
9	<a href="#">9360410M0300</a> Pin, dowel (688)	<a href="#">Buy now</a>
12	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
13	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">6L54532100CA</a> Plate	<a href="#">Buy now</a>
15	<a href="#">6L5453150000</a> Packing,lower casing	<a href="#">Buy now</a>
16	<a href="#">6L2441470000</a> Boot, shift rod	<a href="#">Buy now</a>
17	<a href="#">6L54536100EJ</a> Cap, lower casing	<a href="#">Buy now</a>
18	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>
19	<a href="#">932104880000</a> O-ring	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
20	<a href="#">973950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
22	<a href="#">6L5443110000</a> Housing, water pump	<a href="#">Buy now</a>
23	<a href="#">9321033M8500</a> O-ring(615)	<a href="#">Buy now</a>
24	<a href="#">6L5443220000</a> Insert, cartridge	<a href="#">Buy now</a>
25	<a href="#">6L5443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
26	<a href="#">6E0443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
27	<a href="#">6L5443520000</a> Impeller	<a href="#">Buy now</a>
28	<a href="#">9360407M1300</a> Pin, dowel(615)	<a href="#">Buy now</a>
29	<a href="#">973950604000</a> Bolt (682)	<a href="#">Buy now</a>
30	<a href="#">936041808000</a> Pin. dowel. (647)	<a href="#">Buy now</a>
31	<a href="#">6L5443280000</a> Plate	<a href="#">Buy now</a>
32	<a href="#">6L5443601100</a> Water Tube assembly	<a href="#">Buy now</a>
33	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
34	<a href="#">6L5455111000</a> Shaft, Drive	<a href="#">Buy now</a>
35	<a href="#">9046707M1200</a> Clip(615)	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
36	<a href="#">6L5455510000</a> Pinion	<a href="#">Buy now</a>
37	<a href="#">990090660000</a> Circlip(53)	<a href="#">Buy now</a>
38	<a href="#">6L5455333000</a> Shim (t:2.3mm)	<a href="#">Buy now</a>
40	<a href="#">6L5456110000</a> Shaft, propeller	<a href="#">Buy now</a>
42	<a href="#">6L5456350000</a> Plunger, shift	<a href="#">Buy now</a>
44	<a href="#">6L5459870000</a> Spacer 1	<a href="#">Buy now</a>
47	<a href="#">914902503000</a> Pin, cotter(615)	<a href="#">Buy now</a>
49	<a href="#">6L54594300EL</a> Propeller (3x7-1/4 x6 -bs)	<a href="#">Buy now</a>
52	<a href="#">9342022M0300</a> Cir clip (6e0)	<a href="#">Buy now</a>
53	<a href="#">9010106M1800</a> Bolt(615)	<a href="#">Buy now</a>

# Repair Kit




Ref	Part	
1	<a href="#">6L5W00010100</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310120M2900</a> Oil seal(6j1)	<a href="#">Buy now</a>
3	<a href="#">9310109M4200</a> Oil seal(6l5)	<a href="#">Buy now</a>
4	<a href="#">6L5153690000</a> Gasket, oil seal housing	<a href="#">Buy now</a>
5	<a href="#">6L511181A200</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
6	<a href="#">6L5111930000</a> Gasket, head cover	<a href="#">Buy now</a>
7	<a href="#">6L5124140000</a> Gasket, cover	<a href="#">Buy now</a>
8	<a href="#">9310120M3400</a> Oil seal(6j1)	<a href="#">Buy now</a>
9	<a href="#">6L513621A200</a> Gasket, valve seat	<a href="#">Buy now</a>
10	<a href="#">6L5141980100</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">6G1143980000</a> Washer	<a href="#">Buy now</a>
12	<a href="#">6GEG51130000</a> Gasket, upper casing	<a href="#">Buy now</a>
13	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
14	<a href="#">6G1W00930000</a> Carburetor repair kit	<a href="#">Buy now</a>
15	<a href="#">679149230000</a> Screw, pilot	<a href="#">Buy now</a>

# Repair Kit




Ref	Part	
16	<a href="#">6G1149660000</a> Cap	<a href="#">Buy now</a>
17	<a href="#">6G1141260000</a> Packing	<a href="#">Buy now</a>
18	<a href="#">679149660000</a> Rubber cap	<a href="#">Buy now</a>
19	<a href="#">6G1149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
20	<a href="#">979800411400</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
21	<a href="#">6G1149850000</a> Float comp.	<a href="#">Buy now</a>
22	<a href="#">6G1145460100</a> Valve, needle	<a href="#">Buy now</a>
23	<a href="#">676141860000</a> Pin, valve	<a href="#">Buy now</a>
24	<a href="#">688145480000</a> Pin, arm	<a href="#">Buy now</a>
26	<a href="#">9310309M4100</a> Oil seal	<a href="#">Buy now</a>
27	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
28	<a href="#">6L545315A000</a> Packing, lower casing	<a href="#">Buy now</a>
29	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>
31	<a href="#">6L5W00780000</a> Water pump repair kit	<a href="#">Buy now</a>
32	<a href="#">9321033M8500</a> O-ring(615)	<a href="#">Buy now</a>

## Repair Kit




Ref	Part	
33	<a href="#">6L5443220000</a> Insert, cartridge	<a href="#">Buy now</a>
34	<a href="#">6L5443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
35	<a href="#">6E0443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
36	<a href="#">6L5443520000</a> Impeller	<a href="#">Buy now</a>
37	<a href="#">973950604000</a> Bolt (682)	<a href="#">Buy now</a>
38	<a href="#">936041808000</a> Pin. dowel. (647)	<a href="#">Buy now</a>
39	<a href="#">6L5443280000</a> Plate	<a href="#">Buy now</a>

# Starter



Ref	Part	
1	<a href="#">6L5157100000</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">6L5157110000</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">9038706M7000</a> Collar (6h5)	<a href="#">Buy now</a>
4	<a href="#">6L5157140000</a> Drum, sheave	<a href="#">Buy now</a>
5	<a href="#">6L5157410000</a> Pawl, drive	<a href="#">Buy now</a>
6	<a href="#">6L5157130000</a> Spring, starter	<a href="#">Buy now</a>
7	<a href="#">6L5157160000</a> Plate, drive	<a href="#">Buy now</a>
8	<a href="#">6A1157050000</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">970130601200</a> Bolt(gh1)	<a href="#">Buy now</a>
10	<a href="#">6A1157670000</a> Spring, return	<a href="#">Buy now</a>
13	<a href="#">958800603500</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
14	<a href="#">6L5157580098</a> Guide, rope	<a href="#">Buy now</a>
15	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
16	<a href="#">6L5157610000</a> Seal, rubber 1	<a href="#">Buy now</a>
17	<a href="#">6L5426771000</a> Graphic, front	<a href="#">Buy now</a>


## Starter



Ref	Part	
18	<u><a href="#">6L5157550000</a></u> Handle, starter	<u><a href="#">Buy now</a></u>
19	<u><a href="#">6L5157790000</a></u> Cover	<u><a href="#">Buy now</a></u>
20	<u><a href="#">6L5157890000</a></u> Damper	<u><a href="#">Buy now</a></u>




## Upper Casing & Bracket




Ref	Part	
2	<a href="#">9360410M0300</a> Pin, dowel (688)	<a href="#">Buy now</a>
3	<a href="#">973950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
4	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">937000600400</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
6	<a href="#">6L5451520000</a> Cover, upper casing 2	<a href="#">Buy now</a>
7	<a href="#">6L545115A000</a> Gasket,upper casing 3	<a href="#">Buy now</a>
8	<a href="#">9014905M0800</a> Ybs53-525 screw,flat head	<a href="#">Buy now</a>
9	<a href="#">647451510100</a> Cover, upper casing	<a href="#">Buy now</a>
12	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
13	<a href="#">6E0431160100</a> Screw, transom clamp	<a href="#">Buy now</a>
14	<a href="#">6E0431180000</a> Handle, transom clamp	<a href="#">Buy now</a>
15	<a href="#">9025404M0000</a> Pin(6a1)	<a href="#">Buy now</a>
16	<a href="#">9010108M1000</a> Bolt(615)	<a href="#">Buy now</a>
17	<a href="#">6G1431360000</a> Piece, friction	<a href="#">Buy now</a>
18	<a href="#">6L5421210000</a> Bracket	<a href="#">Buy now</a>

## Upper Casing & Bracket



Ref	Part	
19	<a href="#">9050816M3000</a> Spring, torsion(6l5)	<a href="#">Buy now</a>
21	<a href="#">6A1431130100</a> Plate, clamp bracket	<a href="#">Buy now</a>
22	<a href="#">9038706M1100</a> Collar	<a href="#">Buy now</a>
23	<a href="#">901010633500</a> Bolt, hexagon (624)	<a href="#">Buy now</a>
25	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
29	<a href="#">973950603500</a> Bolt(j52)	<a href="#">Buy now</a>
31	<a href="#">6E0433130094</a> Bracket, swivel 3	<a href="#">Buy now</a>
32	<a href="#">620431890000</a> Bushing	<a href="#">Buy now</a>
34	<a href="#">6L5431810000</a> Lever, tilt stop 1	<a href="#">Buy now</a>
35	<a href="#">6L5441972000</a> Indicator 4	<a href="#">Buy now</a>
37	<a href="#">905081602000</a> Spring 6474319800	<a href="#">Buy now</a>
38	<a href="#">905081602100</a> Spring 6474318800	<a href="#">Buy now</a>
39	<a href="#">6L5431600000</a> Tilt rod assembly	<a href="#">Buy now</a>
40	<a href="#">6L5436140000</a> Plate, tilt lock	<a href="#">Buy now</a>
41	<a href="#">9050808M2600</a> Spring, torsion(6l5)	<a href="#">Buy now</a>

## Upper Casing & Bracket



Ref	Part	
42	<a href="#">9050808M2700</a> Spring, torsion(6l5)	<a href="#">Buy now</a>
43	<a href="#">6L5436590000</a> Shaft, reverse lock	<a href="#">Buy now</a>
44	<a href="#">990800560000</a> Circlip(22k)	<a href="#">Buy now</a>
45	<a href="#">6L5425370000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
46	<a href="#">6L5425380000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
47	<a href="#">6L5425390000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
48	<a href="#">6L5425490000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
49	<a href="#">6E0425280300</a> Plate, friction	<a href="#">Buy now</a>
50	<a href="#">6L5425290100</a> Screw, friction piece	<a href="#">Buy now</a>
51	<a href="#">6L5425610000</a> Knob, steering lock	<a href="#">Buy now</a>
52	<a href="#">9026604M0500</a> Rivet(6l5)	<a href="#">Buy now</a>
53	<a href="#">6L5441962000</a> Indicator 3	<a href="#">Buy now</a>
56	<a href="#">9015906M1000</a> Screw, with washer(6l5)	<a href="#">Buy now</a>
57	<a href="#">6A1427920100</a> Mark (100:1)	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.