



Yamaha 3AMH 2005

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

CONTROL	3
COWLING & FUEL	7
CYLINDER & CRANKCASE	11
ELECTRICAL	15
GENERATOR	16
INTAKE	18
LOWER CASING & DRIVE	22
REPAIR KIT	27
STARTER	30
UPPER CASING & BRACKET	32


Control



B6

Ref	Part	
1	6G142111124D Handle, steering	Buy now
2	9020636M21 Washer, wave(63v)	Buy now
3	9020236M55 Washer, plate(63v)	Buy now
4	9038634M97 Bush(63v)	Buy now
5	9038633M96 Bush(63v)	Buy now
6	6G14213102 Cover, handle steering	Buy now
7	9011608016 Bolt, stud	Buy now
8	9018508057 Nut, nylon (6j8)	Buy now
9	6644211900 Grip, steering handle	Buy now
10	6G14217700 Rubber, handle	Buy now
11	6L54213700 Indicator, throttle	Buy now
12	9026902M09 Rivet(6l5)	Buy now
13	9050123215 Spring (655)	Buy now
14	9290310600 Washer, plate	Buy now
15	9014905M13 Screw, countersunk	Buy now


Control



B6

Ref	Part	
16	9020908M17 Washer(6l5)	Buy now
17	9038608032 Bushing (650)	Buy now
18	6G14213801 Lever, throttle	Buy now
19	6E04215902 Stay	Buy now
20	9788505012 Screw,pan head (646)	Buy now
21	6L54212500 Bolt, friction adjusting	Buy now
22	6G14212600 Piece, friction	Buy now
23	9908003600 Circlip(6l5)	Buy now
24	6L52630101 Throttle cable assembly	Buy now
25	6L54411100 Handle, gear shift	Buy now
26	9321012327 O-ring(3ld)	Buy now
27	6L54419600 Indicator 3	Buy now
28	6L54419700 Indicator 4	Buy now
29	9350516024 Ball	Buy now
30	9050112274 Spring 6554411600	Buy now


Control



B6

Ref	Part	
31	6L54412100 Lever, shift rod	Buy now
32	9778040520 Ybs83-420 screw,panh,tapping	Buy now
33	9299004600 Washer, plain (646)	Buy now
34	6L54414300 Rod, shift	Buy now
35	9299005600 Washer, plain (646)	Buy now
36	9149016010 Pin, cotter	Buy now
37	6E04414500 Connector, shift rod 1	Buy now
38	6E04414600 Connector, shift rod 2	Buy now
39	9589506020 Bolt, flange(jk3)	Buy now
40	6L54414400 Rod, shift S	Buy now
40	6L54414410 Rod, shift L	Buy now
41	9160925014 Pin, Spring	Buy now
42	6L542731004D Carrying handle	Buy now
43	6L54273500 Protector	Buy now
44	9016104M02 Screw, tapping (676)	Buy now


Control



B6

Ref	Part	
45	9709506020 Bolt(7u8)	Buy now
46	9299506600 Washer, plain (646)	Buy now
47	6A12415A41 Label, caution	Buy now
48	6A12415A51 Label Caution	Buy now


Cowling & Fuel



A4

Ref	Part	
1	6L542610134D Top Cowling assembly	Buy now
2	6L5W007013 Graphic Set	Buy now
3	6L54267812 Graphic, rear	Buy now
4	6L54271111 Cowling, bottom	Buy now
5	6L54271212 Cowling, bottom	Buy now
6	6L54277400 Stay, apron 1	Buy now
7	6L54277500 Stay, apron 2	Buy now
8	9788005010 Screw, pan head(62x)	Buy now
9	9709506016 Bolt, hexagon deep recess	Buy now
10	9299506600 Washer, plain (646)	Buy now
11	6L54264700 Holder, clamp band	Buy now
12	6L54282300 Plate, stop	Buy now
13	9016703M02 Screw, tapping(615)	Buy now
14	6L52459100 Emblem, Fuel Cock	Buy now
15	6L54266200 Damper	Buy now


Cowling & Fuel



A4

Ref	Part	
16	6L54266300 Damper	Buy now
17	6L52411102 Tank, fuel	Buy now
18	6L52461000 Cap assembly	Buy now
19	6A08231700 Damper, ignition coil	Buy now
20	6244254200 Collar	Buy now
21	9011906M65 Bolt, with washer	Buy now
22	6L52464100 Gasket, cap 1	Buy now
23	6L52450060 Fuel cock assembly 1	Buy now
24	9015906M10 Screw, with washer(6l5)	Buy now
25	6L54419600 Indicator 3	Buy now
26	6L54419700 Indicator 4	Buy now
27	6L52425100 Strainer 1	Buy now
28	6L52431100 Pipe, fuel 2	Buy now
29	9046708004 Clip, pipe 6162435600	Buy now
30	6L52431200 Pipe 2	Buy now


Cowling & Fuel



A4

Ref	Part	
31	9046513M11 Clamp (6e5)	Buy now
32	6A12817600 Label Caution	Buy now
33	61H2819R31 Tag Warning	Buy now
34	656W281002 Tool kit	Buy now
35	6L52819970D0 3a UR (NL)	Buy now
35	6L52819970E0 3a UR (E)	Buy now
35	6L52819970F0 3a UR (F)	Buy now
35	6L52819970G0 3a UR (D)	Buy now
35	6L52819970H0 3a UR (I)	Buy now
35	6L52819970S0 3a UR (ES)	Buy now
36	6L52819980K0 3a UR (DK)	Buy now
36	6L52819980L0 3a UR (SF)	Buy now
36	6L52819980M0 3a UR (S)	Buy now
36	6L52819980N0 3a UR (N)	Buy now
36	6L52819980P0 3a UR (P)	Buy now


Cowling & Fuel



Ref	Part	
36	<u>6L52819980R0</u> 3a UR (GR)	Buy now

A4


Cylinder & Crankcase



A6

Ref	Part	
1	6L5W0090011S Crank cylinder assembly	Buy now
2	6L515100001S Crankcase assembly	Buy now
3	6241448500 Pipe, joint	Buy now
4	6E51137201 Nipple, hose	Buy now
5	9044507M29 Hose (l200)	Buy now
6	9046706016 Clip (655)	Buy now
7	9360612019 Pin, dowel (614)	Buy now
8	9010506M16 Bolt (6e0)	Buy now
9	9010506M40 Bolt, washer based(6l5)	Buy now
10	6L5153960094 Housing, oil seal	Buy now
11	9310120M29 Oil seal(6j1)	Buy now
12	9310109M42 Oil seal(6l5)	Buy now
13	6L515369A0 Gasket, oil seal housing	Buy now
14	9709506020 Bolt(7u8)	Buy now
15	9299506600 Washer, plain (646)	Buy now


Cylinder & Crankcase



A6

Ref	Part	
16	6L511111001S Head, cylinder 1	Buy now
17	6L511181A2 Gasket, cylinder head 1	Buy now
18	9011906047 Bolt, with washer	Buy now
19	6L511191001S Cover, cylinder head 1	Buy now
20	6L511193A1 Gasket, head cover	Buy now
21	9011906MA2 Bolt, with washer	Buy now
22	9011906027 Bolt, with washer	Buy now
23	6E51241102 Thermostat	Buy now
24	6L512413001S Cover, thermostat	Buy now
25	6L512414A1 Gasket, cover	Buy now
27	6L51140000 Crankshaft assembly	Buy now
28	6L51141200 Crank 1	Buy now
29	6L51142200 Crank 2	Buy now
30	6L51165100 Rod, connecting	Buy now
31	6L51168100 Pin, crank 1	Buy now

Cylinder & Crankcase




A6


Ref	Part	
32	93310416N7 Brg,needle	Buy now
33	93306204U0 Bearing(6e0)	Buy now
34	9310220M06 Oil seal(6j1)	Buy now
35	9020132M00 Washer, plate(6l5)	Buy now
36	9020132M01 Washer, plate(6l5)	Buy now
37	6L5116310096 Piston (std)	Buy now
37	6L51163500 Piston (0.25mm o/s) AP	Buy now
37	6L51163600 Piston (0.50mm o/s) AP	Buy now
38	6L51161000 Piston ring set (std)	Buy now
38	6L51161010 Piston ring set (0.25mm o/s) AP	Buy now
38	6L51161020 Piston ring set (0.50mm o/s) AP	Buy now
39	93310112U0 Bearing, cylindrical(6l5)	Buy now
40	6L51163300 Pin, piston	Buy now
41	9345013022 Circlip 132116340000	Buy now
42	6L545113A1 Gasket, upper casing	Buy now

Cylinder & Crankcase

Ref	Part	
43	9470200274 Plug, spark (br6hs-10)	Buy now



A6





 6L53700-C060

B5

Ref	Part	
1	6G18237021 Plug cap assembly	Buy now
2	6L58231600 Bracket, ignition coil	Buy now
3	9709506016 Bolt, hexagon deep recess	Buy now
4	9299506600 Washer, plain (646)	Buy now
5	6L585570N0 Ignition coil assembly	Buy now
6	9788006016 Screw pan head	Buy now
7	9299006600 Washer, plain (646)	Buy now
8	6L585540M0 C.d.i. unit assembly	Buy now
11	9046518147 Clamp	Buy now
12	6L58255000 Stop switch assembly	Buy now
13	9709006012 Bolt(gh1)	Buy now


Generator



B4

Ref	Part	
1	6L585550M0 Rotor assembly	Buy now
2	6L585560M1 Base assembly	Buy now
3	6E08552070 Charge coil ass'y	Buy now
4	6L585595M0 Coil, pulser	Buy now
5	6L585592M0 Pulser coil assembly	Buy now
6	6E08133670 Grommet	Buy now
7	6E08132870 Clamp	Buy now
8	9015905038 -	Buy now
9	9015905037 Screw,w/washer	Buy now
10	9015904036 Screw, pan head(6g8)	Buy now
11	9015904035 Screw panhead (695)	Buy now
12	6L5157710194 Stay 1	Buy now
13	9044610M01 Tube (6e5)	Buy now
14	9780305008 Screw, pan head (7g3)	Buy now
15	9046510M34 Clamp(6l5)	Buy now


Generator



Ref	Part	
16	9589506016 Bolt, flange deep recess	Buy now
17	9028004M06 Key, woodruff(6a1)	Buy now
18	9017010113 Nut, crank shaft (650)	Buy now
19	9020110126 Washer, plate (26h)	Buy now

B4


Intake




B1

Ref	Part	
1	6L51361002 Reed valve assembly	Buy now
2	6L5W000402 Reed set	Buy now
3	6L513621A2 Gasket, valve seat	Buy now
4	9589506016 Bolt, flange deep recess	Buy now
5	6L51430103 Carburetor assembly 1	Buy now
6	6791492300 Screw, pilot	Buy now
7	6791455500 Spring	Buy now
8	6G11496600 Cap	Buy now
9	6G11452700 Plate	Buy now
10	6G11412600 Packing	Buy now
11	6L51494803 Jet (#40)	Buy now
12	6761496600 Rubber cap	Buy now
13	9788004010 Screw, pan head (e56)	Buy now
14	9299004100 Ybs67-4 washer, spring	Buy now
15	9050110326 Spring coil(663)(carb)	Buy now

Intake



Intake




6L51100-4030

B1

Ref	Part	
31	9538003600 Nut (6g8)	Buy now
32	9798004125 Screw, with washer	Buy now
33	6G12445200 Cover, pump	Buy now
34	6G12443200 Packing	Buy now
35	6G12447100 Diaphragm	Buy now
36	6G12441201 Body 1	Buy now
37	6G12441100 Diaphragm	Buy now
38	6G12443101 Gasket, fuel pump 1	Buy now
39	6L52442100 Valve, check	Buy now
40	6L514198A1 Gasket	Buy now
41	6L51444000 Silencer assembly, intake	Buy now
42	9778040716 Screw, tapping(6l5)	Buy now
43	9589506095 Bolt, flange deep recess	Buy now
44	6L54127100 Knob, choke	Buy now
45	6L54125200 Lever, choke 1	Buy now


Intake



Ref	Part	
46	9169040048 Pin, spring (689)	Buy now
47	6894127300 Grommet	Buy now
48	6J84127400 Grommet 2	Buy now


B1

Lower Casing & Drive



Ref	Part	
1	6L545300014D Lower unit assembly S	Buy now
1	6L545300114D Lower Unit assembly L	Buy now
2	6L545311004D Casing, lower	Buy now
3	6L54531709 Bushing, d/shaft 2 90381-09m08	Buy now
4	6L54531609 Bushing, d/shaft 1 90380-09m23	Buy now
5	6L54525103 Anode	Buy now
6	9010106M18 Bolt(6l5) L	Buy now
6	9589506030 Bolt, flange deep recess S	Buy now
7	9299006300 Washer, tooth	Buy now
8	9310309M41 Oil seal	Buy now
9	93316003U0 Bearing, cylindrical(6l5)	Buy now
10	6L54556700 Shim UN	Buy now
57	9360412M07 Pin, dowel (688) L	Buy now
12	9709506030 Bolt(jf7) S	Buy now
13	9299506600 Washer, plain (646) S	Buy now


Lower Casing & Drive



C4


Ref	Part	
14	9034008002 Plug, straight screw	Buy now
15	9043008020 Gasket	Buy now
16	6L545321005B Plate	Buy now
17	6L545315A0 Packing, lower casing	Buy now
18	6L24414700 Boot, shift rod	Buy now
19	6L545361004D Cap, lower casing	Buy now
20	9310113M12 Oil seal	Buy now
21	9321048214 O-ring	Buy now
22	9709506016 Bolt, hexagon deep recess	Buy now
24	6L54431100 Housing, water pump	Buy now
25	9321033M85 O-ring(615)	Buy now
26	6L54432200 Insert, cartridge	Buy now
27	6L54432300 Outer plate, cartridge	Buy now
28	6E04436600 Damper, water seal 2	Buy now
29	6L54435200 Impeller	Buy now

Lower Casing & Drive




Ref	Part	
30	9360407M13 Pin, dowel(615)	Buy now
31	9709506040 Bolt (682)	Buy now
32	9360418080 Pin. dowel. (647)	Buy now
33	6L54432800 Plate	Buy now
34	6L54436001 Water tube assembly <i>S</i>	Buy now
34	6L54436011 Water Tube assembly <i>L</i>	Buy now
35	6464436500 Damper, water seal 1	Buy now
36	6L54551100 Shaft, drive <i>S</i>	Buy now
36	6L54551110 Shaft, Drive <i>L</i>	Buy now
37	9046707M12 Clip(615)	Buy now
38	6L54555100 Pinion	Buy now
39	9900106600 Circlip(531)	Buy now
40	6L54553300 Shim <i>UR</i>	Buy now
40	6L54553310 Shim (t:2.1mm) <i>UR</i>	Buy now
40	6L54553320 Shim (t:2.2mm) <i>UR</i>	Buy now

Lower Casing & Drive



Ref	Part	
40	6L54553330 Shim (t:2.3mm) UR	Buy now
41	6L54556000 Gear	Buy now
42	6L54561100 Shaft, propeller	Buy now
43	9050110064 Spring, compression 6164563600	Buy now
44	6L54563500 Plunger, shift	Buy now
45	6L54563100 Clutch, dog	Buy now
46	6L54598701 Spacer 1	Buy now
47	9020113198 Washer 6474556600	Buy now
48	6L54561600 Nut, propeller	Buy now
49	9149025030 Pin, cotter(6!5)	Buy now
50	9020108M54 Washer, plate (6e5)	Buy now
51	6L54594300EL Propeller (3x7-1/4 x 6 -bs) UR	Buy now
51	6L54594500EL Propeller (3x7-1/4"x7-1/4"-bs) UR	Buy now
51	6L54594700EL Propeller (3x7-1/4"x8-1/4"-bs) UR	Buy now
51	6L54594900EL Propeller (3x7-1/4 x 5 -bs) UR	Buy now


Lower Casing & Drive



Ref	Part	
51	6L54595200EL Propeller (3x7-1/4"x5-1/2"-bs) UR	Buy now
52	6L545211004D Extension L	Buy now
53	6L54531800 Bushing, drive shaft L	Buy now
54	9342022M03 Cir clip (6e0) L	Buy now
56	9299006600 Washer, plain (646) L	Buy now

C4

Repair Kit




6L50010-4100

C7

Ref	Part	
1	6L5W0001A1 Power head gasket kit	Buy now
2	9310120M29 Oil seal(6j1)	Buy now
3	9310109M42 Oil seal(6l5)	Buy now
4	6L515369A0 Gasket, oil seal housing	Buy now
5	6L511181A2 Gasket, cylinder head 1	Buy now
6	6L511193A1 Gasket, head cover	Buy now
7	6L512414A1 Gasket, cover	Buy now
8	9310220M06 Oil seal(6j1)	Buy now
9	6L513621A2 Gasket, valve seat	Buy now
10	6L514198A1 Gasket	Buy now
11	6G11439800 Washer	Buy now
12	6L545113A1 Gasket, upper casing	Buy now
13	6464436500 Damper, water seal 1	Buy now
14	6G1W009300 Carburetor repair kit	Buy now
15	6791492300 Screw, pilot	Buy now


Repair Kit



C7

Ref	Part	
16	6G11496600 Cap	Buy now
17	6G11412600 Packing	Buy now
18	6761496600 Rubber cap	Buy now
19	6G11498400 Gasket, float chamber	Buy now
20	9798004114 Screw, pan head(ga5)	Buy now
21	6G11498500 Float comp.	Buy now
22	6G11454600 Valve, needle	Buy now
23	6761418600 Pin, valve	Buy now
24	6881454800 Pin, arm	Buy now
25	6L5W000121 Lower Unit Gasket Kit	Buy now
26	9310309M41 Oil seal	Buy now
27	9043008020 Gasket	Buy now
28	6L545315A0 Packing,lower casing	Buy now
29	9310113M12 Oil seal	Buy now
30	9321048214 O-ring	Buy now


Repair Kit



Ref	Part	
31	6L5W007800 Water pump repair kit	Buy now
32	9321033M85 O-ring(615)	Buy now
33	6L54432200 Insert, cartridge	Buy now
34	6L54432300 Outer plate, cartridge	Buy now
35	6E04436600 Damper, water seal 2	Buy now
36	6L54435200 Impeller	Buy now
37	9709506040 Bolt (682)	Buy now
38	9360418080 Pin. dowel. (647)	Buy now
39	6L54432800 Plate	Buy now

C7

Starter





 6L54300-D040

*1:CUT FROM 50M ROLLS,PART NO.90790-77002,CUTTING LENGTH 1.65M
 *1:A PRELEVER SUR BOBINE 50M ,REFERENCE 90790-77002,
 LONGUEUR DE COUPE 1.65M

B3

Ref	Part	
1	6L51571000 Starter assembly	Buy now
2	6L51571100 Case, starter	Buy now
3	9038706M70 Collar (6h5)	Buy now
4	6L51571400 Drum, sheave	Buy now
5	6L51574100 Pawl, drive	Buy now
6	6L51571300 Spring, starter	Buy now
7	6L51571600 Plate, drive	Buy now
8	6A11570500 Spring, drive pawl	Buy now
9	9731306012 Bolt(gh1)	Buy now
10	6A11576700 Spring, return	Buy now
11	* item_description *1	Buy now
12	9589506020 Bolt, flange(jk3)	Buy now
13	9589506035 Bolt, flange(4nx)	Buy now
14	6L5157580098 Guide, rope	Buy now
15	9589506016 Bolt, flange deep recess	Buy now

Starter




 6L54300-D040

*1:CUT FROM 50M ROLLS,PART NO.90790-77002,CUTTING LENGTH 1.65M
*1:A PRELEVER SUR BOBINE 50M ,REFERENCE 90790-77002,
LONGUEUR DE COUPE 1.65M

B3

Ref	Part	
16	6L51576100 Seal, rubber 1	Buy now
17	6L54267710 Graphic, front	Buy now
18	6L51575500 Handle, starter	Buy now
19	6L51577900 Cover	Buy now
20	6L51578900 Damper	Buy now
21	6H84279110 Mark 1	Buy now
22	6A18362541 Mark 5	Buy now
23	6A18362551 Mark 5	Buy now


Upper Casing & Bracket



C1

Ref	Part	
1	6L545111024D Casing, upper	Buy now
2	9360412M07 Pin, dowel (688)	Buy now
3	9709506030 Bolt(jf7)	Buy now
4	9299506600 Washer, plain (646)	Buy now
5	9370006M03 Nipple, grease(6a1)	Buy now
6	6L54515200 Cover, upper casing 2	Buy now
7	6L545115A0 Gasket,upper casing 3	Buy now
8	9014905M08 Ybs53-525 screw,flat head	Buy now
9	6474515101 Cover, upper casing	Buy now
10	6L543111014D Bracket Clamp 1	Buy now
11	6L543112004D Bracket Clamp 2	Buy now
12	6204311400 Pad, transom clamp	Buy now
13	6E04311601 Screw, transom clamp	Buy now
14	6E04311801 Handle, transom clamp	Buy now
15	9024304M01 Pin(6a1)	Buy now


Upper Casing & Bracket



C1

Ref	Part	
16	9010108M10 Bolt(6l5)	Buy now
17	6G14313600 Piece, friction	Buy now
18	6L54212100 Bracket	Buy now
19	9050816M30 Spring, torsion(6l5)	Buy now
20	9018508057 Nut, nylon (6j8)	Buy now
21	6A14311301 Plate, clamp bracket	Buy now
22	9038706M11 Collar	Buy now
23	9010106335 Bolt, hexagon (624)	Buy now
24	9299006600 Washer, plain (646)	Buy now
25	9538006600 Nut(661)	Buy now
26	6L543311014D Bracket, swivel 1	Buy now
27	6L544511004D Cover, upper mount	Buy now
28	6L544553004D Cover, lower mount	Buy now
29	9709506035 Bolt(j52)	Buy now
31	6E0433130094 Bracket, swivel 3	Buy now


Upper Casing & Bracket



C1

Ref	Part	
32	6204318900 Bushing	Buy now
33	9589506020 Bolt, flange(jk3)	Buy now
34	6L54318100 Lever, tilt stop 1	Buy now
35	6L54419600 Indicator 3	Buy now
36	6L54419700 Indicator 4	Buy now
37	9050816020 Spring 6474319800	Buy now
38	9050816021 Spring 6474318800	Buy now
39	6L54316000 Tilt rod assembly	Buy now
40	6L54361400 Plate, tilt lock	Buy now
41	9050808M26 Spring, torsion(6l5)	Buy now
42	9050808M27 Spring, torsion(6l5)	Buy now
43	6L54365900 Shaft, reverse lock	Buy now
44	9908005600 Circlip(22k)	Buy now
45	6L54253700 Bushing, pivot shaft	Buy now
46	6L54253800 Bushing, pivot shaft	Buy now

Upper Casing & Bracket



6L52110-3080

C1

Ref	Part	
47	6L54253900 Bushing, pivot shaft	Buy now
48	6L54254900 Bushing, pivot shaft	Buy now
49	6E04252803 Plate, friction	Buy now
50	6L54252901 Screw, friction piece	Buy now
51	6L54256100 Knob, steering lock	Buy now
52	9026604M05 Rivet(6l5)	Buy now
55	6L54331811 Cover	Buy now
56	9015906M10 Screw, with washer(6l5)	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.