



Yamaha 40YMHO 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


BOTTOM COWLING	3
BRACKET 1	7
BRACKET 2	11
BRACKET 3	13
BRACKET 4	16
CARBURETOR	19
CONTROL	25
CRANKSHAFT. PISTON	28
CYLINDER. CRANKCASE	30
ELECTRICAL 1	33
ELECTRICAL 2	35
ELECTRICAL 3	38
ELECTRICAL 4	39
FUEL	40
FUEL TANK	43
GENERATOR	44
INTAKE	46
LOWER CASING. DRIVE 1	49
LOWER CASING. DRIVE 2	55
METER 1	57
METER 2	58
OIL PUMP 1	59
OIL PUMP 2	62
POWER TRIM & TILT ASSY 1	66
POWER TRIM & TILT ASSY 2	71
REMOTE CONTROL ASSY	73
REMOTE CONTROL BOX	78
REPAIR KIT 1	79
REPAIR KIT 2	81
STARTER	83
STARTING MOTOR	86
STEERING	88
STEERING GUIDE	93
TOP COWLING	94
UPPER CASING	96

Bottom Cowling




Ref	Part	
1	6H4-42711-07-4D Cowling, bottom 1	Buy now
1	6H4-42711-25-4D Cowling, bottom	Buy now
2	6H4-42815-00 Lever, clamp 1	Buy now
3	90206-12052 Washer, wave (666)	Buy now
4	90386-12069 Bush(666)	Buy now
5	6H4-42816-00 Lever, clamp 2	Buy now
6	90119-06M73 Bolt(gh1)	Buy now
7	6H4-48531-11-94 Bracket, remote control 1	Buy now
8	6H4-48532-11-94 Bracket, remote control 2	Buy now
9	97095-05016 Bolt(6a1)	Buy now
10	92995-05600 Washer, plain (646)	Buy now
11	97095-06020 Bolt(7u8)	Buy now
12	92995-06600 Washer, plain (646)	Buy now
13	6H4-42724-00 Grommet	Buy now
13	6H4-42724-20 Grommet	Buy now

Bottom Cowling




Ref	Part	
14	6E5-44391-00 Nipple, hose	Buy now
15	6H4-42716-00 Rubber seal 1	Buy now
16	6E5-42724-00 Grommet	Buy now
17	90480-09M21 Grommet (6e9)	Buy now
18	90387-06M41 Collar (6e9)	Buy now
19	90119-06M61 Bolt, with washer	Buy now
20	63D-42741-00-4D Apron	Buy now
21	63D-42717-00 Rubber, seal 2	Buy now
22	97780-60525 Screw, tapping(65j)	Buy now
23	676-42726-00 Grommet 3	Buy now
23	6H4-42726-40 Grommet	Buy now
24	688-42726-10 Grommet	Buy now
24	6H4-42726-00 Grommet	Buy now
25	703-82119-00 Cover, lead wire	Buy now
25	90464-09M13 Clamp (6h1)	Buy now

Bottom Cowling




Ref	Part	
26	90157-06M01 Screw (6e5)	Buy now
26	90338-05M03 Plug (6h1)	Buy now
27	6E5-24367-01 Clamp, fuel pipe 2	Buy now
35	92990-06600 Washer, plain (646) 40V	Buy now
29	6H4-42725-00 Grommet 2	Buy now
29	6J8-85410-00 Emergency signal light assembly	Buy now
30	90464-08M07 Clamp	Buy now
31	6H4-85415-10 Mark, signal lamp	Buy now
32	63D-84342-00 Seat, emblem 40V	Buy now
33	6H4-83589-00 Gasket 40V	Buy now
34	97880-06014 Screw, pan head(6h2) 40V	Buy now
36	63D-84301-00 Pilot light assembly 1 40V	Buy now
36	6H3-42727-00 Grommet "ETO"-40Y	Buy now
37	6E5-82588-00 Plate	Buy now
40	6E7-42791-10 Mark 1 40V	Buy now

Bottom Cowling



Ref	Part	
40	6G5-42791-10 Mark 1 40Y	Buy now
41	6A1-28176-00 Label Caution	Buy now
42	6E3-8257H-00 Plate Mark	Buy now

Bracket 1




63D0100-1171

F2

Ref	Part	
1	63D-43111-01-4D Bracket, clamp 1	Buy now
2	63D-43112-01-4D Bracket, clamp 2	Buy now
3	63D-82148-00 Wire, lead 5	Buy now
4	97885-06008 Screw, pan head(6a3)	Buy now
5	63D-43128-01-4D Spacer, clamp bracket	Buy now
6	63D-45251-00 Anode	Buy now
7	97095-06025 Bolt	Buy now
8	92995-06100 Washer(6a1)	Buy now
9	6H1-82148-00 Wire, lead	Buy now
10	97095-06010 Bolt	Buy now
11	92995-06600 Washer, plain (646)	Buy now
12	63D-43311-03-4D Bracket, swivel 1 S	Buy now
12	63D-43311-13-4D Bracket, swivel 1 L	Buy now
13	93700-06M03 Nipple, grease(6a1)	Buy now
14	63D-43131-01 Bolt, clamp bracket	Buy now

Bracket 1




63D0100-1171

F2

Ref	Part	
15	90386-22M15 Bushing (688)	Buy now
16	90201-22M03 Washer, plate(64j)	Buy now
17	90185-22M11 Nut, self-locking	Buy now
18	6G5-43145-01 Cap, clamp bracket	Buy now
19	6H5-43181-03 Lever, tilt stop 1	Buy now
20	6H5-43185-03 Lever, tilt stop 2	Buy now
21	90386-10M16 Bushing (688)	Buy now
22	90386-10025 Bushing (658)	Buy now
23	91690-30020 Pin, spring (6h4)	Buy now
24	6G5-43148-00 Collar, distance	Buy now
25	90249-06M19 Pin(6e5)	Buy now
26	90506-14M24 Spring, tension(6e5)	Buy now
28	6G5-43144-00 Hook, spring	Buy now
29	688-43160-01 Tilt rod ass'y	Buy now
30	688-43165-00 Stopper, tilt rod	Buy now

Bracket 1




63D0100-1171

F2

Ref	Part	
31	91690-30012 Pin, spring	Buy now
32	90502-16M02 Spring, conical (688)	Buy now
33	6E5-43126-02 Pin, upper shock mount	Buy now
34	90386-18M92 Bush(62x)	Buy now
35	90386-18M35 Bush (688)	Buy now
36	93410-18M02 Circlip (6f2)	Buy now
37	90116-18M52 Bolt, stud(62x)	Buy now
38	90170-18M10 Nut (6h5)	Buy now
39	92995-18600 Washer(64j)	Buy now
40	90386-18M44 Bushing (6g5)	Buy now
41	90101-06020 Bolt	Buy now
42	65W-45251-00 Anode	Buy now
43	90101-12M65 Bolt	Buy now
44	92995-12200 Ybs66-12 washer,plain	Buy now
45	90201-12426 Washe, plate(663)	Buy now

Bracket 1




63D0100-1171

FWD

Ref	Part	
46	95380-12600 Nut (707)	Buy now
47	90440-14M00 Pipe(6h4)	Buy now
48	90465-11M10 Clamp	Buy now

F2

Bracket 2




63D0010-5200

F4

Ref	Part	
1	6H4-43111-05-4D Bracket, clamp 1	Buy now
2	6H4-43112-04-4D Bracket, clamp 2	Buy now
3	6E5-82148-00 Wire, lead 5	Buy now
4	97885-06008 Screw, pan head(6a3)	Buy now
5	6E0-43118-01 Handle, transom clamp	Buy now
6	90243-04M01 Pin(6a1)	Buy now
7	90149-14M12 Screw(6h4)	Buy now
8	648-43114-01 Pad, transom clamp	Buy now
9	63D-43131-01 Bolt, clamp bracket	Buy now
10	90386-22M69 Bush(6k9)	Buy now
11	6J8-43113-01 Plate, clamp bracket	Buy now
12	90201-22M03 Washer, plate(64j)	Buy now
13	90185-22M11 Nut, self-locking	Buy now
14	6G5-43145-01 Cap, clamp bracket	Buy now
15	90101-08339 Bolt, hexagon (656)	Buy now

Bracket 2




63D0010-5200

F4

Ref	Part	
16	90387-08M03 Collar	Buy now
17	92990-08600 Washer, plain (663)	Buy now
18	95380-08600 Nut (661)	Buy now
19	6J8-43311-04-4D Bracket, swivel S	Buy now
19	6J8-43311-10-4D Bracket, swivel 1 L	Buy now
20	93700-06M03 Nipple, grease(6a1)	Buy now
21	6J8-42528-00 Plate, friction	Buy now
22	689-43373-01 Seal, damper	Buy now
23	90105-06M18 Bolt (689)	Buy now
24	90101-10M58 Bolt	Buy now
25	92995-10600 Washer, plate	Buy now
26	90201-12426 Washer, plate(663)	Buy now
27	95380-10600 Nut(624)	Buy now


Bracket 3



F6


Ref	Part	
1	6H4-43160-01 Tilt rod assembly	Buy now
2	676-43165-00 Stopper plate, titl lock rod	Buy now
3	91690-30010 Pin, spring (663)	Buy now
4	90502-10M04 Spring, conical(6f5)	Buy now
5	6J8-43181-01 Lever, tilt stop 1	Buy now
6	90506-12M25 Spring, tension(6h4)	Buy now
7	90249-12M28 Pin(6h4)	Buy now
8	93430-10M00 Circlip	Buy now
9	90202-12031 Washer, plate 6484412600	Buy now
10	682-43318-01 Cover	Buy now
11	6J8-43627-00 Stopper	Buy now
12	90249-12M27 Pin(6f6)	Buy now
15	90206-12M16 Washer, wave(6j8)	Buy now
16	6J8-43614-00 Plate, tilt lock	Buy now
17	6J8-43615-00 Plate, tilt lock	Buy now

Bracket 3



Ref	Part	
18	6J8-43613-01 Arm, tilt lock	Buy now
19	6H4-43659-00 Shaft, reverse lock	Buy now
20	6J8-43611-01 Shaft, tilt lock	Buy now
21	90387-07M64 Collar (6h4)	Buy now
22	93430-06M02 Circlip (689)	Buy now
46	99080-05600 Circlip(22k) AP	Buy now
24	90506-32M22 Spring, tension(6j8)	Buy now
25	6H4-43674-00 Washer 2 WITHOUT SHALLOW	Buy now
26	91490-20010 Pin, cotter	Buy now
27	6J8-43631-00 Lever, tilt	Buy now
38	6J8-43633-00 Cover, tilt lever AP	Buy now
29	90508-18M23 Spring, torsion(6h4) AP FOR SHALLOW	Buy now
29	90508-18M24 Spring, torsion(6h4)	Buy now
39	6H4-43616-00 Rod, tilt lock 1 AP	Buy now
40	6J8-43641-00 Lever, tilt AP	Buy now


Bracket 3



F6


Ref	Part	
32	90249-06M23 Pin(6e7)	Buy now
32	90249-06M24 Pin(6h4) AP FOR SHALLOW	Buy now
33	6J8-43617-00 Rod, tilt lock	Buy now
35	6J8-43681-01 Lever, shallow water drive AP	Buy now
36	6J8-43673-00 Washer 1 AP	Buy now
37	6J8-43631-10 Lever, tilt AP	Buy now
41	6J8-43617-10 Rod, tilt lock AP	Buy now
42	6J8-43186-00 Lever AP	Buy now
43	6J8-43187-00 Lever 2 AP	Buy now
44	90508-25M21 Spring, torsion(6h4) AP	Buy now
45	90249-07M25 Pin(6h4) AP	Buy now
47	6J8-41262-00 Joint, choke lever AP	Buy now
48	6J8-43616-10 Rod, tilt lock AP	Buy now
49	90508-20M22 Spring, torsion(6h4) AP	Buy now

Bracket 4



Ref	Part	
1	63B-42510-00-4D Steering bracket assembly S	Buy now
1	63B-42510-10-4D Steering bracket assembly L	Buy now
1	63D-42510-01-4D Steering bracket assembly S	Buy now
1	63D-42510-11-4D Steering bracket assembly L	Buy now
2	90201-30M00 Washer, plate(6h1)	Buy now
3	90386-30M78 Bush(6h0)	Buy now
4	90386-30M77 Bush(6h0)	Buy now
5	93210-29M94 O-ring(6h1)	Buy now
6	90386-30M60 Bush(6j8)	Buy now
7	90116-10175 Bolt, stud	Buy now
8	90185-10051 Nut, self-locking	Buy now
9	63D-44551-01-4D Housing, lower mount rubber 1	Buy now
10	93410-28M06 Circlip (688)	Buy now
11	63D-44555-00-94 Mount damper, lower side L	Buy now
11	687-44555-00-94 Mount damper, lower side S	Buy now


Bracket 4



A4

Ref	Part	
12	90201-12M16 Washer, plate (679)	Buy now
13	90202-25M04 Washer, plate (663)	Buy now
14	90201-13M19 Washer, plate (663)	Buy now
15	90109-12M21 Bolt (6h3)	Buy now
16	663-44575-00 Damper, lower mount rubber	Buy now
17	95380-12800 Nut crown(663)	Buy now
18	63D-44552-01-4D Housing, lower mount rubber	Buy now
19	97075-08030 Bolt, hexagon (fj1)	Buy now
20	92995-08100 Ybs67-8 washer, spring	Buy now
21	63D-82127-00 Wire, lead 2 S	Buy now
21	63D-82127-10 Wire, lead 2 L	Buy now
22	63D-44514-01-94 Mount damper, upper side	Buy now
23	90101-08M15 Bolt	Buy now
24	63D-44526-00 Plate	Buy now
25	90201-09425 Washer, plate (663)	Buy now


Bracket 4



A4


Ref	Part	
26	90185-08045 Nut, self-locking	Buy now
29	90465-06M86 Clamp	Buy now
30	90465-11M10 Clamp	Buy now
31	90445-07MF1 Hose (I570)	Buy now
32	6E5-83558-00 End, nipple	Buy now
33	63D-83672-01 Trim sender	Buy now
34	97885-06016 Screw, pan head(6b0)	Buy now
35	90465-13M11 Clamp (6e5)	Buy now
36	63D-48511-00-4D Hook, steering STEERING GUIDE	Buy now
37	703-82119-00 Cover, lead wire	Buy now

Carburetor




Ref	Part	
1	62W-14301-00 Carburetor assembly 1 40Y	Buy now
1	62X-14301-00 Carburetor assembly 1 40Y	Buy now
1	63B-14301-00 Carburetor assembly 1 40V	Buy now
1	63D-14301-00 Carburetor assembly 1 40V	Buy now
2	62W-14302-00 Carburetor assembly 2 40Y	Buy now
2	62X-14302-00 Carburetor assembly 2 40Y	Buy now
2	63B-14302-00 Carburetor assembly 2 40V	Buy now
2	63D-14302-00 Carburetor assembly 2 40V	Buy now
3	62W-14303-00 Carburetor assembly 3 40Y	Buy now
3	62X-14303-00 Carburetor assembly 3 40Y	Buy now
3	63B-14303-00 Carburetor assembly 3 40V	Buy now
3	63D-14303-00 Carburetor assembly 3 40V	Buy now
4	97980-04114 Screw, pan head(ga5)	Buy now
5	6K5-14592-00 Screw	Buy now
6	90201-05652 Washer, plate(65j)	Buy now

Carburetor




Ref	Part	
7	63V-14523-00 Screw, stop #2	Buy now
8	90501-10326 Spring coil(663)(carb) #2	Buy now
9	6H2-14578-00 Collar #3	Buy now
10	6H4-14548-00 Pin, float arm	Buy now
11	98580-04008 Screw, pan head (713)	Buy now
12	663-14159-00 Clip	Buy now
13	676-14186-00 Pin, valve	Buy now
14	6H4-14985-01 Float	Buy now
15	6H4-14146-10 Plate #1,3	Buy now
16	6H3-14146-10 Plate #2	Buy now
16	6H4-14146-00 Plate #2	Buy now
17	6H4-14984-00 Gasket, float chamber	Buy now
18	6H3-14980-10 Body, float chamber #2	Buy now
18	6H4-14980-00 Body, float chamber #1,3	Buy now
19	6H3-14992-00 Screw, drain	Buy now

Carburetor




B3

Ref	Part	
20	93210-04230 O-ring (371)	Buy now
21	62W-14947-00 Jet, needle 40Y	Buy now
21	62X-14947-00 Jet, needle 40Y	Buy now
21	63D-14947-00 Jet, needle 40V	Buy now
22	63D-14943-81 Jet, main (#118) 40V-#2	Buy now
22	676-14943-30 Jet, main (#115) 40V-#1,3	Buy now
22	676-14943-32 Jet, main (#125) 40Y	Buy now
22	676-14943-33 Jet, main (#130) 40Y	Buy now
23	676-14966-00 Rubber cap	Buy now
24	62X-14948-12 Jet (#62) 40Y	Buy now
24	6H4-14948-11 Jet (#60) 40V	Buy now
25	679-14555-00 Spring	Buy now
26	692-14923-00 Screw, adjusting	Buy now
27	6H4-14590-00 Needle valve assembly	Buy now
28	93210-04228 O-ring (371)	Buy now



Ref	Part	
29	6H3-24452-10 Cover #2	Buy now
30	6H4-14147-00 O-ring	Buy now
31	6H4-14567-00 Screw #2	Buy now
32	6H3-14137-00 Clip #2	Buy now
33	6H3-14349-00 Pipe #2	Buy now
34	63D-14380-00 Prime starter assembly #2	Buy now
35	97803-04010 Screw, pan head (e56) #2	Buy now
36	95380-03600 Nut (6g8) #2	Buy now
37	98980-03006 Screw, bind(6g1) #2	Buy now
38	6L5-24421-00 Valve, check #2	Buy now
39	6H4-24413-00 Body 2 #2	Buy now
40	6H4-24486-00 O-ring #2	Buy now
41	6H3-24411-10 Diaphragm #2	Buy now
42	6H3-24434-10 Gasket, body #2	Buy now
43	97013-06012 Bolt(gh1)	Buy now


Carburetor



Ref	Part	
44	92903-06600 Washer, plain (646)	Buy now

B3

Control




63B2300-3180

E7

Ref	Part	
1	6H4-48344-00 Cable end, remote control	Buy now
2	90468-18008 Clip 620436610000	Buy now
3	63D-41213-00 Cam, accel. 40V	Buy now
3	68P-41213-A0 Cam Accel. 40Y	Buy now
4	90109-06M43 Bolt(6h4)	Buy now
5	63D-41632-00 Lever, magneto control	Buy now
6	90508-26M35 Spring, torsion	Buy now
7	63D-41636-00 Rod, magneto control	Buy now
8	6H4-41237-00 Joint, link	Buy now
9	95380-05600 Nut, hexagon (663)	Buy now
10	90157-06M13 Screw, pan head(6h4)	Buy now
11	95303-06600 Nut(661)	Buy now
12	688-44194-00 Cap	Buy now
13	63D-44120-00 Handle gear shift assembly S	Buy now
13	63D-44120-10 Handle gear shift assembly L	Buy now

Control





63B2300-3180

E7

Ref	Part	
15	90202-07M07 Washer, plate (688)	Buy now
16	63D-44117-00 Bracket	Buy now
17	93501-04M02 Ball (697)	Buy now
18	90501-12082 Spring 6484411600	Buy now
19	648-42715-00 Bushing 2	Buy now
20	97013-06020 Bolt(62y)	Buy now
21	92903-06600 Washer, plain (646)	Buy now
22	97013-06045 Bolt, hexagon	Buy now
24	63D-44121-00 Lever, shift rod	Buy now
25	90386-07M58 Bush(6h1)	Buy now
26	92990-08200 Ybs66-8 washer, plain	Buy now
27	91490-20012 Pin, cotter (648)	Buy now
28	688-44122-00 Bushing, shift rod lever	Buy now
29	63D-48344-00 Cable end, remote control	Buy now
29	663-48344-00 Cable end, remote control	Buy now

Control





63B2300-3180

E7


Ref	Part	
30	63D-15774-00 Stay 4	Buy now
31	97095-06016 Bolt, hexagon deep recess	Buy now
32	92995-06600 Washer, plain (646)	Buy now

Crankshaft. Piston




Ref	Part	
1	6H4-15369-A1 Gasket, oil seal housing	Buy now
2	6H4-15396-03-5B Housing, oil seal	Buy now
3	93102-25M28 Oil seal(6h4)	Buy now
4	93104-16M01 Oil seal(6a8)	Buy now
5	93210-58M21 O-ring (683)	Buy now
6	97095-06020 Bolt(7u8)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	6H4-11400-14 Crankshaft assembly	Buy now
9	6H4-11536-00 Gear, drive	Buy now
10	93306-305U8 Bearing(6h4)	Buy now
11	93440-62057 Cir clip (656)	Buy now
12	90201-50306 Washer plate 648115870000	Buy now
13	6H4-11631-01-95 Piston (std)	Buy now
13	6H4-11635-01 Piston (0.25mm o/s) AP	Buy now
13	6H4-11636-01 Piston (0.50mm o/s) AP	Buy now

Crankshaft. Piston




Ref	Part	
14	63D-11603-00 Piston ring set (std)	Buy now
14	63D-11604-00 Piston ring set (0.25mm o/s) AP	Buy now
14	63D-11605-00 Piston ring set (0.50mm o/s) AP	Buy now
15	648-11633-00 Pin,piston	Buy now
16	93602-20M02 Pin, dowel b (664)	Buy now
17	6H4-11641-00 Washer, piston pin	Buy now
18	6H4-11634-01 Clip, piston pin	Buy now

Cylinder. Crankcase




Ref	Part	
3	650-11370-01 Check valve assembly	Buy now
4	624-14485-00 Pipe, joint	Buy now
5	6H4-11372-01 Nipple, hose	Buy now
7	688-11370-01 Check valve assembly	Buy now
8	650-24378-00 Pipe, joint 2 EO SPEC	Buy now
9	90119-08019 Bolt, with washer	Buy now
10	90119-06M13 Bolt, with washer (682)	Buy now
11	93606-12019 Pin, dowel (614)	Buy now
12	90445-07M46 Hose (I390)	Buy now
13	90445-07M27 Hose (I390)	Buy now
14	90445-07M24 Hose (I390)	Buy now
15	90467-06016 Clip (655)	Buy now
16	90445-07MA3 Hose (I200)	Buy now
18	6H4-11119-01 Hanger, engine	Buy now
19	90101-06021 Bolt	Buy now

Cylinder. Crankcase




Ref	Part	
20	688-11325-00 Anode	Buy now
21	98780-04016 Screw, flat head(ga5)	Buy now
23	63D-11181-A1 Gasket, cylinder head 1	Buy now
24	90340-14M00 Plug, straight screw(62y)	Buy now
25	90430-14115 Gasket (663)	Buy now
26	63D-11191-00-1S Cover, cylinder head 1	Buy now
27	63D-11193-A0 Gasket, head cover 1	Buy now
28	90119-08015 Bolt, with washer	Buy now
29	90119-06MA3 Bolt, with washer	Buy now
30	6E5-12411-30 Thermostat	Buy now
31	6H4-12413-00-1S Cover, thermostat	Buy now
32	6J8-12414-A0 Gasket, cover	Buy now
34	6H4-41113-00-1S Outer cover, exhaust	Buy now
35	6H4-41111-00-1S Inner cover, exhaust	Buy now
36	6H4-41112-A0 Gasket, exhaust inner cover	Buy now

Cylinder. Crankcase




Ref	Part	
37	6H4-41114-A0 Gasket, exhaust outer cover	Buy now
38	90445-09M37 Hose (I1500)	Buy now
39	90467-08004 Clip, pipe 6162435600	Buy now
40	90119-06MA5 Bolt, with washer	Buy now
41	94702-00247 Plug, spark (br8hs-10) 40Y	Buy now
41	94702-00271 Plug, spark (br7hs-10) 40V	Buy now

Electrical 1




Ref	Part	
1	63D-85540-03 C.d.i. unit assembly	Buy now
2	90119-06M51 Bolt, with washer(6h4)	Buy now
3	90464-15M11 Clamp (3y2)	Buy now
4	703-82119-00 Cover, lead wire	Buy now
5	97095-06014 Bolt(gj3)	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	6H5-85570-00 Ignition coil assembly	Buy now
8	90480-25161 Grommet(656)	Buy now
9	97095-06020 Bolt(7u8)	Buy now
11	6G1-82370-21 Plug cap assembly	Buy now
12	689-82560-00 Thermo switch assembly	Buy now
13	6H4-82560-00 Thermo switch assembly	Buy now
14	6H4-81822-02-98 Bracket, starting motor	Buy now
15	97095-06030 Bolt(jf7)	Buy now
17	97013-08050 Bolt, hexagon	Buy now

Electrical 1



Ref	Part	
18	92903-08600 Washer, plain (663)	Buy now
19	95670-06640 Bolt, stud(6h4)	Buy now
20	90179-06M24 Nut(6j8)	Buy now
23	63D-82531-00 Wire, lead	Buy now
24	90446-10M02 Tube (6e5)	Buy now
25	6G1-83557-00 Tube	Buy now
26	90464-05M16 Clamp(6j8)	Buy now


Electrical 2



D3


Ref	Part	
1	63D-82105-U0 Battery cable 40Y	Buy now
1	6H4-82105-02 Battery cable 40V	Buy now
2	6G1-81941-10 Starter relay	Buy now
3	6H4-81952-00 Holder, relay	Buy now
4	6H4-81945-00 Plate, switch fitting	Buy now
5	90116-06M22 Bolt, stud (6h1)	Buy now
6	95380-06600 Nut(661)	Buy now
7	92990-06600 Washer, plain (646)	Buy now
8	6H2-81960-10 Rectifier & regulator assembly	Buy now
9	6H4-82150-00 Fuse holder assembly	Buy now
10	663-82151-00 Fuse	Buy now
11	97095-06014 Bolt(gj3)	Buy now
12	92995-06600 Washer, plain (646)	Buy now
13	90464-15M27 Clamp(6h4)	Buy now
14	90338-05M11 Plug(6h4)	Buy now

Electrical 2



Ref	Part	
15	63D-82594-00 Clamp	Buy now
16	97095-06012 Bolt(gh1)	Buy now
18	63D-82590-10 Wire harness assembly	Buy now
18	63D-82590-20 Wire harness assembly	Buy now
19	6H1-81950-00 Relay aasy	Buy now
20	97095-06025 Bolt	Buy now
22	6H4-81945-20 Plate, switch fitting	Buy now
23	90480-13M24 Grommet (6e9)	Buy now
24	90387-06M05 Collar(6h4)	Buy now
25	90105-06M15 Bolt (6e0)	Buy now
26	90105-06M16 Bolt (6e0)	Buy now
27	6H5-81949-00 Wire, lead	Buy now
28	61A-81949-00 Wire, lead	Buy now
29	682-82119-01 Cover, lead wire	Buy now
30	90464-07M20 Clamp(6h0)	Buy now


Electrical 2



D3

Ref	Part	
31	6H4-82117-00 Wire, lead	Buy now
32	63D-82563-10 Trim & tilt switch assembly	Buy now
33	6E5-82587-00 Gasket	Buy now
34	6R3-83614-00 Bracket	Buy now
35	97095-06016 Bolt, hexagon deep recess	Buy now

Electrical 3




63B0300-5130

D5

Ref	Part	
1	6J8-81960-00 Rectifier & regulator assembly 40V	Buy now
2	97095-06012 Bolt(gh1) 40V	Buy now
3	92995-06600 Washer, plain (646) 40V	Buy now
4	6H4-81975-02 Plate, rectifier fitting 40V	Buy now
5	97013-06012 Bolt(gh1) 40V	Buy now
6	6F5-81922-00 Grommet 1 40V	Buy now
7	90464-12M35 Clamp(6h4) 40V	Buy now
8	90440-14M00 Pipe(6h4) 40V	Buy now
9	682-84381-00 2p concent 1 40V	Buy now
10	90202-26M45 Washer, plate(6h4) 40V	Buy now

Electrical 4





63B0100-0140

D6


Ref	Part	
1	6K5-82575-03 Engine stop switch assembly	Buy now
2	682-82556-00 Lanyard, stop switch	Buy now
3	689-8257Y-00 Cap	Buy now

Fuel




Ref	Part	
1	6G1-24304-02 Fuel pipe joint comp. 1	Buy now
2	97095-06025 Bolt	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	90467-08004 Clip, pipe 6162435600	Buy now
5	61N-24560-00 Filter assembly	Buy now
6	61N-24563-00 Element, filter	Buy now
7	61N-24521-00 Cup, filter	Buy now
8	93210-32738 O-ring(1wg)	Buy now
9	6H4-24566-02 Bracket, filter	Buy now
10	97013-06014 Bolt(gj3)	Buy now
11	95380-08600 Nut (661)	Buy now
12	6H4-24314-00 Pipe 4	Buy now
14	692-24410-00 Fuel pump assembly	Buy now
15	6A0-24413-00 Cover, pump	Buy now
16	692-24411-00 Diaphragm	Buy now

Fuel



Ref	Part	
17	648-24434-01 Gasket, body	Buy now
18	95380-03600 Nut (6g8)	Buy now
19	663-24411-00 Diaphragm	Buy now
20	648-24435-02 Gasket, body 2	Buy now
21	98503-05028 Ybs86-530 screw,panhead	Buy now
22	92990-05100 Ybs67-5 washer, spring	Buy now
23	6A0-24421-01 Valve, check	Buy now
24	6A0-14325-00 Screw, pan head	Buy now
25	6A0-24412-02 Body 1	Buy now
26	650-24431-A0 Gasket,fuel pump	Buy now
27	97095-06040 Bolt (682)	Buy now
29	90445-09063 Hose (11500)	Buy now
30	688-24378-00 Pipe, joint	Buy now
31	90445-09057 Hose (1180)	Buy now
32	6H4-24313-00 Pipe 3	Buy now


Fuel



C3


Ref	Part	
33	6H4-24312-00 Pipe, fuel 2	Buy now
35	6H4-24311-00 Pipe 1	Buy now
36	90464-15M11 Clamp (3y2)	Buy now
37	656-W2810-02 Tool kit	Buy now
38	6E0-28193-00-94 Plug, water check AP D)12.5MM	Buy now
39	63B-28199-77-A0 O/m 40veo/vmho/veto/yeto/50'03 UR (E,F,S)	Buy now
39	63B-28199-77-B0 O/m 40veo/vmho/veto/yeto/50'03 UR (D,NL,I)	Buy now
40	63B-28199-87-A0 O/m 40veo/veto/vmho/yeto/ '03 UR (DK,P,GR)	Buy now
40	63B-28199-87-B0 O/m 40veo/veto/vmho/yeto/ '03 UR (N,S,SS)	Buy now

Fuel Tank



Ref	Part	
1	6YK-24201-01 Fuel Tank assembly (25L) AP PLASTIC, 25L,	Buy now
2	6YL-24268-01 Gasket, fuel meter	Buy now
3	6YK-24610-00 Cap assembly WITH INDICATOR	Buy now
4	6YL-24641-00 Gasket, cap 1	Buy now
5	6YK-24260-01 Fuel meter assembly	Buy now
6	90157-05M16 Screw, pan head	Buy now
7	6YL-24329-00 Seal	Buy now
8	6YL-24306-52 Fuel pipe comp. 1 AP	Buy now


Generator



C7


Ref	Part	
1	63D-85550-00 Rotor assembly	Buy now
1	63D-85550-10 Rotor assembly	Buy now
2	63D-85560-00 Base assembly	Buy now
2	63D-85560-10 Base assembly	Buy now
3	6H4-15359-04-94 Housing, oil seal	Buy now
4	63D-85520-00 Coil, charge	Buy now
5	63D-85533-00 Coil, lighting	Buy now
5	63D-85533-10 Coil, lighting	Buy now
6	63D-85580-00 Coil, pulser	Buy now
7	6H4-83354-00 Wire, earth lead 1	Buy now
8	63D-81345-00 Screw, pan	Buy now
9	63D-81345-10 Screw, pan head (76t)	Buy now
10	63D-81345-20 Screw, pan	Buy now
11	90464-03M15 Clamp(6j8)	Buy now
12	93102-23096 Oil seal (23x38x7-648)	Buy now

Generator




Ref	Part	
13	703-82119-00 Cover, lead wire 40V	Buy now
14	6H4-11545-00 Key, woodruff	Buy now
15	90179-16M05 Nut (689)	Buy now
16	90201-16M44 Washer (689)	Buy now
17	6H4-81332-00 Plate, timing	Buy now
18	97885-05010 Screw, pan head(62x)	Buy now
19	92995-05600 Washer, plain (646)	Buy now
20	97013-06018 Bolt, hexagon	Buy now
21	92903-06600 Washer, plain (646)	Buy now

Intake




Ref	Part	
1	6H5-13610-00 Reed valve assembly	Buy now
2	6H4-W0004-00 Reed set	Buy now
3	97880-05014 Screw, pan head(3yl)	Buy now
4	92990-05600 Washer, plain (646)	Buy now
5	6H4-13641-12-94 Manifold 1	Buy now
5	6H4-13641-30-94 Manifold 1	Buy now
6	6H1-14485-00 Pipe, joint	Buy now
7	6H4-13624-01-94 Plate, reed valve	Buy now
8	6H4-13621-A1 Gasket, valve seat	Buy now
9	90119-06MA2 Bolt, with washer	Buy now
10	6H4-14198-01 Gasket	Buy now
11	6H4-14406-00 Hinge	Buy now
12	97095-06095 Bolt, hexagon deep recess	Buy now
13	6H4-14431-02 Silencer, intake 1	Buy now
13	6H4-14431-13 Silencer, intake 1	Buy now

Intake



Ref	Part	
14	6H3-14457-01 Seal	Buy now
15	97885-06040 Screw pan head	Buy now
16	97885-06055 Screw, panhead (gc2)	Buy now
17	90209-06M05 Washer (688)	Buy now
18	6H4-41257-00 Rod, choke link 2	Buy now
19	661-41262-02 Joint, choke lever	Buy now
20	6H4-41271-01 Knob, choke	Buy now
21	6H4-41259-01 Rod, choke 3	Buy now
22	6J8-41262-00 Joint, choke lever	Buy now
23	6J8-41274-00 Grommet 2	Buy now
24	6H4-41217-01 Rod, accel. lever	Buy now
25	689-41273-00 Grommet	Buy now
25	6G1-42748-00 Grommet	Buy now
26	90464-06M19 Clamp(6h4)	Buy now
27	90445-07MA5 Hose (I200)	Buy now


Intake



B1


Ref	Part	
28	90467-06016 Clip (655)	Buy now
29	6H3-14349-00 Pipe	Buy now
30	90467-08004 Clip, pipe 6162435600	Buy now
31	6A1-83625-41 Mark 5	Buy now
32	6A1-83625-51 Mark 5	Buy now
33	6H1-85711-60 Mark, caution	Buy now

Lower Casing. Drive 1



Ref	Part	
1	63D-45300-02-4D Lower unit assembly S	Buy now
1	63D-45300-12-4D Lower unit assembly L	Buy now
2	63D-45301-03-4D Casing, lower	Buy now
3	93315-32224 Brg,cyl-cal roller 42.2g nk	Buy now
4	6H4-45536-00 Sleeve, drive shaft	Buy now
5	663-45587-01-10 Shim (t:0.10mm) UR	Buy now
5	663-45587-01-12 Shim (t:0.12mm) UR	Buy now
5	663-45587-01-15 Shim (t:0.15mm) UR	Buy now
5	663-45587-01-18 Shim (t:0.18mm) UR	Buy now
5	663-45587-01-30 Shim (t:0.30mm) UR	Buy now
5	663-45587-01-40 Shim (t:0.40mm) UR	Buy now
5	663-45587-01-50 Shim (t:0.50mm) UR	Buy now
6	93332-00001 Brg, tapered roller (409)	Buy now
7	90340-08002 Plug, straight screw	Buy now
8	90430-08020 Gasket	Buy now


Lower Casing. Drive 1



B4

Ref	Part	
9	688-45341-10 Plug, drain	Buy now
10	63D-45214-00 Cover, water inlet	Buy now
11	63D-45215-00 Cover, water inlet	Buy now
12	90142-05M06 Screw, countersunk	Buy now
13	95380-05600 Nut, hexagon (663)	Buy now
14	63D-45321-00 Plate	Buy now
15	93106-09014 Oil seal	Buy now
16	93210-33MG4 O-ring	Buy now
17	6E5-45378-00 Nipple, hose	Buy now
18	90445-07M31 Hose (I200) L	Buy now
18	90445-07ME9 Hose (I250) S	Buy now
19	6E5-83558-10 End, nipple	Buy now
19	6E5-83558-00 End, nipple	Buy now
20	90465-11M10 Clamp	Buy now
21	63D-44311-00 Housing, water pump	Buy now


Lower Casing. Drive 1



B4


Ref	Part	
22	63D-44322-00 Insert, cartridge	Buy now
23	6H3-44352-00 Impellar	Buy now
24	93210-59MG7 O-ring	Buy now
25	90280-03024 Key, woodruff(662)	Buy now
26	63D-44323-00 Outer plate, cartridge	Buy now
27	63D-44316-00 Gasket, water pump	Buy now
28	93604-08062 Pin,dowel (626)	Buy now
29	90119-08M15 Bolt, with washer(62w)	Buy now
30	63D-W4434-00 Water pump housing assembly	Buy now
31	63D-44341-00 Housing, water pump set	Buy now
32	93101-25M57 Oil seal	Buy now
33	93210-48MG8 O-ring	Buy now
34	63D-45344-00 Cover, oil seal	Buy now
35	90201-27M00 Washer, plate(62x)	Buy now
36	63D-45501-00 Drive shaft comp. S	Buy now

Lower Casing. Drive 1




Ref	Part	
36	63D-45501-10 Drive shaft comp. L	Buy now
37	6H4-45551-01 Pinion	Buy now
38	90170-12138 Nut hexagon(663)	Buy now
39	6H4-45560-01 Gear	Buy now
40	93332-00003 Brg,cyl-cal roller 318g ky	Buy now
41	663-45567-01-10 Shim (t:0.10mm) UR	Buy now
41	663-45567-01-12 Shim (t:0.12mm) UR	Buy now
41	663-45567-01-15 Shim (t:0.15mm) UR	Buy now
41	663-45567-01-18 Shim (t:0.18mm) UR	Buy now
41	663-45567-01-30 Shim (t:0.30mm) UR	Buy now
41	663-45567-01-40 Shim (t:0.40mm) UR	Buy now
41	663-45567-01-50 Shim (t:0.50mm) UR	Buy now
42	6H4-45571-01 Gear	Buy now
43	63D-45361-02-4D Cap, lower casing	Buy now
44	90105-08M61 Bolt, washer based(62x)	Buy now

Lower Casing. Drive 1



Ref	Part	
45	93306-001U1 Bearing(62x)	Buy now
46	63D-45577-00-10 Shim (t:0.10mm) UR	Buy now
46	63D-45577-00-12 Shim (t:0.12mm) UR	Buy now
46	63D-45577-00-15 Shim (t:0.15mm) UR	Buy now
46	63D-45577-00-18 Shim (t:0.18mm) UR	Buy now
46	63D-45577-00-30 Shim (t:0.30mm) UR	Buy now
46	63D-45577-00-40 Shim (t:0.40mm) UR	Buy now
46	63D-45577-00-50 Shim (t:0.50mm) UR	Buy now
47	93210-74MG5 O-ring (xea)	Buy now
48	93210-69MG6 O-ring	Buy now
49	93317-22204 Brg,cyl-cal roller 25.5g nt	Buy now
50	93101-22M00 Oil seal (22x36x6-663)	Buy now
51	663-44151-00 Cam, shift	Buy now
52	63D-44144-00 Rod, shift	Buy now
53	93210-07003 O-ring (11m)	Buy now


Lower Casing. Drive 1



B4


Ref	Part	
54	99001-08600 Circlip(2r6)	Buy now
55	63D-45611-00 Shaft, propeller	Buy now
56	90201-22429 Washer, plate(663)	Buy now
57	63D-45631-01 Clutch, dog	Buy now
58	663-45634-00 Slide, shift	Buy now
59	90501-16M01 Spring compression	Buy now
60	63D-45635-00 Plunger, shift	Buy now
61	90250-06023 Pin, strait (663)	Buy now
62	663-45633-00 Ring, cross pin	Buy now

Lower Casing. Drive 2



Ref	Part	
1	63D-44361-00 Tube, water S	Buy now
1	63D-44361-10 Tube, water L	Buy now
2	90202-12060 Washer, plate(663)	Buy now
3	90430-12072 Gasket	Buy now
4	63D-44367-00 Damper, water seal	Buy now
5	663-45376-00-94 Guide, seal damper	Buy now
6	63D-45375-00 Damper, seal	Buy now
7	93606-12019 Pin, dowel (614)	Buy now
8	97075-10040 Bolt, hexagon deep recess	Buy now
9	92995-10100 Ybs67-10 washer, spring	Buy now
10	92995-10600 Washer, plate	Buy now
11	90119-08M84 Bolt, with washer	Buy now
12	664-45371-01 Tab-trim	Buy now
13	97095-08025 Bolt (62g)	Buy now
14	92995-08100 Ybs67-8 washer, spring	Buy now

Lower Casing. Drive 2





63D0100-0241

C1

Ref	Part	
15	67C-45251-00 Anode	Buy now
16	97095-08035 Bolt(70w)	Buy now
18	663-44366-00 Damper, water seal 2	Buy now
19	63D-44312-00 Cover, water pump housing	Buy now
20	663-45987-02 Spacer	Buy now
21	670-45997-02 Spacer	Buy now
22	92990-16200 958-58204-00 washer,plain	Buy now
23	90171-16011 Nut, castle (663)	Buy now
24	91490-30025 Pin cotter	Buy now
25	663-45941-01-EL Propeller (3x10-3/4"x17"-g) UR	Buy now
25	663-45949-01-EL Propeller (3x10-3/4"x16"-g) UR	Buy now

Meter 1




63B0700-1330

D2

Ref	Part	
1	6Y5-83670-12 Trim meter assembly. AP 40V	Buy now
2	6Y5-83518-00 Bulb (12v-1.7w) t6.5	Buy now
3	6Y5-83536-00 Socket, meter	Buy now
4	6Y5-83544-00 Plate, fitting	Buy now
5	688-83664-00 Damper	Buy now
6	6Y5-83553-00 Wire, lead (l=2.5m) AP 40V	Buy now
7	1E6-82151-00 Fuse (10a)	Buy now
8	6R3-82553-70 Extension, wire lead (for trim AP 40V 4P,7M	Buy now

Meter 2




6H30100-0270

D3


Ref	Part	
1	6Y5-8350T-02 Digital tachometer assembly AP 40Y	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83553-00 Wire, lead (l=2.5m) AP 40Y	Buy now
7	1E6-82151-00 Fuse (10a)	Buy now
8	6R3-82521-70 Wire, lead (for tacho., 7m) AP 40Y 7M	Buy now
9	6R3-82553-70 Extension, wire lead (for trim AP 40Y 4P,7M	Buy now
10	6H4-81315-11 Lead wire assembly AP 40Y	Buy now

Oil Pump 1




Ref	Part	
1	63D-13200-00 Oil injection pump assembly	Buy now
2	93210-19MA7 O-ring(6r0)	Buy now
3	90201-08M93 Washer, plate (6g5)	Buy now
4	6H4-11537-01 Gear, driven	Buy now
5	6H1-13117-01 Collar, distance	Buy now
6	93210-13M04 93210-13m04	Buy now
7	90109-06M39 Bolt(6h0)	Buy now
8	90109-06M40 Bolt(6h0)	Buy now
9	90445-07M44 Hose (I390)	Buy now
10	90445-07M23 Hose (I570)	Buy now
11	90445-07MA6 Hose (I200)	Buy now
12	90468-07M02 Clip (6e5)	Buy now
14	90464-07M20 Clamp(6h0)	Buy now
15	6H4-41241-01 Rod, link	Buy now
16	6H1-41237-00 Joint, link	Buy now

Oil Pump 1



Ref	Part	
17	90202-05088 Washer, plate (666)	Buy now
18	90468-05M03 Clip(6j8)	Buy now
19	95380-05600 Nut, hexagon (663)	Buy now
20	6E9-41237-00 Joint, link	Buy now
21	63D-21707-10 Oil tank comp.	Buy now
22	90445-11M15 Hose (l360)	Buy now
23	90467-11M08 Clip(72x)	Buy now
24	63D-2175R-00 Hook, band	Buy now
25	63D-2176M-00 Hook	Buy now
26	6H4-21770-00 Oil tank cap assembly	Buy now
27	90445-11M23 Hose (l100)	Buy now
28	6H4-21757-00 Washer, special 1	Buy now
29	63D-21744-00 Breather	Buy now
30	6H4-24634-00 Hook, chain ball	Buy now
31	90467-10M04 Clip, pipe 1 (6e9)	Buy now

Oil Pump 1




63B0100-1060

B6


Ref	Part	
32	90445-11M17 Hose (I360)	Buy now
33	90446-10M01 Tube (6e5)	Buy now
34	6H4-24633-00 Chain, ball	Buy now
35	6J8-13411-00 Strainer, oil	Buy now
36	6J8-13414-00 Gasket, strainer cover	Buy now
37	6L2-13416-00 Pipe, oil 1	Buy now
38	90467-08004 Clip, pipe 6162435600	Buy now
39	6A0-82317-00 Damper, ignition coil	Buy now
40	624-42542-00 Collar	Buy now
41	90119-06M65 Bolt, with washer	Buy now
42	90119-06M67 Bolt, with washer	Buy now
43	90445-07M87 Hose(62t)	Buy now
44	6E9-13183-70 Valve check	Buy now
47	63D-85720-10 Oil level gauge assembly	Buy now

Oil Pump 2




Ref	Part	
1	63D-13200-00 Oil injection pump assembly	Buy now
2	93210-19MA7 O-ring(6r0)	Buy now
3	90201-08M93 Washer, plate (6g5)	Buy now
4	6H4-11537-01 Gear, driven	Buy now
5	6H1-13117-01 Collar, distance	Buy now
6	93210-13M04 93210-13m04	Buy now
7	90109-06M39 Bolt(6h0)	Buy now
8	90109-06M40 Bolt(6h0)	Buy now
9	90445-07M44 Hose (I390)	Buy now
10	90445-07M23 Hose (I570)	Buy now
11	90445-07MA6 Hose (I200)	Buy now
12	90468-07M02 Clip (6e5)	Buy now
14	90464-07M20 Clamp(6h0)	Buy now
15	6H4-41241-01 Rod, link	Buy now
16	6H1-41237-00 Joint, link	Buy now

Oil Pump 2




Ref	Part	
17	90202-05088 Washer, plate (666)	Buy now
18	90468-05M03 Clip(6j8)	Buy now
19	95380-05600 Nut, hexagon (663)	Buy now
20	6E9-41237-00 Joint, link	Buy now
21	63D-21707-00 Oil tank comp.	Buy now
22	90445-11M15 Hose (I360)	Buy now
23	90467-11M08 Clip(72x)	Buy now
24	6H4-21752-00 Tube, filler 1	Buy now
25	90465-13M30 Clamp	Buy now
26	63D-2175R-00 Hook, band	Buy now
27	63D-2176M-00 Hook	Buy now
28	6H4-21770-00 Oil tank cap assembly	Buy now
29	6H5-24633-00 Chain, Ball	Buy now
30	6j8-21758-00 Washer, special 2	Buy now
31	6H1-21757-00 Washer, special 1	Buy now

Oil Pump 2



Ref	Part	
32	90445-11M23 Hose (l100)	Buy now
33	63D-21744-00 Breather	Buy now
34	90467-10M04 Clip, pipe 1 (6e9)	Buy now
35	90445-11M17 Hose (l360)	Buy now
36	90446-10M01 Tube (6e5)	Buy now
37	6J8-13411-00 Strainer, oil	Buy now
38	6J8-13414-00 Gasket, strainer cover	Buy now
39	6L2-13416-00 Pipe, oil 1	Buy now
40	90467-08004 Clip, pipe 6162435600	Buy now
41	6A0-82317-00 Damper, ignition coil	Buy now
42	624-42542-00 Collar	Buy now
43	90119-06M65 Bolt, with washer	Buy now
44	90119-06M67 Bolt, with washer	Buy now
45	90445-07M87 Hose(62t)	Buy now
46	6E9-13183-70 Valve check	Buy now

Oil Pump 2




63B0100-0070

C1


Ref	Part	
49	90465-06M86 Clamp	Buy now
50	63D-85720-00 Oil level gauge assembly	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
1	62Y-43800-01-4D Power trim & tilt assembly	Buy now
2	62Y-4380K-01 Cylinder, tilt sub assembly	Buy now
3	62X-43810-01 Tilt piston sub assembly	Buy now
4	62X-43861-00 O-ring	Buy now
5	62X-43862-00 O-ring	Buy now
6	93210-29375 O-ring (j10)	Buy now
7	62X-43871-00 Ring, back up	Buy now
8	93210-44383 O-ring (705)	Buy now
9	93210-48214 O-ring	Buy now
10	62X-4388A-00 Piston, trim	Buy now
11	62Y-22471-00 Cylinder, shock absorber	Buy now
12	67F-43875-00 Ring, snap	Buy now
13	69W-4381B-00 Free piston sub assembly	Buy now
14	62X-43899-00 Plate stopper	Buy now
15	93503-16003 Ball	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
16	62X-4384H-00 Spring	Buy now
17	1UF-22434-00 Plate, valve 1	Buy now
18	62X-43875-00 Ring, snap	Buy now
19	6H1-43831-10 Connector, shaft	Buy now
21	62Y-43830-01 Gear pump assembly	Buy now
22	69J-43841-00 Piston, shuttle	Buy now
23	69J-4384M-00 Piston, shuttle 2	Buy now
24	69A-4384F-00 Seal, main valve	Buy now
25	6H1-43883-00 O-ring	Buy now
26	99002-03600 Circlip(6I5)	Buy now
27	93505-32038 Ball(7fk)	Buy now
28	65W-4386A-00 Pin, absorber valve	Buy now
29	69J-43853-00 Spring, main valve	Buy now
30	69J-4389J-00 O-ring	Buy now
31	6H1-4384G-11 Seal, relief valve	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
32	62Y-43855-00 Spring, up relief	Buy now
33	6H1-4384F-10 Seal, main valve	Buy now
34	6H1-43856-10 Spring, down relief	Buy now
35	6H1-43844-10 Pin, valve support	Buy now
37	92A08-03110 Screw set	Buy now
38	95302-03600 Nut(7h6)	Buy now
39	62Y-4382A-00 Adaptor 1	Buy now
40	93604-26256 Pin, dowel	Buy now
41	62Y-43816-00 Filter 1	Buy now
42	62Y-4382L-00 Cap, relief valve	Buy now
43	91318-05020 Bolt, socket	Buy now
44	91318-05008 Bolt,socket	Buy now
45	93501-08001 Ball	Buy now
46	69W-4384G-00 Seal, relief valve	Buy now
47	62Y-43854-00 Spring, manual release	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
48	69J-43894-00 Spring, shuttle return	Buy now
49	62Y-4387J-00 Washer, special 2	Buy now
50	62Y-22434-00 Plate, valve 1	Buy now
51	62Y-4387I-00 Ring, back up	Buy now
52	62Y-4387G-00 Washer	Buy now
53	69J-43893-00 Washer	Buy now
54	6H1-43816-00 Filter 1	Buy now
56	91318-06040 Bolt,socket	Buy now
57	93210-18397 O-ring (6g5)	Buy now
58	6H1-43875-00 Ring, snap	Buy now
59	62Y-43845-00 Screw, manual release	Buy now
60	93210-09165 O-ring	Buy now
61	6H1-43829-00 Plug, reservoir	Buy now
62	62X-43865-00 O-ring	Buy now
63	69W-43899-01 Plate stopper	Buy now


Power Trim & Tilt Assy 1



A6

Ref	Part	
64	62Y4382200 Seal, trim dust	Buy now
65	62X4382100 Screw, trim cylinder end	Buy now
66	62X4387200 Ring, back up	Buy now
67	6C54386300 O-ring	Buy now


Power Trim & Tilt Assy 2



B2

Ref	Part	
1	62X-43888-00 Bolt,socket	Buy now
2	62Y-43880-01 Motor assembly	Buy now
3	62Y-43805-00 Armature assembly	Buy now
4	62X-43804-01 Stator assembly	Buy now
5	62Y-43892-00 Brush 2	Buy now
6	62Y-43891-00 Brush 1	Buy now
7	62Y-82181-01 Circuit breaker comp.	Buy now
8	62X-43807-00 Wire sub assembly	Buy now
9	69W-4380F-00 Plate, brush holder	Buy now
10	62X-4386K-00 Spring, brush	Buy now
11	97880-05020 Screw, pan head (e22)	Buy now
12	9760204216 Screw, pan head with washer	Buy now
13	62Y-43881-00 Frame, end	Buy now
14	62X-4380H-00 Metal	Buy now
15	93102-08414 Oil seal(61a)	Buy now


Power Trim & Tilt Assy 2



B2

Ref	Part	
16	90201-083J8 Washer, plate(62x)	Buy now
17	93210-52449 O-ring(50m)	Buy now


Remote Control Assy



C6

Ref	Part	
1	703-48201-A2 Remote control assembly (10p) AP	Buy now
1	703-48205-A4 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	703-48261-01 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now


Remote Control Assy



C6

Ref	Part	
15	703-48243-00 Bushing 3	Buy now
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now


Remote Control Assy



C6

Ref	Part	
30	703-48219-00 Cover, lead	Buy now
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-12 Main switch assembly FOR PRIME START	Buy now


Remote Control Assy



C6

Ref	Part	
45	676-82577-00 Cap, key	Buy now
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-A0 Buzzer	Buy now
52	703-48284-00 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-48224-00 Cover, control lever WITHOUT PT/T SW.	Buy now
55	703-82563-02 Trim & tilt switch assembly WITH PT/T SW.	Buy now
56	703-48221-00 Grip	Buy now
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now


Remote Control Assy



C6

Ref	Part	
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now
63	703-82542-00 Cap	Buy now
64	703-48218-00 Graphic	Buy now

Remote Control Box




67M0100-8280

C5

Ref	Part	
1	703-48201-A2 Remote control assembly (10p) AP	Buy now
1	703-48205-A4 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	701-48320-00 Cable, Remote Control L=12F UR	Buy now
2	701-48320-20 Cable, Remote Control L=13F UR	Buy now
2	701-48320-30 Cable, Remote Control L=14F UR	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now
2	701-48320-60 Cable, Remote Control L=16F UR	Buy now
2	701-48320-80 Cable, Remote Control L=17F UR	Buy now

Repair Kit 1




63D0010-5270

D4

Ref	Part	
1	63D-W0001-00 Power head gasket kit	Buy now
2	63D-11181-A1 Gasket, cylinder head 1	Buy now
3	63D-11193-A0 Gasket, head cover 1	Buy now
4	90430-14115 Gasket (663)	Buy now
5	61A-12414-A0 Gasket, cover	Buy now
6	6H4-41112-A0 Gasket, exhaust inner cover	Buy now
7	6H4-41114-A0 Gasket, exhaust outer cover	Buy now
8	6H4-15369-A1 Gasket, oil seal housing	Buy now
9	93104-16M01 Oil seal(6a8)	Buy now
10	93102-25M28 Oil seal(6h4)	Buy now
11	93210-58M21 O-ring (683)	Buy now
12	6H4-13621-A1 Gasket, valve seat	Buy now
13	6H4-14198-01 Gasket	Buy now
14	6H3-14457-01 Seal	Buy now
15	6H4-14984-00 Gasket, float chamber	Buy now

Repair Kit 1




63D0010-5270

D4

Ref	Part	
16	93210-32738 O-ring(1wg)	Buy now
17	650-24431-A0 Gasket,fuel pump	Buy now
18	6H4-45113-A0 Gasket, upper casing	Buy now
19	6H4-W0093-03 Carburetor repair kit	Buy now
21	676-14966-00 Rubber cap	Buy now
22	6H4-14590-00 Needle valve assembly	Buy now
23	663-14159-00 Clip	Buy now
24	676-14186-00 Pin, valve	Buy now
25	6H4-14985-01 Float	Buy now
26	6H4-14548-00 Pin, float arm	Buy now
28	97980-04114 Screw, pan head(ga5)	Buy now
29	93210-04230 O-ring (371)	Buy now
30	6H4-14147-00 O-ring	Buy now
31	692-14923-00 Screw, adjusting	Buy now


Repair Kit 2



D6

Ref	Part	
1	63D-W0001-20 Lower unit gasket kit	Buy now
2	63D-45114-A0 Gasket, upper casing	Buy now
3	6H4-41134-A0 Gasket, exhaust manifold	Buy now
4	6H3-45127-00 Seal 1	Buy now
5	63D-45123-00 Gasket, muffler	Buy now
6	90430-08020 Gasket	Buy now
7	93210-33MG4 O-ring	Buy now
8	93106-09014 Oil seal	Buy now
9	93210-59MG7 O-ring	Buy now
10	63D-44316-00 Gasket, water pump	Buy now
11	93210-48MG8 O-ring	Buy now
12	93101-25M57 Oil seal	Buy now
13	93210-69MG6 O-ring	Buy now
14	93101-22M00 Oil seal (22x36x6-663)	Buy now
15	93210-74MG5 O-ring (xea)	Buy now


Repair Kit 2



D6


Ref	Part	
16	63D-W0078-01 Water pump repair kit	Buy now
17	63D-44322-00 Insert, cartridge	Buy now
18	6H3-44352-00 Impellar	Buy now
19	63D-44312-00 Cover, water pump housing	Buy now
20	63D-44323-00 Outer plate, cartridge	Buy now
23	90119-08M15 Bolt, with washer(62w)	Buy now
24	663-44366-00 Damper, water seal 2	Buy now
25	90280-03024 Key, woodruff(662)	Buy now
26	63D-W0078-0A Chrome pump kit	Buy now
27	63D-44322-40 Insert, cartridge	Buy now
28	63D-44323-40 Outer plate, cartridge	Buy now

Starter




Ref	Part	
1	6H4-15710-04-4D Starter assembly	Buy now
2	6H4-15711-02-94 Case, starter	Buy now
3	91690-40018 Pin spring(664)	Buy now
4	6H4-15758-01-4D Guide rope	Buy now
5	97095-06016 Bolt, hexagon deep recess	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	6H4-15762-00 Seal, rubber 2	Buy now
8	6A0-15789-00 Damper	Buy now
9	6F5-15752-00 Roller, wire	Buy now
10	90387-06M69 Collar (688)	Buy now
11	97013-06030 Bolt	Buy now
12	92903-06100 Washer(6a1)	Buy now
13	92903-06600 Washer, plain (646)	Buy now
14	95380-06600 Nut(661)	Buy now
15	6H4-15787-01 Stay	Buy now

Starter




Ref	Part	
16	689-15755-01 Handle, starter	Buy now
17	6F5-15779-02 Cover	Buy now
18	* item_description	Buy now
19	6H4-15714-00 Drum, sheave	Buy now
20	90510-08002 Spring spiral 656157130000	Buy now
21	6H4-15717-01 Shaft, starter	Buy now
22	90201-06060 Washer, plate	Buy now
23	97095-06020 Bolt(7u8)	Buy now
25	676-15741-03 Pawl, drive	Buy now
26	93430-06M02 Circlip (689)	Buy now
27	6H4-15705-00 Spring drive pawl assembly	Buy now
28	97095-06035 Bolt(j52)	Buy now
30	99530-10014 Pin, dowel	Buy now
31	63D-15771-00-4D Stay 1	Buy now
32	97013-08025 Bolt (682)	Buy now

Starter




Ref	Part	
33	92903-08600 Washer, plain (663)	Buy now
34	90119-06MA2 Bolt, with washer	Buy now
35	6H4-15772-02-94 Stay 2	Buy now
36	90119-06MA3 Bolt, with washer	Buy now
37	6H4-15723-01-94 Pulley, starter	Buy now
38	6J8-81365-A0 Gasket, hole cover	Buy now
39	97013-08020 Bolt(6td)	Buy now
41	90387-06M66 Collar (6h4)	Buy now
42	63D-15746-00 Arm	Buy now
43	97095-06040 Bolt (682)	Buy now
45	63D-15770-00 Cable comp., starter stop	Buy now
46	656-15748-00 Plunger, starter stop	Buy now
47	90501-10227 Spring, comprrshion(656)	Buy now
48	63D-13437-N0 Mark, caution	Buy now

Starting Motor




Ref	Part	
1	6F5-81800-11 Starting motor assembly	Buy now
2	689-81857-11 Pinion stopper set	Buy now
3	689-81807-12 Pinion assembly	Buy now
4	6F5-81830-11 Front cover assembly	Buy now
5	689-81831-00 Metal, front	Buy now
6	689-81847-11 O-ring	Buy now
7	689-81809-11 Washer kit	Buy now
8	689-81850-12 Armature assembly	Buy now
9	689-81810-11 Stator ass'y	Buy now
10	689-81811-11 Brush 1	Buy now
11	689-81840-11 Brush holder assembly	Buy now
12	689-81812-11 Brush 2	Buy now
13	689-81813-10 Spring, brush	Buy now
14	689-81820-11 Rear cover ass'y	Buy now
15	689-81826-10 Bolt	Buy now

Starting Motor



Ref	Part	
16	97013-08030 Bolt	Buy now
17	92903-08600 Washer, plain (663)	Buy now
18	97013-08016 Bolt, hexagon	Buy now
20	63D-15771-00-4D Stay 1	Buy now
21	97013-08025 Bolt (682)	Buy now
23	90119-06MA2 Bolt, with washer	Buy now
24	6H4-15772-02-94 Stay 2	Buy now
25	90119-06MA3 Bolt, with washer	Buy now
26	6J8-15723-E1 Pulley, starter	Buy now
27	6J8-81365-A0 Gasket, hole cover	Buy now
28	97013-08014 Bolt(692)	Buy now
30	6H4-81337-01 Cover, flywheel	Buy now
31	90387-06M65 Collar (6h4)	Buy now
32	90159-06M21 Screw, with washer(61c)	Buy now
33	90159-06M22 Screw, with washer(61c)	Buy now


Steering



E4

Ref	Part	
3	6K5-42137-00 Indicator, throttle	Buy now
4	90269-02M09 Rivet(6I5)	Buy now
5	63D-44100-11 Shift Link assembly	Buy now
6	63D-44104-00 Plate Comp	Buy now
7	63D-48261-00 Arm, Throttle	Buy now
8	63D-42115-00 Shaft, Steering Handle	Buy now
10	91690-30025 Pin, spring	Buy now
11	63D-42159-00 Stay	Buy now
12	98580-06016 Screw pan head	Buy now
13	93430-08006 Circlip(2r6)	Buy now
14	63D-44113-01 Cam Plate Handle	Buy now
15	63D-48236-00 Roller, detent	Buy now
16	63D-48119-00 Cover	Buy now
17	63D-42153-00 Shaft Throttle Control	Buy now
18	63D-44132-00 Bushing	Buy now

Steering





63B2300-3170

E4

Ref	Part	
19	63D-48118-00 Clip, Shift Lever	Buy now
20	63D-48237-00 Adaptor	Buy now
21	98785-05014 Screw 3	Buy now
22	63D-48238-00 Spring, detent	Buy now
23	63D-42181-00 Washer	Buy now
24	97095-06016 Bolt, hexagon deep recess	Buy now
25	92995-06600 Washer, plain (646)	Buy now
26	63D-42131-00 Cover, handle steering	Buy now
27	90480-14M14 Grommet (6e0)	Buy now
28	97885-06016 Screw, pan head(6b0)	Buy now
30	97885-06040 Screw pan head	Buy now
32	63D-42725-00 Grommet	Buy now
33	63D-48321-01 Cable	Buy now
34	63D-26301-01 Throttle cable assembly	Buy now
35	90101-12M09 Bolt	Buy now

Steering




63B2300-3170

E4

Ref	Part	
36	92990-12200 Ybs66-12 washer,plain	Buy now
37	63D-48531-00 Bracket Remote Control 1	Buy now
38	63D-48538-00 Clamp, cable 1	Buy now
39	90464-09M42 Clamp(6b0)	Buy now
42	90386-12M93 Bush(6b0)	Buy now
43	90386-29M95 Bush(6B0)	Buy now
44	92990-12600 Washer, plate(663)	Buy now
45	90206-12M22 Washer, wave(6b0)	Buy now
46	90185-12M12 Nut, self-locking(6e5)	Buy now
47	90387-12M02 Collar(6b0)	Buy now
48	63D-42126-00 Friction, steering handle grip	Buy now
49	63D-48154-00 Knob, Throttle	Buy now
50	95380-06600 Nut(661)	Buy now
51	91490-20010 Pin, cotter	Buy now
52	6G8-44191-00 Indicator, shift	Buy now

Steering





63B2300-3170

E4

Ref	Part	
53	90202-24M53 Washer Plate(6B0)	Buy now
54	97095-08040 Bolt, hexagon	Buy now
55	92995-08600 Washer, plain (663)	Buy now
56	63D-44159-01 Handle Gear Shift	Buy now
57	90159-06M18 Screw, with washer(6b0)	Buy now
58	63D-44173-00 Lever, Shift Control	Buy now
59	664-42119-00 Grip, steering handle	Buy now
60	6G1-42177-00 Rubber, handle	Buy now
61	90149-05M13 Screw, countersunk	Buy now
62	92903-10600 Washer, plate	Buy now
63	90501-23215 Spring (655)	Buy now
64	90386-08032 Bushing (650)	Buy now
65	93430-04M03 Circlip (eu0)	Buy now
66	63D-42121-20-4D Bracket	Buy now
67	6E0-83627-41 Label, caution 7	Buy now

Steering





63B2300-3170

E4

Ref	Part	
68	6E0-83627-51 Label, Caution 7	Buy now

Steering Guide




62Y0010-5200

C4

Ref	Part	
1	63D-61350-00 Steering guide attachment kit AP	Buy now
2	63D-61351-00 Rod, steering link	Buy now
3	90201-10M20 Washer, plate (663)	Buy now
4	90185-09M01 Nut, nylon (663)	Buy now
5	90170-09M03 Nut (689)	Buy now
6	90387-10M42 Coller (688)	Buy now
7	90101-09M01 Bolt(62x)	Buy now
8	90201-10M63 Washer, plate	Buy now
9	6E5-43145-01 Cap, clamp bracket	Buy now
10	93210-16275 O-ring	Buy now


Top Cowling



A4

Ref	Part	
1	63D-42610-20-4D Top Cowling assembly	Buy now
1	63D-42610-50-4D Top Cowling assembly	Buy now
2	6H4-15761-00 Seal 1	Buy now
3	6H4-42615-00 Seal	Buy now
4	6H4-42651-00 Hook 1	Buy now
5	6H4-42652-00 Hook 2	Buy now
6	90266-04M01 Rivet (689)	Buy now
7	6H4-42613-01-4D Molding, air duct	Buy now
7	6H4-42613-11-4D Molding air duct	Buy now
8	90119-06M99 Bolt, with washer(6h4)	Buy now
9	63D-42677-20 Graphic, front	Buy now
10	63D-42678-11 Graphic, rear	Buy now
11	63D-W0070-10 Graphic set	Buy now
12	63D-13436-40 Mark	Buy now
13	63D-2177H-00 Disk cap 2	Buy now


Top Cowling



A4


Ref	Part	
14	6H3-21732-00 Seal 1	Buy now
15	6H3-21735-00 Seal 2	Buy now
16	6H1-42694-00 Band	Buy now
17	90338-05M03 Plug (6h1)	Buy now
18	90183-05M06 Nut, spring(6h4)	Buy now
19	63D-42681-10 Mark, cowling	Buy now
20	63D-42682-10 Mark, cowling	Buy now

Upper Casing



Ref	Part	
1	63D-45111-01-4D Casing, upper S	Buy now
1	63D-45111-11-4D Casing, upper L	Buy now
2	97095-06012 Bolt(gh1)	Buy now
3	92995-06100 Washer(6a1)	Buy now
4	63D-45155-00 Cap	Buy now
5	97575-08445 Bolt, hexagon w/w deep recess	Buy now
6	93606-12019 Pin, dowel (614)	Buy now
7	90119-08M83 Bolt, with washer(697)	Buy now
8	63D-41137-01-5B Guide, exhaust	Buy now
9	63D-45114-A0 Gasket, upper casing	Buy now
10	6H4-41131-01-5B Manifold, exhaust 40V	Buy now
10	6H5-41131-00-5B Manifold, ext 40Y	Buy now
11	63D-14711-00-5B Muffler 1 S	Buy now
11	63D-14711-11-5B Muffler L	Buy now
12	63D-45123-00 Gasket, muffler	Buy now

Upper Casing



Ref	Part	
13	97075-08030 Bolt, hexagon (fj1)	Buy now
14	92995-08600 Washer, plain (663)	Buy now
17	90119-08M79 Bolt, hexagon (fj1)	Buy now
18	6H3-45127-00 Seal 1	Buy now
19	6H4-45113-A0 Gasket, upper casing	Buy now
22	6H4-41134-A0 Gasket, exhaust manifold	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.