



# Yamaha 5CMH 1996

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Bottom Cowling</b>	3
<b>Control</b>	6
<b>Cylinder &amp; Crankcase</b>	9
<b>Generator</b>	13
<b>Intake</b>	15
<b>Kits De Reparation</b>	19
<b>Lower Casing &amp; Drive</b>	22
<b>Partie Electrique 1</b>	26
<b>Starter</b>	27
<b>Top Cowling</b>	29
<b>Upper Casing &amp; Bracket</b>	30

## Bottom Cowling




Ref	Part	
1	<a href="#">6E042711054D</a> Cowling, bottom	<a href="#">Buy now</a>
3	<a href="#">9048006M1900</a> Grommet (6e3)	<a href="#">Buy now</a>
4	<a href="#">6E042815004D</a> Lever, clamp	<a href="#">Buy now</a>
5	<a href="#">903861206900</a> Bush(666)	<a href="#">Buy now</a>
6	<a href="#">6L2428160000</a> Lever, clamp	<a href="#">Buy now</a>
7	<a href="#">902061205200</a> Washer, wave (666)	<a href="#">Buy now</a>
8	<a href="#">978850603000</a> Screw, pan head(6e0)	<a href="#">Buy now</a>
9	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
10	<a href="#">9048014M1400</a> Grommet (6e0)	<a href="#">Buy now</a>
11	<a href="#">958800602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
12	<a href="#">6E0241820000</a> Damper, locating 2	<a href="#">Buy now</a>
13	<a href="#">6E0425420000</a> Pipe 1	<a href="#">Buy now</a>
14	<a href="#">958950602500</a> Bolt, flange deep recess	<a href="#">Buy now</a>
15	<a href="#">6A1427920100</a> Mark (100:1)	<a href="#">Buy now</a>
16	<a href="#">6E024110014D</a> Fuel Tank Comp	<a href="#">Buy now</a>

## Bottom Cowling




Ref	Part	
17	<a href="#">6E0246100200</a> Cap assembly	<a href="#">Buy now</a>
18	<a href="#">6E0241810000</a> Damper, locating 1	<a href="#">Buy now</a>
19	<a href="#">6E0246410000</a> Gasket, cap	<a href="#">Buy now</a>
20	<a href="#">90445090F600</a> Hose (I1500)	<a href="#">Buy now</a>
21	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
22	<a href="#">6E0245000000</a> Fuel cock assembly 1	<a href="#">Buy now</a>
23	<a href="#">6E0245710000</a> Bushing	<a href="#">Buy now</a>
25	<a href="#">6E0245720000</a> Shaft, fuel change	<a href="#">Buy now</a>
26	<a href="#">6E0245750100</a> Lever, fuel change	<a href="#">Buy now</a>
27	<a href="#">9020212M1700</a> Washer, plate (6e0)	<a href="#">Buy now</a>
28	<a href="#">6E1426430100</a> Plate, Clamp	<a href="#">Buy now</a>
29	<a href="#">6E1426940000</a> Band	<a href="#">Buy now</a>
30	<a href="#">6E1241820000</a> Damper, Locating 2	<a href="#">Buy now</a>
31	<a href="#">6G1243041000</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
32	<a href="#">646242510200</a> Strainer 1	<a href="#">Buy now</a>

## Bottom Cowling




Ref	Part	
33	<a href="#">904450905700</a> Hose (I180)	<a href="#">Buy now</a>
34	<a href="#">6A4243120000</a> Pipe, fuel 2	<a href="#">Buy now</a>
36	<a href="#">6E0825750000</a> Engine stop switch assembly	<a href="#">Buy now</a>
37	<a href="#">682825560000</a> Lanyard, stop switch	<a href="#">Buy now</a>

## Control



Ref	Part	
1	<a href="#">6E042111024D</a> Handle, steering	<a href="#">Buy now</a>
2	<a href="#">6E0421290200</a> Bushing, rubber	<a href="#">Buy now</a>
3	<a href="#">6E4421290000</a> Bushing, rubber	<a href="#">Buy now</a>
4	<a href="#">9038626M3000</a> Bushing (6e0)	<a href="#">Buy now</a>
5	<a href="#">6E0421310294</a> Cover, handle steering	<a href="#">Buy now</a>
6	<a href="#">970130502000</a> Bolt, hexagon	<a href="#">Buy now</a>
7	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">9038626M3300</a> Bushing (6e0)	<a href="#">Buy now</a>
9	<a href="#">6E0421250000</a> Bolt, friction adjust	<a href="#">Buy now</a>
10	<a href="#">6E0421340200</a> Cover, throttle lever	<a href="#">Buy now</a>
11	<a href="#">985800501200</a> Screw, pan head (646)	<a href="#">Buy now</a>
12	<a href="#">914901201200</a> Pin, cotter (6g8)	<a href="#">Buy now</a>
13	<a href="#">9020207M2200</a> Washer (6e0)	<a href="#">Buy now</a>
14	<a href="#">6E0421190000</a> Grip, steering handle	<a href="#">Buy now</a>
15	<a href="#">6E0421170000</a> Rubber, handle	<a href="#">Buy now</a>


## Control



Ref	Part	
16	<a href="#">6E0421371000</a> Indicator, throttle	<a href="#">Buy now</a>
17	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>
18	<a href="#">902011011900</a> Washer, plain(735)	<a href="#">Buy now</a>
19	<a href="#">9014905M1300</a> Screw, countersunk	<a href="#">Buy now</a>
20	<a href="#">9026902M0900</a> Rivet(615)	<a href="#">Buy now</a>
21	<a href="#">6E0421380100</a> Lever, throttle	<a href="#">Buy now</a>
22	<a href="#">6E0421590200</a> Stay	<a href="#">Buy now</a>
23	<a href="#">978850501200</a> Screw,pan head (646)	<a href="#">Buy now</a>
24	<a href="#">6E0263010100</a> Throttle wire assembly	<a href="#">Buy now</a>
25	<a href="#">6E0441110200</a> Handle, gear shift	<a href="#">Buy now</a>
26	<a href="#">932101279000</a> O-ring(3ld)	<a href="#">Buy now</a>
27	<a href="#">9020616M0600</a> Washer, wave (6e0)	<a href="#">Buy now</a>
29	<a href="#">6E0441160000</a> Spring	<a href="#">Buy now</a>
30	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
31	<a href="#">970800601200</a> Bolt(gh1)	<a href="#">Buy now</a>



## Control




Control

Exploded view diagram of a boat's control system, showing the shift lever assembly and the shift rod assembly. The diagram includes numbered callouts for various components, including bolts, washers, levers, rods, connectors, and pins. A watermark "Flood Marine Services" is visible across the diagram.

Ref	Part	
32	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
33	<a href="#">6E0441210000</a> Lever, shift rod 1	<a href="#">Buy now</a>
34	<a href="#">958950602500</a> Bolt, flange deep recess	<a href="#">Buy now</a>
35	<a href="#">6E0441430000</a> Rod, shift 1	<a href="#">Buy now</a>
37	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
38	<a href="#">6E0441450000</a> Connector, shift rod 1	<a href="#">Buy now</a>
39	<a href="#">6E0441460000</a> Connector, shift rod 2	<a href="#">Buy now</a>
40	<a href="#">958950602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>




# Cylinder & Crankcase




Ref	Part	
1	<a href="#">6E0W0090044D</a> Crank cylinder assembly	<a href="#">Buy now</a>
2	<a href="#">6E3151000200</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">650113700000</a> Check valve assembly	<a href="#">Buy now</a>
4	<a href="#">624144850000</a> Pipe, joint	<a href="#">Buy now</a>
5	<a href="#">6E5113720000</a> Nipple, hose	<a href="#">Buy now</a>
6	<a href="#">936040806200</a> Pin,dowel (626)	<a href="#">Buy now</a>
7	<a href="#">9010506M1600</a> Bolt (6e0)	<a href="#">Buy now</a>
8	<a href="#">9010506M1700</a> Bolt (6e0)	<a href="#">Buy now</a>
9	<a href="#">6E0243780000</a> Pipe, joint	<a href="#">Buy now</a>
10	<a href="#">904670601600</a> Clip (655)	<a href="#">Buy now</a>
11	<a href="#">9044507M0000</a> Hose (I200)	<a href="#">Buy now</a>
12	<a href="#">9044507MA300</a> Hose (I200)	<a href="#">Buy now</a>
13	<a href="#">9044507M3200</a> Hose (I200)	<a href="#">Buy now</a>
14	<a href="#">9044507M2800</a> Hose (I200)	<a href="#">Buy now</a>
16	<a href="#">6E015396035B</a> Housing, oil seal	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
17	<a href="#">932103111400</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9310110M2500</a> Oil seal(6e0)	<a href="#">Buy now</a>
19	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
20	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
21	<a href="#">6E011191019M</a> Cover, cylinder head 1	<a href="#">Buy now</a>
22	<a href="#">6E311193A100</a> Gasket,head cover	<a href="#">Buy now</a>
23	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
24	<a href="#">6E341111011S</a> Inner cover, exhaust	<a href="#">Buy now</a>
25	<a href="#">6E041112A100</a> Gasket,inner cover exhaust	<a href="#">Buy now</a>
26	<a href="#">6E341113011S</a> Outer cover, exhaust	<a href="#">Buy now</a>
27	<a href="#">6E041114A100</a> Gasket,outer cover exhaust	<a href="#">Buy now</a>
28	<a href="#">9010506M2400</a> Bolt (6g1)	<a href="#">Buy now</a>
31	<a href="#">6E0114000000</a> Crank assembly	<a href="#">Buy now</a>
32	<a href="#">6E0114120000</a> Crank 1	<a href="#">Buy now</a>
33	<a href="#">6E0114220000</a> Crank 2	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
34	<a href="#">6G1116810000</a> Pin, crank	<a href="#">Buy now</a>
35	<a href="#">93306204U000</a> Bearing(6e0)	<a href="#">Buy now</a>
36	<a href="#">93310418V100</a> Bearing (6e0)	<a href="#">Buy now</a>
37	<a href="#">6E0116510100</a> Rod, connecting	<a href="#">Buy now</a>
38	<a href="#">902091811200</a> Washer 132116850000	<a href="#">Buy now</a>
39	<a href="#">9310120M2900</a> Oil seal(6j1)	<a href="#">Buy now</a>
40	<a href="#">676455672000</a> Shim (t:0.90mm)	<a href="#">Buy now</a>
41	<a href="#">6E0116310098</a> Piston	<a href="#">Buy now</a>
42	<a href="#">6J1116100000</a> Piston ring set (std)	<a href="#">Buy now</a>
43	<a href="#">93310112V000</a> Bearing (6e0)	<a href="#">Buy now</a>
44	<a href="#">6G1116330000</a> Pin, piston	<a href="#">Buy now</a>
45	<a href="#">934501302200</a> Circlip 132116340000	<a href="#">Buy now</a>
46	<a href="#">6E5124110200</a> Thermostat	<a href="#">Buy now</a>
47	<a href="#">6E045113A100</a> Gasket,upper casing	<a href="#">Buy now</a>
48	<a href="#">9046807M0200</a> Clip (6e5)	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
49	<a href="#">947010011000</a> Plug, spark (br7hs)	<a href="#">Buy now</a>

# Generator



Ref	Part	
1	<a href="#">6E0855507100</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">6E0157230094</a> Pulley, Starter	<a href="#">Buy now</a>
3	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
4	<a href="#">6E0855607000</a> Base assembly	<a href="#">Buy now</a>
5	<a href="#">6E0153590100</a> Housing, oil seal	<a href="#">Buy now</a>
6	<a href="#">6E0855207000</a> Charge coil ass'y	<a href="#">Buy now</a>
7	<a href="#">985070501600</a> Screw, pan head(jj6)	<a href="#">Buy now</a>
8	<a href="#">6E0855957000</a> Coil pulser assembly 1	<a href="#">Buy now</a>
9	<a href="#">985070401000</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
10	<a href="#">6E0855927000</a> Pulser coil assembly 2	<a href="#">Buy now</a>
11	<a href="#">976070521200</a> Screw,w/washer	<a href="#">Buy now</a>
12	<a href="#">6E0813367000</a> Grommet	<a href="#">Buy now</a>
13	<a href="#">6E0813287000</a> Clamp	<a href="#">Buy now</a>
15	<a href="#">9310220M2500</a> Oil seal (6e0)	<a href="#">Buy now</a>
16	<a href="#">932104215900</a> O-ring (647)	<a href="#">Buy now</a>


# Generator



Ref	Part	
17	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
18	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
19	<a href="#">6E0241830000</a> Damper, locating 3	<a href="#">Buy now</a>
20	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
21	<a href="#">901701011300</a> Nut, crank shaft (650)	<a href="#">Buy now</a>
22	<a href="#">90201102G900</a> Washer, plate (26h)	<a href="#">Buy now</a>
23	<a href="#">6E0813038000</a> Lighting coil assembly	<a href="#">Buy now</a>
24	<a href="#">901590504000</a> Screw, pan head(4my)	<a href="#">Buy now</a>




# Intake



Ref	Part	
1	<a href="#">6E0136100000</a> Reed valve assembly	<a href="#">Buy now</a>
2	<a href="#">6E0W00040000</a> Reed set	<a href="#">Buy now</a>
3	<a href="#">6E013621A200</a> Gasket, valve seat	<a href="#">Buy now</a>
4	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
5	<a href="#">6E0143010500</a> Carburetor assembly 1	<a href="#">Buy now</a>
6	<a href="#">6E0143810200</a> Body, float chamber	<a href="#">Buy now</a>
7	<a href="#">6E0143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
8	<a href="#">979800411600</a> Screw, with washer(61b)	<a href="#">Buy now</a>
9	<a href="#">978900500600</a> Screw,panhead (eg9)	<a href="#">Buy now</a>
10	<a href="#">646141980100</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">6E7143850100</a> Float	<a href="#">Buy now</a>
12	<a href="#">647143861000</a> Pin, float	<a href="#">Buy now</a>
13	<a href="#">6E0143410100</a> Nozzle, main	<a href="#">Buy now</a>
14	<a href="#">648143434000</a> Jet, main (#80)	<a href="#">Buy now</a>
15	<a href="#">6F5143920000</a> Valve, needle	<a href="#">Buy now</a>




# Intake




Ref	Part	
16	<a href="#">6E0141570000</a> Cover, plate	<a href="#">Buy now</a>
17	<a href="#">6E0142270000</a> Gasket	<a href="#">Buy now</a>
18	<a href="#">978900400700</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
19	<a href="#">647143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
20	<a href="#">646142120100</a> Spring, pilot adjusting	<a href="#">Buy now</a>
21	<a href="#">664143210100</a> Screw, throttle	<a href="#">Buy now</a>
22	<a href="#">648143422600</a> Jet, pilot (#52)	<a href="#">Buy now</a>
23	<a href="#">647143260000</a> Screw, guide	<a href="#">Buy now</a>
24	<a href="#">985800402000</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
25	<a href="#">6E0244130000</a> Cover, pump	<a href="#">Buy now</a>
26	<a href="#">6E0244710000</a> Diaphragm	<a href="#">Buy now</a>
27	<a href="#">6E0244350000</a> Gasket, cover pump	<a href="#">Buy now</a>
28	<a href="#">6E0244120000</a> Body, pump	<a href="#">Buy now</a>
29	<a href="#">6E0244230000</a> Spring	<a href="#">Buy now</a>
30	<a href="#">6E0143460000</a> Plate	<a href="#">Buy now</a>

# Intake




Ref	Part	
31	<a href="#">6E0244110000</a> Diaphragm	<a href="#">Buy now</a>
32	<a href="#">6E0244340000</a> Gasket, body pump	<a href="#">Buy now</a>
33	<a href="#">6E0141590000</a> Clip	<a href="#">Buy now</a>
34	<a href="#">6E014198A000</a> Gasket	<a href="#">Buy now</a>
35	<a href="#">9538R0670000</a> Nut	<a href="#">Buy now</a>
36	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
37	<a href="#">6E0144170000</a> Cover 1	<a href="#">Buy now</a>
38	<a href="#">6E0144180000</a> Cover 2	<a href="#">Buy now</a>
39	<a href="#">985800552500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
40	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
41	<a href="#">977804032000</a> Ybs81-420 screw,0.head tapping	<a href="#">Buy now</a>
42	<a href="#">6E0412560000</a> Rod, choke link	<a href="#">Buy now</a>
43	<a href="#">6E0412710000</a> Knob, choke	<a href="#">Buy now</a>
44	<a href="#">6E0412720000</a> Knob, choke 2	<a href="#">Buy now</a>
45	<a href="#">9020212M1600</a> Washer, plate (6e0)	<a href="#">Buy now</a>

# Intake




Ref	Part	
46	<a href="#">661412620200</a> Joint, choke lever	<a href="#">Buy now</a>
47	<a href="#">956270632500</a> Bolt, stud(6e0)	<a href="#">Buy now</a>
48	<a href="#">9011606M0800</a> Bolt, stud (689)	<a href="#">Buy now</a>

## Kits De Reparation




Ref	Part	
1	<a href="#">6E0W0001A300</a> Gasket kit, power unit	<a href="#">Buy now</a>
2	<a href="#">932104215900</a> O-ring (647)	<a href="#">Buy now</a>
3	<a href="#">9310220M2500</a> Oil seal (6e0)	<a href="#">Buy now</a>
4	<a href="#">6E041112A100</a> Gasket,inner cover exhaust	<a href="#">Buy now</a>
5	<a href="#">6E341114A100</a> Gasket,outer cover exhaust	<a href="#">Buy now</a>
6	<a href="#">6E011193A100</a> Gasket,head cover	<a href="#">Buy now</a>
7	<a href="#">9310120M2900</a> Oil seal(6j1)	<a href="#">Buy now</a>
8	<a href="#">9310110M2500</a> Oil seal(6e0)	<a href="#">Buy now</a>
9	<a href="#">932103111400</a> O-ring	<a href="#">Buy now</a>
10	<a href="#">6E013621A200</a> Gasket, valve seat	<a href="#">Buy now</a>
11	<a href="#">6E014198A000</a> Gasket	<a href="#">Buy now</a>
12	<a href="#">6E0143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
13	<a href="#">6A1143980000</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">6E045113A100</a> Gasket,upper casing	<a href="#">Buy now</a>
15	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>

## Kits De Reparation



Ref	Part	
16	<a href="#">6E0W00930300</a> Carburetor repair set	<a href="#">Buy now</a>
19	<a href="#">985800401600</a> Screw, panhead (796)	<a href="#">Buy now</a>
21	<a href="#">6E7143850100</a> Float	<a href="#">Buy now</a>
22	<a href="#">647143860000</a> Pin, float	<a href="#">Buy now</a>
23	<a href="#">6F5143920000</a> Valve, needle	<a href="#">Buy now</a>
24	<a href="#">6E0142270000</a> Gasket	<a href="#">Buy now</a>
25	<a href="#">647143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
26	<a href="#">6E0244710000</a> Diaphragm	<a href="#">Buy now</a>
27	<a href="#">6E0244110000</a> Diaphragm	<a href="#">Buy now</a>
28	<a href="#">6E0W0001C100</a> Lower unit gasket kit	<a href="#">Buy now</a>
29	<a href="#">9310110M1400</a> Oil seal	<a href="#">Buy now</a>
30	<a href="#">904300800300</a> Gasket	<a href="#">Buy now</a>
31	<a href="#">6E045315A000</a> Packing, lower casing	<a href="#">Buy now</a>
32	<a href="#">6E044315A000</a> Gasket, water pump 1	<a href="#">Buy now</a>
33	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>


## Kits De Reparation



Ref	Part	
34	<a href="#">932104880000</a> O-ring	<a href="#">Buy now</a>
35	<a href="#">6E0W0078A200</a> Water pump repair kit	<a href="#">Buy now</a>
36	<a href="#">6E0443110000</a> Housing, water pump	<a href="#">Buy now</a>
38	<a href="#">6E0443220200</a> Insert, cartridge	<a href="#">Buy now</a>
39	<a href="#">6E0443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
40	<a href="#">6E0443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
41	<a href="#">6E0443520000</a> Impeller	<a href="#">Buy now</a>
42	<a href="#">970950604500</a> Bolt, hexagon	<a href="#">Buy now</a>
43	<a href="#">936040906600</a> Pin, dowel	<a href="#">Buy now</a>
45	<a href="#">6E0443224000</a> Insert, cartridge	<a href="#">Buy now</a>
46	<a href="#">6E0443234000</a> Outer plate, cartridge	<a href="#">Buy now</a>




## Lower Casing & Drive



Ref	Part	
1	<a href="#">6E045300034D</a> Lower unit assembly	<a href="#">Buy now</a>
2	<a href="#">6E045311024D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">6E0453170900</a> Bushing	<a href="#">Buy now</a>
4	<a href="#">6E0453160900</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">9310110M1400</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">933060042600</a> Bearing (7k2)	<a href="#">Buy now</a>
7	<a href="#">6L5452510300</a> Anode	<a href="#">Buy now</a>
8	<a href="#">958950601200</a> Bolt, flange deep recess	<a href="#">Buy now</a>
9	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
10	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">903400800200</a> Plug, straight screw	<a href="#">Buy now</a>
12	<a href="#">9011906M4000</a> Bolt, with washer	<a href="#">Buy now</a>
13	<a href="#">9038706M1400</a> Collar(6e0)	<a href="#">Buy now</a>
14	<a href="#">6E04532101CA</a> Plate	<a href="#">Buy now</a>
15	<a href="#">6E045315A000</a> Packing, lower casing	<a href="#">Buy now</a>




## Lower Casing & Drive




Ref	Part	
16	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
17	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">6E045361018D</a> Cap, lower casing	<a href="#">Buy now</a>
20	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>
21	<a href="#">932104880000</a> O-ring	<a href="#">Buy now</a>
22	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
23	<a href="#">6E0443110000</a> Housing, water pump	<a href="#">Buy now</a>
24	<a href="#">6E044315A000</a> Gasket, water pump 1	<a href="#">Buy now</a>
25	<a href="#">6E0443224000</a> Insert, cartridge	<a href="#">Buy now</a>
26	<a href="#">6E0443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
27	<a href="#">6E0443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
28	<a href="#">6E0443520000</a> Impeller	<a href="#">Buy now</a>
29	<a href="#">936040906600</a> Pin, dowel	<a href="#">Buy now</a>
30	<a href="#">970950604500</a> Bolt, hexagon	<a href="#">Buy now</a>
31	<a href="#">936041808000</a> Pin, dowel. (647)	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
32	<a href="#">6E0443280000</a> Plate	<a href="#">Buy now</a>
33	<a href="#">6E0443611000</a> Tube, water	<a href="#">Buy now</a>
34	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
35	<a href="#">6E0455110000</a> Shaft, drive	<a href="#">Buy now</a>
36	<a href="#">9046708M0100</a> Clip (6e0)	<a href="#">Buy now</a>
37	<a href="#">6E0455510000</a> Pinion (13t)	<a href="#">Buy now</a>
38	<a href="#">990090660000</a> Circlip(53l)	<a href="#">Buy now</a>
39	<a href="#">9020111M4900</a> Washer, plate (6e0)	<a href="#">Buy now</a>
40	<a href="#">6E0455600000</a> Gear 1 assembly (27t)	<a href="#">Buy now</a>
41	<a href="#">6E0455700000</a> Gear 2 assembly (27t)	<a href="#">Buy now</a>
42	<a href="#">9020113M5000</a> Washer, plate (6e0)	<a href="#">Buy now</a>
43	<a href="#">6E0456310000</a> Clutch, dog	<a href="#">Buy now</a>
44	<a href="#">902500504600</a> Pin,straight	<a href="#">Buy now</a>
45	<a href="#">654456330000</a> Ring, cross pin	<a href="#">Buy now</a>
46	<a href="#">905011006400</a> Spring, compression 6164563600	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
47	<a href="#">654456350000</a> Plunger, shift	<a href="#">Buy now</a>
48	<a href="#">6E0456110100</a> Shaft, propeller	<a href="#">Buy now</a>
49	<a href="#">6L5459870100</a> Spacer 1	<a href="#">Buy now</a>
50	<a href="#">6L5456160000</a> Nut, propeller	<a href="#">Buy now</a>
51	<a href="#">914902503000</a> Pin, cotter(6I5)	<a href="#">Buy now</a>
52	<a href="#">9020108M5400</a> Washer, plate (6e5)	<a href="#">Buy now</a>
53	<a href="#">6E0441500000</a> Shift cam assembly	<a href="#">Buy now</a>
54	<a href="#">6G1441470000</a> Boot, shift rod	<a href="#">Buy now</a>
55	<a href="#">6E0459490000</a> Propeller (3x7-1/4 x6-1/2 -ba)	<a href="#">Buy now</a>
56	<a href="#">6E045331005B</a> Housing, bearing	<a href="#">Buy now</a>
57	<a href="#">6E0453180100</a> Bushing, drive shaft 3	<a href="#">Buy now</a>
58	<a href="#">9342022M0300</a> Cir clip (6e0)	<a href="#">Buy now</a>
59	<a href="#">985800552500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
60	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>

## Partie Electrique 1




Ref	Part	
1	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
2	<a href="#">6E3823702100</a> Plug cap assembly	<a href="#">Buy now</a>
3	<a href="#">6E0823160194</a> Bracket, ignition coil	<a href="#">Buy now</a>
4	<a href="#">6E0823170000</a> Damper	<a href="#">Buy now</a>
5	<a href="#">6E0855700000</a> Ignition coil assembly	<a href="#">Buy now</a>
6	<a href="#">970800603000</a> Bolt(jf7)	<a href="#">Buy now</a>
7	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">904802516100</a> Grommet(656)	<a href="#">Buy now</a>
9	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>
10	<a href="#">6E0855480000</a> Holder, wire harness	<a href="#">Buy now</a>
11	<a href="#">6E0855407100</a> C.d.i. unit assembly	<a href="#">Buy now</a>
12	<a href="#">958950602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>

# Starter



Ref	Part	
1	<a href="#">6E0157100394</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">6E4157117194</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">6E0157140100</a> Drum, sheave	<a href="#">Buy now</a>
4	<a href="#">9051008M0300</a> Spring, spiral (6g1)	<a href="#">Buy now</a>
5	<a href="#">6E0157170000</a> Shaft, starter	<a href="#">Buy now</a>
6	<a href="#">970140603500</a> Bolt(3rv)	<a href="#">Buy now</a>
7	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
8	<a href="#">9020106M3000</a> Washer, plate (6a1)	<a href="#">Buy now</a>
9	<a href="#">677157410100</a> Pawl, drive	<a href="#">Buy now</a>
10	<a href="#">9343006M0200</a> Circlip (689)	<a href="#">Buy now</a>
11	<a href="#">6E0157050000</a> Spring drive pawl assembly	<a href="#">Buy now</a>
12	<a href="#">6G1157790000</a> Cover	<a href="#">Buy now</a>
14	<a href="#">6G1157550000</a> Handle, starter	<a href="#">Buy now</a>
15	<a href="#">6E3157580100</a> Guide, wire	<a href="#">Buy now</a>
16	<a href="#">6E0157610000</a> Seal, rubber 1	<a href="#">Buy now</a>


# Starter



Ref	Part	
17	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
18	<a href="#">958950602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>




## Top Cowling



Ref	Part	
1	<a href="#">6E0426104000</a> Top Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">6E0426150000</a> Seal	<a href="#">Buy now</a>
3	<a href="#">6E0426470100</a> Holder, clamp band	<a href="#">Buy now</a>
4	<a href="#">6E0426510200</a> Hook	<a href="#">Buy now</a>
5	<a href="#">9026604M0000</a> Rivet 2 (662)	<a href="#">Buy now</a>
7	<a href="#">6E3426771000</a> Graphic Front	<a href="#">Buy now</a>
8	<a href="#">6E3426781100</a> Graphic, Rear	<a href="#">Buy now</a>
10	<a href="#">656W28100200</a> Tool kit	<a href="#">Buy now</a>




## Upper Casing & Bracket




Ref	Part	
1	<a href="#">6E045111024D</a> Casing, upper	<a href="#">Buy now</a>
2	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
3	<a href="#">970800603000</a> Bolt(jf7)	<a href="#">Buy now</a>
4	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
7	<a href="#">9538R0670000</a> Nut	<a href="#">Buy now</a>
8	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
9	<a href="#">647451510100</a> Cover, upper casing	<a href="#">Buy now</a>
10	<a href="#">9048010M1300</a> Grommet (6e0)	<a href="#">Buy now</a>
11	<a href="#">6E043111024D</a> Bracket, clamp 1	<a href="#">Buy now</a>
12	<a href="#">6E043112014D</a> Bracket, clamp 2	<a href="#">Buy now</a>
13	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
14	<a href="#">6E0431160100</a> Screw, transom clamp	<a href="#">Buy now</a>
15	<a href="#">6E0431180100</a> Handle, transom clamp	<a href="#">Buy now</a>
16	<a href="#">9024304M0100</a> Pin(6a1)	<a href="#">Buy now</a>

## Upper Casing & Bracket




Ref	Part	
17	<a href="#">9010108M0700</a> Bolt(6e0)	<a href="#">Buy now</a>
18	<a href="#">9020108M0300</a> Washer, plate(6e0)	<a href="#">Buy now</a>
19	<a href="#">6A1431130100</a> Plate, clamp bracket	<a href="#">Buy now</a>
20	<a href="#">957800830000</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
21	<a href="#">6EEG31220000</a> Collar	<a href="#">Buy now</a>
22	<a href="#">901010633500</a> Bolt, hexagon (624)	<a href="#">Buy now</a>
24	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
25	<a href="#">6E043311044D</a> Bracket, swivel 1	<a href="#">Buy now</a>
26	<a href="#">6E043312024D</a> Bracket, swivel 2	<a href="#">Buy now</a>
28	<a href="#">958950603500</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
29	<a href="#">6E0431810000</a> Lever, tilt stop 1	<a href="#">Buy now</a>
30	<a href="#">6E0436320000</a> Knob, tilt	<a href="#">Buy now</a>
31	<a href="#">6E0433130094</a> Bracket, swivel 3	<a href="#">Buy now</a>
32	<a href="#">620431890000</a> Bushing	<a href="#">Buy now</a>
33	<a href="#">958950602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>

## Upper Casing & Bracket



Ref	Part	
34	<a href="#">905081602000</a> Spring 6474319800	<a href="#">Buy now</a>
35	<a href="#">905081602100</a> Spring 6474318800	<a href="#">Buy now</a>
36	<a href="#">6E0431600100</a> Tilt rod assembly	<a href="#">Buy now</a>
37	<a href="#">689431650000</a> Plate, tilt lock	<a href="#">Buy now</a>
38	<a href="#">916903000800</a> Pin. spring(656)	<a href="#">Buy now</a>
39	<a href="#">6E043614005B</a> Plate, tilt lock	<a href="#">Buy now</a>
40	<a href="#">9050814M1000</a> Spring, torsion (6e0)	<a href="#">Buy now</a>
41	<a href="#">9050814M1100</a> Spring, torsion (6e0)	<a href="#">Buy now</a>
42	<a href="#">958800601000</a> Bolt, flange(7ht)	<a href="#">Buy now</a>
43	<a href="#">6E0425370200</a> Bushing, pivot shaft	<a href="#">Buy now</a>
44	<a href="#">6E0425380200</a> Bushing, pivot shaft	<a href="#">Buy now</a>
45	<a href="#">6E0425390000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
46	<a href="#">6E0425490000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
47	<a href="#">6E0425280300</a> Plate, friction	<a href="#">Buy now</a>
48	<a href="#">988800810000</a> Nut, hex.	<a href="#">Buy now</a>

## Upper Casing & Bracket



Ref	Part	
49	<a href="#">9050208M0500</a> Spring, conical(6e0)	<a href="#">Buy now</a>
50	<a href="#">6L5425290100</a> Screw, friction piece	<a href="#">Buy now</a>
51	<a href="#">6L5425610000</a> Knob, steering lock	<a href="#">Buy now</a>
52	<a href="#">6L5441960000</a> Indicator 3	<a href="#">Buy now</a>
53	<a href="#">6L5441970000</a> Indicator 4	<a href="#">Buy now</a>
54	<a href="#">9026604M0500</a> Rivet(6I5)	<a href="#">Buy now</a>
55	<a href="#">6E0281930094</a> Plug, water check	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.