



Yamaha 90AETO 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	10
CARBURETOR	13
CONTROL	17
CRANKSHAFT. PISTON	21
CYLINDER. CRANKCASE	24
ELECTRICAL	28
FUEL	32
FUEL TANK	35
GENERATOR	36
INTAKE	38
LOWER CASING. DRIVE 1	40
LOWER CASING. DRIVE 2	46
METER	49
OIL PUMP	51
POWER TRIM & TILT ASSY	55
REMOTE CONTROL ASSY	61
REMOTE CONTROL BOX	66
REPAIR KIT 1	67
REPAIR KIT 2	69
STARTING MOTOR	71
STEERING GUIDE	73
TOP COWLING	74
UPPER CASING	77

Bottom Cowling




6H12300-2110

Ref	Part	
1	6H1-42711-01-4D Cowling, bottom 1	Buy now
2	6H3-44391-01 Nipple, hose	Buy now
3	688-42815-01-4D Lever, clamp	Buy now
4	688-42817-01-4D Lever, clamp	Buy now
5	90386-13M38 Bushing (697)	Buy now
6	90206-13019 Washer, wave 6264283200	Buy now
7	688-42816-00 Lever, clamp 2	Buy now
8	90119-06M09 Bolt, with washer	Buy now
9	688-42716-02 Rubber seal 1	Buy now
10	663-42724-00 Grommet	Buy now
11	688-42725-20 Grommet	Buy now
12	688-42738-01-94 Plate, fitting	Buy now
13	97095-06016 Bolt, hexagon deep recess	Buy now
14	92995-06600 Washer, plain (646)	Buy now
15	90480-09M12 Grommet (6a0)	Buy now

D1

Bottom Cowling




6H12300-2110

D1

Ref	Part	
16	90387-06M69 Collar (688)	Buy now
17	90201-06416 Washer, plate(663)	Buy now
18	97095-06030 Bolt(jf7)	Buy now
19	90119-06M61 Bolt, with washer	Buy now
20	90157-06M01 Screw (6e5)	Buy now
21	90464-15M08 Clamp (6h1)	Buy now
22	688-42726-10 Grommet	Buy now
23	6G1-42748-00 Grommet	Buy now
24	688-42741-01-4D Apron	Buy now
25	688-42771-01-4D Apron	Buy now
26	97095-06020 Bolt(7u8)	Buy now
27	92995-06100 Washer(6a1)	Buy now
30	6E5-24367-01 Clamp, fuel pipe 2	Buy now
31	92990-06600 Washer, plain (646)	Buy now
32	6G5-42791-10 Mark 1	Buy now

Bottom Cowling




 FWD
6H12300-2110

D1

Ref	Part	
33	6A1-28176-00 Label Caution	Buy now
34	6E3-8257H-00 Plate Mark	Buy now


Bracket 1



D5

Ref	Part	
1	6H1-43111-01-4D Bracket, clamp 1	Buy now
2	6H1-45251-03 Anode	Buy now
3	6H1-44526-00 Plate 2	Buy now
4	90119-06M29 Bolt, with washer	Buy now
5	97095-06016 Bolt, hexagon deep recess	Buy now
6	92995-06100 Washer(6a1)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	6H1-82148-00 Wire, lead	Buy now
9	97095-06010 Bolt	Buy now
11	6H1-43112-00-4D Bracket, clamp 2	Buy now
12	6E5-82148-00 Wire, lead 5	Buy now
13	97880-06012 Screw, pan head(62j)	Buy now
14	97095-10045 Bolt(64d)	Buy now
15	92995-10100 Ybs67-10 washer, spring	Buy now
16	6H1-43311-01-4D Bracket, swivel 1	Buy now


Bracket 1



D5

Ref	Part	
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	663-45119-00 Cap, grease nipple	Buy now
19	90464-11M18 Clamp(6e5)	Buy now
20	90338-05M03 Plug (6h1)	Buy now
21	688-43131-03 Bolt, clamp bracket	Buy now
22	90386-22M15 Bushing (688)	Buy now
23	90201-22M67 Washer, plate (688)	Buy now
24	90185-22043 Nut, self-locking	Buy now
25	6G5-43145-01 Cap, clamp bracket	Buy now
26	6H1-43181-01 Lever, tilt stop 1	Buy now
27	6H1-43185-01 Lever, tilt stop 2	Buy now
28	90386-10M16 Bushing (688)	Buy now
29	6G5-43148-00 Collar, distance	Buy now
30	91690-30020 Pin, spring (6h4)	Buy now
31	90249-06M19 Pin(6e5)	Buy now

Bracket 1




D5

Ref	Part	
32	90387-10M02 Collar(6e5)	Buy now
33	90506-14M24 Spring, tension(6e5)	Buy now
34	6G5-43144-00 Hook, spring	Buy now
36	688-43160-01 Tilt rod ass'y	Buy now
37	688-43165-00 Stopper, tilt rod	Buy now
38	91690-30012 Pin, spring	Buy now
39	90502-16M02 Spring, conical (688)	Buy now
40	6E5-43126-02 Pin, upper shock mount	Buy now
41	90386-18M35 Bush (688)	Buy now
42	93410-18M02 Circlip (6f2)	Buy now
43	90386-18M63 Bush(6e5)	Buy now
44	90101-12M65 Bolt	Buy now
45	92995-12200 Ybs66-12 washer,plain	Buy now
46	90201-12426 Washe, plate(663)	Buy now
47	95380-12600 Nut (707)	Buy now

Bracket 1


Ref	Part	
48	90440-14M00 Pipe(6h4)	Buy now



6H10010-0151


D5

Bracket 2




Ref	Part	
1	6H1-83672-12 Trim sender	Buy now
2	97885-06016 Screw, pan head(6b0)	Buy now
3	688-42510-02-4D Steering bracket assembly	Buy now
4	90201-30M00 Washer, plate(6h1)	Buy now
5	90386-30M78 Bush(6h0)	Buy now
6	90386-30M77 Bush(6h0)	Buy now
7	93210-29M94 O-ring(6h1)	Buy now
8	90386-30M60 Bush(6j8)	Buy now
9	663-44551-02-4D Housing, lower mount rubber	Buy now
10	93410-28M06 Circlip (688)	Buy now
11	687-44555-00-94 Mount damper, lower side	Buy now
12	90201-12M16 Washer, plate (679)	Buy now
13	90202-25M04 Washer, plate (663)	Buy now
14	90201-13M19 Washer, plate (663)	Buy now
15	90109-12261 Bolt(663)	Buy now

Bracket 2



Ref	Part	
16	663-44575-00 Damper, lower mount rubber	Buy now
17	95380-12800 Nut crown(663)	Buy now
18	687-44552-02-94 Housing, lower mount rubber	Buy now
19	97075-08025 Bolt, hexagon deep recess	Buy now
20	92995-08100 Ybs67-8 washer, spring	Buy now
21	90501-14M08 Spring, compression(64j)	Buy now
22	90179-06066 Nut(663)	Buy now
23	663-44553-01-4D Cover, lower mount	Buy now
25	688-82127-02 Wire, lead 2	Buy now
26	688-44514-00-94 Mount damper, upper side	Buy now
27	90101-10M49 Bolt	Buy now
28	90201-20M21 Washer, plate (688)	Buy now
29	90202-20M06 Washer, plate (688)	Buy now
30	90201-11M22 Washer, plate (688)	Buy now
31	90185-10051 Nut, self-locking	Buy now


Bracket 2



D7

Ref	Part	
33	688-44511-00-94 Cover, upper mount	Buy now
34	97075-08035 Bolt(70w)	Buy now
36	688-48511-11-4D Hook, steering STEERING GUIDE	Buy now
37	90116-10M28 Bolt, stud	Buy now
39	6H1-43376-00 Bolt, thrust receiver	Buy now
40	90185-08057 Nut, nylon (6j8)	Buy now
41	90465-11M10 Clamp	Buy now
42	703-82119-00 Cover, lead wire AP	Buy now


Carburetor



B5

Ref	Part	
1	6H0-14301-07 Carburetor assembly 1	Buy now
1	6H1-14301-07 Carburetor assembly 1	Buy now
2	6H0-14302-07 Carburetor assembly 2	Buy now
2	6H1-14302-07 Carburetor assembly 2	Buy now
3	6H0-14303-07 Carburetor assembly 3	Buy now
3	6H1-14303-07 Carburetor assembly 3	Buy now
4	97980-04114 Screw, pan head(ga5)	Buy now
5	63V-14523-00 Screw, stop #2	Buy now
6	90501-10326 Spring coil(663)(carb) #2	Buy now
7	6H2-14578-00 Collar #3	Buy now
8	6H4-14146-00 Plate #1,3	Buy now
9	6H3-14146-10 Plate #2	Buy now
10	6H4-14147-00 O-ring	Buy now
11	692-14923-00 Screw, adjusting	Buy now
12	697-14555-00 Spring	Buy now


Carburetor



B5

Ref	Part	
13	93210-04228 O-ring (371)	Buy now
14	692-14590-00 Needle valve assembly	Buy now
15	6H4-14548-00 Pin, float arm	Buy now
16	98580-04008 Screw, pan head (713)	Buy now
17	663-14159-00 Clip	Buy now
18	676-14186-00 Pin, valve	Buy now
19	6H4-14985-01 Float	Buy now
20	6H1-14947-75 Jet, needle	Buy now
21	6H1-14943-39 Jet, main (#160)	Buy now
22	676-14966-00 Rubber cap	Buy now
23	6H1-14948-18 Jet (#78)	Buy now
24	6H4-14984-00 Gasket, float chamber	Buy now
25	6H3-14992-00 Screw, drain	Buy now
26	93210-04230 O-ring (371)	Buy now
27	6H4-14980-00 Body, float chamber #1,3	Buy now


Carburetor



B5

Ref	Part	
28	6H3-14980-10 Body, float chamber #2	Buy now
29	6H3-24452-10 Cover #2	Buy now
30	6H4-14567-00 Screw #2	Buy now
31	6H3-14137-00 Clip #2	Buy now
32	6H3-14349-00 Pipe #2	Buy now
33	6H3-14380-00 Prime starter assembly #2	Buy now
34	97803-04008 Screw, pan head (713) #2	Buy now
35	95380-03600 Nut (6g8) #2	Buy now
36	98980-03006 Screw, bind(6g1) #2	Buy now
37	6L5-24421-00 Valve, check #2	Buy now
38	6H4-24413-00 Body 2 #2	Buy now
39	6H4-24486-00 O-ring #2	Buy now
40	6H3-24411-10 Diaphragm #2	Buy now
41	6H3-24434-10 Gasket, body #2	Buy now
42	90465-18147 Clamp	Buy now

Carburetor




6H30010-4050

B5


Ref	Part	
43	97013-06012 Bolt(gh1)	Buy now
44	92903-06600 Washer, plain (646)	Buy now

Control




D3

Ref	Part	
1	663-48531-00 Bracket, remote control	Buy now
2	663-48538-00 Clamp, cable 1	Buy now
3	91690-30012 Pin, spring	Buy now
4	97095-08016 Bolt, hexagon deep recess	Buy now
5	92995-08100 Ybs67-8 washer, spring	Buy now
6	663-48344-00 Cable end, remote control	Buy now
7	688-41632-01-94 Lever, magneto control	Buy now
8	662-41214-01 Joint 1	Buy now
9	90468-18008 Clip 620436610000	Buy now
10	97095-08045 Bolt, hexagon	Buy now
11	90201-08M23 Washer, plate (6e5)	Buy now
12	90386-12089 Bushing(663)	Buy now
13	90387-08M16 Collar	Buy now
14	90386-22M13 Bushing (688)	Buy now
15	90202-12092 Washer, plate(663)	Buy now




D3

Ref	Part	
16	90201-08M13 Washer plate (682)	Buy now
17	90508-29M05 Spring, torsion (688)	Buy now
18	688-41631-01-94 Lever, magneto control	Buy now
19	6F5-41237-00 Joint, link	Buy now
20	90157-06013 Screw, pan head(697)	Buy now
21	688-44194-00 Cap	Buy now
22	95303-06600 Nut(661)	Buy now
23	90501-16M12 Spring, compression (688)	Buy now
24	6H1-41636-00 Rod, magneto control	Buy now
25	95380-05600 Nut, hexagon (663)	Buy now
26	662-41237-01 Joint, link	Buy now
27	688-41211-01 Link, accel	Buy now
29	682-41237-00 Joint, link 2	Buy now
30	6H1-41213-00 Cam, Accel	Buy now
31	90387-06M17 Collar, lever 1	Buy now



D3


Ref	Part	
32	90206-10M04 Washer, wave (676)	Buy now
33	90119-06M24 Bolt, with washer	Buy now
34	688-44117-00-94 Bracket 1	Buy now
35	97013-06020 Bolt(62y)	Buy now
36	92903-06600 Washer, plain (646)	Buy now
37	688-44124-00 Link, shift rod	Buy now
38	688-44122-00 Bushing, shift rod lever	Buy now
39	90202-07M07 Washer, plate (688)	Buy now
41	6H1-44121-00 Lever, shift rod 1	Buy now
42	688-44118-00-94 Bracket	Buy now
43	97013-08030 Bolt	Buy now
44	92903-08100 Ybs67-8 washer, spring	Buy now
45	92903-08600 Washer, plain (663)	Buy now
46	93501-04M02 Ball (697)	Buy now
47	90501-12082 Spring 6484411600	Buy now



D3

Ref	Part	
48	648-42715-00 Bushing 2	Buy now
49	6H1-44120-12 Handle gear shift assembly L	Buy now
50	90386-07M58 Bush(6h1)	Buy now
51	92990-08200 Ybs66-8 washer, plain	Buy now


Crankshaft. Piston



B2


Ref	Part	
1	6H1-15359-01-94 Housing, oil seal	Buy now
2	688-11370-00 Check valve assembly	Buy now
3	93102-30M05 Oil seal (688)	Buy now
4	93104-20M02 Oil seal (688)	Buy now
5	93210-62269 Ring, o(663)	Buy now
6	688-15379-00 Seal, crank case	Buy now
7	90445-07M86 Hose (l770)	Buy now
8	90467-06016 Clip (655)	Buy now
9	97095-06020 Bolt(7u8)	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	688-11411-01 Crank, shaft	Buy now
12	93310-636U4 Bearing (688)	Buy now
13	93102-36M02 Oil seal(52w)	Buy now
14	93210-46M16 O-ring (688)	Buy now
15	93310-835U8 Brg,cyl-cal roller (688)	Buy now

Crankshaft. Piston



Ref	Part	
16	93306-206U5 Brg,r-b 6206 66mm (688)	Buy now
17	93410-32M00 Circlip	Buy now
18	6H1-11631-03-95 Piston (std)	Buy now
18	6H1-11635-03 Piston (0.25mm o/s) AP	Buy now
18	6H1-11636-03 Piston (0.50mm o/s) AP	Buy now
19	688-11603-A0 Piston ring set (std)	Buy now
19	688-11604-A0 Piston ring set (0.25mm o/s) AP	Buy now
19	688-11605-A0 Piston ring set (0.50mm o/s) AP	Buy now
20	663-11633-00 Pin, piston	Buy now
21	688-11634-10 Clip, piston pin	Buy now
22	688-11650-03 Connecting rod assembly	Buy now
23	90109-08022 Bolt	Buy now
24	93603-21111 Pin, dowel(663)	Buy now
25	90201-20417 Washer, plate(663)	Buy now
26	93310-730V8 Bearing (688)	Buy now

Crankshaft. Piston




6H10010-0031

B2


Ref	Part	
27	6H1-11536-00 Gear, drive	Buy now

Cylinder. Crankcase



Ref	Part	
3	688-11370-00 Check valve assembly	Buy now
4	650-11370-00 Check valve assembly	Buy now
5	624-14485-00 Pipe, joint	Buy now
6	663-11518-01 Lock, bearing	Buy now
7	650-24378-00 Pipe, joint 2	Buy now
8	93608-12063 Pin, dowel (626)	Buy now
9	90119-06M12 Bolt, with washer (697)	Buy now
10	90119-10005 Bolt, with washer	Buy now
11	90201-10008 Washer, plate	Buy now
12	95313-10600 Nut(3bm)	Buy now
13	90157-06014 Screw, pan head(697)	Buy now
14	688-44194-00 Cap	Buy now
15	95303-06700 Nut	Buy now
16	90445-07260 Hose (I390)	Buy now
17	90467-06016 Clip (655)	Buy now

Cylinder. Crankcase




6H12200-2020

A6

Ref	Part	
18	90480-24M04 Grommet (688)	Buy now
19	90445-07M00 Hose (I200)	Buy now
20	90445-07M23 Hose (I570)	Buy now
22	90116-10M06 Bolt, stud (688)	Buy now
23	90465-12M03 Clamp, cord (688)	Buy now
24	97095-06014 Bolt(gj3)	Buy now
25	92995-06100 Washer(6a1)	Buy now
26	688-11325-00 Anode	Buy now
27	98780-04015 Screw, flat head(ga5)	Buy now
28	688-11119-01 Hanger, engine	Buy now
29	90119-08MA3 Bolt, with washer	Buy now
30	6H1-11111-01-1S Head, cylinder 1	Buy now
31	688-11181-A1 Gasket, cylinder head 1	Buy now
32	90119-08MA8 Bolt, with washer	Buy now
33	90340-14M00 Plug, straight screw(62y)	Buy now

Cylinder. Crankcase




6H12200-2020

Aa

Ref	Part	
34	90430-14115 Gasket (663)	Buy now
35	688-11191-00-1S Cover, cylinder head 1	Buy now
36	688-11193-A1 Gasket, head cover 1	Buy now
37	90119-06MA3 Bolt, with washer	Buy now
38	90480-20M05 Grommet (688)	Buy now
39	688-12416-00 Valve, pressure control	Buy now
40	90501-16M11 Spring, compression (688)	Buy now
41	688-12411-10 Thermostat	Buy now
42	688-12413-00-1S Cover, thermostat	Buy now
43	688-12414-A1 Gasket, cover	Buy now
44	90119-06MA5 Bolt, with washer	Buy now
45	688-41111-00-1S Inner cover, exhaust	Buy now
46	688-41112-A0 Gasket, exhaust inner cover	Buy now
47	688-41114-A0 Gasket, exhaust outer cover	Buy now
48	688-41113-00-1S Outer cover, exhaust	Buy now


Cylinder. Crankcase



6H12200-2020

A6


Ref	Part	
49	663-24312-01 Pipe 1	Buy now
50	90467-08004 Clip, pipe 6162435600	Buy now
51	90119-08020 Bolt, with washer	Buy now
52	6H1-15772-00 Stay 2	Buy now
53	97095-06012 Bolt(gh1)	Buy now
54	6H1-15773-01 Stay 3	Buy now
55	6H1-21796-00 Hinge	Buy now
56	97095-08012 Bolt, hexagon deep recess	Buy now
57	94702-00247 Plug, spark (br8hs-10)	Buy now



6H12200-2090

C5


Ref	Part	
1	6H0-85540-05 C.d.i. unit assembly	Buy now
2	703-82119-00 Cover, lead wire	Buy now
3	6H1-85542-10 Bracket	Buy now
4	90465-13M11 Clamp (6e5)	Buy now
5	97095-06050 Bolt(jf7)	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	697-85570-00 Ignition coil assembly	Buy now
8	97013-06020 Bolt(62y)	Buy now
9	92903-06600 Washer, plain (646)	Buy now
10	6H0-81960-10 Rectifier & regulator assembly	Buy now
11	97095-06020 Bolt(7u8)	Buy now
13	90465-08M23 Clamp (6h3)	Buy now
14	97095-06012 Bolt(gh1)	Buy now
15	92995-06100 Washer(6a1)	Buy now
16	6G1-81941-10 Starter relay	Buy now



6H12200-2090

C5

Ref	Part	
17	6G1-81952-00 Holder, relay	Buy now
18	6E9-81945-70 Plate, switch fitting	Buy now
19	97013-06016 Bolt, hexagon deep recess	Buy now
21	6G5-82152-00 Holder, fuse	Buy now
22	6H1-85542-00-94 Bracket	Buy now
23	90480-09M25 Grommet(688)	Buy now
24	90387-06M03 Collar (676)	Buy now
25	90119-06M75 Bolt, with washer	Buy now
26	90109-06M39 Bolt(6h0)	Buy now
27	90201-06M31 Washer (6a0)	Buy now
28	6H1-81916-00 Cover, terminal	Buy now
29	90159-06M11 Screw, with washer(6l2)	Buy now
30	6E3-82370-21 Plug cap assembly	Buy now
31	688-82560-10 Thermo switch assembly	Buy now
32	688-82588-01 Plate	Buy now




6H12200-2090

C5

Ref	Part	
33	6H0-82590-12 Wire harness assembly (10p)	Buy now
34	663-82151-00 Fuse	Buy now
35	6H0-82105-02 Battery cable	Buy now
36	90464-23M22 Clamp	Buy now
37	6H0-82117-00 Wire, lead	Buy now
38	697-82519-00 Wire,earth lead	Buy now
39	688-82594-00 Clamp	Buy now
40	61A-81950-00 Relay assembly	Buy now
41	97095-06025 Bolt	Buy now
43	682-82119-01 Cover, lead wire	Buy now
44	6H0-81949-10 Wire, lead	Buy now
45	6H0-81949-01 Wire, lead	Buy now
47	6H1-82563-10 Trim & tilt switch assembly	Buy now
48	6E5-82587-00 Gasket	Buy now
49	6H1-83614-00 Braket	Buy now

Electrical




6H12200-2090

C5

Ref	Part	
50	97095-06016 Bolt, hexagon deep recess	Buy now
51	90464-18M14 Clamp(6h1)	Buy now
52	6R5-85711-60 Mark, caution	Buy now


Fuel



6H10010-007C


C2

Ref	Part	
1	6G1-24304-02 Fuel pipe joint comp. 1	Buy now
2	97095-06020 Bolt(7u8)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	90445-09105 Hose (l420)	Buy now
5	90467-08004 Clip, pipe 6162435600	Buy now
6	61N-24560-00 Filter assembly	Buy now
7	61N-24563-00 Element, filter	Buy now
8	61N-24521-00 Cup, filter	Buy now
9	93210-32738 O-ring(1wg)	Buy now
10	6H1-24566-01 Bracket, filter	Buy now
11	95380-08600 Nut (661)	Buy now
12	692-24410-00 Fuel pump assembly	Buy now
13	6A0-24413-00 Cover, pump	Buy now
14	692-24411-00 Diaphragm	Buy now
15	648-24434-01 Gasket, body	Buy now



C2


Ref	Part	
16	95380-03600 Nut (6g8)	Buy now
17	663-24411-00 Diaphragm	Buy now
18	648-24435-02 Gasket, body 2	Buy now
19	98503-05028 Ybs86-530 screw,panhead	Buy now
20	92990-05100 Ybs67-5 washer, spring	Buy now
21	6A0-24421-01 Valve, check	Buy now
22	6A0-14325-00 Screw, pan head	Buy now
23	6A0-24412-02 Body 1	Buy now
24	650-24431-A0 Gasket,fuel pump	Buy now
25	97095-06040 Bolt (682)	Buy now
27	6H1-24314-00 Pipe 4	Buy now
29	90445-09097 Hose (I1500)	Buy now
30	688-24313-00 Pipe, fuel 2	Buy now
31	688-24314-00 Pipe, fuel 2	Buy now
33	90445-09220 Hose (I1500)	Buy now



Ref	Part	
34	688-24378-00 Pipe, joint	Buy now
35	656-W2810-02 Tool kit	Buy now
36	6E0-28193-00-94 Plug, water check AP D)12.5MM	Buy now

C2


Fuel Tank



F5

Ref	Part	
1	6YK-24201-01 Fuel Tank assembly (25L) AP PLASTIC, 25L,	Buy now
2	6YL-24268-01 Gasket, fuel meter	Buy now
3	6YK-24610-00 Cap assembly WITH INDICATOR	Buy now
4	6YL-24641-00 Gasket, cap 1	Buy now
5	6YK-24260-01 Fuel meter assembly	Buy now
6	90157-05M16 Screw, pan head	Buy now
7	6YL-24329-00 Seal	Buy now
8	6YL-24306-52 Fuel pipe comp. 1 AP	Buy now

Generator




6H12200-2080

C4

Ref	Part	
1	6H0-85550-00 Rotor assembly	Buy now
2	6H0-85510-03 Stator assembly	Buy now
3	6H0-85580-01 Coil, pulser	Buy now
4	6H2-85895-01 Crank position sender	Buy now
5	97095-05012 Bolt, hexagon	Buy now
6	97095-06040 Bolt (682)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	90280-05015 Key, woodruff	Buy now
9	90170-20137 Nut, hexagon(663)	Buy now
10	90201-21M18 Washer, plate (663)	Buy now
11	688-81332-01 Plate, timing	Buy now
12	97095-06010 Bolt	Buy now
14	6H1-81337-01 Cover, flywheel	Buy now
15	90159-06M20 Screw, with washer(6h0)	Buy now
16	90465-06M90 Clamp	Buy now

Generator




6H12200-2080

C4

Ref	Part	
17	97095-06012 Bolt(gh1)	Buy now
19	6H1-14488-00 Label, caution	Buy now
20	6H1-13437-21 Mark, caution	Buy now


Intake



B4

Ref	Part	
1	90445-07M23 Hose (I570)	Buy now
2	90467-06016 Clip (655)	Buy now
3	688-41217-01 Rod, accel. lever	Buy now
4	6H3-14349-00 Pipe	Buy now
5	90467-08004 Clip, pipe 6162435600	Buy now
6	6H1-13641-02-94 Manifold, intake 1 & hose	Buy now
7	6H1-14485-00 Pipe, joint	Buy now
8	97095-06095 Bolt, hexagon deep recess	Buy now
9	93210-39ME4 O-ring(6h2)	Buy now
10	688-13621-A1 Gasket, valve seat	Buy now
11	688-13624-00 Plate, reed valve	Buy now
12	688-13610-00 Reed valve assembly	Buy now
13	688-W0004-00 Reed set	Buy now
14	97880-05020 Screw, pan head (e22)	Buy now
15	92990-05100 Ybs67-5 washer, spring	Buy now


Intake



Ref	Part	
16	97013-06030 Bolt	Buy now
17	92903-06100 Washer(6a1)	Buy now
18	6H1-14440-02 Silencer assembly	Buy now
19	93210-46044 O-ring	Buy now
20	97885-06050 Screw pan head	Buy now
21	90209-06M05 Washer (688)	Buy now
22	6H1-14413-02 Stay	Buy now
23	6H1-85711-60 Mark, caution	Buy now
24	6A1-83625-41 Mark 5	Buy now
25	6A1-83625-51 Mark 5	Buy now

B4


Lower Casing. Drive 1



E6


Ref	Part	
1	6H1-45300-15-4D Lower unit assembly L	Buy now
2	6H1-45301-03-4D Lower casing set	Buy now
3	93315-325V1 Bearing, needle (688)	Buy now
4	688-45536-01 Sleeve, drive shaft	Buy now
5	688-45587-01-10 Shim (t:0.10mm) UR	Buy now
5	688-45587-01-12 Shim (t:0.12mm) UR	Buy now
5	688-45587-01-15 Shim (t:0.15mm) UR	Buy now
5	688-45587-01-18 Shim (t:0.18mm) UR	Buy now
5	688-45587-01-30 Shim (t:0.30mm) UR	Buy now
5	688-45587-01-40 Shim (t:0.40mm) UR	Buy now
5	688-45587-01-50 Shim (t:0.50mm) UR	Buy now
6	93332-000U3 Brg,tapered roller 50mm (688)	Buy now
7	688-45567-01-10 Shim (t:0.10mm) UR	Buy now
7	688-45567-01-12 Shim (t:0.12mm) UR	Buy now
7	688-45567-01-15 Shim (t:0.15mm) UR	Buy now

Lower Casing. Drive 1



Ref	Part	
7	688-45567-01-18 Shim (t:0.18mm) UR	Buy now
7	688-45567-01-30 Shim (t:0.30mm) UR	Buy now
7	688-45567-01-40 Shim (t:0.40mm) UR	Buy now
7	688-45567-01-50 Shim (t:0.50mm) UR	Buy now
8	93332-000W7 Bearing(6b0)	Buy now
9	90340-08002 Plug, straight screw	Buy now
10	688-45341-10 Plug, drain	Buy now
11	90430-08020 Gasket	Buy now
12	6H1-45214-00 Cover, water inlet	Buy now
13	6H1-45215-00 Cover, water inlet	Buy now
14	90151-05M00 Screw, countersunk(692)	Buy now
15	90185-05002 Nut nylon (sus)(ex4)	Buy now
16	688-45321-00 Plate	Buy now
17	93210-49046 O-ring (620)	Buy now
18	93106-09014 Oil seal	Buy now


Lower Casing. Drive 1



E6

Ref	Part	
19	97095-06016 Bolt, hexagon deep recess	Buy now
20	92995-06600 Washer, plain (646)	Buy now
21	688-44311-01 Housing, water pump 1	Buy now
22	688-44322-00 Insert, cartridge	Buy now
23	688-44315-A0 Gasket,water pump 1	Buy now
24	688-44352-03 Impeller	Buy now
25	90280-04M04 Key, woodruff (688)	Buy now
26	688-44341-01-94 Housing, water pump set	Buy now
27	93101-25M03 Oil seal	Buy now
28	93210-46044 O-ring	Buy now
29	688-44316-A0 Gasket,water pump 2	Buy now
30	688-44323-00 Outer plate, cartridge	Buy now
31	688-44324-A0 Gasket,cartridge Outer plate	Buy now
32	93604-10M03 Pin, dowel (688)	Buy now
33	90119-08M16 Bolt, with washer(6h0)	Buy now


Lower Casing. Drive 1



E6

Ref	Part	
34	90119-08M13 Bolt, with washer(6h0)	Buy now
35	6H1-45501-11 Drive shaft comp. L	Buy now
36	688-45551-01 Pinion	Buy now
37	90170-16M01 Nut, hexagon (688)	Buy now
38	688-45560-00 Gear 1 (26t)	Buy now
39	6H1-45611-01 Shaft, propeller	Buy now
40	90501-12M48 Spring (6h1)	Buy now
41	6H1-45641-01 Shifter	Buy now
42	93603-12M11 Pin, dowel(6h1)	Buy now
43	6H1-45634-02 Slide, shift	Buy now
44	90501-16M65 Spring, compression(6h1)	Buy now
45	93503-16003 Ball	Buy now
46	6H1-45668-00 Shaft, free 1	Buy now
47	90201-03313 Washer, plate 8077743700	Buy now
48	90183-02M03 Nut, spring (6h1)	Buy now


Lower Casing. Drive 1



E6

Ref	Part	
49	6H1-45631-01 Clutch, dog	Buy now
50	90250-07M02 Pin, straight (688)	Buy now
51	688-45633-00 Ping, cross pin	Buy now
52	6H1-45635-00 Plunger, shift	Buy now
53	6H1-45571-00 Gear 2	Buy now
54	688-45331-00-94 Housing, bearing	Buy now
55	93306-207U0 Brg,r-b 6207 72mm 280g (688)	Buy now
56	688-45577-01-10 Shim (t:0.10mm) UR	Buy now
56	688-45577-01-12 Shim (t:0.12mm) UR	Buy now
56	688-45577-01-15 Shim (t:0.15mm) UR	Buy now
56	688-45577-01-18 Shim (t:0.18mm) UR	Buy now
56	688-45577-01-30 Shim (t:0.30mm) UR	Buy now
56	688-45577-01-40 Shim (t:0.40mm) UR	Buy now
56	688-45577-01-50 Shim (t:0.50mm) UR	Buy now
57	688-45576-00 Washer, thrust 2	Buy now

Lower Casing. Drive 1




6H10664-4170

E6

Ref	Part	
58	93210-85M97 O-ring(6h1)	Buy now
59	93317-325U0 Brg,needle	Buy now
61	688-45383-02 Washer, claw	Buy now
62	688-45384-00 Nut	Buy now
63	90282-04010 Key, strait(663)	Buy now
64	6E5-45378-00 Nipple, hose	Buy now
65	90445-07ME9 Hose (l250) L	Buy now
66	6E5-83558-10 End, nipple	Buy now
67	90465-11M10 Clamp	Buy now
68	6H1-44151-00 Cam, shift	Buy now
69	6H1-44144-00 Rod, shift 2	Buy now
70	93210-07003 O-ring (11m)	Buy now
71	99001-08600 Circlip(2r6)	Buy now
72	93450-07M00 Circlip (6e5)	Buy now


Lower Casing. Drive 2



F3


Ref	Part	
1	663-44367-00 Damper, water seal 3	Buy now
2	688-44361-10 Tube, water 1 L	Buy now
3	90202-12060 Washer, plate(663)	Buy now
4	90430-12072 Gasket	Buy now
5	93606-12019 Pin, dowel (614)	Buy now
6	97075-10040 Bolt, hexagon deep recess	Buy now
7	92990-10600 Washer, plate	Buy now
8	92990-10100 Ybs67-10 washer, spring	Buy now
9	90119-08M84 Bolt, with washer	Buy now
10	663-45376-00-94 Guide, seal damper	Buy now
11	688-45375-00 Damper, seal 2	Buy now
12	688-45371-02 Tab-trim	Buy now
13	90105-10M67 Bolt, hexagon (663)	Buy now
14	663-44366-00 Damper, water seal 2	Buy now
15	90480-19M06 Grommet (688)	Buy now

Lower Casing. Drive 2




Ref	Part	
16	97780-40512 Screw, pan head tapping	Buy now
17	688-45987-01 Spacer	Buy now
18	688-45997-01 Spacer 2	Buy now
19	90201-17M00 Washer, plate(6h1)	Buy now
20	90171-16011 Nut, castle (663)	Buy now
21	91490-40025 Pin, cotter (663)	Buy now
22	6E5-45941-00-EL Propeller (3x13x19-k) UR	Buy now
22	6E5-45943-00-EL Propeller (3x12-5/8"x21"-k) UR	Buy now
22	6E5-45945-01-EL Propeller (3x13-1/4x17-k) UR	Buy now
22	6E5-45947-00-EL Propeller (3x13-1/2x15-k) UR	Buy now
22	6E5-45949-00-EL Propeller (3x13-5/8"x13"-k) UR	Buy now
22	6E5-45952-00-EL Propeller (3x13"x23"-k) UR	Buy now
22	688-45930-02-98 Propeller (3x13x17) UR	Buy now
22	688-45932-60-98 Propeller (3x13-1/2"x14"-k) UR	Buy now
22	688-45970-03-98 Propeller (3x13"x19"-k) UR	Buy now

Lower Casing. Drive 2




Ref	Part	
22	688-45972-02-98 Propeller (3x13"x21"-k) UR	Buy now
22	688-45974-02-98 Propeller (3x13"x23"-k) UR	Buy now
22	688-45976-01-98 Propeller (ss 3x13"x25"-k) UR	Buy now
22	688-45978-60-98 Propeller (3x13-1/2"x16"-k) UR	Buy now
22	6E5-45954-00-EL Propeller (3x14"x11"-k) UR	Buy now
22	6E5-45956-00-EL Propeller (3x13"x25"-k) UR	Buy now
23	6E5-45970-10 Propeller (ss 3x14"x20"-p) UR	Buy now
23	6E5-45972-10 Propeller (ss 3x14"x24"-p) UR	Buy now
23	6E5-45974-10 Propeller (ss 3x14"x28"-p) UR	Buy now
23	6E5-45976-10 Propellar assembly (3x14"x22"-p) UR	Buy now
23	6E5-45978-10 Propeller assembly (3x14"x26"-p) UR	Buy now
24	6E5-45994-10 Plate, tooth	Buy now
25	6E5-45371-10 Tab-trim	Buy now
26	90445-07MF1 Hose (I570)	Buy now
27	6E5-83558-00 End, nipple	Buy now

Meter



Ref	Part	
1	6Y5-8350T-01 Digital tachometer assembly AP	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83500-S5 Meter assembly AP	Buy now
7	6Y5-83570-S5 Speedometer assembly	Buy now
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
20	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a)	Buy now

Meter




6H12300-2230

A7

Ref	Part	
17	6Y5-82117-00 Wire, lead AP	Buy now
18	68F-82553-70 Extension, wire lead (7m) AP	Buy now
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now
21	6H4-81315-11 Lead wire assembly AP	Buy now


Oil Pump



B7

Ref	Part	
1	6H1-13200-02 Oil injection pump assembly	Buy now
2	6R3-13471-00 Screw	Buy now
3	6L2-13475-00 Gasket, breather bolt	Buy now
4	93210-19MA7 O-ring(6r0)	Buy now
5	90109-06M39 Bolt(6h0)	Buy now
6	90109-06M40 Bolt(6h0)	Buy now
7	90468-07M02 Clip (6e5)	Buy now
8	90445-07M90 Hose (l390)	Buy now
9	90445-07240 Hose (l390)	Buy now
10	90445-07M44 Hose (l390)	Buy now
12	90445-07M87 Hose(62t)	Buy now
13	6E9-13183-70 Valve check	Buy now
15	90464-07M05 Clamp (6g5)	Buy now
16	6H1-11537-01 Gear, driven	Buy now
17	90201-08M93 Washer, plate (6g5)	Buy now


Oil Pump



B7

Ref	Part	
18	6H1-13117-01 Collar, distance	Buy now
19	93210-13M04 93210-13m04	Buy now
20	6H1-41241-02 Rod, link	Buy now
21	6H1-41237-00 Joint, link	Buy now
22	95380-05600 Nut, hexagon (663)	Buy now
23	90202-05088 Washer, plate (666)	Buy now
24	90468-05M03 Clip(6j8)	Buy now
25	6E9-41237-00 Joint, link	Buy now
26	6H1-21707-07 Oil tank comp.	Buy now
27	90445-11M09 Hose (l600)	Buy now
28	90464-11M24 Clamp(6h1)	Buy now
29	90465-11M27 Clamp(6h1)	Buy now
30	90467-11M08 Clip(72x)	Buy now
31	97095-06016 Bolt, hexagon deep recess	Buy now
32	90387-06M31 Coller (6a0)	Buy now


Oil Pump



B7

Ref	Part	
33	6H1-21752-00 Tube, filler 1	Buy now
34	90465-13M30 Clamp	Buy now
35	63D-2176M-00 Hook	Buy now
36	63D-2175R-00 Hook, band	Buy now
37	6H4-21770-00 Oil tank cap assembly	Buy now
38	6J8-21758-00 Washer, special 2	Buy now
39	6H1-21757-00 Washer, special 1	Buy now
40	6H1-24633-00 Chain, Ball	Buy now
41	6J8-13414-00 Gasket, strainer cover	Buy now
42	6H1-13411-00 Strainer, oil	Buy now
43	6H1-21766-01 Pipe, oil	Buy now
44	90445-08M01 Hose (I30)	Buy now
45	6H1-13435-00 Nipple	Buy now
46	90467-12M11 Clip(6k8)	Buy now
47	90467-08004 Clip, pipe 6162435600	Buy now


Oil Pump



Ref	Part	
48	90119-06M88 Bolt, with washer	Buy now
49	624-42542-00 Collar	Buy now
50	6A0-82317-00 Damper, ignition coil	Buy now
51	6H1-85720-15 Oil level gauge assembly	Buy now
52	6R5-82582-B0 Cover, wire harness AP	Buy now

B7


Power Trim & Tilt Assy



E2

Ref	Part	
1	6H1-43800-16-4D Power trim & tilt assembly	Buy now
2	6H1-43880-02 Motor assembly	Buy now
3	6H1-43805-10 Armature assembly	Buy now
4	6H1-43804-10 Stator assembly	Buy now
5	6H1-43891-10 Brush	Buy now
6	6H1-43892-10 Breaker comp. (brush 2)	Buy now
7	6H1-4380F-10 Plate, brush holder	Buy now
8	6H1-4380J-10 Holder, brush	Buy now
9	6H1-4386K-10 Spring, brush	Buy now
10	97885-05016 Screw, pan head(6b0)	Buy now
11	97607-04310 Screw, pan head(6g8)	Buy now
12	6H1-43881-10 Frame, end	Buy now
13	6H1-4380H-10 Metal	Buy now
14	93102-08M43 Oil seal(6b0)	Buy now
15	6H1-4380G-10 Plate	Buy now


Power Trim & Tilt Assy



E2

Ref	Part	
16	6H1-43865-10 O-ring	Buy now
17	6H1-43840-11 Power tilt assembly	Buy now
18	6H1-43861-10 O-ring	Buy now
19	6H1-43814-11 Piston, free	Buy now
20	6H1-43810-11 Tilt piston sub assembly	Buy now
21	6H1-43861-00 O-ring	Buy now
23	6H1-43871-10 Ring, back up	Buy now
24	6H1-43812-00 Seal dast	Buy now
25	6H1-43872-10 Ring, back up	Buy now
26	93210-18397 O-ring (6g5)	Buy now
27	6H1-43813-10 Cylinder, tilt	Buy now
28	93210-64488 93210-64488	Buy now
29	6H1-43835-10 Pipe	Buy now
30	6H1-43828-10 Body, reservoir	Buy now
31	90386-18M14 Bushing (6e5)	Buy now


Power Trim & Tilt Assy



E2

Ref	Part	
32	6E5-43818-00 Pin, lower shock mount	Buy now
33	6H1-43833-10 Pipe	Buy now
34	6H1-43834-00 Pipe	Buy now
35	97595-06420 Bolt(7u8)	Buy now
36	6H1-43829-00 Plug, reservoir	Buy now
37	93210-09165 O-ring	Buy now
38	93210-064A5 O-ring(61a)	Buy now
39	6T4-43802-03 Valve sub assembly	Buy now
40	6H1-43866-00 O-ring	Buy now
41	6H1-43867-00 O-ring	Buy now
42	6H1-43841-11 Piston, shuttle	Buy now
43	6H1-43856-10 Spring, down relief	Buy now
44	6H1-43844-10 Pin, valve support	Buy now
45	6H1-4384G-11 Seal, relief valve	Buy now
46	6H1-4384F-10 Seal, main valve	Buy now


Power Trim & Tilt Assy



E2

Ref	Part	
47	6H1-43817-01 Filter 2	Buy now
48	6H1-43831-10 Connector, shaft	Buy now
49	6H1-43830-11 Gear pump assembly	Buy now
50	6H1-43847-00 Seat, manual valve	Buy now
51	6H1-43899-00 Spring, manual release	Buy now
52	6H1-4382A-10 Adaptor 1	Buy now
53	6H1-43854-00 Spring, manual release	Buy now
54	93210-10M74 O-ring	Buy now
55	6H1-43845-00 Screw, manual release	Buy now
56	93210-18M75 O-ring (6e5)	Buy now
57	6H1-43875-00 Ring, snap	Buy now
58	6H1-43822-10 Seal, trim dust	Buy now
59	6H1-43821-11 Screw, trim cylinder end	Buy now
61	6H1-4384E-20 Spring, trim	Buy now
62	98501-05010 Screw, pan head(62x)	Buy now


Power Trim & Tilt Assy



E2

Ref	Part	
63	92901-05200 Ybs66-5 washer, plain	Buy now
64	6H1-43820-11 Piston sub assembly	Buy now
65	6H1-43864-00 O-ring	Buy now
66	91318-08016 Bolt, socket	Buy now
67	6H1-43874-00 Ring, back up	Buy now
68	6H1-43816-00 Filter 1	Buy now
69	6H1-43896-00 O-ring (2h7)	Buy now
70	6H1-43895-12 Seat, relief valve	Buy now
71	6H1-43855-11 Spring, up relief	Buy now
72	6H1-43843-11 Screw, valve lock	Buy now
73	6H1-4388E-11 Plug, tapper screw	Buy now
74	6H1-43868-00 O-ring	Buy now
75	98501-04025 Screw, pan head	Buy now
76	92901-04100 Ybs67-4 washer, spring	Buy now
77	6H1-4387J-00 Washer, special 2	Buy now


Power Trim & Tilt Assy



Ref	Part	
78	6H1-4385H-00 Spring, seal	Buy now
79	93505-32038 Ball(7fk)	Buy now

E2


Remote Control Assy



A4

Ref	Part	
1	<u>703-48207-17</u> 703 mec rc side mount push AP WITH PT/T SW.	Buy now
2	<u>703-48261-01</u> Arm, throttle	Buy now
3	<u>703-48153-00</u> Shaft, free accel.	Buy now
4	<u>703-48235-00</u> Bushing	Buy now
5	<u>703-48268-00</u> Spacer 3	Buy now
6	<u>703-48264-00</u> Throttle, friction	Buy now
7	<u>95380-05600</u> Nut, hexagon (663)	Buy now
8	<u>97380-05025</u> Bolt	Buy now
9	<u>703-48265-00</u> Shaft Friction	Buy now
10	<u>93430-06024</u> Circlip (701)	Buy now
11	<u>703-48245-00</u> Plate, lock	Buy now
12	<u>703-48252-00</u> Roller, cam	Buy now
13	<u>701-48248-00</u> Roller, free accel	Buy now
14	<u>703-48198-00</u> Washer, wave 3	Buy now
15	<u>703-48243-00</u> Bushing 3	Buy now


Remote Control Assy



A4

Ref	Part	
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now
30	703-48219-00 Cover, lead	Buy now


Remote Control Assy



A4

Ref	Part	
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-43 Main switch assembly	Buy now
45	703-82577-00 Cap, key	Buy now


Remote Control Assy



A4

Ref	Part	
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-A0 Buzzer	Buy now
52	703-48284-10 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-82563-12 Trim & tilt switch assembly	Buy now
56	703-48221-00 Grip	Buy now
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now


Remote Control Assy



Ref	Part	
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now

A4

Remote Control Box




67M0100-8280

F7

Ref	Part	
1	703-48207-17 703 mec rc side mount push AP WITH PT/T SW.	Buy now
2	701-48320-00 Cable, Remote Control L=12F UR	Buy now
2	701-48320-20 Cable, Remote Control L=13F UR	Buy now
2	701-48320-30 Cable, Remote Control L=14F UR	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now
2	701-48320-60 Cable, Remote Control L=16F UR	Buy now
2	701-48320-80 Cable, Remote Control L=17F UR	Buy now


Repair Kit 1



B1

Ref	Part	
1	6H1-W0001-02 Power head gasket kit	Buy now
2	93210-46044 O-ring	Buy now
3	93210-39ME4 O-ring(6h2)	Buy now
4	688-13621-A1 Gasket, valve seat	Buy now
5	6H4-14984-00 Gasket, float chamber	Buy now
6	688-11181-A1 Gasket, cylinder head 1	Buy now
7	90430-14115 Gasket (663)	Buy now
8	688-11193-A1 Gasket, head cover 1	Buy now
9	688-12414-A1 Gasket, cover	Buy now
10	688-41112-A0 Gasket, exhaust inner cover	Buy now
11	688-41114-A0 Gasket, exhaust outer cover	Buy now
12	93210-46M16 O-ring (688)	Buy now
13	93102-36M02 Oil seal(52w)	Buy now
14	93102-30M05 Oil seal (688)	Buy now
15	93104-20M02 Oil seal (688)	Buy now

Repair Kit 1




6H10010-4230

Ref	Part	
16	93210-62269 Ring, o(663)	Buy now
17	688-45113-A0 Gasket, upper casing	Buy now
18	93210-32738 O-ring(1wg)	Buy now
19	650-24431-A0 Gasket,fuel pump	Buy now
20	6H1-W0093-10 Carburetor repair kit	Buy now
21	6H4-14147-00 O-ring	Buy now
22	93210-04228 O-ring (371)	Buy now
23	692-14590-00 Needle valve assembly	Buy now
24	6H4-14548-00 Pin, float arm	Buy now
25	663-14159-00 Clip	Buy now
26	676-14186-00 Pin, valve	Buy now
27	676-14966-00 Rubber cap	Buy now
29	93210-04230 O-ring (371)	Buy now

B1


Repair Kit 2



B3

Ref	Part	
1	688-W0001-21 Lower unit gasket kit	Buy now
2	688-45114-A1 Gasket, upper casing	Buy now
3	688-41134-A0 Gasket, exhaust manifold	Buy now
4	688-41133-00 Gasket, exhaust manifold 1	Buy now
5	688-45123-00 Gasket, muffler	Buy now
6	90430-08020 Gasket	Buy now
7	93210-49046 O-ring (620)	Buy now
8	93106-09014 Oil seal	Buy now
9	688-44315-A0 Gasket,water pump 1	Buy now
10	688-44324-A0 Gasket,cartridge Outer plate	Buy now
11	688-44316-A0 Gasket,water pump 2	Buy now
12	93210-46044 O-ring	Buy now
13	93210-85M97 O-ring(6h1)	Buy now
14	93101-25M03 Oil seal	Buy now
15	90430-12072 Gasket	Buy now


Repair Kit 2



Ref	Part	
16	663-44366-00 Damper, water seal 2	Buy now
17	692-W0078-02 Water pump repair kit	Buy now
18	688-44322-00 Insert, cartridge	Buy now
19	688-44352-03 Impeller	Buy now
21	688-44323-00 Outer plate, cartridge	Buy now
25	90119-08M13 Bolt, with washer(6h0)	Buy now
26	90119-08M16 Bolt, with washer(6h0)	Buy now
27	90280-04M04 Key, woodruff (688)	Buy now
28	688-W0078-1A Chrome pump kit	Buy now
29	688-44321-41 Inner plate, cartridge	Buy now
30	688-44322-41 Insert, cartridge	Buy now
31	688-44323-40 Outer plate, cartridge	Buy now

B3


Starting Motor



C7

Ref	Part	
1	688-81800-12 Starting motor assembly	Buy now
2	676-81850-11 Armature assembly	Buy now
3	676-81809-10 Washer kit	Buy now
4	676-81857-10 Pinion stopper set	Buy now
5	688-81810-11 Stator assembly	Buy now
6	663-81840-11 Brush holder assembly	Buy now
7	663-81811-11 Brush 1	Buy now
8	663-81812-11 Brush 2	Buy now
9	663-81813-10 Spring, brush	Buy now
10	663-81820-12 Rear bracket assembly	Buy now
11	663-81832-11 Pinion assembly	Buy now
12	688-81830-11 Front bracket assembly	Buy now
13	688-81831-00 Metal, front	Buy now
14	663-81826-10 Bolt 1	Buy now
15	688-81824-00 Washer 2	Buy now


Starting Motor



Ref	Part	
16	97013-08030 Bolt	Buy now
17	92903-08100 Ybs67-8 washer, spring	Buy now
18	92990-08600 Washer, plain (663)	Buy now
19	6H1-15771-00 Stay 1	Buy now
20	97885-04010 Screw, pan head (e56)	Buy now
21	92995-04600 Washer, plain (646)	Buy now

C7

Steering Guide




6880700-9190

F6

Ref	Part	
1	688-61350-10 Steering guide attachment kit AP	Buy now
2	688-61351-10 Rod, steering link	Buy now
3	90201-10M20 Washer, plate (663)	Buy now
4	90185-09M01 Nut, nylon (663)	Buy now
5	90170-09M03 Nut (689)	Buy now
6	90387-10M42 Coller (688)	Buy now
7	90201-10M63 Washer, plate	Buy now
8	6E5-61355-00 Bolt	Buy now
9	6E5-43145-01 Cap, clamp bracket	Buy now
10	93210-16275 O-ring	Buy now


Top Cowling



A4

Ref	Part	
1	6H0-42610-B0-4D Top Cowling assembly	Buy now
1	6H1-42610-60-4D Top Cowling assembly	Buy now
2	63D-2177H-00 Disk cap 2	Buy now
3	6H1-42647-00-94 Holder, clamp band	Buy now
4	6H1-42649-00-94 Holder, clamp band	Buy now
5	663-42662-00 Damper	Buy now
6	688-42652-10 Hook 2	Buy now
7	97095-06016 Bolt, hexagon deep recess	Buy now
8	92995-06100 Washer(6a1)	Buy now
9	92995-06600 Washer, plain (646)	Buy now
10	90266-06009 Rivet (697)	Buy now
11	6H1-42613-01-4D Molding air duct	Buy now
14	688-42615-00 Seal	Buy now
15	6H0-42677-A0 Graphic Front	Buy now
15	6H1-42677-60 Graphic, front	Buy now

Top Cowling




A4

Ref	Part	
16	6H0-42678-90 Graphic, Rear	Buy now
16	6H1-42678-30 Graphic, front	Buy now
17	6H1-W0070-30 Graphic set	Buy now
18	6H1-13436-00 1-	Buy now
18	6H1-13436-41 1-	Buy now
19	6H1-42617-10 Rubber, Form 1	Buy now
20	6H1-42619-00 Damper (350x640)	Buy now
21	6H1-42627-00 Damper (350x640)	Buy now
22	6H1-42637-00 Damper, Form 4	Buy now
23	6H1-42694-00 Band	Buy now
24	6H3-21732-00 Seal 1	Buy now
25	6H3-21735-00 Seal 2	Buy now
26	90338-05M12 Plug(6h4)	Buy now
27	90183-05M06 Nut, spring(6h4)	Buy now
28	6H1-42681-30 Mark Cowling	Buy now


Top Cowling

Ref	Part	
29	6H1-42682-30 Mark Cowling	Buy now



A4


Upper Casing



E5

Ref	Part	
1	688-45111-04-4D Casing, upper	Buy now
2	663-45155-10 Cap	Buy now
3	93606-12019 Pin, dowel (614)	Buy now
4	90119-08M80 Bolt, with washer(688)	Buy now
5	688-41137-03-94 Guide, exhaust	Buy now
6	688-45114-A1 Gasket, upper casing	Buy now
7	688-41134-A0 Gasket, exhaust manifold	Buy now
8	688-41131-00-5B Manifold, ext. 1	Buy now
8	692-41131-00-5B Manifold, ext. 1	Buy now
9	688-41133-00 Gasket, exhaust manifold 1	Buy now
10	688-14711-01-5B Muffler 1	Buy now
11	688-45123-00 Gasket, muffler	Buy now
12	663-14737-10 Damper, muffler	Buy now
13	97075-08030 Bolt, hexagon (fj1)	Buy now
14	92995-08100 Ybs67-8 washer, spring	Buy now

Upper Casing



E5

Ref	Part	
15	97075-08025 Bolt, hexagon deep recess	Buy now
17	90119-08M79 Bolt, hexagon (fj1)	Buy now
18	97075-08035 Bolt(70w)	Buy now
20	688-45113-A0 Gasket, upper casing	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.