



Yamaha D150HETO 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	9
CARBURETOR	12
CONTROL	14
CRANKSHAFT. PISTON	18
CYLINDER. CRANKCASE 1	21
CYLINDER. CRANKCASE 2	24
ELECTRICAL 1	26
ELECTRICAL 2	28
FUEL 1	32
FUEL 2	35
GENERATOR	36
INTAKE	38
LOWER CASING. DRIVE 1	41
LOWER CASING. DRIVE 2	45
LOWER CASING. DRIVE 3	49
METER	51
OIL PUMP	53
OIL TANK	55
POWER TRIM & TILT ASSY 1	58
POWER TRIM & TILT ASSY 2	61
REPAIR KIT 1	64
REPAIR KIT 2	67
STARTING MOTOR	69
TOP COWLING	71
UPPER CASING	73

Bottom Cowling




Ref	Part	
1	64D42711018D Cowling, bottom	Buy now
2	9016905M00 Screw truss head tapping	Buy now
3	61A4272700 Grommet	Buy now
4	6H44274800 Grommet	Buy now
5	64D42815004D Lever, clamp	Buy now
6	64D42816004D Lever, clamp	Buy now
7	64D4283500 Pin, set1	Buy now
8	9709506040 Bolt (682)	Buy now
9	9020106068 Washer,plate (6k8)	Buy now
10	9038615M73 Bush(6I2)	Buy now
11	9020615M18 Washer, wave(6I2)	Buy now
12	64D4281820 Lever, clamp	Buy now
13	64D4281830 Lever, clamp	Buy now
14	64D4314400 Hook, spring	Buy now
15	9709006012 Bolt(gh1)	Buy now

Bottom Cowling



Ref	Part	
16	9299006600 Washer, plain (646)	Buy now
17	9050616M34 Spring, tension(64d)	Buy now
18	6E54439100 Nipple, hose	Buy now
19	64D4272530 Grommet	Buy now
20	64D42738005B Plate, fitting	Buy now
21	64D42738105B Plate, fitting	Buy now
22	9709506016 Bolt, hexagon deep recess	Buy now
23	9299506600 Washer, plain (646)	Buy now
24	9048022M15 Grommet (6e5)	Buy now
25	9038708M37 Collar (6e5)	Buy now
26	9020108M54 Washer, plate (6e5)	Buy now
27	9707508035 Bolt(70w)	Buy now
28	9011908M22 Bolt, with washer	Buy now
29	6884272610 Grommet	Buy now
30	6E58258800 Plate	Buy now


Bottom Cowling



D7


Ref	Part	
31	9709506020 Bolt(7u8)	Buy now
36	64D4271700 Rubber Seal 2	Buy now
40	6E54271610 Rubber seal 1	Buy now
41	6R3Y125J70 Flushing kit	Buy now
42	6R31257200 Adapter	Buy now
43	6R31258000 Joint assembly	Buy now
44	9044511M35 Hose (I700)	Buy now
45	9046511M10 Clamp	Buy now
47	68F4275300 Fastner	Buy now
48	9046420258 Clamp	Buy now
49	6G54279110 Mark 1	Buy now
50	6A12817600 Label Caution	Buy now
51	6E38257H00 Plate Mark	Buy now

Bracket 1




Ref	Part	
1	64E43111028D Bracket, clamp	Buy now
2	6G54525102 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506030 Bolt(jf7)	Buy now
5	9299506100 Washer(6a1)	Buy now
6	6E58214800 Wire, lead 5	Buy now
7	9709506010 Bolt	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	64E43112028D Bracket, clamp	Buy now
11	9788006012 Screw, pan head(62j)	Buy now
12	9299006600 Washer, plain (646)	Buy now
13	9370006M03 Nipple, grease(6a1)	Buy now
14	6634511900 Cap, grease nipple AP	Buy now
15	64E4313101 Bolt, clamp bracket	Buy now
16	9709508020 Bolt, hexagon	Buy now

Bracket 1




Ref	Part	
17	9299508100 Ybs67-8 washer, spring	Buy now
18	9038625M31 Bushing (6e5)	Buy now
19	9020126M59 Washer, plate (6e5)	Buy now
20	9018522M11 Nut, self-locking	Buy now
21	9046511M10 Clamp	Buy now
22	64E43311108D Bracket, swivel L	Buy now
23	9046508M63 Clamp(61u)	Buy now
26	6E58214700 Wire, lead 5 L	Buy now
27	6G54314400 Hook, spring	Buy now
29	6G54318102 Lever, tilt stop 1	Buy now
30	6G54318502 Lever, tilt stop 2	Buy now
31	9038610M16 Bushing (688)	Buy now
32	6G54314800 Collar, distance	Buy now
33	9024906M19 Pin(6e5)	Buy now
34	9038710M05 Collar(6e5)	Buy now

Bracket 1




Ref	Part	
35	9169030020 Pin, spring (6h4)	Buy now
36	9050614M24 Spring, tension(6e5)	Buy now
37	64E4312600 Pin, upper shock mount	Buy now
38	9038622M98 Bush(61u)	Buy now
39	9341022M11 Circlip(61u)	Buy now
40	9010112M03 Bolt (l:115mm)	Buy now
41	9020113M01 Washer, plate(6e5)	Buy now
42	9020112M05 Washer, plate(663)	Buy now
43	9538012600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	64E4313902 Cam, trim sender (with screw)	Buy now
2	9778060525 Screw, tapping(65j)	Buy now
3	64E8367202 Trim sender	Buy now
4	9788506016 Screw, pan head(6b0)	Buy now
5	9046511M10 Clamp	Buy now
6	9321037MH7 O-ring(61u)	Buy now
7	9020240M47 Washer, plate(61a)	Buy now
8	61A4337600 Bolt, thrust receiver	Buy now
9	9578010300 Nut, nylon (6e5)	Buy now
10	6E542510A18D Steering bracket assembly L	Buy now
11	9020138M60 Washer, plate (6e5)	Buy now
12	9038638M32 Bush(6e5)	Buy now
13	6G544551018D Housing, lower mount rubber	Buy now
14	9341037M04 Circlip (6e5)	Buy now
15	6E54457500 Damper, lower mount rubber	Buy now

Bracket 2




Ref	Part	
16	6J9445550094 Mount damper, lower side	Buy now
17	9020232M19 Washer, plate (6e5)	Buy now
18	9020116M55 Washer, plate (6e5)	Buy now
19	6E58214900 Wire, lead 3	Buy now
20	9010914M34 Bolt(6e5)	Buy now
21	9020115M58 Washer, plate (6e5)	Buy now
22	9538014800 Nut, crown (6e5)	Buy now
23	9299514600 Washer (6e5)	Buy now
24	6E5445520194 Housing, lower mount rubber	Buy now
25	9709510045 Bolt(64d)	Buy now
26	9299510100 Ybs67-10 washer, spring	Buy now
27	6J94455301NA Cover, lower mount	Buy now
28	65N43155N0 Mark 1	Buy now
29	65N43156N0 Mark 2	Buy now
30	9050116M28 Spring (6e5)	Buy now

Bracket 2



Ref	Part	
31	9015706M05 Screw, Pan Head	Buy now
32	9017906066 Nut(663)	Buy now
33	6J9445140094 Mount damper, upper side	Buy now
34	9020126M57 Washer, plate (6e5)	Buy now
35	9020226M18 Washer, plate (6e5)	Buy now
36	9020114M56 Washer, plate (6e5)	Buy now
37	9010912M37 Bolt	Buy now
38	9018512M12 Nut, self-locking(6e5)	Buy now
39	6634457500 Damper, lower mount rubber	Buy now
40	6E544511005B Cover, upper mount	Buy now


Carburetor



B5

Ref	Part	
1	64K1430101 Carburetor assembly 1	Buy now
2	64K1430201 Carburetor assembly 2	Buy now
3	64K1430301 Carburetor assembly 3	Buy now
4	64D1438401 Gasket, float chamber	Buy now
5	64D1438100 Body, float chamber	Buy now
6	6E51438502 Float	Buy now
7	6E51454600 Valve, needle	Buy now
8	6E51415900 Clip	Buy now
9	6E51438602 Pin, float	Buy now
10	64D1492F42 Jet, air slow	Buy now
11	61U1495900 Gasket	Buy now
12	64D1439400 Valve, drain	Buy now
13	64D1492E76 Jet, main	Buy now
14	64D1492E77 Jet, main	Buy now
15	64D1492E79 Jet, main	Buy now

Carburetor




64F0010-6060

B5

Ref	Part	
16	6E51439801 Gasket	Buy now
17	61A1492H12 Jet, slow air (#60)	Buy now
18	61A1438301 Screw, drain	Buy now
19	6E51432100 Screw, throttle #2	Buy now
20	6J81433400 Spring, throttle #2	Buy now
21	6E51432801 Plug	Buy now
22	6E51497900 Gasket	Buy now
23	6E51432303 Screw, air adjusting	Buy now
24	6E51422300 Spring, air adjusting	Buy now
25	9798005116 Screw, pan head	Buy now
26	6E51452701 Plate	Buy now
27	9798005108 Screw, with washer	Buy now
28	6E51432400 Screw, flat head	Buy now
29	6J81495900 Gasket, drin screw	Buy now

Control




64F0010-0150

E2

Ref	Part	
1	64D4853100 Bracket, remote control 1	Buy now
2	64D4853200 Bracket, remote control 2	Buy now
3	6E54853800 Clamp, cable	Buy now
4	9169030012 Pin, spring	Buy now
5	9709508020 Bolt, hexagon	Buy now
6	9299508100 Ybs67-8 washer, spring	Buy now
7	61H41632021S Lever, magneto control	Buy now
8	6E54834400 Cable end, remote control	Buy now
9	9046818008 Clip 620436610000	Buy now
10	6G541631011S Lever, magneto control	Buy now
11	6638551800 Joint, ball	Buy now
12	9015706013 Screw, pan head(697)	Buy now
13	9050116M12 Spring, compression (688)	Buy now
14	9530306600 Nut(661)	Buy now
15	6884419400 Cap	Buy now

Control




64F0010-0150

E2

Ref	Part	
16	9038708M17 Collar	Buy now
17	9010108M14 Bolt(61h)	Buy now
18	9020108M23 Washer, plate (6e5)	Buy now
19	9038612089 Bushing(663)	Buy now
20	9038708M16 Collar	Buy now
21	9038622M13 Bushing (688)	Buy now
22	9020212092 Washer, plate(663)	Buy now
23	9020108M13 Washer plate (682)	Buy now
24	9050829M12 Spring (6e5)	Buy now
25	6G54163601 Rod, magneto control	Buy now
26	9538005600 Nut, hexagon (663)	Buy now
27	6624123701 Joint, link	Buy now
28	9015706014 Screw, pan head(697)	Buy now
31	6824123750 Joint, link 2	Buy now
34	61H4121300 Cam, accel.	Buy now

Control




64F0010-0150

E2

Ref	Part	
35	9038706M29 Collar (6a0)	Buy now
36	9020610M04 Washer, wave (676)	Buy now
37	9709506025 Bolt	Buy now
38	6E544117001S Bracket	Buy now
39	9011906MA2 Bolt, with washer	Buy now
40	68F4412100 Lever, shift rod	Buy now
41	6E54412200 Bushing, shift rod lever	Buy now
42	9020208M20 Washer, plate (6e5)	Buy now
45	9038606M12 Bushing (688)	Buy now
46	6E5441180194 Bracket 2	Buy now
47	9701308030 Bolt	Buy now
48	9290308600 Washer, plain (663)	Buy now
49	9350104M02 Ball (697)	Buy now
50	9050112082 Spring 6484411600	Buy now
51	6484271500 Bushing 2	Buy now


Control



E2


Ref	Part	
52	9370006M03 Nipple, grease(6a1)	Buy now
53	6E54412003 Handle gear shift assembly L	Buy now
54	9321009165 O-ring	Buy now
55	9038616M66 Bush(6e5)	Buy now
56	9020216061 Washer, plate(663)	Buy now
57	9341016006 Circlip	Buy now

Crankshaft. Piston



Ref	Part	
1	6G51141102 Crankshaft	Buy now
2	6E51144700 Seal, ring	Buy now
3	6R3151630015 Housing, bearing 1	Buy now
4	93311940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	9310240M14 Oil seal(61a)	Buy now
6	9321104001 O-ring	Buy now
7	9011906MA2 Bolt, with washer	Buy now
8	93310954U1 Bearing, cylindrical(64c)	Buy now
9	6R31153600 Gear, drive	Buy now
10	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	9341040M03 Circlip(n02)	Buy now
12	6G5153590094 Housing, oil seal	Buy now
13	9310235M13 Oil seal (6e5)	Buy now
14	9310122M15 Oil seal (6e5)	Buy now
15	9321074M35 O-ring (6e5)	Buy now


Crankshaft. Piston



A7


Ref	Part	
17	64D116310290 Piston (std)	Buy now
17	64D1163502 Piston (0.25mm o/s) AP	Buy now
17	64D1163602 Piston (0.50mm o/s) AP	Buy now
18	64D116420290 Piston 2 (std)	Buy now
18	64D1164502 Piston 2 (0.25mm o/s) AP	Buy now
18	64D1164602 Piston 2 (0.50mm o/s) AP	Buy now
19	64D1160301 Piston ring set (std)	Buy now
19	64D1160401 Piston ring set (0.25mm o/s) AP	Buy now
19	64D1160501 Piston ring set (0.50mm o/s) AP	Buy now
20	6R51163310 Pin, piston	Buy now
21	6R51163410 Clip, piston pin	Buy now
22	6R51165010 Connecting kit	Buy now
23	9010908022 Bolt	Buy now
24	93310323V6 Bearing	Buy now
25	9020123M01 Washer, plate(6g6)	Buy now

Crankshaft. Piston




Ref	Part	
26	93310836V2 Brg, cyl-cal roller (6e5)	Buy now

Cylinder. Crankcase 1




Ref	Part	
3	6E51137200 Nipple, hose	Buy now
4	6241448500 Pipe, joint	Buy now
5	6F61137200 Nipple, hose	Buy now
6	6241137900 Valve, check	Buy now
7	9038406M07 Bush, bimetal formed(6r3)	Buy now
8	9038414M09 Bush, bimetal formed(6r3)	Buy now
9	6631151801 Lock, bearing	Buy now
10	6461137000 Check valve assembly	Buy now
11	9034014M00 Plug, straight screw(62y)	Buy now
12	9043014115 Gasket (663)	Buy now
13	9360812063 Pin, dowel (626)	Buy now
14	9044507M10 Hose (L770)	Buy now
15	9010510M20 Bolt (6e5)	Buy now
16	9011908M94 Bolt, with washer	Buy now
17	9011608M45 Bolt, stud (6e5)	Buy now

Cylinder. Crankcase 1




Ref	Part	
18	9044507M11 Hose (I770)	Buy now
19	9044507M09 Hose (I390)	Buy now
20	9044507M12 Hose (L390)	Buy now
21	9044507M08 Hose (I390)	Buy now
22	9044507M90 Hose (I390)	Buy now
23	9044507M34 Hose (L260)	Buy now
24	9046407M05 Clamp (6g5)	Buy now
25	9046407M20 Clamp(6h0)	Buy now
26	6E51132500 Anode	Buy now
27	9878004015 Screw, flat head(ga5)	Buy now
28	67H1111901 Hanger, engine	Buy now
29	9011908MA3 Bolt, with washer	Buy now
30	6K711371011S Cover	Buy now
31	6E511381A2 Gasket 1	Buy now
32	9011906MA2 Bolt, with washer	Buy now

Cylinder. Crankcase 1



Ref	Part	
33	6E542761001S Stopper	Buy now
34	6E542762001S Stopper	Buy now
35	68F4453300 Damper, upper mount rubber	Buy now


Cylinder. Crankcase 2



B2

Ref	Part	
1	6G411111021S Head, cylinder 1	Buy now
2	6G511181A1 Gasket, cylinder head 1	Buy now
3	9011908MA8 Bolt, with washer	Buy now
4	6G511191001S Cover, cylinder head 1	Buy now
5	6G511193A0 Gasket, head cover 1	Buy now
6	9011906MA4 Bolt, with washer	Buy now
7	6E51241120 Thermostat	Buy now
8	68812413001S Cover, thermostat	Buy now
9	68812414A1 Gasket, cover	Buy now
10	9011906MA6 Bolt, with washer	Buy now
11	64D41111001S Inner cover, exhaust	Buy now
12	6G541112A1 Gasket, exhaust inner cover	Buy now
13	6G541114A0 Gasket, exhaust inner cover	Buy now
14	6R341113001S Outer cover, exhaust	Buy now
15	6502437800 Pipe, joint 2	Buy now


Cylinder. Crankcase 2



B2

Ref	Part	
16	9011906MA5 Bolt, with washer	Buy now
17	9044509097 Hose (I1500)	Buy now
18	6G51241600 Valve, pressure control	Buy now
19	9050116M11 Spring, compression (688)	Buy now
20	9048020M05 Grommet (688)	Buy now
21	6G511382A1 Gasket 2	Buy now
22	6G511372001S Cover, bypass 2	Buy now
23	9011906MA2 Bolt, with washer	Buy now
24	6G51257600 Hose 1	Buy now
25	9046513M18 Clamp	Buy now
26	9046506M86 Clamp	Buy now
27	9470200247 Plug, spark (br8hs-10)	Buy now

Electrical 1




65N1300-2120

D1

Ref	Part	
1	6R38196010 Rectifier & regulator assembly	Buy now
2	6R38215000 Fuse holder assembly	Buy now
3	7058215100 Fuse (30a)	Buy now
4	6G58215200 Holder, fuse	Buy now
5	64D8194200 Cover	Buy now
6	9038706M66 Collar (6h4)	Buy now
7	9701306055 Bolt(64d)	Buy now
8	9290306600 Washer, plain (646)	Buy now
9	9709506012 Bolt(gh1)	Buy now
10	9299506600 Washer, plain (646)	Buy now
11	9046506M88 Clamp	Buy now
12	9046415M11 Clamp (3y2)	Buy now
15	64D8554010 C.d.i. unit assembly	Buy now
16	9788006020 Screw pan head	Buy now
17	9299006600 Washer, plain (646)	Buy now

Electrical 1




65N1300-2120

D1


Ref	Part	
18	9046505M87 Clamp	Buy now
19	6R385542031S Bracket	Buy now
20	9038706M03 Collar (676)	Buy now
21	9048009M12 Grommet (6a0)	Buy now
22	9011906M61 Bolt, with washer	Buy now
23	64D8553700 Cover	Buy now
24	9015906M11 Screw, with washer(6l2)	Buy now
25	6R38259E00 Switch assembly	Buy now
26	6628251900 Wire, earth lead	Buy now
27	6R38251900 Wire, earth lead	Buy now
30	6E58571160 Mark Caution	Buy now

Electrical 2




Ref	Part	
1	6R38557001 Ignition coil assembly	Buy now
2	6E38237021 Plug cap assembly	Buy now
3	9709506020 Bolt(7u8)	Buy now
4	9299506600 Washer, plain (646)	Buy now
5	9048025161 Grommet(656)	Buy now
6	6E58253110 Wire, lead	Buy now
7	64D8259000 Wire harness assembly	Buy now
8	6638215100 Fuse	Buy now
9	7058215100 Fuse (30a)	Buy now
10	6888259400 Clamp	Buy now
11	9046505M87 Clamp	Buy now
12	9046508M89 Clamp	Buy now
13	9709506012 Bolt(gh1)	Buy now
15	6K78258800 Plate	Buy now
18	6888256010 Thermo switch assembly	Buy now

Electrical 2




Ref	Part	
19	61A8579000 Thermosensor assembly	Buy now
20	9299010600 Washer, plate	Buy now
21	9046506M86 Clamp	Buy now
24	64E8611000 Solenoid	Buy now
25	9709506016 Bolt, hexagon deep recess	Buy now
27	9321003261 O-ring (663)	Buy now
28	6R38256300 Trim & tilt switch assembly	Buy now
29	6E58258700 Gasket	Buy now
30	6R38361400 Bracket	Buy now
32	61A8194100 Starter relay assembly	Buy now
33	6898195210 Holder, starter relay	Buy now
34	6E58195000 Relay assembly	Buy now
35	6E58195A00 Relay assembly	Buy now
36	6G58714910 Connector	Buy now
37	6G58211900 Cover, lead wire	Buy now

Electrical 2




Ref	Part	
38	6E58211600 Wire, minus lead	Buy now
39	6G58194811 Bracket	Buy now
42	6E98355770 Tube	Buy now
43	9046513M18 Clamp	Buy now
44	64D8210500 Battery cable	Buy now
45	64D8192001 Terminal assembly	Buy now
46	9538008700 Nut(661)	Buy now
47	9299008100 Ybs67-8 washer, spring	Buy now
48	9538006700 Nut	Buy now
49	9299006100 Washer(6a1)	Buy now
50	9709506035 Bolt(j52)	Buy now
51	9299506100 Washer(6a1)	Buy now
52	64D8211700 Wire, Lead	Buy now
53	64D8211600 Wire, Minus Lead	Buy now
54	6E58211701 Wire, lead	Buy now

Electrical 2



Ref	Part	
55	6E58258800 Plate	Buy now
58	9046512M25 Clamp (6e5)	Buy now
61	6G58215200 Holder, fuse	Buy now


Fuel 1



C4

Ref	Part	
1	6R32431320 Pipe 3	Buy now
2	6R32437700 Pipe, joint 3	Buy now
3	9046511M10 Clamp	Buy now
5	6R32456000 Filter assembly	Buy now
6	61N2456300 Element, filter	Buy now
7	61N2452100 Cup, filter	Buy now
8	9321032738 O-ring(1wg)	Buy now
9	6482456602 Bracket, filter	Buy now
10	9701306014 Bolt(gj3)	Buy now
11	9290306100 Washer(6a1)	Buy now
12	9538008600 Nut (661)	Buy now
15	6G52431400 Pipe 4	Buy now
16	6E52437800 Pipe, joint 3	Buy now
17	6K72431500 Pipe 5	Buy now
18	6E52431500 Pipe 5	Buy now


Fuel 1



C4

Ref	Part	
20	6E52441003 Fuel pump assembly	Buy now
21	9850305035 Screw, pan head (686)	Buy now
22	9290305600 Washer, plain (646)	Buy now
23	6E52441300 Body 2	Buy now
24	6E52447100 Diaphragm	Buy now
25	6E52443500 Gasket, body 2	Buy now
26	6E52441100 Diaphragm	Buy now
27	6482442400 Seat, spring	Buy now
28	6E52442300 Spring, diaphragm	Buy now
29	6E52443402 Gasket, body	Buy now
30	6A02442101 Valve, check	Buy now
31	6A01432500 Screw, pan head	Buy now
32	9538003600 Nut (6g8)	Buy now
33	6E52441210 Body 1	Buy now
34	65024431A0 Gasket, fuel pump	Buy now


Fuel 1



C4

Ref	Part	
35	9709506050 Bolt(jf7)	Buy now
36	9299506600 Washer, plain (646)	Buy now
37	6G52431610 Pipe 6	Buy now
41	9044513M03 Hose (I90)	Buy now
42	9044513M02 Hose (I90)	Buy now
43	6K72431700 Pipe 7	Buy now
44	6K72431800 Pipe, overflow	Buy now
45	6K72431900 Pipe, oil	Buy now

Fuel 2




6N61300-2100

C6

Ref	Part	
1	6YK2430742 Fuel pipe comp. 2 AP	Buy now
2	9045010M07 Hose, clamp AP	Buy now

Generator




65N1300-2110

C7


Ref	Part	
1	64D8555002 Rotor assembly	Buy now
2	6R38551000 Stator assembly	Buy now
3	64D8558000 Coil, pulser	Buy now
4	9046506M86 Clamp	Buy now
5	6R58589501 Crank position sender	Buy now
6	9788005012 Screw, pan head (646)	Buy now
7	9046415M11 Clamp (3y2)	Buy now
8	9028005015 Key, woodruff	Buy now
9	9020121M18 Washer, plate (663)	Buy now
10	9017020137 Nut, hexagon(663)	Buy now
11	9701306070 Bolt(62j)	Buy now
12	9290306600 Washer, plain (646)	Buy now
13	6884161100 Retainer, magneto base 1	Buy now
14	6884161200 Retainer, magneto base 2	Buy now
15	9788006018 Screw, pan head(6e5)	Buy now

Generator




Ref	Part	
16	6E58133200 Plate, timing	Buy now
17	9788506010 Screw pan head	Buy now
18	9299506600 Washer, plain (646)	Buy now
19	64D8133701 Cover, Flywheel	Buy now
20	9048013M24 Grommet (6e9)	Buy now
21	6638231701 Damper, ignition coil	Buy now
22	6A18362551 Mark 5	Buy now
23	6A18362541 Mark 5	Buy now
24	64E1448800 Label, caution	Buy now

Intake




Ref	Part	
1	6K71361000 Reed valve assembly	Buy now
2	6E5W000400 Reed set	Buy now
3	6K713621A1 Gasket, valve seat	Buy now
4	9788005016 Screw, pan head(6b0)	Buy now
5	9299005600 Washer, plain (646)	Buy now
6	64E13624001S Plate,reed valve	Buy now
7	6881137200 Nipple, hose	Buy now
8	6R51448500 Pipe, joint	Buy now
9	9033608M06 Plug, Taper(64F)	Buy now
10	6K713646A2 Gasket, manifold 2	Buy now
11	64E13641001S Manifold 1	Buy now
12	6E51355200 Nozzle	Buy now
13	6241448500 Pipe, joint	Buy now
14	6K78133801 Stay	Buy now
15	9048010M28 Grommet(6k7)	Buy now

Intake




Ref	Part	
16	9011606M30 Bolt, stud(6e5)	Buy now
17	64E13645A0 Gasket, manifold 1	Buy now
18	9701306050 Bolt, hexagon	Buy now
19	9290306600 Washer, plain (646)	Buy now
20	6E514198A2 Gasket	Buy now
21	9538006600 Nut(661)	Buy now
22	9299506100 Washer(6a1)	Buy now
23	6G54121701 Rod, accel. lever	Buy now
24	6E54125601 Rod, choke 1	Buy now
25	6614126202 Joint, choke lever	Buy now
26	61H4127110 Knob, choke	Buy now
27	6894127300 Grommet	Buy now
28	64D1444000 Silencer assembly, Intake	Buy now
29	9044507MA3 Hose (I200)	Buy now
30	6K71448300 Gasket	Buy now

Intake



Ref	Part	
31	9015906M08 Screw, with washer(6k7)	Buy now


Lower Casing. Drive 1



A4

Ref	Part	
1	65N4530001NA Lower unit assembly L	Buy now
2	65N4530100NA Casing, Lower	Buy now
3	93315628U9 Brg,cyl-cal roller (6e5)	Buy now
4	9034008002 Plug, straight screw	Buy now
5	6884534110 Plug, drain	Buy now
6	9043008020 Gasket	Buy now
7	9020622M19 Washer, wave(61a)	Buy now
8	9020122M01 Washer, plate(61a)	Buy now
9	61A4552700 Collar, drive shaft	Buy now
10	61A4553800 Spacer, 1	Buy now
11	65N4553600 Sleeve, Drive Shaft	Buy now
12	6E54537800 Nipple, hose	Buy now
13	9044507ME8 Hose (I250) L	Buy now
14	6E58355810 End, nipple	Buy now
15	65N4532100 Plate	Buy now


Lower Casing. Drive 1



A4


Ref	Part	
16	9321033M49 O-ring(6I5)	Buy now
17	9310609014 Oil seal	Buy now
18	65N4415000 Shift Cam assembly	Buy now
19	9900108600 Circlip(2r6)	Buy now
20	61A4431101 Housing, water pump	Buy now
21	61A4432202 Insert, cartridge	Buy now
22	9321086M38 O-ring (6e5)	Buy now
23	9321037160 O-ring (6g8)	Buy now
24	6E54436500 Damper, water seal 1	Buy now
25	6E54431200 Cover, water pump housing	Buy now
26	6E54435201 Impeller	Buy now
27	9028004M05 Key, woodruff (6e5)	Buy now
28	65N4432300 Outer plate, cartridge	Buy now
29	65N44315A0 Gasket, water pump	Buy now
30	9360612019 Pin, dowel (614)	Buy now

Lower Casing. Drive 1



Ref	Part	
31	9011908M14 Bolt, with washer	Buy now
32	65N4431200 Cover, Water Pump Housing	Buy now
33	9709508035 Bolt(70w)	Buy now
34	9020908M02 Washer, plate (688)	Buy now
35	6E5453310094 Housing, bearing	Buy now
36	9310128M16 Oil seal (6e5)	Buy now
37	93317330U2 Bearing, cylindrical(6k0)	Buy now
38	6E5455870110 Shim (t:0.10mm) UR	Buy now
38	6E5455870112 Shim (t:0.12mm) UR	Buy now
38	6E5455870115 Shim (t:0.15mm) UR	Buy now
38	6E5455870118 Shim (t:0.18mm) UR	Buy now
38	6E5455870130 Shim (t:0.30mm) UR	Buy now
38	6E5455870140 Shim (t:0.40mm) UR	Buy now
38	6E5455870150 Shim (t:0.50mm) UR	Buy now
39	93341930V2 Bearing, thrust(64d)	Buy now

Lower Casing. Drive 1




65N0300-9220

A4


Ref	Part	
40	9321055M14 O-ring (70e)	Buy now
41	6E54534400 Cover, oil seal	Buy now
42	9709508025 Bolt (62g)	Buy now
43	9299508600 Washer, plain (663)	Buy now
44	65N4550100 Drive Shaft Comp	Buy now

Lower Casing. Drive 2




Ref	Part	
1	9333200048 Bearing(6k0)	Buy now
2	6G5455670110 Shim (t:0.10mm) UR	Buy now
2	6G5455670112 Shim (t:0.12mm) UR	Buy now
2	6G5455670115 Shim (t:0.15mm) UR	Buy now
2	6G5455670118 Shim (t:0.18mm) UR	Buy now
2	6G5455670130 Shim (t:0.30mm) UR	Buy now
2	6G5455670140 Shim (t:0.40mm) UR	Buy now
2	6G5455670150 Shim (t:0.50mm) UR	Buy now
3	65N4555100 Pinion (13T)	Buy now
4	9017016M01 Nut, hexagon (688)	Buy now
5	65N4556000 Gear	Buy now
6	9020135M02 Washer Plate(65N)	Buy now
7	65N4561100 Shaft, propeller	Buy now
8	9020128M03 Washer, Plate	Buy now
9	65N4563400 Slide, Shift	Buy now

Lower Casing. Drive 2




Ref	Part	
10	9050110M77 Spring, compression(61a)	Buy now
11	6H14566800 Shaft, free 1	Buy now
12	9020102M00 Washer, plate(61a)	Buy now
13	61A4563500 Plunger, shift	Buy now
14	9350104011 Ball	Buy now
15	9018302M03 Nut, spring (6h1)	Buy now
16	9025008M07 Pin, straight (6g5)	Buy now
17	65N4563100 Clutch, dog	Buy now
18	6E54563301 Ring, cross pin	Buy now
19	65N4563110 Clutch Dog	Buy now
20	9360642M22 Pin, Dowel	Buy now
21	9038732M00 Collar	Buy now
22	9020136M00 Washer, plate(65n)	Buy now
23	9344036M09 Circlip(65N)	Buy now
24	65N4561150 Shaft, propeller	Buy now

Lower Casing. Drive 2




Ref	Part	
25	65N453320094 Housing, bearing	Buy now
26	93317445U9 Bearing, cylindrical(65n)	Buy now
27	65N4557000 Gear 2 (26T)	Buy now
28	65N4557600 Washer, Thrust 2	Buy now
30	93341445V3 Bearing	Buy now
31	65N455780010 Shim (T)0.10Mm) UR	Buy now
31	65N455780012 Shim (T)0.12Mm) UR	Buy now
31	65N455780015 Shim (T)0.15Mm) UR	Buy now
31	65N455780018 Shim (T)0.18Mm) UR	Buy now
31	65N455780030 Shim UR	Buy now
31	65N455780040 Shim (T)0.40Mm) UR	Buy now
31	65N455780050 Shim (T:0.50Mm) UR	Buy now
32	9310145M59 Oil seal(65n)	Buy now
33	9321098M33 O-ring (6a5)	Buy now
34	9321103MH9 O-ring(65n)	Buy now

Lower Casing. Drive 2




Ref	Part	
35	65N455770010 Shim (T)0.10Mm) UR	Buy now
35	65N455770012 Shim (T)0.12Mm) UR	Buy now
35	65N455770015 Shim (T)0.15Mm) UR	Buy now
35	65N455770018 Shim (T)0.18Mm) UR	Buy now
35	65N455770030 Shim (T)0.30Mm) UR	Buy now
35	65N455770040 Shim (T)0.40Mm) UR	Buy now
35	65N455770050 Shim (T)0.50Mm) UR	Buy now
36	65N4538300 Washer, Claw	Buy now
37	65N4538400 Nut	Buy now

Lower Casing. Drive 3



Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	6E54436100 Tube, water L	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9010110M70 Bolt(6j9)	Buy now
6	9707510035 Bolt	Buy now
7	9299510100 Ybs67-10 washer, spring	Buy now
8	65N4521400 Cover Water Inlet	Buy now
9	65N4521500 Cover, Water Inlet 2	Buy now
10	9014205M07 Screw, Countersunk	Buy now
11	9018505002 Nut nylon (sus)(ex4)	Buy now
12	9044507M33 Hose (L1080)	Buy now
13	6E58355800 End, nipple	Buy now
14	9046511M10 Clamp	Buy now
15	93317428U8 Bearing, cylindrical(6u4)	Buy now


Lower Casing. Drive 3



B2


Ref	Part	
16	9310128M67 Oil seal	Buy now
17	65N4598700 Spacer	Buy now
18	65N4599700 Spacer 2	Buy now
19	6884599701 Spacer 2	Buy now
20	65N4599400 Plate, tooth	Buy now
21	65N4561600 Nut, propeller	Buy now
22	9299018200 Washer (6e5)	Buy now
23	9017118M04 Nut, castle (6e5)	Buy now
24	9149040030 Pin, cotter (663)	Buy now
25	65N4594100 Propeller (3X14"X25"-Mf) UR	Buy now
25	65N4594500 Propeller (3X14"X27"-Mf) UR	Buy now
26	65N4594300 Propeller, Rear (25" X 13"-Mr) UR	Buy now
26	65N4594700 Propeller (3X13"X27"-Mr) UR	Buy now

Meter



Ref	Part	
1	6Y58350T01 Digital tachometer assembly AP	Buy now
2	9E45004433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E45004533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	9299004100 Ybs67-4 washer, spring	Buy now
5	9538004600 Nut,hex	Buy now
6	6Y58350055 Meter assembly AP	Buy now
7	6Y583570S5 Speedometer assembly	Buy now
10	6Y583533T2 Grommet	Buy now
11	6Y58355731 Tube	Buy now
12	6Y58372800 Connector assembly	Buy now
20	9046511M10 Clamp AP	Buy now
14	6Y587122S0 Cord assembly 1 AP	Buy now
15	6Y583553M0 Wire, lead (l=2.5m) AP	Buy now
16	1E68215100 Fuse (10a)	Buy now
17	6Y58211700 Wire, lead AP	Buy now

Meter




61A1700-2290

B4


Ref	Part	
18	68F8255380 Extension, wire lead (8m) AP	Buy now
19	6Y58355710 Tube (8m) AP	Buy now

Oil Pump




Ref	Part	
1	6E51427601 Lever	Buy now
2	9169030016 Pin, spring	Buy now
3	6R54123700 Joint, link	Buy now
4	6R41320000 Oil injection pump assembly	Buy now
5	6R31347100 Screw	Buy now
6	6L21347500 Gasket, breather bolt	Buy now
7	9321019MA7 O-ring(6r0)	Buy now
8	9010906M40 Bolt(6h0)	Buy now
9	6R31341600 Pipe, oil 1	Buy now
10	9046511M10 Clamp	Buy now
11	9044507M77 Hose (I390)	Buy now
12	9044507M85 Hose (I390)	Buy now
13	9044507M72 Hose (I390)	Buy now
14	9044507196 Hose (I200)	Buy now
15	6R31318310 Valve, check	Buy now

Oil Pump



Ref	Part	
16	9044507M87 Hose(62t)	Buy now
17	9044507M07 Hose(62t)	Buy now
18	9046407M05 Clamp (6g5)	Buy now
19	9046807M02 Clip (6e5)	Buy now
20	6R31153700 Gear, driven	Buy now
21	6R31311700 Collar, distance	Buy now
22	9321013M04 93210-13m04	Buy now
23	9020208M44 Washer, plate(6r3)	Buy now
24	6R54124100 Rod, link	Buy now
25	6H14123700 Joint, link	Buy now
26	9538005600 Nut, hexagon (663)	Buy now
27	9046805M03 Clip(6j8)	Buy now
28	9020205088 Washer, plate (666)	Buy now


Oil Tank



C2

Ref	Part	
1	61A2170803 Sub oil tank assembly.	Buy now
2	6E52173302 Sub tank, oil (10.5l)	Buy now
3	6E52177003 Oil tank cap assembly	Buy now
4	6E52432200 Pipe 11	Buy now
5	9046511M10 Clamp	Buy now
6	6462425102 Strainer 1	Buy now
7	6E52431901 Pipe, oil	Buy now
9	6E58190001 Oil feed pump assembly	Buy now
10	6E58192200 Grommet	Buy now
11	6E52432101 Pipe 10	Buy now
12	6E52437900 Pipe, joint 4	Buy now
13	9044511M26 Hose (l8000)	Buy now
15	9048006M19 Grommet (6e3)	Buy now
16	6E58572004 Oil level gauge assembly	Buy now
17	6R38572180 Wire, lead	Buy now


Oil Tank



C2


Ref	Part	
18	9046513M11 Clamp (6e5)	Buy now
19	6E5217340133 Holder, oil sub tank	Buy now
20	6E5217980133 Bracket, damper	Buy now
21	6E52174600 Damper	Buy now
22	9708006100 Bolt, hexagon	Buy now
23	9299006600 Washer, plain (646)	Buy now
24	9538006600 Nut(661)	Buy now
25	6E52175005 Oil tank assembly	Buy now
26	6R38573003 Oil level gauge assembly	Buy now
27	6E51341100 Strainer, oil	Buy now
28	6E51341400 Gasket, strainer cover	Buy now
29	9044505M02 Hose (I700)	Buy now
30	6A08231700 Damper, ignition coil	Buy now
31	6244254200 Collar	Buy now
32	9011906M65 Bolt, with washer	Buy now

Oil Tank




Ref	Part	
35	9046413M34 Clamp(6r3)	Buy now
36	64E2432300 Pipe 12	Buy now
37	9044512207 Hose (I3000)	Buy now
40	6E51343762 Mark Caution	Buy now
41	656W281002 Tool kit	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
1	64E43800024D Power trim & tilt assembly	Buy now
2	64E4382501 Housing Trim & Tilt	Buy now
3	64E4388J00 Plug 2	Buy now
4	9321010M74 O-ring	Buy now
5	64E4381700 Filter 2	Buy now
6	64E4381000 Tilt piston sub assembly	Buy now
7	64E4389800 Seal, dust 2	Buy now
8	64E4386700 O-ring 7	Buy now
9	64E4386600 O-ring 6	Buy now
10	6E54386200 O-ring 2	Buy now
11	64E4388300 O-ring 10	Buy now
12	6E54387200 Ring, back-up 2	Buy now
13	6E54381402 Piston, free	Buy now
15	64E4382000 Trim piston sub assembly	Buy now
16	64E4382100 Screw, trim cylinder end	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
17	64E4382200 Seal, trim dust	Buy now
18	64E4384J00 Seal, trim down	Buy now
19	6G54386400 O-ring 4	Buy now
20	6E54386400 O-ring 4	Buy now
21	6E54387401 Ring, back-up 4	Buy now
22	64E4382800 Body, reservoir	Buy now
23	64E4382900 Plug, reservoir	Buy now
24	64E4389700 O-ring	Buy now
25	64E4388E00 Bolt ,screw (l:14mm)	Buy now
26	64E4386900 O-ring 9	Buy now
27	64E4381G00 Pin 1	Buy now
28	6E54385800 Ball 1	Buy now
29	64E4382G00 Valve seat	Buy now
30	9020108M14 Washer, plate	Buy now
31	9708008016 Bolt	Buy now


Power Trim & Tilt Assy 1



F2


Ref	Part	
32	64E4381801 Lower shock mount pin set	Buy now
33	9038622M98 Bush(61u)	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
1	64E4388E10 Bolt ,screw (l:34.7mm)	Buy now
2	64E4383100 Connector, shaft	Buy now
3	64E4386800 O-ring 8	Buy now
4	64E4383000 Gear pump assembly	Buy now
5	72X4385800 Ball	Buy now
6	64E4384300 Screw, valve lock	Buy now
7	64E4384100 Piston, shuttle	Buy now
8	64E4380200 Valve sub assembly	Buy now
9	6E54389600 O-ring	Buy now
10	6G54386300 O-ring 3	Buy now
11	64E4385100 Seat, Relief Valve	Buy now
12	64E4385800 Ball	Buy now
13	64E4385900 Pin, Valve Support	Buy now
14	64E4385500 Spring, up relief	Buy now
15	64E4385000 Valve sub assembly	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
16	64E4386500 O-ring 10	Buy now
17	64E4381600 Filter 1	Buy now
19	64E4381710 Filter 2	Buy now
20	64E4386000 Manual valve sub-assembly	Buy now
21	72X85075L0 O-ring (nsd161)	Buy now
22	64E4382700 Ring set	Buy now
23	64E4387A00 O-ring	Buy now
24	64E4387300 Ring, back up	Buy now
25	64E4387500 Ring, snap	Buy now
26	64E4387910 Screw, with washer	Buy now
27	64E4387900 Screw, with washer	Buy now
28	64E4388001 Motor assembly	Buy now
29	6H14386K10 Spring, brush	Buy now
30	64E4380J00 Holder Brush	Buy now
31	64E4389100 Brush 1	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
32	9760704310 Screw, pan head(6g8)	Buy now
33	64E4380F00 Holder, brush 2	Buy now
34	64E4389200 Breaker comp. (brush 2)	Buy now
35	6G54386500 O-ring	Buy now
36	9310208M43 Oil seal(6b0)	Buy now
37	64E4380500 Armature assembly	Buy now
38	64E4384310 Screw valve lock	Buy now

Repair Kit 1



Ref	Part	
1	65NW000101 Power Head Gasket Kit	Buy now
2	6E511381A2 Gasket 1	Buy now
3	6G511181A1 Gasket, cylinder head 1	Buy now
4	6G511193A0 Gasket, head cover 1	Buy now
5	68812414A1 Gasket, cover	Buy now
6	6G541112A1 Gasket, exhaust inner cover	Buy now
7	6G541114A0 Gasket, exhaust inner cover	Buy now
8	6G511382A1 Gasket 2	Buy now
9	9310240M14 Oil seal(61a)	Buy now
10	9321104001 O-ring	Buy now
11	9310235M13 Oil seal (6e5)	Buy now
12	9310122M15 Oil seal (6e5)	Buy now
13	9321074M35 O-ring (6e5)	Buy now
14	6K713621A1 Gasket, valve seat	Buy now
15	6K713646A2 Gasket, manifold 2	Buy now

Repair Kit 1




Ref	Part	
16	64E13645A0 Gasket, manifold 1	Buy now
17	6E514198A2 Gasket	Buy now
18	6K71448300 Gasket	Buy now
19	65024431A0 Gasket, fuel pump	Buy now
20	6G545113A1 Gasket, upper casing	Buy now
21	65NW009300 Carburetor repair kit	Buy now
22	64D1438401 Gasket, float chamber	Buy now
23	6E51454600 Valve, needle	Buy now
24	6E51415900 Clip	Buy now
25	6E51438602 Pin, float	Buy now
26	61U1495900 Gasket	Buy now
27	64D1439400 Valve, drain	Buy now
28	6E51439801 Gasket	Buy now
29	6E51432801 Plug	Buy now
30	6E51497900 Gasket	Buy now

Repair Kit 1




31	6J81495900 Gasket, drin screw	Buy now
----	--	-------------------------

Repair Kit 2




Ref	Part	
1	65NW000121 Lower unit gasket kit	Buy now
2	6G541134A0 Gasket, exhaust manifold	Buy now
3	6G545114A0 Gasket, upper casing	Buy now
4	6E541135A0 Gasket, exhaust manifold	Buy now
5	9043008020 Gasket	Buy now
6	6E54512300 Gasket, muffler	Buy now
7	6E54436500 Damper, water seal 1	Buy now
8	6E54436600 Damper, water seal 2	Buy now
9	9321055M14 O-ring (70e)	Buy now
10	9310609014 Oil seal	Buy now
11	9321033M49 O-ring(6l5)	Buy now
12	9321086M38 O-ring (6e5)	Buy now
13	65N44315A0 Gasket, water pump	Buy now
14	9310128M67 Oil seal	Buy now
15	9321037160 O-ring (6g8)	Buy now

Repair Kit 2



Ref	Part	
16	9321098M33 O-ring (6a5)	Buy now
17	9321103MH9 O-ring(65n)	Buy now
18	9310145M59 Oil seal(65n)	Buy now
19	9310128M16 Oil seal (6e5)	Buy now
20	65NW0078A1 Water pump repair kit	Buy now
21	61A4432202 Insert, cartridge	Buy now
24	6E54435201 Impeller	Buy now
25	65N4432300 Outer plate, cartridge	Buy now
27	9028004M05 Key, woodruff (6e5)	Buy now
28	9360612019 Pin, dowel (614)	Buy now
29	9011908M14 Bolt, with washer	Buy now


Starting Motor



D6

Ref	Part	
1	6N78180010 Starting motor assembly	Buy now
2	6N78185010 Armature assembly	Buy now
3	61A8180900 Washer kit	Buy now
4	61A8182400 Washer 2	Buy now
5	6N78181000 Stator assembly	Buy now
6	6K78182G10 Bush, terminal	Buy now
7	6N78184000 Brush holder assembly	Buy now
8	6N78180100 Brush set	Buy now
9	6N78181300 Spring, brush	Buy now
10	6N78182010 Rear bracket assembly	Buy now
11	6N78180700 Gear assembly, starting motor	Buy now
12	6N78185700 Pinion stopper set	Buy now
13	6N78183000 Front bracket assembly	Buy now
14	6K78182610 Bolt	Buy now
15	6E58182E10 Washer, spring	Buy now


Starting Motor



D6

Ref	Part	
16	6E58182F10 Washer,plain	Buy now
17	6E58182A10 Nut	Buy now
18	6E58182K10 Nut	Buy now
19	6K7818220094 Bracket, starting motor	Buy now
20	9011908M76 Bolt, with washer(6e5)	Buy now
21	9011908M77 Bolt, with washer(6e5)	Buy now
22	9011908M57 Bolt, with washer	Buy now
23	9299008600 Washer, plain (663)	Buy now
24	9709508016 Bolt, hexagon deep recess	Buy now
25	9299508600 Washer, plain (663)	Buy now


Top Cowling



A4

Ref	Part	
2	6R34264700 Holder, clamp band	Buy now
3	9299006100 Washer(6a1)	Buy now
4	9538006600 Nut(661)	Buy now
5	64D4266200 Damper	Buy now
6	64D4281400 Hook, clamp	Buy now
7	9709506012 Bolt(gh1)	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	64D4261500 Seal	Buy now
11	9017906M24 Nut(6j8)	Buy now
12	65N42677P0 Graphic, front	Buy now
13	65NW0070N1 Graphic Set	Buy now
14	65N42681N0 Mark, cowling	Buy now
15	65N4267AN0 Graphic, rear 2	Buy now
16	65N42682N0 Mark, cowling	Buy now
17	65N42678N0 Graphic, front	Buy now


Top Cowling



A4

Ref	Part	
18	65N42683N0 Mark, Cowling	Buy now


Upper Casing



F6

Ref	Part	
1	6E545111028D Casing, upper L	Buy now
2	6N94279140 Mark 1	Buy now
3	6N94279240 Mark 2	Buy now
4	6E54515500 Cap	Buy now
5	6E54276900 Seal, rubber	Buy now
6	9709506010 Bolt	Buy now
7	9299506600 Washer, plain (646)	Buy now
8	9360812M05 Pin, dowel b (6e5)	Buy now
9	9011908M78 Bolt, with washer	Buy now
10	6G5411371194 Guide, exhaust FLUSHING KIT	Buy now
11	6E54272400 Grommet	Buy now
12	6G51258100 Joint, hose	Buy now
14	6G545113A1 Gasket, upper casing	Buy now
15	9011908M79 Bolt, hexagon (fj1)	Buy now
16	9709508045 Bolt, hexagon	Buy now

Upper Casing



F6

Ref	Part	
17	9299508100 Ybs67-8 washer, spring	Buy now
18	9538008700 Nut(661)	Buy now
20	6H11137200 Nipple, hose FLUSHING KIT	Buy now
21	6G541131015B Manifold, ext. 1	Buy now
22	6G545114A0 Gasket, upper casing	Buy now
23	9709508030 Bolt, hexagon (fj1)	Buy now
24	9299508600 Washer, plain (663)	Buy now
25	64D41132005B Manifold, exhaust	Buy now
26	6G541134A0 Gasket, exhaust manifold	Buy now
29	6E514711015B Muffler 1	Buy now
30	6E51473700 Damper, muffler	Buy now
31	9018305M02 Nut, spring (6e5)	Buy now
32	6E54512300 Gasket, muffler	Buy now
33	6E541135A0 Gasket, exhaust manifold	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.