



Yamaha E115AE 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers




Contents

BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	10
BRACKET 3	14
BRACKET 4	16
BRACKET 5	19
CARBURETOR 1	23
CARBURETOR 2	26
CONTROL	29
CRANKSHAFT. PISTON	33
CYLINDER. CRANKCASE 1	35
CYLINDER. CRANKCASE 2	37
ELECTRICAL 1	39
ELECTRICAL 2	41
ELECTRICAL 3	44
FUEL 1	46
FUEL 2	49
FUEL 3	52
FUEL TANK	53
GENERATOR	55
INTAKE 1	57
INTAKE 2	60
LOWER CASING. DRIVE 1	63
LOWER CASING. DRIVE 2	70
METER	73
POWER TRIM & TILT ASSY 1	75
POWER TRIM & TILT ASSY 2	78
REMOTE CONTROL ASSY	81
REMOTE CONTROL BOX	86
REPAIR KIT 1	87
REPAIR KIT 2	89
STARTER	91
STARTING MOTOR	95
STEERING	97
STEERING GUIDE	101
TOP COWLING 1	102
TOP COWLING 2	104
UPPER CASING	106


Bottom Cowling



Bottom Cowling




Bottom Cowling



Ref	Part	
41	688-82594-00 Clamp	Buy now
41	703-82119-00 Cover, lead wire	Buy now
42	689-85547-00 Damper	Buy now
42	6E5-82594-00 Clamp	Buy now
43	6G5-42791-00 Mark 1	Buy now
43	6G5-42791-10 Mark 1 FOR CHINA,CARIB	Buy now
44	6A1-28176-00 Label Caution FOR CARIB	Buy now
45	6E3-8257H-00 Plate Mark FOR CARIB	Buy now

E5


Bracket 1



F6

Ref	Part	
1	6E5-43111-04-8D Bracket, Clamp	Buy now
1	6E5-43111-62-8D Bracket, Clamp FOR TUNA	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06030 Bolt(jf7)	Buy now
5	92995-06100 Washer(6a1)	Buy now
6	6E5-43112-04-8D Bracket, Clamp	Buy now
6	6E5-43112-62-8D Bracket, Clamp FOR TUNA	Buy now
7	6E5-82148-00 Wire, lead 5	Buy now
8	97880-06012 Screw, pan head(62j)	Buy now
9	92990-06600 Washer, plain (646)	Buy now
10	97095-10045 Bolt(64d)	Buy now
11	92995-10100 Ybs67-10 washer, spring	Buy now
12	93700-06M03 Nipple, grease(6a1)	Buy now
13	663-45119-00 Cap, grease nipple AP	Buy now


Bracket 1



F6


Ref	Part	
14	6R3-43131-00 Bolt, clamp bracket	Buy now
15	90386-25M31 Bushing (6e5)	Buy now
16	90201-26M59 Washer, plate (6e5)	Buy now
17	90185-22M11 Nut, self-locking	Buy now
18	6G5-43145-01 Cap, clamp bracket	Buy now
19	6E5-43160-00 Tilt rod ass'y	Buy now
19	90109-12M55 Bolt(6e5) FOR TUNA	Buy now
20	688-43165-00 Stopper, tilt rod	Buy now
21	91690-30014 Pin, spring (647)	Buy now
22	90502-20M03 Spring (6e5)	Buy now
22	92995-16600 Washer(6e5) FOR TUNA	Buy now
23	92995-12200 Ybs66-12 washer,plain FOR TUNA	Buy now
24	95780-12300 Nut, nylon (6f2) FOR TUNA	Buy now
25	6E5-43311-A2-8D Bracket, Swivel 1 L/Y	Buy now
25	6E5-43311-E2-8D Bracket, Swivel 1 X	Buy now

Bracket 1



Ref	Part	
28	6E5-82147-00 Wire, lead 5 L/Y	Buy now
28	6E5-82147-20 Wire, lead 5 X	Buy now
29	6G5-43144-00 Hook, spring	Buy now
30	97095-06010 Bolt	Buy now
31	61U-43181-00 Lever, tilt stop 1	Buy now
32	61U-43185-00 Lever, tilt stop 2	Buy now
33	90386-10M16 Bushing (688)	Buy now
34	6G5-43148-00 Collar, distance	Buy now
35	90249-06M19 Pin(6e5)	Buy now
36	90387-10M05 Collar(6e5)	Buy now
37	91690-30020 Pin, spring (6h4)	Buy now
38	90506-14M24 Spring, tension(6e5)	Buy now
39	6E5-43126-02 Pin, upper shock mount	Buy now
40	90386-18M44 Bushing (6g5)	Buy now
41	93410-18M02 Circlip (6f2)	Buy now


Bracket 1



Ref	Part	
42	90101-12M03 Bolt (l:115mm) FOR TUNA	Buy now
43	90201-13M01 Washer, plate(6e5) FOR TUNA	Buy now
44	90201-12M05 Washe, plate(663) FOR TUNA	Buy now
45	95380-12600 Nut (707) FOR TUNA	Buy now


F6

Bracket 2



Ref	Part	
1	93109-38M02 Oil seal (6e5)	Buy now
2	6E5-42510-05-8D Steering bracket assembly L	Buy now
2	6E5-42510-11-8D Steering Bracket assembly L/Y	Buy now
2	6E5-42510-25-8D Steering bracket assembly X	Buy now
2	6E5-42510-61-8D Steering bracket assembly L-FOR TUNA	Buy now
2	6E5-42510-71-8D Steering Bracket assembly X	Buy now
3	90116-10M28 Bolt, stud	Buy now
4	90185-10051 Nut, self-locking	Buy now
5	90201-38M60 Washer, plate (6e5) FOR TUNA	Buy now
6	90386-38M32 Bush(6e5)	Buy now
6	90386-38M89 Bush(6e5) FOR TUNA	Buy now
7	6E5-44551-61-8D Housing, Lower Mount Rubber FOR TUNA	Buy now
7	6G5-44551-01-8D Housing, lower mount rubber	Buy now
8	6E5-42535-60 Washer, thrust FOR TUNA	Buy now
8	93410-37M04 Circlip (6e5)	Buy now


Bracket 2



A5

Ref	Part	
9	6E5-42546-60 Nut FOR TUNA	Buy now
10	6E5-44575-00 Damper, lower mount rubber	Buy now
11	6E5-44555-00-94 Mount damper, lower side	Buy now
12	90202-32M19 Washer, plate (6e5)	Buy now
13	90201-16M55 Washer, plate (6e5)	Buy now
14	6E5-82149-00 Wire, lead 3	Buy now
15	90109-14M34 Bolt(6e5)	Buy now
15	90109-14M54 Bolt(6e5) FOR TUNA	Buy now
16	90201-15M58 Washer, plate (6e5)	Buy now
17	90185-14M00 Nut, self-locking(61a) FOR TUNA	Buy now
17	95380-14800 Nut, crown (6e5)	Buy now
18	92995-14600 Washer (6e5)	Buy now
19	6E5-44552-01-94 Housing, lower mount rubber	Buy now
20	97095-10045 Bolt(64d)	Buy now
21	92995-10100 Ybs67-10 washer, spring	Buy now


Bracket 2



A5

Ref	Part	
22	6E5-44553-01-8D Cover, lower mount	Buy now
23	90501-16M28 Spring (6e5)	Buy now
24	97885-06016 Screw, pan head(6b0)	Buy now
25	90179-06066 Nut(663)	Buy now
26	6E5-44514-00-94 Mount damper, upper side	Buy now
26	6E5-44514-60-94 Mount damper, upper side FOR TUNA	Buy now
27	90201-26M57 Washer, plate (6e5)	Buy now
28	90202-26M18 Washer, plate (6e5)	Buy now
28	92995-14200 23 – FOR TUNA	Buy now
29	90201-14M56 Washer, plate (6e5)	Buy now
29	90201-15M00 Washer, plate(6e5) FOR TUNA	Buy now
30	90109-12M37 Bolt	Buy now
30	90109-14M53 Bolt(6e5) FOR TUNA	Buy now
31	90185-12M12 Nut, self-locking(6e5)	Buy now
32	663-44575-00 Damper, lower mount rubber EXCEPT FOR TUNA	Buy now


Bracket 2



Ref	Part	
33	6E5-44511-00-5B Cover, upper mount	Buy now
33	6E5-44511-60-5B Cover, upper mount FOR TUNA	Buy now

A5

Bracket 3




 6E50200-0160

A7

Ref	Part	
1	6E5-43170-00-4D Shock Absorber assembly	Buy now
2	6E5-43128-00-8D Spacer, clamp bracket	Buy now
3	90109-06M07 Bolt (6e5)	Buy now
4	6E5-43124-00 Pin, lower shock mount	Buy now
5	90386-18M44 Bushing (6g5)	Buy now
6	6E5-43613-00 Arm, tilt lock	Buy now
7	6E5-43614-00 Plate, tilt lock 1	Buy now
8	6E5-43615-00 Plate, Tilt Lock	Buy now
9	90240-06M07 Pin, Clevis	Buy now
10	92990-06600 Washer, plain (646)	Buy now
11	91490-25012 Pin, cotter	Buy now
12	90506-23M10 Spring, Tension	Buy now
13	6E5-43659-00 Shaft, Reverse Lock	Buy now
14	92995-08600 Washer, plain (663)	Buy now
16	6E5-43679-00 Stopper, Hook	Buy now

Bracket 3





6E50200-0160

A7


Ref	Part	
17	97095-06016 Bolt, hexagon deep recess	Buy now
18	6E5-43630-01 Tilt Lever assembly	Buy now
19	90386-08032 Bushing (650)	Buy now
20	90202-08M08 Washer, Plate	Buy now
22	61U-43631-00 Lever, Tilt	Buy now
23	90254-03003 Pin, spring	Buy now
24	6E5-43317-00 Grip	Buy now
25	90152-05M00 Screw, Countersunk	Buy now
26	6E5-43616-00 Rod, tilt lock	Buy now
27	90506-09M09 Spring, Tension	Buy now
28	688-43184-00 Collar, anchor lever	Buy now
29	91490-30025 Pin cotter	Buy now
30	6E5-43676-00 Hook	Buy now

Bracket 4




Ref	Part	
1	64E-43111-02-8D Bracket, clamp	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06030 Bolt(jf7)	Buy now
5	92995-06100 Washer(6a1)	Buy now
6	6E5-82148-00 Wire, lead 5	Buy now
7	97095-06010 Bolt	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	64E-43112-02-8D Bracket, clamp	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	92990-06600 Washer, plain (646)	Buy now
13	93700-06M03 Nipple, grease(6a1)	Buy now
14	663-45119-00 Cap, grease nipple AP	Buy now
15	64E-43131-01 Bolt, clamp bracket	Buy now
16	97095-08020 Bolt, hexagon	Buy now

Bracket 4



Ref	Part	
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	90386-25M31 Bushing (6e5)	Buy now
19	90201-26M59 Washer, plate (6e5)	Buy now
20	90185-22M11 Nut, self-locking	Buy now
21	90465-11M10 Clamp	Buy now
22	64E-43311-10-8D Bracket, swivel L	Buy now
22	64E-43311-20-8D Bracket, swivel X	Buy now
23	90465-08M63 Clamp(61u)	Buy now
26	6E5-82147-00 Wire, lead 5 L	Buy now
26	6E5-82147-20 Wire, lead 5 X	Buy now
27	6G5-43144-00 Hook, spring	Buy now
29	6G5-43181-02 Lever, tilt stop 1	Buy now
30	6G5-43185-02 Lever, tilt stop 2	Buy now
31	90386-10M16 Bushing (688)	Buy now
32	6G5-43148-00 Collar, distance	Buy now


Bracket 4



Ref	Part	
33	90249-06M19 Pin(6e5)	Buy now
34	90387-10M05 Collar(6e5)	Buy now
35	91690-30020 Pin, spring (6h4)	Buy now
36	90506-14M24 Spring, tension(6e5)	Buy now
37	64E-43126-00 Pin, upper shock mount	Buy now
38	90386-22M98 Bush(61u)	Buy now
39	93410-22M11 Circlip(61u)	Buy now
40	90101-12M03 Bolt (l:115mm) FOR TUNA	Buy now
41	90201-13M01 Washer, plate(6e5) FOR TUNA	Buy now
42	90201-12M05 Washe, plate(663) FOR TUNA	Buy now
43	95380-12600 Nut (707) FOR TUNA	Buy now

B2


Bracket 5



B4

Ref	Part	
1	64E-43139-02 Cam, trim sender (with screw)	Buy now
2	97780-60525 Screw, tapping(65j)	Buy now
3	64E-83672-02 Trim sender	Buy now
4	97885-06016 Screw, pan head(6b0)	Buy now
5	90465-11M10 Clamp	Buy now
6	93210-37MH7 O-ring(61u)	Buy now
7	90202-40M47 Washer, plate(61a)	Buy now
8	61A-43376-00 Bolt, thrust receiver	Buy now
9	95780-10300 Nut, nylon (6e5)	Buy now
10	6E5-42510-05-8D Steering bracket assembly L	Buy now
10	6E5-42510-25-8D Steering bracket assembly X	Buy now
10	6E5-42510-61-8D Steering bracket assembly L-FOR TUNA	Buy now
11	90201-38M60 Washer, plate (6e5) FOR TUNA	Buy now
12	90386-38M32 Bush(6e5)	Buy now
12	90386-38M89 Bush(6e5) FOR TUNA	Buy now


Bracket 5



B4

Ref	Part	
13	6E5-44551-61-8D Housing, Lower Mount Rubber FOR TUNA	Buy now
13	6G5-44551-01-8D Housing, lower mount rubber	Buy now
14	6E5-42535-60 Washer, thrust FOR TUNA	Buy now
14	93410-37M04 Circlip (6e5)	Buy now
15	6E5-42546-60 Nut FOR TUNA	Buy now
16	6E5-44575-00 Damper, lower mount rubber	Buy now
17	6E5-44555-00-94 Mount damper, lower side	Buy now
18	90202-32M19 Washer, plate (6e5)	Buy now
19	90201-16M55 Washer, plate (6e5)	Buy now
20	6E5-82149-00 Wire, lead 3	Buy now
21	90109-14M34 Bolt(6e5)	Buy now
21	90109-14M54 Bolt(6e5) FOR TUNA	Buy now
22	90201-15M58 Washer, plate (6e5)	Buy now
23	90185-14M00 Nut, self-locking(61a) FOR TUNA	Buy now
23	95380-14800 Nut, crown (6e5)	Buy now


Bracket 5



B4

Ref	Part	
24	92995-14600 Washer (6e5)	Buy now
25	6E5-44552-01-94 Housing, lower mount rubber	Buy now
26	97095-10045 Bolt(64d)	Buy now
27	92995-10100 Ybs67-10 washer, spring	Buy now
28	6E5-44553-01-8D Cover, lower mount	Buy now
29	90501-16M28 Spring (6e5)	Buy now
31	90179-06066 Nut(663)	Buy now
32	6E5-44514-00-94 Mount damper, upper side	Buy now
32	6E5-44514-60-94 Mount damper, upper side FOR TUNA	Buy now
33	90201-26M57 Washer, plate (6e5)	Buy now
34	90202-26M18 Washer, plate (6e5)	Buy now
34	92995-14200 23 – FOR TUNA	Buy now
35	90201-14M56 Washer, plate (6e5)	Buy now
35	90201-15M00 Washer, plate(6e5) FOR TUNA	Buy now
36	90109-12M37 Bolt	Buy now


Bracket 5



Ref	Part	
36	90109-14M53 Bolt(6e5) FOR TUNA	Buy now
37	90185-12M12 Nut, self-locking(6e5)	Buy now
38	663-44575-00 Damper, lower mount rubber EXCEPT FOR TUNA	Buy now
39	6E5-44511-00-5B Cover, upper mount	Buy now
39	6E5-44511-60-5B Cover, upper mount FOR TUNA	Buy now
42	703-82119-00 Cover, lead wire	Buy now
43	90465-13M18 Clamp	Buy now


B4

Carburetor 1



Ref	Part	
1	61U-14301-M1 Carburetor assembly 1	Buy now
2	61U-14302-M1 Carburetor assembly 2	Buy now
3	6E5-14384-04 Gasket, float chamber	Buy now
4	61U-14381-00 Body, float chamber #2	Buy now
5	61U-14381-M0 Body, float chamber #1	Buy now
6	6E5-14383-01 Screw, drain	Buy now
7	6J8-14959-00 Gasket, drin screw	Buy now
8	6E5-14385-02 Float	Buy now
9	6E5-14546-00 Valve, needle	Buy now
10	6E5-14159-00 Clip	Buy now
11	6E5-14386-02 Pin, float	Buy now
12	61U-1492F-39 Jet, air slow	Buy now
13	61U-14959-00 Gasket	Buy now
14	61U-14394-00 Valve, drain	Buy now
15	61A-1492E-87 Jet, main (#174)	Buy now


Carburetor 1



C1

Ref	Part	
16	6E5-14398-01 Gasket	Buy now
17	6E5-1492A-00 Nozzle, main	Buy now
18	6E5-14321-00 Screw, throttle #2	Buy now
19	6J8-14334-00 Spring, throttle #2	Buy now
20	6E5-14328-01 Plug	Buy now
21	6E5-14979-00 Gasket	Buy now
22	6E5-14323-03 Screw, air adjusting	Buy now
23	6E5-14223-00 Spring, air adjusting	Buy now
24	6E5-14527-01 Plate	Buy now
25	6E5-14959-01 Gasket	Buy now
26	97880-05008 Screw, with washer	Buy now
27	92900-05100 Ybs67-5 washer, spring	Buy now
28	97880-05016 Screw, pan head(6b0)	Buy now
30	61A-1492H-12 Jet, slow air (#60)	Buy now
31	61A-1492G-54 Jet, main air (#270)	Buy now


Carburetor 1




Ref	Part	
32	6E5-14324-00 Screw, flat head	Buy now
34	61A-14383-01 Screw, drain	Buy now

C1

Carburetor 2





64W0171-4060



C3

Ref	Part	
1	61U-14301-02 Carburetor assembly 1 (61u-03)	Buy now
2	61U-14302-02 Carburetor assembly 2 (61U-03)	Buy now
3	6E5-14384-04 Gasket, float chamber	Buy now
4	61U-14381-00 Body, float chamber	Buy now
5	97980-05116 Screw, pan head	Buy now
6	6E5-14383-01 Screw, drain	Buy now
7	6J8-14995-00 Gasket, drin screw	Buy now
8	6E5-14385-02 Float	Buy now
9	6E5-14546-00 Valve, needle	Buy now
10	6E5-14159-00 Clip	Buy now
11	6E5-14386-02 Pin, float	Buy now
12	61U-1492F-39 Jet, air slow	Buy now
13	61U-14959-00 Gasket	Buy now
14	61U-14394-00 Valve, drain	Buy now
15	61A-1492E-87 Jet, main (#174)	Buy now

Carburetor 2





64W0171-4060

C3

Ref	Part	
16	6E5-14398-01 Gasket	Buy now
17	6E5-1492A-00 Nozzle, main	Buy now
18	6E5-14321-00 Screw, throttle #2	Buy now
19	6J8-14334-00 Spring, throttle #2	Buy now
20	6E5-14328-01 Plug	Buy now
21	6E5-14979-00 Gasket	Buy now
22	6E5-14323-03 Screw, air adjusting	Buy now
23	6E5-14223-00 Spring, air adjusting	Buy now
24	6E5-14527-01 Plate	Buy now
25	6E5-14959-01 Gasket	Buy now
26	61A-1492H-12 Jet, slow air (#60)	Buy now
27	61A-1492G-54 Jet, main air (#270)	Buy now
28	6E5-14324-00 Screw, flat head	Buy now
29	61A-14383-01 Screw, drain	Buy now
30	97980-05108 Screw, with washer	Buy now


Carburetor 2



64W0171-4060


C3

Ref	Part	
31	6J8-14959-00 Gasket, drin screw	Buy now




F3

Ref	Part	
1	6E5-48531-00 Bracket, remote control	Buy now
2	6E5-48538-00 Clamp, cable	Buy now
3	91690-30012 Pin, spring	Buy now
4	97095-08020 Bolt, hexagon	Buy now
5	92995-08100 Ybs67-8 washer, spring	Buy now
6	6E5-41632-02-1S Lever, magneto control	Buy now
7	6E5-48344-00 Cable end, remote control	Buy now
8	92990-06200 Ybs66-6 washer, plain	Buy now
9	90185-06M07 Nut, self-locking(6e5)	Buy now
10	6E5-41631-01-1S Lever, magneto control	Buy now
11	90157-06013 Screw, pan head(697)	Buy now
12	90501-16M12 Spring, compression (688)	Buy now
13	95303-06600 Nut(661)	Buy now
14	688-44194-00 Cap	Buy now
15	97013-08045 Bolt	Buy now




F3

Ref	Part	
16	90201-08M23 Washer, plate (6e5)	Buy now
17	90386-12089 Bushing(663)	Buy now
18	90387-08M16 Collar	Buy now
19	90386-22M13 Bushing (688)	Buy now
20	90202-12092 Washer, plate(663)	Buy now
21	90201-08M13 Washer plate (682)	Buy now
22	90508-29M12 Spring (6e5)	Buy now
23	6E5-41636-01 Rod, magneto control	Buy now
24	95380-05600 Nut, hexagon (663)	Buy now
25	662-41237-01 Joint, link	Buy now
29	688-41636-00 Rod 1	Buy now
32	6E5-41213-00 Cam, accel.	Buy now
33	90387-06M29 Coller (6a0)	Buy now
34	90206-10M04 Washer, wave (676)	Buy now
35	97095-06025 Bolt	Buy now



F3


Ref	Part	
36	6E5-44117-00-1S Bracket	Buy now
37	90119-06MA2 Bolt, with washer	Buy now
38	68F-44121-00 Lever, shift rod	Buy now
39	6E5-44122-00 Bushing, shift rod lever	Buy now
40	90202-08M20 Washer, plate (6e5)	Buy now
41	90468-18008 Clip 620436610000	Buy now
43	90386-06M12 Bushing (688)	Buy now
44	6E5-44118-01-94 Bracket 2	Buy now
45	97013-08030 Bolt	Buy now
46	92903-08600 Washer, plain (663)	Buy now
47	93501-04M02 Ball (697)	Buy now
48	90501-12082 Spring 6484411600	Buy now
49	648-42715-00 Bushing 2	Buy now
50	93700-06M03 Nipple, grease(6a1)	Buy now
51	61U-44120-01 Handle Gear Shift assembly L	Buy now



F3

Ref	Part	
51	61U-44120-11 Handle Gear Shift assembly Y	Buy now
51	6E5-44120-03 Handle gear shift assembly L	Buy now
51	6E5-44120-23 Handle gear shift assembly X	Buy now
51	61U-44120-21 Handle Gear Shift assembly X	Buy now
52	93210-09165 O-ring	Buy now
53	90386-16M66 Bush(6e5)	Buy now
54	90202-16061 Washer, plate(663)	Buy now
55	93410-16006 Circlip	Buy now


Crankshaft. Piston



B1


Ref	Part	
1	6N7-11411-01 Crankshaft	Buy now
2	6E5-11447-00 Seal, ring	Buy now
3	6E5-15163-00-1S Housing, bearing 1	Buy now
4	93311-940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	93102-40M14 Oil seal(61a)	Buy now
6	93211-04001 O-ring	Buy now
7	90119-06MA2 Bolt, with washer	Buy now
8	93310-954U1 Bearing, cylindrical(64c)	Buy now
9	93306-208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
10	93410-40M03 Circlip(n02)	Buy now
11	6G5-15359-00-94 Housing, oil seal	Buy now
12	93102-35M13 Oil seal (6e5)	Buy now
13	93101-22M15 Oil seal (6e5)	Buy now
14	93210-74M35 O-ring (6e5)	Buy now
16	6R5-11631-01-93 Piston (std)	Buy now

Crankshaft. Piston



Ref	Part	
16	6R5-11635-01 Piston (0.25mm o/s) AP	Buy now
16	6R5-11636-01 Piston (0.50mm o/s) AP	Buy now
17	61U-11601-00 Piston ring set (std)	Buy now
17	61U-11601-10 Piston ring set (0.25mm o/s) AP	Buy now
17	61U-11601-20 Piston ring set (0.50mm o/s) AP	Buy now
18	6R5-11642-01-93 Piston 2 (std)	Buy now
18	6R5-11645-01 Piston 2 (0.25mm o/s) AP	Buy now
18	6R5-11646-01 Piston 2 (0.50mm o/s) AP	Buy now
20	6K7-11633-00 Pin, piston	Buy now
21	6E5-11634-00 Clip, piston pin	Buy now
22	6E5-11650-01 Rod, connecting assembly	Buy now
23	90109-08022 Bolt	Buy now
24	93603-21111 Pin, dowel(663) UN (QTY)120	Buy now
25	90201-21M75 Washer, plate (6f3)	Buy now
26	93310-836U0 Bearing, cylindrical(61u)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
3	624-11379-00 Valve, check	Buy now
4	663-11518-01 Lock, bearing	Buy now
5	6E5-11372-01 Nipple, hose	Buy now
6	90340-14M00 Plug, straight screw(62y)	Buy now
7	90430-14115 Gasket (663)	Buy now
8	93608-12063 Pin, dowel (626)	Buy now
9	90105-10M20 Bolt (6e5)	Buy now
10	90119-08M94 Bolt, with washer	Buy now
11	90116-08M45 Bolt, stud (6e5)	Buy now
12	6E5-11325-00 Anode	Buy now
13	98780-04015 Screw, flat head(ga5)	Buy now
14	6R3-1131M-01 Cover	Buy now
15	6R3-11397-01 Gasket	Buy now
16	97013-06016 Bolt, hexagon deep recess	Buy now
17	92903-06600 Washer, plain (646)	Buy now

Cylinder. Crankcase 1




61U2200-3030

Ref	Part	
18	61U-11119-01 3-	Buy now
18	6E5-11119-01 Hanger, engine	Buy now
19	90119-08MA3 Bolt, with washer	Buy now
22	68F-44533-00 Damper, upper mount rubber	Buy now
23	90119-06MA2 Bolt, with washer	Buy now
25	6E5-11381-A2 Gasket 1	Buy now
27	90465-06M86 Clamp	Buy now

A6


Cylinder. Crankcase 2



B3

Ref	Part	
1	6E5-11111-00-1S Head, cylinder 1	Buy now
2	6E5-11181-A1 Gasket, cylinder head 1	Buy now
3	90119-08MA8 Bolt, with washer	Buy now
4	6E5-11191-01-1S Cover, cylinder head 1	Buy now
5	6E5-11193-A0 Gasket, head cover 1	Buy now
6	90119-06MA4 Bolt, with washer	Buy now
7	6E5-12411-30 Thermostat	Buy now
8	6G5-12413-00-1S Cover, thermostat	Buy now
9	688-12414-A1 Gasket, cover	Buy now
10	90119-06MA6 Bolt, with washer	Buy now
11	6E5-41111-00-1S Inner cover, exhaust	Buy now
12	6E5-41112-A1 Gasket, exhaust inner cover	Buy now
13	6N7-41113-00-1S Outer cover, exhaust	Buy now
14	650-24378-00 Pipe, joint 2	Buy now
15	6E5-24312-00 Pipe 2	Buy now


Cylinder. Crankcase 2



Ref	Part	
16	90467-08004 Clip, pipe 6162435600	Buy now
17	90119-06MA5 Bolt, with washer	Buy now
18	6G5-12416-00 Valve, pressure control	Buy now
19	90501-16M11 Spring, compression (688)	Buy now
20	90480-20M05 Grommet (688)	Buy now
21	6G5-11382-A1 Gasket 2	Buy now
22	6G5-11372-00-1S Cover, bypass 2	Buy now
23	90119-06MA2 Bolt, with washer	Buy now
24	6E5-12576-00 Hose 1	Buy now
25	90465-13M18 Clamp	Buy now
26	94702-00160 Plug, spark (b8hs-10)	Buy now
26	94702-00247 Plug, spark (br8hs-10) FOR CHINA,CARIB	Buy now

B3

Electrical 1




 61U0200-0151

D7

Ref	Part	
1	6N7-85537-00 Cover	Buy now
2	6N7-85542-01-1S Bracket	Buy now
3	6A0-82317-00 Damper, ignition coil	Buy now
4	624-42542-00 Collar	Buy now
5	90119-06M59 Bolt, with washer	Buy now
6	97095-06012 Bolt(gh1)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	6E5-85540-00 C.d.i. unit assembly	Buy now
9	97880-06040 Screw pan head	Buy now
10	92990-06100 Washer(6a1)	Buy now
11	92990-06600 Washer, plain (646)	Buy now
12	90159-06M11 Screw, with washer(6l2)	Buy now
13	6H0-81960-00 Rectifier & regulator assembly	Buy now
14	6E5-81961-00 Cover	Buy now
15	90387-06M77 Collar	Buy now


Electrical 1




61U0200-0151

D7

Ref	Part	
16	97013-06045 Bolt, hexagon	Buy now
17	92903-06600 Washer, plain (646)	Buy now
18	90201-06M05 Washer, plate(6e3)	Buy now
19	90465-06M86 Clamp	Buy now




Ref	Part	
1	6G5-82152-00 Holder, fuse	Buy now
2	6R3-85570-01 Ignition coil assembly	Buy now
3	97095-06020 Bolt(7u8)	Buy now
4	92995-06600 Washer, plain (646)	Buy now
5	663-82370-01 Plug cap assembly	Buy now
5	6G1-82370-21 Plug cap assembly FOR CARIB	Buy now
6	61A-81941-00 Starter relay assembly	Buy now
7	689-81952-10 Holder, starter relay	Buy now
8	6E5-81948-10 Bracket	Buy now
8	6E5-81948-22 Bracket	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
11	6E5-86110-02 Solenoid	Buy now
12	6E5-86116-01 Wire, pull	Buy now
13	91609-30010 Pin, spring (663)	Buy now
16	93210-03261 O-ring (663)	Buy now



E1


Ref	Part	
17	688-82560-10 Thermo switch assembly	Buy now
18	61U-82590-M1 Wire Harness assembly	Buy now
18	6E5-82590-04 Wire Harness assembly	Buy now
19	663-82151-00 Fuse FOR 6E5-82590-04	Buy now
20	61U-82105-01 Wire Harness	Buy now
21	6E5-82117-01 Wire, lead	Buy now
22	6R3-82519-00 Wire, earth lead	Buy now
23	97095-06012 Bolt(gh1)	Buy now
25	6E5-82531-10 Wire, lead	Buy now
28	662-82519-00 Wire, earth lead	Buy now
31	90465-12M25 Clamp (6e5)	Buy now
31	92995-06200 Ybs66-6 washer, plain	Buy now
32	90465-05M87 Clamp	Buy now
33	90465-08M89 Clamp	Buy now
34	6E5-81950-00 Relay assembly	Buy now

Electrical 2



Ref	Part	
35	6E5-8195A-00 Relay assembly	Buy now
36	6G5-87149-10 Connector	Buy now
37	6G5-82119-00 Cover, lead wire	Buy now
38	6E5-82116-00 Wire, minus lead	Buy now
39	6N7-83557-00 Tube I.DIA.) 22MM	Buy now
40	90465-13M18 Clamp	Buy now



E1



E3

Ref	Part	
1	688-82540-11 Neutral switch assembly	Buy now
2	6E5-82554-00 Stay, neutral switch	Buy now
3	663-82555-01 Plate	Buy now
4	63D-82510-10 Main switch assembly	Buy now
5	676-82577-00 Cap, key	Buy now
6	97885-06012 Screw, pan head(62j)	Buy now
7	697-8252E-01-4D Cover, Main Switch	Buy now
8	697-8252F-01-4D Cover, main switch 2	Buy now
9	97880-06025 Screw, pan head(6b0)	Buy now
10	92990-06100 Washer(6a1)	Buy now
11	97013-06030 Bolt	Buy now
12	92903-06100 Washer(6a1)	Buy now
13	97013-06020 Bolt(62y)	Buy now
15	69W-82575-00 Engine stop switch assembly	Buy now
16	682-82556-00 Lanyard, stop switch	Buy now

Electrical 3




61U2200-3170

Ref	Part	
17	689-8257Y-00 Cap	Buy now
18	97095-06016 Bolt, hexagon deep recess	Buy now
19	92995-06100 Washer(6a1)	Buy now

E3


Fuel 1



C5

Ref	Part	
1	6E5-24304-10 Fuel pipe joint comp. 1	Buy now
2	97095-06028 Bolt (6g0)	Buy now
3	61U-24313-00 Pipe 3	Buy now
4	90465-11M10 Clamp	Buy now
6	61A-24560-04 Filter assembly	Buy now
7	61A-24521-00 Cup, filter	Buy now
8	65L-24531-01 Nut	Buy now
9	61A-24564-00 O-ring	Buy now
10	61A-24577-01 Spring	Buy now
11	61A-24563-00 Element, filter	Buy now
12	61A-24469-00 Float, water level	Buy now
13	65L-24558-00 Holder, filter	Buy now
14	97095-06016 Bolt, hexagon deep recess	Buy now
15	92995-06100 Washer(6a1)	Buy now
16	90201-06068 Washer,plate (6k8)	Buy now


Fuel 1



C5

Ref	Part	
17	61U-24566-01 Bracket, filter	Buy now
18	97095-06014 Bolt(gj3)	Buy now
19	92995-06600 Washer, plain (646)	Buy now
22	61U-24314-00 Pipe 4	Buy now
24	6E5-24410-03 Fuel pump assembly	Buy now
25	6E5-24444-00 Screw	Buy now
26	6E5-24413-00 Body 2	Buy now
27	6E5-24471-00 Diaphragm	Buy now
28	6E5-24435-00 Gasket, body 2	Buy now
29	6E5-24411-00 Diaphragm	Buy now
30	648-24424-00 Seat,spring	Buy now
31	6E5-24423-00 Spring, diaphragm	Buy now
32	6E5-24434-02 Gasket, body	Buy now
33	6A0-24421-01 Valve, check	Buy now
34	6A0-14325-00 Screw, pan head	Buy now


Fuel 1



Ref	Part	
35	95380-03600 Nut (6g8)	Buy now
36	6E5-24412-10 Body 1	Buy now
37	650-24431-A0 Gasket,fuel pump	Buy now
38	97095-06050 Bolt(jf7)	Buy now
40	6G5-24316-10 Pipe 6	Buy now
43	6E5-24376-10 Pipe, joint 1	Buy now
44	6G5-24318-10 Hose (l90)	Buy now
45	6G5-24319-10 Pipe 9	Buy now
48	90446-15M07 Hose(6g4)	Buy now
49	656-W2810-02 Tool kit	Buy now

C5


Fuel 2



C7

Ref	Part	
1	61U-24316-00 Pipe 6	Buy now
2	90465-11M10 Clamp	Buy now
3	90445-13M11 Pipe, fuel 1	Buy now
5	6E5-24378-00 Pipe, joint 3	Buy now
6	61U-24410-00 Fuel pump assembly	Buy now
7	61U-24411-00 Diaphragm	Buy now
8	61U-24421-00 Valve, Check	Buy now
9	61U-24423-00 Spring, Diaphragm	Buy now
10	61U-24454-00 Spring	Buy now
11	61U-24486-00 O-Ring	Buy now
12	61U-24461-00 Pipe, Joint	Buy now
13	61U-24478-00 Joint	Buy now
14	61U-24479-00 O-Ring	Buy now
15	61U-24489-00 O-Ring	Buy now
16	97880-06016 Screw pan head	Buy now


Fuel 2



C7

Ref	Part	
17	61U-24424-00 Seat, Spring	Buy now
18	92990-06100 Washer(6a1)	Buy now
19	61U-24491-10 Bracket, Fuel Pump	Buy now
20	97095-06020 Bolt(7u8)	Buy now
21	92995-06600 Washer, plain (646)	Buy now
22	61U-24315-00 Pipe 5	Buy now
24	90465-08M46 Clamp(61u)	Buy now
25	97095-06012 Bolt(gh1)	Buy now
27	90445-07MA3 Hose (I200)	Buy now
28	90445-07M32 Hose (I200)	Buy now
29	90468-07M02 Clip (6e5)	Buy now
30	61U-24317-00 Pipe 7	Buy now
33	61A-24500-00 Fuel cock assembly 1	Buy now
34	90445-13M02 Hose (I90)	Buy now
36	61U-24496-00 Knob	Buy now


Fuel 2



Ref	Part	
37	95380-05600 Nut, hexagon (663)	Buy now
38	90386-05M54 Bushing (6g8)	Buy now
39	90501-07M81 Spring, compression(61u)	Buy now
40	90201-05M06 Washer, plate(61u)	Buy now
41	90468-05M03 Clip(6j8)	Buy now
42	61U-24494-00 Wire, pull	Buy now
43	97095-05010 Bolt (682)	Buy now
44	92995-05600 Washer, plain (646)	Buy now
46	92995-06100 Washer(6a1)	Buy now
48	61U-42744-00 Stay	Buy now
49	97095-06016 Bolt, hexagon deep recess	Buy now

C7

Fuel 3




61U0200-0120

D2


Ref	Part	
1	6Y2-24306-53 Fuel pipe comp. 1 AP FOR TUNA	Buy now
2	6E5-24305-04 Fuel pipe joint comp. 2	Buy now
3	93210-08287 O-ring (655)	Buy now
4	6Y2-24305-04 Fuel pipe joint comp. 2	Buy now
6	90445-13M01 Hose (I2050)	Buy now
7	6E5-24351-51 Band 1	Buy now
8	90445-13M00 Hose (I850)	Buy now
9	6Y2-24360-52 Primer pump assembly	Buy now

Fuel Tank



Ref	Part	
1	6YJ-24201-00 Fuel tank comp. AP	Buy now
1	6YJ-24201-10 Fuel Tank assembly (24L) AP FOR CHINA	Buy now
2	6YJ-24610-01 Cap assembly	Buy now
3	6Y1-24260-12 Fuel meter assembly FOR CHINA	Buy now
3	6YJ-24260-00 Fuel meter assembly	Buy now
4	98586-05016 Screw, pan head	Buy now
5	6Y1-24329-00 Seal	Buy now
6	6Y1-24268-00 Gasket, fuel meter	Buy now
7	6YJ-24167-00 Strainer	Buy now
8	6Y2-24306-07 Fuel Pipe Comp. 1 AP	Buy now
9	6E5-24305-04 Fuel pipe joint comp. 2	Buy now
10	93210-08287 O-ring (655)	Buy now
11	6Y2-24305-04 Fuel pipe joint comp. 2	Buy now
13	90445-13M01 Hose (I2050)	Buy now
14	6E5-24351-50 Band 1	Buy now

Fuel Tank




6E50700-0210

D5

Ref	Part	
15	90445-13M00 Hose (I850)	Buy now
16	6Y2-24360-02 Primer pump assembly	Buy now



Generator



D6

Ref	Part	
1	6E5-85550-00 Rotor assembly	Buy now
2	6E5-85510-01 Stator assembly	Buy now
3	6E5-85580-00 Coil, pulser	Buy now
4	90280-05015 Key, woodruff	Buy now
5	90201-21M18 Washer, plate (663)	Buy now
6	90170-20137 Nut, hexagon(663)	Buy now
7	97013-06060 Bolt, hexagon	Buy now
8	92903-06600 Washer, plain (646)	Buy now
9	688-41611-00 Retainer, magneto base 1	Buy now
10	688-41612-00 Retainer, magneto base 2	Buy now
11	97880-06018 Screw, pan head(6e5)	Buy now
12	90464-12M00 Clamp	Buy now
13	6E5-81332-00 Plate, timing	Buy now
14	97885-06010 Screw pan head	Buy now
15	92995-06600 Washer, plain (646)	Buy now

Generator




6E51200-2091

D6

Ref	Part	
16	6E5-81337-01 Cover, flywheel	Buy now
17	6G5-82317-00 Damper	Buy now
18	6A0-82317-00 Damper, ignition coil	Buy now
19	624-42542-00 Collar	Buy now
20	90119-06M65 Bolt, with washer	Buy now
21	6E5-14488-00 Label, caution	Buy now


Intake 1



B4

Ref	Part	
1	6E5-13610-00 Reed valve assembly	Buy now
2	6E5-W0004-00 Reed set	Buy now
3	6E5-13621-A1 Gasket, valve seat	Buy now
4	97880-05025 Screw, panhead (a93)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
6	6E5-13641-03-1S Manifold 1	Buy now
7	624-14485-00 Pipe, joint	Buy now
8	6E5-11370-01 Check valve assembly	Buy now
9	90445-07M28 Hose (l200)	Buy now
10	90445-07M24 Hose (l390)	Buy now
11	90445-07M25 Hose (l200)	Buy now
12	90445-07M23 Hose (l570)	Buy now
13	6E0-24378-00 Pipe, joint	Buy now
14	90468-07M02 Clip (6e5)	Buy now
15	90445-07M46 Hose (l390)	Buy now


Intake 1



B4

Ref	Part	
16	90445-07M59 Hose (I770)	Buy now
17	90445-07M27 Hose (I390)	Buy now
20	90116-06M30 Bolt, stud(6e5)	Buy now
21	6E5-13645-A1 Gasket, manifold 1	Buy now
22	90119-06MA3 Bolt, with washer	Buy now
23	97013-06045 Bolt, hexagon	Buy now
24	92903-06600 Washer, plain (646)	Buy now
25	90465-06M86 Clamp	Buy now
26	97095-06012 Bolt(gh1)	Buy now
27	92995-06600 Washer, plain (646)	Buy now
28	6E5-14198-A2 Gasket	Buy now
29	90179-06M28 Nut(63v)	Buy now
30	6E5-41217-01 Rod, accel. lever	Buy now
31	6G1-42748-00 Grommet	Buy now
32	61U-14417-00-94 Cover 1	Buy now


Intake 1



Ref	Part	
34	6E5-14485-00 Pipe, joint	Buy now
36	647-14395-60 Cap, over flow pipe	Buy now
37	6E5-14483-A1 Gasket	Buy now
38	97013-06020 Bolt(62y)	Buy now
40	6E5-14418-00 Cover 2	Buy now
41	6E5-1441K-00 Emblem 1	Buy now
42	6E5-14416-A1 Gasket, air cleaner	Buy now
43	90119-06M31 Bolt, with washer(680)	Buy now

B4


Intake 2



B6

Ref	Part	
1	6E5-13610-00 Reed valve assembly	Buy now
2	6E5-W0004-00 Reed set	Buy now
3	6E5-13621-A1 Gasket, valve seat	Buy now
4	97880-05025 Screw, panhead (a93)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
6	6E5-13641-03-1S Manifold 1	Buy now
7	624-14485-00 Pipe, joint	Buy now
8	6E5-11370-01 Check valve assembly	Buy now
9	90445-07M28 Hose (l200)	Buy now
10	90445-07M24 Hose (l390)	Buy now
11	90445-07M46 Hose (l390)	Buy now
12	90116-06M30 Bolt, stud(6e5)	Buy now
13	6E5-13645-A1 Gasket, manifold 1	Buy now
14	90119-06MA3 Bolt, with washer	Buy now
15	90465-06M86 Clamp	Buy now


Intake 2



B6

Ref	Part	
16	97095-06012 Bolt(gh1)	Buy now
17	92995-06600 Washer, plain (646)	Buy now
18	6E5-14198-A2 Gasket	Buy now
19	90179-06M28 Nut(63v)	Buy now
20	6E5-41217-01 Rod, accel. lever	Buy now
21	6E5-41256-01 Rod, choke 1	Buy now
22	661-41262-02 Joint, choke lever	Buy now
23	6E5-41271-02 Knob, choke	Buy now
24	689-41273-00 Grommet	Buy now
25	6E5-14417-10-94 Cover 1	Buy now
27	6E5-14485-00 Pipe, joint	Buy now
28	90445-07M23 Hose (I570)	Buy now
29	647-14395-60 Cap,over flow pipe	Buy now
30	6E5-14483-A1 Gasket	Buy now
31	97013-06020 Bolt(62y)	Buy now


Intake 2



Ref	Part	
32	92903-06600 Washer, plain (646)	Buy now
33	6E5-14418-00 Cover 2	Buy now
34	6E5-1441K-00 Emblem 1	Buy now
35	6E5-14416-A1 Gasket, air cleaner	Buy now
36	90119-06M31 Bolt, with washer(680)	Buy now


B6

Lower Casing. Drive 1




Ref	Part	
1	61U-45300-13-8D Lower unit assembly L	Buy now
1	61U-45300-23-8D Lower Unit assembly X	Buy now
1	61U-45300-33-8D Lower Unit assembly Y	Buy now
2	6E5-45301-05-8D Casing, lower	Buy now
3	93315-628U9 Brg,cyl-cal roller (6e5)	Buy now
4	93332-000U7 Brg,tapered roller 76mm (6e5)	Buy now
5	6E5-45567-01-10 Shim (t:0.10mm) UR	Buy now
5	6E5-45567-01-12 Shim (t:0.12mm) UR	Buy now
5	6E5-45567-01-15 Shim (t:0.15mm) UR	Buy now
5	6E5-45567-01-18 Shim (t:0.18mm) UR	Buy now
5	6E5-45567-01-30 Shim (t:0.30mm) UR	Buy now
5	6E5-45567-01-40 Shim (t:0.40mm) UR	Buy now
5	6E5-45567-01-50 Shim (t:0.50mm) UR	Buy now
6	90340-08002 Plug, straight screw	Buy now
7	688-45341-10 Plug, drain	Buy now

Lower Casing. Drive 1




Ref	Part	
8	90430-08020 Gasket	Buy now
9	6E5-45536-00 Sleeve, drive shaft	Buy now
10	6E5-45378-00 Nipple, hose	Buy now
11	90445-07ME8 Hose (I250) L	Buy now
11	90445-07ME9 Hose (I250) X/Y	Buy now
12	6E5-83558-00 End, nipple FOR TUNA	Buy now
12	6E5-83558-10 End, nipple	Buy now
13	6E5-45321-00 Plate	Buy now
14	93210-58144 O-ring(47x)	Buy now
15	93106-09014 Oil seal	Buy now
16	90119-06M10 Bolt, with washer	Buy now
17	6E5-44150-02 Shift cam assembly	Buy now
18	99001-08600 Circlip(2r6)	Buy now
19	90501-11M10 Spring, compression (663)	Buy now
20	61A-45538-00 Spacer, 1	Buy now

Lower Casing. Drive 1




Ref	Part	
21	90201-22M01 Washer, plate(61a)	Buy now
22	90206-22M19 Washer, wave(61a)	Buy now
23	61A-45527-00 Collar, drive shaft	Buy now
24	61A-44311-01 Housing, water pump	Buy now
25	6R3-44322-42 Insert, cartridge FOR CHROMATE	Buy now
26	93210-86M38 O-ring (6e5)	Buy now
27	93210-37160 O-ring (6g8)	Buy now
28	6E5-44352-01 Impeller	Buy now
29	90280-04M05 Key, woodruff (6e5)	Buy now
30	6E5-44323-40 Outer plate, cartridge FOR CHROMATE	Buy now
31	6E5-44315-A0 Gasket,water pump	Buy now
32	93606-12019 Pin, dowel (614)	Buy now
33	90119-08M14 Bolt, with washer	Buy now
34	6E5-45331-00-94 Housing, bearing	Buy now
35	93101-28M16 Oil seal (6e5)	Buy now

Lower Casing. Drive 1



Ref	Part	
36	93317-330U2 Bearing, cylindrical(6k0)	Buy now
37	6E5-45587-01-10 Shim (t:0.10mm) UR	Buy now
37	6E5-45587-01-12 Shim (t:0.12mm) UR	Buy now
37	6E5-45587-01-15 Shim (t:0.15mm) UR	Buy now
37	6E5-45587-01-18 Shim (t:0.18mm) UR	Buy now
37	6E5-45587-01-30 Shim (t:0.30mm) UR	Buy now
37	6E5-45587-01-40 Shim (t:0.40mm) UR	Buy now
37	6E5-45587-01-50 Shim (t:0.50mm) UR	Buy now
38	93341-930V2 Bearing, thrust(64d)	Buy now
39	93210-55M14 O-ring (70e)	Buy now
40	6E5-45344-00 Cover, oil seal	Buy now
41	97095-08025 Bolt (62g)	Buy now
42	92995-08600 Washer, plain (663)	Buy now
43	6E5-45501-01 Drive shaft comp. L	Buy now
43	6E5-45501-11 Drive shaft comp. Y	Buy now


Lower Casing. Drive 1



C6

Ref	Part	
43	6E5-45501-21 Drive shaft comp. X	Buy now
44	6E5-45551-02 Pinion	Buy now
45	90170-16M01 Nut, hexagon (688)	Buy now
46	6E5-45560-01 Gear 1 assembly	Buy now
47	93315-425U7 Brg,cyl-cal roller (6e5)	Buy now
48	6E5-45611-01 Shaft, propeller	Buy now
49	6E5-45641-02 Shifter	Buy now
50	6E5-45634-01 Slide, shift	Buy now
51	90501-16M37 Spring (6g5)	Buy now
52	93507-32009 Ball (12r)	Buy now
53	93511-32017 Ball (498)	Buy now
54	93503-16003 Ball	Buy now
55	90250-08M07 Pin, straight (6g5)	Buy now
56	6E5-45631-01 Clutch, dog	Buy now
57	6E5-45633-01 Ring, cross pin	Buy now


Lower Casing. Drive 1



C6

Ref	Part	
58	6E5-45332-00-94 Housing, bearing	Buy now
59	93306-208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
60	6E5-45571-01 Gear 2	Buy now
61	6E5-45576-00 Washer, thrust 2	Buy now
62	93315-430U8 Bearing	Buy now
63	93101-30M17 Oil seal (6e5)	Buy now
64	93210-86M39 O-ring (6e5)	Buy now
65	6L6-45577-00-10 Shim (t:0.10mm) UR	Buy now
65	6L6-45577-00-12 Shim (t:0.12mm) UR	Buy now
65	6L6-45577-00-15 Shim (t:0.15mm) UR	Buy now
65	6L6-45577-00-18 Shim (t:0.18mm) UR	Buy now
65	6L6-45577-00-30 Shim (t:0.30mm) UR	Buy now
65	6L6-45577-00-40 Shim (t:0.40mm) UR	Buy now
65	6L6-45577-00-50 Shim (t:0.50mm) UR	Buy now
66	90201-30M92 Washer (6g5)	Buy now


Lower Casing. Drive 1



Ref	Part	
67	90282-04010 Key, strait(663)	Buy now
68	688-45383-02 Washer, claw	Buy now
69	688-45384-00 Nut	Buy now


C6

Lower Casing. Drive 2



Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	6E5-44361-00 Tube, water L	Buy now
2	6E5-44361-10 Tube, water Y	Buy now
2	6E5-44361-20 Tube, water X	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5) L/X	Buy now
5	97075-10045 Bolt(64d) L/X	Buy now
6	92995-10100 Ybs67-10 washer, spring L/X	Buy now
7	90119-10M89 Bolt, with washer L/X	Buy now
8	663-45376-00-94 Guide, seal damper	Buy now
9	688-45375-00 Damper, seal 2	Buy now
10	688-45214-02 Cover, water inlet	Buy now
11	688-45215-02 Cover, water inlet	Buy now
12	90152-05M07 Screw, countersunk	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now

Lower Casing. Drive 2




64W0171-0230

D3

Ref	Part	
14	6E5-45371-01 Trim tab	Buy now
15	90105-10M00 Bolt, hexagon (663)	Buy now
16	90445-07MFO Hose (I1160) EXCEPT FOR TUNA	Buy now
17	6E5-83558-00 End, nipple EXCEPT FOR TUNA	Buy now
18	90465-11M10 Clamp FOR TUNA	Buy now
20	6E5-44312-00 Cover, water pump housing	Buy now
21	6E5-45987-01 Spacer 1	Buy now
22	688-45997-01 Spacer 2	Buy now
23	92990-18200 Washer (6e5)	Buy now
24	90171-18M04 Nut, castle (6e5)	Buy now
25	91490-40030 Pin, cotter (663)	Buy now
26	688-45930-02-98 Propeller (3x13x17) UR	Buy now
26	688-45941-00-EL Propeller assembly(3X13"X19"-K) UR	Buy now
26	688-45970-03-98 Propeller (3x13"x19"-k) UR	Buy now
26	6E5-45943-00-EL Propeller (3x12-5/8"x21"-k) UR	Buy now

Lower Casing. Drive 2




 FWD
64W0171-0230

D3

Ref	Part	
26	6E5-45945-01-EL Propeller (3x13-1/4x17-k) UR	Buy now
26	6E5-45947-00-EL Propeller (3x13-1/2x15-k) UR	Buy now

Meter




6E50200-0280

E4

Ref	Part	
1	6Y5-83540-14 Tachometer assembly AP EXCEPT FOR TUNA	Buy now
2	6Y5-83517-00 Bulb (12v-1.7w)	Buy now
3	6Y5-83536-10 Socket, meter	Buy now
4	6Y5-83523-00 Damper	Buy now
5	6Y5-83514-00 Plate, fitting	Buy now
6	95380-05600 Nut, hexagon (663)	Buy now
7	92990-05100 Ybs67-5 washer, spring	Buy now
8	6Y5-83670-12 Trim meter assembly. AP	Buy now
9	6Y5-83518-00 Bulb (12v-1.7w) t6.5	Buy now
10	6Y5-83536-00 Socket, meter	Buy now
11	6Y5-83544-00 Plate, fitting	Buy now
12	688-83664-00 Damper	Buy now
13	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
14	1E6-82151-00 Fuse (10a)	Buy now
15	6Y5-82117-00 Wire, lead AP EXCEPT FOR TUNA	Buy now


Meter



Ref	Part	
16	6R3-82553-70 Extension, wire lead (for trim AP 4P,7M)	Buy now

E4

Power Trim & Tilt Assy 1




61U1200-2270

B7

Ref	Part	
1	64E-43800-02-4D Power trim & tilt assembly	Buy now
2	64E-43825-01 Housing Trim & Tilt	Buy now
3	64E-4388J-00 Plug 2	Buy now
4	93210-10M74 O-ring	Buy now
5	64E-43817-00 Filter 2	Buy now
6	64E-43810-00 Tilt piston sub assembly	Buy now
7	64E-43898-00 Seal, dust 2	Buy now
8	64E-43867-00 O-ring 7	Buy now
9	64E-43866-00 O-ring 6	Buy now
10	6E5-43862-00 O-ring 2	Buy now
11	64E-43883-00 O-ring 10	Buy now
12	6E5-43872-00 Ring, back-up 2	Buy now
13	6E5-43814-02 Piston, free	Buy now
15	64E-43820-00 Trim piston sub assembly	Buy now
16	64E-43821-00 Screw, trim cylinder end	Buy now

Power Trim & Tilt Assy 1




B7

Ref	Part	
17	64E-43822-00 Seal, trim dust	Buy now
18	64E-4384J-00 Seal, trim down	Buy now
19	6G5-43864-00 O-ring 4	Buy now
20	6E5-43864-00 O-ring 4	Buy now
21	6E5-43874-01 Ring, back-up 4	Buy now
22	64E-43828-00 Body, reservoir	Buy now
23	64E-43829-00 Plug, reservoir	Buy now
24	64E-43897-00 O-ring	Buy now
25	64E-4388E-00 Bolt ,screw (l:14mm)	Buy now
26	64E-43869-00 O-ring 9	Buy now
27	64E-4381G-00 Pin 1	Buy now
28	6E5-43858-00 Ball 1	Buy now
29	64E-4382G-00 Valve seat	Buy now
30	90201-08M14 Washer, plate	Buy now
31	97080-08016 Bolt	Buy now


Power Trim & Tilt Assy 1

Ref	Part	
32	64E-43818-01 Lower shock mount pin set	Buy now
33	90386-22M98 Bush(61u)	Buy now



B7


Power Trim & Tilt Assy 2



C2

Ref	Part	
1	64E-4388E-10 Bolt ,screw (l:34.7mm)	Buy now
2	64E-43831-00 Connector, shaft	Buy now
3	64E-43868-00 O-ring 8	Buy now
4	64E-43830-00 Gear pump assembly	Buy now
5	72X-43858-00 Ball	Buy now
6	64E-43843-00 Screw, valve lock	Buy now
7	64E-43841-00 Piston, shuttle	Buy now
8	64E-43802-00 Valve sub assembly	Buy now
9	6E5-43896-00 O-ring	Buy now
10	6G5-43863-00 O-ring 3	Buy now
11	64E-43851-00 Seat, Relief Valve	Buy now
12	64E-43858-00 Ball	Buy now
13	64E-43859-00 Pin, Valve Support	Buy now
14	64E-43855-00 Spring, up relief	Buy now
15	64E-43850-00 Valve sub assembly	Buy now


Power Trim & Tilt Assy 2



C2

Ref	Part	
16	64E-43865-00 O-ring 10	Buy now
17	64E-43816-00 Filter 1	Buy now
19	64E-43817-10 Filter 2	Buy now
20	64E-43860-00 Manual valve sub-assembly	Buy now
21	72X-85075-L0 O-ring (nsd161)	Buy now
22	64E-43827-00 Ring set	Buy now
23	64E-4387A-00 O-ring	Buy now
24	64E-43873-00 Ring, back up	Buy now
25	64E-43875-00 Ring, snap	Buy now
26	64E-43879-10 Screw, with washer	Buy now
27	64E-43879-00 Screw, with washer	Buy now
28	64E-43880-01 Motor assembly	Buy now
29	6H1-4386K-10 Spring, brush	Buy now
30	64E-4380J-00 Holder Brush	Buy now
31	64E-43891-00 Brush 1	Buy now


Power Trim & Tilt Assy 2



C2

Ref	Part	
32	97607-04310 Screw, pan head(6g8)	Buy now
33	64E-4380F-00 Holder, brush 2	Buy now
34	64E-43892-00 Breaker comp. (brush 2)	Buy now
35	6G5-43865-00 O-ring	Buy now
36	93102-08M43 Oil seal(6b0)	Buy now
37	64E-43805-00 Armature assembly	Buy now
38	64E-43843-10 Screw valve lock	Buy now


Remote Control Assy



E-

Ref	Part	
1	703-48201-16 Remote control assembly (10p) AP	Buy now
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	703-48261-01 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now


Remote Control Assy



E1

Ref	Part	
15	703-48243-00 Bushing 3	Buy now
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now


Remote Control Assy



E1

Ref	Part	
30	703-48219-00 Cover, lead	Buy now
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-43 Main switch assembly	Buy now


Remote Control Assy



E1

Ref	Part	
45	703-82577-00 Cap, key	Buy now
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-02 Buzzer	Buy now
52	703-48284-00 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-48224-00 Cover, control lever WITHOUT PT/T SW.	Buy now
55	703-82563-02 Trim & tilt switch assembly WITH PT/T SW.	Buy now
56	703-48221-00 Grip	Buy now
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now


Remote Control Assy



E1

Ref	Part	
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now
63	703-82542-00 Cap FOR 703-48201-16	Buy now

Remote Control Box




67M0100-8280

D7

Ref	Part	
1	703-48201-16 Remote control assembly (10p) AP	Buy now
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	701-48320-30 Cable, Remote Control L=14F UR	Buy now
2	701-48320-40 Cable, Remote Control L=19F UR	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now
2	701-48320-80 Cable, Remote Control L=17F UR	Buy now


Repair Kit 1



E5

Ref	Part	
1	6E5-W0001-A3 Gasket kit	Buy now
2	6E5-14416-A1 Gasket, air cleaner	Buy now
3	6E5-14483-A1 Gasket	Buy now
4	6E5-14198-A2 Gasket	Buy now
5	6E5-11381-A2 Gasket 1	Buy now
6	6E5-11181-A1 Gasket, cylinder head 1	Buy now
7	6E5-11193-A0 Gasket, head cover 1	Buy now
8	688-12414-A1 Gasket, cover	Buy now
9	6E5-41112-A1 Gasket, exhaust inner cover	Buy now
10	93102-40M14 Oil seal(61a)	Buy now
11	93211-04001 O-ring	Buy now
12	93102-35M13 Oil seal (6e5)	Buy now
13	93101-22M15 Oil seal (6e5)	Buy now
14	93210-74M35 O-ring (6e5)	Buy now
15	6E5-13621-A1 Gasket, valve seat	Buy now


Repair Kit 1



E5


Ref	Part	
16	6E5-13645-A1 Gasket, manifold 1	Buy now
17	6E5-14384-04 Gasket, float chamber	Buy now
18	6E5-45113-A0 Gasket, upper casing	Buy now
19	61U-W0093-01 Carburetor repair kit	Buy now
22	6E5-14546-00 Valve, needle	Buy now
23	6E5-14386-02 Pin, float	Buy now
24	6E5-14385-02 Float	Buy now
26	6E5-14398-01 Gasket	Buy now
27	97880-05016 Screw, pan head(6b0)	Buy now
28	92990-05100 Ybs67-5 washer, spring	Buy now
29	6E5-14323-03 Screw, air adjusting	Buy now
30	6E5-14979-00 Gasket	Buy now
31	6J8-14959-00 Gasket, drin screw	Buy now
32	6E5-14959-01 Gasket	Buy now

Repair Kit 2



Ref	Part	
1	6E5-W0001-C1 Gasket kit, lower unit	Buy now
2	6E5-41134-B0 Gasket, exhaust manifold	Buy now
3	6E5-45114-A0 Gasket, upper casing	Buy now
4	6E5-45123-00 Gasket, muffler	Buy now
5	6E5-41135-A0 Gasket, exhaust manifold	Buy now
6	6E5-44365-00 Damper, water seal 1	Buy now
7	6E5-44366-00 Damper, water seal 2	Buy now
8	90430-08020 Gasket	Buy now
9	93210-58144 O-ring(47x)	Buy now
10	93106-09014 Oil seal	Buy now
11	93210-86M38 O-ring (6e5)	Buy now
12	93210-37160 O-ring (6g8)	Buy now
13	6E5-44315-A0 Gasket,water pump	Buy now
14	93101-28M16 Oil seal (6e5)	Buy now
15	93210-55M14 O-ring (70e)	Buy now

Repair Kit 2




61U0200-4380

Ref	Part	
16	93210-86M39 O-ring (6e5)	Buy now
17	93101-30M17 Oil seal (6e5)	Buy now
18	61U-W0078-03 Water pump repair kit	Buy now
19	6R3-44322-42 Insert, cartridge	Buy now
22	6E5-44352-01 Impeller	Buy now
23	6E5-44323-40 Outer plate, cartridge	Buy now
25	93606-12019 Pin, dowel (614)	Buy now
26	90119-08M14 Bolt, with washer	Buy now
27	90280-04M05 Key, woodruff (6e5)	Buy now

E7

Starter




61U2200-313C

D3

Ref	Part	
1	61U-W1571-00 Starter assembly	Buy now
2	61U-15711-00 Case, starter	Buy now
3	696-15773-00 Stay 3	Buy now
4	663-15739-00 Washer, thrust 2	Buy now
5	663-15713-00 Spring, starter	Buy now
6	61U-15714-00 Drum, sheave	Buy now
7	663-15764-00 Collar	Buy now
8	663-15741-02 Pawl, drive	Buy now
9	663-15754-00 Bushing	Buy now
10	663-15726-01 Washer, flat 1	Buy now
11	663-15744-00 Circlip	Buy now
12	663-15715-00 Spring, drive plate	Buy now
13	696-15716-00 Drive, plate	Buy now
14	696-15734-00 Spring, return	Buy now
15	663-15719-00 Washer, thrust	Buy now


Starter



D3

Ref	Part	
16	92905-06100 Washer(6a1)	Buy now
17	97305-06016 Bolt	Buy now
18	663-15752-00 Roller, wire	Buy now
19	663-15753-00 Bushing 1	Buy now
20	61U-15758-00 Guide, rope	Buy now
21	97305-06012 Bolt	Buy now
22	97305-06025 Bolt	Buy now
23	689-15755-01 Handle, starter	Buy now
24	* item_description	Buy now
25	6F5-15779-02 Cover	Buy now
26	90119-08M26 Bolt, with washer	Buy now
27	90387-08M05 Collar (663)	Buy now
28	90385-12M04 Bushing (6f5)	Buy now
29	697-15787-00-94 Adaptor	Buy now
30	90119-06M95 Bolt, with washer	Buy now


Starter



D3

Ref	Part	
31	624-42542-00 Collar	Buy now
32	6A0-82317-00 Damper, ignition coil	Buy now
33	692-15758-01-94 Guide, Rope	Buy now
34	697-15762-00 Seal 2	Buy now
35	97095-06020 Bolt(7u8)	Buy now
36	92995-06100 Washer(6a1)	Buy now
37	92995-06600 Washer, plain (646)	Buy now
38	95380-06600 Nut(661)	Buy now
39	61U-15772-00 Stay 2	Buy now
46	697-15789-00 Damper	Buy now
47	61U-15774-00-94 Stay 4	Buy now
48	61U-15723-01 Pulley, Starter	Buy now
49	97013-08016 Bolt, hexagon	Buy now
50	92903-08100 Ybs67-8 washer, spring	Buy now
51	61U-15770-00 Cable comp., starter stop	Buy now


Starter



Ref	Part	
52	663-15735-01 Guide, cam	Buy now
53	90506-08M23 Spring, tension(6k5)	Buy now
54	90508-12015 Spring torsion 616436420000	Buy now
55	90149-05095 Screw(663)	Buy now
56	663-15794-00 Stopper	Buy now
57	97095-06010 Bolt	Buy now
59	92990-06200 Ybs66-6 washer, plain	Buy now
60	91490-16012 Pin, cotter (e57)	Buy now
61	90202-06009 Washer plate 626427510000	Buy now
63	90468-18008 Clip 620436610000	Buy now
64	61U-2415A-00 Label, Caution	Buy now
65	61U-14488-00 Label, Caution	Buy now


D3

Starting Motor



Ref	Part	
1	6N7-81800-10 Starting motor assembly	Buy now
2	6N7-81850-10 Armature assembly	Buy now
3	61A-81809-00 Washer kit	Buy now
4	61A-81824-00 Washer 2	Buy now
5	6N7-81810-00 Stator assembly	Buy now
6	6K7-8182G-10 Bush, terminal	Buy now
7	6N7-81840-00 Brush holder assembly	Buy now
8	6N7-81801-00 Brush set	Buy now
9	6N7-81813-00 Spring, brush	Buy now
10	6N7-81820-10 Rear bracket assembly	Buy now
11	6N7-81807-00 Gear assembly, starting motor	Buy now
12	6N7-81857-00 Pinion stopper set	Buy now
13	6N7-81830-00 Front bracket assembly	Buy now
14	6K7-81826-10 Bolt	Buy now
15	6E5-8182E-10 Washer, spring	Buy now


Starting Motor



E4

Ref	Part	
16	6E5-8182F-10 Washer,plain	Buy now
17	6E5-8182A-10 Nut	Buy now
18	6E5-8182K-10 Nut	Buy now
19	6E5-81822-02-98 Bracket, starting motor	Buy now
20	90119-08M76 Bolt, with washer(6e5)	Buy now
21	90119-08M77 Bolt, with washer(6e5)	Buy now
22	90119-08M57 Bolt, with washer	Buy now
23	92990-08600 Washer, plain (663)	Buy now
24	97095-08016 Bolt, hexagon deep recess	Buy now
25	92995-08600 Washer, plain (663)	Buy now


Steering



E7

Ref	Part	
3	664-42119-00 Grip, steering handle	Buy now
4	6F6-42177-A0 Rubber, handle	Buy now
5	6K5-42137-00 Indicator, throttle	Buy now
6	90269-02M09 Rivet(6l5)	Buy now
7	90149-05M13 Screw, countersunk	Buy now
8	92903-10600 Washer, plate	Buy now
9	90501-23215 Spring (655)	Buy now
10	90386-08032 Bushing (650)	Buy now
11	692-42115-00 Shaft, steering handle	Buy now
12	663-42138-00 Lever, throttle	Buy now
13	90254-03003 Pin, spring	Buy now
14	692-42135-00 Housing, throttle lever	Buy now
15	663-42133-01 Gasket	Buy now
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	97885-06008 Screw, pan head(6a3)	Buy now

Steering




61U2200-3200

E7

Ref	Part	
19	97885-05012 Screw,pan head (646)	Buy now
20	692-26301-03 Throttle cable assembly	Buy now
22	90101-12M06 Bolt	Buy now
23	92990-12200 Ybs66-12 washer,plain	Buy now
24	90386-12089 Bushing(663)	Buy now
25	90202-12092 Washer, plate(663)	Buy now
26	90201-12537 Washer, plate(663)	Buy now
27	90206-12054 Washer, wave(663)	Buy now
28	90185-12058 Nut, nylon(663)	Buy now
29	697-44113-00 Cam plate, handle	Buy now
30	6K5-44191-00 Indicator,shift	Buy now
31	97013-06016 Bolt, hexagon deep recess	Buy now
32	92903-06100 Washer(6a1)	Buy now
33	692-44159-01 Handle, gear shift 2	Buy now
34	663-44173-00 Lever, shift control	Buy now


Steering



E7

Ref	Part	
35	90501-16M17 Spring (697)	Buy now
36	93515-32M01 Ball (697)	Buy now
37	90386-10009 Bushing 6484418600	Buy now
38	90201-10120 Washer, plate	Buy now
39	90185-10051 Nut, self-locking	Buy now
40	90387-12M30 Coller (697)	Buy now
41	90201-12M34 Washer (692)	Buy now
42	6E5-48310-01 Cable, remote control	Buy now
43	95380-05600 Nut, hexagon (663)	Buy now
44	6E5-44124-00 Link, shift lever	Buy now
45	95780-05300 Nut, nylon (6k8)	Buy now
46	92990-06600 Washer, plain (646)	Buy now
47	91490-25012 Pin, cotter	Buy now
48	663-42126-01 Friction, steering handle	Buy now
49	90101-06M27 Bolt	Buy now


Steering



E7

Ref	Part	
51	90175-06003 Nut, wing (f87)	Buy now
52	6E5-42518-01 Shaft, Friction	Buy now
53	663-42528-00 Piece, friction	Buy now
54	97080-06035 Bolt(j52)	Buy now
56	6E5-42515-00 Rod, steering link	Buy now
57	92995-08600 Washer, plain (663)	Buy now
58	90185-08057 Nut, nylon (6j8)	Buy now
59	90465-06M90 Clamp	Buy now
60	97885-06012 Screw, pan head(62j)	Buy now
61	697-82575-00 Engine stop switch assembly	Buy now
62	682-82556-00 Lanyard, stop switch	Buy now
63	689-8257Y-00 Cap	Buy now

Steering Guide




67H0100-9290

D6

Ref	Part	
1	6E5-61350-02 Steering guide attachment kit AP FOR CHINA	Buy now
2	6E5-61351-01 Rod, steering link	Buy now
3	90387-10M61 Collar (6e5)	Buy now
4	90560-12M01 Spacer (6e5)	Buy now
5	6E5-61355-00 Bolt	Buy now
6	90185-09M01 Nut, nylon (663)	Buy now
7	90201-10M20 Washer, plate (663)	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now


Top Cowling 1



A4

Ref	Part	
1	61U-42610-L0-4D Top Cowling assembly	Buy now
2	6E5-42647-00-94 Holder, clamp band	Buy now
3	6E5-42649-01-94 Holder, clamp band	Buy now
4	663-42662-00 Damper	Buy now
5	90266-06009 Rivet (697)	Buy now
6	90266-06M02 Rivet (697)	Buy now
7	6E5-42652-00 Hook 2	Buy now
8	688-42652-00 Hook 2	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	6E5-42617-00 Damper 1	Buy now
12	61U-42619-10 Damper, form	Buy now
13	61U-42627-10 Damper, form	Buy now
14	6E5-42615-00 Seal	Buy now
15	6G5-42613-00-4D Molding, air duct	Buy now


Top Cowling 1



A4

Ref	Part	
16	90179-06M24 Nut(6j8)	Buy now
17	61U-42626-00 Louver, 1	Buy now
18	61U-42636-00 Louver, 2	Buy now
19	90387-06M35 Collar(61u)	Buy now
20	61U-42677-J0 Graphic, front	Buy now
21	61U-W0070-H0 1-	Buy now
22	61U-42678-H0 Graphic, rear	Buy now
23	697-15761-01 Seal 1	Buy now
24	677-13437-08 1-	Buy now

Top Cowling 2




 61U1200-2020

A5

Ref	Part	
4	663-42662-00 Damper	Buy now
5	90266-06009 Rivet (697)	Buy now
6	90266-06M02 Rivet (697)	Buy now
7	6E5-42652-00 Hook 2	Buy now
8	688-42652-00 Hook 2	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	6E5-42617-00 Damper 1	Buy now
12	6E5-42619-00 Damper, Form	Buy now
13	6E5-42627-00 Damper, Form	Buy now
14	6E5-42615-00 Seal	Buy now
18	61U-42677-J0 Graphic, front	Buy now
19	61U-W0070-H0 1-	Buy now
20	61U-42678-H0 Graphic, rear	Buy now
21	688-42681-61 Mark, Cowling FOR TUNA	Buy now

Top Cowling 2




61U1200-2020

A5

Ref	Part	
22	688-42682-61 Mark, Cowling FOR TUNA	Buy now
23	677-13437-08 1-	Buy now


Upper Casing



C4

Ref	Part	
1	6E5-45111-02-8D Casing, upper L/Y	Buy now
1	6E5-45111-23-8D Casing, upper X	Buy now
2	6E5-45155-00 Cap	Buy now
3	6E5-42769-00 Seal, rubber	Buy now
4	97095-06010 Bolt	Buy now
5	92995-06600 Washer, plain (646)	Buy now
36	93608-12M05 Pin, dowel b (6e5) Y	Buy now
7	90119-08027 Bolt, with washer	Buy now
8	6E5-41137-03-94 Guide, exhaust	Buy now
9	6E5-42724-00 Grommet	Buy now
10	6G5-12581-00 Joint, hose	Buy now
12	6E5-45113-A0 Gasket, upper casing	Buy now
13	90119-08M79 Bolt, hexagon (fj1)	Buy now
14	97095-08045 Bolt, hexagon	Buy now
15	92995-08100 Ybs67-8 washer, spring	Buy now


Upper Casing



C4

Ref	Part	
16	95380-08700 Nut(661)	Buy now
18	6E5-41131-01-5B Manifold, Ext. 1	Buy now
19	6E5-45114-A0 Gasket, upper casing	Buy now
20	97095-08030 Bolt, hexagon (fj1)	Buy now
21	92995-08600 Washer, plain (663)	Buy now
22	6E5-41132-00-5B Manifold, exhaust	Buy now
23	6E5-41134-B0 Gasket, exhaust manifold	Buy now
26	6E5-14711-01-5B Muffler 1	Buy now
27	6E5-14737-00 Damper, muffler	Buy now
28	90183-05M02 Nut, spring (6e5)	Buy now
29	6E5-45123-00 Gasket, muffler	Buy now
30	6E5-41135-A0 Gasket, exhaust manifold	Buy now
33	6E5-45318-00 Bushing, drive shaft 3 X	Buy now
34	93420-36M01 Circlip (6a0) X	Buy now
35	6E5-45211-00-4D Extension Y	Buy now

Upper Casing



C4

Ref	Part	
37	<u>90116-10M38</u> Bolt, stud (6e5) Y	Buy now
38	<u>90101-10M02</u> Bolt Y	Buy now
39	<u>92990-10600</u> Washer, plate Y	Buy now
40	<u>92990-10100</u> Ybs67-10 washer, spring Y	Buy now
41	<u>95380-10600</u> Nut(624) Y	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.