



# Yamaha E115AWH 2003

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

|                                     |     |
|-------------------------------------|-----|
| <b>BOTTOM COWLING</b>               | 3   |
| <b>BRACKET 1</b>                    | 6   |
| <b>BRACKET 2</b>                    | 10  |
| <b>BRACKET 3</b>                    | 14  |
| <b>BRACKET 4</b>                    | 16  |
| <b>BRACKET 5</b>                    | 19  |
| <b>CARBURETOR 1</b>                 | 23  |
| <b>CARBURETOR 2</b>                 | 26  |
| <b>CONTROL</b>                      | 29  |
| <b>CRANKSHAFT. PISTON</b>           | 33  |
| <b>CYLINDER. CRANKCASE 1</b>        | 35  |
| <b>CYLINDER. CRANKCASE 2</b>        | 37  |
| <b>ELECTRICAL 1</b>                 | 39  |
| <b>ELECTRICAL 2</b>                 | 41  |
| <b>ELECTRICAL 3</b>                 | 44  |
| <b>FUEL 1</b>                       | 46  |
| <b>FUEL 2</b>                       | 49  |
| <b>FUEL 3</b>                       | 52  |
| <b>FUEL TANK</b>                    | 53  |
| <b>GENERATOR</b>                    | 55  |
| <b>INTAKE 1</b>                     | 57  |
| <b>INTAKE 2</b>                     | 60  |
| <b>LOWER CASING. DRIVE 1</b>        | 63  |
| <b>LOWER CASING. DRIVE 2</b>        | 70  |
| <b>METER</b>                        | 73  |
| <b>POWER TRIM &amp; TILT ASSY 1</b> | 75  |
| <b>POWER TRIM &amp; TILT ASSY 2</b> | 78  |
| <b>REMOTE CONTROL ASSY</b>          | 81  |
| <b>REMOTE CONTROL BOX</b>           | 86  |
| <b>REPAIR KIT 1</b>                 | 87  |
| <b>REPAIR KIT 2</b>                 | 89  |
| <b>STARTER</b>                      | 91  |
| <b>STARTING MOTOR</b>               | 95  |
| <b>STEERING</b>                     | 97  |
| <b>STEERING GUIDE</b>               | 101 |
| <b>TOP COWLING 1</b>                | 102 |
| <b>TOP COWLING 2</b>                | 104 |
| <b>UPPER CASING</b>                 | 106 |


## Bottom Cowling



**E5**


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 2   | <a href="#">6H4-42748-00</a><br>Grommet                  | <a href="#">Buy now</a> |
| 4   | <a href="#">688-42816-00</a><br>Lever, clamp 2           | <a href="#">Buy now</a> |
| 5   | <a href="#">90386-13M38</a><br>Bushing (697)             | <a href="#">Buy now</a> |
| 6   | <a href="#">90206-13M10</a><br>Washer, wave (6e5)        | <a href="#">Buy now</a> |
| 7   | <a href="#">90119-06M09</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 9   | <a href="#">6G5-42816-00</a><br>Lever, clamp 2           | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-42816-01</a><br>Lever, clamp 2           | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-44391-00</a><br>Nipple, hose             | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-42725-00</a><br>Grommet                  | <a href="#">Buy now</a> |
| 16  | <a href="#">61U-42725-00</a><br>Grommet                  | <a href="#">Buy now</a> |
| 18  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 19  | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 20  | <a href="#">90480-22M15</a><br>Grommet (6e5)             | <a href="#">Buy now</a> |
| 21  | <a href="#">90387-08M37</a><br>Coller (6e5)              | <a href="#">Buy now</a> |
| 22  | <a href="#">90201-08M54</a><br>Washer, plate (6e5)       | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 23  | <a href="#">97075-08035</a><br>Bolt(70w)           | <a href="#">Buy now</a> |
| 24  | <a href="#">90119-08M22</a><br>Bolt, with washer   | <a href="#">Buy now</a> |
| 25  | <a href="#">688-42726-10</a><br>Grommet            | <a href="#">Buy now</a> |
| 25  | <a href="#">6H4-42726-00</a><br>Grommet            | <a href="#">Buy now</a> |
| 26  | <a href="#">90480-10M36</a><br>Grommet (6e5)       | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5-42741-01-4D</a><br>Apron           | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-42771-01-4D</a><br>Apron           | <a href="#">Buy now</a> |
| 29  | <a href="#">97095-06020</a><br>Bolt(7u8)           | <a href="#">Buy now</a> |
| 31  | <a href="#">6E5-24367-01</a><br>Clamp, fuel pipe 2 | <a href="#">Buy now</a> |
| 31  | <a href="#">90338-05M03</a><br>Plug (6h1)          | <a href="#">Buy now</a> |
| 32  | <a href="#">90157-06M01</a><br>Screw (6e5)         | <a href="#">Buy now</a> |
| 33  | <a href="#">92990-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5-24367-10</a><br>Clamp, fuel pipe 2 | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-42716-00</a><br>Seal               | <a href="#">Buy now</a> |
| 38  | <a href="#">6E5-82588-00</a><br>Plate              | <a href="#">Buy now</a> |

# Bottom Cowling




| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 41  | <a href="#">688-82594-00</a><br>Clamp                      | <a href="#">Buy now</a> |
| 41  | <a href="#">703-82119-00</a><br>Cover, lead wire           | <a href="#">Buy now</a> |
| 42  | <a href="#">689-85547-00</a><br>Damper                     | <a href="#">Buy now</a> |
| 42  | <a href="#">6E5-82594-00</a><br>Clamp                      | <a href="#">Buy now</a> |
| 43  | <a href="#">6G5-42791-00</a><br>Mark 1                     | <a href="#">Buy now</a> |
| 43  | <a href="#">6G5-42791-10</a><br>Mark 1<br>FOR CHINA,CARIB  | <a href="#">Buy now</a> |
| 44  | <a href="#">6A1-28176-00</a><br>Label Caution<br>FOR CARIB | <a href="#">Buy now</a> |
| 45  | <a href="#">6E3-8257H-00</a><br>Plate Mark<br>FOR CARIB    | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-43111-04-8D</a><br>Bracket, Clamp             | <a href="#">Buy now</a> |
| 1   | <a href="#">6E5-43111-62-8D</a><br>Bracket, Clamp<br>FOR TUNA | <a href="#">Buy now</a> |
| 2   | <a href="#">6G5-45251-02</a><br>Anode                         | <a href="#">Buy now</a> |
| 3   | <a href="#">6G5-44526-00</a><br>Plate                         | <a href="#">Buy now</a> |
| 4   | <a href="#">97095-06030</a><br>Bolt(jf7)                      | <a href="#">Buy now</a> |
| 5   | <a href="#">92995-06100</a><br>Washer(6a1)                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-43112-04-8D</a><br>Bracket, Clamp             | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-43112-62-8D</a><br>Bracket, Clamp<br>FOR TUNA | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-82148-00</a><br>Wire, lead 5                  | <a href="#">Buy now</a> |
| 8   | <a href="#">97880-06012</a><br>Screw, pan head(62j)           | <a href="#">Buy now</a> |
| 9   | <a href="#">92990-06600</a><br>Washer, plain (646)            | <a href="#">Buy now</a> |
| 10  | <a href="#">97095-10045</a><br>Bolt(64d)                      | <a href="#">Buy now</a> |
| 11  | <a href="#">92995-10100</a><br>Ybs67-10 washer, spring        | <a href="#">Buy now</a> |
| 12  | <a href="#">93700-06M03</a><br>Nipple, grease(6a1)            | <a href="#">Buy now</a> |
| 13  | <a href="#">663-45119-00</a><br>Cap, grease nipple<br>AP      | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 14  | <a href="#">6R3-43131-00</a><br>Bolt, clamp bracket              | <a href="#">Buy now</a> |
| 15  | <a href="#">90386-25M31</a><br>Bushing (6e5)                     | <a href="#">Buy now</a> |
| 16  | <a href="#">90201-26M59</a><br>Washer, plate (6e5)               | <a href="#">Buy now</a> |
| 17  | <a href="#">90185-22M11</a><br>Nut, self-locking                 | <a href="#">Buy now</a> |
| 18  | <a href="#">6G5-43145-01</a><br>Cap, clamp bracket               | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5-43160-00</a><br>Tilt rod ass'y                   | <a href="#">Buy now</a> |
| 19  | <a href="#">90109-12M55</a><br>Bolt(6e5)<br>FOR TUNA             | <a href="#">Buy now</a> |
| 20  | <a href="#">688-43165-00</a><br>Stopper, tilt rod                | <a href="#">Buy now</a> |
| 21  | <a href="#">91690-30014</a><br>Pin, spring (647)                 | <a href="#">Buy now</a> |
| 22  | <a href="#">90502-20M03</a><br>Spring (6e5)                      | <a href="#">Buy now</a> |
| 22  | <a href="#">92995-16600</a><br>Washer(6e5)<br>FOR TUNA           | <a href="#">Buy now</a> |
| 23  | <a href="#">92995-12200</a><br>Ybs66-12 washer,plain<br>FOR TUNA | <a href="#">Buy now</a> |
| 24  | <a href="#">95780-12300</a><br>Nut, nylon (6f2)<br>FOR TUNA      | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-43311-A2-8D</a><br>Bracket, Swivel 1<br>L/Y      | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-43311-E2-8D</a><br>Bracket, Swivel 1<br>X        | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 28  | <a href="#">6E5-82147-00</a><br>Wire, lead 5<br>L/Y    | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-82147-20</a><br>Wire, lead 5<br>X      | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5-43144-00</a><br>Hook, spring           | <a href="#">Buy now</a> |
| 30  | <a href="#">97095-06010</a><br>Bolt                    | <a href="#">Buy now</a> |
| 31  | <a href="#">61U-43181-00</a><br>Lever, tilt stop 1     | <a href="#">Buy now</a> |
| 32  | <a href="#">61U-43185-00</a><br>Lever, tilt stop 2     | <a href="#">Buy now</a> |
| 33  | <a href="#">90386-10M16</a><br>Bushing (688)           | <a href="#">Buy now</a> |
| 34  | <a href="#">6G5-43148-00</a><br>Collar, distance       | <a href="#">Buy now</a> |
| 35  | <a href="#">90249-06M19</a><br>Pin(6e5)                | <a href="#">Buy now</a> |
| 36  | <a href="#">90387-10M05</a><br>Collar(6e5)             | <a href="#">Buy now</a> |
| 37  | <a href="#">91690-30020</a><br>Pin, spring (6h4)       | <a href="#">Buy now</a> |
| 38  | <a href="#">90506-14M24</a><br>Spring, tension(6e5)    | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5-43126-02</a><br>Pin, upper shock mount | <a href="#">Buy now</a> |
| 40  | <a href="#">90386-18M44</a><br>Bushing (6g5)           | <a href="#">Buy now</a> |
| 41  | <a href="#">93410-18M02</a><br>Circlip (6f2)           | <a href="#">Buy now</a> |

# Bracket 1



| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 42  | <a href="#">90101-12M03</a><br>Bolt (l:115mm)<br>FOR TUNA     | <a href="#">Buy now</a> |
| 43  | <a href="#">90201-13M01</a><br>Washer, plate(6e5)<br>FOR TUNA | <a href="#">Buy now</a> |
| 44  | <a href="#">90201-12M05</a><br>Washer, plate(6e3)<br>FOR TUNA | <a href="#">Buy now</a> |
| 45  | <a href="#">95380-12600</a><br>Nut (707)<br>FOR TUNA          | <a href="#">Buy now</a> |


## Bracket 2



A5


| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">93109-38M02</a><br>Oil seal (6e5)                              | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-42510-05-8D</a><br>Steering bracket assembly<br>L          | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-42510-11-8D</a><br>Steering Bracket assembly<br>L/Y        | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-42510-25-8D</a><br>Steering bracket assembly<br>X          | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-42510-61-8D</a><br>Steering bracket assembly<br>L-FOR TUNA | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-42510-71-8D</a><br>Steering Bracket assembly<br>X          | <a href="#">Buy now</a> |
| 3   | <a href="#">90116-10M28</a><br>Bolt, stud                                  | <a href="#">Buy now</a> |
| 4   | <a href="#">90185-10051</a><br>Nut, self-locking                           | <a href="#">Buy now</a> |
| 5   | <a href="#">90201-38M60</a><br>Washer, plate (6e5)<br>FOR TUNA             | <a href="#">Buy now</a> |
| 6   | <a href="#">90386-38M32</a><br>Bush(6e5)                                   | <a href="#">Buy now</a> |
| 6   | <a href="#">90386-38M89</a><br>Bush(6e5)<br>FOR TUNA                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-44551-61-8D</a><br>Housing, Lower Mount Rubber<br>FOR TUNA | <a href="#">Buy now</a> |
| 7   | <a href="#">6G5-44551-01-8D</a><br>Housing, lower mount rubber             | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-42535-60</a><br>Washer, thrust<br>FOR TUNA                 | <a href="#">Buy now</a> |
| 8   | <a href="#">93410-37M04</a><br>Circlip (6e5)                               | <a href="#">Buy now</a> |

## Bracket 2




| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 9   | <a href="#">6E5-42546-60</a><br>Nut<br>FOR TUNA                   | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-44575-00</a><br>Damper, lower mount rubber        | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-44555-00-94</a><br>Mount damper, lower side       | <a href="#">Buy now</a> |
| 12  | <a href="#">90202-32M19</a><br>Washer, plate (6e5)                | <a href="#">Buy now</a> |
| 13  | <a href="#">90201-16M55</a><br>Washer, plate (6e5)                | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-82149-00</a><br>Wire, lead 3                      | <a href="#">Buy now</a> |
| 15  | <a href="#">90109-14M34</a><br>Bolt(6e5)                          | <a href="#">Buy now</a> |
| 15  | <a href="#">90109-14M54</a><br>Bolt(6e5)<br>FOR TUNA              | <a href="#">Buy now</a> |
| 16  | <a href="#">90201-15M58</a><br>Washer, plate (6e5)                | <a href="#">Buy now</a> |
| 17  | <a href="#">90185-14M00</a><br>Nut, self-locking(61a)<br>FOR TUNA | <a href="#">Buy now</a> |
| 17  | <a href="#">95380-14800</a><br>Nut, crown (6e5)                   | <a href="#">Buy now</a> |
| 18  | <a href="#">92995-14600</a><br>Washer (6e5)                       | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5-44552-01-94</a><br>Housing, lower mount rubber    | <a href="#">Buy now</a> |
| 20  | <a href="#">97095-10045</a><br>Bolt(64d)                          | <a href="#">Buy now</a> |
| 21  | <a href="#">92995-10100</a><br>Ybs67-10 washer, spring            | <a href="#">Buy now</a> |

## Bracket 2



| Ref | Part                                                                          |                         |
|-----|-------------------------------------------------------------------------------|-------------------------|
| 22  | <a href="#">6E5-44553-01-8D</a><br>Cover, lower mount                         | <a href="#">Buy now</a> |
| 23  | <a href="#">90501-16M28</a><br>Spring (6e5)                                   | <a href="#">Buy now</a> |
| 24  | <a href="#">97885-06016</a><br>Screw, pan head(6b0)                           | <a href="#">Buy now</a> |
| 25  | <a href="#">90179-06066</a><br>Nut(663)                                       | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-44514-00-94</a><br>Mount damper, upper side                   | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-44514-60-94</a><br>Mount damper, upper side<br>FOR TUNA       | <a href="#">Buy now</a> |
| 27  | <a href="#">90201-26M57</a><br>Washer, plate (6e5)                            | <a href="#">Buy now</a> |
| 28  | <a href="#">90202-26M18</a><br>Washer, plate (6e5)                            | <a href="#">Buy now</a> |
| 28  | <a href="#">92995-14200</a><br>23 –<br>FOR TUNA                               | <a href="#">Buy now</a> |
| 29  | <a href="#">90201-14M56</a><br>Washer, plate (6e5)                            | <a href="#">Buy now</a> |
| 29  | <a href="#">90201-15M00</a><br>Washer, plate(6e5)<br>FOR TUNA                 | <a href="#">Buy now</a> |
| 30  | <a href="#">90109-12M37</a><br>Bolt                                           | <a href="#">Buy now</a> |
| 30  | <a href="#">90109-14M53</a><br>Bolt(6e5)<br>FOR TUNA                          | <a href="#">Buy now</a> |
| 31  | <a href="#">90185-12M12</a><br>Nut, self-locking(6e5)                         | <a href="#">Buy now</a> |
| 32  | <a href="#">663-44575-00</a><br>Damper, lower mount rubber<br>EXCEPT FOR TUNA | <a href="#">Buy now</a> |


# Bracket 2



| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 33  | <a href="#">6E5-44511-00-5B</a><br>Cover, upper mount             | <a href="#">Buy now</a> |
| 33  | <a href="#">6E5-44511-60-5B</a><br>Cover, upper mount<br>FOR TUNA | <a href="#">Buy now</a> |

A5

## Bracket 3




FWD  
6E50200-0160

A7

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-43170-00-4D</a><br>Shock Absorber assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-43128-00-8D</a><br>Spacer, clamp bracket   | <a href="#">Buy now</a> |
| 3   | <a href="#">90109-06M07</a><br>Bolt (6e5)                  | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5-43124-00</a><br>Pin, lower shock mount     | <a href="#">Buy now</a> |
| 5   | <a href="#">90386-18M44</a><br>Bushing (6g5)               | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-43613-00</a><br>Arm, tilt lock             | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-43614-00</a><br>Plate, tilt lock 1         | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-43615-00</a><br>Plate, Tilt Lock           | <a href="#">Buy now</a> |
| 9   | <a href="#">90240-06M07</a><br>Pin, Clevis                 | <a href="#">Buy now</a> |
| 10  | <a href="#">92990-06600</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 11  | <a href="#">91490-25012</a><br>Pin, cotter                 | <a href="#">Buy now</a> |
| 12  | <a href="#">90506-23M10</a><br>Spring, Tension             | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-43659-00</a><br>Shaft, Reverse Lock        | <a href="#">Buy now</a> |
| 14  | <a href="#">92995-08600</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5-43679-00</a><br>Stopper, Hook              | <a href="#">Buy now</a> |

## Bracket 3




FWD  
6E50200-0160

A7


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 17  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-43630-01</a><br>Tilt Lever assembly      | <a href="#">Buy now</a> |
| 19  | <a href="#">90386-08032</a><br>Bushing (650)             | <a href="#">Buy now</a> |
| 20  | <a href="#">90202-08M08</a><br>Washer, Plate             | <a href="#">Buy now</a> |
| 22  | <a href="#">61U-43631-00</a><br>Lever, Tilt              | <a href="#">Buy now</a> |
| 23  | <a href="#">90254-03003</a><br>Pin, spring               | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-43317-00</a><br>Grip                     | <a href="#">Buy now</a> |
| 25  | <a href="#">90152-05M00</a><br>Screw, Countersunk        | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-43616-00</a><br>Rod, tilt lock           | <a href="#">Buy now</a> |
| 27  | <a href="#">90506-09M09</a><br>Spring, Tension           | <a href="#">Buy now</a> |
| 28  | <a href="#">688-43184-00</a><br>Collar, anchor lever     | <a href="#">Buy now</a> |
| 29  | <a href="#">91490-30025</a><br>Pin cotter                | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5-43676-00</a><br>Hook                     | <a href="#">Buy now</a> |

## Bracket 4




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">64E-43111-02-8D</a><br>Bracket, clamp        | <a href="#">Buy now</a> |
| 2   | <a href="#">6G5-45251-02</a><br>Anode                    | <a href="#">Buy now</a> |
| 3   | <a href="#">6G5-44526-00</a><br>Plate                    | <a href="#">Buy now</a> |
| 4   | <a href="#">97095-06030</a><br>Bolt(jf7)                 | <a href="#">Buy now</a> |
| 5   | <a href="#">92995-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-82148-00</a><br>Wire, lead 5             | <a href="#">Buy now</a> |
| 7   | <a href="#">97095-06010</a><br>Bolt                      | <a href="#">Buy now</a> |
| 8   | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 9   | <a href="#">64E-43112-02-8D</a><br>Bracket, clamp        | <a href="#">Buy now</a> |
| 11  | <a href="#">97880-06012</a><br>Screw, pan head(62j)      | <a href="#">Buy now</a> |
| 12  | <a href="#">92990-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 13  | <a href="#">93700-06M03</a><br>Nipple, grease(6a1)       | <a href="#">Buy now</a> |
| 14  | <a href="#">663-45119-00</a><br>Cap, grease nipple<br>AP | <a href="#">Buy now</a> |
| 15  | <a href="#">64E-43131-01</a><br>Bolt, clamp bracket      | <a href="#">Buy now</a> |
| 16  | <a href="#">97095-08020</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |

## Bracket 4




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 17  | <a href="#">92995-08100</a><br>Ybs67-8 washer, spring   | <a href="#">Buy now</a> |
| 18  | <a href="#">90386-25M31</a><br>Bushing (6e5)            | <a href="#">Buy now</a> |
| 19  | <a href="#">90201-26M59</a><br>Washer, plate (6e5)      | <a href="#">Buy now</a> |
| 20  | <a href="#">90185-22M11</a><br>Nut, self-locking        | <a href="#">Buy now</a> |
| 21  | <a href="#">90465-11M10</a><br>Clamp                    | <a href="#">Buy now</a> |
| 22  | <a href="#">64E-43311-10-8D</a><br>Bracket, swivel<br>L | <a href="#">Buy now</a> |
| 22  | <a href="#">64E-43311-20-8D</a><br>Bracket, swivel<br>X | <a href="#">Buy now</a> |
| 23  | <a href="#">90465-08M63</a><br>Clamp(61u)               | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-82147-00</a><br>Wire, lead 5<br>L       | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-82147-20</a><br>Wire, lead 5<br>X       | <a href="#">Buy now</a> |
| 27  | <a href="#">6G5-43144-00</a><br>Hook, spring            | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5-43181-02</a><br>Lever, tilt stop 1      | <a href="#">Buy now</a> |
| 30  | <a href="#">6G5-43185-02</a><br>Lever, tilt stop 2      | <a href="#">Buy now</a> |
| 31  | <a href="#">90386-10M16</a><br>Bushing (688)            | <a href="#">Buy now</a> |
| 32  | <a href="#">6G5-43148-00</a><br>Collar, distance        | <a href="#">Buy now</a> |

## Bracket 4




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 33  | <a href="#">90249-06M19</a><br>Pin(6e5)                       | <a href="#">Buy now</a> |
| 34  | <a href="#">90387-10M05</a><br>Collar(6e5)                    | <a href="#">Buy now</a> |
| 35  | <a href="#">91690-30020</a><br>Pin, spring (6h4)              | <a href="#">Buy now</a> |
| 36  | <a href="#">90506-14M24</a><br>Spring, tension(6e5)           | <a href="#">Buy now</a> |
| 37  | <a href="#">64E-43126-00</a><br>Pin, upper shock mount        | <a href="#">Buy now</a> |
| 38  | <a href="#">90386-22M98</a><br>Bush(61u)                      | <a href="#">Buy now</a> |
| 39  | <a href="#">93410-22M11</a><br>Circlip(61u)                   | <a href="#">Buy now</a> |
| 40  | <a href="#">90101-12M03</a><br>Bolt (l:115mm)<br>FOR TUNA     | <a href="#">Buy now</a> |
| 41  | <a href="#">90201-13M01</a><br>Washer, plate(6e5)<br>FOR TUNA | <a href="#">Buy now</a> |
| 42  | <a href="#">90201-12M05</a><br>Washer, plate(663)<br>FOR TUNA | <a href="#">Buy now</a> |
| 43  | <a href="#">95380-12600</a><br>Nut (707)<br>FOR TUNA          | <a href="#">Buy now</a> |

## Bracket 5




| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">64E-43139-02</a><br>Cam, trim sender (with screw)              | <a href="#">Buy now</a> |
| 2   | <a href="#">97780-60525</a><br>Screw, tapping(65j)                         | <a href="#">Buy now</a> |
| 3   | <a href="#">64E-83672-02</a><br>Trim sender                                | <a href="#">Buy now</a> |
| 4   | <a href="#">97885-06016</a><br>Screw, pan head(6b0)                        | <a href="#">Buy now</a> |
| 5   | <a href="#">90465-11M10</a><br>Clamp                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">93210-37MH7</a><br>O-ring(61u)                                 | <a href="#">Buy now</a> |
| 7   | <a href="#">90202-40M47</a><br>Washer, plate(61a)                          | <a href="#">Buy now</a> |
| 8   | <a href="#">61A-43376-00</a><br>Bolt, thrust receiver                      | <a href="#">Buy now</a> |
| 9   | <a href="#">95780-10300</a><br>Nut, nylon (6e5)                            | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-42510-05-8D</a><br>Steering bracket assembly<br>L          | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-42510-25-8D</a><br>Steering bracket assembly<br>X          | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-42510-61-8D</a><br>Steering bracket assembly<br>L-FOR TUNA | <a href="#">Buy now</a> |
| 11  | <a href="#">90201-38M60</a><br>Washer, plate (6e5)<br>FOR TUNA             | <a href="#">Buy now</a> |
| 12  | <a href="#">90386-38M32</a><br>Bush(6e5)                                   | <a href="#">Buy now</a> |
| 12  | <a href="#">90386-38M89</a><br>Bush(6e5)<br>FOR TUNA                       | <a href="#">Buy now</a> |

# Bracket 5




| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 13  | <a href="#">6E5-44551-61-8D</a><br>Housing, Lower Mount Rubber<br>FOR TUNA | <a href="#">Buy now</a> |
| 13  | <a href="#">6G5-44551-01-8D</a><br>Housing, lower mount rubber             | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-42535-60</a><br>Washer, thrust<br>FOR TUNA                 | <a href="#">Buy now</a> |
| 14  | <a href="#">93410-37M04</a><br>Circlip (6e5)                               | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-42546-60</a><br>Nut<br>FOR TUNA                            | <a href="#">Buy now</a> |
| 16  | <a href="#">6E5-44575-00</a><br>Damper, lower mount rubber                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-44555-00-94</a><br>Mount damper, lower side                | <a href="#">Buy now</a> |
| 18  | <a href="#">90202-32M19</a><br>Washer, plate (6e5)                         | <a href="#">Buy now</a> |
| 19  | <a href="#">90201-16M55</a><br>Washer, plate (6e5)                         | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5-82149-00</a><br>Wire, lead 3                               | <a href="#">Buy now</a> |
| 21  | <a href="#">90109-14M34</a><br>Bolt(6e5)                                   | <a href="#">Buy now</a> |
| 21  | <a href="#">90109-14M54</a><br>Bolt(6e5)<br>FOR TUNA                       | <a href="#">Buy now</a> |
| 22  | <a href="#">90201-15M58</a><br>Washer, plate (6e5)                         | <a href="#">Buy now</a> |
| 23  | <a href="#">90185-14M00</a><br>Nut, self-locking(61a)<br>FOR TUNA          | <a href="#">Buy now</a> |
| 23  | <a href="#">95380-14800</a><br>Nut, crown (6e5)                            | <a href="#">Buy now</a> |

## Bracket 5



| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 24  | <a href="#">92995-14600</a><br>Washer (6e5)                             | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-44552-01-94</a><br>Housing, lower mount rubber          | <a href="#">Buy now</a> |
| 26  | <a href="#">97095-10045</a><br>Bolt(64d)                                | <a href="#">Buy now</a> |
| 27  | <a href="#">92995-10100</a><br>Ybs67-10 washer, spring                  | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-44553-01-8D</a><br>Cover, lower mount                   | <a href="#">Buy now</a> |
| 29  | <a href="#">90501-16M28</a><br>Spring (6e5)                             | <a href="#">Buy now</a> |
| 31  | <a href="#">90179-06066</a><br>Nut(663)                                 | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5-44514-00-94</a><br>Mount damper, upper side             | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5-44514-60-94</a><br>Mount damper, upper side<br>FOR TUNA | <a href="#">Buy now</a> |
| 33  | <a href="#">90201-26M57</a><br>Washer, plate (6e5)                      | <a href="#">Buy now</a> |
| 34  | <a href="#">90202-26M18</a><br>Washer, plate (6e5)                      | <a href="#">Buy now</a> |
| 34  | <a href="#">92995-14200</a><br>23 -<br>FOR TUNA                         | <a href="#">Buy now</a> |
| 35  | <a href="#">90201-14M56</a><br>Washer, plate (6e5)                      | <a href="#">Buy now</a> |
| 35  | <a href="#">90201-15M00</a><br>Washer, plate(6e5)<br>FOR TUNA           | <a href="#">Buy now</a> |
| 36  | <a href="#">90109-12M37</a><br>Bolt                                     | <a href="#">Buy now</a> |


## Bracket 5



**B4**

| Ref | Part                                                                          |                         |
|-----|-------------------------------------------------------------------------------|-------------------------|
| 36  | <a href="#">90109-14M53</a><br>Bolt(6e5)<br>FOR TUNA                          | <a href="#">Buy now</a> |
| 37  | <a href="#">90185-12M12</a><br>Nut, self-locking(6e5)                         | <a href="#">Buy now</a> |
| 38  | <a href="#">663-44575-00</a><br>Damper, lower mount rubber<br>EXCEPT FOR TUNA | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5-44511-00-5B</a><br>Cover, upper mount                         | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5-44511-60-5B</a><br>Cover, upper mount<br>FOR TUNA             | <a href="#">Buy now</a> |
| 42  | <a href="#">703-82119-00</a><br>Cover, lead wire                              | <a href="#">Buy now</a> |
| 43  | <a href="#">90465-13M18</a><br>Clamp                                          | <a href="#">Buy now</a> |


# Carburetor 1



**C1**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">61U-14301-M1</a><br>Carburetor assembly 1     | <a href="#">Buy now</a> |
| 2   | <a href="#">61U-14302-M1</a><br>Carburetor assembly 2     | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-14384-04</a><br>Gasket, float chamber     | <a href="#">Buy now</a> |
| 4   | <a href="#">61U-14381-00</a><br>Body, float chamber<br>#2 | <a href="#">Buy now</a> |
| 5   | <a href="#">61U-14381-M0</a><br>Body, float chamber<br>#1 | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-14383-01</a><br>Screw, drain              | <a href="#">Buy now</a> |
| 7   | <a href="#">6J8-14959-00</a><br>Gasket, drain screw       | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-14385-02</a><br>Float                     | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-14546-00</a><br>Valve, needle             | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-14159-00</a><br>Clip                      | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-14386-02</a><br>Pin, float                | <a href="#">Buy now</a> |
| 12  | <a href="#">61U-1492F-39</a><br>Jet, air slow             | <a href="#">Buy now</a> |
| 13  | <a href="#">61U-14959-00</a><br>Gasket                    | <a href="#">Buy now</a> |
| 14  | <a href="#">61U-14394-00</a><br>Valve, drain              | <a href="#">Buy now</a> |
| 15  | <a href="#">61A-1492E-87</a><br>Jet, main (#174)          | <a href="#">Buy now</a> |


# Carburetor 1



**C1**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">6E5-14398-01</a><br>Gasket                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-1492A-00</a><br>Nozzle, main           | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-14321-00</a><br>Screw, throttle<br>#2  | <a href="#">Buy now</a> |
| 19  | <a href="#">6J8-14334-00</a><br>Spring, throttle<br>#2 | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5-14328-01</a><br>Plug                   | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-14979-00</a><br>Gasket                 | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-14323-03</a><br>Screw, air adjusting   | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-14223-00</a><br>Spring, air adjusting  | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-14527-01</a><br>Plate                  | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-14959-01</a><br>Gasket                 | <a href="#">Buy now</a> |
| 26  | <a href="#">97880-05008</a><br>Screw, with washer      | <a href="#">Buy now</a> |
| 27  | <a href="#">92900-05100</a><br>Ybs67-5 washer, spring  | <a href="#">Buy now</a> |
| 28  | <a href="#">97880-05016</a><br>Screw, pan head(6b0)    | <a href="#">Buy now</a> |
| 30  | <a href="#">61A-1492H-12</a><br>Jet, slow air (#60)    | <a href="#">Buy now</a> |
| 31  | <a href="#">61A-1492G-54</a><br>Jet, main air (#270)   | <a href="#">Buy now</a> |


# Carburetor 1



**C1**

| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 32  | <a href="#">6E5-14324-00</a><br>Screw, flat head | <a href="#">Buy now</a> |
| 34  | <a href="#">61A-14383-01</a><br>Screw, drain     | <a href="#">Buy now</a> |


## Carburetor 2



**C3**

| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">61U-14301-02</a><br>Carburetor assembly 1 (61U-03) | <a href="#">Buy now</a> |
| 2   | <a href="#">61U-14302-02</a><br>Carburetor assembly 2 (61U-03) | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-14384-04</a><br>Gasket, float chamber          | <a href="#">Buy now</a> |
| 4   | <a href="#">61U-14381-00</a><br>Body, float chamber            | <a href="#">Buy now</a> |
| 5   | <a href="#">97980-05116</a><br>Screw, pan head                 | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-14383-01</a><br>Screw, drain                   | <a href="#">Buy now</a> |
| 7   | <a href="#">6J8-14995-00</a><br>Gasket, drain screw            | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-14385-02</a><br>Float                          | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-14546-00</a><br>Valve, needle                  | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-14159-00</a><br>Clip                           | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-14386-02</a><br>Pin, float                     | <a href="#">Buy now</a> |
| 12  | <a href="#">61U-1492F-39</a><br>Jet, air slow                  | <a href="#">Buy now</a> |
| 13  | <a href="#">61U-14959-00</a><br>Gasket                         | <a href="#">Buy now</a> |
| 14  | <a href="#">61U-14394-00</a><br>Valve, drain                   | <a href="#">Buy now</a> |
| 15  | <a href="#">61A-1492E-87</a><br>Jet, main (#174)               | <a href="#">Buy now</a> |


## Carburetor 2



C3

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">6E5-14398-01</a><br>Gasket                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-1492A-00</a><br>Nozzle, main           | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-14321-00</a><br>Screw, throttle<br>#2  | <a href="#">Buy now</a> |
| 19  | <a href="#">6J8-14334-00</a><br>Spring, throttle<br>#2 | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5-14328-01</a><br>Plug                   | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-14979-00</a><br>Gasket                 | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-14323-03</a><br>Screw, air adjusting   | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-14223-00</a><br>Spring, air adjusting  | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-14527-01</a><br>Plate                  | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-14959-01</a><br>Gasket                 | <a href="#">Buy now</a> |
| 26  | <a href="#">61A-1492H-12</a><br>Jet, slow air (#60)    | <a href="#">Buy now</a> |
| 27  | <a href="#">61A-1492G-54</a><br>Jet, main air (#270)   | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-14324-00</a><br>Screw, flat head       | <a href="#">Buy now</a> |
| 29  | <a href="#">61A-14383-01</a><br>Screw, drain           | <a href="#">Buy now</a> |
| 30  | <a href="#">97980-05108</a><br>Screw, with washer      | <a href="#">Buy now</a> |


## Carburetor 2



**C3**

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 31  | <a href="#">6J8-14959-00</a><br>Gasket, drin screw | <a href="#">Buy now</a> |


# Control



**F3**


| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-48531-00</a><br>Bracket, remote control   | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-48538-00</a><br>Clamp, cable              | <a href="#">Buy now</a> |
| 3   | <a href="#">91690-30012</a><br>Pin, spring                | <a href="#">Buy now</a> |
| 4   | <a href="#">97095-08020</a><br>Bolt, hexagon              | <a href="#">Buy now</a> |
| 5   | <a href="#">92995-08100</a><br>Ybs67-8 washer, spring     | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-41632-02-1S</a><br>Lever, magneto control | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-48344-00</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 8   | <a href="#">92990-06200</a><br>Ybs66-6 washer, plain      | <a href="#">Buy now</a> |
| 9   | <a href="#">90185-06M07</a><br>Nut, self-locking(6e5)     | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-41631-01-1S</a><br>Lever, magneto control | <a href="#">Buy now</a> |
| 11  | <a href="#">90157-06013</a><br>Screw, pan head(697)       | <a href="#">Buy now</a> |
| 12  | <a href="#">90501-16M12</a><br>Spring, compression (688)  | <a href="#">Buy now</a> |
| 13  | <a href="#">95303-06600</a><br>Nut(661)                   | <a href="#">Buy now</a> |
| 14  | <a href="#">688-44194-00</a><br>Cap                       | <a href="#">Buy now</a> |
| 15  | <a href="#">97013-08045</a><br>Bolt                       | <a href="#">Buy now</a> |

# Control




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">90201-08M23</a><br>Washer, plate (6e5)   | <a href="#">Buy now</a> |
| 17  | <a href="#">90386-12089</a><br>Bushing(663)          | <a href="#">Buy now</a> |
| 18  | <a href="#">90387-08M16</a><br>Collar                | <a href="#">Buy now</a> |
| 19  | <a href="#">90386-22M13</a><br>Bushing (688)         | <a href="#">Buy now</a> |
| 20  | <a href="#">90202-12092</a><br>Washer, plate(663)    | <a href="#">Buy now</a> |
| 21  | <a href="#">90201-08M13</a><br>Washer plate (682)    | <a href="#">Buy now</a> |
| 22  | <a href="#">90508-29M12</a><br>Spring (6e5)          | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-41636-01</a><br>Rod, magneto control | <a href="#">Buy now</a> |
| 24  | <a href="#">95380-05600</a><br>Nut, hexagon (663)    | <a href="#">Buy now</a> |
| 25  | <a href="#">662-41237-01</a><br>Joint, link          | <a href="#">Buy now</a> |
| 29  | <a href="#">688-41636-00</a><br>Rod 1                | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5-41213-00</a><br>Cam, accel.          | <a href="#">Buy now</a> |
| 33  | <a href="#">90387-06M29</a><br>Collar (6a0)          | <a href="#">Buy now</a> |
| 34  | <a href="#">90206-10M04</a><br>Washer, wave (676)    | <a href="#">Buy now</a> |
| 35  | <a href="#">97095-06025</a><br>Bolt                  | <a href="#">Buy now</a> |

# Control



| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 36  | <a href="#">6E5-44117-00-1S</a><br>Bracket                      | <a href="#">Buy now</a> |
| 37  | <a href="#">90119-06MA2</a><br>Bolt, with washer                | <a href="#">Buy now</a> |
| 38  | <a href="#">68F-44121-00</a><br>Lever, shift rod                | <a href="#">Buy now</a> |
| 39  | <a href="#">6E5-44122-00</a><br>Bushing, shift rod lever        | <a href="#">Buy now</a> |
| 40  | <a href="#">90202-08M20</a><br>Washer, plate (6e5)              | <a href="#">Buy now</a> |
| 41  | <a href="#">90468-18008</a><br>Clip 620436610000                | <a href="#">Buy now</a> |
| 43  | <a href="#">90386-06M12</a><br>Bushing (688)                    | <a href="#">Buy now</a> |
| 44  | <a href="#">6E5-44118-01-94</a><br>Bracket 2                    | <a href="#">Buy now</a> |
| 45  | <a href="#">97013-08030</a><br>Bolt                             | <a href="#">Buy now</a> |
| 46  | <a href="#">92903-08600</a><br>Washer, plain (663)              | <a href="#">Buy now</a> |
| 47  | <a href="#">93501-04M02</a><br>Ball (697)                       | <a href="#">Buy now</a> |
| 48  | <a href="#">90501-12082</a><br>Spring 6484411600                | <a href="#">Buy now</a> |
| 49  | <a href="#">648-42715-00</a><br>Bushing 2                       | <a href="#">Buy now</a> |
| 50  | <a href="#">93700-06M03</a><br>Nipple, grease(6a1)              | <a href="#">Buy now</a> |
| 51  | <a href="#">61U-44120-01</a><br>Handle Gear Shift assembly<br>L | <a href="#">Buy now</a> |


# Control



**F3**


| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 51  | <a href="#">61U-44120-11</a><br>Handle Gear Shift assembly<br>Y | <a href="#">Buy now</a> |
| 51  | <a href="#">6E5-44120-03</a><br>Handle gear shift assembly<br>L | <a href="#">Buy now</a> |
| 51  | <a href="#">6E5-44120-23</a><br>Handle gear shift assembly<br>X | <a href="#">Buy now</a> |
| 51  | <a href="#">61U-44120-21</a><br>Handle Gear Shift assembly<br>X | <a href="#">Buy now</a> |
| 52  | <a href="#">93210-09165</a><br>O-ring                           | <a href="#">Buy now</a> |
| 53  | <a href="#">90386-16M66</a><br>Bush(6e5)                        | <a href="#">Buy now</a> |
| 54  | <a href="#">90202-16061</a><br>Washer, plate(663)               | <a href="#">Buy now</a> |
| 55  | <a href="#">93410-16006</a><br>Circlip                          | <a href="#">Buy now</a> |

# Crankshaft. Piston



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6N7-11411-01</a><br>Crankshaft                  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-11447-00</a><br>Seal, ring                  | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-15163-00-1S</a><br>Housing, bearing 1       | <a href="#">Buy now</a> |
| 4   | <a href="#">93311-940U3</a><br>Brg,cyl-cal roller 36g (6e5) | <a href="#">Buy now</a> |
| 5   | <a href="#">93102-40M14</a><br>Oil seal(61a)                | <a href="#">Buy now</a> |
| 6   | <a href="#">93211-04001</a><br>O-ring                       | <a href="#">Buy now</a> |
| 7   | <a href="#">90119-06MA2</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 8   | <a href="#">93310-954U1</a><br>Bearing, cylindrical(64c)    | <a href="#">Buy now</a> |
| 9   | <a href="#">93306-208U0</a><br>Brg,r-b 6208 80mm 345g (6e5) | <a href="#">Buy now</a> |
| 10  | <a href="#">93410-40M03</a><br>Circlip(n02)                 | <a href="#">Buy now</a> |
| 11  | <a href="#">6G5-15359-00-94</a><br>Housing, oil seal        | <a href="#">Buy now</a> |
| 12  | <a href="#">93102-35M13</a><br>Oil seal (6e5)               | <a href="#">Buy now</a> |
| 13  | <a href="#">93101-22M15</a><br>Oil seal (6e5)               | <a href="#">Buy now</a> |
| 14  | <a href="#">93210-74M35</a><br>O-ring (6e5)                 | <a href="#">Buy now</a> |
| 16  | <a href="#">6R5-11631-01-93</a><br>Piston (std)             | <a href="#">Buy now</a> |


# Crankshaft. Piston



**B1**

| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6R5-11635-01</a><br>Piston (0.25mm o/s)<br>AP          | <a href="#">Buy now</a> |
| 16  | <a href="#">6R5-11636-01</a><br>Piston (0.50mm o/s)<br>AP          | <a href="#">Buy now</a> |
| 17  | <a href="#">61U-11601-00</a><br>Piston ring set (std)              | <a href="#">Buy now</a> |
| 17  | <a href="#">61U-11601-10</a><br>Piston ring set (0.25mm o/s)<br>AP | <a href="#">Buy now</a> |
| 17  | <a href="#">61U-11601-20</a><br>Piston ring set (0.50mm o/s)<br>AP | <a href="#">Buy now</a> |
| 18  | <a href="#">6R5-11642-01-93</a><br>Piston 2 (std)                  | <a href="#">Buy now</a> |
| 18  | <a href="#">6R5-11645-01</a><br>Piston 2 (0.25mm o/s)<br>AP        | <a href="#">Buy now</a> |
| 18  | <a href="#">6R5-11646-01</a><br>Piston 2 (0.50mm o/s)<br>AP        | <a href="#">Buy now</a> |
| 20  | <a href="#">6K7-11633-00</a><br>Pin, piston                        | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-11634-00</a><br>Clip, piston pin                   | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-11650-01</a><br>Rod, connecting assembly           | <a href="#">Buy now</a> |
| 23  | <a href="#">90109-08022</a><br>Bolt                                | <a href="#">Buy now</a> |
| 24  | <a href="#">93603-21111</a><br>Pin, dowel(663)<br>UN (QTY)120      | <a href="#">Buy now</a> |
| 25  | <a href="#">90201-21M75</a><br>Washer, plate (6f3)                 | <a href="#">Buy now</a> |
| 26  | <a href="#">93310-836U0</a><br>Bearing, cylindrical(61u)           | <a href="#">Buy now</a> |


# Cylinder. Crankcase 1



A6

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 3   | <a href="#">624-11379-00</a><br>Valve, check             | <a href="#">Buy now</a> |
| 4   | <a href="#">663-11518-01</a><br>Lock, bearing            | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-11372-01</a><br>Nipple, hose             | <a href="#">Buy now</a> |
| 6   | <a href="#">90340-14M00</a><br>Plug, straight screw(62y) | <a href="#">Buy now</a> |
| 7   | <a href="#">90430-14115</a><br>Gasket (663)              | <a href="#">Buy now</a> |
| 8   | <a href="#">93608-12063</a><br>Pin, dowel (626)          | <a href="#">Buy now</a> |
| 9   | <a href="#">90105-10M20</a><br>Bolt (6e5)                | <a href="#">Buy now</a> |
| 10  | <a href="#">90119-08M94</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 11  | <a href="#">90116-08M45</a><br>Bolt, stud (6e5)          | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-11325-00</a><br>Anode                    | <a href="#">Buy now</a> |
| 13  | <a href="#">98780-04015</a><br>Screw, flat head(ga5)     | <a href="#">Buy now</a> |
| 14  | <a href="#">6R3-1131M-01</a><br>Cover                    | <a href="#">Buy now</a> |
| 15  | <a href="#">6R3-11397-01</a><br>Gasket                   | <a href="#">Buy now</a> |
| 16  | <a href="#">97013-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 17  | <a href="#">92903-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |


# Cylinder. Crankcase 1



A6


| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 18  | <a href="#">61U-11119-01</a><br>3-                         | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-11119-01</a><br>Hanger, engine             | <a href="#">Buy now</a> |
| 19  | <a href="#">90119-08MA3</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 22  | <a href="#">68F-44533-00</a><br>Damper, upper mount rubber | <a href="#">Buy now</a> |
| 23  | <a href="#">90119-06MA2</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-11381-A2</a><br>Gasket 1                   | <a href="#">Buy now</a> |
| 27  | <a href="#">90465-06M86</a><br>Clamp                       | <a href="#">Buy now</a> |

## Cylinder. Crankcase 2




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-11111-00-1S</a><br>Head, cylinder 1         | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-11181-A1</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 3   | <a href="#">90119-08MA8</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5-11191-01-1S</a><br>Cover, cylinder head 1   | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-11193-A0</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 6   | <a href="#">90119-06MA4</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-12411-30</a><br>Thermostat                  | <a href="#">Buy now</a> |
| 8   | <a href="#">6G5-12413-00-1S</a><br>Cover, thermostat        | <a href="#">Buy now</a> |
| 9   | <a href="#">688-12414-A1</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 10  | <a href="#">90119-06MA6</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-41111-00-1S</a><br>Inner cover, exhaust     | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-41112-A1</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 13  | <a href="#">6N7-41113-00-1S</a><br>Outer cover, exhaust     | <a href="#">Buy now</a> |
| 14  | <a href="#">650-24378-00</a><br>Pipe, joint 2               | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-24312-00</a><br>Pipe 2                      | <a href="#">Buy now</a> |

## Cylinder. Crankcase 2



| Ref | Part                                                                     |                         |
|-----|--------------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">90467-08004</a><br>Clip, pipe 6162435600                     | <a href="#">Buy now</a> |
| 17  | <a href="#">90119-06MA5</a><br>Bolt, with washer                         | <a href="#">Buy now</a> |
| 18  | <a href="#">6G5-12416-00</a><br>Valve, pressure control                  | <a href="#">Buy now</a> |
| 19  | <a href="#">90501-16M11</a><br>Spring, compression (688)                 | <a href="#">Buy now</a> |
| 20  | <a href="#">90480-20M05</a><br>Grommet (688)                             | <a href="#">Buy now</a> |
| 21  | <a href="#">6G5-11382-A1</a><br>Gasket 2                                 | <a href="#">Buy now</a> |
| 22  | <a href="#">6G5-11372-00-1S</a><br>Cover, bypass 2                       | <a href="#">Buy now</a> |
| 23  | <a href="#">90119-06MA2</a><br>Bolt, with washer                         | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-12576-00</a><br>Hose 1                                   | <a href="#">Buy now</a> |
| 25  | <a href="#">90465-13M18</a><br>Clamp                                     | <a href="#">Buy now</a> |
| 26  | <a href="#">94702-00160</a><br>Plug, spark (b8hs-10)                     | <a href="#">Buy now</a> |
| 26  | <a href="#">94702-00247</a><br>Plug, spark (br8hs-10)<br>FOR CHINA,CARIB | <a href="#">Buy now</a> |

# Electrical 1




61U0200-0151

**D7**


| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6N7-85537-00</a><br>Cover                          | <a href="#">Buy now</a> |
| 2   | <a href="#">6N7-85542-01-1S</a><br>Bracket                     | <a href="#">Buy now</a> |
| 3   | <a href="#">6A0-82317-00</a><br>Damper, ignition coil          | <a href="#">Buy now</a> |
| 4   | <a href="#">624-42542-00</a><br>Collar                         | <a href="#">Buy now</a> |
| 5   | <a href="#">90119-06M59</a><br>Bolt, with washer               | <a href="#">Buy now</a> |
| 6   | <a href="#">97095-06012</a><br>Bolt(gh1)                       | <a href="#">Buy now</a> |
| 7   | <a href="#">92995-06600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-85540-00</a><br>C.d.i. unit assembly           | <a href="#">Buy now</a> |
| 9   | <a href="#">97880-06040</a><br>Screw pan head                  | <a href="#">Buy now</a> |
| 10  | <a href="#">92990-06100</a><br>Washer(6a1)                     | <a href="#">Buy now</a> |
| 11  | <a href="#">92990-06600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 12  | <a href="#">90159-06M11</a><br>Screw, with washer(6l2)         | <a href="#">Buy now</a> |
| 13  | <a href="#">6H0-81960-00</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-81961-00</a><br>Cover                          | <a href="#">Buy now</a> |
| 15  | <a href="#">90387-06M77</a><br>Collar                          | <a href="#">Buy now</a> |

# Electrical 1



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">97013-06045</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 17  | <a href="#">92903-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 18  | <a href="#">90201-06M05</a><br>Washer, plate(6e3)  | <a href="#">Buy now</a> |
| 19  | <a href="#">90465-06M86</a><br>Clamp               | <a href="#">Buy now</a> |


## Electrical 2



**E1**

| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G5-82152-00</a><br>Holder, fuse                   | <a href="#">Buy now</a> |
| 2   | <a href="#">6R3-85570-01</a><br>Ignition coil assembly         | <a href="#">Buy now</a> |
| 3   | <a href="#">97095-06020</a><br>Bolt(7u8)                       | <a href="#">Buy now</a> |
| 4   | <a href="#">92995-06600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 5   | <a href="#">663-82370-01</a><br>Plug cap assembly              | <a href="#">Buy now</a> |
| 5   | <a href="#">6G1-82370-21</a><br>Plug cap assembly<br>FOR CARIB | <a href="#">Buy now</a> |
| 6   | <a href="#">61A-81941-00</a><br>Starter relay assembly         | <a href="#">Buy now</a> |
| 7   | <a href="#">689-81952-10</a><br>Holder, starter relay          | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-81948-10</a><br>Bracket                        | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-81948-22</a><br>Bracket                        | <a href="#">Buy now</a> |
| 9   | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess       | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-86110-02</a><br>Solenoid                       | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-86116-01</a><br>Wire, pull                     | <a href="#">Buy now</a> |
| 13  | <a href="#">91609-30010</a><br>Pin, spring (663)               | <a href="#">Buy now</a> |
| 16  | <a href="#">93210-03261</a><br>O-ring (663)                    | <a href="#">Buy now</a> |


## Electrical 2



E1


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 17  | <a href="#">688-82560-10</a><br>Thermo switch assembly   | <a href="#">Buy now</a> |
| 18  | <a href="#">61U-82590-M1</a><br>Wire Harness assembly    | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-82590-04</a><br>Wire Harness assembly    | <a href="#">Buy now</a> |
| 19  | <a href="#">663-82151-00</a><br>Fuse<br>FOR 6E5-82590-04 | <a href="#">Buy now</a> |
| 20  | <a href="#">61U-82105-01</a><br>Wire Harness             | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-82117-01</a><br>Wire, lead               | <a href="#">Buy now</a> |
| 22  | <a href="#">6R3-82519-00</a><br>Wire, earth lead         | <a href="#">Buy now</a> |
| 23  | <a href="#">97095-06012</a><br>Bolt(gh1)                 | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-82531-10</a><br>Wire, lead               | <a href="#">Buy now</a> |
| 28  | <a href="#">662-82519-00</a><br>Wire, earth lead         | <a href="#">Buy now</a> |
| 31  | <a href="#">90465-12M25</a><br>Clamp (6e5)               | <a href="#">Buy now</a> |
| 31  | <a href="#">92995-06200</a><br>Ybs66-6 washer, plain     | <a href="#">Buy now</a> |
| 32  | <a href="#">90465-05M87</a><br>Clamp                     | <a href="#">Buy now</a> |
| 33  | <a href="#">90465-08M89</a><br>Clamp                     | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5-81950-00</a><br>Relay assembly           | <a href="#">Buy now</a> |

# Electrical 2



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 35  | <a href="#">6E5-8195A-00</a><br>Relay assembly       | <a href="#">Buy now</a> |
| 36  | <a href="#">6G5-87149-10</a><br>Connector            | <a href="#">Buy now</a> |
| 37  | <a href="#">6G5-82119-00</a><br>Cover, lead wire     | <a href="#">Buy now</a> |
| 38  | <a href="#">6E5-82116-00</a><br>Wire, minus lead     | <a href="#">Buy now</a> |
| 39  | <a href="#">6N7-83557-00</a><br>Tube<br>I.DIA.) 22MM | <a href="#">Buy now</a> |
| 40  | <a href="#">90465-13M18</a><br>Clamp                 | <a href="#">Buy now</a> |

## Electrical 3




  
61U2200-3170

**E3**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">688-82540-11</a><br>Neutral switch assembly     | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-82554-00</a><br>Stay, neutral switch        | <a href="#">Buy now</a> |
| 3   | <a href="#">663-82555-01</a><br>Plate                       | <a href="#">Buy now</a> |
| 4   | <a href="#">63D-82510-10</a><br>Main switch assembly        | <a href="#">Buy now</a> |
| 5   | <a href="#">676-82577-00</a><br>Cap, key                    | <a href="#">Buy now</a> |
| 6   | <a href="#">97885-06012</a><br>Screw, pan head(62j)         | <a href="#">Buy now</a> |
| 7   | <a href="#">697-8252E-01-4D</a><br>Cover, Main Switch       | <a href="#">Buy now</a> |
| 8   | <a href="#">697-8252F-01-4D</a><br>Cover, main switch 2     | <a href="#">Buy now</a> |
| 9   | <a href="#">97880-06025</a><br>Screw, pan head(6b0)         | <a href="#">Buy now</a> |
| 10  | <a href="#">92990-06100</a><br>Washer(6a1)                  | <a href="#">Buy now</a> |
| 11  | <a href="#">97013-06030</a><br>Bolt                         | <a href="#">Buy now</a> |
| 12  | <a href="#">92903-06100</a><br>Washer(6a1)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">97013-06020</a><br>Bolt(62y)                    | <a href="#">Buy now</a> |
| 15  | <a href="#">69W-82575-00</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 16  | <a href="#">682-82556-00</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |

## Electrical 3




  
61U2200-3170

**E3**


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 17  | <a href="#">689-8257Y-00</a><br>Cap                      | <a href="#">Buy now</a> |
| 18  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 19  | <a href="#">92995-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-24304-10</a><br>Fuel pipe joint comp. 1  | <a href="#">Buy now</a> |
| 2   | <a href="#">97095-06028</a><br>Bolt (6g0)                | <a href="#">Buy now</a> |
| 3   | <a href="#">61U-24313-00</a><br>Pipe 3                   | <a href="#">Buy now</a> |
| 4   | <a href="#">90465-11M10</a><br>Clamp                     | <a href="#">Buy now</a> |
| 6   | <a href="#">61A-24560-04</a><br>Filter assembly          | <a href="#">Buy now</a> |
| 7   | <a href="#">61A-24521-00</a><br>Cup, filter              | <a href="#">Buy now</a> |
| 8   | <a href="#">65L-24531-01</a><br>Nut                      | <a href="#">Buy now</a> |
| 9   | <a href="#">61A-24564-00</a><br>O-ring                   | <a href="#">Buy now</a> |
| 10  | <a href="#">61A-24577-01</a><br>Spring                   | <a href="#">Buy now</a> |
| 11  | <a href="#">61A-24563-00</a><br>Element, filter          | <a href="#">Buy now</a> |
| 12  | <a href="#">61A-24469-00</a><br>Float, water level       | <a href="#">Buy now</a> |
| 13  | <a href="#">65L-24558-00</a><br>Holder, filter           | <a href="#">Buy now</a> |
| 14  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 15  | <a href="#">92995-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 16  | <a href="#">90201-06068</a><br>Washer,plate (6k8)        | <a href="#">Buy now</a> |

# Fuel 1



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 17  | <a href="#">61U-24566-01</a><br>Bracket, filter    | <a href="#">Buy now</a> |
| 18  | <a href="#">97095-06014</a><br>Bolt(gj3)           | <a href="#">Buy now</a> |
| 19  | <a href="#">92995-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 22  | <a href="#">61U-24314-00</a><br>Pipe 4             | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-24410-03</a><br>Fuel pump assembly | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-24444-00</a><br>Screw              | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-24413-00</a><br>Body 2             | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5-24471-00</a><br>Diaphragm          | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-24435-00</a><br>Gasket, body 2     | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5-24411-00</a><br>Diaphragm          | <a href="#">Buy now</a> |
| 30  | <a href="#">648-24424-00</a><br>Seat,spring        | <a href="#">Buy now</a> |
| 31  | <a href="#">6E5-24423-00</a><br>Spring, diaphragm  | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5-24434-02</a><br>Gasket, body       | <a href="#">Buy now</a> |
| 33  | <a href="#">6A0-24421-01</a><br>Valve, check       | <a href="#">Buy now</a> |
| 34  | <a href="#">6A0-14325-00</a><br>Screw, pan head    | <a href="#">Buy now</a> |


# Fuel 1



| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 35  | <a href="#">95380-03600</a><br>Nut (6g8)         | <a href="#">Buy now</a> |
| 36  | <a href="#">6E5-24412-10</a><br>Body 1           | <a href="#">Buy now</a> |
| 37  | <a href="#">650-24431-A0</a><br>Gasket,fuel pump | <a href="#">Buy now</a> |
| 38  | <a href="#">97095-06050</a><br>Bolt(jf7)         | <a href="#">Buy now</a> |
| 40  | <a href="#">6G5-24316-10</a><br>Pipe 6           | <a href="#">Buy now</a> |
| 43  | <a href="#">6E5-24376-10</a><br>Pipe, joint 1    | <a href="#">Buy now</a> |
| 44  | <a href="#">6G5-24318-10</a><br>Hose (l90)       | <a href="#">Buy now</a> |
| 45  | <a href="#">6G5-24319-10</a><br>Pipe 9           | <a href="#">Buy now</a> |
| 48  | <a href="#">90446-15M07</a><br>Hose(6g4)         | <a href="#">Buy now</a> |
| 49  | <a href="#">656-W2810-02</a><br>Tool kit         | <a href="#">Buy now</a> |

C5


## Fuel 2



**C7**


| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 1   | <a href="#">61U-24316-00</a><br>Pipe 6             | <a href="#">Buy now</a> |
| 2   | <a href="#">90465-11M10</a><br>Clamp               | <a href="#">Buy now</a> |
| 3   | <a href="#">90445-13M11</a><br>Pipe, fuel 1        | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-24378-00</a><br>Pipe, joint 3      | <a href="#">Buy now</a> |
| 6   | <a href="#">61U-24410-00</a><br>Fuel pump assembly | <a href="#">Buy now</a> |
| 7   | <a href="#">61U-24411-00</a><br>Diaphragm          | <a href="#">Buy now</a> |
| 8   | <a href="#">61U-24421-00</a><br>Valve, Check       | <a href="#">Buy now</a> |
| 9   | <a href="#">61U-24423-00</a><br>Spring, Diaphragm  | <a href="#">Buy now</a> |
| 10  | <a href="#">61U-24454-00</a><br>Spring             | <a href="#">Buy now</a> |
| 11  | <a href="#">61U-24486-00</a><br>O-Ring             | <a href="#">Buy now</a> |
| 12  | <a href="#">61U-24461-00</a><br>Pipe, Joint        | <a href="#">Buy now</a> |
| 13  | <a href="#">61U-24478-00</a><br>Joint              | <a href="#">Buy now</a> |
| 14  | <a href="#">61U-24479-00</a><br>O-Ring             | <a href="#">Buy now</a> |
| 15  | <a href="#">61U-24489-00</a><br>O-Ring             | <a href="#">Buy now</a> |
| 16  | <a href="#">97880-06016</a><br>Screw pan head      | <a href="#">Buy now</a> |

## Fuel 2



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 17  | <a href="#">61U-24424-00</a><br>Seat, Spring         | <a href="#">Buy now</a> |
| 18  | <a href="#">92990-06100</a><br>Washer(6a1)           | <a href="#">Buy now</a> |
| 19  | <a href="#">61U-24491-10</a><br>Bracket, Fuel Pump   | <a href="#">Buy now</a> |
| 20  | <a href="#">97095-06020</a><br>Bolt(7u8)             | <a href="#">Buy now</a> |
| 21  | <a href="#">92995-06600</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 22  | <a href="#">61U-24315-00</a><br>Pipe 5               | <a href="#">Buy now</a> |
| 24  | <a href="#">90465-08M46</a><br>Clamp(61u)            | <a href="#">Buy now</a> |
| 25  | <a href="#">97095-06012</a><br>Bolt(gh1)             | <a href="#">Buy now</a> |
| 27  | <a href="#">90445-07MA3</a><br>Hose (l200)           | <a href="#">Buy now</a> |
| 28  | <a href="#">90445-07M32</a><br>Hose (l200)           | <a href="#">Buy now</a> |
| 29  | <a href="#">90468-07M02</a><br>Clip (6e5)            | <a href="#">Buy now</a> |
| 30  | <a href="#">61U-24317-00</a><br>Pipe 7               | <a href="#">Buy now</a> |
| 33  | <a href="#">61A-24500-00</a><br>Fuel cock assembly 1 | <a href="#">Buy now</a> |
| 34  | <a href="#">90445-13M02</a><br>Hose (l90)            | <a href="#">Buy now</a> |
| 36  | <a href="#">61U-24496-00</a><br>Knob                 | <a href="#">Buy now</a> |


## Fuel 2



**C7**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 37  | <a href="#">95380-05600</a><br>Nut, hexagon (663)        | <a href="#">Buy now</a> |
| 38  | <a href="#">90386-05M54</a><br>Bushing (6g8)             | <a href="#">Buy now</a> |
| 39  | <a href="#">90501-07M81</a><br>Spring, compression(61u)  | <a href="#">Buy now</a> |
| 40  | <a href="#">90201-05M06</a><br>Washer, plate(61u)        | <a href="#">Buy now</a> |
| 41  | <a href="#">90468-05M03</a><br>Clip(6j8)                 | <a href="#">Buy now</a> |
| 42  | <a href="#">61U-24494-00</a><br>Wire, pull               | <a href="#">Buy now</a> |
| 43  | <a href="#">97095-05010</a><br>Bolt (682)                | <a href="#">Buy now</a> |
| 44  | <a href="#">92995-05600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 46  | <a href="#">92995-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 48  | <a href="#">61U-42744-00</a><br>Stay                     | <a href="#">Buy now</a> |
| 49  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |

## Fuel 3




61U0200-0120

**D2**


| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y2-24306-53</a><br>Fuel pipe comp. 1<br><b>AP FOR TUNA</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-24305-04</a><br>Fuel pipe joint comp. 2                 | <a href="#">Buy now</a> |
| 3   | <a href="#">93210-08287</a><br>O-ring (655)                             | <a href="#">Buy now</a> |
| 4   | <a href="#">6Y2-24305-04</a><br>Fuel pipe joint comp. 2                 | <a href="#">Buy now</a> |
| 6   | <a href="#">90445-13M01</a><br>Hose (I2050)                             | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-24351-51</a><br>Band 1                                  | <a href="#">Buy now</a> |
| 8   | <a href="#">90445-13M00</a><br>Hose (I850)                              | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y2-24360-52</a><br>Primer pump assembly                    | <a href="#">Buy now</a> |

# Fuel Tank



| Ref | Part                                                                     |                         |
|-----|--------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YJ-24201-00</a><br>Fuel tank comp.<br>AP                    | <a href="#">Buy now</a> |
| 1   | <a href="#">6YJ-24201-10</a><br>Fuel Tank assembly (24L)<br>AP FOR CHINA | <a href="#">Buy now</a> |
| 2   | <a href="#">6YJ-24610-01</a><br>Cap assembly                             | <a href="#">Buy now</a> |
| 3   | <a href="#">6Y1-24260-12</a><br>Fuel meter assembly<br>FOR CHINA         | <a href="#">Buy now</a> |
| 3   | <a href="#">6YJ-24260-00</a><br>Fuel meter assembly                      | <a href="#">Buy now</a> |
| 4   | <a href="#">98586-05016</a><br>Screw, pan head                           | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y1-24329-00</a><br>Seal                                     | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y1-24268-00</a><br>Gasket, fuel meter                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6YJ-24167-00</a><br>Strainer                                 | <a href="#">Buy now</a> |
| 8   | <a href="#">6Y2-24306-07</a><br>Fuel Pipe Comp. 1<br>AP                  | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-24305-04</a><br>Fuel pipe joint comp. 2                  | <a href="#">Buy now</a> |
| 10  | <a href="#">93210-08287</a><br>O-ring (655)                              | <a href="#">Buy now</a> |
| 11  | <a href="#">6Y2-24305-04</a><br>Fuel pipe joint comp. 2                  | <a href="#">Buy now</a> |
| 13  | <a href="#">90445-13M01</a><br>Hose (I2050)                              | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-24351-50</a><br>Band 1                                   | <a href="#">Buy now</a> |


# Fuel Tank



**D5**


| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 15  | <a href="#">90445-13M00</a><br>Hose (l850)           | <a href="#">Buy now</a> |
| 16  | <a href="#">6Y2-24360-02</a><br>Primer pump assembly | <a href="#">Buy now</a> |

# Generator



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-85550-00</a><br>Rotor assembly           | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-85510-01</a><br>Stator assembly          | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-85580-00</a><br>Coil, pulser             | <a href="#">Buy now</a> |
| 4   | <a href="#">90280-05015</a><br>Key, woodruff             | <a href="#">Buy now</a> |
| 5   | <a href="#">90201-21M18</a><br>Washer, plate (663)       | <a href="#">Buy now</a> |
| 6   | <a href="#">90170-20137</a><br>Nut, hexagon(663)         | <a href="#">Buy now</a> |
| 7   | <a href="#">97013-06060</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 8   | <a href="#">92903-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 9   | <a href="#">688-41611-00</a><br>Retainer, magneto base 1 | <a href="#">Buy now</a> |
| 10  | <a href="#">688-41612-00</a><br>Retainer, magneto base 2 | <a href="#">Buy now</a> |
| 11  | <a href="#">97880-06018</a><br>Screw, pan head(6e5)      | <a href="#">Buy now</a> |
| 12  | <a href="#">90464-12M00</a><br>Clamp                     | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-81332-00</a><br>Plate, timing            | <a href="#">Buy now</a> |
| 14  | <a href="#">97885-06010</a><br>Screw pan head            | <a href="#">Buy now</a> |
| 15  | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |


# Generator



**D6**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">6E5-81337-01</a><br>Cover, flywheel       | <a href="#">Buy now</a> |
| 17  | <a href="#">6G5-82317-00</a><br>Damper                | <a href="#">Buy now</a> |
| 18  | <a href="#">6A0-82317-00</a><br>Damper, ignition coil | <a href="#">Buy now</a> |
| 19  | <a href="#">624-42542-00</a><br>Collar                | <a href="#">Buy now</a> |
| 20  | <a href="#">90119-06M65</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-14488-00</a><br>Label, caution        | <a href="#">Buy now</a> |


# Intake 1



**B4**


| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-13610-00</a><br>Reed valve assembly  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-W0004-00</a><br>Reed set             | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-13621-A1</a><br>Gasket, valve seat   | <a href="#">Buy now</a> |
| 4   | <a href="#">97880-05025</a><br>Screw, panhead (a93)  | <a href="#">Buy now</a> |
| 5   | <a href="#">92990-05600</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-13641-03-1S</a><br>Manifold 1        | <a href="#">Buy now</a> |
| 7   | <a href="#">624-14485-00</a><br>Pipe, joint          | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-11370-01</a><br>Check valve assembly | <a href="#">Buy now</a> |
| 9   | <a href="#">90445-07M28</a><br>Hose (I200)           | <a href="#">Buy now</a> |
| 10  | <a href="#">90445-07M24</a><br>Hose (I390)           | <a href="#">Buy now</a> |
| 11  | <a href="#">90445-07M25</a><br>Hose (I200)           | <a href="#">Buy now</a> |
| 12  | <a href="#">90445-07M23</a><br>Hose (I570)           | <a href="#">Buy now</a> |
| 13  | <a href="#">6E0-24378-00</a><br>Pipe, joint          | <a href="#">Buy now</a> |
| 14  | <a href="#">90468-07M02</a><br>Clip (6e5)            | <a href="#">Buy now</a> |
| 15  | <a href="#">90445-07M46</a><br>Hose (I390)           | <a href="#">Buy now</a> |

# Intake 1



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">90445-07M59</a><br>Hose (l770)         | <a href="#">Buy now</a> |
| 17  | <a href="#">90445-07M27</a><br>Hose (l390)         | <a href="#">Buy now</a> |
| 20  | <a href="#">90116-06M30</a><br>Bolt, stud(6e5)     | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-13645-A1</a><br>Gasket, manifold 1 | <a href="#">Buy now</a> |
| 22  | <a href="#">90119-06MA3</a><br>Bolt, with washer   | <a href="#">Buy now</a> |
| 23  | <a href="#">97013-06045</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 24  | <a href="#">92903-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 25  | <a href="#">90465-06M86</a><br>Clamp               | <a href="#">Buy now</a> |
| 26  | <a href="#">97095-06012</a><br>Bolt(gh1)           | <a href="#">Buy now</a> |
| 27  | <a href="#">92995-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-14198-A2</a><br>Gasket             | <a href="#">Buy now</a> |
| 29  | <a href="#">90179-06M28</a><br>Nut(63v)            | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5-41217-01</a><br>Rod, accel. lever  | <a href="#">Buy now</a> |
| 31  | <a href="#">6G1-42748-00</a><br>Grommet            | <a href="#">Buy now</a> |
| 32  | <a href="#">61U-14417-00-94</a><br>Cover 1         | <a href="#">Buy now</a> |


# Intake 1



**B4**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 34  | <a href="#">6E5-14485-00</a><br>Pipe, joint           | <a href="#">Buy now</a> |
| 36  | <a href="#">647-14395-60</a><br>Cap, over flow pipe   | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-14483-A1</a><br>Gasket                | <a href="#">Buy now</a> |
| 38  | <a href="#">97013-06020</a><br>Bolt(62y)              | <a href="#">Buy now</a> |
| 40  | <a href="#">6E5-14418-00</a><br>Cover 2               | <a href="#">Buy now</a> |
| 41  | <a href="#">6E5-1441K-00</a><br>Emblem 1              | <a href="#">Buy now</a> |
| 42  | <a href="#">6E5-14416-A1</a><br>Gasket, air cleaner   | <a href="#">Buy now</a> |
| 43  | <a href="#">90119-06M31</a><br>Bolt, with washer(680) | <a href="#">Buy now</a> |

## Intake 2




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-13610-00</a><br>Reed valve assembly  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-W0004-00</a><br>Reed set             | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-13621-A1</a><br>Gasket, valve seat   | <a href="#">Buy now</a> |
| 4   | <a href="#">97880-05025</a><br>Screw, panhead (a93)  | <a href="#">Buy now</a> |
| 5   | <a href="#">92990-05600</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-13641-03-1S</a><br>Manifold 1        | <a href="#">Buy now</a> |
| 7   | <a href="#">624-14485-00</a><br>Pipe, joint          | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-11370-01</a><br>Check valve assembly | <a href="#">Buy now</a> |
| 9   | <a href="#">90445-07M28</a><br>Hose (I200)           | <a href="#">Buy now</a> |
| 10  | <a href="#">90445-07M24</a><br>Hose (I390)           | <a href="#">Buy now</a> |
| 11  | <a href="#">90445-07M46</a><br>Hose (I390)           | <a href="#">Buy now</a> |
| 12  | <a href="#">90116-06M30</a><br>Bolt, stud(6e5)       | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-13645-A1</a><br>Gasket, manifold 1   | <a href="#">Buy now</a> |
| 14  | <a href="#">90119-06MA3</a><br>Bolt, with washer     | <a href="#">Buy now</a> |
| 15  | <a href="#">90465-06M86</a><br>Clamp                 | <a href="#">Buy now</a> |

## Intake 2



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">97095-06012</a><br>Bolt(gh1)           | <a href="#">Buy now</a> |
| 17  | <a href="#">92995-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-14198-A2</a><br>Gasket             | <a href="#">Buy now</a> |
| 19  | <a href="#">90179-06M28</a><br>Nut(63v)            | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5-41217-01</a><br>Rod, accel. lever  | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-41256-01</a><br>Rod, choke 1       | <a href="#">Buy now</a> |
| 22  | <a href="#">661-41262-02</a><br>Joint, choke lever | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-41271-02</a><br>Knob, choke        | <a href="#">Buy now</a> |
| 24  | <a href="#">689-41273-00</a><br>Grommet            | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-14417-10-94</a><br>Cover 1         | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5-14485-00</a><br>Pipe, joint        | <a href="#">Buy now</a> |
| 28  | <a href="#">90445-07M23</a><br>Hose (I570)         | <a href="#">Buy now</a> |
| 29  | <a href="#">647-14395-60</a><br>Cap,over flow pipe | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5-14483-A1</a><br>Gasket             | <a href="#">Buy now</a> |
| 31  | <a href="#">97013-06020</a><br>Bolt(62y)           | <a href="#">Buy now</a> |


## Intake 2



**B6**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 32  | <a href="#">92903-06600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 33  | <a href="#">6E5-14418-00</a><br>Cover 2               | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5-1441K-00</a><br>Emblem 1              | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5-14416-A1</a><br>Gasket, air cleaner   | <a href="#">Buy now</a> |
| 36  | <a href="#">90119-06M31</a><br>Bolt, with washer(680) | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



C6


| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">61U-45300-13-8D</a><br>Lower unit assembly<br>L  | <a href="#">Buy now</a> |
| 1   | <a href="#">61U-45300-23-8D</a><br>Lower Unit assembly<br>X  | <a href="#">Buy now</a> |
| 1   | <a href="#">61U-45300-33-8D</a><br>Lower Unit assembly<br>Y  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-45301-05-8D</a><br>Casing, lower             | <a href="#">Buy now</a> |
| 3   | <a href="#">93315-628U9</a><br>Brg,cyl-cal roller (6e5)      | <a href="#">Buy now</a> |
| 4   | <a href="#">93332-000U7</a><br>Brg,tapered roller 76mm (6e5) | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-10</a><br>Shim (t:0.10mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-12</a><br>Shim (t:0.12mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-15</a><br>Shim (t:0.15mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-18</a><br>Shim (t:0.18mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-30</a><br>Shim (t:0.30mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-40</a><br>Shim (t:0.40mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-45567-01-50</a><br>Shim (t:0.50mm)<br>UR     | <a href="#">Buy now</a> |
| 6   | <a href="#">90340-08002</a><br>Plug, straight screw          | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45341-10</a><br>Plug, drain                  | <a href="#">Buy now</a> |

## Lower Casing. Drive 1



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 8   | <a href="#">90430-08020</a><br>Gasket                    | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-45536-00</a><br>Sleeve, drive shaft      | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-45378-00</a><br>Nipple, hose             | <a href="#">Buy now</a> |
| 11  | <a href="#">90445-07ME8</a><br>Hose (I250)<br>L          | <a href="#">Buy now</a> |
| 11  | <a href="#">90445-07ME9</a><br>Hose (I250)<br>X/Y        | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-83558-00</a><br>End, nipple<br>FOR TUNA  | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-83558-10</a><br>End, nipple              | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-45321-00</a><br>Plate                    | <a href="#">Buy now</a> |
| 14  | <a href="#">93210-58144</a><br>O-ring(47x)               | <a href="#">Buy now</a> |
| 15  | <a href="#">93106-09014</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 16  | <a href="#">90119-06M10</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-44150-02</a><br>Shift cam assembly       | <a href="#">Buy now</a> |
| 18  | <a href="#">99001-08600</a><br>Circlip(2r6)              | <a href="#">Buy now</a> |
| 19  | <a href="#">90501-11M10</a><br>Spring, compression (663) | <a href="#">Buy now</a> |
| 20  | <a href="#">61A-45538-00</a><br>Spacer, 1                | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



C6

| Ref | Part                                                                          |                         |
|-----|-------------------------------------------------------------------------------|-------------------------|
| 21  | <a href="#">90201-22M01</a><br>Washer, plate(61a)                             | <a href="#">Buy now</a> |
| 22  | <a href="#">90206-22M19</a><br>Washer, wave(61a)                              | <a href="#">Buy now</a> |
| 23  | <a href="#">61A-45527-00</a><br>Collar, drive shaft                           | <a href="#">Buy now</a> |
| 24  | <a href="#">61A-44311-01</a><br>Housing, water pump                           | <a href="#">Buy now</a> |
| 25  | <a href="#">6R3-44322-42</a><br>Insert, cartridge<br><b>FOR CHROMATE</b>      | <a href="#">Buy now</a> |
| 26  | <a href="#">93210-86M38</a><br>O-ring (6e5)                                   | <a href="#">Buy now</a> |
| 27  | <a href="#">93210-37160</a><br>O-ring (6g8)                                   | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-44352-01</a><br>Impeller                                      | <a href="#">Buy now</a> |
| 29  | <a href="#">90280-04M05</a><br>Key, woodruff (6e5)                            | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5-44323-40</a><br>Outer plate, cartridge<br><b>FOR CHROMATE</b> | <a href="#">Buy now</a> |
| 31  | <a href="#">6E5-44315-A0</a><br>Gasket, water pump                            | <a href="#">Buy now</a> |
| 32  | <a href="#">93606-12019</a><br>Pin, dowel (614)                               | <a href="#">Buy now</a> |
| 33  | <a href="#">90119-08M14</a><br>Bolt, with washer                              | <a href="#">Buy now</a> |
| 34  | <a href="#">6E5-45331-00-94</a><br>Housing, bearing                           | <a href="#">Buy now</a> |
| 35  | <a href="#">93101-28M16</a><br>Oil seal (6e5)                                 | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



C6


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 36  | <a href="#">93317-330U2</a><br>Bearing, cylindrical(6k0) | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-10</a><br>Shim (t:0.10mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-12</a><br>Shim (t:0.12mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-15</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-18</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-30</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-40</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">6E5-45587-01-50</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 38  | <a href="#">93341-930V2</a><br>Bearing, thrust(64d)      | <a href="#">Buy now</a> |
| 39  | <a href="#">93210-55M14</a><br>O-ring (70e)              | <a href="#">Buy now</a> |
| 40  | <a href="#">6E5-45344-00</a><br>Cover, oil seal          | <a href="#">Buy now</a> |
| 41  | <a href="#">97095-08025</a><br>Bolt (62g)                | <a href="#">Buy now</a> |
| 42  | <a href="#">92995-08600</a><br>Washer, plain (663)       | <a href="#">Buy now</a> |
| 43  | <a href="#">6E5-45501-01</a><br>Drive shaft comp.<br>L   | <a href="#">Buy now</a> |
| 43  | <a href="#">6E5-45501-11</a><br>Drive shaft comp.<br>Y   | <a href="#">Buy now</a> |

## Lower Casing. Drive 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 43  | <a href="#">6E5-45501-21</a><br>Drive shaft comp.<br>X  | <a href="#">Buy now</a> |
| 44  | <a href="#">6E5-45551-02</a><br>Pinion                  | <a href="#">Buy now</a> |
| 45  | <a href="#">90170-16M01</a><br>Nut, hexagon (688)       | <a href="#">Buy now</a> |
| 46  | <a href="#">6E5-45560-01</a><br>Gear 1 assembly         | <a href="#">Buy now</a> |
| 47  | <a href="#">93315-425U7</a><br>Brg,cyl-cal roller (6e5) | <a href="#">Buy now</a> |
| 48  | <a href="#">6E5-45611-01</a><br>Shaft, propeller        | <a href="#">Buy now</a> |
| 49  | <a href="#">6E5-45641-02</a><br>Shifter                 | <a href="#">Buy now</a> |
| 50  | <a href="#">6E5-45634-01</a><br>Slide, shift            | <a href="#">Buy now</a> |
| 51  | <a href="#">90501-16M37</a><br>Spring (6g5)             | <a href="#">Buy now</a> |
| 52  | <a href="#">93507-32009</a><br>Ball (12r)               | <a href="#">Buy now</a> |
| 53  | <a href="#">93511-32017</a><br>Ball (498)               | <a href="#">Buy now</a> |
| 54  | <a href="#">93503-16003</a><br>Ball                     | <a href="#">Buy now</a> |
| 55  | <a href="#">90250-08M07</a><br>Pin, straight (6g5)      | <a href="#">Buy now</a> |
| 56  | <a href="#">6E5-45631-01</a><br>Clutch, dog             | <a href="#">Buy now</a> |
| 57  | <a href="#">6E5-45633-01</a><br>Ring, cross pin         | <a href="#">Buy now</a> |

## Lower Casing. Drive 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 58  | <a href="#">6E5-45332-00-94</a><br>Housing, bearing         | <a href="#">Buy now</a> |
| 59  | <a href="#">93306-208U0</a><br>Brg,r-b 6208 80mm 345g (6e5) | <a href="#">Buy now</a> |
| 60  | <a href="#">6E5-45571-01</a><br>Gear 2                      | <a href="#">Buy now</a> |
| 61  | <a href="#">6E5-45576-00</a><br>Washer, thrust 2            | <a href="#">Buy now</a> |
| 62  | <a href="#">93315-430U8</a><br>Bearing                      | <a href="#">Buy now</a> |
| 63  | <a href="#">93101-30M17</a><br>Oil seal (6e5)               | <a href="#">Buy now</a> |
| 64  | <a href="#">93210-86M39</a><br>O-ring (6e5)                 | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-10</a><br>Shim (t:0.10mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-12</a><br>Shim (t:0.12mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-15</a><br>Shim (t:0.15mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-18</a><br>Shim (t:0.18mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-30</a><br>Shim (t:0.30mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-40</a><br>Shim (t:0.40mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">6L6-45577-00-50</a><br>Shim (t:0.50mm)<br>UR    | <a href="#">Buy now</a> |
| 66  | <a href="#">90201-30M92</a><br>Washer (6g5)                 | <a href="#">Buy now</a> |

# Lower Casing. Drive 1




| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 67  | <a href="#">90282-04010</a><br>Key, strait(663) | <a href="#">Buy now</a> |
| 68  | <a href="#">688-45383-02</a><br>Washer, claw    | <a href="#">Buy now</a> |
| 69  | <a href="#">688-45384-00</a><br>Nut             | <a href="#">Buy now</a> |

## Lower Casing. Drive 2




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-44366-00</a><br>Damper, water seal 2          | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-44361-00</a><br>Tube, water<br>L              | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-44361-10</a><br>Tube, water<br>Y              | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-44361-20</a><br>Tube, water<br>X              | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-44365-00</a><br>Damper, water seal 1          | <a href="#">Buy now</a> |
| 4   | <a href="#">93608-12M05</a><br>Pin, dowel b (6e5)<br>L/X      | <a href="#">Buy now</a> |
| 5   | <a href="#">97075-10045</a><br>Bolt(64d)<br>L/X               | <a href="#">Buy now</a> |
| 6   | <a href="#">92995-10100</a><br>Ybs67-10 washer, spring<br>L/X | <a href="#">Buy now</a> |
| 7   | <a href="#">90119-10M89</a><br>Bolt, with washer<br>L/X       | <a href="#">Buy now</a> |
| 8   | <a href="#">663-45376-00-94</a><br>Guide, seal damper         | <a href="#">Buy now</a> |
| 9   | <a href="#">688-45375-00</a><br>Damper, seal 2                | <a href="#">Buy now</a> |
| 10  | <a href="#">688-45214-02</a><br>Cover, water inlet            | <a href="#">Buy now</a> |
| 11  | <a href="#">688-45215-02</a><br>Cover, water inlet            | <a href="#">Buy now</a> |
| 12  | <a href="#">90152-05M07</a><br>Screw, countersunk             | <a href="#">Buy now</a> |
| 13  | <a href="#">90185-05002</a><br>Nut nylon (sus)(ex4)           | <a href="#">Buy now</a> |

## Lower Casing. Drive 2



| Ref | Part                                                                     |                         |
|-----|--------------------------------------------------------------------------|-------------------------|
| 14  | <a href="#">6E5-45371-01</a><br>Trim tab                                 | <a href="#">Buy now</a> |
| 15  | <a href="#">90105-10M00</a><br>Bolt, hexagon (663)                       | <a href="#">Buy now</a> |
| 16  | <a href="#">90445-07MF0</a><br>Hose (I1160)<br>EXCEPT FOR TUNA           | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-83558-00</a><br>End, nipple<br>EXCEPT FOR TUNA           | <a href="#">Buy now</a> |
| 18  | <a href="#">90465-11M10</a><br>Clamp<br>FOR TUNA                         | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5-44312-00</a><br>Cover, water pump housing                | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-45987-01</a><br>Spacer 1                                 | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45997-01</a><br>Spacer 2                                 | <a href="#">Buy now</a> |
| 23  | <a href="#">92990-18200</a><br>Washer (6e5)                              | <a href="#">Buy now</a> |
| 24  | <a href="#">90171-18M04</a><br>Nut, castle (6e5)                         | <a href="#">Buy now</a> |
| 25  | <a href="#">91490-40030</a><br>Pin, cotter (663)                         | <a href="#">Buy now</a> |
| 26  | <a href="#">688-45930-02-98</a><br>Propeller (3x13x17)<br>UR             | <a href="#">Buy now</a> |
| 26  | <a href="#">688-45941-00-EL</a><br>Propeller assembly(3X13"X19"-K)<br>UR | <a href="#">Buy now</a> |
| 26  | <a href="#">688-45970-03-98</a><br>Propeller (3x13"x19"-k)<br>UR         | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-45943-00-EL</a><br>Propeller (3x12-5/8"x21"-k)<br>UR     | <a href="#">Buy now</a> |

## Lower Casing. Drive 2




  
64W0171-0230

**D3**

| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 26  | <a href="#">6E5-45945-01-EL</a><br>Propeller (3x13-1/4x17-k)<br>UR | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-45947-00-EL</a><br>Propeller (3x13-1/2x15-k)<br>UR | <a href="#">Buy now</a> |

# Meter




6E50200-0280

**E4**

| Ref | Part                                                                      |                         |
|-----|---------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y5-83540-14</a><br>Tachometer assembly<br>AP EXCEPT FOR TUNA | <a href="#">Buy now</a> |
| 2   | <a href="#">6Y5-83517-00</a><br>Bulb (12v-1.7w)                           | <a href="#">Buy now</a> |
| 3   | <a href="#">6Y5-83536-10</a><br>Socket, meter                             | <a href="#">Buy now</a> |
| 4   | <a href="#">6Y5-83523-00</a><br>Damper                                    | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y5-83514-00</a><br>Plate, fitting                            | <a href="#">Buy now</a> |
| 6   | <a href="#">95380-05600</a><br>Nut, hexagon (663)                         | <a href="#">Buy now</a> |
| 7   | <a href="#">92990-05100</a><br>Ybs67-5 washer, spring                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6Y5-83670-12</a><br>Trim meter assembly.<br>AP                | <a href="#">Buy now</a> |
| 9   | <a href="#">6Y5-83518-00</a><br>Bulb (12v-1.7w) t6.5                      | <a href="#">Buy now</a> |
| 10  | <a href="#">6Y5-83536-00</a><br>Socket, meter                             | <a href="#">Buy now</a> |
| 11  | <a href="#">6Y5-83544-00</a><br>Plate, fitting                            | <a href="#">Buy now</a> |
| 12  | <a href="#">688-83664-00</a><br>Damper                                    | <a href="#">Buy now</a> |
| 13  | <a href="#">6Y5-83553-00</a><br>Wire, lead (l=2.5m)<br>AP                 | <a href="#">Buy now</a> |
| 14  | <a href="#">1E6-82151-00</a><br>Fuse (10a)                                | <a href="#">Buy now</a> |
| 15  | <a href="#">6Y5-82117-00</a><br>Wire, lead<br>AP EXCEPT FOR TUNA          | <a href="#">Buy now</a> |

## Meter




6E50200-0280

**E4**


| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6R3-82553-70</a><br>Extension, wire lead (for trim<br>AP 4P,7M | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy 1




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">64E-43800-02-4D</a><br>Power trim & tilt assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">64E-43825-01</a><br>Housing Trim & Tilt           | <a href="#">Buy now</a> |
| 3   | <a href="#">64E-4388J-00</a><br>Plug 2                        | <a href="#">Buy now</a> |
| 4   | <a href="#">93210-10M74</a><br>O-ring                         | <a href="#">Buy now</a> |
| 5   | <a href="#">64E-43817-00</a><br>Filter 2                      | <a href="#">Buy now</a> |
| 6   | <a href="#">64E-43810-00</a><br>Tilt piston sub assembly      | <a href="#">Buy now</a> |
| 7   | <a href="#">64E-43898-00</a><br>Seal, dust 2                  | <a href="#">Buy now</a> |
| 8   | <a href="#">64E-43867-00</a><br>O-ring 7                      | <a href="#">Buy now</a> |
| 9   | <a href="#">64E-43866-00</a><br>O-ring 6                      | <a href="#">Buy now</a> |
| 10  | <a href="#">6E5-43862-00</a><br>O-ring 2                      | <a href="#">Buy now</a> |
| 11  | <a href="#">64E-43883-00</a><br>O-ring 10                     | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-43872-00</a><br>Ring, back-up 2               | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-43814-02</a><br>Piston, free                  | <a href="#">Buy now</a> |
| 15  | <a href="#">64E-43820-00</a><br>Trim piston sub assembly      | <a href="#">Buy now</a> |
| 16  | <a href="#">64E-43821-00</a><br>Screw, trim cylinder end      | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy 1




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 17  | <a href="#">64E-43822-00</a><br>Seal, trim dust      | <a href="#">Buy now</a> |
| 18  | <a href="#">64E-4384J-00</a><br>Seal, trim down      | <a href="#">Buy now</a> |
| 19  | <a href="#">6G5-43864-00</a><br>O-ring 4             | <a href="#">Buy now</a> |
| 20  | <a href="#">6E5-43864-00</a><br>O-ring 4             | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-43874-01</a><br>Ring, back-up 4      | <a href="#">Buy now</a> |
| 22  | <a href="#">64E-43828-00</a><br>Body, reservoir      | <a href="#">Buy now</a> |
| 23  | <a href="#">64E-43829-00</a><br>Plug, reservoir      | <a href="#">Buy now</a> |
| 24  | <a href="#">64E-43897-00</a><br>O-ring               | <a href="#">Buy now</a> |
| 25  | <a href="#">64E-4388E-00</a><br>Bolt ,screw (l:14mm) | <a href="#">Buy now</a> |
| 26  | <a href="#">64E-43869-00</a><br>O-ring 9             | <a href="#">Buy now</a> |
| 27  | <a href="#">64E-4381G-00</a><br>Pin 1                | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5-43858-00</a><br>Ball 1               | <a href="#">Buy now</a> |
| 29  | <a href="#">64E-4382G-00</a><br>Valve seat           | <a href="#">Buy now</a> |
| 30  | <a href="#">90201-08M14</a><br>Washer, plate         | <a href="#">Buy now</a> |
| 31  | <a href="#">97080-08016</a><br>Bolt                  | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 32  | <a href="#">64E-43818-01</a><br>Lower shock mount pin set | <a href="#">Buy now</a> |
| 33  | <a href="#">90386-22M98</a><br>Bush(61u)                  | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy 2




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">64E-4388E-10</a><br>Bolt ,screw (l:34.7mm) | <a href="#">Buy now</a> |
| 2   | <a href="#">64E-43831-00</a><br>Connector, shaft       | <a href="#">Buy now</a> |
| 3   | <a href="#">64E-43868-00</a><br>O-ring 8               | <a href="#">Buy now</a> |
| 4   | <a href="#">64E-43830-00</a><br>Gear pump assembly     | <a href="#">Buy now</a> |
| 5   | <a href="#">72X-43858-00</a><br>Ball                   | <a href="#">Buy now</a> |
| 6   | <a href="#">64E-43843-00</a><br>Screw, valve lock      | <a href="#">Buy now</a> |
| 7   | <a href="#">64E-43841-00</a><br>Piston, shuttle        | <a href="#">Buy now</a> |
| 8   | <a href="#">64E-43802-00</a><br>Valve sub assembly     | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-43896-00</a><br>O-ring                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6G5-43863-00</a><br>O-ring 3               | <a href="#">Buy now</a> |
| 11  | <a href="#">64E-43851-00</a><br>Seat, Relief Valve     | <a href="#">Buy now</a> |
| 12  | <a href="#">64E-43858-00</a><br>Ball                   | <a href="#">Buy now</a> |
| 13  | <a href="#">64E-43859-00</a><br>Pin, Valve Support     | <a href="#">Buy now</a> |
| 14  | <a href="#">64E-43855-00</a><br>Spring, up relief      | <a href="#">Buy now</a> |
| 15  | <a href="#">64E-43850-00</a><br>Valve sub assembly     | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy 2



| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 16  | <a href="#">64E-43865-00</a><br>O-ring 10                 | <a href="#">Buy now</a> |
| 17  | <a href="#">64E-43816-00</a><br>Filter 1                  | <a href="#">Buy now</a> |
| 19  | <a href="#">64E-43817-10</a><br>Filter 2                  | <a href="#">Buy now</a> |
| 20  | <a href="#">64E-43860-00</a><br>Manual valve sub-assembly | <a href="#">Buy now</a> |
| 21  | <a href="#">72X-85075-L0</a><br>O-ring (nsd161)           | <a href="#">Buy now</a> |
| 22  | <a href="#">64E-43827-00</a><br>Ring set                  | <a href="#">Buy now</a> |
| 23  | <a href="#">64E-4387A-00</a><br>O-ring                    | <a href="#">Buy now</a> |
| 24  | <a href="#">64E-43873-00</a><br>Ring, back up             | <a href="#">Buy now</a> |
| 25  | <a href="#">64E-43875-00</a><br>Ring, snap                | <a href="#">Buy now</a> |
| 26  | <a href="#">64E-43879-10</a><br>Screw, with washer        | <a href="#">Buy now</a> |
| 27  | <a href="#">64E-43879-00</a><br>Screw, with washer        | <a href="#">Buy now</a> |
| 28  | <a href="#">64E-43880-01</a><br>Motor assembly            | <a href="#">Buy now</a> |
| 29  | <a href="#">6H1-4386K-10</a><br>Spring, brush             | <a href="#">Buy now</a> |
| 30  | <a href="#">64E-4380J-00</a><br>Holder Brush              | <a href="#">Buy now</a> |
| 31  | <a href="#">64E-43891-00</a><br>Brush 1                   | <a href="#">Buy now</a> |


## Power Trim & Tilt Assy 2



**C2**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 32  | <a href="#">97607-04310</a><br>Screw, pan head(6g8)     | <a href="#">Buy now</a> |
| 33  | <a href="#">64E-4380F-00</a><br>Holder, brush 2         | <a href="#">Buy now</a> |
| 34  | <a href="#">64E-43892-00</a><br>Breaker comp. (brush 2) | <a href="#">Buy now</a> |
| 35  | <a href="#">6G5-43865-00</a><br>O-ring                  | <a href="#">Buy now</a> |
| 36  | <a href="#">93102-08M43</a><br>Oil seal(6b0)            | <a href="#">Buy now</a> |
| 37  | <a href="#">64E-43805-00</a><br>Armature assembly       | <a href="#">Buy now</a> |
| 38  | <a href="#">64E-43843-10</a><br>Screw valve lock        | <a href="#">Buy now</a> |


# Remote Control Assy



**E1**

| Ref | Part                                                                                   |                         |
|-----|----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703-48201-16</a><br>Remote control assembly (10p)<br>AP                    | <a href="#">Buy now</a> |
| 1   | <a href="#">703-48205-17</a><br>Remote control assembly (10p, ptt)<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">703-48261-01</a><br>Arm, throttle                                          | <a href="#">Buy now</a> |
| 3   | <a href="#">703-48153-00</a><br>Shaft, free accel.                                     | <a href="#">Buy now</a> |
| 4   | <a href="#">703-48235-00</a><br>Bushing                                                | <a href="#">Buy now</a> |
| 5   | <a href="#">703-48268-00</a><br>Spacer 3                                               | <a href="#">Buy now</a> |
| 6   | <a href="#">703-48264-00</a><br>Throttle, friction                                     | <a href="#">Buy now</a> |
| 7   | <a href="#">95380-05600</a><br>Nut, hexagon (663)                                      | <a href="#">Buy now</a> |
| 8   | <a href="#">97380-05025</a><br>Bolt                                                    | <a href="#">Buy now</a> |
| 9   | <a href="#">703-48265-00</a><br>Shaft Friction                                         | <a href="#">Buy now</a> |
| 10  | <a href="#">93430-06024</a><br>Circlip (701)                                           | <a href="#">Buy now</a> |
| 11  | <a href="#">703-48245-00</a><br>Plate, lock                                            | <a href="#">Buy now</a> |
| 12  | <a href="#">703-48252-00</a><br>Roller, cam                                            | <a href="#">Buy now</a> |
| 13  | <a href="#">701-48248-00</a><br>Roller, free accel                                     | <a href="#">Buy now</a> |
| 14  | <a href="#">703-48198-00</a><br>Washer, wave 3                                         | <a href="#">Buy now</a> |


# Remote Control Assy



**E1**

| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 15  | <a href="#">703-48243-00</a><br>Bushing 3                            | <a href="#">Buy now</a> |
| 16  | <a href="#">703-48236-00</a><br>Bushing                              | <a href="#">Buy now</a> |
| 17  | <a href="#">703-48189-00</a><br>Retainer                             | <a href="#">Buy now</a> |
| 18  | <a href="#">703-48234-00</a><br>Roller, detent                       | <a href="#">Buy now</a> |
| 19  | <a href="#">703-48345-01</a><br>Cable end, remote control 2          | <a href="#">Buy now</a> |
| 20  | <a href="#">703-48358-00</a><br>Anchor, cable                        | <a href="#">Buy now</a> |
| 21  | <a href="#">703-48244-00</a><br>Spring, free accel.                  | <a href="#">Buy now</a> |
| 22  | <a href="#">703-48238-00</a><br>Spring, detent                       | <a href="#">Buy now</a> |
| 23  | <a href="#">703-48246-00</a><br>Spacer 1                             | <a href="#">Buy now</a> |
| 24  | <a href="#">703-48227-00</a><br>Spring, neutral lock                 | <a href="#">Buy now</a> |
| 25  | <a href="#">703-82594-00</a><br>Clamp<br><b>WITH PT/T SW.</b>        | <a href="#">Buy now</a> |
| 26  | <a href="#">703-48226-00</a><br>Plate, stopper                       | <a href="#">Buy now</a> |
| 27  | <a href="#">703-48222-00</a><br>Grip, control lever<br><b>SINGLE</b> | <a href="#">Buy now</a> |
| 28  | <a href="#">703-48223-00</a><br>Lock, neutral                        | <a href="#">Buy now</a> |
| 29  | <a href="#">703-48225-00</a><br>Cover                                | <a href="#">Buy now</a> |


# Remote Control Assy



**E1**

| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 30  | <a href="#">703-48219-00</a><br>Cover, lead                      | <a href="#">Buy now</a> |
| 31  | <a href="#">703-48281-00</a><br>Screw, flat head                 | <a href="#">Buy now</a> |
| 32  | <a href="#">703-48282-00</a><br>Screw                            | <a href="#">Buy now</a> |
| 33  | <a href="#">97380-08030</a><br>Bolt, hexagon (fj1)               | <a href="#">Buy now</a> |
| 34  | <a href="#">92990-08600</a><br>Washer, plain (663)               | <a href="#">Buy now</a> |
| 35  | <a href="#">98580-04010</a><br>Screw, pan head (e56)             | <a href="#">Buy now</a> |
| 36  | <a href="#">98580-04006</a><br>Screw, pan head (7h3)             | <a href="#">Buy now</a> |
| 37  | <a href="#">98580-05010</a><br>Screw, pan head(62x)              | <a href="#">Buy now</a> |
| 38  | <a href="#">98580-03015</a><br>Screw, pan head (n151)            | <a href="#">Buy now</a> |
| 39  | <a href="#">703-48291-10</a><br>Screw                            | <a href="#">Buy now</a> |
| 40  | <a href="#">95380-06600</a><br>Nut(661)                          | <a href="#">Buy now</a> |
| 41  | <a href="#">703-48293-10</a><br>Spacer, remote control<br>SINGLE | <a href="#">Buy now</a> |
| 42  | <a href="#">701-48287-00</a><br>Washer 1                         | <a href="#">Buy now</a> |
| 43  | <a href="#">703-48215-00</a><br>Graphic                          | <a href="#">Buy now</a> |
| 44  | <a href="#">703-82510-43</a><br>Main switch assembly             | <a href="#">Buy now</a> |


# Remote Control Assy



**E1**


| Ref | Part                                                                         |                         |
|-----|------------------------------------------------------------------------------|-------------------------|
| 45  | <a href="#">703-82577-00</a><br>Cap, key                                     | <a href="#">Buy now</a> |
| 46  | <a href="#">703-82531-00</a><br>Wire, lead                                   | <a href="#">Buy now</a> |
| 47  | <a href="#">688-82575-01</a><br>Engine stop switch assembly                  | <a href="#">Buy now</a> |
| 48  | <a href="#">682-82556-00</a><br>Lanyard, stop switch                         | <a href="#">Buy now</a> |
| 49  | <a href="#">688-8258A-20</a><br>10p main harness mec 2m (6ft)<br>LJ5M (10P)  | <a href="#">Buy now</a> |
| 50  | <a href="#">703-82540-00</a><br>Neutral switch assembly                      | <a href="#">Buy now</a> |
| 51  | <a href="#">703-83383-02</a><br>Buzzer                                       | <a href="#">Buy now</a> |
| 52  | <a href="#">703-48284-00</a><br>Grommet                                      | <a href="#">Buy now</a> |
| 53  | <a href="#">703-82591-00</a><br>Band                                         | <a href="#">Buy now</a> |
| 54  | <a href="#">703-82592-00</a><br>Band                                         | <a href="#">Buy now</a> |
| 55  | <a href="#">703-48224-00</a><br>Cover, control lever<br>WITHOUT PT/T SW.     | <a href="#">Buy now</a> |
| 55  | <a href="#">703-82563-02</a><br>Trim & tilt switch assembly<br>WITH PT/T SW. | <a href="#">Buy now</a> |
| 56  | <a href="#">703-48221-00</a><br>Grip                                         | <a href="#">Buy now</a> |
| 57  | <a href="#">703-48152-00</a><br>Knob, free accel                             | <a href="#">Buy now</a> |
| 58  | <a href="#">703-48212-00</a><br>Rear housing                                 | <a href="#">Buy now</a> |

# Remote Control Assy




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 59  | <a href="#">703-48213-00</a><br>Back, panel             | <a href="#">Buy now</a> |
| 60  | <a href="#">703-48271-00</a><br>Arm, shift              | <a href="#">Buy now</a> |
| 61  | <a href="#">703-48211-01</a><br>Housing,1               | <a href="#">Buy now</a> |
| 62  | <a href="#">703-48232-00</a><br>Drive gear              | <a href="#">Buy now</a> |
| 63  | <a href="#">703-82542-00</a><br>Cap<br>FOR 703-48201-16 | <a href="#">Buy now</a> |

# Remote Control Box



| Ref | Part                                                                                   |                         |
|-----|----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703-48201-16</a><br>Remote control assembly (10p)<br>AP                    | <a href="#">Buy now</a> |
| 1   | <a href="#">703-48205-17</a><br>Remote control assembly (10p, ptt)<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-30</a><br>Cable, Remote Control L=14F<br>UR                      | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-40</a><br>Cable, Remote Control L=19F<br>UR                      | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-50</a><br>Cable, Remote Control L=15F<br>UR                      | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-80</a><br>Cable, Remote Control L=17F<br>UR                      | <a href="#">Buy now</a> |


# Repair Kit 1



**E5**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-W0001-A3</a><br>Gasket kit                  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-14416-A1</a><br>Gasket, air cleaner         | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-14483-A1</a><br>Gasket                      | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5-14198-A2</a><br>Gasket                      | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-11381-A2</a><br>Gasket 1                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-11181-A1</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-11193-A0</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 8   | <a href="#">688-12414-A1</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-41112-A1</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 10  | <a href="#">93102-40M14</a><br>Oil seal(61a)                | <a href="#">Buy now</a> |
| 11  | <a href="#">93211-04001</a><br>O-ring                       | <a href="#">Buy now</a> |
| 12  | <a href="#">93102-35M13</a><br>Oil seal (6e5)               | <a href="#">Buy now</a> |
| 13  | <a href="#">93101-22M15</a><br>Oil seal (6e5)               | <a href="#">Buy now</a> |
| 14  | <a href="#">93210-74M35</a><br>O-ring (6e5)                 | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-13621-A1</a><br>Gasket, valve seat          | <a href="#">Buy now</a> |


# Repair Kit 1



**E5**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">6E5-13645-A1</a><br>Gasket, manifold 1    | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-14384-04</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-45113-A0</a><br>Gasket, upper casing  | <a href="#">Buy now</a> |
| 19  | <a href="#">61U-W0093-01</a><br>Carburetor repair kit | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-14546-00</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-14386-02</a><br>Pin, float            | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-14385-02</a><br>Float                 | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-14398-01</a><br>Gasket                | <a href="#">Buy now</a> |
| 27  | <a href="#">97880-05016</a><br>Screw, pan head(6b0)   | <a href="#">Buy now</a> |
| 28  | <a href="#">92990-05100</a><br>Ybs67-5 washer, spring | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5-14323-03</a><br>Screw, air adjusting  | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5-14979-00</a><br>Gasket                | <a href="#">Buy now</a> |
| 31  | <a href="#">6J8-14959-00</a><br>Gasket, drin screw    | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5-14959-01</a><br>Gasket                | <a href="#">Buy now</a> |

## Repair Kit 2




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-W0001-C1</a><br>Gasket kit, lower unit   | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-41134-B0</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-45114-A0</a><br>Gasket, upper casing     | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5-45123-00</a><br>Gasket, muffler          | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-41135-A0</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 6   | <a href="#">6E5-44365-00</a><br>Damper, water seal 1     | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-44366-00</a><br>Damper, water seal 2     | <a href="#">Buy now</a> |
| 8   | <a href="#">90430-08020</a><br>Gasket                    | <a href="#">Buy now</a> |
| 9   | <a href="#">93210-58144</a><br>O-ring(47x)               | <a href="#">Buy now</a> |
| 10  | <a href="#">93106-09014</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 11  | <a href="#">93210-86M38</a><br>O-ring (6e5)              | <a href="#">Buy now</a> |
| 12  | <a href="#">93210-37160</a><br>O-ring (6g8)              | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-44315-A0</a><br>Gasket, water pump       | <a href="#">Buy now</a> |
| 14  | <a href="#">93101-28M16</a><br>Oil seal (6e5)            | <a href="#">Buy now</a> |
| 15  | <a href="#">93210-55M14</a><br>O-ring (70e)              | <a href="#">Buy now</a> |

## Repair Kit 2



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">93210-86M39</a><br>O-ring (6e5)            | <a href="#">Buy now</a> |
| 17  | <a href="#">93101-30M17</a><br>Oil seal (6e5)          | <a href="#">Buy now</a> |
| 18  | <a href="#">61U-W0078-03</a><br>Water pump repair kit  | <a href="#">Buy now</a> |
| 19  | <a href="#">6R3-44322-42</a><br>Insert, cartridge      | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-44352-01</a><br>Impeller               | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-44323-40</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |
| 25  | <a href="#">93606-12019</a><br>Pin, dowel (614)        | <a href="#">Buy now</a> |
| 26  | <a href="#">90119-08M14</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 27  | <a href="#">90280-04M05</a><br>Key, woodruff (6e5)     | <a href="#">Buy now</a> |

# Starter




61U2200-3130

**D3**

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">61U-W1571-00</a><br>Starter assembly    | <a href="#">Buy now</a> |
| 2   | <a href="#">61U-15711-00</a><br>Case, starter       | <a href="#">Buy now</a> |
| 3   | <a href="#">696-15773-00</a><br>Stay 3              | <a href="#">Buy now</a> |
| 4   | <a href="#">663-15739-00</a><br>Washer, thrust 2    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-15713-00</a><br>Spring, starter     | <a href="#">Buy now</a> |
| 6   | <a href="#">61U-15714-00</a><br>Drum, sheave        | <a href="#">Buy now</a> |
| 7   | <a href="#">663-15764-00</a><br>Collar              | <a href="#">Buy now</a> |
| 8   | <a href="#">663-15741-02</a><br>Pawl, drive         | <a href="#">Buy now</a> |
| 9   | <a href="#">663-15754-00</a><br>Bushing             | <a href="#">Buy now</a> |
| 10  | <a href="#">663-15726-01</a><br>Washer, flat 1      | <a href="#">Buy now</a> |
| 11  | <a href="#">663-15744-00</a><br>Circlip             | <a href="#">Buy now</a> |
| 12  | <a href="#">663-15715-00</a><br>Spring, drive plate | <a href="#">Buy now</a> |
| 13  | <a href="#">696-15716-00</a><br>Drive, plate        | <a href="#">Buy now</a> |
| 14  | <a href="#">696-15734-00</a><br>Spring, return      | <a href="#">Buy now</a> |
| 15  | <a href="#">663-15719-00</a><br>Washer, thrust      | <a href="#">Buy now</a> |

# Starter




61U2200-3130

**D3**

| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 16  | <a href="#">92905-06100</a><br>Washer(6a1)       | <a href="#">Buy now</a> |
| 17  | <a href="#">97305-06016</a><br>Bolt              | <a href="#">Buy now</a> |
| 18  | <a href="#">663-15752-00</a><br>Roller, wire     | <a href="#">Buy now</a> |
| 19  | <a href="#">663-15753-00</a><br>Bushing 1        | <a href="#">Buy now</a> |
| 20  | <a href="#">61U-15758-00</a><br>Guide, rope      | <a href="#">Buy now</a> |
| 21  | <a href="#">97305-06012</a><br>Bolt              | <a href="#">Buy now</a> |
| 22  | <a href="#">97305-06025</a><br>Bolt              | <a href="#">Buy now</a> |
| 23  | <a href="#">689-15755-01</a><br>Handle, starter  | <a href="#">Buy now</a> |
| 24  | <a href="#">*</a><br>item_description            | <a href="#">Buy now</a> |
| 25  | <a href="#">6F5-15779-02</a><br>Cover            | <a href="#">Buy now</a> |
| 26  | <a href="#">90119-08M26</a><br>Bolt, with washer | <a href="#">Buy now</a> |
| 27  | <a href="#">90387-08M05</a><br>Collar (663)      | <a href="#">Buy now</a> |
| 28  | <a href="#">90385-12M04</a><br>Bushing (6f5)     | <a href="#">Buy now</a> |
| 29  | <a href="#">697-15787-00-94</a><br>Adaptor       | <a href="#">Buy now</a> |
| 30  | <a href="#">90119-06M95</a><br>Bolt, with washer | <a href="#">Buy now</a> |

# Starter




61U2200-3130

**D3**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 31  | <a href="#">624-42542-00</a><br>Collar                    | <a href="#">Buy now</a> |
| 32  | <a href="#">6A0-82317-00</a><br>Damper, ignition coil     | <a href="#">Buy now</a> |
| 33  | <a href="#">692-15758-01-94</a><br>Guide, Rope            | <a href="#">Buy now</a> |
| 34  | <a href="#">697-15762-00</a><br>Seal 2                    | <a href="#">Buy now</a> |
| 35  | <a href="#">97095-06020</a><br>Bolt(7u8)                  | <a href="#">Buy now</a> |
| 36  | <a href="#">92995-06100</a><br>Washer(6a1)                | <a href="#">Buy now</a> |
| 37  | <a href="#">92995-06600</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |
| 38  | <a href="#">95380-06600</a><br>Nut(661)                   | <a href="#">Buy now</a> |
| 39  | <a href="#">61U-15772-00</a><br>Stay 2                    | <a href="#">Buy now</a> |
| 46  | <a href="#">697-15789-00</a><br>Damper                    | <a href="#">Buy now</a> |
| 47  | <a href="#">61U-15774-00-94</a><br>Stay 4                 | <a href="#">Buy now</a> |
| 48  | <a href="#">61U-15723-01</a><br>Pulley, Starter           | <a href="#">Buy now</a> |
| 49  | <a href="#">97013-08016</a><br>Bolt, hexagon              | <a href="#">Buy now</a> |
| 50  | <a href="#">92903-08100</a><br>Ybs67-8 washer, spring     | <a href="#">Buy now</a> |
| 51  | <a href="#">61U-15770-00</a><br>Cable comp., starter stop | <a href="#">Buy now</a> |

# Starter




61U2200-3130

**D3**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 52  | <a href="#">663-15735-01</a><br>Guide, cam                 | <a href="#">Buy now</a> |
| 53  | <a href="#">90506-08M23</a><br>Spring, tension(6k5)        | <a href="#">Buy now</a> |
| 54  | <a href="#">90508-12015</a><br>Spring torsion 616436420000 | <a href="#">Buy now</a> |
| 55  | <a href="#">90149-05095</a><br>Screw(663)                  | <a href="#">Buy now</a> |
| 56  | <a href="#">663-15794-00</a><br>Stopper                    | <a href="#">Buy now</a> |
| 57  | <a href="#">97095-06010</a><br>Bolt                        | <a href="#">Buy now</a> |
| 59  | <a href="#">92990-06200</a><br>Ybs66-6 washer, plain       | <a href="#">Buy now</a> |
| 60  | <a href="#">91490-16012</a><br>Pin, cotter (e57)           | <a href="#">Buy now</a> |
| 61  | <a href="#">90202-06009</a><br>Washer plate 626427510000   | <a href="#">Buy now</a> |
| 63  | <a href="#">90468-18008</a><br>Clip 620436610000           | <a href="#">Buy now</a> |
| 64  | <a href="#">61U-2415A-00</a><br>Label, Caution             | <a href="#">Buy now</a> |
| 65  | <a href="#">61U-14488-00</a><br>Label, Caution             | <a href="#">Buy now</a> |


# Starting Motor



**E4**

| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6N7-81800-10</a><br>Starting motor assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">6N7-81850-10</a><br>Armature assembly             | <a href="#">Buy now</a> |
| 3   | <a href="#">61A-81809-00</a><br>Washer kit                    | <a href="#">Buy now</a> |
| 4   | <a href="#">61A-81824-00</a><br>Washer 2                      | <a href="#">Buy now</a> |
| 5   | <a href="#">6N7-81810-00</a><br>Stator assembly               | <a href="#">Buy now</a> |
| 6   | <a href="#">6K7-8182G-10</a><br>Bush, terminal                | <a href="#">Buy now</a> |
| 7   | <a href="#">6N7-81840-00</a><br>Brush holder assembly         | <a href="#">Buy now</a> |
| 8   | <a href="#">6N7-81801-00</a><br>Brush set                     | <a href="#">Buy now</a> |
| 9   | <a href="#">6N7-81813-00</a><br>Spring, brush                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6N7-81820-10</a><br>Rear bracket assembly         | <a href="#">Buy now</a> |
| 11  | <a href="#">6N7-81807-00</a><br>Gear assembly, starting motor | <a href="#">Buy now</a> |
| 12  | <a href="#">6N7-81857-00</a><br>Pinion stopper set            | <a href="#">Buy now</a> |
| 13  | <a href="#">6N7-81830-00</a><br>Front bracket assembly        | <a href="#">Buy now</a> |
| 14  | <a href="#">6K7-81826-10</a><br>Bolt                          | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-8182E-10</a><br>Washer, spring                | <a href="#">Buy now</a> |


# Starting Motor



**E4**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6E5-8182F-10</a><br>Washer,plain               | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5-8182A-10</a><br>Nut                        | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-8182K-10</a><br>Nut                        | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5-81822-02-98</a><br>Bracket, starting motor | <a href="#">Buy now</a> |
| 20  | <a href="#">90119-08M76</a><br>Bolt, with washer(6e5)      | <a href="#">Buy now</a> |
| 21  | <a href="#">90119-08M77</a><br>Bolt, with washer(6e5)      | <a href="#">Buy now</a> |
| 22  | <a href="#">90119-08M57</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 23  | <a href="#">92990-08600</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |
| 24  | <a href="#">97095-08016</a><br>Bolt, hexagon deep recess   | <a href="#">Buy now</a> |
| 25  | <a href="#">92995-08600</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |


# Steering



**E7**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 3   | <a href="#">664-42119-00</a><br>Grip, steering handle   | <a href="#">Buy now</a> |
| 4   | <a href="#">6F6-42177-A0</a><br>Rubber, handle          | <a href="#">Buy now</a> |
| 5   | <a href="#">6K5-42137-00</a><br>Indicator, throttle     | <a href="#">Buy now</a> |
| 6   | <a href="#">90269-02M09</a><br>Rivet(6I5)               | <a href="#">Buy now</a> |
| 7   | <a href="#">90149-05M13</a><br>Screw, countersunk       | <a href="#">Buy now</a> |
| 8   | <a href="#">92903-10600</a><br>Washer, plate            | <a href="#">Buy now</a> |
| 9   | <a href="#">90501-23215</a><br>Spring (655)             | <a href="#">Buy now</a> |
| 10  | <a href="#">90386-08032</a><br>Bushing (650)            | <a href="#">Buy now</a> |
| 11  | <a href="#">692-42115-00</a><br>Shaft, steering handle  | <a href="#">Buy now</a> |
| 12  | <a href="#">663-42138-00</a><br>Lever, throttle         | <a href="#">Buy now</a> |
| 13  | <a href="#">90254-03003</a><br>Pin, spring              | <a href="#">Buy now</a> |
| 14  | <a href="#">692-42135-00</a><br>Housing, throttle lever | <a href="#">Buy now</a> |
| 15  | <a href="#">663-42133-01</a><br>Gasket                  | <a href="#">Buy now</a> |
| 17  | <a href="#">93700-06M03</a><br>Nipple, grease(6a1)      | <a href="#">Buy now</a> |
| 18  | <a href="#">97885-06008</a><br>Screw, pan head(6a3)     | <a href="#">Buy now</a> |


# Steering



**E7**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 19  | <a href="#">97885-05012</a><br>Screw,pan head (646)      | <a href="#">Buy now</a> |
| 20  | <a href="#">692-26301-03</a><br>Throttle cable assembly  | <a href="#">Buy now</a> |
| 22  | <a href="#">90101-12M06</a><br>Bolt                      | <a href="#">Buy now</a> |
| 23  | <a href="#">92990-12200</a><br>Ybs66-12 washer,plain     | <a href="#">Buy now</a> |
| 24  | <a href="#">90386-12089</a><br>Bushing(663)              | <a href="#">Buy now</a> |
| 25  | <a href="#">90202-12092</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 26  | <a href="#">90201-12537</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 27  | <a href="#">90206-12054</a><br>Washer, wave(663)         | <a href="#">Buy now</a> |
| 28  | <a href="#">90185-12058</a><br>Nut, nylon(663)           | <a href="#">Buy now</a> |
| 29  | <a href="#">697-44113-00</a><br>Cam plate, handle        | <a href="#">Buy now</a> |
| 30  | <a href="#">6K5-44191-00</a><br>Indicator,shift          | <a href="#">Buy now</a> |
| 31  | <a href="#">97013-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 32  | <a href="#">92903-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 33  | <a href="#">692-44159-01</a><br>Handle, gear shift 2     | <a href="#">Buy now</a> |
| 34  | <a href="#">663-44173-00</a><br>Lever, shift control     | <a href="#">Buy now</a> |


# Steering



**E7**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 35  | <a href="#">90501-16M17</a><br>Spring (697)               | <a href="#">Buy now</a> |
| 36  | <a href="#">93515-32M01</a><br>Ball (697)                 | <a href="#">Buy now</a> |
| 37  | <a href="#">90386-10009</a><br>Bushing 6484418600         | <a href="#">Buy now</a> |
| 38  | <a href="#">90201-10120</a><br>Washer, plate              | <a href="#">Buy now</a> |
| 39  | <a href="#">90185-10051</a><br>Nut, self-locking          | <a href="#">Buy now</a> |
| 40  | <a href="#">90387-12M30</a><br>Collar (697)               | <a href="#">Buy now</a> |
| 41  | <a href="#">90201-12M34</a><br>Washer (692)               | <a href="#">Buy now</a> |
| 42  | <a href="#">6E5-48310-01</a><br>Cable, remote control     | <a href="#">Buy now</a> |
| 43  | <a href="#">95380-05600</a><br>Nut, hexagon (663)         | <a href="#">Buy now</a> |
| 44  | <a href="#">6E5-44124-00</a><br>Link, shift lever         | <a href="#">Buy now</a> |
| 45  | <a href="#">95780-05300</a><br>Nut, nylon (6k8)           | <a href="#">Buy now</a> |
| 46  | <a href="#">92990-06600</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |
| 47  | <a href="#">91490-25012</a><br>Pin, cotter                | <a href="#">Buy now</a> |
| 48  | <a href="#">663-42126-01</a><br>Friction, steering handle | <a href="#">Buy now</a> |
| 49  | <a href="#">90101-06M27</a><br>Bolt                       | <a href="#">Buy now</a> |


# Steering



**E7**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 51  | <a href="#">90175-06003</a><br>Nut, wing (f87)              | <a href="#">Buy now</a> |
| 52  | <a href="#">6E5-42518-01</a><br>Shaft, Friction             | <a href="#">Buy now</a> |
| 53  | <a href="#">663-42528-00</a><br>Piece, friction             | <a href="#">Buy now</a> |
| 54  | <a href="#">97080-06035</a><br>Bolt(j52)                    | <a href="#">Buy now</a> |
| 56  | <a href="#">6E5-42515-00</a><br>Rod, steering link          | <a href="#">Buy now</a> |
| 57  | <a href="#">92995-08600</a><br>Washer, plain (663)          | <a href="#">Buy now</a> |
| 58  | <a href="#">90185-08057</a><br>Nut, nylon (6j8)             | <a href="#">Buy now</a> |
| 59  | <a href="#">90465-06M90</a><br>Clamp                        | <a href="#">Buy now</a> |
| 60  | <a href="#">97885-06012</a><br>Screw, pan head(62j)         | <a href="#">Buy now</a> |
| 61  | <a href="#">697-82575-00</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 62  | <a href="#">682-82556-00</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 63  | <a href="#">689-8257Y-00</a><br>Cap                         | <a href="#">Buy now</a> |

# Steering Guide




67H0100-9290

**D6**

| Ref | Part                                                                          |                         |
|-----|-------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-61350-02</a><br>Steering guide attachment kit<br>AP FOR CHINA | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-61351-01</a><br>Rod, steering link                            | <a href="#">Buy now</a> |
| 3   | <a href="#">90387-10M61</a><br>Collar (6e5)                                   | <a href="#">Buy now</a> |
| 4   | <a href="#">90560-12M01</a><br>Spacer (6e5)                                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6E5-61355-00</a><br>Bolt                                          | <a href="#">Buy now</a> |
| 6   | <a href="#">90185-09M01</a><br>Nut, nylon (663)                               | <a href="#">Buy now</a> |
| 7   | <a href="#">90201-10M20</a><br>Washer, plate (663)                            | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-43145-01</a><br>Cap, clamp bracket                            | <a href="#">Buy now</a> |
| 9   | <a href="#">93210-16275</a><br>O-ring                                         | <a href="#">Buy now</a> |


## Top Cowling 1



**A4**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">61U-42610-L0-4D</a><br>Top Cowling assembly  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-42647-00-94</a><br>Holder, clamp band    | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-42649-01-94</a><br>Holder, clamp band    | <a href="#">Buy now</a> |
| 4   | <a href="#">663-42662-00</a><br>Damper                   | <a href="#">Buy now</a> |
| 5   | <a href="#">90266-06009</a><br>Rivet (697)               | <a href="#">Buy now</a> |
| 6   | <a href="#">90266-06M02</a><br>Rivet (697)               | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-42652-00</a><br>Hook 2                   | <a href="#">Buy now</a> |
| 8   | <a href="#">688-42652-00</a><br>Hook 2                   | <a href="#">Buy now</a> |
| 9   | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 10  | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-42617-00</a><br>Damper 1                 | <a href="#">Buy now</a> |
| 12  | <a href="#">61U-42619-10</a><br>Damper, form             | <a href="#">Buy now</a> |
| 13  | <a href="#">61U-42627-10</a><br>Damper, form             | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-42615-00</a><br>Seal                     | <a href="#">Buy now</a> |
| 15  | <a href="#">6G5-42613-00-4D</a><br>Molding, air duct     | <a href="#">Buy now</a> |


## Top Cowling 1



**A4**

| Ref | Part                                           |                         |
|-----|------------------------------------------------|-------------------------|
| 16  | <a href="#">90179-06M24</a><br>Nut(6j8)        | <a href="#">Buy now</a> |
| 17  | <a href="#">61U-42626-00</a><br>Louver, 1      | <a href="#">Buy now</a> |
| 18  | <a href="#">61U-42636-00</a><br>Louver, 2      | <a href="#">Buy now</a> |
| 19  | <a href="#">90387-06M35</a><br>Collar(61u)     | <a href="#">Buy now</a> |
| 20  | <a href="#">61U-42677-J0</a><br>Graphic, front | <a href="#">Buy now</a> |
| 21  | <a href="#">61U-W0070-H0</a><br>1-             | <a href="#">Buy now</a> |
| 22  | <a href="#">61U-42678-H0</a><br>Graphic, rear  | <a href="#">Buy now</a> |
| 23  | <a href="#">697-15761-01</a><br>Seal 1         | <a href="#">Buy now</a> |
| 24  | <a href="#">677-13437-08</a><br>1-             | <a href="#">Buy now</a> |

## Top Cowling 2




FWD  
61U1200-2020

**A5**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 4   | <a href="#">663-42662-00</a><br>Damper                    | <a href="#">Buy now</a> |
| 5   | <a href="#">90266-06009</a><br>Rivet (697)                | <a href="#">Buy now</a> |
| 6   | <a href="#">90266-06M02</a><br>Rivet (697)                | <a href="#">Buy now</a> |
| 7   | <a href="#">6E5-42652-00</a><br>Hook 2                    | <a href="#">Buy now</a> |
| 8   | <a href="#">688-42652-00</a><br>Hook 2                    | <a href="#">Buy now</a> |
| 9   | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess  | <a href="#">Buy now</a> |
| 10  | <a href="#">92995-06600</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |
| 11  | <a href="#">6E5-42617-00</a><br>Damper 1                  | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-42619-00</a><br>Damper, Form              | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5-42627-00</a><br>Damper, Form              | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-42615-00</a><br>Seal                      | <a href="#">Buy now</a> |
| 18  | <a href="#">61U-42677-J0</a><br>Graphic, front            | <a href="#">Buy now</a> |
| 19  | <a href="#">61U-W0070-H0</a><br>1-                        | <a href="#">Buy now</a> |
| 20  | <a href="#">61U-42678-H0</a><br>Graphic, rear             | <a href="#">Buy now</a> |
| 21  | <a href="#">688-42681-61</a><br>Mark, Cowling<br>FOR TUNA | <a href="#">Buy now</a> |

## Top Cowling 2




61U1200-2020

A5

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 22  | <a href="#">688-42682-61</a><br>Mark, Cowling<br>FOR TUNA | <a href="#">Buy now</a> |
| 23  | <a href="#">677-13437-08</a><br>1-                        | <a href="#">Buy now</a> |


# Upper Casing



**C4**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E5-45111-02-8D</a><br>Casing, upper<br>L/Y | <a href="#">Buy now</a> |
| 1   | <a href="#">6E5-45111-23-8D</a><br>Casing, upper<br>X   | <a href="#">Buy now</a> |
| 2   | <a href="#">6E5-45155-00</a><br>Cap                     | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5-42769-00</a><br>Seal, rubber            | <a href="#">Buy now</a> |
| 4   | <a href="#">97095-06010</a><br>Bolt                     | <a href="#">Buy now</a> |
| 5   | <a href="#">92995-06600</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 36  | <a href="#">93608-12M05</a><br>Pin, dowel b (6e5)<br>Y  | <a href="#">Buy now</a> |
| 7   | <a href="#">90119-08027</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-41137-03-94</a><br>Guide, exhaust       | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-42724-00</a><br>Grommet                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6G5-12581-00</a><br>Joint, hose             | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-45113-A0</a><br>Gasket, upper casing    | <a href="#">Buy now</a> |
| 13  | <a href="#">90119-08M79</a><br>Bolt, hexagon (fj1)      | <a href="#">Buy now</a> |
| 14  | <a href="#">97095-08045</a><br>Bolt, hexagon            | <a href="#">Buy now</a> |
| 15  | <a href="#">92995-08100</a><br>Ybs67-8 washer, spring   | <a href="#">Buy now</a> |

# Upper Casing



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">95380-08700</a><br>Nut(661)                     | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5-41131-01-5B</a><br>Manifold, Ext. 1         | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5-45114-A0</a><br>Gasket, upper casing        | <a href="#">Buy now</a> |
| 20  | <a href="#">97095-08030</a><br>Bolt, hexagon (fj1)          | <a href="#">Buy now</a> |
| 21  | <a href="#">92995-08600</a><br>Washer, plain (663)          | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-41132-00-5B</a><br>Manifold, exhaust        | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-41134-B0</a><br>Gasket,exhaust manifold     | <a href="#">Buy now</a> |
| 26  | <a href="#">6E5-14711-01-5B</a><br>Muffler 1                | <a href="#">Buy now</a> |
| 27  | <a href="#">6E5-14737-00</a><br>Damper, muffler             | <a href="#">Buy now</a> |
| 28  | <a href="#">90183-05M02</a><br>Nut, spring (6e5)            | <a href="#">Buy now</a> |
| 29  | <a href="#">6E5-45123-00</a><br>Gasket, muffler             | <a href="#">Buy now</a> |
| 30  | <a href="#">6E5-41135-A0</a><br>Gasket, exhaust manifold    | <a href="#">Buy now</a> |
| 33  | <a href="#">6E5-45318-00</a><br>Bushing, drive shaft 3<br>X | <a href="#">Buy now</a> |
| 34  | <a href="#">93420-36M01</a><br>Circlip (6a0)<br>X           | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5-45211-00-4D</a><br>Extension<br>Y           | <a href="#">Buy now</a> |

# Upper Casing



**C4**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 37  | <a href="#">90116-10M38</a><br>Bolt, stud (6e5)<br>Y        | <a href="#">Buy now</a> |
| 38  | <a href="#">90101-10M02</a><br>Bolt<br>Y                    | <a href="#">Buy now</a> |
| 39  | <a href="#">92990-10600</a><br>Washer, plate<br>Y           | <a href="#">Buy now</a> |
| 40  | <a href="#">92990-10100</a><br>Ybs67-10 washer, spring<br>Y | <a href="#">Buy now</a> |
| 41  | <a href="#">95380-10600</a><br>Nut(624)<br>Y                | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.