



Yamaha E48CMH 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	11
BRACKET 3	13
BRACKET 4	16
BRACKET 5	19
BRACKET 6	25
CONTROL	26
CYLINDER. CRANKCASE	31
ELECTRICAL 1	36
ELECTRICAL 2	39
ELECTRICAL 3	40
FUEL	42
FUEL TANK	45
GENERATOR 1	47
GENERATOR 2	49
INTAKE	51
LOWER CASING. DRIVE 1	57
LOWER CASING. DRIVE 2	63
LOWER CASING. DRIVE 3	69
METER 1	71
METER 2	72
POWER TRIM & TILT ASSY	73
REMOTE CONTROL ASSY	79
REMOTE CONTROL BOX	84
REPAIR KIT 1	85
REPAIR KIT 2	87
STARTER	89
STARTING MOTOR	94
STEERING	96
STEERING GUIDE	100
TOP COWLING 1	101
TOP COWLING 2	103
UPPER CASING	105

Bottom Cowling



Ref	Part	
1	696-42711-03-4D Cowling, bottom	Buy now
1	697-42711-02-4D Cowling, bottom	Buy now
2	663-24376-00 Pipe, joint 1	Buy now
3	688-42726-10 Grommet	Buy now
3	6H4-42726-00 Grommet	Buy now
4	663-42716-01 Sea 1	Buy now
5	663-42724-00 Grommet	Buy now
6	90480-12004 Grommet(661)	Buy now
7	90338-05M03 Plug (6h1)	Buy now
8	663-42725-01 Grommet	Buy now
8	663-42725-11 Grommet	Buy now
9	663-42738-03-94 Plate, fitting	Buy now
10	97095-06016 Bolt, hexagon deep recess	Buy now
11	92995-06100 Washer(6a1)	Buy now
12	92995-06600 Washer, plain (646)	Buy now


Bottom Cowling



D5

Ref	Part	
13	90480-09M12 Grommet (6a0)	Buy now
14	90387-06M03 Collar (676)	Buy now
15	90201-06416 Washer, plate(663)	Buy now
16	97095-06030 Bolt(jf7)	Buy now
18	90119-06M08 Bolt, with washer	Buy now
19	663-42744-02 Stay	Buy now
20	97095-06014 Bolt(gj3)	Buy now
22	663-42723-01-94 Cover, bottom	Buy now
23	663-42741-01-4D Apron	Buy now
24	663-42771-02-4D Apron	Buy now
25	97095-06020 Bolt(7u8)	Buy now
27	97095-06025 Bolt	Buy now
29	663-82594-03 Clamp	Buy now
30	90465-06M86 Clamp	Buy now
31	6E9-85411-00 Overheat warning lamp	Buy now


Bottom Cowling



D5


Ref	Part	
32	692-85415-00 Mark, Signal Lamp	Buy now
33	90157-06M01 Screw (6e5)	Buy now
34	6E5-24367-10 Clamp, fuel pipe 2	Buy now
35	92990-06600 Washer, plain (646)	Buy now
36	663-42791-00 Mark 1	Buy now
36	664-42791-00 Mark 1	Buy now
36	664-42791-10 Mark 1 FOR CARIB,CHINA	Buy now
36	6G5-42791-00 Mark 1	Buy now
36	6G5-42791-10 Mark 1 FOR CHINA	Buy now
37	6A1-28176-00 Label Caution FOR CARIB	Buy now
38	6E3-8257H-00 Plate Mark FOR CARIB	Buy now

Bracket 1




Ref	Part	
1	688-43111-13-4D Bracket, clamp 1 L	Buy now
1	697-43111-05-4D Bracket, clamp S	Buy now
2	663-45251-00 Anode S	Buy now
2	6H1-45251-03 Anode L	Buy now
3	6H1-44526-00 Plate 2 L	Buy now
4	90119-06M29 Bolt, with washer L	Buy now
5	90152-06M01 Screw, countersunk S	Buy now
6	97095-06016 Bolt, hexagon deep recess L	Buy now
7	92995-06100 Washer(6a1) L	Buy now
8	92995-06600 Washer, plain (646) L	Buy now
9	688-43112-12-4D Bracket, clamp 2 L	Buy now
9	697-43112-03-4D Bracket, clamp S	Buy now
10	6E5-82148-00 Wire, lead 5	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	648-43114-01 Pad, transom clamp	Buy now

Bracket 1




Ref	Part	
13	663-43116-01 Screw, transom	Buy now
14	90243-04007 Pin (663)	Buy now
15	663-43118-01-4D Handle, transom clamp	Buy now
16	97095-10045 Bolt(64d)	Buy now
17	92995-10100 Ybs67-10 washer, spring	Buy now
18	697-43311-03-4D Bracket, swivel S	Buy now
18	6H1-43311-01-4D Bracket, swivel 1 L	Buy now
19	93700-06M03 Nipple, grease(6a1)	Buy now
20	663-45119-00 Cap, grease nipple AP	Buy now
21	688-43131-03 Bolt, clamp bracket	Buy now
22	90386-22M15 Bushing (688)	Buy now
23	90201-22M67 Washer, plate (688)	Buy now
24	90185-22043 Nut, self-locking	Buy now
25	6G5-43145-01 Cap, clamp bracket	Buy now
26	688-43181-04 Lever, tilt stop 1 S	Buy now

Bracket 1




Ref	Part	
26	688-43181-10 Lever, tilt stop 1 L	Buy now
27	688-43185-04 Lever, tilt stop 2 S	Buy now
27	688-43185-10 Lever, tilt stop 2 L	Buy now
28	90386-10M16 Bushing (688)	Buy now
29	6G5-43148-00 Collar, distance L	Buy now
29	92990-10600 Washer, plate S	Buy now
30	90501-10M21 Spring (688) S	Buy now
30	91690-30020 Pin, spring (6h4) L	Buy now
31	90249-06M19 Pin(6e5) L	Buy now
31	90387-10M38 Collar (6e5) S	Buy now
32	90387-10M02 Collar(6e5) L	Buy now
32	91490-30025 Pin cotter S	Buy now
33	663-43318-00 Cover	Buy now
34	688-43160-01 Tilt rod ass'y L	Buy now
34	697-43160-00 Tilt lock ass'y S	Buy now

Bracket 1




Ref	Part	
35	688-43165-00 Stopper, tilt rod	Buy now
36	91690-30012 Pin, spring	Buy now
37	90502-16M02 Spring, conical (688) L	Buy now
37	90502-20M03 Spring (6e5) S	Buy now
38	6E5-43126-02 Pin, upper shock mount	Buy now
39	90386-18M21 Bushing (688)	Buy now
40	90386-18M35 Bush (688)	Buy now
41	93410-18M02 Circlip (6f2)	Buy now
42	90506-14M24 Spring, tension(6e5) L	Buy now
43	6G5-43144-00 Hook, spring L	Buy now
44	97095-06010 Bolt L	Buy now
45	90101-12M51 Bolt	Buy now
46	92995-12200 Ybs66-12 washer,plain	Buy now
47	90201-12426 Wash, plate(663)	Buy now
48	95380-12600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	688-43128-01-4D Spacer, clamp bracket L	Buy now
1	697-43128-01-4D Spacer, clamp bracket S	Buy now
2	688-43170-04-4D Shock absorber sub-assembly L	Buy now
2	697-43170-03-4D Shock absorber sub-assembly S	Buy now
3	688-43631-00 Lever, tilt 1 S	Buy now
3	688-43631-10 Lever, tilt L	Buy now
4	97080-06010 Bolt	Buy now
5	688-43124-02 Pin, lower shock mount	Buy now
6	90386-18M21 Bushing (688) S	Buy now
7	90386-18M63 Bush(6e5) L	Buy now
8	90386-18M35 Bush (688)	Buy now
9	682-43318-01 Cover L	Buy now
10	688-43186-00 Lever L	Buy now
11	91690-30020 Pin, spring (6h4) L	Buy now
12	6J8-41262-00 Joint, choke lever L	Buy now

Bracket 2



Ref	Part	
13	688-43616-00 Rod, tilt lock L	Buy now
14	90202-03M51 Washer, plate(688) L	Buy now
15	688-43651-00 Lever, reverse lock1 L	Buy now


Bracket 3



F2

Ref	Part	
1	6H1-43111-01-4D Bracket, clamp 1	Buy now
2	6H1-45251-03 Anode	Buy now
3	6H1-44526-00 Plate 2	Buy now
4	90119-06M29 Bolt, with washer	Buy now
5	97095-06016 Bolt, hexagon deep recess	Buy now
6	92995-06100 Washer(6a1)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	6H1-82148-00 Wire, lead	Buy now
9	97095-06010 Bolt	Buy now
11	6H1-43112-00-4D Bracket, clamp 2	Buy now
12	6E5-82148-00 Wire, lead 5	Buy now
13	97880-06012 Screw, pan head(62j)	Buy now
14	97095-10045 Bolt(64d)	Buy now
15	92995-10100 Ybs67-10 washer, spring	Buy now
16	6H1-43311-01-4D Bracket, swivel 1	Buy now


Bracket 3



F2

Ref	Part	
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	663-45119-00 Cap, grease nipple AP	Buy now
19	688-43131-03 Bolt, clamp bracket	Buy now
20	90386-22M15 Bushing (688)	Buy now
21	90201-22M67 Washer, plate (688)	Buy now
22	90185-22043 Nut, self-locking	Buy now
23	6G5-43145-01 Cap, clamp bracket	Buy now
24	6H1-43181-01 Lever, tilt stop 1	Buy now
25	6H1-43185-01 Lever, tilt stop 2	Buy now
26	90386-10M16 Bushing (688)	Buy now
27	90387-10M02 Collar(6e5)	Buy now
28	91690-30020 Pin, spring (6h4)	Buy now
29	688-43160-01 Tilt rod ass'y	Buy now
30	688-43165-00 Stopper, tilt rod	Buy now
31	91690-30012 Pin, spring	Buy now

Bracket 3




6970700-0110

F2


Ref	Part	
32	90502-16M02 Spring, conical (688)	Buy now
33	6E5-43126-02 Pin, upper shock mount	Buy now
34	90386-18M63 Bush(6e5)	Buy now
35	90386-18M35 Bush (688)	Buy now
36	93410-18M02 Circlip (6f2)	Buy now
37	90249-06M19 Pin(6e5)	Buy now
38	6G5-43148-00 Collar, distance	Buy now
39	90506-14M24 Spring, tension(6e5)	Buy now
40	6G5-43144-00 Hook, spring	Buy now
42	90101-12M51 Bolt	Buy now
43	92995-12200 Ybs66-12 washer,plain	Buy now
44	90201-12426 Washer, plate(663)	Buy now
45	95380-12600 Nut (707)	Buy now
46	90440-14M00 Pipe(6h4)	Buy now

Bracket 4




Ref	Part	
1	6H1-83672-12 Trim sender	Buy now
2	97885-06016 Screw, pan head(6b0)	Buy now
3	703-82119-00 Cover, lead wire	Buy now
4	6H1-43376-00 Bolt, thrust receiver	Buy now
5	90185-08057 Nut, nylon (6j8)	Buy now
6	663-42510-03-4D Steering bracket assembly S	Buy now
6	663-42510-13-4D Steering bracket assembly L	Buy now
7	90201-30M00 Washer, plate(6h1)	Buy now
8	90386-30M78 Bush(6h0)	Buy now
9	90386-30M77 Bush(6h0)	Buy now
10	93210-29M94 O-ring(6h1)	Buy now
11	90386-30M60 Bush(6j8)	Buy now
12	663-44551-02-4D Housing, lower mount rubber	Buy now
13	93410-28M06 Circlip (688)	Buy now
14	687-44555-00-94 Mount damper, lower side	Buy now

Bracket 4




Ref	Part	
15	90201-12M16 Washer, plate (679)	Buy now
16	90202-25M04 Washer, plate (663)	Buy now
17	90201-13M19 Washer, plate (663)	Buy now
18	90109-12261 Bolt(663)	Buy now
19	663-44575-00 Damper, lower mount rubber	Buy now
20	95380-12800 Nut crown(663)	Buy now
21	687-44552-02-94 Housing, lower mount rubber	Buy now
22	97075-08025 Bolt, hexagon deep recess	Buy now
23	92995-08100 Ybs67-8 washer, spring	Buy now
24	90501-14M08 Spring, compression(64j)	Buy now
25	90179-06066 Nut(663)	Buy now
26	663-44553-01-4D Cover, lower mount	Buy now
28	688-82127-02 Wire, lead 2 L	Buy now
28	697-82127-01 Wire, lead 2 S	Buy now
29	670-44514-00-94 Mount damper, upper side	Buy now

Bracket 4




Ref	Part	
30	90109-08262 Bolt(663)	Buy now
31	90201-15423 Washer, plate(663)	Buy now
32	90202-15065 Washer, plate (663)	Buy now
33	90201-09425 Washer, plate (663)	Buy now
34	90185-08045 Nut, self-locking	Buy now
35	663-44533-00 Damper, upper mount	Buy now
36	663-44511-00-94 Cover, upper mount	Buy now
37	97075-08035 Bolt(70w)	Buy now
39	688-48511-01-4D Hook, steering	Buy now
39	688-48511-51-4D Hook, steering	Buy now
40	90116-10M28 Bolt, stud	Buy now
41	90185-10051 Nut, self-locking	Buy now
42	90465-11M10 Clamp	Buy now

Bracket 5




Ref	Part	
1	696-43111-01-4D Bracket, clamp	Buy now
2	648-43114-01 Pad, transom clamp	Buy now
3	663-43116-01 Screw, transom	Buy now
4	90243-04007 Pin (663)	Buy now
5	663-43118-01-4D Handle, transom clamp	Buy now
6	663-45251-00 Anode	Buy now
7	90152-06M01 Screw, countersunk	Buy now
8	696-43112-00-4D Bracket, clamp	Buy now
13	6E5-82148-00 Wire, lead 5	Buy now
14	97880-06012 Screw, pan head(62j)	Buy now
15	663-43123-00 Bolt, clamp bracket 2	Buy now
16	90387-10M03 Collar(697)	Buy now
17	92990-10600 Washer, plate	Buy now
18	95380-10600 Nut(624)	Buy now
19	696-43311-00-4D Bracket, swivel S	Buy now

Bracket 5




Ref	Part	
19	696-43311-10-4D Bracket, swivel L	Buy now
20	90269-03010 Rivet (663)	Buy now
21	93700-06M03 Nipple, grease(6a1)	Buy now
22	663-45119-00 Cap, grease nipple AP	Buy now
23	91690-40040 Pin, spring (663)	Buy now
24	696-43131-01 Bolt, clamp bracket	Buy now
25	90386-22M15 Bushing (688)	Buy now
26	90201-22M03 Washer, plate(64j)	Buy now
27	90185-22043 Nut, self-locking	Buy now
28	6G5-43145-01 Cap, clamp bracket	Buy now
29	697-43181-02 Lever, tilt stop 1	Buy now
30	697-43185-02 Lever, tilt stop 2	Buy now
31	90386-10045 Bush (663)	Buy now
32	90206-10M08 Washer, wave (688)	Buy now
33	90387-10269 Collar	Buy now

Bracket 5




Ref	Part	
34	91490-30025 Pin cotter	Buy now
35	663-43318-00 Cover	Buy now
36	696-43610-00 Tilt lock ass'y	Buy now
37	696-43611-00 Shaft, tilt lock	Buy now
38	91490-25025 Pin, cotter(615)	Buy now
39	90506-12078 Spring tenssion(663)	Buy now
41	670-43616-01 Rod, tilt lock 1 S	Buy now
41	670-43616-11 Rod, tilt lock 1 L	Buy now
42	95380-08600 Nut (661)	Buy now
43	663-43653-00 Nut, conection	Buy now
44	90240-08M21 Pin, clevis	Buy now
45	91490-20012 Pin, cotter (648)	Buy now
46	676-43160-02 Tilt rod assembly	Buy now
47	676-43165-00 Stopper plate, titl lock rod	Buy now
48	91690-30010 Pin, spring (663)	Buy now

Bracket 5




Ref	Part	
49	90502-10M04 Spring, conical(6f5)	Buy now
50	663-42510-03-4D Steering bracket assembly S	Buy now
50	663-42510-13-4D Steering bracket assembly L	Buy now
51	90201-30M00 Washer, plate(6h1)	Buy now
52	90386-30048 Bush	Buy now
53	93109-30M03 Oil seal (688)	Buy now
54	90201-31418 Washer plate(663)	Buy now
55	663-44551-02-4D Housing, lower mount rubber	Buy now
56	93410-28M06 Circlip (688)	Buy now
57	670-44555-00-94 Mount damper, lower side	Buy now
58	90201-12M16 Washer, plate (679)	Buy now
59	90202-21100 Washer plate (663)	Buy now
60	90201-13421 Washer, plate (679)	Buy now
61	90109-12261 Bolt(663)	Buy now
62	670-44575-00 Damper, lower mount 1	Buy now

Bracket 5




Ref	Part	
63	95380-12800 Nut crown(663)	Buy now
64	663-44552-01-94 Housing, lower mount rubber	Buy now
65	97075-08025 Bolt, hexagon deep recess	Buy now
66	92995-08100 Ybs67-8 washer, spring	Buy now
67	90501-14M08 Spring, compression(64j)	Buy now
68	90179-06066 Nut(663)	Buy now
69	663-44553-01-4D Cover, lower mount	Buy now
70	97885-06016 Screw, pan head(6b0)	Buy now
71	696-82127-00 Wire, lead 2 S	Buy now
71	696-82127-10 Wire, lead 2 L	Buy now
72	670-44514-00-94 Mount damper, upper side	Buy now
73	90109-08262 Bolt(663)	Buy now
74	90201-15423 Washer, plate(663)	Buy now
75	90202-15095 Washer, plate(670)	Buy now
76	90201-09425 Washer, plate (663)	Buy now

Bracket 5



Ref	Part	
77	90185-08045 Nut, self-locking	Buy now
78	663-44533-00 Damper, upper mount	Buy now
79	663-44511-00-94 Cover, upper mount	Buy now
80	97075-08035 Bolt(70w)	Buy now
82	90116-10175 Bolt, stud	Buy now
83	90185-10051 Nut, self-locking	Buy now
84	90101-10M58 Bolt	Buy now
85	92995-10600 Washer, plate	Buy now
86	90201-12426 Washer, plate(663)	Buy now

Bracket 6




6960100-4130

A6

Ref	Part	
1	663-43170-02-4D Shock absorber assembly	Buy now
2	90201-12426 Washer, plate(663)	Buy now
3	90109-12263 Bolt(663)	Buy now
4	663-43125-00 Cover, shock mount	Buy now
5	98780-05015 Ybs53-516 screw,flat head	Buy now
6	663-43126-00 Pin, upper shock mount	Buy now
7	90560-25061 Spacer(663)	Buy now
8	90201-19427 Washer, plate(663)	Buy now
9	90385-19008 Bush(663)	Buy now
10	663-43124-00 Pin, lower shock mount	Buy now
11	90202-19059 Washer, plate(663)	Buy now
12	90385-19007 Bush(663)	Buy now


Control



E2

Ref	Part	
1	663-48531-00 Bracket, remote control	Buy now
2	663-48538-00 Clamp, cable 1	Buy now
3	91690-30012 Pin, spring	Buy now
4	97095-08016 Bolt, hexagon deep recess	Buy now
5	92995-08100 Ybs67-8 washer, spring	Buy now
6	663-48344-00 Cable end, remote control	Buy now
7	663-41632-00-94 Lever, magneto control 2	Buy now
8	663-41282-00 Stopper free, axle link	Buy now
9	90249-05125 Pin (663)	Buy now
10	93607-23110 Pin, dowel(663)	Buy now
11	91690-30018 926-51502-00 pin, spring (700)	Buy now
12	663-41662-00-94 Bracket 2	Buy now
13	90386-10009 Bushing 6484418600	Buy now
14	97095-06018 Bolt (fj0)	Buy now
15	92995-06600 Washer, plain (646)	Buy now


Control



E2


Ref	Part	
16	663-44114-00 Stopper	Buy now
17	90386-06M39 Bushing (697)	Buy now
18	99080-05600 Circlip(22k)	Buy now
19	90501-08232 Spring, compression(663)	Buy now
20	92903-06600 Washer, plain (646)	Buy now
21	663-41633-00-94 Lever, magneto control 3	Buy now
23	663-41635-00 Shaft, link connecting	Buy now
24	90508-20169 Spring, torsion(663)	Buy now
26	663-41631-00-94 Lever, magneto control	Buy now
28	663-41661-00-94 Bracket 1	Buy now
30	91690-40010 Pin, spring	Buy now
33	688-41636-00 Rod 1	Buy now
34	90157-06M11 Screw, pan head(697)	Buy now
34	90157-06M12 Screw, pan head(697)	Buy now
35	688-44194-00 Cap	Buy now

Control




Ref	Part	
36	662-41237-01 Joint, link	Buy now
37	90170-06017 Nut	Buy now
37	95380-06700 Nut	Buy now
40	663-44194-00 Cap	Buy now
41	95380-05600 Nut, hexagon (663)	Buy now
42	663-41211-00 Link, axle	Buy now
42	697-41211-00 Link, accel.	Buy now
43	6H4-41237-00 Joint, link	Buy now
45	663-41213-01-94 Cam, accel.	Buy now
47	90206-10M04 Washer, wave (676)	Buy now
48	90109-06260 Bolt(663)	Buy now
49	663-44117-01 Bracket 1	Buy now
50	90468-18008 Clip 620436610000	Buy now
51	90241-06M00 Pin with head (663)	Buy now
53	90206-06040 Washer, wave (663)	Buy now

Control



Ref	Part	
54	663-44121-01 Lever, shift rod	Buy now
56	91490-16012 Pin, cotter (e57)	Buy now
57	688-44118-00-94 Bracket	Buy now
58	90462-05M02 Clamp (697)	Buy now
59	97013-08030 Bolt	Buy now
60	92903-08100 Ybs67-8 washer, spring	Buy now
61	92903-08600 Washer, plain (663)	Buy now
62	93501-04M02 Ball (697)	Buy now
63	90501-12082 Spring 6484411600	Buy now
64	648-42715-00 Bushing 2	Buy now
65	696-44120-02 Handle gear shift assembly S	Buy now
65	696-44120-12 Handle gear shift assembly L	Buy now
65	697-44120-02 Handle gear shift assembly S	Buy now
65	697-44120-12 Handle gear shift assembly L	Buy now
66	696-44147-00 Boot, shift rod	Buy now


Control



E2

Ref	Part	
67	90386-08006 Bushing (688)	Buy now
68	92990-08200 Ybs66-8 washer, plain	Buy now
71	696-43662-00 Guide, reverse rod	Buy now
71	697-43662-00 Guide, reverse rod	Buy now


Cylinder. Crankcase



A6

Ref	Part	
3	650-11370-01 Check valve assembly	Buy now
4	624-14485-00 Pipe, joint	Buy now
5	93604-08062 Pin,dowel (626)	Buy now
6	663-11518-01 Lock, bearing	Buy now
7	93608-12063 Pin, dowel (626)	Buy now
8	90119-06M12 Bolt, with washer (697)	Buy now
9	90119-10005 Bolt, with washer	Buy now
10	90201-10008 Washer, plate	Buy now
11	95313-10600 Nut(3bm)	Buy now
12	90445-07240 Hose (I390)	Buy now
13	90467-06016 Clip (655)	Buy now
14	90461-04011 Clamp 6208236100	Buy now
16	93104-18049 Oil seal (18x30x5-663)	Buy now
17	93102-28135 Oil seal (28x47x7-663)	Buy now
18	93210-62269 Ring, o(663)	Buy now


Cylinder. Crankcase



A6

Ref	Part	
19	97095-06016 Bolt, hexagon deep recess	Buy now
20	92995-06600 Washer, plain (646)	Buy now
21	90116-10177 Bolt, stud(663)	Buy now
22	663-11325-00 Anode	Buy now
23	98780-04015 Screw, flat head(ga5)	Buy now
24	697-11119-00 Hanger, engine	Buy now
25	90119-08018 Bolt, with washer	Buy now
26	663-11111-02-1S Head, cylinder 1	Buy now
27	697-11181-A1 Gasket, cylinder head 1	Buy now
28	90119-08MA8 Bolt, with washer	Buy now
29	663-11191-00-1S Cover, cylinder head 1	Buy now
30	663-11193-A0 Gasket, head cover	Buy now
31	90119-06MA2 Bolt, with washer	Buy now
32	90430-14115 Gasket (663)	Buy now
33	90340-14036 Plug, (663)	Buy now


Cylinder. Crankcase



A6

Ref	Part	
34	663-12416-00 Valve, pressure control	Buy now
35	90501-14234 Spring, compression(663)	Buy now
36	90480-18065 Grommet(663)	Buy now
37	6F5-12411-02 Thermostat	Buy now
38	663-12413-00-1S Cover, thermostat	Buy now
39	663-12414-A0 Gasket, thermostat	Buy now
40	90119-06MA4 Bolt, with washer	Buy now
41	663-41113-00-1S Outer cover, exhaust	Buy now
42	663-41114-A0 Gasket, exhaust outer cover	Buy now
44	650-24378-00 Pipe, joint 2	Buy now
45	663-24312-01 Pipe 1	Buy now
46	90467-08004 Clip, pipe 6162435600 AP	Buy now
47	663-11411-01 Shaft, crank	Buy now
48	93311-632U1 Brg,needle	Buy now
49	93102-32M07 Oil seal (697)	Buy now


Cylinder. Crankcase



A6


Ref	Part	
50	93210-42159 O-ring (647)	Buy now
51	93311-832U4 Bearing, needle (6f0)	Buy now
52	93306-206U3 Brg,r-b 6206 66mm 236g (696)	Buy now
52	93306-206U4 Brg,r-b 6206 66mm 236g (696)	Buy now
53	663-11561-00 Shim, crank	Buy now
54	688-11631-03-94 Piston (std)	Buy now
54	688-11635-03 Piston (0.25mm o/s) AP	Buy now
54	688-11636-03 Piston (0.50mm o/s) AP	Buy now
55	688-11603-A0 Piston ring set (std)	Buy now
55	688-11604-A0 Piston ring set (0.25mm o/s) AP	Buy now
55	688-11605-A0 Piston ring set (0.50mm o/s) AP	Buy now
56	663-11633-00 Pin, piston	Buy now
57	688-11634-00 Clip, piston pin	Buy now
58	688-11650-03 Connecting rod assembly	Buy now
59	90109-08022 Bolt	Buy now

Cylinder. Crankcase




Ref	Part	
60	93603-21111 Pin, dowel(663)	Buy now
61	93310-730V8 Bearing (688)	Buy now
62	90201-20417 Washer, plate(663)	Buy now
63	94702-00040 Plug, spark (b7hs)	Buy now
63	94702-00041 Plug, spark (b8hs)	Buy now
63	94702-00160 Plug, spark (b8hs-10)	Buy now
63	94702-00247 Plug, spark (br8hs-10) FOR CHINA	Buy now
63	94702-00272 Plug, spark (br7hs) FOR CARIB,CHINA	Buy now

Electrical 1




Ref	Part	
1	663-85542-01-94 Bracket	Buy now
2	6A0-82317-00 Damper, ignition coil	Buy now
3	624-42542-00 Collar	Buy now
4	90119-06M59 Bolt, with washer	Buy now
5	97095-06012 Bolt(gh1)	Buy now
6	92995-06100 Washer(6a1)	Buy now
7	90464-07M10 Clamp (6h3)	Buy now
8	6G5-83557-00 Tube	Buy now
9	697-83557-00 Tube	Buy now
10	697-85540-00 C.d.i. unit assembly	Buy now
11	697-85547-00 Damper	Buy now
12	663-82131-01 Band	Buy now
13	662-82519-00 Wire, earth lead	Buy now
14	697-85570-00 Ignition coil assembly	Buy now
15	697-82519-00 Wire,earth lead	Buy now

Electrical 1



Ref	Part	
16	97095-06020 Bolt(7u8)	Buy now
17	92995-06600 Washer, plain (646)	Buy now
18	90480-25161 Grommet(656)	Buy now
19	663-82370-01 Plug cap assembly	Buy now
20	664-81970-61 Rectifier assembly	Buy now
21	97880-05030 Ybs86-530 screw,panhead	Buy now
22	92990-05100 Ybs67-5 washer, spring	Buy now
23	697-81971-01 Wire, lead	Buy now
23	697-81971-11 Wire, lead	Buy now
24	90465-13M11 Clamp (6e5)	Buy now
25	697-82590-12 Wire harness assembly	Buy now
25	697-82590-21 Wire harness assembly	Buy now
26	697-82105-12 Battery cable	Buy now
26	697-82105-20 Battery cable	Buy now
27	697-82594-00 Clamp	Buy now

Electrical 1




6960200-5090

C5

Ref	Part	
28	97095-08016 Bolt, hexagon deep recess	Buy now
29	92995-08600 Washer, plain (663)	Buy now
30	688-82560-00 Thermo switch assembly	Buy now
31	663-82588-00 Plate	Buy now
32	97013-06010 Bolt(63v)	Buy now
33	92903-06100 Washer(6a1)	Buy now
34	90465-06M86 Clamp	Buy now
35	682-82150-10 Fuse holder assembly	Buy now
36	663-82151-00 Fuse	Buy now
37	90465-13M39 Clamp(6e8)	Buy now

Electrical 2




6970700-0070

C7


Ref	Part	
1	697-82117-00 Wire, lead	Buy now
2	61A-81949-00 Wire, lead	Buy now
3	97013-06012 Bolt(gh1)	Buy now
4	92903-06600 Washer, plain (646)	Buy now
5	697-81950-00 Relay assembly	Buy now
6	697-81945-00 Plate, switch fitting	Buy now
7	97095-06020 Bolt(7u8)	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	6A0-82317-00 Damper, ignition coil	Buy now
10	624-42542-00 Collar	Buy now
11	95895-06045 Bolt, flange deep recess	Buy now
12	90387-06M38 Collar(697)	Buy now
13	90201-12M16 Washer, plate (679)	Buy now
14	697-82154-00 Case	Buy now

Electrical 3




Ref	Part	
1	696-85542-00-94 Bracket	Buy now
2	6A0-82317-00 Damper, ignition coil	Buy now
3	624-42542-00 Collar	Buy now
4	90119-06M59 Bolt, with washer	Buy now
5	97013-06012 Bolt(gh1)	Buy now
6	92903-06100 Washer(6a1)	Buy now
7	92903-06600 Washer, plain (646)	Buy now
8	696-85540-11 C.d.i. unit assembly	Buy now
9	97013-06020 Bolt(62y)	Buy now
11	696-85590-10 Control unit ass'y	Buy now
14	696-85570-11 Ignition coil assembly	Buy now
15	696-81443-00 Clamp 1	Buy now
16	696-81444-00 Clamp 2	Buy now
17	696-81916-00 Cover, terminal	Buy now
18	97095-06030 Bolt(jf7)	Buy now

Electrical 3



D1


Ref	Part	
19	92995-06600 Washer, plain (646)	Buy now
20	90464-20M04 Clamp	Buy now
21	663-82370-01 Plug cap assembly	Buy now
21	6G1-82370-21 Plug cap assembly FOR CARIB	Buy now
22	688-82560-00 Thermo switch assembly	Buy now
23	663-82588-00 Plate	Buy now
24	97013-06010 Bolt(63v)	Buy now
26	90465-06M86 Clamp	Buy now
27	696-82531-00 Wire, Lead	Buy now
28	662-82519-00 Wire, earth lead	Buy now
32	697-82519-00 Wire,earth lead	Buy now



6970700-0040

B5


Ref	Part	
1	6G1-24304-02 Fuel pipe joint comp. 1	Buy now
2	97095-06020 Bolt(7u8)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	90445-09109 Hose (I1500)	Buy now
5	90467-08004 Clip, pipe 6162435600	Buy now
6	90464-04011 Clamp(663)	Buy now
7	61N-24560-00 Filter assembly	Buy now
8	61N-24563-00 Element, filter	Buy now
9	61N-24521-00 Cup, filter	Buy now
10	93210-32738 O-ring(1wg)	Buy now
11	6E9-24566-70 Bracket, filter	Buy now
12	97013-06014 Bolt(gj3)	Buy now
13	92903-06100 Washer(6a1)	Buy now
14	95380-08600 Nut (661)	Buy now
15	90445-09097 Hose (I1500)	Buy now



6970700-0040


B5

Ref	Part	
17	692-24410-00 Fuel pump assembly	Buy now
18	6A0-24413-00 Cover, pump	Buy now
19	692-24411-00 Diaphragm	Buy now
20	648-24434-01 Gasket, body	Buy now
21	95380-03600 Nut (6g8)	Buy now
22	663-24411-00 Diaphragm	Buy now
23	648-24435-02 Gasket, body 2	Buy now
24	98503-05028 Ybs86-530 screw,panhead	Buy now
25	92990-05100 Ybs67-5 washer, spring	Buy now
26	6A0-24421-01 Valve, check	Buy now
27	6A0-14325-00 Screw, pan head	Buy now
28	6A0-24412-02 Body 1	Buy now
29	650-24431-A0 Gasket,fuel pump	Buy now
30	97095-06040 Bolt (682)	Buy now
32	90445-09086 Hose (I1500)	Buy now




Ref	Part	
34	688-24378-00 Pipe, joint	Buy now
35	90445-09061 Hose (L65)	Buy now
36	656-W2810-02 Tool kit	Buy now
37	626-28193-01-94 Plug, water check AP D)15MM	Buy now

Fuel Tank



Ref	Part	
1	6YJ-24201-00 Fuel tank comp. AP	Buy now
1	6YJ-24201-10 Fuel Tank assembly (24L) AP FOR CHINA	Buy now
2	6YJ-24610-00 Cap assembly	Buy now
3	6Y1-24260-12 Fuel meter assembly FOR CHINA	Buy now
3	6YJ-24260-00 Fuel meter assembly	Buy now
4	98586-05016 Screw, pan head	Buy now
5	6Y1-24329-00 Seal	Buy now
6	6Y1-24268-00 Gasket, fuel meter	Buy now
7	6YJ-24167-00 Strainer	Buy now
8	61J-24306-02 Fuel pipe comp. 1 AP	Buy now
9	90445-11M06 Hose (I3000)	Buy now
10	61J-24360-00 Primer pump assembly	Buy now
11	90445-11M05 Hose (I1000)	Buy now
12	650-24351-51 Band 1	Buy now
13	6G1-24305-03 Fuel pipe joint comp. 2	Buy now


Fuel Tank



D1

Ref	Part	
14	93210-08287 O-ring (655)	Buy now
15	6Y1-24305-04 Fuel pipe joint comp. 2	Buy now


Generator 1



C3


Ref	Part	
1	697-85550-00 Rotor assembly	Buy now
2	697-85560-01 Base assembly	Buy now
3	697-85561-00 Base, magneto	Buy now
4	697-85580-00 Coil, pulser	Buy now
5	697-85580-10 Coil, pulser	Buy now
6	6F0-85599-A0 Cover	Buy now
7	697-85520-02 Coil, charge	Buy now
8	697-85533-00 Coil, lighting	Buy now
9	97602-05130 Screw, Pan Head With Washer	Buy now
10	97602-05132 Screw, pan head with washer	Buy now
11	97602-05114 Screw, pan head with washer	Buy now
12	663-85518-00 Joint, ball	Buy now
13	90480-06158 Grommet (663)	Buy now
14	90280-05015 Key, woodruff	Buy now
15	90170-20137 Nut, hexagon(663)	Buy now

Generator 1



Ref	Part	
16	90201-21M18 Washer, plate (663)	Buy now
17	663-41612-00 Retainer, magneto base 2	Buy now
18	97013-06020 Bolt(62y)	Buy now
19	92903-06600 Washer, plain (646)	Buy now
20	663-41619-00 Washer, magneto 2	Buy now
21	697-81332-00 Plate, timing	Buy now
22	97095-06016 Bolt, hexagon deep recess	Buy now
23	92995-06600 Washer, plain (646)	Buy now

Generator 2





6960100-0070

C4


Ref	Part	
1	696-85550-F1 Rotor ass'y	Buy now
2	696-85560-F0 Base ass'y	Buy now
3	696-85561-F0 Base, magneto	Buy now
4	6E7-85520-70 Coil assembly	Buy now
5	90159-05039 Screw panhead (695)	Buy now
6	6E7-85580-70 Pulser coil ass'y	Buy now
7	90159-05038 Screw, With Washer	Buy now
8	696-81303-F0 Lighting coil ass'y	Buy now
9	90159-05040 Screw, pan head(4my)	Buy now
10	663-85518-00 Joint, ball	Buy now
11	90280-05015 Key, woodruff	Buy now
12	90170-20137 Nut, hexagon(663)	Buy now
13	90201-21M18 Washer, plate (663)	Buy now
14	663-41612-00 Retainer, magneto base 2	Buy now
15	97013-06020 Bolt(62y)	Buy now

Generator 2



Ref	Part	
16	92903-06600 Washer, plain (646)	Buy now
17	663-41619-00 Washer, magneto 2	Buy now
18	663-81332-01 Plate, timing	Buy now
19	97095-06016 Bolt, hexagon deep recess	Buy now
20	92995-06600 Washer, plain (646)	Buy now

Intake




6970700-4030

B2

Ref	Part	
1	696-13610-00 Reed valve ass'y	Buy now
1	697-13610-00 Reed valve ass'y	Buy now
1	698-13610-00 Reed valve ass'y	Buy now
2	688-W0004-00 Reed set	Buy now
2	692-W0004-00 Reed set	Buy now
3	663-13621-A0 Packing, valve seat 1	Buy now
4	663-13622-A0 Packing, valve seat 2	Buy now
5	663-13641-02-94 Manifold, Intake 1	Buy now
5	670-13641-01-94 Manifold Intake 1	Buy now
6	663-14198-A0 Gasket	Buy now
7	624-14485-00 Pipe, joint	Buy now
8	647-14395-60 Cap, over flow pipe	Buy now
9	663-24321-00 Hose	Buy now
10	90467-08004 Clip, pipe 6162435600	Buy now
11	92995-06100 Washer(6a1)	Buy now


Intake



B2


Ref	Part	
12	95380-06600 Nut(661)	Buy now
13	697-41217-01 Rod, accel. lever	Buy now
14	663-41257-02 Rod, choke 2	Buy now
15	663-41256-01 Rod, choke 1	Buy now
15	663-41256-41 Rod, choke 1	Buy now
16	661-41262-02 Joint, choke lever	Buy now
17	697-14417-00-94 Cover 1	Buy now
18	663-14483-A0 Gasket, plate	Buy now
19	97013-06025 Bolt(62y)	Buy now
20	697-14418-00-94 Cover 2	Buy now
21	697-14416-00 Gasket, air cleaner	Buy now
22	97095-06045 Bolt, hexagon	Buy now
24	92995-06600 Washer, plain (646)	Buy now
25	90116-06176 Stud(663)	Buy now
26	663-86110-02 Solenoid coil assembly	Buy now

Intake



Ref	Part	
27	91690-30010 Pin, spring (663)	Buy now
28	663-86115-00 Holder, solenoid	Buy now
29	97880-05030 Ybs86-530 screw,panhead	Buy now
30	663-86116-01 Wire, pull	Buy now
31	676-86117-00 Hook, wire pull	Buy now
32	93210-03261 O-ring (663)	Buy now
33	663-86118-00 Damper	Buy now
34	696-14501-04 Carburetor assembly 1 #1	Buy now
34	697-14501-04 Carburetor assembly 1 #1	Buy now
34	6A3-14501-04 Carburetor assembly 1 #1	Buy now
35	696-14502-04 Carburetor assembly #2	Buy now
35	697-14502-04 Carburetor assembly 2 #2	Buy now
35	6A3-14502-04 Carburetor assembly #2	Buy now
36	663-14950-26 Pilot, air jet (#98)	Buy now
36	663-14950-27 Pilot, air jet(#100)	Buy now


Intake



B2

Ref	Part	
36	663-14950-29 Pilot, air jet (#110)	Buy now
37	663-14945-32 Air jet, main (#125)	Buy now
37	663-14945-34 Air jet, main (#135)	Buy now
37	663-14945-43 Jet (#180)	Buy now
38	697-14991-00 Plug, screw	Buy now
39	679-14557-00 Washer (carb)	Buy now
40	663-14567-01 Screw, plug	Buy now
41	663-14942-19 Jet, pilot (#80)	Buy now
41	663-14942-22 Jet, pilot (#88)	Buy now
42	63V-14523-00 Screw, stop #2	Buy now
43	90501-10326 Spring coil(663)(carb) #2	Buy now
44	663-14923-00 Screw, adjust	Buy now
45	90501-08214 Spring, compression	Buy now
46	6K5-14592-00 Screw #1	Buy now
47	90201-05652 Washer, plate(65j) #1	Buy now


Intake



B2

Ref	Part	
48	663-14947-01 Nozzle, main	Buy now
48	6F0-14947-00 Nozzle, main	Buy now
49	663-14943-39 Jet, main (#160)	Buy now
49	663-14943-40 Jet, main (#165)	Buy now
49	663-14943-43 Jet, main (#180)	Buy now
50	696-14590-01 Needle valve assembly	Buy now
51	663-14159-00 Clip	Buy now
52	93210-07229 O-ring (371)	Buy now
53	810-14186-00 Pin, valve	Buy now
54	371-14919-60 Clip	Buy now
55	98580-04006 Screw, pan head (7h3)	Buy now
56	6F0-14985-00 Float comp.	Buy now
57	663-14548-00 Pin, arm	Buy now
58	93210-64272 O-ring (663) (carb)	Buy now
59	663-14980-00 Body, float chamber	Buy now


Intake



B2


Ref	Part	
60	97980-04112 Screw, pan head (686)	Buy now
61	6H3-14992-00 Screw, drain	Buy now
62	93210-04230 O-ring (371)	Buy now

Lower Casing. Drive 1



Ref	Part	
1	697-45300-01-4D Lower unit assembly S	Buy now
1	697-45300-12-4D Lower unit assembly L	Buy now
2	697-45311-02-4D Casing, lower	Buy now
3	93315-32224 Brg,cyl-cal roller 42.2g nk	Buy now
4	663-45536-00 Sleeve, drive shaft	Buy now
5	663-45587-01-10 Shim (t:0.10mm) UR	Buy now
5	663-45587-01-12 Shim (t:0.12mm) UR	Buy now
5	663-45587-01-15 Shim (t:0.15mm) UR	Buy now
5	663-45587-01-18 Shim (t:0.18mm) UR	Buy now
5	663-45587-01-30 Shim (t:0.30mm) UR	Buy now
5	663-45587-01-40 Shim (t:0.40mm) UR	Buy now
5	663-45587-01-50 Shim (t:0.50mm) UR	Buy now
6	93332-00001 Brg, tapered roller (409)	Buy now
7	663-45567-01-10 Shim (t:0.10mm) UR	Buy now
7	663-45567-01-12 Shim (t:0.12mm) UR	Buy now


Lower Casing. Drive 1



B5


Ref	Part	
7	663-45567-01-15 Shim (t:0.15mm) UR	Buy now
7	663-45567-01-18 Shim (t:0.18mm) UR	Buy now
7	663-45567-01-30 Shim (t:0.30mm) UR	Buy now
7	663-45567-01-40 Shim (t:0.40mm) UR	Buy now
7	663-45567-01-50 Shim (t:0.50mm) UR	Buy now
8	93332-00003 Brg,cyl-cal roller 318g ky	Buy now
9	663-45376-00-94 Guide, seal damper	Buy now
10	663-45375-00 Rubber, seal 2	Buy now
11	90430-08020 Gasket	Buy now
12	90340-08002 Plug, straight screw	Buy now
13	688-45341-10 Plug, drain	Buy now
14	663-45321-00 Plate	Buy now
15	93210-49046 O-ring (620)	Buy now
16	93106-09014 Oil seal	Buy now
17	97095-06016 Bolt, hexagon deep recess	Buy now

Lower Casing. Drive 1



Ref	Part	
18	92995-06600 Washer, plain (646)	Buy now
19	663-45577-01-10 Shim (t:0.10mm) UR	Buy now
19	663-45577-01-12 Shim (t:0.12mm) UR	Buy now
19	663-45577-01-15 Shim (t:0.15mm) UR	Buy now
19	663-45577-01-18 Shim (t:0.18mm) UR	Buy now
19	663-45577-01-30 Shim (t:0.30mm) UR	Buy now
19	663-45577-01-40 Shim (t:0.40mm) UR	Buy now
19	663-45577-01-50 Shim (t:0.50mm) UR	Buy now
20	663-45576-00 Washer, thrust 2	Buy now
21	663-45331-00-94 Housing, bearing	Buy now
22	93306-00702 Brg,r-b 6007 62mm 150g ky	Buy now
23	93317-22204 Brg,cyl-cal roller 25.5g nt	Buy now
24	93101-22067 Oil seal (22x36x6-663)	Buy now
25	93210-66M98 O-ring(6h4)	Buy now
26	90214-48M03 Washer, claw(697)	Buy now


Lower Casing. Drive 1



B5

Ref	Part	
27	697-45384-00 Nut	Buy now
28	90282-04010 Key, strait(663)	Buy now
29	663-44311-02 Housing, water pump	Buy now
30	663-44322-00 Insert, cartridge FOR STD	Buy now
30	663-44322-40 Insert, cartridge FOR CHROMATE	Buy now
31	663-44315-A0 Gasket,water pump 1	Buy now
32	663-44366-00 Damper, water seal 2	Buy now
33	697-44352-00 Impellar	Buy now
34	90280-03M03 Key, woodruff (697)	Buy now
35	663-44341-00-94 Housing, water pump	Buy now
36	93101-23070 Oil seal (663)	Buy now
37	93210-41042 O-ring (132)	Buy now
38	663-44316-A0 Gasket,water pump 2	Buy now
39	663-44323-00 Outer plate, cartridge FOR STD	Buy now
39	670-44323-00 Outer plate, cartridge FOR CHROMATE	Buy now


Lower Casing. Drive 1



B5

Ref	Part	
40	663-44324-A0 Gasket,cartridge outer plate	Buy now
41	93604-08062 Pin,dowel (626)	Buy now
42	97095-08055 Bolt, hexagon	Buy now
43	92995-08600 Washer, plain (663)	Buy now
44	97095-08045 Bolt, hexagon	Buy now
46	663-45510-01 Drive shaft assembly S	Buy now
46	663-45510-11 Drive shaft assembly L	Buy now
47	663-45552-00 Bearing, plain	Buy now
48	697-45551-00 Pinion	Buy now
49	90170-12138 Nut hexagon(663)	Buy now
50	697-45560-00 Gear 1 assembly	Buy now
51	697-45611-00 Shaft, propeller	Buy now
52	90501-16233 Spring compression(663)	Buy now
53	663-45634-00 Slide, shift	Buy now
54	663-45631-01 Clutch, dog	Buy now


Lower Casing. Drive 1



Ref	Part	
55	90250-06023 Pin, strait (663)	Buy now
56	663-45633-00 Ring, cross pin	Buy now
57	688-45635-00 Plunger, shift	Buy now
58	90201-22429 Washer, plate(663)	Buy now
59	697-45571-00 Gear 2	Buy now
60	663-44144-01 Rod, shift 2	Buy now
61	99001-08600 Circlip(2r6)	Buy now
62	663-44151-00 Cam, shift	Buy now


B5

Lower Casing. Drive 2



Ref	Part	
1	696-45300-02-4D Lower unit assembly S	Buy now
1	696-45300-12-4D Lower unit assembly L	Buy now
2	697-45311-02-4D Casing, lower	Buy now
3	93315-32224 Brg,cyl-cal roller 42.2g nk	Buy now
4	663-45536-00 Sleeve, drive shaft	Buy now
5	663-45587-01-10 Shim (t:0.10mm) UR	Buy now
5	663-45587-01-12 Shim (t:0.12mm) UR	Buy now
5	663-45587-01-15 Shim (t:0.15mm) UR	Buy now
5	663-45587-01-18 Shim (t:0.18mm) UR	Buy now
5	663-45587-01-30 Shim (t:0.30mm) UR	Buy now
5	663-45587-01-40 Shim (t:0.40mm) UR	Buy now
5	663-45587-01-50 Shim (t:0.50mm) UR	Buy now
6	93332-00001 Brg, tapered roller (409)	Buy now
7	663-45567-01-10 Shim (t:0.10mm) UR	Buy now
7	663-45567-01-12 Shim (t:0.12mm) UR	Buy now


Lower Casing. Drive 2



C2


Ref	Part	
7	663-45567-01-15 Shim (t:0.15mm) UR	Buy now
7	663-45567-01-18 Shim (t:0.18mm) UR	Buy now
7	663-45567-01-30 Shim (t:0.30mm) UR	Buy now
7	663-45567-01-40 Shim (t:0.40mm) UR	Buy now
7	663-45567-01-50 Shim (t:0.50mm) UR	Buy now
8	93332-00003 Brg,cyl-cal roller 318g ky	Buy now
9	663-45376-00-94 Guide, seal damper	Buy now
10	663-45375-00 Rubber, seal 2	Buy now
11	90430-08020 Gasket	Buy now
12	90340-08002 Plug, straight screw	Buy now
13	688-45341-10 Plug, drain	Buy now
14	663-45321-00 Plate	Buy now
15	93210-49046 O-ring (620)	Buy now
16	93106-09014 Oil seal	Buy now
17	97095-06016 Bolt, hexagon deep recess	Buy now

Lower Casing. Drive 2



Ref	Part	
18	92995-06600 Washer, plain (646)	Buy now
19	663-45577-01-10 Shim (t:0.10mm) UR	Buy now
19	663-45577-01-12 Shim (t:0.12mm) UR	Buy now
19	663-45577-01-15 Shim (t:0.15mm) UR	Buy now
19	663-45577-01-18 Shim (t:0.18mm) UR	Buy now
19	663-45577-01-30 Shim (t:0.30mm) UR	Buy now
19	663-45577-01-40 Shim (t:0.40mm) UR	Buy now
19	663-45577-01-50 Shim (t:0.50mm) UR	Buy now
20	663-45576-00 Washer, thrust 2	Buy now
21	663-45331-00-94 Housing, bearing	Buy now
22	93306-00702 Brg,r-b 6007 62mm 150g ky	Buy now
23	93317-22204 Brg,cyl-cal roller 25.5g nt	Buy now
24	93101-22067 Oil seal (22x36x6-663)	Buy now
25	93210-66M98 O-ring(6h4)	Buy now
26	90214-48M03 Washer, claw(697)	Buy now


Lower Casing. Drive 2



C2


Ref	Part	
27	697-45384-00 Nut	Buy now
28	90282-04010 Key, strait(663)	Buy now
29	663-44311-02 Housing, water pump	Buy now
30	663-44322-40 Insert, cartridge FOR CHROMATE	Buy now
31	663-44315-A0 Gasket,water pump 1	Buy now
32	663-44366-00 Damper, water seal 2	Buy now
33	697-44352-00 Impellar	Buy now
34	90280-03M03 Key, woodruff (697)	Buy now
35	663-44341-00-94 Housing, water pump	Buy now
36	93101-23070 Oil seal (663)	Buy now
37	93210-41042 O-ring (132)	Buy now
38	663-44316-A0 Gasket,water pump 2	Buy now
39	670-44323-00 Outer plate, cartridge FOR CHROMATE	Buy now
40	663-44324-A0 Gasket,cartridge outer plate	Buy now
41	93604-08062 Pin,dowel (626)	Buy now

Lower Casing. Drive 2



Ref	Part	
42	97095-08055 Bolt, hexagon	Buy now
43	92995-08600 Washer, plain (663)	Buy now
44	97095-08045 Bolt, hexagon	Buy now
46	670-45510-00 Drive shaft assembly S	Buy now
46	670-45510-10 Drive shaft assembly L	Buy now
46	696-45510-10 Drive Shaft assembly L-FOR MEXICO	Buy now
47	663-45552-00 Bearing, plain	Buy now
48	697-45551-00 Pinion	Buy now
49	90170-12138 Nut hexagon(663)	Buy now
50	697-45560-00 Gear 1 assembly	Buy now
51	697-45611-00 Shaft, propeller	Buy now
52	90501-16233 Spring compression(663)	Buy now
53	663-45634-00 Slide, shift	Buy now
54	663-45631-01 Clutch, dog	Buy now
55	90250-06023 Pin, strait (663)	Buy now


Lower Casing. Drive 2



C2


Ref	Part	
56	663-45633-00 Ring, cross pin	Buy now
57	688-45635-00 Plunger, shift	Buy now
58	90201-22429 Washer, plate(663)	Buy now
59	697-45571-00 Gear 2	Buy now
60	663-44144-01 Rod, shift 2	Buy now
61	663-44155-01 Cam, reverse rod	Buy now
62	99001-08600 Circlip(2r6)	Buy now
63	663-44151-00 Cam, shift	Buy now

Lower Casing. Drive 3




Ref	Part	
1	663-44367-00 Damper, water seal 3	Buy now
2	688-45214-02 Cover, water inlet	Buy now
3	688-45215-02 Cover, water inlet	Buy now
4	90152-05M05 Screw, countersunk	Buy now
5	90185-05002 Nut nylon (sus)(ex4)	Buy now
6	93606-12019 Pin, dowel (614)	Buy now
7	95380-10600 Nut(624)	Buy now
7	97075-10040 Bolt, hexagon deep recess	Buy now
8	92990-10100 Ybs67-10 washer, spring	Buy now
8	92995-10100 Ybs67-10 washer, spring	Buy now
9	90119-08M84 Bolt, with washer	Buy now
9	90119-08M85 Bolt, with washer	Buy now
10	679-45371-00 Tab trim	Buy now
11	90105-10M67 Bolt, hexagon (663)	Buy now
12	90202-12060 Washer, plate(663)	Buy now

Lower Casing. Drive 3



Ref	Part	
13	663-44361-00 Tube, water S	Buy now
13	663-44361-10 Tube, water L	Buy now
13	670-44361-00 Tube, water S	Buy now
13	670-44361-10 Tube,water L	Buy now
14	90430-12072 Gasket	Buy now
15	663-44373-00 Set plate, water tube	Buy now
16	97095-06012 Bolt(gh1)	Buy now
17	92995-06100 Washer(6a1)	Buy now
18	663-45987-02 Spacer	Buy now
19	670-45997-02 Spacer	Buy now
20	92990-16200 958-58204-00 washer,plain	Buy now
21	90171-16011 Nut, castle (663)	Buy now
22	91490-40025 Pin, cotter (663)	Buy now

Meter 1




6K50200-0270

D7

Ref	Part	
1	6Y5-W0080-12 Tachometer kit AP FOR CHINA	Buy now
2	6Y5-83540-14 Tachometer assembly WITHOUT OIL LAMP	Buy now
3	6Y5-83517-00 Bulb (12v-1.7w)	Buy now
4	6Y5-83536-10 Socket, meter	Buy now
5	6Y5-83523-00 Damper	Buy now
6	6Y5-83514-00 Plate, fitting	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	92990-05100 Ybs67-5 washer, spring	Buy now
9	6Y5-83553-00 Wire, lead (l=2.5m) AP FOR CHINA	Buy now
10	1E6-82151-00 Fuse (10a)	Buy now

Meter 2




63B0100-0310

E1

Ref	Part	
1	6Y5-83670-12 Trim meter assembly. AP	Buy now
2	6Y5-83518-00 Bulb (12v-1.7w) t6.5	Buy now
3	6Y5-83536-00 Socket, meter	Buy now
4	6Y5-83544-00 Plate, fitting	Buy now
5	688-83664-00 Damper	Buy now
6	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
7	1E6-82151-00 Fuse (10a)	Buy now
8	6R3-82553-70 Extension, wire lead (for trim AP 4P,7M	Buy now


Power Trim & Tilt Assy



A7

Ref	Part	
1	62F-43800-04-4D Power trim & tilt assembly	Buy now
2	6H1-43880-02 Motor assembly	Buy now
3	6H1-43805-10 Armature assembly	Buy now
4	6H1-43804-10 Stator assembly	Buy now
5	6H1-43891-10 Brush	Buy now
6	6H1-43892-10 Breaker comp. (brush 2)	Buy now
7	6H1-4380F-10 Plate, brush holder	Buy now
8	6H1-4380J-10 Holder, brush	Buy now
9	6H1-4386K-10 Spring, brush	Buy now
10	97885-05016 Screw, pan head(6b0)	Buy now
11	97607-04310 Screw, pan head(6g8)	Buy now
12	6H1-43881-10 Frame, end	Buy now
13	6H1-4380H-10 Metal	Buy now
14	93102-08M43 Oil seal(6b0)	Buy now
15	6H1-4380G-10 Plate	Buy now


Power Trim & Tilt Assy



A7

Ref	Part	
16	6H1-43865-10 O-ring	Buy now
17	6H1-43840-11 Power tilt assembly	Buy now
18	6H1-43861-10 O-ring	Buy now
19	6H1-43814-11 Piston, free	Buy now
20	6H1-43810-11 Tilt piston sub assembly	Buy now
21	6H1-43861-00 O-ring	Buy now
23	6H1-43871-10 Ring, back up	Buy now
24	6H1-43812-00 Seal dust	Buy now
25	6H1-43872-10 Ring, back up	Buy now
26	93210-18397 O-ring (6g5)	Buy now
27	6H1-43813-10 Cylinder, tilt	Buy now
28	93210-64488 93210-64488	Buy now
29	6H1-43835-10 Pipe	Buy now
30	6H1-43828-10 Body, reservoir	Buy now
31	90386-18M14 Bushing (6e5)	Buy now


Power Trim & Tilt Assy



A7

Ref	Part	
32	6E5-43818-00 Pin, lower shock mount	Buy now
33	6H1-43833-10 Pipe	Buy now
34	6H1-43834-00 Pipe	Buy now
35	97595-06420 Bolt(7u8)	Buy now
36	6H1-43829-00 Plug, reservoir	Buy now
37	93210-09165 O-ring	Buy now
38	93210-064A5 O-ring(61a)	Buy now
39	67F-43802-00 Valve sub assembly	Buy now
40	6H1-43866-00 O-ring	Buy now
41	6H1-43867-00 O-ring	Buy now
42	6H1-43841-11 Piston, shuttle	Buy now
43	6H1-43856-10 Spring, down relief	Buy now
44	6H1-43844-10 Pin, valve support	Buy now
45	6H1-4384G-11 Seal, relief valve	Buy now
46	6H1-4384F-10 Seal, main valve	Buy now

Power Trim & Tilt Assy




6H30010-4190

A7

Ref	Part	
47	6H1-43817-01 Filter 2	Buy now
48	6H1-43831-10 Connector, shaft	Buy now
49	6H1-43830-11 Gear pump assembly	Buy now
50	6H1-43847-00 Seat, manual valve	Buy now
51	6H1-43899-00 Spring, manual release	Buy now
52	6H1-4382A-10 Adaptor 1	Buy now
53	6H1-43854-00 Spring, manual release	Buy now
54	93210-10M74 O-ring	Buy now
55	6H1-43845-00 Screw, manual release	Buy now
56	93210-18M75 O-ring (6e5)	Buy now
57	6H1-43875-00 Ring, snap	Buy now
58	6H1-43822-10 Seal, trim dust	Buy now
59	6H1-43821-11 Screw, trim cylinder end	Buy now
61	6H1-4384E-20 Spring, trim	Buy now
62	98501-05010 Screw, pan head(62x)	Buy now


Power Trim & Tilt Assy



A7

Ref	Part	
63	92901-05200 Ybs66-5 washer, plain	Buy now
64	6H1-43820-11 Piston sub assembly	Buy now
65	6H1-43864-00 O-ring	Buy now
66	91318-08016 Bolt, socket	Buy now
67	6H1-43874-00 Ring, back up	Buy now
68	6H1-43816-00 Filter 1	Buy now
69	6H1-43896-00 O-ring (2h7)	Buy now
70	6H1-43895-12 Seat, relief valve	Buy now
71	62F-43855-00 Spring, up relief	Buy now
72	6H1-43843-11 Screw, valve lock	Buy now
73	6H1-4388E-11 Plug, taper screw	Buy now
74	6H1-43868-00 O-ring	Buy now
75	98501-04025 Screw, pan head	Buy now
76	92901-04100 Ybs67-4 washer, spring	Buy now
77	6H1-4387J-00 Washer, special 2	Buy now


Power Trim & Tilt Assy



Ref	Part	
78	6H1-4385H-00 Spring, seal	Buy now
79	93505-32038 Ball(7fk)	Buy now

A7


Remote Control Assy



D4


Ref	Part	
1	703-48230-15 Remote control assembly (7p) AP	Buy now
1	703-48250-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	703-48261-11 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now

Remote Control Assy



Ref	Part	
15	703-48243-00 Bushing 3	Buy now
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-82594-00 Clamp WITH PT/T SW.	Buy now
26	703-48226-00 Plate, stopper	Buy now
27	703-48222-00 Grip, control lever SINGLE	Buy now
28	703-48223-00 Lock, neutral	Buy now
29	703-48225-00 Cover	Buy now


Remote Control Assy



D4

Ref	Part	
30	703-48219-00 Cover, lead	Buy now
31	703-48281-00 Screw, flat head	Buy now
32	703-48282-00 Screw	Buy now
33	97380-08030 Bolt, hexagon (fj1)	Buy now
34	92990-08600 Washer, plain (663)	Buy now
35	98580-04010 Screw, pan head (e56)	Buy now
36	98580-04006 Screw, pan head (7h3)	Buy now
37	98580-05010 Screw, pan head(62x)	Buy now
38	98580-03015 Screw, pan head (n151)	Buy now
39	703-48291-10 Screw	Buy now
40	95380-06600 Nut(661)	Buy now
41	703-48293-10 Spacer, remote control SINGLE	Buy now
42	701-48287-00 Washer 1	Buy now
43	703-48215-00 Graphic	Buy now
44	703-82510-33 Main switch assembly	Buy now


Remote Control Assy



D4

Ref	Part	
44	703-82510-43 Main switch assembly	Buy now
45	703-82577-00 Cap, key	Buy now
46	703-82531-00 Wire, lead	Buy now
47	688-82575-01 Engine stop switch assembly	Buy now
48	682-82556-00 Lanyard, stop switch	Buy now
49	688-82586-21 Extension, wire harness L)5M (7P)	Buy now
49	688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P)	Buy now
50	703-82540-00 Neutral switch assembly	Buy now
51	703-83383-02 Buzzer	Buy now
52	703-48284-00 Grommet	Buy now
53	703-82591-00 Band	Buy now
54	703-82592-00 Band	Buy now
55	703-48224-00 Cover, control lever WITHOUT PT/T SW.	Buy now
55	703-82563-02 Trim & tilt switch assembly WITH PT/T SW.	Buy now
56	703-48221-00 Grip	Buy now



Remote Control Assy



D4

Ref	Part	
57	703-48152-00 Knob, free accel	Buy now
58	703-48212-00 Rear housing	Buy now
59	703-48213-00 Back, panel	Buy now
60	703-48271-00 Arm, shift	Buy now
61	703-48211-01 Housing,1	Buy now
62	703-48232-00 Drive gear	Buy now

Remote Control Box




67M0100-8280

D3


Ref	Part	
1	703-48230-15 Remote control assembly (7p) AP	Buy now
1	703-48250-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	701-48320-20 Cable, Remote Control L=13F UR	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now

Repair Kit 1



Ref	Part	
1	697-W0001-02 Power head gasket kit	Buy now
2	663-14483-A0 Gasket, plate	Buy now
3	663-14198-A0 Gasket	Buy now
4	663-13621-A0 Packing, valve seat 1	Buy now
5	663-13622-A0 Packing, valve seat 2	Buy now
6	93210-64272 O-ring (663) (carb)	Buy now
7	697-11181-A1 Gasket, cylinder head 1	Buy now
8	663-11193-A0 Gasket, head cover	Buy now
9	663-12414-A0 Gasket, thermostat	Buy now
10	663-41114-A0 Gasket, exhaust outer cover	Buy now
11	93210-42159 O-ring (647)	Buy now
12	93102-32M07 Oil seal (697)	Buy now
13	93102-28135 Oil seal (28x47x7-663)	Buy now
14	93104-18049 Oil seal (18x30x5-663)	Buy now
15	93210-62269 Ring, o(663)	Buy now

Repair Kit 1




6970700-4220

E2


Ref	Part	
16	696-45113-A0 Gasket, upper casing	Buy now
17	93210-32738 O-ring(1wg)	Buy now
18	650-24431-A0 Gasket, fuel pump	Buy now
19	696-W0093-02 Carburetor repair kit	Buy now
22	679-14557-00 Washer (carb)	Buy now
23	663-14923-00 Screw, adjust	Buy now
24	696-14590-01 Needle valve assembly	Buy now
25	93210-07229 O-ring (371)	Buy now
26	810-14186-00 Pin, valve	Buy now
27	6F0-14985-00 Float comp.	Buy now
28	663-14548-00 Pin, arm	Buy now
30	97980-04112 Screw, pan head (686)	Buy now
31	93210-04230 O-ring (371)	Buy now

Repair Kit 2




Ref	Part	
1	698-W0001-21 Lower unit gasket kit	Buy now
2	697-45114-A0 Gasket, upper casing 2	Buy now
3	663-45123-00 Gasket, muffler	Buy now
4	90430-08020 Gasket	Buy now
5	93210-49046 O-ring (620)	Buy now
6	663-44315-A0 Gasket, water pump 1	Buy now
7	663-44324-A0 Gasket, cartridge outer plate	Buy now
8	663-44316-A0 Gasket, water pump 2	Buy now
9	93210-41042 O-ring (132)	Buy now
10	93101-23070 Oil seal (663)	Buy now
11	93210-66M98 O-ring(6h4)	Buy now
12	93101-22067 Oil seal (22x36x6-663)	Buy now
13	663-W0078-01 Water pump repair kit	Buy now
13	696-W0078-00 Water pump repair kit	Buy now
14	663-44322-00 Insert, cartridge	Buy now

Repair Kit 2



Ref	Part	
14	663-44322-40 Insert, cartridge	Buy now
15	697-44352-00 Impellar	Buy now
17	663-44323-00 Outer plate, cartridge	Buy now
17	670-44323-00 Outer plate, cartridge	Buy now
19	97095-08055 Bolt, hexagon	Buy now
20	97095-08045 Bolt, hexagon	Buy now
21	663-44366-00 Damper, water seal 2	Buy now
22	90280-03M03 Key, woodruff (697)	Buy now
23	697-W0078-0A Chrome pump kit	Buy now

Starter




6960100-0060

B7

Ref	Part	
1	696-W1571-02 Starter assembly	Buy now
2	663-15711-02 Case, starter	Buy now
3	696-15773-00 Stay 3	Buy now
4	663-15739-00 Washer, thrust 2	Buy now
5	663-15713-00 Spring, starter	Buy now
6	663-15714-01 Drum, sheave	Buy now
7	663-15764-00 Collar	Buy now
8	663-15741-02 Pawl, drive	Buy now
9	663-15754-00 Bushing	Buy now
10	663-15726-01 Washer, flat 1	Buy now
11	663-15744-00 Circlip	Buy now
12	663-15715-00 Spring, drive plate	Buy now
13	696-15716-00 Drive, plate	Buy now
14	696-15734-00 Spring, return	Buy now
15	663-15719-00 Washer, thrust	Buy now


Starter



B7

Ref	Part	
16	92903-06100 Washer(6a1)	Buy now
17	97303-06016 Bolt, hexagon deep recess	Buy now
18	663-15752-00 Roller, wire	Buy now
19	663-15753-00 Bushing 1	Buy now
20	663-15791-00 Washer, lock	Buy now
22	97303-06025 Bolt, hexagon	Buy now
23	689-15755-01 Handle, starter	Buy now
24	* item_description	Buy now
25	6F5-15779-02 Cover	Buy now
26	6K5-15723-00 Pulley, starter	Buy now
27	90385-12M04 Bushing (6f5)	Buy now
28	90387-08M05 Collar (663)	Buy now
29	90119-08M26 Bolt, with washer	Buy now
30	90201-08095 Washer, plate(j40)	Buy now
31	97095-08040 Bolt, hexagon	Buy now


Starter



B7

Ref	Part	
32	92995-08100 Ybs67-8 washer, spring	Buy now
33	697-15789-00 Damper	Buy now
34	97013-08014 Bolt(692)	Buy now
35	92903-08100 Ybs67-8 washer, spring	Buy now
36	697-15787-00-94 Adaptor	Buy now
37	90119-06M30 Bolt, with washer	Buy now
38	95303-06600 Nut(661)	Buy now
39	6A0-82317-00 Damper, ignition coil	Buy now
40	624-42542-00 Collar	Buy now
41	697-15758-01-4D Guide, Rope	Buy now
42	97095-06020 Bolt(7u8)	Buy now
43	92995-06100 Washer(6a1)	Buy now
44	92995-06600 Washer, plain (646)	Buy now
46	697-15762-00 Seal 2	Buy now
47	663-15771-00-94 Stay 1	Buy now


Starter



B7

Ref	Part	
48	97013-08030 Bolt	Buy now
50	697-15770-01 Cable comp., starter stop	Buy now
51	663-15735-01 Guide, cam	Buy now
52	90506-08M23 Spring, tension(6k5)	Buy now
53	90508-12015 Spring torsion 616436420000	Buy now
54	90149-05095 Screw(663)	Buy now
55	97095-06012 Bolt(gh1)	Buy now
57	663-15794-00 Stopper	Buy now
58	663-15736-00 Ring, retaining 1	Buy now
59	92995-06200 Ybs66-6 washer, plain	Buy now
60	91490-16012 Pin, cotter (e57)	Buy now
61	663-15772-01 Stay 2	Buy now
62	97013-08012 Bolt(62e)	Buy now
63	91702-06014 Pin, clevis AP	Buy now
64	90465-06M90 Clamp	Buy now


Starter



B7

Ref	Part	
65	697-11119-00 Hanger, engine	Buy now


Starting Motor



D3

Ref	Part	
1	697-81800-13 Starting motor assembly	Buy now
2	676-81830-10 Front cover assembly	Buy now
3	688-81831-00 Metal, front	Buy now
4	682-81941-11 Starter, relay	Buy now
5	663-81832-12 Pinion assembly	Buy now
6	676-81850-12 Armature assembly	Buy now
7	663-81810-11 Stator assembly	Buy now
8	663-81840-11 Brush holder assembly	Buy now
9	663-81811-11 Brush 1	Buy now
10	663-81812-11 Brush 2	Buy now
11	663-81813-10 Spring, brush	Buy now
12	663-81820-12 Rear bracket assembly	Buy now
13	98503-04012 Screw, pan head (686)	Buy now
14	92901-04100 Ybs67-4 washer, spring	Buy now
15	97313-06010 Bolt	Buy now


Starting Motor



D3


Ref	Part	
16	663-81826-10 Bolt 1	Buy now
17	697-81857-12 Pinion stopper set	Buy now
18	697-81809-10 Washer kit	Buy now
19	697-81815-10 Wire, lead	Buy now
20	697-81952-10 Holder, relay	Buy now
21	688-81824-00 Washer 2	Buy now
22	97013-08040 Bolt, Hexagon	Buy now
23	92903-08100 Ybs67-8 washer, spring	Buy now
24	92903-08600 Washer, plain (663)	Buy now
25	663-81842-01-94 Cover 3	Buy now
26	97013-08025 Bolt (682)	Buy now
28	663-81162-00 Washer, Plain	Buy now
29	97013-08016 Bolt, hexagon	Buy now

Steering



Ref	Part	
3	664-42119-00 Grip, steering handle	Buy now
4	6F6-42177-A0 Rubber, handle	Buy now
5	697-42137-10 Indicator, throttle	Buy now
6	90269-02M09 Rivet(615)	Buy now
7	90149-05M13 Screw, countersunk	Buy now
8	92903-10600 Washer, plate	Buy now
9	90501-23215 Spring (655)	Buy now
10	90386-08032 Bushing (650)	Buy now
11	663-42115-00 Shaft, steering handle	Buy now
12	663-42138-00 Lever, throttle	Buy now
13	90254-03003 Pin, spring	Buy now
14	663-42135-01 Housing, throttle lever	Buy now
15	663-42133-01 Gasket	Buy now
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	97885-06008 Screw, pan head(6a3)	Buy now

Steering




6962200-3140

D7

Ref	Part	
19	97885-05012 Screw,pan head (646)	Buy now
20	692-26301-03 Throttle cable assembly	Buy now
22	90101-12M06 Bolt	Buy now
23	92990-12200 Ybs66-12 washer,plain	Buy now
24	90386-12089 Bushing(663)	Buy now
25	90202-12092 Washer, plate(663)	Buy now
26	90201-12537 Washer, plate(663)	Buy now
27	90206-12054 Washer, wave(663)	Buy now
28	90185-12058 Nut, nylon(663)	Buy now
29	697-44113-00 Cam plate, handle	Buy now
30	6K5-44191-00 Indicator,shift	Buy now
31	97013-06016 Bolt, hexagon deep recess	Buy now
32	92903-06100 Washer(6a1)	Buy now
33	697-44159-00 Handle, gear shift 2	Buy now
34	663-44173-00 Lever, shift control	Buy now

Steering




6962200-3140

D7

Ref	Part	
35	90501-16M17 Spring (697)	Buy now
36	93515-32M01 Ball (697)	Buy now
37	90386-10009 Bushing 6484418600	Buy now
38	90201-10120 Washer, plate	Buy now
39	90185-10051 Nut, self-locking	Buy now
40	90387-12M30 Collar (697)	Buy now
41	90201-12M34 Washer (692)	Buy now
42	663-42164-00 Rod, manual shift	Buy now
43	92990-06600 Washer, plain (646)	Buy now
44	91490-25012 Pin, cotter	Buy now
45	90386-06088 Bushing(663)	Buy now
46	700-48339-00 Nut,cable end	Buy now
47	663-42126-01 Friction, steering handle	Buy now
48	90101-06M27 Bolt	Buy now
50	90175-06003 Nut, wing (f87)	Buy now

Steering




FWD
6962200-3140

D7

Ref	Part	
51	6K5-82575-03 Engine stop switch assembly	Buy now
52	682-82556-00 Lanyard, stop switch	Buy now
53	689-8257Y-00 Cap	Buy now

Steering Guide




6880700-9190

D2

Ref	Part	
1	697-61350-00 Steering guide attachment kit AP FOR CHINA	Buy now
2	697-61351-00 Rod, steering link	Buy now
3	90201-10M20 Washer, plate (663)	Buy now
4	90185-09M01 Nut, nylon (663)	Buy now
5	90170-09M03 Nut (689)	Buy now
6	90387-10M42 Coller (688)	Buy now
7	90201-10M63 Washer, plate	Buy now
8	6E5-61355-00 Bolt	Buy now
9	6E5-43145-01 Cap, clamp bracket	Buy now
10	93210-16275 O-ring	Buy now

Top Cowling 1




6961200-2010

A4

Ref	Part	
1	697-42610-40-4D Top cowling assembly	Buy now
2	697-42647-00-94 Holder, clamp band	Buy now
3	697-42649-00-94 Holder, clamp band	Buy now
4	90202-19M10 Washer, plate (697)	Buy now
5	663-42662-00 Damper	Buy now
6	90266-06009 Rivet (697)	Buy now
7	90266-06M02 Rivet (697)	Buy now
8	697-42613-01-4D Molding, air duct	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	663-42615-02 Seal	Buy now
12	697-42815-11-98 Lever, clamp 1	Buy now
13	697-42817-11-98 Lever, clamp 3	Buy now
14	90386-13M38 Bushing (697)	Buy now
15	90206-13019 Washer, wave 6264283200	Buy now

Top Cowling 1




6961200-2010

A4

Ref	Part	
16	663-42816-02 Lever, clamp 2	Buy now
17	97095-06012 Bolt(gh1)	Buy now
18	90201-06068 Washer,plate (6k8)	Buy now
19	697-42677-40 Graphic, front	Buy now
20	697-W0070-31 Graphic Set	Buy now
21	697-42678-30 Graphic, rear	Buy now
22	697-42681-31 Mark Cowling	Buy now
23	697-42682-31 Mark Cowling	Buy now

Top Cowling 2





6961200-2020

A5

Ref	Part	
1	696-42610-J0-4D Top Cowling assembly	Buy now
1	6A3-42610-J0-4D Top cowling assembly	Buy now
2	697-42647-00-94 Holder, clamp band	Buy now
3	697-42649-00-94 Holder, clamp band	Buy now
4	90202-19M10 Washer, plate (697)	Buy now
5	663-42662-00 Damper	Buy now
6	90266-06009 Rivet (697)	Buy now
7	670-43691-00 Indicator, Tilt	Buy now
8	697-42613-11-4D Molding, air duct	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	663-42615-02 Seal	Buy now
12	697-42815-11-98 Lever, clamp 1	Buy now
13	697-42817-01-98 Lever, clamp 3	Buy now
14	90386-13M38 Bushing (697)	Buy now

Top Cowling 2





 6961200-2020

A5

Ref	Part	
15	90206-13019 Washer, wave 6264283200	Buy now
16	663-42816-02 Lever, clamp 2	Buy now
17	97095-06012 Bolt(gh1)	Buy now
18	90201-06068 Washer,plate (6k8)	Buy now
19	696-W0070-H0 2-	Buy now
19	6A3-W0070-H0 2-	Buy now
20	696-42678-H0 Graphic, Rear	Buy now
20	6A3-42678-H0 Graphic, rear	Buy now
21	697-15761-01 Seal 1	Buy now
22	677-13437-08 1-	Buy now
23	69P-42677-H0 Graphic, Front ENDURO	Buy now


Upper Casing



6960200-0200

Ref	Part	
1	691-45111-01-4D Lower unit assembly S	Buy now
1	691-45111-13-4D Casing, upper L	Buy now
1	697-45111-01-4D Casing, upper S	Buy now
1	697-45111-13-4D Casing, upper L	Buy now
2	663-45123-00 Gasket, muffler	Buy now
3	663-45155-10 Cap	Buy now
4	93606-12019 Pin, dowel (614)	Buy now
5	90119-08M82 Bolt, with washer(697)	Buy now
6	663-41137-04-5B Guide, exhaust	Buy now
7	90386-02M04 Bushing (663)	Buy now
8	663-45127-00 Seal 1	Buy now
9	663-45129-00 Hook, damper seal	Buy now
10	697-45114-A0 Gasket,upper casing 2	Buy now
11	663-14711-02-5B Muffler S	Buy now
11	663-14711-12-5B Muffler L	Buy now

Upper Casing



6960200-0200

B3

Ref	Part	
12	90334-30017 Plug strait(663)	Buy now
13	663-45251-00 Anode	Buy now
14	90152-06M01 Screw, countersunk	Buy now
15	97075-08035 Bolt(70w)	Buy now
16	92995-08100 Ybs67-8 washer, spring	Buy now
17	97075-08030 Bolt, hexagon (fj1)	Buy now
19	696-45113-A0 Gasket,upper casing	Buy now
21	97575-08440 Bolt, with washer	Buy now
22	663-14737-00 Damper, muffler S	Buy now
22	663-14737-10 Damper, muffler L	Buy now
23	696-45211-01-4D Extension	Buy now
24	90116-10M31 Bolt, stud(6a3)	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.