



Yamaha E60HWHD 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	11
BRACKET 3	13
BRACKET 4	17
CARBURETOR	20
CONTROL	23
CRANKSHAFT. PISTON	26
CYLINDER. CRANKCASE	29
ELECTRICAL 1	32
ELECTRICAL 2	35
ELECTRICAL 3	36
ELECTRICAL 4	38
FUEL	40
FUEL TANK	43
GENERATOR	45
INTAKE	47
LOWER CASING. DRIVE 1	49
LOWER CASING. DRIVE 2	55
LOWER CASING. DRIVE 3	61
METER	64
REMOTE CONTROL ASSY	65
REMOTE CONTROL BOX	70
REPAIR KIT 1	71
REPAIR KIT 2	74
STARTER	76
STARTING MOTOR	80
STEERING	82
STEERING GUIDE	87
TOP COWLING	88
UPPER CASING	89

Bottom Cowling




69D1300-2100

D3


Ref	Part	
1	6H3-42711-05-4D Cowling, bottom	Buy now
1	6H3-42711-14-4D Cowling, bottom 1	Buy now
2	69D-44391-00 Nipple, hose	Buy now
3	6H3-42815-01-4D Lever, clamp	Buy now
4	6H3-42817-01-4D Lever, clamp	Buy now
5	90386-13M38 Bushing (697)	Buy now
6	90206-13M10 Washer, wave (6e5)	Buy now
7	6H3-42813-00 Spring, clamp lever	Buy now
8	90269-04M03 Rivet (6h3)	Buy now
9	6H3-42816-00 Lever, clamp 2	Buy now
10	6H3-42818-00 Lever, clamp 4	Buy now
11	90119-06M09 Bolt, with washer	Buy now
12	6H3-42716-02 Rubber, seal 1	Buy now
13	6K5-42717-00 Rubber, seal 2	Buy now
14	6E5-42724-00 Grommet	Buy now

Bottom Cowling



Ref	Part	
15	6H3-42725-00 Grommet	Buy now
15	6H3-42725-20 Grommet 2	Buy now
15	6K5-42725-00 Grommet	Buy now
16	6H3-42738-01-5B Plate, fitting	Buy now
17	97095-06016 Bolt, hexagon deep recess	Buy now
18	92995-06600 Washer, plain (646)	Buy now
19	6H3-42727-00 Grommet	Buy now
20	90480-09M12 Grommet (6a0)	Buy now
21	90387-06M69 Collar (688)	Buy now
22	90119-06M61 Bolt, with washer	Buy now
23	6H3-42768-00 Damper	Buy now
24	6H4-42726-00 Grommet	Buy now
25	703-82119-00 Cover, lead wire	Buy now
26	90338-05M03 Plug (6h1)	Buy now
28	6H3-42741-01-4D Apron	Buy now

Bottom Cowling




69D1300-2100

D3


Ref	Part	
29	6H3-42771-01-4D Apron	Buy now
30	97095-06025 Bolt	Buy now
32	97095-06020 Bolt(7u8)	Buy now
34	6H3-42718-00 Rubber, seal 3	Buy now
35	6G5-42791-00 Mark 1	Buy now
35	6G5-42791-10 Mark 1 FOR CARIB,CHINA	Buy now
36	6A1-28176-00 Label Caution FOR CARIB	Buy now
37	6E3-8257H-00 Plate Mark FOR CARIB	Buy now

Bracket 1




Ref	Part	
1	688-43111-13-4D Bracket, clamp 1 X	Buy now
1	697-43111-05-4D Bracket, clamp S	Buy now
2	663-45251-00 Anode S	Buy now
2	6H1-45251-03 Anode X	Buy now
3	6H1-44526-00 Plate 2 X	Buy now
4	90119-06M29 Bolt, with washer X	Buy now
5	90152-06M01 Screw, countersunk S	Buy now
6	97095-06016 Bolt, hexagon deep recess X	Buy now
7	92995-06100 Washer(6a1) X	Buy now
8	92995-06600 Washer, plain (646) X	Buy now
9	688-43112-12-4D Bracket, clamp 2 X	Buy now
9	697-43112-03-4D Bracket, clamp S	Buy now
10	6E5-82148-00 Wire, lead 5	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	648-43114-01 Pad, transom clamp	Buy now

Bracket 1




Ref	Part	
13	663-43116-01 Screw, transom	Buy now
14	90243-04007 Pin (663)	Buy now
15	663-43118-01-4D Handle, transom clamp	Buy now
16	97095-10045 Bolt(64d)	Buy now
17	92995-10100 Ybs67-10 washer, spring	Buy now
18	697-43311-03-4D Bracket, swivel S	Buy now
18	6H1-43311-01-4D Bracket, swivel 1 X	Buy now
19	93700-06M03 Nipple, grease(6a1)	Buy now
20	63D-43691-00 Indicator, tilt	Buy now
21	688-43131-03 Bolt, clamp bracket	Buy now
22	90386-22M15 Bushing (688)	Buy now
23	90201-22M67 Washer, plate (688)	Buy now
24	90185-22043 Nut, self-locking	Buy now
25	6G5-43145-01 Cap, clamp bracket	Buy now
26	688-43181-04 Lever, tilt stop 1 S	Buy now

Bracket 1




Ref	Part	
26	688-43181-10 Lever, tilt stop 1 X	Buy now
27	688-43185-04 Lever, tilt stop 2 S	Buy now
27	688-43185-10 Lever, tilt stop 2 X	Buy now
28	90386-10M16 Bushing (688)	Buy now
29	6G5-43148-00 Collar, distance X	Buy now
29	92990-10600 Washer, plate S	Buy now
30	90501-10M21 Spring (688) S	Buy now
30	91690-30020 Pin, spring (6h4) X	Buy now
31	90249-06M19 Pin(6e5) X	Buy now
31	90387-10M38 Collar (6e5) S	Buy now
32	90387-10M02 Collar(6e5) X	Buy now
32	91490-30025 Pin cotter S	Buy now
33	663-43318-00 Cover	Buy now
34	688-43160-01 Tilt rod ass'y X	Buy now
34	697-43160-00 Tilt lock ass'y S	Buy now

Bracket 1




Ref	Part	
35	688-43165-00 Stopper, tilt rod	Buy now
36	91690-30012 Pin, spring	Buy now
37	90502-16M02 Spring, conical (688) X	Buy now
37	90502-20M03 Spring (6e5) S	Buy now
38	6E5-43126-02 Pin, upper shock mount	Buy now
39	90386-18M21 Bushing (688)	Buy now
40	90386-18M35 Bush (688)	Buy now
41	93410-18M02 Circlip (6f2)	Buy now
42	90506-14M24 Spring, tension(6e5) X	Buy now
43	6G5-43144-00 Hook, spring X	Buy now
44	97095-06010 Bolt X	Buy now
45	90101-12M65 Bolt	Buy now
46	92995-12200 Ybs66-12 washer,plain	Buy now
47	90201-12426 Washer, plate(663)	Buy now
48	95380-12600 Nut (707)	Buy now

Bracket 2



Ref	Part	
1	688-43128-01-4D Spacer, clamp bracket X	Buy now
1	697-43128-01-4D Spacer, clamp bracket S	Buy now
2	688-43170-04-4D Shock absorber sub-assembly X	Buy now
2	697-43170-03-4D Shock absorber sub-assembly S	Buy now
3	688-43631-00 Lever, tilt 1 S	Buy now
3	688-43631-10 Lever, tilt X	Buy now
4	97080-06010 Bolt	Buy now
5	688-43124-02 Pin, lower shock mount	Buy now
6	90386-18M21 Bushing (688) S	Buy now
7	90386-18M63 Bush(6e5) X	Buy now
8	90386-18M35 Bush (688)	Buy now
9	682-43318-01 Cover X	Buy now
10	688-43186-00 Lever X	Buy now
11	91690-30020 Pin, spring (6h4) X	Buy now
12	6J8-41262-00 Joint, choke lever X	Buy now

Bracket 2




Ref	Part	
13	688-43616-00 Rod, tilt lock X	Buy now
14	90202-03M51 Washer, plate(688) X	Buy now
15	688-43651-00 Lever, reverse lock1 X	Buy now

E6

Bracket 3

FOR LONG




69D0200-1180

E7

Ref	Part	
1	63D-43111-01-4D Bracket, clamp 1	Buy now
2	63D-45251-00 Anode	Buy now
3	97095-06025 Bolt	Buy now
4	92995-06100 Washer(6a1)	Buy now
5	6H1-82148-00 Wire, lead	Buy now
6	97095-06010 Bolt	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	63D-43112-01-4D Bracket, clamp 2	Buy now
9	63D-82148-00 Wire, lead 5	Buy now
10	97885-06008 Screw, pan head(6a3)	Buy now
11	648-43114-01 Pad, transom clamp	Buy now
12	663-43116-01 Screw, transom	Buy now
13	90243-04007 Pin (663)	Buy now
14	663-43118-01-4D Handle, transom clamp	Buy now
15	63D-43128-01-4D Spacer, clamp bracket	Buy now

Bracket 3

FOR LONG





69D0200-1180

E7

Ref	Part	
16	69D-43311-11-4D Bracket, swivel 1	Buy now
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	63D-43691-00 Indicator, tilt	Buy now
19	63D-43131-01 Bolt, clamp bracket	Buy now
20	90386-22M15 Bushing (688)	Buy now
21	90201-22M03 Washer, plate(64j)	Buy now
22	90185-22M11 Nut, self-locking	Buy now
23	6G5-43145-01 Cap, clamp bracket	Buy now
24	6H5-43181-03 Lever, tilt stop 1	Buy now
25	6H5-43185-03 Lever, tilt stop 2	Buy now
26	90386-10M16 Bushing (688)	Buy now
27	90386-10025 Bushing (658)	Buy now
28	6G5-43148-00 Collar, distance	Buy now
29	91690-30020 Pin, spring (6h4)	Buy now
30	90249-06M19 Pin(6e5)	Buy now

Bracket 3

FOR LONG




69D0200-1180

E7

Ref	Part	
31	688-43160-01 Tilt rod ass'y	Buy now
32	688-43165-00 Stopper, tilt rod	Buy now
33	91690-30012 Pin, spring	Buy now
34	90502-16M02 Spring, conical (688)	Buy now
35	69D-43170-10-4D Shock absorber sub-assembly	Buy now
36	69D-43631-00 Lever, tilt	Buy now
38	663-45251-00 Anode	Buy now
39	98680-06525 Screw flat head	Buy now
40	69D-43126-00 Pin, upper shock mount	Buy now
41	90387-16003 Collar	Buy now
42	90387-16004 Collar	Buy now
43	93410-16006 Circlip	Buy now
44	90116-18M52 Bolt, stud(62x)	Buy now
45	90386-18M44 Bushing (6g5)	Buy now
46	92995-18600 Washer(64j)	Buy now

Bracket 3

FOR LONG




69D0200-1180

E7


Ref	Part	
47	90170-18M10 Nut (6h5)	Buy now
48	682-43318-01 Cover	Buy now
49	90506-14M24 Spring, tension(6e5)	Buy now
50	6G5-43144-00 Hook, spring	Buy now
52	90101-12M65 Bolt	Buy now
53	92995-12200 Ybs66-12 washer,plain	Buy now
54	90201-12426 Washer, plate(663)	Buy now
55	95380-12600 Nut (707)	Buy now

Bracket 4




Ref	Part	
1	69D-42510-10-4D Steering Bracket assembly L/X	Buy now
1	6H3-42510-02-4D Steering bracket assembly S	Buy now
2	90201-30M00 Washer, plate(6h1)	Buy now
3	90386-30M78 Bush(6h0)	Buy now
4	90386-30M77 Bush(6h0)	Buy now
5	93210-29M94 O-ring(6h1)	Buy now
6	90386-30M60 Bush(6j8)	Buy now
7	69D-44551-10-4D Housing, lower mount rubber 1 L/X	Buy now
7	6H3-44551-01-4D Housing, lower mount rubber 1 S	Buy now
8	93410-28M06 Circlip (688)	Buy now
9	687-44555-00-94 Mount damper, lower side S/L	Buy now
9	688-44555-00-94 Mount damper, lower side X	Buy now
10	90201-12M16 Washer, plate (679)	Buy now
11	90202-25M04 Washer, plate (663)	Buy now
12	90201-13M19 Washer, plate (663)	Buy now

Bracket 4



Ref	Part	
13	90109-12M21 Bolt (6h3)	Buy now
14	663-44575-00 Damper, lower mount rubber	Buy now
15	95380-12800 Nut crown(663)	Buy now
16	6H3-44552-03-94 Housing, lower mount rubber	Buy now
17	97075-08025 Bolt, hexagon deep recess	Buy now
18	92995-08100 Ybs67-8 washer, spring	Buy now
19	90501-14M08 Spring, compression(64j)	Buy now
20	90179-06066 Nut(663)	Buy now
21	6H3-44553-01-4D Cover, lower mount	Buy now
22	97885-06016 Screw, pan head(6b0)	Buy now
23	688-82127-02 Wire, lead 2 L/X	Buy now
23	697-82127-01 Wire, lead 2 S	Buy now
24	6H3-48511-51-4D Hook, steering STEERING GUIDE	Buy now
25	688-44514-00-94 Mount damper, upper side	Buy now
26	90101-10M49 Bolt	Buy now


Bracket 4



F3


Ref	Part	
27	90201-20M21 Washer, plate (688)	Buy now
28	90202-20M06 Washer, plate (688)	Buy now
29	90201-11M22 Washer, plate (688)	Buy now
30	90185-10051 Nut, self-locking	Buy now
32	688-44511-00-94 Cover, upper mount	Buy now
33	97075-08035 Bolt(70w)	Buy now
35	90116-10M28 Bolt, stud	Buy now

Carburetor




Ref	Part	
1	6K5-14301-03 Carburetor assembly 1	Buy now
2	6K5-14302-03 Carburetor assembly 2	Buy now
3	6K5-14303-03 Carburetor assembly 3	Buy now
4	6H2-14947-02 Nozzle, main	Buy now
5	676-14943-34 Jet, main (#135)	Buy now
6	6H4-14948-15 Jet, sl0w (#70)	Buy now
7	676-14966-00 Rubber cap	Buy now
8	6H3-14590-01 Needle valve assembly	Buy now
9	663-14159-00 Clip	Buy now
10	676-14186-00 Pin, valve	Buy now
11	98580-04008 Screw, pan head (713)	Buy now
12	6G1-14985-00 Float comp.	Buy now
13	688-14548-00 Pin, arm	Buy now
14	6G1-14984-00 Gasket, float chamber	Buy now
15	6H2-14980-00 Body, float chamber	Buy now

Carburetor




Ref	Part	
16	97980-04114 Screw, pan head(ga5)	Buy now
17	6H3-14992-00 Screw, drain	Buy now
18	93210-04230 O-ring (371)	Buy now
19	663-14126-00 Packing	Buy now
20	663-14527-00 Plate	Buy now
21	688-14126-00 Packing	Buy now
22	688-14527-00 Plate	Buy now
23	6H2-14527-01 Plate	Buy now
24	97980-05310 Screw, with washer(6k5)	Buy now
25	692-14923-00 Screw, adjusting	Buy now
26	679-14555-00 Spring	Buy now
27	6K5-14592-00 Screw #1,2	Buy now
28	90201-05652 Washer, plate(65j) #1,2	Buy now
29	63V-14523-00 Screw, stop #2	Buy now
30	90501-10326 Spring coil(663)(carb) #2	Buy now

Carburetor



Ref	Part	
31	6H2-14578-00 Collar #3	Buy now
32	6H3-14578-00 Collar	Buy now
33	93210-15M52 O-ring (6e9)	Buy now
34	93210-04228 O-ring (371)	Buy now
35	6K5-14945-36 Jet, air main (#145)	Buy now
36	6K5-14950-21 Jet, air slow (#85)	Buy now


Control



E1


Ref	Part	
1	6H3-41238-00 Joint, link 1	Buy now
2	6H3-41631-00 Lever, magneto control 1	Buy now
3	90157-06M13 Screw, pan head(6h4)	Buy now
4	95380-06600 Nut(661)	Buy now
5	688-44194-00 Cap	Buy now
6	90387-06M60 Collar (6h3)	Buy now
7	97095-06025 Bolt	Buy now
8	6H3-41632-00 Lever, magneto control 2	Buy now
9	90201-06M31 Washer (6a0)	Buy now
10	90508-29M19 Spring, torsion	Buy now
11	6H3-41633-00 Lever, magneto control 3	Buy now
12	90387-06M59 Collar (6h3)	Buy now
13	90119-06M91 Bolt, with washer	Buy now
14	662-41237-01 Joint, link	Buy now
15	679-41636-00 Rod, magneto control	Buy now

Control



Ref	Part	
16	95380-05600 Nut, hexagon (663)	Buy now
17	663-48344-00 Cable end, remote control	Buy now
18	90468-18008 Clip 620436610000	Buy now
19	682-41237-50 Joint, link 2	Buy now
22	6H3-41213-01 Cam, accele	Buy now
23	90206-10M04 Washer, wave (676)	Buy now
26	6K5-44120-01 Handle gear shift assembly S	Buy now
26	6K5-44120-11 Handle gear shift assembly L	Buy now
26	69D-44120-20 Handle gear shift assembly X	Buy now
27	648-42715-00 Bushing 2	Buy now
28	93501-04M02 Ball (697)	Buy now
29	90501-12082 Spring 6484411600	Buy now
30	6H3-44117-00-94 Bracket 1	Buy now
30	6J2-44117-01-94 Bracket FOR OMAN	Buy now
31	97013-06020 Bolt(62y)	Buy now


Control



E1

Ref	Part	
32	92903-06600 Washer, plain (646)	Buy now
33	90386-07M58 Bush(6h1)	Buy now
34	92990-08200 Ybs66-8 washer, plain	Buy now
35	91490-20012 Pin, cotter (648)	Buy now
36	6H3-44121-01 Lever, shift rod	Buy now
38	90202-07M07 Washer, plate (688)	Buy now
39	688-44122-00 Bushing, shift rod lever	Buy now
41	6H3-48538-00 Clamp, cable	Buy now


Crankshaft. Piston



A7

Ref	Part	
1	6H3-15359-00-94 Housing, oil seal	Buy now
2	93102-30M23 Oil seal (6h3)	Buy now
3	93106-18M01 Oil seal (6h3)	Buy now
4	93210-65M50 O-ring	Buy now
5	97095-06020 Bolt(7u8)	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	69D-11400-00 Crankshaft assembly	Buy now
8	6K5-11401-00 Crank sub-assembly 1	Buy now
9	6K5-11412-00 Crank 1	Buy now
10	6K5-11422-00 Crank 2	Buy now
11	6K5-11651-00 Rod, connecting	Buy now
12	6K5-11681-00 Pin, crank 1	Buy now
13	90209-27M11 Washer	Buy now
14	93310-527W1 Bearing, cylindrical(6k5)	Buy now
15	6K5-11402-00 Crank sub-assembly 2	Buy now


Crankshaft. Piston



A7

Ref	Part	
17	6H3-11432-00 Crank 3	Buy now
22	6K5-11403-00 Crank sub-assembly 3	Buy now
24	6K5-11442-00 Crank 4	Buy now
29	93311-636U6 Bearing, needle (6h3)	Buy now
30	93102-36M24 Oil seal(52w)	Buy now
31	93440-49M04 Circlip (6h3)	Buy now
32	93332-000UE Bearing	Buy now
33	93306-306V1 Bearing(6h2)	Buy now
34	6H3-11515-00 Seal, labyrinth	Buy now
35	90254-03002 Pin, spring	Buy now
36	93210-46M16 O-ring (688)	Buy now
37	6K5-11631-03-95 Piston (std)	Buy now
37	6K5-11635-03 Piston (0.25mm o/s) AP	Buy now
37	6K5-11636-03 Piston (0.50mm o/s) AP	Buy now
38	6K5-11601-02 Piston ring set (std)	Buy now


Crankshaft. Piston



A7


Ref	Part	
38	6K5-11601-12 Piston ring set (1st o/s) AP	Buy now
38	6K5-11601-22 Piston ring set (2nd o/s) AP	Buy now
39	6H3-11633-00 Pin, piston	Buy now
40	688-11634-10 Clip, piston pin	Buy now
41	93603-18M09 Pin, dowel b (6h3)	Buy now
42	90201-20417 Washer, plate(663)	Buy now

Cylinder. Crankcase




Ref	Part	
3	688-11370-01 Check valve assembly	Buy now
4	650-11370-01 Check valve assembly	Buy now
5	624-14485-00 Pipe, joint	Buy now
6	93608-12063 Pin, dowel (626)	Buy now
7	90119-10005 Bolt, with washer	Buy now
8	90119-08M64 Bolt, with washer	Buy now
9	90445-07M44 Hose (I390)	Buy now
10	90467-06016 Clip (655)	Buy now
11	90445-07M02 Hose (I200)	Buy now
12	90445-07M45 Hose (I390)	Buy now
13	90445-07M82 Hose (I770)	Buy now
15	90464-07M05 Clamp (6g5)	Buy now
16	6H3-11325-01 Anode	Buy now
18	6H3-11328-00 Grommet, anode	Buy now
19	90119-06023 Bolt, with washer	Buy now

Cylinder. Crankcase




Ref	Part	
20	6K5-11119-01 Hanger, engine	Buy now
21	90101-08002 Bolt	Buy now
22	90340-14M00 Plug, straight screw(62y)	Buy now
23	90430-14115 Gasket (663)	Buy now
25	6H3-11181-A1 Gasket, cylinder head 1	Buy now
27	6H3-11193-A1 Gasket, head cover 1	Buy now
28	90119-08MA5 Bolt, with washer	Buy now
29	90116-08M69 Bolt, stud	Buy now
30	90179-08M34 Nut	Buy now
31	6H3-12411-10 Thermostat	Buy now
32	6H3-12413-00-1S Cover, thermostat	Buy now
33	6H3-12414-A1 Gasket, cover	Buy now
34	90119-06MA3 Bolt, with washer	Buy now
35	6H3-41111-01-1S Inner cover, exhaust	Buy now
36	6H3-41112-A0 Gasket, exhaust inner cover	Buy now

Cylinder. Crankcase




Ref	Part	
37	6H3-41113-02-1S Outer cover, exhaust	Buy now
38	6H3-41114-A0 Gasket, exhaust outer cover	Buy now
39	90119-06MA5 Bolt, with washer	Buy now
40	663-24312-01 Pipe 1	Buy now
41	90467-08004 Clip, pipe 6162435600	Buy now
42	94702-00160 Plug, spark (b8hs-10)	Buy now
42	94702-00247 Plug, spark (br8hs-10) FOR CARIB,CHINA	Buy now

Electrical 1




Ref	Part	
1	97013-06012 Bolt(gh1)	Buy now
2	92903-06600 Washer, plain (646)	Buy now
3	6K5-82531-00 Wire, lead	Buy now
4	6H4-85411-00 Overheat warning lamp	Buy now
5	6H4-85415-00 Mark, Signal Lamp	Buy now
6	6H3-85542-00-94 Bracket	Buy now
7	90105-06M14 Bolt (6e0)	Buy now
8	90387-06M43 Coller (6e9)	Buy now
9	90480-13M24 Grommet (6e9)	Buy now
10	6H3-81922-00 Grommet	Buy now
11	90116-06M07 Bolt, stud (688)	Buy now
12	95380-06700 Nut	Buy now
13	92990-06200 Ybs66-6 washer, plain	Buy now
14	92990-06100 Washer(6a1)	Buy now
15	90464-04M12 Clamp (6h3)	Buy now

Electrical 1




Ref	Part	
16	6H3-85540-11 C.d.i. unit assembly	Buy now
17	97880-06025 Screw, pan head(6b0)	Buy now
18	92990-06600 Washer, plain (646)	Buy now
19	90464-08M07 Clamp	Buy now
20	90464-12M17 Clamp(6j8)	Buy now
21	90464-07M10 Clamp (6h3)	Buy now
22	6H3-81916-00 Cover, terminal	Buy now
23	97885-06012 Screw, pan head(62j)	Buy now
24	92995-06600 Washer, plain (646)	Buy now
25	6H3-85570-10 Ignition coil assembly	Buy now
26	97013-06025 Bolt(62y)	Buy now
28	663-82370-01 Plug cap assembly	Buy now
28	6G1-82370-21 Plug cap assembly FOR CARIB	Buy now
29	90465-06M90 Clamp	Buy now
31	92903-06100 Washer(6a1)	Buy now

Electrical 1



Ref	Part	
32	688-82560-10 Thermo switch assembly	Buy now
33	90446-10M02 Tube (6e5)	Buy now


Electrical 2



C6

Ref	Part	
1	6G1-81970-61 Rectifier assembly	Buy now
2	6G1-82151-00 Fuse (10a)	Buy now
3	97880-05025 Screw, panhead (a93)	Buy now
4	92990-05600 Washer, plain (646)	Buy now
5	6K5-82590-00 10 -	Buy now
6	688-81950-10 Relay assembly	Buy now
7	97013-06016 Bolt, hexagon deep recess	Buy now
8	92903-06600 Washer, plain (646)	Buy now
9	6H3-82164-00 Case 2	Buy now
10	90464-15M11 Clamp (3y2)	Buy now
11	6H3-82105-01 Battery cable	Buy now
12	6H3-82117-00 Wire, lead	Buy now
13	688-82594-00 Clamp	Buy now

Electrical 3




6K50200-4110

C7

Ref	Part	
1	6G1-81970-61 Rectifier assembly	Buy now
2	6G1-82151-00 Fuse (10a)	Buy now
3	97880-05025 Screw, panhead (a93)	Buy now
4	92990-05600 Washer, plain (646)	Buy now
5	688-81950-10 Relay assembly	Buy now
6	97013-06016 Bolt, hexagon deep recess	Buy now
7	92903-06600 Washer, plain (646)	Buy now
8	6H3-82164-00 Case 2	Buy now
9	90464-15M11 Clamp (3y2)	Buy now
10	6H3-82105-01 Battery cable	Buy now
11	6H3-82117-00 Wire, lead	Buy now
12	6H3-82590-01 Wire harness assembly	Buy now
13	97013-06012 Bolt(gh1)	Buy now
15	688-82594-00 Clamp	Buy now
16	6H3-86110-02 Solenoid	Buy now

Electrical 3




6K50200-4110

C7


Ref	Part	
17	6H3-86116-00 Wire, Pull	Buy now
18	91690-30010 Pin, spring (663)	Buy now
21	93210-03261 O-ring (663)	Buy now
22	90465-18147 Clamp	Buy now

Electrical 4



Ref	Part	
1	6H3-82510-02 Main switch assembly	Buy now
2	676-82577-00 Cap, key	Buy now
3	688-82575-01 Engine stop switch assembly	Buy now
4	682-82556-00 Lanyard, stop switch	Buy now
5	6H3-82540-00 Neutral switch assembly	Buy now
6	6H3-82554-00 Stay, neutral switch	Buy now
7	663-82555-01 Plate	Buy now
8	97885-06012 Screw, pan head(62j)	Buy now
9	92995-06100 Washer(6a1)	Buy now
10	697-8252E-01-4D Cover, Main Switch	Buy now
11	697-8252F-01-4D Cover, main switch 2	Buy now
12	97880-06025 Screw, pan head(6b0)	Buy now
13	92990-06100 Washer(6a1)	Buy now
14	97013-06030 Bolt	Buy now
15	92903-06100 Washer(6a1)	Buy now


Electrical 4



D1


Ref	Part	
16	97013-06020 Bolt(62y)	Buy now

Fuel




Ref	Part	
1	6G1-24304-02 Fuel pipe joint comp. 1	Buy now
2	97095-06025 Bolt	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	69D-24311-00 Pipe, fuel 1	Buy now
5	90465-11M10 Clamp	Buy now
6	90464-10M59 Clamp	Buy now
7	61A-24560-04 Filter assembly	Buy now
8	61A-24521-00 Cup, filter	Buy now
9	65L-24531-01 Nut	Buy now
10	61A-24564-00 O-ring	Buy now
11	61A-24577-01 Spring	Buy now
12	61A-24563-00 Element, filter	Buy now
13	61A-24469-00 Float, water level	Buy now
14	65L-24558-00 Holder, filter	Buy now
15	97095-06016 Bolt, hexagon deep recess	Buy now

Fuel




Ref	Part	
16	92995-06100 Washer(6a1)	Buy now
17	90201-06068 Washer,plate (6k8)	Buy now
18	69D-24566-01 Bracket, filter	Buy now
19	97095-06014 Bolt(gj3)	Buy now
23	69D-24312-00 Pipe 2	Buy now
25	90465-08M83 Clamp	Buy now
26	692-24410-00 Fuel pump assembly	Buy now
27	6A0-24413-00 Cover, pump	Buy now
28	692-24411-00 Diaphragm	Buy now
29	648-24434-01 Gasket, body	Buy now
30	95380-03600 Nut (6g8)	Buy now
31	663-24411-00 Diaphragm	Buy now
32	648-24435-02 Gasket, body 2	Buy now
33	98503-05028 Ybs86-530 screw,panhead	Buy now
34	92990-05100 Ybs67-5 washer, spring	Buy now

Fuel




Ref	Part	
35	6A0-24421-01 Valve, check	Buy now
36	6A0-14325-00 Screw, pan head	Buy now
37	6A0-24412-02 Body 1	Buy now
38	650-24431-A0 Gasket,fuel pump	Buy now
39	97095-06040 Bolt (682)	Buy now
41	90445-09072 Hose (I1500)	Buy now
42	90467-08004 Clip, pipe 6162435600	Buy now
43	688-24378-00 Pipe, joint	Buy now
44	6H3-24313-00 Pipe, fuel 2	Buy now
45	90445-09220 Hose (I1500)	Buy now
46	6H3-24314-00 Pipe 4	Buy now
48	656-W2810-02 Tool kit	Buy now

Fuel Tank




Ref	Part	
1	6YJ-24201-00 Fuel tank comp. AP	Buy now
1	6YJ-24201-10 Fuel Tank assembly (24L) AP FOR CHINA	Buy now
2	6YJ-24610-01 Cap assembly	Buy now
3	6Y1-24260-12 Fuel meter assembly FOR CHINA	Buy now
3	6YJ-24260-00 Fuel meter assembly	Buy now
4	98586-05016 Screw, pan head	Buy now
5	6Y1-24329-00 Seal	Buy now
6	6Y1-24268-00 Gasket, fuel meter	Buy now
7	6YJ-24167-00 Strainer	Buy now
8	61J-24306-02 Fuel pipe comp. 1 AP	Buy now
9	90445-11M06 Hose (I3000)	Buy now
10	61J-24360-00 Primer pump assembly	Buy now
11	90445-11M05 Hose (I1000)	Buy now
12	650-24351-51 Band 1	Buy now
13	6G1-24305-03 Fuel pipe joint comp. 2	Buy now

Fuel Tank




Ref	Part	
14	93210-08287 O-ring (655)	Buy now
15	6Y1-24305-04 Fuel pipe joint comp. 2	Buy now

Generator




Ref	Part	
1	6K5-85550-10 Rotor assembly	Buy now
1	6K5-85550-A0 Rotor assembly	Buy now
2	6H3-85510-A1 Stator assembly	Buy now
3	6H3-85520-00 Charge coil assembly	Buy now
4	663-85518-00 Joint, ball	Buy now
5	97902-05125 Screw, with washer(6m6)	Buy now
6	6H3-85533-A0 Lighting coil assembly	Buy now
7	97013-06030 Bolt	Buy now
8	92903-06600 Washer, plain (646)	Buy now
9	90280-05015 Key, woodruff	Buy now
10	90170-20137 Nut, hexagon(663)	Buy now
11	90201-21M18 Washer, plate (663)	Buy now
12	6H4-41611-00 Retainer, magneto base	Buy now
13	6H3-41612-00 Retainer, magneto base 2	Buy now
14	97885-06012 Screw, pan head(62j)	Buy now

Generator



Ref	Part	
15	92995-06600 Washer, plain (646)	Buy now
16	6H3-41612-10 Retainer, magneto base 2	Buy now
17	6K5-41618-00 Washer, magneto	Buy now
18	6K5-81332-00 Plate, Timing	Buy now
18	6K5-81332-60 Plate, timing	Buy now
19	97885-06010 Screw pan head	Buy now


Intake



B2


Ref	Part	
1	6H2-13610-00 Reed valve assembly	Buy now
2	688-W0004-00 Reed set	Buy now
3	97880-05016 Screw, pan head(6b0)	Buy now
4	92990-05600 Washer, plain (646)	Buy now
5	6H3-13641-03-94 Manifold, intake 1	Buy now
6	6H3-13621-A1 Gasket, valve seat	Buy now
7	6H3-13624-00-94 Plate, reed valve	Buy now
8	6H3-13622-A1 Gasket, valve seat	Buy now
9	90119-06MA3 Bolt, with washer	Buy now
10	97095-06095 Bolt, hexagon deep recess	Buy now
11	6H3-14198-A1 Gasket	Buy now
12	6H3-41217-00 Rod, accel lever	Buy now
13	6H3-41257-00 Rod, choke link 2	Buy now
14	661-41262-02 Joint, choke lever	Buy now
15	6H3-41271-00 Knob, choke	Buy now

Intake




Ref	Part	
16	689-41273-00 Grommet	Buy now
18	6H3-14413-10 Stay	Buy now
19	6H3-14440-02 Silencer assembly, intake	Buy now
20	6H3-14457-01 Seal	Buy now
21	97885-06045 Screw, pan head(6b0)	Buy now
22	90209-06M05 Washer (688)	Buy now
23	6K5-14488-00 Label, caution	Buy now

Lower Casing. Drive 1




Ref	Part	
1	69D-45300-00-4D Lower unit assembly S	Buy now
1	69D-45300-10-4D Lower unit assembly L	Buy now
1	69D-45300-20-4D Lower Unit assembly X	Buy now
2	6H1-45301-03-4D Lower casing set	Buy now
3	93315-325V1 Bearing, needle (688)	Buy now
4	688-45536-01 Sleeve, drive shaft	Buy now
5	688-45587-01-10 Shim (t:0.10mm) UR	Buy now
5	688-45587-01-12 Shim (t:0.12mm) UR	Buy now
5	688-45587-01-15 Shim (t:0.15mm) UR	Buy now
5	688-45587-01-18 Shim (t:0.18mm) UR	Buy now
5	688-45587-01-30 Shim (t:0.30mm) UR	Buy now
5	688-45587-01-40 Shim (t:0.40mm) UR	Buy now
5	688-45587-01-50 Shim (t:0.50mm) UR	Buy now
6	93332-000U3 Brg,tapered roller 50mm (688)	Buy now
7	688-45567-01-10 Shim (t:0.10mm) UR	Buy now

Lower Casing. Drive 1




Ref	Part	
7	688-45567-01-12 Shim (t:0.12mm) UR	Buy now
7	688-45567-01-15 Shim (t:0.15mm) UR	Buy now
7	688-45567-01-18 Shim (t:0.18mm) UR	Buy now
7	688-45567-01-30 Shim (t:0.30mm) UR	Buy now
7	688-45567-01-40 Shim (t:0.40mm) UR	Buy now
7	688-45567-01-50 Shim (t:0.50mm) UR	Buy now
8	93332-000W7 Bearing(6b0)	Buy now
9	90340-08002 Plug, straight screw	Buy now
10	688-45341-10 Plug, drain	Buy now
11	90430-08020 Gasket	Buy now
12	6H1-45214-00 Cover, water inlet	Buy now
13	6H1-45215-00 Cover, water inlet	Buy now
14	90151-05M00 Screw, countersunk(692)	Buy now
15	90185-05002 Nut nylon (sus)(ex4)	Buy now
16	688-45321-00 Plate	Buy now

Lower Casing. Drive 1




Ref	Part	
17	93210-49046 O-ring (620)	Buy now
18	93106-09014 Oil seal	Buy now
19	97095-06016 Bolt, hexagon deep recess	Buy now
20	92995-06600 Washer, plain (646)	Buy now
21	6J8-45378-00 Nipple, hose (plug)	Buy now
22	688-44311-01 Housing, water pump 1	Buy now
23	69D-44322-00 Insert, cartridge	Buy now
24	688-44315-A0 Gasket, water pump 1	Buy now
25	688-44352-03 Impeller	Buy now
26	90280-04M04 Key, woodruff (688)	Buy now
27	688-44341-01-94 Housing, water pump set	Buy now
28	93101-25M03 Oil seal	Buy now
29	93210-46044 O-ring	Buy now
30	688-44316-A0 Gasket, water pump 2	Buy now
31	688-44323-40 Outer plate, cartridge	Buy now

Lower Casing. Drive 1



Ref	Part	
32	688-44324-A0 Gasket, cartridge Outer plate	Buy now
33	93604-10M03 Pin, dowel (688)	Buy now
34	90119-08M16 Bolt, with washer(6h0)	Buy now
35	90119-08M13 Bolt, with washer(6h0)	Buy now
36	69D-45501-00 Drive Shaft Comp. S	Buy now
36	69D-45501-10 Drive shaft comp. L	Buy now
36	69D-45501-20 Drive shaft comp. X	Buy now
37	6K5-45551-00 Pinion	Buy now
38	90170-16M01 Nut, hexagon (688)	Buy now
39	6K5-45560-00 Gear	Buy now
40	6H1-45611-01 Shaft, propeller	Buy now
41	6H1-45631-01 Clutch, dog	Buy now
42	93603-12M11 Pin, dowel(6h1)	Buy now
43	6H1-45634-02 Slide, shift	Buy now
44	90501-16M65 Spring, compression(6h1)	Buy now


Lower Casing. Drive 1



F7


Ref	Part	
45	93503-16003 Ball	Buy now
46	6H1-45668-00 Shaft, free 1	Buy now
47	6H1-45635-00 Plunger, shift	Buy now
48	90501-12M48 Spring (6h1)	Buy now
49	90201-03313 Washer, plate 8077743700	Buy now
50	90183-02M03 Nut, spring (6h1)	Buy now
51	90250-07M02 Pin, straight (688)	Buy now
52	688-45633-00 Ping, cross pin	Buy now
53	6H1-45641-01 Shifter	Buy now
54	6H1-44151-00 Cam, shift	Buy now
55	6H1-44144-00 Rod, shift 2	Buy now
56	93210-07003 O-ring (11m)	Buy now
57	99001-08600 Circlip(2r6)	Buy now
58	93450-07M00 Circlip (6e5)	Buy now
59	6H3-45571-00 Gear 2	Buy now

Lower Casing. Drive 1




Ref	Part	
60	688-45331-00-94 Housing, bearing	Buy now
61	93306-207U0 Brg,r-b 6207 72mm 280g (688)	Buy now
62	688-45577-01-10 Shim (t:0.10mm) UR	Buy now
62	688-45577-01-12 Shim (t:0.12mm) UR	Buy now
62	688-45577-01-15 Shim (t:0.15mm) UR	Buy now
62	688-45577-01-18 Shim (t:0.18mm) UR	Buy now
62	688-45577-01-30 Shim (t:0.30mm) UR	Buy now
62	688-45577-01-40 Shim (t:0.40mm) UR	Buy now
62	688-45577-01-50 Shim (t:0.50mm) UR	Buy now
63	688-45576-00 Washer, thrust 2	Buy now
64	93210-85M97 O-ring(6h1)	Buy now
65	93317-325U0 Brg,needle	Buy now
67	90282-04010 Key, strait(663)	Buy now
68	688-45383-02 Washer, claw	Buy now
69	688-45384-00 Nut	Buy now

Lower Casing. Drive 2




Ref	Part	
1	69D-45300-40-4D Lower Unit assembly L	Buy now
2	688-45311-06-4D Lower casing set	Buy now
3	93315-325V1 Bearing, needle (688)	Buy now
4	688-45536-01 Sleeve, drive shaft	Buy now
5	688-45587-01-10 Shim (t:0.10mm) UR	Buy now
5	688-45587-01-12 Shim (t:0.12mm) UR	Buy now
5	688-45587-01-15 Shim (t:0.15mm) UR	Buy now
5	688-45587-01-18 Shim (t:0.18mm) UR	Buy now
5	688-45587-01-30 Shim (t:0.30mm) UR	Buy now
5	688-45587-01-40 Shim (t:0.40mm) UR	Buy now
5	688-45587-01-50 Shim (t:0.50mm) UR	Buy now
6	93332-000U3 Brg,tapered roller 50mm (688)	Buy now
7	688-45567-01-10 Shim (t:0.10mm) UR	Buy now
7	688-45567-01-12 Shim (t:0.12mm) UR	Buy now
7	688-45567-01-15 Shim (t:0.15mm) UR	Buy now

Lower Casing. Drive 2




Ref	Part	
7	688-45567-01-18 Shim (t:0.18mm) UR	Buy now
7	688-45567-01-30 Shim (t:0.30mm) UR	Buy now
7	688-45567-01-40 Shim (t:0.40mm) UR	Buy now
7	688-45567-01-50 Shim (t:0.50mm) UR	Buy now
8	93332-000W7 Bearing(6b0)	Buy now
9	90340-08002 Plug, straight screw	Buy now
10	688-45341-10 Plug, drain	Buy now
11	90430-08020 Gasket	Buy now
12	6H1-45214-00 Cover, water inlet	Buy now
13	6H1-45215-00 Cover, water inlet	Buy now
14	90151-05M00 Screw, countersunk(692)	Buy now
15	90185-05002 Nut nylon (sus)(ex4)	Buy now
16	688-45321-00 Plate	Buy now
17	93210-49046 O-ring (620)	Buy now
18	93106-09014 Oil seal	Buy now

Lower Casing. Drive 2




Ref	Part	
19	97095-06016 Bolt, hexagon deep recess	Buy now
20	92995-06600 Washer, plain (646)	Buy now
21	688-44311-01 Housing, water pump 1	Buy now
22	69D-44322-00 Insert, cartridge	Buy now
23	688-44315-A0 Gasket, water pump 1	Buy now
24	688-44352-03 Impeller	Buy now
25	90280-04M04 Key, woodruff (688)	Buy now
26	688-44341-01-94 Housing, water pump set	Buy now
27	93101-25M03 Oil seal	Buy now
28	93210-46044 O-ring	Buy now
29	688-44316-A0 Gasket, water pump 2	Buy now
30	688-44323-40 Outer plate, cartridge	Buy now
31	688-44324-A0 Gasket, cartridge Outer plate	Buy now
32	93604-10M03 Pin, dowel (688)	Buy now
33	90119-08M16 Bolt, with washer(6h0)	Buy now

Lower Casing. Drive 2




Ref	Part	
34	90119-08M13 Bolt, with washer(6h0)	Buy now
35	69D-45501-10 Drive shaft comp. L	Buy now
36	6K5-45551-00 Pinion	Buy now
37	90170-16M01 Nut, hexagon (688)	Buy now
38	6K5-45560-00 Gear	Buy now
39	688-45611-00 Shaft, propeller	Buy now
40	688-45631-01 Clutch, dog	Buy now
41	688-45634-00 Slide, shift	Buy now
42	90501-16233 Spring compression(663)	Buy now
43	688-45635-00 Plunger, shift	Buy now
44	90250-07M02 Pin, straight (688)	Buy now
45	688-45633-00 Ping, cross pin	Buy now
46	663-44151-00 Cam, shift	Buy now
47	6K5-44144-00 Rod, shift	Buy now
48	93210-07003 O-ring (11m)	Buy now

Lower Casing. Drive 2




Ref	Part	
49	99001-08600 Circlip(2r6)	Buy now
50	6K5-45571-00 Gear	Buy now
51	688-45331-00-94 Housing, bearing	Buy now
52	93306-207U0 Brg,r-b 6207 72mm 280g (688)	Buy now
53	688-45577-01-10 Shim (t:0.10mm) UR	Buy now
53	688-45577-01-12 Shim (t:0.12mm) UR	Buy now
53	688-45577-01-15 Shim (t:0.15mm) UR	Buy now
53	688-45577-01-18 Shim (t:0.18mm) UR	Buy now
53	688-45577-01-30 Shim (t:0.30mm) UR	Buy now
53	688-45577-01-40 Shim (t:0.40mm) UR	Buy now
53	688-45577-01-50 Shim (t:0.50mm) UR	Buy now
54	688-45576-00 Washer, thrust 2	Buy now
55	93210-85M97 O-ring(6h1)	Buy now
56	93317-325U0 Brg,needle	Buy now
58	90282-04010 Key, strait(663)	Buy now

Lower Casing. Drive 2



Ref	Part	
59	688-45383-02 Washer, claw	Buy now
60	688-45384-00 Nut	Buy now

Lower Casing. Drive 3





69D0100-1200

B3


Ref	Part	
1	663-44367-00 Damper, water seal 3	Buy now
2	69D-44361-00 Tube, Water S	Buy now
2	69D-44361-10 Tube, water 1 L	Buy now
2	69D-44361-20 Tube, water 1 X	Buy now
3	90202-12060 Washer, plate(663)	Buy now
4	90430-12072 Gasket	Buy now
5	93606-12019 Pin, dowel (614)	Buy now
6	663-45376-00-94 Guide, seal damper	Buy now
7	688-45375-00 Damper, seal 2	Buy now
8	688-45371-02 Tab-trim	Buy now
9	90105-10M67 Bolt, hexagon (663)	Buy now
10	663-44366-00 Damper, water seal 2	Buy now
11	90480-19M06 Grommet (688)	Buy now
12	97780-40512 Screw, pan head tapping	Buy now
13	688-45987-01 Spacer	Buy now

Lower Casing. Drive 3



Ref	Part	
14	688-45997-01 Spacer 2	Buy now
15	90201-17M00 Washer, plate(6h1)	Buy now
16	90171-16011 Nut, castle (663)	Buy now
17	91490-40025 Pin, cotter (663)	Buy now
18	6E5-45941-00-EL Propeller (3x13x19-k) UR	Buy now
18	6E5-45943-00-EL Propeller (3x12-5/8"x21"-k) UR	Buy now
18	6E5-45945-01-EL Propeller (3x13-1/4x17-k) UR	Buy now
18	6E5-45947-00-EL Propeller (3x13-1/2x15-k) UR	Buy now
18	6E5-45949-00-EL Propeller (3x13-5/8"x13"-k) UR	Buy now
18	6E5-45952-00-EL Propeller (3x13"x23"-k) UR	Buy now
18	6E5-45954-00-EL Propeller (3x14"x11"-k) UR	Buy now
18	6E5-45956-00-EL Propeller (3x13"x25"-k) UR	Buy now
18	688-45930-02-98 Propeller (3x13x17) UR	Buy now
18	688-45932-60-98 Propeller (3x13-1/2"x14"-k) UR	Buy now
18	688-45970-03-98 Propeller (3x13"x19"-k) UR	Buy now

Lower Casing. Drive 3





69D0100-1200

B3

Ref	Part	
18	688-45972-02-98 Propeller (3x13"x21"-k) UR	Buy now
18	688-45974-02-98 Propeller (3x13"x23"-k) UR	Buy now
18	688-45976-01-98 Propeller (ss 3x13"x25"-k) UR	Buy now
18	688-45978-60-98 Propeller (3x13-1/2"x16"-k) UR	Buy now

Meter




6K50200-0270

C4

Ref	Part	
1	6Y5-W0080-12 Tachometer kit AP FOR CHINA	Buy now
2	6Y5-83540-14 Tachometer assembly WITHOUT OIL LAMP	Buy now
3	6Y5-83517-00 Bulb (12v-1.7w)	Buy now
4	6Y5-83536-10 Socket, meter	Buy now
5	6Y5-83523-00 Damper	Buy now
6	6Y5-83514-00 Plate, fitting	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	92990-05100 Ybs67-5 washer, spring	Buy now
9	6Y5-83553-00 Wire, lead (l=2.5m) AP FOR CHINA	Buy now
10	1E6-82151-00 Fuse (10a)	Buy now

Remote Control Assy




6J83664-2230

C1

Ref	Part	
1	703-48230-15 Remote control assembly (7p) AP	Buy now
2	703-48261-11 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now
15	703-48243-00 Bushing 3	Buy now


Remote Control Assy



C1

Ref	Part	
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-48226-00 Plate, stopper	Buy now
26	703-48222-00 Grip, control lever SINGLE	Buy now
27	703-48223-00 Lock, neutral	Buy now
28	703-48225-00 Cover	Buy now
29	703-48219-00 Cover, lead	Buy now
30	703-48281-00 Screw, flat head	Buy now


Remote Control Assy



C1

Ref	Part	
31	703-48282-00 Screw	Buy now
32	97380-08030 Bolt, hexagon (fj1)	Buy now
33	92990-08600 Washer, plain (663)	Buy now
34	98580-04010 Screw, pan head (e56)	Buy now
35	98580-04006 Screw, pan head (7h3)	Buy now
36	98580-05010 Screw, pan head(62x)	Buy now
37	98580-03015 Screw, pan head (n151)	Buy now
38	703-48291-10 Screw	Buy now
39	95380-06600 Nut(661)	Buy now
40	703-48293-10 Spacer, remote control SINGLE	Buy now
41	701-48287-00 Washer 1	Buy now
42	703-48215-00 Graphic	Buy now
43	703-82510-33 Main switch assembly	Buy now
44	703-82577-00 Cap, key	Buy now
45	703-82531-00 Wire, lead	Buy now


Remote Control Assy



C1

Ref	Part	
46	688-82575-01 Engine stop switch assembly	Buy now
47	682-82556-00 Lanyard, stop switch	Buy now
48	688-82586-21 Extension, wire harness L)5M (7P)	Buy now
49	703-82540-00 Neutral switch assembly	Buy now
50	703-83383-02 Buzzer	Buy now
51	703-48284-00 Grommet	Buy now
52	703-82591-00 Band	Buy now
53	703-82592-00 Band	Buy now
54	703-48224-00 Cover, control lever WITHOUT PT/T SW.	Buy now
55	703-48221-00 Grip	Buy now
56	703-48152-00 Knob, free accel	Buy now
57	703-48212-00 Rear housing	Buy now
58	703-48213-00 Back, panel	Buy now
59	703-48271-00 Arm, shift	Buy now
60	703-48211-01 Housing,1	Buy now



Remote Control Assy



C1

Ref	Part	
61	703-48232-00 Drive gear	Buy now

Remote Control Box




67M0100-8280

B7


Ref	Part	
1	703-48230-15 Remote control assembly (7p) AP	Buy now
2	701-48320-20 Cable, Remote Control L=13F UR	Buy now
2	701-48320-50 Cable, Remote Control L=15F UR	Buy now

Repair Kit 1




Ref	Part	
1	69D-W0001-00 Power head gasket kit	Buy now
2	6H3-11181-A1 Gasket, cylinder head 1	Buy now
3	90430-14115 Gasket (663)	Buy now
4	6H3-11193-A1 Gasket, head cover 1	Buy now
5	6H3-12414-A1 Gasket, cover	Buy now
6	6H3-41112-A0 Gasket, exhaust inner cover	Buy now
7	6H3-41114-A0 Gasket, exhaust outer cover	Buy now
8	93102-36M24 Oil seal(52w)	Buy now
9	93210-46M16 O-ring (688)	Buy now
10	93102-30M23 Oil seal (6h3)	Buy now
11	93106-18M01 Oil seal (6h3)	Buy now
12	93210-65M50 O-ring	Buy now
13	6H3-13621-A1 Gasket, valve seat	Buy now
14	6H3-14198-A1 Gasket	Buy now
15	6G1-14984-00 Gasket, float chamber	Buy now

Repair Kit 1




Ref	Part	
16	61A-24564-00 O-ring	Buy now
17	650-24431-A0 Gasket, fuel pump	Buy now
18	6H3-45113-A0 Gasket, upper casing	Buy now
19	6H3-13622-A1 Gasket, valve seat	Buy now
20	6H3-W0093-02 Carburetor repair kit	Buy now
22	676-14966-00 Rubber cap	Buy now
23	6H3-14590-01 Needle valve assembly	Buy now
24	663-14159-00 Clip	Buy now
25	676-14186-00 Pin, valve	Buy now
26	6G1-14985-00 Float comp.	Buy now
27	688-14548-00 Pin, arm	Buy now
29	97980-04114 Screw, pan head(ga5)	Buy now
30	93210-04230 O-ring (371)	Buy now
31	663-14126-00 Packing	Buy now
32	688-14126-00 Packing	Buy now

Repair Kit 1




Ref	Part	
33	692-14923-00 Screw, adjusting	Buy now
34	93210-15M52 O-ring (6e9)	Buy now

Repair Kit 2




Ref	Part	
1	69D-W0001-20 Lower unit gasket kit	Buy now
2	6H3-45114-A1 Gasket, upper casing	Buy now
3	6H3-45123-00 Gasket, muffer	Buy now
4	90430-08020 Gasket	Buy now
5	93210-49046 O-ring (620)	Buy now
6	93106-09014 Oil seal	Buy now
7	688-44315-A0 Gasket, water pump 1	Buy now
8	688-44324-A0 Gasket, cartridge Outer plate	Buy now
9	688-44316-A0 Gasket, water pump 2	Buy now
10	93210-46044 O-ring	Buy now
11	93210-85M97 O-ring(6h1)	Buy now
12	93101-25M03 Oil seal	Buy now
13	90430-12072 Gasket	Buy now
14	663-44366-00 Damper, water seal 2	Buy now
15	69D-W0078-00 Water pump repair kit	Buy now

Repair Kit 2



Ref	Part	
16	69D-44322-00 Insert, cartridge	Buy now
17	688-44352-03 Impeller	Buy now
19	688-44323-40 Outer plate, cartridge	Buy now
23	90119-08M16 Bolt, with washer(6h0)	Buy now
24	90119-08M13 Bolt, with washer(6h0)	Buy now
25	90280-04M04 Key, woodruff (688)	Buy now


Starter



B7

Ref	Part	
1	692-W1571-02 Starter assembly	Buy now
2	692-15711-00 Case, starter	Buy now
3	648-15773-00 Stay 3	Buy now
4	663-15739-00 Washer, thrust 2	Buy now
5	663-15713-00 Spring, starter	Buy now
6	663-15714-01 Drum, sheave	Buy now
7	663-15764-00 Collar	Buy now
8	663-15741-02 Pawl, drive	Buy now
9	663-15754-00 Bushing	Buy now
10	663-15726-01 Washer, flat 1	Buy now
11	663-15744-00 Circlip	Buy now
12	663-15715-00 Spring, drive plate	Buy now
13	663-15716-01 Drive, plate	Buy now
14	663-15734-01 Spring, return	Buy now
15	663-15719-00 Washer, thrust	Buy now


Starter



B7

Ref	Part	
16	92903-06100 Washer(6a1)	Buy now
17	97303-06016 Bolt, hexagon deep recess	Buy now
18	663-15752-00 Roller, wire	Buy now
19	663-15753-00 Bushing 1	Buy now
20	663-15791-00 Washer, lock	Buy now
22	97303-06025 Bolt, hexagon	Buy now
23	689-15755-01 Handle, starter	Buy now
24	* item_description	Buy now
25	6F5-15779-02 Cover	Buy now
26	97013-08012 Bolt(62e)	Buy now
27	92903-08100 Ybs67-8 washer, spring	Buy now
28	92903-08600 Washer, plain (663)	Buy now
29	90119-08M28 Bolt, with washer	Buy now
30	90119-08M32 Bolt, with washer	Buy now
31	90385-12M04 Bushing (6f5)	Buy now


Starter



B7

Ref	Part	
32	90387-08M05 Collar (663)	Buy now
33	6K5-15771-00-94 Stay 1	Buy now
34	97013-06025 Bolt(62y)	Buy now
35	92903-06600 Washer, plain (646)	Buy now
36	6K5-15772-00-94 Stay 2	Buy now
37	97013-06055 Bolt(64d)	Buy now
39	6K5-15773-01 Stay 3	Buy now
40	6K5-15758-01-94 Guide wire	Buy now
41	6A0-82317-00 Damper, ignition coil	Buy now
42	624-42542-00 Collar	Buy now
43	90119-06M65 Bolt, with washer	Buy now
44	6K5-15762-00 Seal, rubber 2	Buy now
45	697-15789-00 Damper	Buy now
46	6K5-15723-00 Pulley, starter	Buy now
47	6K5-15770-01 Cable comp., starter stop	Buy now


Starter



B7

Ref	Part	
48	97095-06012 Bolt(gh1)	Buy now
49	92995-06600 Washer, plain (646)	Buy now
50	663-15735-01 Guide, cam	Buy now
51	90506-08M23 Spring, tension(6k5)	Buy now
52	663-15794-00 Stopper	Buy now
53	90508-12015 Spring torsion 616436420000	Buy now
54	90149-05095 Screw(663)	Buy now
55	663-15736-00 Ring, retaining 1	Buy now
56	90468-18008 Clip 620436610000	Buy now
57	92903-06200 Ybs66-6 washer, plain	Buy now
58	91490-16012 Pin, cotter (e57)	Buy now
59	6K5-15774-00 Stay 4	Buy now
60	97013-06012 Bolt(gh1)	Buy now
61	90465-06M90 Clamp	Buy now


Starting Motor



D2

Ref	Part	
1	6H3-81800-11 Starting motor assembly	Buy now
2	689-81857-11 Pinion stopper set	Buy now
3	6H3-81807-10 Pinion assembly	Buy now
4	6H3-81830-10 Front cover assembly	Buy now
5	689-81831-00 Metal, front	Buy now
6	689-81847-11 O-ring	Buy now
7	689-81809-11 Washer kit	Buy now
8	689-81850-12 Armature assembly	Buy now
9	6H3-81810-10 Stator assembly	Buy now
10	689-81840-11 Brush holder assembly	Buy now
11	689-81812-11 Brush 2	Buy now
12	689-81811-11 Brush 1	Buy now
13	689-81813-10 Spring, brush	Buy now
14	6H3-81820-11 Rear cover assembly	Buy now
15	689-81826-10 Bolt	Buy now


Starting Motor



D2

Ref	Part	
16	97013-08035 Bolt	Buy now
17	92903-08600 Washer, plain (663)	Buy now
18	97013-06025 Bolt(62y)	Buy now
19	92903-06600 Washer, plain (646)	Buy now
20	97013-08016 Bolt, hexagon	Buy now


Steering



D5

Ref	Part	
1	663-42111-02-4D Handle, steering	Buy now
1	692-42111-21-4D Handle, Steering PULL TO OPEN TYPE	Buy now
2	664-42119-00 Grip, steering handle	Buy now
3	6F6-42177-A0 Rubber, handle	Buy now
4	6K5-42137-00 Indicator, throttle	Buy now
5	90269-02M09 Rivet(615)	Buy now
6	90149-05M13 Screw, countersunk	Buy now
7	92903-10600 Washer, plate	Buy now
8	90501-23215 Spring (655)	Buy now
9	90386-08032 Bushing (650)	Buy now
10	663-42115-00 Shaft, steering handle	Buy now
10	692-42115-00 Shaft, steering handle PULL TO OPEN TYPE	Buy now
11	663-42138-00 Lever, throttle	Buy now
12	90254-03003 Pin, spring	Buy now
13	663-42135-01 Housing, throttle lever	Buy now


Steering



D5

Ref	Part	
14	663-42133-01 Gasket	Buy now
15	663-42134-03-94 Cover, throttle lever	Buy now
16	93700-06M03 Nipple, grease(6a1)	Buy now
17	97885-06008 Screw, pan head(6a3)	Buy now
18	97885-05012 Screw,pan head (646)	Buy now
19	692-26301-03 Throttle cable assembly	Buy now
20	692-42121-02-4D Bracket	Buy now
21	90101-12M06 Bolt	Buy now
22	92990-12200 Ybs66-12 washer,plain	Buy now
23	90386-12089 Bushing(663)	Buy now
24	90202-12092 Washer, plate(663)	Buy now
25	90201-12537 Washer, plate(663)	Buy now
26	90206-12054 Washer, wave(663)	Buy now
27	90185-12058 Nut, nylon(663)	Buy now
28	697-44113-00 Cam plate, handle	Buy now


Steering



D5

Ref	Part	
29	6K5-44191-00 Indicator,shift	Buy now
30	97013-06016 Bolt, hexagon deep recess	Buy now
31	92903-06100 Washer(6a1)	Buy now
32	692-44159-01 Handle, gear shift 2	Buy now
33	663-44173-00 Lever, shift control	Buy now
34	90501-16M17 Spring (697)	Buy now
35	93515-32M01 Ball (697)	Buy now
36	90386-10009 Bushing 6484418600	Buy now
37	90201-10120 Washer, plate	Buy now
38	90185-10051 Nut, self-locking	Buy now
39	90387-12M30 Collar (697)	Buy now
40	90201-12M34 Washer (692)	Buy now
41	6H3-42191-01 Rod 1	Buy now
42	90386-06088 Bushing(663)	Buy now
43	6H3-42192-00 Rod 2	Buy now


Steering



D5


Ref	Part	
44	700-48339-00 Nut, cable end	Buy now
45	92990-06600 Washer, plain (646)	Buy now
46	91490-25012 Pin, cotter	Buy now
47	663-42518-00 Shaft, friction	Buy now
48	67G-42528-00 Plate, Friction	Buy now
49	97080-06035 Bolt(j52)	Buy now
50	90175-06003 Nut, wing (f87)	Buy now
51	69D-42515-00 Rod, Steering Link	Buy now
52	92990-08600 Washer, plain (663)	Buy now
53	90185-08057 Nut, nylon (6j8)	Buy now
54	97095-08030 Bolt, hexagon (fj1)	Buy now
55	92995-08600 Washer, plain (663)	Buy now
56	663-42126-01 Friction, steering handle	Buy now
57	90101-06M27 Bolt	Buy now
60	6K5-82575-03 Engine stop switch assembly	Buy now

Steering



Ref	Part	
61	682-82556-00 Lanyard, stop switch	Buy now
62	689-8257Y-00 Cap	Buy now
63	90464-08M07 Clamp	Buy now

Steering Guide




6880700-9190

B6

Ref	Part	
1	688-61350-10 Steering guide attachment kit AP	Buy now
2	688-61351-10 Rod, steering link	Buy now
3	90201-10M20 Washer, plate (663)	Buy now
4	90185-09M01 Nut, nylon (663)	Buy now
5	90170-09M03 Nut (689)	Buy now
6	90387-10M42 Coller (688)	Buy now
7	90201-10M63 Washer, plate	Buy now
8	6E5-61355-00 Bolt	Buy now
9	6E5-43145-01 Cap, clamp bracket	Buy now
10	93210-16275 O-ring	Buy now

Top Cowling




69D1100-2010

A4


Ref	Part	
4	663-42662-00 Damper	Buy now
5	6H3-42652-00 Hook 2	Buy now
6	97095-06016 Bolt, hexagon deep recess	Buy now
7	92995-06100 Washer(6a1)	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	90266-06009 Rivet (697)	Buy now
13	6H3-42615-00 Seal	Buy now
14	6K5-15761-00 Seal, rubber 1	Buy now
15	6K5-W0070-H0 Graphic Set	Buy now
16	6K5-42678-H0 Graphic, rear	Buy now
17	677-13437-08 1-	Buy now
18	69D-42677-H0 Graphic, Front	Buy now

Upper Casing



Ref	Part	
1	6H3-45111-01-4D Casing, Upper S	Buy now
1	6H3-45111-11-4D Casing, upper L/X	Buy now
2	93606-12019 Pin, dowel (614)	Buy now
3	6H3-45155-00 Cap	Buy now
4	90119-08M81 Bolt, with washer	Buy now
5	6H3-41137-01-94 Guide, exhaust	Buy now
7	6H3-45113-A0 Gasket, upper casing	Buy now
8	90119-08M79 Bolt, hexagon (fj1)	Buy now
9	97075-08035 Bolt(70w)	Buy now
10	92995-08100 Ybs67-8 washer, spring	Buy now
11	6H2-41131-00-5B Manifold, ext. 1	Buy now
12	97075-08030 Bolt, hexagon (fj1)	Buy now
14	6H3-14711-00-5B Muffler 1 S	Buy now
14	6H3-14711-10-5B Muffler 1 L/X	Buy now
15	6H3-45127-00 Seal 1	Buy now

Upper Casing



F5

Ref	Part	
16	6H3-45123-00 Gasket, muffler	Buy now
17	6H3-45114-A1 Gasket, upper casing	Buy now
20	6H3-14737-00 Damper, Muffler S	Buy now
20	6H3-14737-10 Damper, muffler L/X	Buy now
21	688-45211-01-4D Extension X	Buy now
21	696-45211-01-4D Extension S/L	Buy now
23	90116-10M31 Bolt, stud(6a3) S/L	Buy now
23	90116-10M05 Bolt, stud (688) X	Buy now
24	90119-08M85 Bolt, with washer S/L	Buy now
24	90119-08M86 Bolt, with washer(62x) X	Buy now
25	95380-10600 Nut(624)	Buy now
26	92990-10100 Ybs67-10 washer, spring	Buy now
27	92990-10600 Washer, plate	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.