



Yamaha F15AEP 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

| | |
|------------------------------|----|
| BOTTOM COWLING | 3 |
| BRACKET 1 | 6 |
| BRACKET 2 | 9 |
| CARBURETOR | 12 |
| CONTROL | 15 |
| CRANKSHAFT. PISTON | 18 |
| CYLINDER. CRANKCASE 1 | 20 |
| CYLINDER. CRANKCASE 2 | 22 |
| ELECTRICAL 1 | 23 |
| ELECTRICAL 2 | 25 |
| FUEL | 28 |
| FUEL TANK | 30 |
| GENERATOR | 31 |
| INTAKE | 32 |
| LOWER CASING. DRIVE 1 | 34 |
| LOWER CASING. DRIVE 2 | 39 |
| OIL PAN | 41 |
| OIL PUMP | 43 |
| POWER TILT ASSY | 45 |
| REMOTE CONTROL ASSY | 50 |
| REMOTE CONTROL BOX | 55 |
| REPAIR KIT 1 | 56 |
| REPAIR KIT 2 | 58 |
| REPAIR KIT 3 | 59 |
| STARTER | 61 |
| STARTING MOTOR | 63 |
| STEERING GUIDE | 64 |
| TOP COWLING | 65 |
| UPPER CASING | 66 |
| VALVE | 67 |

Bottom Cowling




 69A1300-2150

D2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 69A-42710-11-4D Bottom cowling assembly WITH TAPPING BOLT | Buy now |
| 2 | 97095-06035 Bolt(j52) | Buy now |
| 3 | 92995-06600 Washer, plain (646) | Buy now |
| 4 | 97095-06025 Bolt | Buy now |
| 6 | 90480-15M31 Grommet (6g1) | Buy now |
| 7 | 90387-06M52 Collar (6g1) | Buy now |
| 8 | 66M-42716-00 Rubber, seal 1 | Buy now |
| 9 | 66M-42738-00-4D Plate, fitting | Buy now |
| 10 | 90109-06M82 Bolt | Buy now |
| 11 | 66M-42725-20 Grommet | Buy now |
| 12 | 62Y-42727-00 Grommet | Buy now |
| 13 | 66M-42815-00-4D Lever, clamp 1 | Buy now |
| 14 | 90386-12M37 Bushing (6f5) | Buy now |
| 15 | 90386-12MA2 Bush | Buy now |
| 16 | 90206-12052 Washer, wave (666) | Buy now |

Bottom Cowling




69A1300-2150

D2

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 6L2-42816-00 Lever, clamp | Buy now |
| 18 | 97095-06012 Bolt(gh1) | Buy now |
| 19 | 66M-42766-00 Bracket 2 | Buy now |
| 20 | 90109-06M86 Bolt | Buy now |
| 21 | 6H3-44391-01 Nipple, hose | Buy now |
| 22 | 65W-26326-10 Grommet | Buy now |
| 23 | 682-42727-00 Grommet | Buy now |
| 24 | 682-42724-00 Grommet | Buy now |
| 25 | 65W-42726-10 Grommet | Buy now |
| 26 | 66M-42743-00 Bracket | Buy now |
| 28 | 90465-25M95 Clamp | Buy now |
| 29 | 90464-09M13 Clamp (6h1) | Buy now |
| 30 | 688-42726-10 Grommet | Buy now |
| 31 | 62Y-82377-00 Label | Buy now |
| 32 | 6A1-28176-00 Label Caution | Buy now |


Bottom Cowling

| Ref | Part | |
|-----|--|-------------------------|
| 33 | 6E3-8257H-00 Plate Mark | Buy now |
| 34 | 6G8-13444-51 Mark | Buy now |



D2

Bracket 1




 FWD
69A1300-2170

D6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 69A-43111-00-4D Bracket, clamp 1 | Buy now |
| 2 | 6E0-43118-01 Handle, transom clamp | Buy now |
| 3 | 90243-04M01 Pin(6a1) | Buy now |
| 4 | 6E7-43116-00 Screw, transom clamp | Buy now |
| 5 | 648-43114-01 Pad, transom clamp | Buy now |
| 6 | 69A-43112-00-4D Bracket, clamp 2 | Buy now |
| 11 | 65W-43192-00 Knob, stopper | Buy now |
| 12 | 65W-43191-00 Shaft, stopper | Buy now |
| 13 | 91690-30018 926-51502-00 pin, spring (700) | Buy now |
| 14 | 90386-14MA1 Bush | Buy now |
| 15 | 90109-06M04 Bolt | Buy now |
| 16 | 69A-43311-00-4D Bracket, Swivel 1 S | Buy now |
| 16 | 69A-43311-10-4D Bracket, swivel 1 L | Buy now |
| 17 | 97885-08010 Rivet | Buy now |
| 18 | 69A-43131-00 Bolt, clamp bracket | Buy now |

Bracket 1




 FWD
69A1300-2170

D6

| Ref | Part | |
|-----|--|-------------------------|
| 19 | 90386-22MA4 Bush | Buy now |
| 20 | 69A-43113-00 Plate, clamp bracket | Buy now |
| 21 | 90185-22043 Nut, self-locking | Buy now |
| 22 | 6G5-43145-01 Cap, clamp bracket | Buy now |
| 23 | 90446-14MH7 Hose | Buy now |
| 24 | 90465-13M97 Clamp | Buy now |
| 25 | 69G-43818-00 Pin, lower shock mount | Buy now |
| 26 | 90386-16MA7 Bush | Buy now |
| 27 | 90386-16MA8 Bush | Buy now |
| 28 | 90387-16M02 Collar | Buy now |
| 29 | 90201-08M00 Washer, plate(6e0) | Buy now |
| 30 | 97080-08016 Bolt | Buy now |
| 31 | 90249-12M36 Pin | Buy now |
| 32 | 90381-12M10 Bush, solid | Buy now |
| 33 | 90381-12M11 Bush, solid | Buy now |

Bracket 1





69A1300-2170

| Ref | Part | |
|-----|--|-------------------------|
| 34 | 93430-10M00 Circlip | Buy now |
| 35 | 90110-08M05 Bolt, hexagon socket head | Buy now |
| 36 | 90185-08057 Nut, nylon (6j8) | Buy now |
| 37 | 92990-08600 Washer, plain (663) | Buy now |
| 38 | 90338-08M19 Plug S | Buy now |
| 39 | 65W-45251-00 Anode | Buy now |
| 40 | 90101-06020 Bolt | Buy now |
| 41 | 63V-82127-00 Wire, lead 2 | Buy now |
| 42 | 97095-06010 Bolt | Buy now |
| 43 | 92995-06600 Washer, plain (646) | Buy now |
| 44 | 69A-43155-00 Mark 1 | Buy now |

D6

Bracket 2




69A0100-0220

E1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 93700-06M03 Nipple, grease(6a1) | Buy now |
| 2 | 63V-42528-00 Plate, friction | Buy now |
| 3 | 689-43373-01 Seal, damper | Buy now |
| 4 | 90105-06M07 Bolt (689) | Buy now |
| 5 | 66M-82127-00 Wire, Lead 2 <i>S</i> | Buy now |
| 5 | 69A-82127-00 Wire Lead 2 <i>L</i> | Buy now |
| 6 | 66M-42511-01-4D Bracket Steering <i>S</i> | Buy now |
| 6 | 66M-42511-11-4D Bracket, steering <i>L</i> | Buy now |
| 7 | 63V-42537-00 Bushing, pivot shaft | Buy now |
| 8 | 90201-45M28 Washer, plate | Buy now |
| 9 | 90386-30048 Bush | Buy now |
| 10 | 93210-29M94 O-ring(6h1) | Buy now |
| 11 | 90386-30M60 Bush(6j8) | Buy now |
| 12 | 66M-44514-00-4D Mount damper, upper side | Buy now |
| 13 | 97075-06025 Bolt | Buy now |

Bracket 2




E1

| Ref | Part | |
|-----|--|-------------------------|
| 14 | 92995-06600 Washer, plain (646) | Buy now |
| 15 | 90116-08M54 Bolt, stud(63v) | Buy now |
| 16 | 90201-08M06 Washer, plate | Buy now |
| 17 | 95380-08600 Nut (661) | Buy now |
| 18 | 66M-44526-00 Plate | Buy now |
| 19 | 66M-44366-00 Damper, water seal | Buy now |
| 20 | 66M-44551-00-4D Housing, lower mount rubber 1 | Buy now |
| 21 | 682-44555-30 Mount damper, lower side | Buy now |
| 22 | 66M-44557-00 Mount damper, lower front | Buy now |
| 23 | 90119-08M45 Bolt, with washer | Buy now |
| 24 | 90119-08M46 Bolt, with washer | Buy now |
| 25 | 90179-08M34 Nut | Buy now |
| 26 | 63V-48511-01 Hook, steering | Buy now |
| 27 | 97075-08035 Bolt(70w) | Buy now |
| 28 | 92995-08600 Washer, plain (663) | Buy now |


Bracket 2

| Ref | Part | |
|-----|---|-------------------------|
| 29 | 90185-08057 Nut, nylon (6j8) | Buy now |



E1


Carburetor



B4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-14301-00 Carburetor assembly 1 | Buy now |
| 2 | 66M-14381-02 Body Float Chamber | Buy now |
| 3 | 62Y-14383-00 Screw, drain | Buy now |
| 4 | 66M-14398-00 Gasket | Buy now |
| 5 | 677-14383-01 Screw, drain | Buy now |
| 6 | 6L2-14398-00 Gasket | Buy now |
| 7 | 66M-14325-00 Screw, pan head | Buy now |
| 8 | 66M-14377-00 Stopper | Buy now |
| 9 | 66M-14958-00 Cover, diaphragm | Buy now |
| 10 | 66M-14368-01 Diaphragm assembly 1 | Buy now |
| 11 | 6G8-14275-02 Spring | Buy now |
| 12 | 66M-14239-00 Seal | Buy now |
| 13 | 66M-14225-00 Cap | Buy now |
| 14 | 66M-14384-00 Gasket, float chamber | Buy now |
| 15 | 6L2-14385-00 Float | Buy now |


Carburetor



B4


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6E5-14386-01 Pin, float | Buy now |
| 17 | 6L2-14392-00 Valve, needle | Buy now |
| 18 | 97980-04110 Screw, pan head (e56) | Buy now |
| 19 | 6L2-14157-00 Cover, mixing | Buy now |
| 20 | 62Y-14399-00 Gasket | Buy now |
| 21 | 66M-14341-00 Nozzle Main | Buy now |
| 22 | 66M-14343-52 Jet, main (#104) | Buy now |
| 23 | 66M-14342-23 Jet, pilot (#45) | Buy now |
| 24 | 66M-14355-00 Plug | Buy now |
| 25 | 5H0-14323-00 Pilot screw set | Buy now |
| 26 | 30X-14334-00 Spring, air adjusting | Buy now |
| 27 | 62Y-14521-00 Screw, adjust | Buy now |
| 28 | 97980-04112 Screw, pan head (686) | Buy now |
| 29 | 62Y-14397-00 O-ring | Buy now |
| 30 | 98980-04006 Screw, bind(6l2) | Buy now |

Carburetor




| Ref | Part | |
|-----|---|-------------------------|
| 31 | 646-14212-01 Spring, pilot adjusting | Buy now |
| 32 | 6F5-14397-00 O-ring | Buy now |
| 33 | 66M-14272-00 Valve, check seat | Buy now |
| 34 | 66M-14827-00 Filter | Buy now |
| 35 | 97890-04005 Screw, pan head(6g8) | Buy now |
| 36 | 66M-14157-00 Cover Mixing | Buy now |
| 37 | 98580-03005 Screw, pan head(78g) | Buy now |
| 38 | 69M-24533-00 O-ring | Buy now |

B4




D4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6H3-48538-00 Clamp, cable | Buy now |
| 2 | 663-48344-00 Cable end, remote control | Buy now |
| 3 | 90468-18008 Clip 620436610000 | Buy now |
| 4 | 65W-44121-00 Lever, shift rod | Buy now |
| 5 | 66M-44122-00 Bushing, shift rod lever | Buy now |
| 6 | 90254-03M05 Pin, spring | Buy now |
| 7 | 6F5-41662-00 Bracket 2 | Buy now |
| 8 | 90109-06M81 Bolt | Buy now |
| 9 | 65W-44116-00 Spring | Buy now |
| 10 | 66R-44114-00 Stopper | Buy now |
| 11 | 90109-06M86 Bolt | Buy now |
| 12 | 66M-44143-00 Rod, shift <i>S</i> | Buy now |
| 12 | 66M-44143-10 Rod, shift <i>L</i> | Buy now |
| 13 | 90170-06015 Connector, shift rod | Buy now |
| 14 | 95380-06700 Nut | Buy now |



D4


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 65W-44142-00 Joint | Buy now |
| 18 | 65W-44125-00 Lever, shift rod | Buy now |
| 19 | 90387-06M29 Coller (6a0) | Buy now |
| 20 | 90201-06M31 Washer (6a0) | Buy now |
| 21 | 97095-06025 Bolt | Buy now |
| 22 | 92995-06600 Washer, plain (646) | Buy now |
| 23 | 66M-44192-00 Joint, rod 1 | Buy now |
| 24 | 90201-05M06 Washer, plate(61u) | Buy now |
| 25 | 90468-10005 Pin, hair 6264123500 | Buy now |
| 27 | 65W-41638-00 Pulley | Buy now |
| 28 | 65W-41283-00 Lever, free accel. | Buy now |
| 29 | 661-41262-02 Joint, choke lever | Buy now |
| 30 | 90387-06M08 Collar | Buy now |
| 31 | 66M-41211-00 Link, accel. | Buy now |
| 32 | 65W-14497-01 Stay, Throttle Wire | Buy now |



| Ref | Part | |
|-----|--|-------------------------|
| 34 | 97095-06055 Bolt, hexagon w/w deep recess | Buy now |
| 36 | 97095-06010 Bolt | Buy now |

D4

Crankshaft. Piston




 FWD
 66M0010-8031

A7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 93102-35M51 Oil seal | Buy now |
| 2 | 93102-25M52 Oil seal | Buy now |
| 3 | 66M-11411-00 Crankshaft | Buy now |
| 4 | 66M-11416-00 Plane bearing, crankshaft 1 UR BROWN | Buy now |
| 4 | 66M-11416-10 Plane bearing, crankshaft 1 UR BLACK | Buy now |
| 4 | 66M-11416-20 Plane bearing, crankshaft 1 UR BLUE | Buy now |
| 5 | 66M-11650-00 Connecting rod kit | Buy now |
| 6 | 66M-11654-00 Bolt, connecting rod | Buy now |
| 7 | 90201-07M01 Washer, plate | Buy now |
| 8 | 66M-11631-00-96 Piston (std) | Buy now |
| 8 | 66M-11635-00 Piston (0.25mm o/s) AP | Buy now |
| 8 | 66M-11636-00 Piston (0.50Mm O/S) AP | Buy now |
| 9 | 66M-11603-00 Piston ring set (std) | Buy now |
| 9 | 66M-11604-00 Piston ring set (0.25mm o/s) AP | Buy now |
| 9 | 66M-11605-00 Piston ring set (0.50mm o/s) AP | Buy now |

Crankshaft. Piston


| Ref | Part | |
|-----|---|-------------------------|
| 10 | 634-11633-00 Pin, piston | Buy now |
| 11 | 93450-15023 Circlip 131116340000 | Buy now |



66M0010-8031

A7


Cylinder. Crankcase 1



A5

| Ref | Part | |
|-----|--|-------------------------|
| 3 | 99510-10114 Pin, dowel(3vd) | Buy now |
| 4 | 90119-08M66 Bolt, with washer | Buy now |
| 5 | 90119-06M14 Bolt, with washer (677) | Buy now |
| 6 | 6E5-24377-00 Pipe, joint | Buy now |
| 7 | 90445-10M46 Hose (I200) | Buy now |
| 8 | 66M-11325-00 Anode | Buy now |
| 10 | 66M-11328-00 Grommet, anode | Buy now |
| 11 | 97095-06020 Bolt(7u8) | Buy now |
| 12 | 92995-06600 Washer, plain (646) | Buy now |
| 13 | 97095-05012 Bolt, hexagon | Buy now |
| 14 | 92995-05600 Washer, plain (646) | Buy now |
| 15 | 66M-12535-00 Plate | Buy now |
| 18 | 66M-11357-00 Seal, cylinder 3 | Buy now |
| 21 | 66M-11351-00 Gasket, cylinder | Buy now |
| 22 | 66M-12411-00 Thermostat | Buy now |

Cylinder. Crankcase 1




69A1300-2020

A5

| Ref | Part | |
|-----|---|-------------------------|
| 24 | 62Y-12414-00 Gasket, cover | Buy now |
| 26 | 676-11372-00 Nipple, hose | Buy now |
| 27 | 66M-41114-00 Gasket, exhaust outer cover | Buy now |
| 28 | 90119-06MA4 Bolt, with washer | Buy now |
| 29 | 90445-09061 Hose (L65) | Buy now |
| 30 | 688-24378-00 Pipe, joint | Buy now |
| 31 | 90445-09086 Hose (I1500) | Buy now |
| 32 | 90445-09105 Hose (I420) | Buy now |
| 33 | 5GH-13440-00 Element assembly, oil cleaner | Buy now |
| 34 | 90401-20M00 Bolt, union(62y) | Buy now |


Cylinder. Crankcase 2



| Ref | Part | |
|-----|--|-------------------------|
| 3 | 66M-11133-10 Guide Valve 1 | Buy now |
| 4 | 93450-09M01 Circlip (6g8) | Buy now |
| 5 | 66M-11181-00 Gasket, cylinder head 1 | Buy now |
| 6 | 99510-10114 Pin, dowel(3vd) | Buy now |
| 7 | 90105-08M78 Bolt, washer based | Buy now |
| 8 | 90119-06MA3 Bolt, with washer | Buy now |
| 10 | 66M-11356-00 Seal, cylinder 2 | Buy now |
| 11 | 97095-06020 Bolt(7u8) | Buy now |
| 12 | 92995-06600 Washer, plain (646) | Buy now |
| 13 | 6G8-15363-00 Plug, oil | Buy now |
| 14 | 93210-24M79 O-ring | Buy now |
| 15 | 66M-12138-60 Mark Caution | Buy now |
| 16 | 94701-00375 Plug, spark (dpr6ea-9)(62y) | Buy now |


B1

Electrical 1



C4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M-85540-10 C.d.i. unit assembly | Buy now |
| 2 | 97095-06020 Bolt(7u8) | Buy now |
| 3 | 92995-06600 Washer, plain (646) | Buy now |
| 4 | 66M-85570-00 Ignition coil assembly | Buy now |
| 5 | 90480-25161 Grommet(656) | Buy now |
| 8 | 6G8-82370-30 Plug cap assembly | Buy now |
| 9 | 62Y-82504-10 Oil pressure switch assembly | Buy now |
| 10 | 66M-82127-10 Wire, lead 2 | Buy now |
| 11 | 69A-85542-10 Bracket | Buy now |
| 12 | 90387-06M05 Collar(6h4) | Buy now |
| 13 | 90480-13M24 Grommet (6e9) | Buy now |
| 14 | 95895-06020 Bolt, flange(jk3) | Buy now |
| 15 | 90201-06M05 Washer, plate(6e3) | Buy now |
| 16 | 97095-06025 Bolt | Buy now |
| 18 | 90464-09M13 Clamp (6h1) | Buy now |




69B0010-1120

C4

| Ref | Part | |
|-----|---|-------------------------|
| 19 | 6G8-81960-A1 Rectifier & regulator assembly | Buy now |
| 20 | 97095-06016 Bolt, hexagon deep recess | Buy now |
| 22 | 6G8-82150-00 Fuse holder assembly | Buy now |
| 23 | 663-82151-00 Fuse | Buy now |
| 24 | 6G5-82152-00 Holder, fuse | Buy now |
| 25 | 65W-85410-01 Emergency signal light assembly | Buy now |
| 26 | 6H1-83557-00 Tube | Buy now |


Electrical 2



C6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6G1-81941-10 Starter relay | Buy now |
| 2 | 6G1-81952-00 Holder, relay | Buy now |
| 3 | 66M-82117-00 Wire, lead | Buy now |
| 4 | 65W-8182B-00 Nut, special | Buy now |
| 5 | 66M-82105-00 Battery cable | Buy now |
| 6 | 95380-08700 Nut(661) | Buy now |
| 7 | 92990-08600 Washer, plain (663) | Buy now |
| 8 | 66M-86111-00 Coil, solenoid | Buy now |
| 9 | 66M-86116-00 Wire, Pull | Buy now |
| 10 | 66M-86112-00 Stay Solenoid | Buy now |
| 11 | 97880-05008 Screw, with washer | Buy now |
| 12 | 92990-05600 Washer, plain (646) | Buy now |
| 13 | 97095-06016 Bolt, hexagon deep recess | Buy now |
| 14 | 92995-06600 Washer, plain (646) | Buy now |
| 15 | 90480-10M13 Grommet (6e0) | Buy now |


Electrical 2



C6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 66M-86117-00 Hook, wire pull | Buy now |
| 17 | 93210-03261 O-ring (663) | Buy now |
| 18 | 69A-81950-00 Relay assembly | Buy now |
| 19 | 90480-09M12 Grommet (6a0) | Buy now |
| 20 | 90387-06M03 Collar (676) | Buy now |
| 21 | 90201-06416 Washer, plate(663) | Buy now |
| 22 | 90109-06MA2 Bolt | Buy now |
| 23 | 6H5-81920-00 Terminal assembly | Buy now |
| 24 | 69A-81929-00 Bracket Terminal | Buy now |
| 25 | 97095-06012 Bolt(gh1) | Buy now |
| 27 | 6G5-82119-00 Cover, lead wire | Buy now |
| 28 | 69A-82590-00 Wire Harness assembly | Buy now |
| 29 | 63D-82563-10 Trim & tilt switch assembly | Buy now |
| 30 | 6E5-82587-00 Gasket | Buy now |
| 31 | 69A-83614-00 Bracket | Buy now |


Electrical 2



| Ref | Part | |
|-----|--------------------------------------|-------------------------|
| 32 | 90109-06M86 Bolt | Buy now |
| 33 | 90465-06M88 Clamp | Buy now |

C6


Fuel



66M0010-9090

B7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6G1-24304-02 Fuel pipe joint comp. 1 | Buy now |
| 2 | 97095-06020 Bolt(7u8) | Buy now |
| 3 | 92995-06600 Washer, plain (646) | Buy now |
| 4 | 90445-10M40 Hose (l400) | Buy now |
| 5 | 65W-24251-00 Strainer 1 | Buy now |
| 6 | 90445-10M20 Hose (l400) | Buy now |
| 7 | 90467-09M03 Clip(6k8) | Buy now |
| 8 | 90465-11M10 Clamp | Buy now |
| 9 | 66M-24410-10 Fuel pump assembly | Buy now |
| 10 | 66M-24413-01 Body 2 | Buy now |
| 11 | 6A0-24421-01 Valve, check | Buy now |
| 12 | 66M-24411-10 Diaphragm | Buy now |
| 13 | 66M-24423-00 Spring, diaphragm | Buy now |
| 14 | 66M-13131-10 Plunger | Buy now |
| 15 | 66M-24454-00 Spring | Buy now |




66M0010-9090

B7

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 66M-24444-00 Screw | Buy now |
| 17 | 66M-24471-00 Diaphragm | Buy now |
| 18 | 6E7-14325-00 Screw, pan head | Buy now |
| 19 | 95380-05600 Nut, hexagon (663) | Buy now |
| 20 | 66M-24374-00 Pin | Buy now |
| 21 | 97880-06030 Screw, pan head(6e0) | Buy now |
| 22 | 92990-06100 Washer(6a1) | Buy now |
| 23 | 92990-06600 Washer, plain (646) | Buy now |
| 24 | 93210-20M65 O-ring | Buy now |
| 25 | 90445-10M93 Hose (l400) | Buy now |
| 27 | 90465-06M86 Clamp | Buy now |
| 28 | 90464-09M31 Clamp(6m7) | Buy now |
| 29 | 62Y-28100-00 Tool kit | Buy now |

Fuel Tank




66R0700-9260

F5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6YL-24201-02 Fuel Tank assembly AP | Buy now |
| 2 | 6YL-24610-00 Cap Assembly | Buy now |
| 3 | 6YL-24641-00 Gasket, cap 1 | Buy now |
| 4 | 6YL-24260-01 Fuel meter assembly | Buy now |
| 5 | 90157-05M16 Screw, pan head | Buy now |
| 6 | 6YL-24329-00 Seal | Buy now |
| 7 | 6YL-24268-01 Gasket, fuel meter | Buy now |
| 8 | 6YL-24306-52 Fuel pipe comp. 1 AP | Buy now |


Generator



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-85550-10 Rotor assembly WITH RING GEAR | Buy now |
| 2 | 66M-85520-00 Coil, charge | Buy now |
| 3 | 66M-85580-00 Coil, pulser | Buy now |
| 4 | 66M-85533-10 Coil, Lighting 10A | Buy now |
| 5 | 97095-06025 Bolt | Buy now |
| 6 | 92995-06100 Washer(6a1) | Buy now |
| 7 | 92995-06600 Washer, plain (646) | Buy now |
| 8 | 97095-06016 Bolt, hexagon deep recess | Buy now |
| 10 | 97095-06040 Bolt (682) | Buy now |
| 12 | 90280-05013 Key, woodruff | Buy now |
| 13 | 90179-16M05 Nut (689) | Buy now |
| 14 | 90201-16M44 Washer (689) | Buy now |

C3


Intake



B3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-13641-00-94 Manifold 1 | Buy now |
| 2 | 66M-13645-00 Gasket, manifold 1 | Buy now |
| 3 | 97095-06040 Bolt (682) | Buy now |
| 4 | 92995-06600 Washer, plain (646) | Buy now |
| 5 | 93606-12019 Pin, dowel (614) | Buy now |
| 6 | 66M-13646-00 Gasket, manifold 2 | Buy now |
| 7 | 66M-14271-00 Insulator | Buy now |
| 8 | 66M-14440-00 Silencer assembly, intake | Buy now |
| 9 | 93210-35M86 O-ring(6l2) | Buy now |
| 10 | 90119-06M76 Bolt, with washer | Buy now |
| 11 | 90387-06M79 Collar | Buy now |
| 12 | 66M-14477-00 Plate | Buy now |
| 13 | 66M-41271-00 Knob, choke | Buy now |
| 14 | 689-41273-00 Grommet | Buy now |
| 15 | 66M-41292-00 Bush 2 | Buy now |

Intake




69B0010-0060

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 66M-41298-00 Washer 2 | Buy now |
| 17 | 97780-50510 Screw, tapping(6u1) | Buy now |
| 18 | 66M-41252-00 Lever, choke 1 | Buy now |
| 19 | 90240-05M20 Pin, clevis | Buy now |
| 20 | 90206-05005 Washer, wave(656) | Buy now |
| 21 | 91690-20016 Pin, spring (677) | Buy now |
| 22 | 90202-05088 Washer, plate (666) | Buy now |
| 23 | 6R5-41237-00 Joint, link | Buy now |
| 24 | 66M-41256-00 Rod, choke 1 | Buy now |
| 25 | 66M-15373-00 Pipe, breather | Buy now |
| 26 | 90465-08M82 Clamp | Buy now |
| 27 | 90465-08M83 Clamp | Buy now |

B3


Lower Casing. Drive 1



F1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 69A-45300-01-4D Lower unit assembly S | Buy now |
| 1 | 69A-45300-11-4D Lower Unit assembly L | Buy now |
| 2 | 63V-45311-01-4D Casing, lower L | Buy now |
| 2 | 66M-45311-00-4D Casing, lower S | Buy now |
| 3 | 93315-314V8 Bearing, needle (6e7) | Buy now |
| 4 | 63V-45536-00 Sleeve, drive shaft | Buy now |
| 5 | 93341-41414 Bearing | Buy now |
| 6 | 6E8-45587-10-13 Shim (t:1.13mm) UR | Buy now |
| 6 | 6E8-45587-10-20 Shim (t:1.20mm) UR | Buy now |
| 7 | 93332-00005 Brg,cyl-cal roller 0.19g nt | Buy now |
| 8 | 664-45567-01-10 Shim (t:0.10mm) UR | Buy now |
| 8 | 664-45567-01-12 Shim (t:0.12mm) UR | Buy now |
| 8 | 664-45567-01-15 Shim (t:0.15mm) UR | Buy now |
| 8 | 664-45567-01-18 Shim (t:0.18mm) UR | Buy now |
| 8 | 664-45567-01-30 Shim (t:0.30mm) UR | Buy now |


Lower Casing. Drive 1



F1


| Ref | Part | |
|-----|--|-------------------------|
| 8 | 664-45567-01-40 Shim (t:0.40mm) UR | Buy now |
| 8 | 664-45567-01-50 Shim (t:0.50mm) UR | Buy now |
| 9 | 90340-08002 Plug, straight screw | Buy now |
| 10 | 90430-08020 Gasket | Buy now |
| 11 | 63V-44301-00 Water pump housing comp. | Buy now |
| 12 | 63V-44322-00 Insert, cartridge | Buy now |
| 13 | 647-44366-00 Damper, water seal 2 | Buy now |
| 14 | 63V-44352-01 Impeller | Buy now |
| 15 | 664-44338-00 Key, woodruff | Buy now |
| 16 | 93210-44398 O-ring(55x) | Buy now |
| 17 | 63V-44323-00 Outer plate, cartridge | Buy now |
| 18 | 93604-12M07 Pin, dowel (688) | Buy now |
| 19 | 97080-08045 Bolt, hexagon | Buy now |
| 20 | 63V-44328-00 Plate | Buy now |
| 21 | 63V-45331-00-5B Housing, bearing | Buy now |

Lower Casing. Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 22 | 90381-14020 Bushing, drive shaft 1 | Buy now |
| 23 | 93101-20048 Oil seal (20x30x6-648) | Buy now |
| 24 | 63V-45315-A0 Packing, lower casing | Buy now |
| 25 | 93210-06ME6 O-ring | Buy now |
| 26 | 97080-08025 Screw, bind(j36) | Buy now |
| 27 | 63V-44150-00 Shift cam assembly S | Buy now |
| 27 | 66M-44150-10 Shift cam assembly L | Buy now |
| 28 | 69A-45510-00 Drive Shaft assembly S | Buy now |
| 28 | 69A-45510-10 Drive Shaft assembly L | Buy now |
| 29 | 63V-45551-00 Pinion | Buy now |
| 30 | 90179-08M06 Nut (6e7) | Buy now |
| 31 | 6E7-45560-01 Gear | Buy now |
| 32 | 6E7-45571-00 Gear 2 | Buy now |
| 33 | 626-45577-00-01 Shim (t:0.10mm) UR | Buy now |
| 33 | 626-45577-00-03 Shim (t:0.30mm) UR | Buy now |

Lower Casing. Drive 1




F1

| Ref | Part | |
|-----|---|-------------------------|
| 33 | 626-45577-00-05 Shim (t:0.50mm) UR | Buy now |
| 34 | 90201-17682 Washer, plate (2k7) | Buy now |
| 35 | 683-45611-00 Shaft propeller | Buy now |
| 36 | 650-45635-00 Plunger, shift | Buy now |
| 37 | 682-45631-00 Clutch, dog | Buy now |
| 38 | 90250-05010 Pin straight 648456320000 | Buy now |
| 39 | 648-45633-00 Ring, cross pin | Buy now |
| 40 | 90501-14M06 Spring, compression | Buy now |
| 41 | 683-45361-02-4D Cap, lower casing | Buy now |
| 42 | 93306-00501 Bearing(1ff) | Buy now |
| 43 | 93315-317U2 Brg,cyl-cal roller 14g (683) | Buy now |
| 44 | 93101-17054 Oil seal (17x30x6-650) | Buy now |
| 45 | 93210-57M09 O-ring (683) | Buy now |
| 46 | 93210-56M80 O-ring(6j8) | Buy now |
| 47 | 97095-06020 Bolt(7u8) | Buy now |


Lower Casing. Drive 1

| Ref | Part | |
|-----|--|-------------------------|
| 48 | 92995-06600 Washer, plain (646) | Buy now |



F1

Lower Casing. Drive 2




 69A0300-0230

 F4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-44361-00 Tube, Water 1 S | Buy now |
| 1 | 66M-44361-10 Tube, water L | Buy now |
| 2 | 63V-44365-10 Damper, water seal 1 | Buy now |
| 3 | 63V-44368-00 Rubber, water seal 4 | Buy now |
| 4 | 93604-12M07 Pin, dowel (688) | Buy now |
| 5 | 97075-08030 Bolt, hexagon (fj1) | Buy now |
| 6 | 92995-08600 Washer, plain (663) | Buy now |
| 7 | 6G1-45214-00 Cover, water inlet | Buy now |
| 8 | 63V-45215-00 Cover, water inlet | Buy now |
| 9 | 90152-05M04 Screw, countersunk | Buy now |
| 10 | 90185-05002 Nut nylon (sus)(ex4) | Buy now |
| 11 | 61N-45251-01 Anode | Buy now |
| 12 | 95895-06030 Bolt, flange deep recess | Buy now |
| 13 | 92990-06300 Washer, tooth | Buy now |
| 14 | 63V-45375-00 Damper, seal | Buy now |

Lower Casing. Drive 2




69A0300-0230

F4

| Ref | Part | |
|-----|---|-------------------------|
| 15 | 6E7-45987-01 Spacer | Buy now |
| 16 | 90201-10M01 Washer, plate(6m7) | Buy now |
| 17 | 90171-10M01 Nut castle (683) | Buy now |
| 18 | 91490-30020 Pin cotter | Buy now |
| 19 | 63V-45947-00-EL Propeller (3x9-1/4 x8 -j) UR | Buy now |
| 19 | 683-45941-00-EL Propeller (3x9-1/4"x12"-j) UR | Buy now |
| 19 | 683-45943-00-EL Propeller (3x9-1/4"x10-1/2"-j) UR | Buy now |
| 19 | 683-45945-00-EL Propeller (3X9-1/4"X9"-j) UR | Buy now |
| 19 | 683-45952-00-EL Propeller (3X9-1/4"x9-3/4"-j) UR | Buy now |
| 20 | 66M-45371-00 Tab-trim S | Buy now |
| 21 | 97095-06016 Bolt, hexagon deep recess S | Buy now |
| 22 | 92995-06600 Washer, plain (646) S | Buy now |


Oil Pan



E7

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M-41137-00-5B Guide, exhaust | Buy now |
| 2 | 93101-12M63 Oil seal | Buy now |
| 3 | 93606-12019 Pin, dowel (614) | Buy now |
| 4 | 66M-11355-00 Seal, cylinder 1 | Buy now |
| 5 | 97095-06020 Bolt(7u8) | Buy now |
| 6 | 92995-06600 Washer, plain (646) | Buy now |
| 7 | 66M-41131-01-94 Manifold, Ext. 1 | Buy now |
| 8 | 66M-41133-00 Gasket, exhaust manifold 1 | Buy now |
| 9 | 97095-06016 Bolt, hexagon deep recess | Buy now |
| 11 | 66M-41138-00 Seal, ext. 1 | Buy now |
| 12 | 66M-13421-00 Strainer 2 | Buy now |
| 13 | 66M-13417-00 Cover, Strainer | Buy now |
| 14 | 66M-13416-00 Pipe Oil 1 | Buy now |
| 15 | 66M-24351-00 Band 1 | Buy now |
| 16 | 6G8-11575-00 Relief valve ass'y | Buy now |


Oil Pan



| Ref | Part | |
|-----|--|-------------------------|
| 17 | 90340-14M06 Plug, straight screw(62y) | Buy now |
| 18 | 90430-14M09 Gasket | Buy now |
| 19 | 66M-15316-00 Damper 1 | Buy now |
| 20 | 66M-15362-00 Plug, Oil Level | Buy now |

E7

Oil Pump




69A1300-2080

B6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 93102-18M21 Oil seal (6g8) | Buy now |
| 2 | 66M-12171-10 Camshaft 1 | Buy now |
| 3 | 66M-11537-00-94 Gear, driven | Buy now |
| 4 | 97013-06016 Bolt, hexagon deep recess | Buy now |
| 5 | 90201-13201 Washer 6474283300 | Buy now |
| 6 | 90201-06M94 Washer (6g8) | Buy now |
| 7 | 66M-11536-10 Gear, drive | Buy now |
| 8 | 66M-11557-00 Washer 1 | Buy now |
| 9 | 90170-28M37 Nut | Buy now |
| 10 | 90280-03M01 Key woodruff 146115450000 | Buy now |
| 11 | 66M-46241-00 Belt | Buy now |
| 12 | 66M-46297-00 Cover, dust | Buy now |
| 13 | 90480-10M16 Grommet(6g8) | Buy now |
| 14 | 90480-12072 Grommet(53y) | Buy now |
| 15 | 66M-13300-10 Oil Pump assembly | Buy now |


Oil Pump



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 66M-13329-10 Gasket, pump cover | Buy now |
| 17 | 97095-06035 Bolt(j52) | Buy now |
| 18 | 92995-06600 Washer, plain (646) | Buy now |

B6


Power Tilt Assy



E3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 69A-43840-00-4D Power tilt assembly | Buy now |
| 2 | 69A-4380K-00 Cylinder, tilt sub assembly | Buy now |
| 3 | 69A-22471-00 Case, cylinder | Buy now |
| 4 | 93210-27666 O-ring(47x) | Buy now |
| 5 | 6H1-4388E-11 Plug, tapper screw | Buy now |
| 6 | 93210-07003 O-ring (11m) | Buy now |
| 7 | 69A-43814-00 Piston, free | Buy now |
| 8 | 93210-21276 O-ring | Buy now |
| 9 | 69A-43872-00 Ring, back up | Buy now |
| 10 | 69A-43810-00 Piston sub assembly | Buy now |
| 11 | 69A-4380D-00 Piston comp. | Buy now |
| 14 | 93505-32038 Ball(7fk) | Buy now |
| 15 | 65W-4386A-00 Pin, absorber valve | Buy now |
| 16 | 93604-06136 Pin, dowel | Buy now |
| 17 | 69A-43857-00 Spring, absorber valve | Buy now |


Power Tilt Assy



E3

| Ref | Part | |
|-----|--|-------------------------|
| 18 | 69A-43801-00 Rod | Buy now |
| 19 | 69A-43811-00 Screw, cylinder end | Buy now |
| 20 | 6H1-43866-00 O-ring | Buy now |
| 21 | 69A-43871-00 Ring, back up | Buy now |
| 22 | 69A-43812-00 Seal, dust | Buy now |
| 23 | 69A-43869-00 O-ring | Buy now |
| 24 | 69A-43830-00 Gear pump assembly | Buy now |
| 25 | 69A-4380C-00 Gear housing assembly | Buy now |
| 26 | 69A-43841-00 Piston, shuttle | Buy now |
| 27 | 69A-4384M-00 Piston, shuttle 2 | Buy now |
| 28 | 62Y-43894-00 Spring, shuttle return | Buy now |
| 29 | 69A-4384F-00 Seal, main valve | Buy now |
| 30 | 6H1-43883-00 O-ring | Buy now |
| 31 | 99001-03600 Circlip(615) | Buy now |
| 32 | 69A-4382G-00 Valve Seat | Buy now |


Power Tilt Assy



E3

| Ref | Part | |
|-----|--|-------------------------|
| 33 | 93210-12N52 O-ring | Buy now |
| 34 | 6T4-43808-00 Seat valve comp. 1 | Buy now |
| 35 | 6T4-43853-00 Spring, main valve | Buy now |
| 36 | 6H1-43816-00 Filter 1 | Buy now |
| 37 | 6H1-4384G-11 Seal, relief valve | Buy now |
| 38 | 6H1-43844-10 Pin, valve support | Buy now |
| 39 | 69A-43855-00 Spring, up relief | Buy now |
| 40 | 6H1-43856-10 Spring, down relief | Buy now |
| 41 | 93501-08001 Ball | Buy now |
| 42 | 69A-4386A-00 Pin, absorber valve | Buy now |
| 43 | 69A-43824-00 Spring, down relief 2 | Buy now |
| 44 | 69A-43848-00 Rod, manual release | Buy now |
| 45 | 93602-15250 Pin, dowel | Buy now |
| 46 | 93210-06001 O-ring (26h) | Buy now |
| 47 | 69A-43854-00 Spring, manual release | Buy now |


Power Tilt Assy



E3

| Ref | Part | |
|-----|--|-------------------------|
| 48 | 69A-4381G-00 Pin 1 | Buy now |
| 51 | 69A-4384H-00 Spring | Buy now |
| 52 | 93606-14081 Pin,dowel(296) | Buy now |
| 53 | 91317-05025 Bolt, socket | Buy now |
| 54 | 69A-43816-00 Filter 1 | Buy now |
| 55 | N35-43862-10 O-ring | Buy now |
| 56 | 69A-23129-00 Gasket, drain plug | Buy now |
| 57 | 69A-43878-00 Bolt, socket | Buy now |
| 58 | 69A-43880-00 Motor assembly | Buy now |
| 59 | 65W-43804-00 Stator assembly | Buy now |
| 60 | 65W-43805-00 Armature assembly | Buy now |
| 61 | 65W-43869-00 O-ring | Buy now |
| 62 | 65W-4386K-00 Spring, brush | Buy now |
| 63 | 65W-43882-00 Oil seal | Buy now |
| 64 | 69A-43881-00 Frame, End | Buy now |


Power Tilt Assy



E3

| Ref | Part | |
|-----|---|-------------------------|
| 65 | 65W-43887-00 Bolt, screw | Buy now |
| 66 | 65W-43892-00 Brush 2 | Buy now |
| 67 | 65W-43891-00 Brush 1 | Buy now |
| 68 | 65W-4380F-00 Plate, brush holder | Buy now |
| 69 | 65W-43879-00 Screw, with washer | Buy now |
| 70 | 65W-4388E-00 Bolt | Buy now |


Remote Control Assy



A4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 703-48261-01 Arm, throttle | Buy now |
| 3 | 703-48153-00 Shaft, free accel. | Buy now |
| 4 | 703-48235-00 Bushing | Buy now |
| 5 | 703-48268-00 Spacer 3 | Buy now |
| 6 | 703-48264-00 Throttle, friction | Buy now |
| 7 | 95380-05600 Nut, hexagon (663) | Buy now |
| 8 | 97380-05025 Bolt | Buy now |
| 9 | 703-48265-00 Shaft Friction | Buy now |
| 10 | 93430-06024 Circlip (701) | Buy now |
| 11 | 703-48245-00 Plate, lock | Buy now |
| 12 | 703-48252-00 Roller, cam | Buy now |
| 13 | 701-48248-00 Roller, free accel | Buy now |
| 14 | 703-48198-00 Washer, wave 3 | Buy now |
| 15 | 703-48243-00 Bushing 3 | Buy now |


Remote Control Assy



A4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 703-48236-00 Bushing | Buy now |
| 17 | 703-48189-00 Retainer | Buy now |
| 18 | 703-48234-00 Roller, detent | Buy now |
| 19 | 703-48345-01 Cable end, remote control 2 | Buy now |
| 20 | 703-48358-00 Anchor, cable | Buy now |
| 21 | 703-48244-00 Spring, free accel. | Buy now |
| 22 | 703-48238-00 Spring, detent | Buy now |
| 23 | 703-48246-00 Spacer 1 | Buy now |
| 24 | 703-48227-00 Spring, neutral lock | Buy now |
| 25 | 703-82594-00 Clamp WITH PT/T SW. | Buy now |
| 26 | 703-48226-00 Plate, stopper | Buy now |
| 27 | 703-48222-00 Grip, control lever SINGLE | Buy now |
| 28 | 703-48223-00 Lock, neutral | Buy now |
| 29 | 703-48225-00 Cover | Buy now |
| 30 | 703-48219-00 Cover, lead | Buy now |


Remote Control Assy



A4

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 703-48281-00 Screw, flat head | Buy now |
| 32 | 703-48282-00 Screw | Buy now |
| 33 | 97380-08030 Bolt, hexagon (fj1) | Buy now |
| 34 | 92990-08600 Washer, plain (663) | Buy now |
| 35 | 98580-04010 Screw, pan head (e56) | Buy now |
| 36 | 98580-04006 Screw, pan head (7h3) | Buy now |
| 37 | 98580-05010 Screw, pan head(62x) | Buy now |
| 38 | 98580-03015 Screw, pan head (n151) | Buy now |
| 39 | 703-48291-10 Screw | Buy now |
| 40 | 95380-06600 Nut(661) | Buy now |
| 41 | 703-48293-10 Spacer, remote control SINGLE | Buy now |
| 42 | 701-48287-00 Washer 1 | Buy now |
| 43 | 703-48215-00 Graphic | Buy now |
| 44 | 703-82510-43 Main switch assembly | Buy now |
| 45 | 703-82577-00 Cap, key | Buy now |


Remote Control Assy



A4

| Ref | Part | |
|-----|---|-------------------------|
| 46 | 703-82531-00 Wire, lead | Buy now |
| 47 | 688-82575-01 Engine stop switch assembly | Buy now |
| 48 | 682-82556-00 Lanyard, stop switch | Buy now |
| 49 | 688-8258A-20 10p main harness mec 2m (6ft) L)5M (10P) | Buy now |
| 50 | 703-82540-00 Neutral switch assembly | Buy now |
| 51 | 703-83383-02 Buzzer | Buy now |
| 52 | 703-48284-00 Grommet | Buy now |
| 53 | 703-82591-00 Band | Buy now |
| 54 | 703-82592-00 Band | Buy now |
| 55 | 703-82563-02 Trim & tilt switch assembly | Buy now |
| 56 | 703-48221-00 Grip | Buy now |
| 57 | 703-48152-00 Knob, free accel | Buy now |
| 58 | 703-48212-00 Rear housing | Buy now |
| 59 | 703-48213-00 Back, panel | Buy now |
| 60 | 703-48271-00 Arm, shift | Buy now |



Remote Control Assy



| Ref | Part | |
|-----|--|-------------------------|
| 61 | 703-48211-01 Housing,1 | Buy now |
| 62 | 703-48232-00 Drive gear | Buy now |

A4

Remote Control Box




 67M0100-8280

F7

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 703-48205-17 Remote control assembly (10p, ptt) AP WITH PTT SW. | Buy now |
| 2 | 701-48310-80 Cable, Remote Control L=10F UR | Buy now |
| 2 | 701-48310-90 Cable, Remote Control L=11F UR | Buy now |
| 2 | 701-48320-00 Cable, Remote Control L=12F UR | Buy now |


Repair Kit 1



A7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-W0001-01 Power head gasket kit | Buy now |
| 2 | 66M-11357-00 Seal, cylinder 3 | Buy now |
| 3 | 66M-11351-00 Gasket, cylinder | Buy now |
| 4 | 62Y-12414-00 Gasket, cover | Buy now |
| 5 | 66M-41114-00 Gasket, exhaust outer cover | Buy now |
| 6 | 66M-11181-00 Gasket, cylinder head 1 | Buy now |
| 7 | 66M-11356-00 Seal, cylinder 2 | Buy now |
| 8 | 93210-24M79 O-ring | Buy now |
| 9 | 93102-35M51 Oil seal | Buy now |
| 10 | 93102-25M52 Oil seal | Buy now |
| 11 | 66M-13645-00 Gasket, manifold 1 | Buy now |
| 12 | 66M-13646-00 Gasket, manifold 2 | Buy now |
| 13 | 93210-35M86 O-ring(6l2) | Buy now |
| 14 | 93102-18M21 Oil seal (6g8) | Buy now |
| 15 | 90280-03M01 Key woodruff 146115450000 | Buy now |

Repair Kit 1




66M0100-1280

A7

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 66M-13329-10 Gasket, pump cover | Buy now |
| 17 | 93210-20M65 O-ring | Buy now |


Repair Kit 2



B1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-W0093-01 Carburetor repair kit | Buy now |
| 2 | 66M-14398-00 Gasket | Buy now |
| 3 | 6L2-14398-00 Gasket | Buy now |
| 4 | 66M-14377-00 Stopper | Buy now |
| 5 | 66M-14384-00 Gasket, float chamber | Buy now |
| 6 | 6L2-14385-00 Float | Buy now |
| 7 | 6E5-14386-01 Pin, float | Buy now |
| 8 | 6L2-14392-00 Valve, needle | Buy now |
| 9 | 62Y-14399-00 Gasket | Buy now |
| 10 | 5H0-14323-00 Pilot screw set | Buy now |
| 11 | 97980-04112 Screw, pan head (686) | Buy now |
| 12 | 62Y-14397-00 O-ring | Buy now |
| 13 | 6F5-14397-00 O-ring | Buy now |
| 14 | 66M-14827-00 Filter | Buy now |

Repair Kit 3




66M0100-8290

B2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M-W0001-20 Lower Unit Gasket Kit | Buy now |
| 2 | 93101-12M63 Oil seal | Buy now |
| 3 | 66M-41133-00 Gasket, exhaust manifold 1 | Buy now |
| 4 | 66M-41138-00 Seal, ext. 1 | Buy now |
| 5 | 90430-14M09 Gasket | Buy now |
| 6 | 66M-45113-00 Gasket, upper casing | Buy now |
| 7 | 66M-45115-00 Gasket, upper casing | Buy now |
| 8 | 66M-45128-00 Seal 2 | Buy now |
| 9 | 90430-08020 Gasket | Buy now |
| 10 | 63V-44322-00 Insert, cartridge | Buy now |
| 11 | 63V-44352-01 Impeller | Buy now |
| 12 | 93210-44398 O-ring(55x) | Buy now |
| 13 | 63V-44323-00 Outer plate, cartridge | Buy now |
| 14 | 93101-20048 Oil seal (20x30x6-648) | Buy now |
| 15 | 63V-45315-A0 Packing, lower casing | Buy now |


Repair Kit 3



B2

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 93210-06ME6 O-ring | Buy now |
| 17 | 93101-17054 Oil seal (17x30x6-650) | Buy now |
| 18 | 93210-57M09 O-ring (683) | Buy now |
| 19 | 93210-56M80 O-ring(6j8) | Buy now |
| 20 | 63V-44365-10 Damper, water seal 1 | Buy now |
| 21 | 63V-44368-00 Rubber, water seal 4 | Buy now |
| 22 | 63V-W0078-00 Water pump repair kit | Buy now |
| 23 | 647-44366-00 Damper, water seal 2 | Buy now |
| 24 | 97080-08045 Bolt, hexagon | Buy now |
| 28 | 664-44338-00 Key, woodruff | Buy now |

Starter




C2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M-15711-10 Case, starter | Buy now |
| 2 | 97095-06020 Bolt(7u8) | Buy now |
| 3 | 92995-06600 Washer, plain (646) | Buy now |
| 4 | 66M-15758-10 Guide, Rope | Buy now |
| 5 | 6G1-42725-00 Grommet | Buy now |
| 6 | 90119-06M59 Bolt, with washer | Buy now |
| 7 | 97095-06090 Bolt(62y) | Buy now |
| 8 | 92995-06100 Washer(6a1) | Buy now |
| 9 | 90201-06M05 Washer, plate(6e3) | Buy now |
| 10 | 95380-06700 Nut | Buy now |
| 11 | 66M-15762-00 Seal Rubber 2 | Buy now |
| 12 | 66M-84342-00 Seat, Emblem | Buy now |
| 13 | 6A1-83625-41 Mark 5 | Buy now |
| 14 | 6A1-83625-51 Mark 5 | Buy now |
| 15 | 66M-14427-60 Label Instruction | Buy now |

Starter


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6G8-13437-63 Mark, caution | Buy now |



 69A1300-2100

C2


Starting Motor



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 66M-81800-01 Starting motor assembly | Buy now |
| 2 | 65W-81826-00 Bolt | Buy now |
| 3 | 65W-81857-01 Retainer | Buy now |
| 4 | 66M-81830-00 Front bracket assembly | Buy now |
| 5 | 65W-81807-00 Gear assembly, starting motor | Buy now |
| 6 | 65W-81850-01 Armature assembly | Buy now |
| 7 | 66M-81820-00 Rear bracket assembly | Buy now |
| 8 | 65W-81801-00 Brush set | Buy now |
| 9 | 65W-81840-00 Brush holder assembly | Buy now |
| 10 | 65W-81825-00 Screw | Buy now |
| 11 | 90119-08M39 Bolt, with washer | Buy now |
| 12 | 90109-08M78 Bolt | Buy now |
| 13 | 90109-08M85 Bolt | Buy now |

D1

Steering Guide




63V0100-5210

F6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 63V-61350-00 Steering guide attachment kit AP | Buy now |
| 2 | 90201-10M20 Washer, plate (663) | Buy now |
| 3 | 90185-09M01 Nut, nylon (663) | Buy now |
| 4 | 90170-09M03 Nut (689) | Buy now |
| 5 | 90387-10M42 Coller (688) | Buy now |
| 6 | 6E5-61355-00 Bolt | Buy now |
| 7 | 90201-10M63 Washer, plate | Buy now |
| 8 | 6E5-43145-01 Cap, clamp bracket | Buy now |
| 9 | 93210-16275 O-ring | Buy now |


Top Cowling



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 69A-42610-10-4D Top Cowling assembly | Buy now |
| 2 | 66M-42613-00 Molding Air Duct | Buy now |
| 3 | 97780-60520 Screw, tapping(6k8) | Buy now |
| 4 | 6E0-42651-02 Hook | Buy now |
| 5 | 90266-04M04 Rivet(6e7) | Buy now |
| 6 | 6E7-42652-00 Hook | Buy now |
| 8 | 66M-42615-00 Seal | Buy now |
| 9 | 66M-42678-20 Graphic Front | Buy now |
| 10 | 66M-W0070-20 Graphic set | Buy now |
| 11 | 69A-42675-00 Graphic, side 1 | Buy now |
| 12 | 66M-42677-00 Graphic, front | Buy now |
| 13 | 90202-05M38 Washer, plate(6l2) | Buy now |
| 14 | 67F-13434-02 Label, Caution | Buy now |

A4

Upper Casing




66M0010-8230

E6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M-45111-00-4D Casing, upper S | Buy now |
| 1 | 66M-45111-10-4D Casing, upper L | Buy now |
| 2 | 66M-45113-00 Gasket, upper casing | Buy now |
| 3 | 97575-08545 Bolt, hexagon w/w deep recess | Buy now |
| 4 | 93606-12019 Pin, dowel (614) | Buy now |
| 5 | 66M-45126-00 Plate, Seal Damper | Buy now |
| 6 | 66M-45115-00 Gasket, upper casing | Buy now |
| 7 | 66M-45136-00 Pipe | Buy now |
| 8 | 66M-45128-00 Seal 2 | Buy now |
| 9 | 90157-06M06 Screw, pan head(6m7) | Buy now |

Valve




B2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M-12111-00 Valve, intake | Buy now |
| 2 | 66M-12121-00 Valve, exhaust | Buy now |
| 3 | 66M-12116-00 Seat, valve spring | Buy now |
| 4 | 66M-12113-00 Spring, valve inner | Buy now |
| 5 | 30X-12117-00 Retainer, valve spring | Buy now |
| 6 | 30X-12118-00 Cotter, valve | Buy now |
| 7 | 51Y-12119-00 Seal, valve stem | Buy now |
| 8 | 66M-12146-00 Shaft, rocker | Buy now |
| 9 | 90387-13M56 Collar (6g8) | Buy now |
| 10 | 90387-13001 Collar | Buy now |
| 11 | 90387-13002 Collar | Buy now |
| 12 | 90501-12M40 Spring, compression (6g8) | Buy now |
| 13 | 90501-12M41 Spring Compression (6G8) | Buy now |
| 14 | 66M-12151-10 Arm, Valve Rocker | Buy now |
| 15 | 62Y-12159-00 Screw Valve Adjusting | Buy now |

Valve

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 62Y-12158-00 Nut, lock | Buy now |



66M0010-1051

B2

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.