



# Yamaha F15AMH 1998

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

<b>Bottom Cowling</b>	3
<b>Bracket 1</b>	5
<b>Bracket 2</b>	8
<b>Carburetor</b>	10
<b>Control</b>	13
<b>Crankshaft &amp; Piston</b>	15
<b>Cylinder &amp; Crankcase</b>	16
<b>Cylinder &amp; Crankcase 2</b>	18
<b>Electrical 1</b>	19
<b>Fuel</b>	21
<b>Fuel 2</b>	23
<b>Generator</b>	24
<b>Intake</b>	25
<b>Lower Casing &amp; Drive 1</b>	27
<b>Lower Casing &amp; Drive 2</b>	31
<b>Oil Pan</b>	33
<b>Oil Pump</b>	35
<b>Repair Kit 1</b>	37
<b>Repair Kit 2</b>	39
<b>Repair Kit 3</b>	40
<b>Starter</b>	42
<b>Steering</b>	45
<b>Steering 2</b>	48
<b>Top Cowling</b>	49
<b>Upper Casing</b>	50
<b>Valve</b>	51


## Bottom Cowling



  
66MJA-8120

Ref	Part	
1	<a href="#">66M42710004D</a> Bottom Cowling Assembly	<a href="#">Buy now</a>
2	<a href="#">975950653500</a> Bolt(j52)	<a href="#">Buy now</a>
3	<a href="#">975950652500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">9048015M3100</a> Grommet (6g1)	<a href="#">Buy now</a>
5	<a href="#">9038706M5200</a> Collar (6g1)	<a href="#">Buy now</a>
6	<a href="#">66M427160000</a> Rubber, seal 1	<a href="#">Buy now</a>
7	<a href="#">66M42738004D</a> Plate, fitting	<a href="#">Buy now</a>
8	<a href="#">9010906M8200</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">66M427250000</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">65W427270000</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">66M42815004D</a> Lever, clamp 1	<a href="#">Buy now</a>
12	<a href="#">9038612M3700</a> Bushing (6f5)	<a href="#">Buy now</a>
13	<a href="#">9038612MA200</a> Bush	<a href="#">Buy now</a>
14	<a href="#">902061205200</a> Washer, wave (666)	<a href="#">Buy now</a>
15	<a href="#">6L2428160000</a> Lever, clamp	<a href="#">Buy now</a>


## Bottom Cowling



66MJA-B120

Ref	Part	
16	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
17	<a href="#">66M427660000</a> Bracket 2	<a href="#">Buy now</a>
18	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
19	<a href="#">6H3443910100</a> Nipple, hose	<a href="#">Buy now</a>
20	<a href="#">66M263260000</a> Grommet	<a href="#">Buy now</a>
21	<a href="#">682427270000</a> Grommet	<a href="#">Buy now</a>
22	<a href="#">682427240000</a> Grommet	<a href="#">Buy now</a>
23	<a href="#">65W427260000</a> Grommet	<a href="#">Buy now</a>
24	<a href="#">66M427430000</a> Bracket	<a href="#">Buy now</a>
26	<a href="#">9046525M5700</a> Clamp(63v)	<a href="#">Buy now</a>


## Bracket 1



66MJA-8130

Ref	Part	
1	<a href="#">63V43111034D</a> Clamp bracket set	<a href="#">Buy now</a>
2	<a href="#">63V43112044D</a> Clamp bracket set	<a href="#">Buy now</a>
3	<a href="#">66M821480000</a> Wire, lead 4	<a href="#">Buy now</a>
4	<a href="#">978850600800</a> Screw, pan head(6a3)	<a href="#">Buy now</a>
5	<a href="#">978850801000</a> Rivet	<a href="#">Buy now</a>
6	<a href="#">6EEG31180000</a> Handle, transom cl	<a href="#">Buy now</a>
7	<a href="#">9024304M0100</a> Pin(6a1)	<a href="#">Buy now</a>
8	<a href="#">6E7431160000</a> Screw, transom clamp	<a href="#">Buy now</a>
9	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
10	<a href="#">63V431311000</a> Bolt, clamp bracket	<a href="#">Buy now</a>
11	<a href="#">9020222M5400</a> Washer, plate(63v)	<a href="#">Buy now</a>
12	<a href="#">9038622M9400</a> Bush(63v)	<a href="#">Buy now</a>
14	<a href="#">66M431130000</a> Plate Clamp Bracket	<a href="#">Buy now</a>
15	<a href="#">63V431450000</a> Nut, self-locking	<a href="#">Buy now</a>
16	<a href="#">9038706M1300</a> Collar(6h6)	<a href="#">Buy now</a>


## Bracket 1



66MJA-8130

Ref	Part	
17	<a href="#">9010106M2900</a> Bolt, hexagon (682)	<a href="#">Buy now</a>
18	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
20	<a href="#">6L2431600100</a> Tilt rod assembly	<a href="#">Buy now</a>
21	<a href="#">63V43311024D</a> Bracket, swivel	<a href="#">Buy now</a>
22	<a href="#">63V436300000</a> Tilt lever assembly	<a href="#">Buy now</a>
23	<a href="#">682433180100</a> Cover	<a href="#">Buy now</a>
24	<a href="#">63V431910000</a> Shaft, stopper	<a href="#">Buy now</a>
25	<a href="#">9038607M9500</a> Bush(63v)	<a href="#">Buy now</a>
26	<a href="#">66M433500000</a> Receiver Assembly	<a href="#">Buy now</a>
27	<a href="#">9050720M0000</a> Spring, tension(63v)	<a href="#">Buy now</a>
28	<a href="#">63V436410000</a> Lever, Tilt	<a href="#">Buy now</a>
29	<a href="#">916903001200</a> Pin, spring	<a href="#">Buy now</a>
30	<a href="#">990800560000</a> Circlip(22k)	<a href="#">Buy now</a>
32	<a href="#">63V436150000</a> Plate, Tilt Lock	<a href="#">Buy now</a>


## Bracket 1



66MJA-8130


Ref	Part	
33	<a href="#">63V436110000</a> Shaft, Tilt Lock	<a href="#">Buy now</a>
34	<a href="#">934300502700</a> Circlip(22k)	<a href="#">Buy now</a>
35	<a href="#">63V436590000</a> Shaft, reverse lock	<a href="#">Buy now</a>
37	<a href="#">63V436170000</a> Rod, Tilt Lock	<a href="#">Buy now</a>
38	<a href="#">9050726M0000</a> Spring, tension(63v)	<a href="#">Buy now</a>
39	<a href="#">63V431810000</a> Lever, tilt stop 1	<a href="#">Buy now</a>
40	<a href="#">9010906M8400</a> Bolt	<a href="#">Buy now</a>
41	<a href="#">9020610M2400</a> Washer, wave	<a href="#">Buy now</a>

## Bracket 2



Ref	Part	
1	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
2	<a href="#">63V425280000</a> Plate, friction	<a href="#">Buy now</a>
3	<a href="#">689433730100</a> Seal, damper	<a href="#">Buy now</a>
4	<a href="#">9010506M0700</a> Bolt (689)	<a href="#">Buy now</a>
5	<a href="#">66M821270000</a> Wire, Lead 2	<a href="#">Buy now</a>
6	<a href="#">66M42511114D</a> Bracket, steering	<a href="#">Buy now</a>
7	<a href="#">63V425370000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
8	<a href="#">903863004800</a> Bush	<a href="#">Buy now</a>
9	<a href="#">9321029M9400</a> O-ring(6h1)	<a href="#">Buy now</a>
10	<a href="#">9038630M6000</a> Bush(6j8)	<a href="#">Buy now</a>
11	<a href="#">9011608M5400</a> Bolt, stud(63v)	<a href="#">Buy now</a>
12	<a href="#">9020108M0600</a> Washer, plate	<a href="#">Buy now</a>
13	<a href="#">66M44514004D</a> Mount damper, upper side	<a href="#">Buy now</a>
14	<a href="#">66M445260000</a> Plate	<a href="#">Buy now</a>
15	<a href="#">953800860000</a> Nut (661)	<a href="#">Buy now</a>


## Bracket 2



66MNV-8150


Ref	Part	
16	<a href="#">66M443660000</a> Damper, water seal	<a href="#">Buy now</a>
17	<a href="#">975750652500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
18	<a href="#">66M44551004D</a> Housing, lower mount rubber 1	<a href="#">Buy now</a>
19	<a href="#">66M445570000</a> Mount damper, lower front	<a href="#">Buy now</a>
20	<a href="#">68244553000</a> Mount damper, lower side	<a href="#">Buy now</a>
21	<a href="#">9011908M4500</a> Bolt, with washer	<a href="#">Buy now</a>
22	<a href="#">9011908M4600</a> Bolt, with washer	<a href="#">Buy now</a>
23	<a href="#">9017908M3400</a> Nut	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
1	<a href="#">66M143010000</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">66M143810200</a> Body Float Chamber	<a href="#">Buy now</a>
3	<a href="#">62Y143830000</a> Screw, drain	<a href="#">Buy now</a>
4	<a href="#">66M143980000</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">677143830100</a> Screw, drain	<a href="#">Buy now</a>
6	<a href="#">6L2143980000</a> Gasket	<a href="#">Buy now</a>
7	<a href="#">66M143250000</a> Screw, pan head	<a href="#">Buy now</a>
8	<a href="#">66M143770000</a> Stopper	<a href="#">Buy now</a>
9	<a href="#">66M149580000</a> Cover, diaphragm	<a href="#">Buy now</a>
10	<a href="#">66M143680100</a> Diaphragm assembly 1	<a href="#">Buy now</a>
11	<a href="#">6G8142750200</a> Spring	<a href="#">Buy now</a>
12	<a href="#">66M142390000</a> Seal	<a href="#">Buy now</a>
13	<a href="#">66M142250000</a> Cap	<a href="#">Buy now</a>
14	<a href="#">66M143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
15	<a href="#">6L2143850000</a> Float	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
16	<a href="#">6E5143860100</a> Pin, float	<a href="#">Buy now</a>
17	<a href="#">6L2143920000</a> Valve, needle	<a href="#">Buy now</a>
18	<a href="#">979800411000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
19	<a href="#">6L2141570000</a> Cover, mixing	<a href="#">Buy now</a>
20	<a href="#">62Y143990000</a> Gasket	<a href="#">Buy now</a>
21	<a href="#">66M143410000</a> Nozzle Main	<a href="#">Buy now</a>
22	<a href="#">66M143435200</a> Jet, main (#104)	<a href="#">Buy now</a>
23	<a href="#">66M143422300</a> Jet, pilot (#45)	<a href="#">Buy now</a>
24	<a href="#">66M143550000</a> Plug	<a href="#">Buy now</a>
25	<a href="#">12V141050000</a> Pilot screw set	<a href="#">Buy now</a>
26	<a href="#">30X143340000</a> Spring, air adjusting	<a href="#">Buy now</a>
27	<a href="#">62Y143210000</a> Screw, throttle	<a href="#">Buy now</a>
28	<a href="#">979800411200</a> Screw, pan head (686)	<a href="#">Buy now</a>
29	<a href="#">5H0143970000</a> O-ring	<a href="#">Buy now</a>
30	<a href="#">989800400600</a> Screw, bind(612)	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
31	<a href="#">646142120100</a> Spring, pilot adjusting	<a href="#">Buy now</a>
32	<a href="#">6F5143970000</a> O-ring	<a href="#">Buy now</a>
33	<a href="#">66M142720000</a> Valve, check seat	<a href="#">Buy now</a>
34	<a href="#">66M148270000</a> Filter	<a href="#">Buy now</a>
36	<a href="#">66M141570000</a> Cover Mixing	<a href="#">Buy now</a>
37	<a href="#">985800300500</a> Screw, pan head(78g)	<a href="#">Buy now</a>
38	<a href="#">69M245330000</a> O-ring	<a href="#">Buy now</a>

# Control




Ref	Part	
1	<a href="#">65W441210000</a> Lever, shift rod	<a href="#">Buy now</a>
2	<a href="#">66M441220000</a> Bushing, shift rod lever	<a href="#">Buy now</a>
3	<a href="#">916903032000</a> Pin, spring	<a href="#">Buy now</a>
4	<a href="#">6F5416620000</a> Bracket 2	<a href="#">Buy now</a>
5	<a href="#">9010906M8100</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">65W441160000</a> Spring	<a href="#">Buy now</a>
7	<a href="#">66M441170000</a> Bracket	<a href="#">Buy now</a>
8	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">66M441430000</a> Rod, shift	<a href="#">Buy now</a>
10	<a href="#">901700601500</a> Connector, shift rod	<a href="#">Buy now</a>
11	<a href="#">9538R0670000</a> Nut	<a href="#">Buy now</a>
12	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>
23	<a href="#">65W416380000</a> Pulley	<a href="#">Buy now</a>
24	<a href="#">65W412830000</a> Lever, free accel.	<a href="#">Buy now</a>
25	<a href="#">661412620200</a> Joint, choke lever	<a href="#">Buy now</a>

## Control



Ref	Part	
26	<a href="#">9038706M0800</a> Collar	<a href="#">Buy now</a>
27	<a href="#">66M412110000</a> Link, accel.	<a href="#">Buy now</a>
28	<a href="#">65W144970000</a> Stay, Throttle Wire	<a href="#">Buy now</a>
29	<a href="#">9020106M3100</a> Washer (6a0)	<a href="#">Buy now</a>
30	<a href="#">975950655500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
31	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>


## Crankshaft & Piston



66MJA-8030


Ref	Part	
1	<a href="#">9310235M5100</a> Oil seal	<a href="#">Buy now</a>
2	<a href="#">9310225M5200</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">66M114110000</a> Crankshaft	<a href="#">Buy now</a>
4	<a href="#">66M114162000</a> Plane bearing, crankshaft 1	<a href="#">Buy now</a>
5	<a href="#">66M116500000</a> Connecting rod kit	<a href="#">Buy now</a>
6	<a href="#">66M116540000</a> Bolt, connecting rod	<a href="#">Buy now</a>
7	<a href="#">9020107M0100</a> Washer, plate	<a href="#">Buy now</a>
8	<a href="#">66M116360000</a> Piston (0.50Mm O/S)	<a href="#">Buy now</a>
9	<a href="#">66M116030000</a> Piston ring set (std)	<a href="#">Buy now</a>
10	<a href="#">634116330000</a> Pin, piston	<a href="#">Buy now</a>
11	<a href="#">934501502300</a> Circlip 131116340000	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
1	<a href="#">66MW009B004D</a> Cylinder Block assembly (With Reli	<a href="#">Buy now</a>
2	<a href="#">66M151000094</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">995301011400</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
4	<a href="#">9011908M2000</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">9011906M1400</a> Bolt, with washer (677)	<a href="#">Buy now</a>
6	<a href="#">6E5243770000</a> Pipe, joint	<a href="#">Buy now</a>
7	<a href="#">9044510M4600</a> Hose (I200)	<a href="#">Buy now</a>
8	<a href="#">66M113250000</a> Anode	<a href="#">Buy now</a>
9	<a href="#">66M113270094</a> Cover, anode	<a href="#">Buy now</a>
10	<a href="#">66M113280000</a> Grommet, anode	<a href="#">Buy now</a>
11	<a href="#">975130652000</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
12	<a href="#">975950551200</a> Bolt, hexagon	<a href="#">Buy now</a>
13	<a href="#">66M125350000</a> Plate	<a href="#">Buy now</a>
14	<a href="#">66M111680094</a> Cover, Breather	<a href="#">Buy now</a>
16	<a href="#">66M113570000</a> Seal, cylinder 3	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
17	<a href="#">970240602000</a> Bolt(3dm)	<a href="#">Buy now</a>
18	<a href="#">66M113510000</a> Gasket, cylinder	<a href="#">Buy now</a>
19	<a href="#">66M124110000</a> Thermostat	<a href="#">Buy now</a>
20	<a href="#">6H3124130000</a> Cover, thermostat	<a href="#">Buy now</a>
21	<a href="#">62Y124140000</a> Gasket, cover	<a href="#">Buy now</a>
22	<a href="#">3FV134400000</a> Element assembly, oil cleaner	<a href="#">Buy now</a>
23	<a href="#">9040120M0000</a> Bolt, union(62y)	<a href="#">Buy now</a>
24	<a href="#">66M41113009M</a> Outer Cover, Exhaust	<a href="#">Buy now</a>
25	<a href="#">676113720000</a> Nipple, hose	<a href="#">Buy now</a>
26	<a href="#">66M411140100</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
27	<a href="#">975130653000</a> Bolt, with washer(63m)	<a href="#">Buy now</a>
28	<a href="#">904450906100</a> Hose (L65)	<a href="#">Buy now</a>
29	<a href="#">688243780000</a> Pipe, joint	<a href="#">Buy now</a>
30	<a href="#">904450908600</a> Hose (I1500)	<a href="#">Buy now</a>
31	<a href="#">904450910500</a> Hose (I420)	<a href="#">Buy now</a>

## Cylinder & Crankcase 2





Ref	Part	
1	<a href="#">66MW009A004D</a> Cylinder Head Complete	<a href="#">Buy now</a>
2	<a href="#">66M111110094</a> Head, Cylinder 1	<a href="#">Buy now</a>
3	<a href="#">66M111331000</a> Guide Valve 1	<a href="#">Buy now</a>
4	<a href="#">9345009M0100</a> Circlip (6g8)	<a href="#">Buy now</a>
5	<a href="#">66M111810000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
6	<a href="#">995101011400</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
7	<a href="#">9010508M7800</a> Bolt, washer based	<a href="#">Buy now</a>
8	<a href="#">975130652500</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
9	<a href="#">66M111910094</a> Cover Cylinder Head 1	<a href="#">Buy now</a>
10	<a href="#">66M113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
11	<a href="#">975130652000</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
12	<a href="#">6G8153630000</a> Plug, oil	<a href="#">Buy now</a>
13	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">947010037500</a> Plug, spark (dpr6ea-9)(62y)	<a href="#">Buy now</a>

# Electrical 1




# Electrical 1




Ref	Part	
16	<a href="#">9020106M0800</a> Washer, plate(6e3)	<a href="#">Buy now</a>
17	<a href="#">975950652500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
18	<a href="#">9046409M1300</a> Clamp (6h1)	<a href="#">Buy now</a>
19	<a href="#">6J8819600000</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
21	<a href="#">975950651600</a> Bolt, with washer(6r6)	<a href="#">Buy now</a>

# Fuel



Ref	Part	
1	<a href="#">6G1243040200</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
3	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">9044510M4300</a> Hose (I400)	<a href="#">Buy now</a>
5	<a href="#">65W242510000</a> Strainer 1	<a href="#">Buy now</a>
6	<a href="#">9044510M2000</a> Hose (I400)	<a href="#">Buy now</a>
7	<a href="#">9046709M0900</a> Clip(6k8)	<a href="#">Buy now</a>
8	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
9	<a href="#">66M244101100</a> Fuel pump assembly	<a href="#">Buy now</a>
10	<a href="#">66M244130000</a> Body 2	<a href="#">Buy now</a>
11	<a href="#">6A0244210100</a> Valve, check	<a href="#">Buy now</a>
12	<a href="#">66M244110100</a> Diaphragm	<a href="#">Buy now</a>
13	<a href="#">66M244230000</a> Spring, diaphragm	<a href="#">Buy now</a>
14	<a href="#">66M131310000</a> Plunger	<a href="#">Buy now</a>
15	<a href="#">66M244540000</a> Spring	<a href="#">Buy now</a>


# Fuel



66MJA-8100


Ref	Part	
16	<a href="#">66M244440000</a> Screw	<a href="#">Buy now</a>
17	<a href="#">66M244710100</a> Diaphragm	<a href="#">Buy now</a>
18	<a href="#">6A0143250000</a> Screw, pan head	<a href="#">Buy now</a>
19	<a href="#">953800560000</a> Nut, hexagon (663)	<a href="#">Buy now</a>
20	<a href="#">66M243740000</a> Pin	<a href="#">Buy now</a>
21	<a href="#">978800603000</a> Screw, pan head(6e0)	<a href="#">Buy now</a>
22	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
23	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
24	<a href="#">9321020M6500</a> O-ring	<a href="#">Buy now</a>
25	<a href="#">9044510M4000</a> Hose (l400)	<a href="#">Buy now</a>
27	<a href="#">9046508M0700</a> Clamp (1e6)	<a href="#">Buy now</a>
28	<a href="#">9046409M3100</a> Clamp(6m7)	<a href="#">Buy now</a>
29	<a href="#">62Y281000000</a> Tool kit	<a href="#">Buy now</a>

## Fuel 2




Ref	Part	
1	<a href="#">6YL242010000</a> Fuel Tank Assembly (12 L)	<a href="#">Buy now</a>
2	<a href="#">6YL246100000</a> Cap Assembly	<a href="#">Buy now</a>
3	<a href="#">6YL246410000</a> Gasket, cap 1	<a href="#">Buy now</a>
4	<a href="#">6YL242600100</a> Fuel meter assembly	<a href="#">Buy now</a>
5	<a href="#">985860501600</a> Screw, pan head	<a href="#">Buy now</a>
6	<a href="#">6Y1243290000</a> Seal	<a href="#">Buy now</a>
7	<a href="#">6YL242680000</a> Gasket, fuel meter	<a href="#">Buy now</a>
8	<a href="#">6YL243066400</a> Fuel pipe comp. 1	<a href="#">Buy now</a>
9	<a href="#">9044511M0600</a> Hose (13000)	<a href="#">Buy now</a>
10	<a href="#">6Y1243605100</a> Primer pump assembly	<a href="#">Buy now</a>
11	<a href="#">9044511M0500</a> Hose (11000)	<a href="#">Buy now</a>
12	<a href="#">650243515100</a> Band 1	<a href="#">Buy now</a>
13	<a href="#">6G1243050100</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>
14	<a href="#">932100828700</a> O-ring (655)	<a href="#">Buy now</a>
15	<a href="#">6Y1243050200</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>

# Generator




Ref	Part	
1	<a href="#">66M855500000</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">66M855200000</a> Coil, charge	<a href="#">Buy now</a>
3	<a href="#">66M855800000</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">66M855330000</a> Coil, Lighting	<a href="#">Buy now</a>
5	<a href="#">975950662500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
6	<a href="#">9011906M4100</a> Bolt, with washer(6r6)	<a href="#">Buy now</a>
7	<a href="#">975950653000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
8	<a href="#">902800501300</a> Key, woodruff	<a href="#">Buy now</a>
9	<a href="#">9017916M0500</a> Nut (689)	<a href="#">Buy now</a>
10	<a href="#">9020116M4400</a> Washer (689)	<a href="#">Buy now</a>

# Intake




Ref	Part	
1	<a href="#">66M136410094</a> Manifold 1	<a href="#">Buy now</a>
2	<a href="#">66M136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
3	<a href="#">975950654000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
5	<a href="#">66M136460000</a> Gasket, manifold 2	<a href="#">Buy now</a>
6	<a href="#">66M142710000</a> Insulator	<a href="#">Buy now</a>
7	<a href="#">66M144400000</a> Silencer assembly, intake	<a href="#">Buy now</a>
8	<a href="#">9321035M8600</a> O-ring(612)	<a href="#">Buy now</a>
9	<a href="#">9011906M7600</a> Bolt, with washer	<a href="#">Buy now</a>
10	<a href="#">9038706M7900</a> Collar	<a href="#">Buy now</a>
11	<a href="#">66M144770000</a> Plate	<a href="#">Buy now</a>
12	<a href="#">66M412710000</a> Knob, choke	<a href="#">Buy now</a>
13	<a href="#">689412730000</a> Grommet	<a href="#">Buy now</a>
14	<a href="#">66M412920000</a> Bush 2	<a href="#">Buy now</a>
15	<a href="#">66M412980000</a> Washer 2	<a href="#">Buy now</a>

## Intake




Ref	Part	
16	<a href="#">977805051000</a> Screw, tapping(6u1)	<a href="#">Buy now</a>
17	<a href="#">66M412520000</a> Lever, choke 1	<a href="#">Buy now</a>
18	<a href="#">9024005M2000</a> Pin, clevis	<a href="#">Buy now</a>
19	<a href="#">902060500500</a> Washer, wave(656)	<a href="#">Buy now</a>
20	<a href="#">916902001600</a> Pin, spring (677)	<a href="#">Buy now</a>
21	<a href="#">902020508800</a> Washer, plate (666)	<a href="#">Buy now</a>
22	<a href="#">6R5412370000</a> Joint, link	<a href="#">Buy now</a>
23	<a href="#">66M412560000</a> Rod, choke 1	<a href="#">Buy now</a>
24	<a href="#">66M153730000</a> Pipe, breather	<a href="#">Buy now</a>
25	<a href="#">9046508M7100</a> Clamp	<a href="#">Buy now</a>
26	<a href="#">9046508M7200</a> Clamp	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
1	<a href="#">66M45300004D</a> Lower unit assembly	<a href="#">Buy now</a>
2	<a href="#">63V45311018D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93315314V800</a> Bearing, needle (6e7)	<a href="#">Buy now</a>
4	<a href="#">63V455360000</a> Sleeve, drive shaft	<a href="#">Buy now</a>
5	<a href="#">933414141400</a> Bearing	<a href="#">Buy now</a>
6	<a href="#">6E8455870013</a> Shim (t:1.13mm)	<a href="#">Buy now</a>
7	<a href="#">933320000500</a> Brg,cyl-cal roller 0.19g nt	<a href="#">Buy now</a>
8	<a href="#">664455670130</a> Shim (t:0.30mm)	<a href="#">Buy now</a>
9	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
10	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">63V443010000</a> Water pump housing comp.	<a href="#">Buy now</a>
12	<a href="#">63V443220000</a> Insert, cartridge	<a href="#">Buy now</a>
13	<a href="#">647443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
14	<a href="#">63V443520100</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">664443380000</a> Key, woodruff	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
16	<a href="#">932104470400</a> O-ring(55x)	<a href="#">Buy now</a>
17	<a href="#">63V443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
18	<a href="#">9360412M0700</a> Pin, dowel (688)	<a href="#">Buy now</a>
19	<a href="#">970800804500</a> Bolt, hexagon	<a href="#">Buy now</a>
20	<a href="#">63V443280100</a> Plate	<a href="#">Buy now</a>
21	<a href="#">63V45331005B</a> Housing, bearing	<a href="#">Buy now</a>
22	<a href="#">903811402000</a> Bushing, drive shaft 1	<a href="#">Buy now</a>
23	<a href="#">931022048400</a> Oil seal	<a href="#">Buy now</a>
24	<a href="#">63V45315A000</a> Packing, lower casing	<a href="#">Buy now</a>
25	<a href="#">9321006ME600</a> O-ring	<a href="#">Buy now</a>
26	<a href="#">970800802500</a> Screw, bind(j36)	<a href="#">Buy now</a>
27	<a href="#">66M441501000</a> Shift cam assembly	<a href="#">Buy now</a>
28	<a href="#">63V455100100</a> Drive shaft assembly	<a href="#">Buy now</a>
29	<a href="#">63V455510000</a> Pinion	<a href="#">Buy now</a>
30	<a href="#">9017908M0600</a> Nut (6e7)	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
31	<a href="#">6E7455600100</a> Gear	<a href="#">Buy now</a>
32	<a href="#">6E7455710000</a> Gear 2	<a href="#">Buy now</a>
33	<a href="#">626455774000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>
34	<a href="#">902011768200</a> Washer, plate (2k7)	<a href="#">Buy now</a>
35	<a href="#">683456110000</a> Shaft propeller	<a href="#">Buy now</a>
36	<a href="#">650456350000</a> Plunger, shift	<a href="#">Buy now</a>
37	<a href="#">682456310000</a> Clutch, dog	<a href="#">Buy now</a>
38	<a href="#">902500501000</a> Pin straight 648456320000	<a href="#">Buy now</a>
39	<a href="#">648456330000</a> Ring, cross pin	<a href="#">Buy now</a>
40	<a href="#">9050114M0600</a> Spring, compression	<a href="#">Buy now</a>
41	<a href="#">68345361028D</a> Cap, lower casing	<a href="#">Buy now</a>
42	<a href="#">933060050100</a> Bearing(1ff)	<a href="#">Buy now</a>
43	<a href="#">93315317U200</a> Brg,cyl-cal roller 14g (683)	<a href="#">Buy now</a>
44	<a href="#">931011705400</a> Oil seal (17x30x6-650)	<a href="#">Buy now</a>
45	<a href="#">9321057M0900</a> O-ring (683)	<a href="#">Buy now</a>

## Lower Casing & Drive 1



Ref	Part	
46	<a href="#">9321056M8000</a> O-ring(6j8)	<a href="#">Buy now</a>
47	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
48	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>


## Lower Casing & Drive 2



66MJA-8200


Ref	Part	
1	<a href="#">66M443610000</a> Tube, Water 1	<a href="#">Buy now</a>
2	<a href="#">63V443651000</a> Damper, water seal 1	<a href="#">Buy now</a>
3	<a href="#">63V443680000</a> Rubber, water seal 4	<a href="#">Buy now</a>
4	<a href="#">9360410M0300</a> Pin, dowel (688)	<a href="#">Buy now</a>
5	<a href="#">975750853000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
6	<a href="#">6G1452140000</a> Cover, water inlet	<a href="#">Buy now</a>
7	<a href="#">63V452150000</a> Cover, water inlet	<a href="#">Buy now</a>
8	<a href="#">986800552500</a> Ybs53-525 screw,flat head	<a href="#">Buy now</a>
9	<a href="#">901850500200</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
10	<a href="#">61N452510000</a> Anode	<a href="#">Buy now</a>
11	<a href="#">958950603000</a> Bolt, flange deep recess	<a href="#">Buy now</a>
12	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
13	<a href="#">63V453750000</a> Damper, seal	<a href="#">Buy now</a>
14	<a href="#">6E7459870100</a> Spacer	<a href="#">Buy now</a>
15	<a href="#">9020110M0100</a> Washer, plate(6m7)	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
16	<a href="#">9017110M0100</a> Nut castle (683)	<a href="#">Buy now</a>
17	<a href="#">914903002000</a> Pin cotter	<a href="#">Buy now</a>
18	<a href="#">683459520000</a> Propeller (3X9-1/4"x9-3/4"-J)	<a href="#">Buy now</a>
19	<a href="#">66M453710000</a> Tab-trim	<a href="#">Buy now</a>
20	<a href="#">975950651600</a> Bolt, with washer(6r6)	<a href="#">Buy now</a>

# Oil Pan




Ref	Part	
1	<a href="#">66M41137005B</a> Guide, exhaust	<a href="#">Buy now</a>
2	<a href="#">9310113M2700</a> Oil seal (6g8)	<a href="#">Buy now</a>
3	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
4	<a href="#">66M113550000</a> Seal, cylinder 1	<a href="#">Buy now</a>
5	<a href="#">970800602000</a> Bolt(7u8)	<a href="#">Buy now</a>
6	<a href="#">66M411310000</a> Manifold, Ext. 1	<a href="#">Buy now</a>
7	<a href="#">66M411330000</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
8	<a href="#">9011906M4100</a> Bolt, with washer(6r6)	<a href="#">Buy now</a>
9	<a href="#">66M411380000</a> Seal, ext. 1	<a href="#">Buy now</a>
10	<a href="#">66M134210000</a> Strainer 2	<a href="#">Buy now</a>
11	<a href="#">66M134170000</a> Cover, Strainer	<a href="#">Buy now</a>
12	<a href="#">66M134160000</a> Pipe Oil 1	<a href="#">Buy now</a>
13	<a href="#">66M243510000</a> Band 1	<a href="#">Buy now</a>
14	<a href="#">6G8115750000</a> Relief valve ass'y	<a href="#">Buy now</a>
15	<a href="#">9034014M0600</a> Plug, straight screw(62y)	<a href="#">Buy now</a>

## Oil Pan




Ref	Part	
16	<a href="#">9043014M0900</a> Gasket	<a href="#">Buy now</a>
17	<a href="#">66M153160000</a> Damper 1	<a href="#">Buy now</a>
18	<a href="#">66M153620000</a> Plug, Oil Level	<a href="#">Buy now</a>

# Oil Pump




Ref	Part	
1	<a href="#">9310218M2100</a> Oil seal (6g8)	<a href="#">Buy now</a>
2	<a href="#">66M121710000</a> Camshaft 1	<a href="#">Buy now</a>
3	<a href="#">66M115370094</a> Gear, driven	<a href="#">Buy now</a>
4	<a href="#">970140601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">902011320100</a> Washer 6474283300	<a href="#">Buy now</a>
6	<a href="#">9020106M9400</a> Washer (6g8)	<a href="#">Buy now</a>
7	<a href="#">66M115360000</a> Gear, drive	<a href="#">Buy now</a>
8	<a href="#">66M115570000</a> Washer 1	<a href="#">Buy now</a>
9	<a href="#">9017028M3700</a> Nut	<a href="#">Buy now</a>
10	<a href="#">9028003M0100</a> Key woodruff 146115450000	<a href="#">Buy now</a>
11	<a href="#">66M462410000</a> Belt	<a href="#">Buy now</a>
12	<a href="#">66M462970000</a> Cover, dust	<a href="#">Buy now</a>
13	<a href="#">9048010M1600</a> Grommet(6g8)	<a href="#">Buy now</a>
14	<a href="#">904801207200</a> Grommet(53y)	<a href="#">Buy now</a>
15	<a href="#">66M133000000</a> Oil pump assembly	<a href="#">Buy now</a>

## Oil Pump




Ref	Part	
16	<a href="#">9321027ME300</a> O-ring	<a href="#">Buy now</a>
17	<a href="#">66M133290000</a> Gasket, Pump Cover	<a href="#">Buy now</a>
18	<a href="#">975950653500</a> Bolt(j52)	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">66MW00010000</a> Power Head Gasket Kit	<a href="#">Buy now</a>
2	<a href="#">66M113570000</a> Seal, cylinder 3	<a href="#">Buy now</a>
3	<a href="#">66M113510000</a> Gasket, cylinder	<a href="#">Buy now</a>
4	<a href="#">62Y124140000</a> Gasket, cover	<a href="#">Buy now</a>
5	<a href="#">66M411140100</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
6	<a href="#">66M111810000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
7	<a href="#">66M113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
8	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>
9	<a href="#">9310235M5100</a> Oil seal	<a href="#">Buy now</a>
10	<a href="#">9310225M5200</a> Oil seal	<a href="#">Buy now</a>
11	<a href="#">66M136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
12	<a href="#">66M136460000</a> Gasket, manifold 2	<a href="#">Buy now</a>
13	<a href="#">9321035M8600</a> O-ring(6l2)	<a href="#">Buy now</a>
14	<a href="#">9310218M2100</a> Oil seal (6g8)	<a href="#">Buy now</a>
15	<a href="#">902800301700</a> Key woodruff 146115450000	<a href="#">Buy now</a>

## Repair Kit 1



Ref	Part	
16	<a href="#">9321027ME300</a> O-ring	<a href="#">Buy now</a>
17	<a href="#">66M133290000</a> Gasket, Pump Cover	<a href="#">Buy now</a>
18	<a href="#">9321020M6500</a> O-ring	<a href="#">Buy now</a>


## Repair Kit 2



66MJA-8260


Ref	Part	
1	<a href="#">66MW00930000</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">66M143980000</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">6L2143980000</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">66M143770000</a> Stopper	<a href="#">Buy now</a>
5	<a href="#">66M143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
6	<a href="#">6L2143850000</a> Float	<a href="#">Buy now</a>
7	<a href="#">6E5143860100</a> Pin, float	<a href="#">Buy now</a>
8	<a href="#">6L2143920000</a> Valve, needle	<a href="#">Buy now</a>
9	<a href="#">62Y143990000</a> Gasket	<a href="#">Buy now</a>
10	<a href="#">5H0143230000</a> Pilot screw set	<a href="#">Buy now</a>
11	<a href="#">979800411200</a> Screw, pan head (686)	<a href="#">Buy now</a>
12	<a href="#">62Y143970000</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">6F5143970000</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">66M148270000</a> Filter	<a href="#">Buy now</a>

# Repair Kit 3




Ref	Part	
1	<a href="#">66MW00012000</a> Lower Unit Gasket Kit	<a href="#">Buy now</a>
2	<a href="#">9310113M2700</a> Oil seal (6g8)	<a href="#">Buy now</a>
3	<a href="#">66M411330000</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
4	<a href="#">66M411380000</a> Seal, ext. 1	<a href="#">Buy now</a>
5	<a href="#">9043014M0900</a> Gasket	<a href="#">Buy now</a>
6	<a href="#">66M451130000</a> Gasket, upper casing	<a href="#">Buy now</a>
7	<a href="#">66M451150000</a> Gasket, upper casing	<a href="#">Buy now</a>
8	<a href="#">66M451280000</a> Seal 2	<a href="#">Buy now</a>
9	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
10	<a href="#">63V443220000</a> Insert, cartridge	<a href="#">Buy now</a>
11	<a href="#">63V443520000</a> Impeller	<a href="#">Buy now</a>
12	<a href="#">932104439800</a> O-ring(55x)	<a href="#">Buy now</a>
13	<a href="#">63V443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
14	<a href="#">931022048400</a> Oil seal	<a href="#">Buy now</a>
15	<a href="#">63V45315A000</a> Packing, lower casing	<a href="#">Buy now</a>

## Repair Kit 3




Ref	Part	
16	<a href="#">9321006ME600</a> O-ring	<a href="#">Buy now</a>
17	<a href="#">931011705400</a> Oil seal (17x30x6-650)	<a href="#">Buy now</a>
18	<a href="#">9321057M0900</a> O-ring (683)	<a href="#">Buy now</a>
19	<a href="#">9321056M8000</a> O-ring(6j8)	<a href="#">Buy now</a>
20	<a href="#">63V443651000</a> Damper, water seal 1	<a href="#">Buy now</a>
21	<a href="#">63V443680000</a> Rubber, water seal 4	<a href="#">Buy now</a>
22	<a href="#">63VW00780200</a> Water pump repair kit	<a href="#">Buy now</a>
23	<a href="#">647443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
24	<a href="#">970800804500</a> Bolt, hexagon	<a href="#">Buy now</a>
28	<a href="#">664443380000</a> Key, woodruff	<a href="#">Buy now</a>

# Starter




Ref	Part	
1	<a href="#">66M157100000</a> Starter Assembly	<a href="#">Buy now</a>
2	<a href="#">66M157110000</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">9038706M0500</a> Collar(6h4)	<a href="#">Buy now</a>
4	<a href="#">63V157140000</a> Drum, sheave	<a href="#">Buy now</a>
5	<a href="#">63V157410000</a> Pawl, drive	<a href="#">Buy now</a>
6	<a href="#">63V157130000</a> Spring, starter	<a href="#">Buy now</a>
7	<a href="#">63V157160000</a> Plate, drive	<a href="#">Buy now</a>
8	<a href="#">63V157051000</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">63V157670100</a> Spring	<a href="#">Buy now</a>
10	<a href="#">63V157840100</a> Spring, return	<a href="#">Buy now</a>
11	<a href="#">63V157440000</a> Circlip	<a href="#">Buy now</a>
12	<a href="#">68T157930000</a> Screw	<a href="#">Buy now</a>
13	<a href="#">63V157640000</a> Collar 1	<a href="#">Buy now</a>
15	<a href="#">66T157940000</a> Stopper	<a href="#">Buy now</a>
16	<a href="#">66T157340000</a> Spring, return	<a href="#">Buy now</a>

# Starter




Ref	Part	
17	<a href="#">66M157700000</a> Cable comp., starter stop	<a href="#">Buy now</a>
18	<a href="#">9044606M9000</a> Hose	<a href="#">Buy now</a>
19	<a href="#">66T157310000</a> Retainer, spring	<a href="#">Buy now</a>
20	<a href="#">6G1157550000</a> Handle, starter	<a href="#">Buy now</a>
21	<a href="#">6G1157790000</a> Cover	<a href="#">Buy now</a>
22	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
23	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
24	<a href="#">66M157580000</a> Guide, Rope	<a href="#">Buy now</a>
25	<a href="#">9011906M5900</a> Bolt, with washer	<a href="#">Buy now</a>
26	<a href="#">970950609000</a> Bolt(62y)	<a href="#">Buy now</a>
27	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
28	<a href="#">9020106M0500</a> Washer, plate(6e3)	<a href="#">Buy now</a>
29	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
30	<a href="#">66M157620000</a> Seal Rubber 2	<a href="#">Buy now</a>
31	<a href="#">66M157740000</a> Stay 4	<a href="#">Buy now</a>

## Starter




Ref	Part	
32	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
33	<a href="#">66M843420000</a> Seat, Emblem	<a href="#">Buy now</a>

# Steering




Ref	Part	
1	<a href="#">66MW0084004D</a> Handle steering assembly	<a href="#">Buy now</a>
2	<a href="#">65W42101014D</a> Handle, steering	<a href="#">Buy now</a>
3	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">65W421380000</a> Lever, throttle	<a href="#">Buy now</a>
5	<a href="#">65W421590000</a> Stay	<a href="#">Buy now</a>
6	<a href="#">6G1421260000</a> Piece, friction	<a href="#">Buy now</a>
7	<a href="#">65W421250000</a> Bolt, friction adjusting	<a href="#">Buy now</a>
8	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
9	<a href="#">66M421770000</a> Rubber, handle	<a href="#">Buy now</a>
10	<a href="#">66M421190100</a> Grip, steering handle	<a href="#">Buy now</a>
11	<a href="#">689421372000</a> Indicator, Throttle	<a href="#">Buy now</a>
12	<a href="#">9026902M0900</a> Rivet(615)	<a href="#">Buy now</a>
13	<a href="#">9014905M1300</a> Screw, countersunk	<a href="#">Buy now</a>
14	<a href="#">929901060000</a> Washer, plate	<a href="#">Buy now</a>
15	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>

# Steering




Ref	Part	
16	<a href="#">903860803200</a> Bushing (650)	<a href="#">Buy now</a>
17	<a href="#">66M263110000</a> Cable, throttle 1	<a href="#">Buy now</a>
18	<a href="#">9044610M8700</a> Hose	<a href="#">Buy now</a>
19	<a href="#">9038640MA000</a> Bushing	<a href="#">Buy now</a>
20	<a href="#">9020143M0000</a> Washer, plate	<a href="#">Buy now</a>
21	<a href="#">9020643M2200</a> Washer, wave	<a href="#">Buy now</a>
22	<a href="#">9020243M5700</a> Washer, plate	<a href="#">Buy now</a>
23	<a href="#">9038640M9900</a> Bush	<a href="#">Buy now</a>
24	<a href="#">66M421310100</a> Cover, handle steering	<a href="#">Buy now</a>
25	<a href="#">957800830000</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
26	<a href="#">953801070000</a> Nut (682)	<a href="#">Buy now</a>
27	<a href="#">66M441110100</a> Handle, gear shift	<a href="#">Buy now</a>
28	<a href="#">975950653000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
29	<a href="#">9020610M0400</a> Washer, wave (676)	<a href="#">Buy now</a>
30	<a href="#">9038706M7800</a> Collar	<a href="#">Buy now</a>

# Steering



Ref	Part	
31	<a href="#">66M441240000</a> Link, shift rod	<a href="#">Buy now</a>
32	<a href="#">929900620000</a> Ybs66-6 washer, plain	<a href="#">Buy now</a>
33	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>
34	<a href="#">6X3441910000</a> Indicator, shift	<a href="#">Buy now</a>
37	<a href="#">65W825750000</a> Engine stop switch assembly	<a href="#">Buy now</a>
38	<a href="#">682825560000</a> Lanyard, stop switch	<a href="#">Buy now</a>
39	<a href="#">6898257Y0000</a> Cap	<a href="#">Buy now</a>


## Steering 2



66MJA-8160


Ref	Part	
2	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
3	<a href="#">66M425270000</a> Plate, friction	<a href="#">Buy now</a>
4	<a href="#">9010908M9100</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">65W425620000</a> Shaft, steering lock	<a href="#">Buy now</a>
6	<a href="#">66M425610000</a> Knob Steering Lock	<a href="#">Buy now</a>
7	<a href="#">689436330000</a> Cover, tilt lever	<a href="#">Buy now</a>
8	<a href="#">9020210M5600</a> Washer, plate	<a href="#">Buy now</a>
9	<a href="#">65W425280000</a> Plate, friction	<a href="#">Buy now</a>
10	<a href="#">9020910M2600</a> Washer	<a href="#">Buy now</a>
11	<a href="#">9018510M1400</a> Nut, self-locking	<a href="#">Buy now</a>
12	<a href="#">9038705M1100</a> Collar	<a href="#">Buy now</a>
13	<a href="#">9010905M8900</a> Bolt, with washer	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
1	<a href="#">66M4261A0900</a> Top cowling w/o graphics	<a href="#">Buy now</a>
2	<a href="#">66M426130000</a> Molding Air Duct	<a href="#">Buy now</a>
3	<a href="#">977806052000</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
4	<a href="#">6E0426510200</a> Hook	<a href="#">Buy now</a>
5	<a href="#">9026604M0400</a> Rivet(6e7)	<a href="#">Buy now</a>
6	<a href="#">6E7426520000</a> Hook	<a href="#">Buy now</a>
8	<a href="#">6D4426150000</a> Seal	<a href="#">Buy now</a>
9	<a href="#">66M426781000</a> Graphic, front	<a href="#">Buy now</a>
11	<a href="#">66M426811000</a> Emblem, yamaha	<a href="#">Buy now</a>
12	<a href="#">66M426821000</a> Emblem, yamaha	<a href="#">Buy now</a>
13	<a href="#">9020205M3800</a> Washer, plate(6l2)	<a href="#">Buy now</a>

## Upper Casing



Ref	Part	
1	<a href="#">66M45111004D</a> Casing, upper	<a href="#">Buy now</a>
2	<a href="#">66M451130000</a> Gasket, upper casing	<a href="#">Buy now</a>
3	<a href="#">975750854500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
5	<a href="#">66M451260000</a> Plate, Seal Damper	<a href="#">Buy now</a>
6	<a href="#">66M451150000</a> Gasket, upper casing	<a href="#">Buy now</a>
7	<a href="#">66M451360000</a> Pipe	<a href="#">Buy now</a>
8	<a href="#">66M451280000</a> Seal 2	<a href="#">Buy now</a>
9	<a href="#">9015706M0600</a> Screw, pan head(6m7)	<a href="#">Buy now</a>

# Valve



66MJA-8040

Ref	Part	
1	<a href="#">66M121110000</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">66M121210000</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">66M121160000</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">66M121130000</a> Spring, valve inner	<a href="#">Buy now</a>
5	<a href="#">30X121170000</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">30X121180000</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">6EEE21190000</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">66M121460000</a> Shaft, rocker	<a href="#">Buy now</a>
9	<a href="#">9038713M5600</a> Collar (6g8)	<a href="#">Buy now</a>
10	<a href="#">9050112M4000</a> Spring, compression (6g8)	<a href="#">Buy now</a>
11	<a href="#">9050112M4100</a> Spring Compression (6G8)	<a href="#">Buy now</a>
13	<a href="#">62Y121590000</a> Screw Valve Adjusting	<a href="#">Buy now</a>
14	<a href="#">62Y121580000</a> Nut, lock	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.