



Yamaha F15CE 2007

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

| | |
|-----------------------------------|----|
| BOTTOM COWLING | 3 |
| BRACKET 1 | 7 |
| BRACKET 2 | 10 |
| BRACKET 3 | 13 |
| CARBURETOR | 16 |
| CONTROL 1 | 19 |
| CONTROL 2 | 21 |
| CRANKSHAFT & PISTON | 24 |
| CYLINDER & CRANKCASE 1 | 26 |
| CYLINDER & CRANKCASE 2 | 28 |
| ELECTRICAL 1 | 30 |
| ELECTRICAL 2 | 33 |
| ELECTRICAL 3 | 36 |
| ELECTRICAL 4 | 38 |
| ELECTRICAL 5 | 41 |
| FUEL | 42 |
| FUEL TANK | 46 |
| GENERATOR | 47 |
| INTAKE | 48 |
| LOWER CASING & DRIVE 1 | 50 |
| LOWER CASING & DRIVE 2 | 55 |
| OIL PAN | 57 |
| OIL PUMP | 59 |
| POWER TILT ASSY | 61 |
| REMOTE CONTROL ASSY | 66 |
| REMOTE CONTROL BOX | 71 |
| REPAIR KIT 1 | 72 |
| REPAIR KIT 2 | 74 |
| REPAIR KIT 3 | 75 |
| STARTER | 77 |
| STARTING MOTOR | 80 |
| STEERING | 82 |
| STEERING FRICTION | 85 |
| STEERING GUIDE | 87 |
| TOP COWLING | 88 |
| UPPER CASING | 90 |
| VALVE | 92 |


Bottom Cowling



D7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH42710004D Bottom cowling assembly | Buy now |
| 1 | 6AH42710104D Bottom cowling assembly | Buy now |
| 2 | 68F8511900 Bolt | Buy now |
| 3 | 9048021M82 Grommet | Buy now |
| 4 | 9038706176 Collar | Buy now |
| 5 | 6AH4271600 Rubber, seal 1 | Buy now |
| 6 | 6AH42738004D Plate, fitting | Buy now |
| 7 | 6AH4271800 Rubber, seal 3 | Buy now |
| 8 | 9010906M82 Bolt | Buy now |
| 9 | 6AH4272500 Grommet | Buy now |
| 9 | 6AH4272510 Grommet | Buy now |
| 9 | 6AH4272520 Grommet | Buy now |
| 10 | 6AH4272400 Grommet | Buy now |
| 10 | 6AH4272410 Grommet | Buy now |
| 11 | 6AH4280100 Cowling clamp comp. | Buy now |


Bottom Cowling



D7

| Ref | Part | |
|-----|---|-------------------------|
| 12 | 9709506012 Bolt(gh1) | Buy now |
| 13 | 9299506600 Washer, plain (646) | Buy now |
| 14 | 6H34439101 Nipple, hose | Buy now |
| 15 | 6AH2632600 Grommet | Buy now |
| 15 | 6AH2632610 Grommet | Buy now |
| 16 | 9046511M10 Clamp | Buy now |
| 17 | 6AH4272700 Grommet | Buy now |
| 18 | 65W4272600 Grommet | Buy now |
| 18 | 65W4272610 Grommet | Buy now |
| 19 | 9048016007 Grommet | Buy now |
| 20 | 6AH4272600 Grommet | Buy now |
| 21 | 6AH2431400 Pipe 4 | Buy now |
| 23 | 68T1257200 Adapter | Buy now |
| 24 | 6R31258100 Joint, hose 1 | Buy now |
| 25 | 6R31258200 Joint, hose 2 | Buy now |


Bottom Cowling



D7

| Ref | Part | |
|-----|--|-------------------------|
| 26 | 6R31258300 Gasket, hose joint | Buy now |
| 27 | 6AH1253500 Plate | Buy now |
| 28 | 9016706002 Screw, tapping | Buy now |
| 29 | 9709506010 Bolt | Buy now |
| 31 | 9046412M58 Clamp | Buy now |
| 32 | 65W4271700 Rubber, seal 2 | Buy now |
| 33 | 6AH4274300 Bracket | Buy now |
| 34 | 9010906M86 Bolt | Buy now |
| 35 | 6AH4276100 Stopper | Buy now |
| 36 | 6AH4276200 Stopper | Buy now |
| 37 | 9707506012 Bolt(gh1) | Buy now |
| 39 | 6AH4274100 Apron | Buy now |
| 40 | 9788506030 Screw, pan head(6e0) | Buy now |
| 41 | 9299506100 Washer(6a1) | Buy now |
| 43 | 9538006600 Nut(661) | Buy now |


Bottom Cowling



| Ref | Part | |
|-----|--|-------------------------|
| 44 | 6AH4271700 Rubber, seal 2 | Buy now |
| 45 | 6AH1577400 Stay 4 | Buy now |
| 47 | 9046508M82 Clamp | Buy now |
| 48 | 6C58237700 □□□ | Buy now |
| 49 | 6G81344451 Mark | Buy now |
| 50 | 6E38257H00 Plate Mark | Buy now |
| 51 | 6A12817600 Label Caution | Buy now |

D7


Bracket 1



F3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH4311004D Bracket, clamp 1 | Buy now |
| 2 | 6E04311801 Handle, transom clamp | Buy now |
| 3 | 9024304M01 Pin(6a1) | Buy now |
| 4 | 6E74311600 Screw, transom clamp | Buy now |
| 5 | 6484311401 Pad, transom clamp | Buy now |
| 6 | 6AH43112004D Bracket, clamp 2 | Buy now |
| 11 | 63W4313110 Bolt, clamp bracket FOR REMOTE CONTROL | Buy now |
| 12 | 9038622MA4 Bush | Buy now |
| 13 | 66R4311300 Plate, clamp bracket | Buy now |
| 14 | 9018522043 Nut, self-locking | Buy now |
| 15 | 9038706M13 Collar(6h6) | Buy now |
| 16 | 9010106M18 Bolt(6l5) | Buy now |
| 17 | 9299006600 Washer, plain (646) | Buy now |
| 18 | 9538006700 Nut | Buy now |
| 19 | 6L24316001 Tilt rod assembly | Buy now |


Bracket 1



F3

| Ref | Part | |
|-----|---|-------------------------|
| 20 | 6894316500 Plate, tilt lock | Buy now |
| 21 | 9169030008 Pin. spring(656) | Buy now |
| 22 | 9050210M07 Spring, conical(6k3) | Buy now |
| 23 | 6AH43311004D Bracket, swivel 1 S(17.1") | Buy now |
| 23 | 6AH43311104D Bracket, swivel 1 L(22.1") | Buy now |
| 24 | 6AH4363100 Lever, tilt | Buy now |
| 25 | 6AH4361600 Rod, tilt lock | Buy now |
| 26 | 6AH4364600 Shaft, lever | Buy now |
| 27 | 6AH4364100 Lever, tilt | Buy now |
| 28 | 6AH4319100 Shaft, stopper | Buy now |
| 29 | 9908005600 Circlip(22k) | Buy now |
| 30 | 6AH4361700 Rod, tilt lock | Buy now |
| 32 | 6AH4335000 Receiver assembly | Buy now |
| 33 | 9050618014 Spring, tension | Buy now |
| 34 | 6AH4361400 Plate, tilt lock | Buy now |


Bracket 1



| Ref | Part | |
|-----|---|-------------------------|
| 35 | 9050620020 Spring, tension | Buy now |
| 36 | 6AH4361500 Plate, tilt lock | Buy now |
| 37 | 68T4361100 Shaft, tilt lock | Buy now |
| 38 | 9038706138 Collar | Buy now |
| 39 | 9343004M03 Circlip (eu0) | Buy now |
| 40 | 68T4365900 Shaft, reverse lock | Buy now |
| 42 | 6AH4362700 Stopper | Buy now |
| 43 | 9010906M84 Bolt | Buy now |
| 44 | 9020610M24 Washer, wave | Buy now |

F3

Bracket 2




 6AH1300-F240

F5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 69A43111014D Bracket, clamp 1 | Buy now |
| 2 | 6E04311801 Handle, transom clamp | Buy now |
| 3 | 9024304M01 Pin(6a1) | Buy now |
| 4 | 6E74311600 Screw, transom clamp | Buy now |
| 5 | 6484311401 Pad, transom clamp | Buy now |
| 6 | 69A43112014D Bracket, clamp 2 | Buy now |
| 11 | 9038622MA4 Bush | Buy now |
| 12 | 9018522043 Nut, self-locking | Buy now |
| 13 | 65W4319200 Knob, stopper | Buy now |
| 14 | 65W4319100 Shaft, stopper | Buy now |
| 15 | 9169030018 926-51502-00 pin, spring (700) | Buy now |
| 16 | 9038614MA1 Bush | Buy now |
| 17 | 9010906M04 Bolt | Buy now |
| 18 | 69A43311114D Bracket, swivel 1 L(22.1") | Buy now |
| 19 | 69A4313100 Bolt, clamp bracket FOR REMOTE CONTROL | Buy now |

Bracket 2





6AH1300-F240

F5

| Ref | Part | |
|-----|--|-------------------------|
| 20 | 69A4311300 Plate, clamp bracket | Buy now |
| 21 | 6G54314501 Cap, clamp bracket | Buy now |
| 22 | 9044614MH7 Hose | Buy now |
| 23 | 69A4315500 Mark 1 | Buy now |
| 24 | 9046513M97 Clamp | Buy now |
| 25 | 69G4381800 Pin, lower shock mount | Buy now |
| 26 | 9038616MA7 Bush | Buy now |
| 27 | 9038616MA8 Bush | Buy now |
| 28 | 9038716M02 Collar | Buy now |
| 29 | 9020108M00 Washer, plate(6e0) | Buy now |
| 30 | 9708008016 Bolt | Buy now |
| 31 | 9024912M36 Pin | Buy now |
| 32 | 9038112M10 Bush, solid | Buy now |
| 33 | 9038112M11 Bush, solid | Buy now |
| 34 | 9343010M00 Circlip | Buy now |

Bracket 2





6AH1300-F240

F5

| Ref | Part | |
|-----|---|-------------------------|
| 35 | 9011008081 Bolt, hexagon socket head | Buy now |
| 36 | 9018508057 Nut, nylon (6j8) | Buy now |
| 37 | 9299008600 Washer, plain (663) | Buy now |
| 38 | 9033808M19 Plug L(22.1") | Buy now |
| 39 | 65W4525100 Anode | Buy now |
| 40 | 9010106020 Bolt | Buy now |
| 41 | 63V8212700 Wire, lead 2 | Buy now |
| 42 | 9709506010 Bolt | Buy now |
| 43 | 9299506600 Washer, plain (646) | Buy now |


Bracket 3



F7


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH42510004D Steering bracket assembly S(17.1") | Buy now |
| 1 | 6AH42510104D Steering bracket assembly L(22.1") | Buy now |
| 2 | 9020940008 Washer | Buy now |
| 3 | 9038640001 Bush | Buy now |
| 4 | 9038630048 Bush | Buy now |
| 5 | 9321029M94 O-ring(6h1) | Buy now |
| 6 | 9038630M60 Bush(6j8) | Buy now |
| 7 | 9011610033 Bolt, stud | Buy now |
| 8 | 6AH445140094 Mount damper, upper side | Buy now |
| 9 | 6AH4452600 Plate | Buy now |
| 10 | 9538010600 Nut(624) | Buy now |
| 11 | 9011908094 Bolt, with washer | Buy now |
| 12 | 6AH44551004D Housing, lower mount rubber 1 | Buy now |
| 13 | 6AH4455700 Mount damper, lower front | Buy now |
| 14 | 6AH4455500 Mount damper, lower side | Buy now |

Bracket 3



| Ref | Part | |
|-----|--|-------------------------|
| 15 | 6AH4457400 Stopper, lower mount rubber | Buy now |
| 16 | 9011908M45 Bolt, with washer | Buy now |
| 17 | 9011908M46 Bolt, with washer | Buy now |
| 18 | 9017908M34 Nut | Buy now |
| 19 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 20 | 6AH8212700 Wire, lead 2 | Buy now |
| 20 | 6AH8212710 Wire, lead 2 EP-L(22.1") | Buy now |
| 21 | 63V4252800 Plate, friction Go to P/N)PE0-OM-060028 | Buy now |
| 22 | 6894337301 Seal, damper Go to P/N)PE0-OM-060028 | Buy now |
| 23 | 9010506M07 Bolt (689) Go to P/N)PE0-OM-060028 | Buy now |
| 24 | 6AH4253210 Cover | Buy now |
| 25 | 9011106072 Bolt,hex. socket button | Buy now |
| 26 | 9778060520 Screw, tapping(6k8) | Buy now |
| 27 | 6AH8377300 Bracket, switch | Buy now |
| 28 | 9709506030 Bolt(jf7) | Buy now |


Bracket 3



| Ref | Part | |
|-----|---|-------------------------|
| 29 | 9299506600 Washer, plain (646) | Buy now |
| 30 | 6AH4851100 Hook, steering | Buy now |
| 31 | 9709508025 Bolt (62g) | Buy now |
| 32 | 9299508600 Washer, plain (663) | Buy now |
| 33 | 9018508057 Nut, nylon (6j8) | Buy now |
| 34 | 6AH4419400 Cap | Buy now |

F7


Carburetor



B4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AG1430110 Carburetor assembly 1 | Buy now |
| 1 | 6AG1430150 Carburetor assembly 1 | Buy now |
| 2 | 9858004006 Screw, pan head (7h3) | Buy now |
| 3 | 65W1457200 Plate | Buy now |
| 4 | 65W1412610 Gasket | Buy now |
| 5 | 9798004110 Screw, pan head (e56) | Buy now |
| 6 | 6AG1494802 Jet (#38) FOR 6AG-14301-10 | Buy now |
| 6 | 6AH1494802 Jet (#38) FOR 6AG-14301-50 | Buy now |
| 7 | 6791496600 Rubber cap | Buy now |
| 8 | 9050110326 Spring coil(663)(carb) | Buy now |
| 9 | 63V1452300 Screw, stop | Buy now |
| 10 | 6AH1494710 Jet, needle | Buy now |
| 11 | 6761494319 Jet, main (#80) | Buy now |
| 12 | 6AH1498500 Float | Buy now |
| 13 | 6G11454601 Valve, needle | Buy now |


Carburetor



B4

| Ref | Part | |
|-----|---|-------------------------|
| 14 | 6761418600 Pin, valve | Buy now |
| 15 | 6631415900 Clip | Buy now |
| 16 | 9858004008 Screw, pan head (713) | Buy now |
| 17 | 6H41454800 Pin, float arm | Buy now |
| 18 | 65W1437301 Cover, plunger cap | Buy now |
| 19 | 6AH1437900 Rod, starter | Buy now |
| 20 | 67C1492320 Screw, pilot | Buy now |
| 21 | 67C1439700 O-ring | Buy now |
| 22 | 67C1455500 Spring | Buy now |
| 23 | 65W1433500 Spring, plunger | Buy now |
| 24 | 6AH1437100 Plunger, starter | Buy now |
| 25 | 6AH1438400 Gasket, float chamber | Buy now |
| 26 | 6AH1498000 Body, float chamber | Buy now |
| 27 | 65W1439800 Washer | Buy now |
| 28 | 65W1499200 Screw, drain | Buy now |


Carburetor



B4

| Ref | Part | |
|-----|---|-------------------------|
| 29 | 9798004114 Screw, pan head(ga5) | Buy now |
| 30 | 6AH1438000 Prime starter assembly FOR 6AG-14301-10 | Buy now |
| 30 | 6AH1438010 Prime starter assembly FOR 6AG-14301-50 | Buy now |
| 31 | 9798004108 Screw, with washer(6m6) | Buy now |
| 32 | 6AH1434600 Plate | Buy now |
| 33 | 67C1456700 Screw | Buy now |
| 34 | 65W1434600 Plate | Buy now |


Control 1



E6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH4412300 Arm, shift rod | Buy now |
| 2 | 9025403M05 Pin, spring | Buy now |
| 3 | 6AH4412100 Lever, shift rod | Buy now |
| 4 | 6AH2636400 End, cable 2 | Buy now |
| 5 | 6G1416620194 Bracket | Buy now |
| 6 | 9709506020 Bolt(7u8) | Buy now |
| 7 | 9299506600 Washer, plain (646) | Buy now |
| 8 | 6AH4412500 Lever, shift rod | Buy now |
| 10 | 65W4411600 Spring | Buy now |
| 11 | 66R4411400 Stopper | Buy now |
| 12 | 9589506014 Bolt, flange deep recess | Buy now |
| 13 | 6AH4414300 Rod, shift S(17.1") | Buy now |
| 13 | 6AH4414310 Rod, shift L(22.1") | Buy now |
| 14 | 9017006015 Connector, shift rod | Buy now |
| 15 | 9538006700 Nut | Buy now |


Control 1



E6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AH4163800 Pulley | Buy now |
| 17 | 9050820M44 Spring, torsion | Buy now |
| 18 | 65W4128300 Lever, free accel. | Buy now |
| 19 | 6J84126200 Joint, choke lever | Buy now |
| 20 | 6AH4121100 Link, accel. | Buy now |
| 21 | 9038706139 Collar | Buy now |
| 22 | 9020106M31 Washer (6a0) | Buy now |
| 23 | 9759506555 Bolt, hexagon w/w deep recess | Buy now |
| 24 | 9709506014 Bolt(gj3) | Buy now |
| 25 | 6AH1457100 Bracket, throttle | Buy now |
| 26 | 6AH4416700 Plunger, shift cam | Buy now |
| 27 | 62Y4217100 Bushing | Buy now |
| 28 | 9020105M04 Washer, plate | Buy now |
| 29 | 9046810005 Pin, hair 6264123500 | Buy now |
| 30 | 6AH1449700 Stay, throttle wire | Buy now |


Control 2



F1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH4412300 Arm, shift rod | Buy now |
| 2 | 9025403M05 Pin, spring | Buy now |
| 3 | 6AH4412100 Lever, shift rod | Buy now |
| 4 | 6AH2636400 End, cable 2 | Buy now |
| 5 | 6G1416620194 Bracket | Buy now |
| 6 | 9709506020 Bolt(7u8) | Buy now |
| 7 | 9299506600 Washer, plain (646) | Buy now |
| 8 | 6AH4412500 Lever, shift rod | Buy now |
| 10 | 65W4411600 Spring | Buy now |
| 11 | 66R4411400 Stopper | Buy now |
| 12 | 9589506014 Bolt, flange deep recess | Buy now |
| 13 | 6AH4414300 Rod, shift S(17.1") | Buy now |
| 13 | 6AH4414310 Rod, shift L(22.1") | Buy now |
| 14 | 9017006015 Connector, shift rod | Buy now |
| 15 | 9538006700 Nut | Buy now |


Control 2



F1


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AH4853200 Bracket, remote control 2 | Buy now |
| 17 | 9048019031 Grommet(75v) | Buy now |
| 18 | 6824853850 Clamp, cable | Buy now |
| 19 | 9169030012 Pin, spring | Buy now |
| 20 | 9709506014 Bolt(gj3) | Buy now |
| 22 | 6634834400 Cable end, remote control | Buy now |
| 23 | 9046818008 Clip 620436610000 | Buy now |
| 24 | 6AH4163800 Pulley | Buy now |
| 25 | 9050820M44 Spring, torsion | Buy now |
| 26 | 65W4128300 Lever, free accel. | Buy now |
| 27 | 6J84126200 Joint, choke lever | Buy now |
| 28 | 6AH4121100 Link, accel. | Buy now |
| 29 | 9038706139 Collar | Buy now |
| 30 | 9020106M31 Washer (6a0) | Buy now |
| 31 | 9759506555 Bolt, hexagon w/w deep recess | Buy now |

Control 2



| Ref | Part | |
|-----|---|-------------------------|
| 33 | 6AH1457100 Bracket, throttle | Buy now |
| 34 | 6AH4853100 Bracket, remote control 1 | Buy now |
| 35 | 9010906M86 Bolt | Buy now |

Crankshaft & Piston




6AH1100-F030

A7

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH1141100 Crankshaft | Buy now |
| 2 | 6AH1141600 Plane bearing, crankshaft 1 UR BROWN | Buy now |
| 2 | 6AH1141610 Plane bearing, crankshaft 1 UR BLACK | Buy now |
| 2 | 6AH1141620 Plane bearing, crankshaft 1 UR BLUE | Buy now |
| 3 | 6AH1165000 Connecting rod assembly | Buy now |
| 4 | 6AH1165400 Bolt, connecting rod | Buy now |
| 5 | 6AH1163100 Piston (std) | Buy now |
| 5 | 6AH1163500 Piston (0.25mm o/s) AP | Buy now |
| 5 | 6AH1163600 Piston (0.50mm o/s) AP | Buy now |
| 6 | 6AH1160300 Piston ring set (std) | Buy now |
| 6 | 6AH1160400 Piston ring set (0.25mm o/s) AP | Buy now |
| 6 | 6AH1160500 Piston ring set (0.50mm o/s) AP | Buy now |
| 7 | 1371163310 Pin, piston | Buy now |
| 8 | 9345017129 Circlip(1ar) | Buy now |
| 9 | 9310237004 Oil seal | Buy now |

Crankshaft & Piston


| Ref | Part | |
|-----|--|-------------------------|
| 10 | 9310225014 Oil seal | Buy now |



 6AH1100-F030

A7


Cylinder & Crankcase 1



A5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AHW009B001S Cylinder block assembly | Buy now |
| 2 | 6AH15100001S Crankcase assembly | Buy now |
| 3 | 9360612019 Pin, dowel (614) | Buy now |
| 4 | 9011908093 Bolt, with washer | Buy now |
| 5 | 9701306040 Bolt (682) | Buy now |
| 6 | 9290306600 Washer, plain (646) | Buy now |
| 7 | 6AH1135100 Gasket, cylinder | Buy now |
| 8 | 6AH41113001S Outer cover, exhaust & pipe | Buy now |
| 9 | 6502437800 Pipe, joint 2 | Buy now |
| 10 | 6761137200 Nipple, hose | Buy now |
| 11 | 6G81132500 Anode | Buy now |
| 12 | 9788005025 Screw, panhead (a93) | Buy now |
| 13 | 6G81119701 Plug, blind | Buy now |
| 14 | 9321013M63 O-ring (6g8) | Buy now |
| 15 | 6AH4111400 Gasket, exhaust outer cover | Buy now |


Cylinder & Crankcase 1



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9011906MA3 Bolt, with washer | Buy now |
| 17 | 6AH1241100 Thermostat | Buy now |
| 18 | 6881241200 Seal, thermostat | Buy now |
| 19 | 6AH12413001S Cover, thermostat | Buy now |
| 20 | 6AH1241400 Gasket, cover | Buy now |
| 24 | 6AH1248100 Pipe 1 | Buy now |
| 25 | 9046511M10 Clamp | Buy now |
| 26 | 6E51132500 Anode | Buy now |
| 27 | 9878004016 Screw, flat head(ga5) | Buy now |
| 28 | 5GH1344020 Element assembly, oil cleaner | Buy now |
| 29 | 6C51285800 Bolt, union | Buy now |

A5


Cylinder & Crankcase 2



B1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AGW009A001S Cylinder head complete | Buy now |
| 2 | 6AH111110094 Head, cylinder with ex valve | Buy now |
| 3 | 6AH1113310 Guide, valve 1 | Buy now |
| 4 | 6AG1118100 Gasket, cylinder head 1 | Buy now |
| 5 | 9360612019 Pin, dowel (614) | Buy now |
| 6 | 9010509006 Bolt, flange | Buy now |
| 7 | 9011906MA3 Bolt, with washer | Buy now |
| 8 | 6AH11191001S Cover, cylinder head 1 | Buy now |
| 9 | 6AH1137200 Nipple, hose | Buy now |
| 10 | 6AH1135600 Seal, cylinder 2 | Buy now |
| 11 | 9709506020 Bolt(7u8) | Buy now |
| 12 | 9299506600 Washer, plain (646) | Buy now |
| 13 | 6AH1116800 Cover, breather | Buy now |
| 14 | 6AH1116900 Gasket, breather cover | Buy now |
| 15 | 9850704010 Screw, pan head(6g8) | Buy now |


Cylinder & Crankcase 2



B1

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9290704600 Washer(jf2) | Buy now |
| 17 | 6G81132500 Anode | Buy now |
| 18 | 9788005025 Screw, panhead (a93) | Buy now |
| 19 | 6G81119701 Plug, blind | Buy now |
| 20 | 9321013M63 O-ring (6g8) | Buy now |
| 21 | 6G81536300 Plug, oil | Buy now |
| 22 | 9321024M79 O-ring | Buy now |
| 23 | 9046508059 Clamp | Buy now |
| 24 | 62Y1213860 Mark Caution | Buy now |
| 25 | 9470200418 Plug, spark (dpr6eb-9) | Buy now |


Electrical 1



C5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH8554000 C.d.i. unit assembly | Buy now |
| 2 | 9709506020 Bolt(7u8) | Buy now |
| 3 | 9299506600 Washer, plain (646) | Buy now |
| 4 | 9010906221 Bolt | Buy now |
| 5 | 6AH8194800 Bracket | Buy now |
| 6 | 9046513M18 Clamp | Buy now |
| 7 | 9011906M35 Bolt, with washer | Buy now |
| 8 | 9038706M60 Collar (6h3) | Buy now |
| 9 | 9048010M23 Grommet(6k7) | Buy now |
| 10 | 6AH8252200 Clamp, coupler | Buy now |
| 11 | 9788006010 Screw pan head | Buy now |
| 12 | 9020106M05 Washer, plate(6e3) | Buy now |
| 13 | 6F58557012 Ignition coil assembly | Buy now |
| 14 | 9048025003 Grommet | Buy now |
| 15 | 67F8236100 Clamp, cord | Buy now |


Electrical 1



C5

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9709506025 Bolt | Buy now |
| 18 | 6AH8237000 Plug cap assembly | Buy now |
| 19 | 9709506014 Bolt(gj3) | Buy now |
| 21 | 6AH8554200 Bracket | Buy now |
| 22 | 9046407M56 Clamp | Buy now |
| 23 | 64J8250400 Oil pressure switch assembly | Buy now |
| 24 | 62Y8430100 Pilot light assembly 1 | Buy now |
| 25 | 6H48358900 Gasket | Buy now |
| 26 | 9788506012 Screw, pan head(62j) | Buy now |
| 28 | 6AH8238800 Plate | Buy now |
| 29 | 9010906M86 Bolt | Buy now |
| 30 | 6AH8256000 Thermo switch assembly | Buy now |
| 31 | 6AH8258800 Plate | Buy now |
| 34 | 9046511M10 Clamp | Buy now |
| 35 | 6AH8254001 Neutral switch assembly | Buy now |

Electrical 1




6AG1300-F120

| Ref | Part | |
|-----|---|-------------------------|
| 35 | 6AH8255400 Stay, neutral switch | Buy now |
| 36 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 38 | 9046418246 Clamp(4tr) | Buy now |
| 40 | 9046410M32 Clamp(6m7) | Buy now |
| 41 | 68T8187000 Starting switch assembly | Buy now |
| 41 | 6G14272500 Grommet | Buy now |
| 42 | 9046416001 Clamp | Buy now |
| 42 | 9046416003 Clamp | Buy now |
| 43 | 6AH8238900 Plate 2 | Buy now |
| 45 | 67C8541500 Mark, signal lamp | Buy now |

C5


Electrical 2



D1

| Ref | Part | |
|-----|--|-------------------------|
| 37 | 6AH8196000 Rectifier & regulator assembly AP | Buy now |
| 38 | 7038211900 Cover, lead wire AP | Buy now |
| 39 | 9898006030 Screw, bind(j39) AP | Buy now |
| 40 | 9038706M70 Collar (6h5) AP | Buy now |
| 41 | 9048013M24 Grommet (6e9) AP | Buy now |
| 42 | 9578006500 Nut, flange(7nb) AP | Buy now |
| 7 | 6AH8194500 Plate, switch fitting | Buy now |
| 43 | 9709506014 Bolt(gj3) AP | Buy now |
| 44 | 9299506600 Washer, plain (646) AP | Buy now |
| 10 | 9046408004 Clamp | Buy now |
| 11 | 68TB194000 Starter relay assembly | Buy now |
| 12 | 9709506010 Bolt | Buy now |
| 13 | 9299506100 Washer(6a1) | Buy now |
| 15 | 6AH8211700 Wire, lead | Buy now |
| 16 | 6AH8210500 Battery cable | Buy now |

Electrical 2




D1

| Ref | Part | |
|-----|---|-------------------------|
| 19 | 9046416001 Clamp | Buy now |
| 20 | 6AH8215000 Fuse holder assembly | Buy now |
| 21 | 67F8215B10 Cap (yellow) | Buy now |
| 22 | 67F8215100 Fuse | Buy now |
| 23 | 6AH8215700 Damper | Buy now |
| 24 | 67F2812A00 Puller, fuse | Buy now |
| 25 | 6AH8239800 Plate 3 | Buy now |
| 26 | 9046418246 Clamp(4tr) | Buy now |
| 27 | 9046513M18 Clamp | Buy now |
| 28 | 9046409010 Clamp | Buy now |
| 29 | 9709508025 Bolt (62g) | Buy now |
| 30 | 9299508600 Washer, plain (663) | Buy now |
| 31 | 9709508016 Bolt, hexagon deep recess | Buy now |
| 33 | 6AH8194900 Wire, lead AP | Buy now |
| 35 | 67F8215B00 Cap (black) | Buy now |


Electrical 2

| Ref | Part | |
|-----|---|-------------------------|
| 36 | 9046406001 Clamp AP | Buy now |



D1


Electrical 3



D2

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH8259010 Wire harness & extension wire | Buy now |
| 1 | 6AH8259M00 Wire harness & extension wire | Buy now |
| 1 | 6AH8259M10 Wire harness & extension wire | Buy now |
| 2 | 9046513M18 Clamp | Buy now |
| 3 | 9044508029 Hose | Buy now |
| 4 | 6AH8552A00 Housing | Buy now |
| 5 | 6AH8552E00 Cover, case | Buy now |
| 6 | 6AH4273530 Protector | Buy now |
| 7 | 6AH4273540 Protector | Buy now |
| 8 | 6AH8553700 Cover | Buy now |
| 9 | 9048019368 Grommet(75v) | Buy now |
| 10 | 6AH8554700 Damper | Buy now |
| 11 | 9046420181 Clamp(4ap) | Buy now |
| 12 | 9709506014 Bolt(gj3) | Buy now |
| 13 | 9299506600 Washer, plain (646) | Buy now |


Electrical 3



| Ref | Part | |
|-----|--|-------------------------|
| 14 | 9798506214 Screw, with washer | Buy now |

D2


Electrical 4



D3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6H58192500 Terminal | Buy now |
| 2 | 6AH8192900 Bracket, terminal | Buy now |
| 3 | 9038706182 Collar | Buy now |
| 4 | 6AH8231700 Damper, ignition coil | Buy now |
| 5 | 9709506014 Bolt(gj3) | Buy now |
| 6 | 9299506600 Washer, plain (646) | Buy now |
| 7 | 9017006M30 Nut(62x) | Buy now |
| 8 | 9020406M00 Washer, spring(62x) | Buy now |
| 9 | 6G58211900 Cover, lead wire | Buy now |
| 10 | 6AH8195000 Relay assembly | Buy now |
| 11 | 9038706M03 Collar (676) | Buy now |
| 12 | 9010906MA2 Bolt | Buy now |
| 13 | 9020106416 Washer, plate(663) | Buy now |
| 14 | 6AH8238800 Plate | Buy now |
| 15 | 6AH8259000 Wire harness & extension wire | Buy now |



Electrical 4



D3

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9046513M18 Clamp | Buy now |
| 17 | 6AH8552A10 Housing | Buy now |
| 19 | 9044507025 Hose | Buy now |
| 20 | 9044507026 Hose | Buy now |
| 21 | 9044507027 Hose | Buy now |
| 22 | 9046412001 Clamp | Buy now |
| 23 | 6AH8552E10 Cover, case | Buy now |
| 24 | 6AH4273510 Protector | Buy now |
| 25 | 6AH4273520 Protector | Buy now |
| 26 | 6AH8553710 Cover | Buy now |
| 27 | 9048019368 Grommet(75v) | Buy now |
| 28 | 6AH8554710 Damper | Buy now |
| 31 | 9798506214 Screw, with washer | Buy now |
| 32 | 6AH8552510 Plate | Buy now |
| 34 | 9020106068 Washer,plate (6k8) | Buy now |


Electrical 4



| Ref | Part | |
|-----|-------------------------------------|-------------------------|
| 35 | 9046476001 Clamp | Buy now |

D3

Electrical 5




6AH1300-F160

D5


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH8256300 Trim & tilt switch assembly | Buy now |
| 2 | 9046511M10 Clamp | Buy now |
| 3 | 9788506020 ワッシャー , ワッシャー | Buy now |
| 4 | 9299506600 Washer, plain (646) | Buy now |

Fuel




B7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6G12430402 Fuel pipe joint comp. 1 | Buy now |
| 2 | 61N2432900 Seal | Buy now |
| 3 | 9589506020 Bolt, flange(jk3) | Buy now |
| 4 | 6AH2431100 Pipe, fuel 1 | Buy now |
| 5 | 61N2456000 Filter assembly | Buy now |
| 6 | 61N2456300 Element, filter | Buy now |
| 7 | 61N2452100 Cup, filter | Buy now |
| 8 | 9321032738 O-ring(1wg) | Buy now |
| 9 | 6AH2456600 Bracket, filter | Buy now |
| 10 | 9538008600 Nut (661) | Buy now |
| 11 | 9011108055 Bolt,hex. socket button | Buy now |
| 12 | 6AH2431200 Pipe 2 | Buy now |
| 13 | 9046709M17 Clip(6k8) | Buy now |
| 14 | 6AH2441000 Fuel pump assembly | Buy now |
| 15 | 6AH2441300 Body 2 | Buy now |



B7


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6A02442101 Valve, check | Buy now |
| 17 | 66M2441111 Diaphragm | Buy now |
| 18 | 66M2442300 Spring, diaphragm | Buy now |
| 19 | 66M1313110 Plunger | Buy now |
| 20 | 66M2445400 Spring | Buy now |
| 21 | 66M2444400 Screw | Buy now |
| 22 | 66M2447101 Diaphragm | Buy now |
| 23 | 6E71432500 Screw, pan head | Buy now |
| 24 | 9538004600 Nut,hex | Buy now |
| 25 | 66M2437400 Pin | Buy now |
| 26 | 9010906215 Bolt | Buy now |
| 27 | 9321020M65 O-ring | Buy now |
| 28 | 6AH2431300 Pipe 3 | Buy now |
| 30 | 6AH2431500 Pipe 5 | Buy now |
| 31 | 9044509026 Hose (I420) | Buy now |



B7

| Ref | Part | |
|-----|--|-------------------------|
| 32 | 9046511M10 Clamp | Buy now |
| 33 | 6AH2431700 Pipe 7 | Buy now |
| 34 | 6882437800 Pipe, joint | Buy now |
| 35 | 6C52437800 Pipe, joint 4 | Buy now |
| 36 | 9046409018 Clamp | Buy now |
| 37 | 61H2819R31 Tag Warning EXCEPT FOR RUS | Buy now |
| 38 | 62Y2810000 Tool kit | Buy now |
| 39 | 6AG2819971D0 Om f15c/f20b/f13.5b '07 UR (NL) | Buy now |
| 39 | 6AG2819971E0 Om f15c/f20b/f13.5b '07 UR (E) | Buy now |
| 39 | 6AG2819971F0 Om f15c/f20b/f13.5b '07 UR (F) | Buy now |
| 39 | 6AG2819971G0 Om f15c/f20b/f13.5b '07 UR (D) | Buy now |
| 39 | 6AG2819971H0 Om f15c/f20b/f13.5b '07 UR (I) | Buy now |
| 39 | 6AG2819971S0 Om f15c/f20b/f13.5b '07 UR (ES) | Buy now |
| 40 | 6AG2819981K0 Om f15c/f20b/f13.5b '07 UR (DK) | Buy now |
| 40 | 6AG2819981L0 Om f15c/f20b/f13.5b '07 UR (SF) | Buy now |


Fuel



B7

| Ref | Part | |
|-----|--|-------------------------|
| 40 | 6AG2819981M0 Om f15c/f20b/f13.5b '07 UR (S) | Buy now |
| 40 | 6AG2819981N0 Om f15c/f20b/f13.5b '07 UR (N) | Buy now |
| 40 | 6AG2819981P0 Om f15c/f20b/f13.5b '07 UR (P) | Buy now |
| 40 | 6AG2819981R0 Om f15c/f20b/f13.5b '07 UR (GR) | Buy now |


Fuel Tank



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6YK2420102 - AP | Buy now |
| 2 | 6YL2426801 Gasket, fuel meter | Buy now |
| 3 | 6YK2461001 Cap assembly | Buy now |
| 4 | 6YK2426001 Fuel meter assembly | Buy now |
| 5 | 9015705M16 Screw, pan head | Buy now |
| 6 | 6YL2432900 Seal | Buy now |
| 7 | 6YL2430654 Fuel pipe comp. 1 AP | Buy now |

C1


Generator



C4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH8555000 Rotor assembly | Buy now |
| 1 | 6AH8555010 Rotor assembly | Buy now |
| 2 | 6AH8551000 Stator assembly | Buy now |
| 3 | 6AH8558000 Coil, pulser | Buy now |
| 4 | 7038211900 Cover, lead wire | Buy now |
| 5 | 9709505012 Bolt, hexagon | Buy now |
| 6 | 9589506030 Bolt, flange deep recess | Buy now |
| 7 | 9028005013 Key, woodruff | Buy now |
| 8 | 9017916M05 Nut (689) | Buy now |
| 9 | 9020116M44 Washer (689) | Buy now |


Intake



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH136410094 Manifold 1 | Buy now |
| 2 | 6AH1364500 Gasket, manifold 1 | Buy now |
| 3 | 9759506555 Bolt, hexagon w/w deep recess | Buy now |
| 4 | 9169050014 Pin, spring (647) | Buy now |
| 5 | 9046508M83 Clamp | Buy now |
| 6 | 9709506012 Bolt(gh1) | Buy now |
| 7 | 9299506600 Washer, plain (646) | Buy now |
| 8 | 6AH1364600 Gasket, manifold 2 | Buy now |
| 9 | 6AH1427100 Insulator | Buy now |
| 10 | 6AH1444000 Silencer assembly, intake | Buy now |
| 11 | 9321035M86 O-ring(6l2) | Buy now |
| 12 | 9589506100 Bolt, flange deep recess | Buy now |
| 13 | 6AH1537300 Pipe, breather | Buy now |
| 14 | 9010906MA1 Bolt | Buy now |
| 15 | 9048016616 Grommet | Buy now |


Intake

| Ref | Part | |
|-----|-------------------------------------|-------------------------|
| 16 | 9046513M18 Clamp | Buy now |




B3

Lower Casing & Drive 1




| Ref | Part | |
|-----|--|-------------------------|
| 1 | <u>6AH45300004D</u> Lower unit assembly S(17.1") | Buy now |
| 1 | <u>6AH45300104D</u> Lower unit assembly L(22.1") | Buy now |
| 2 | <u>6AH45311004D</u> Casing, lower | Buy now |
| 3 | <u>93315314V8</u> Bearing, needle (6e7) | Buy now |
| 4 | <u>63V4553600</u> Sleeve, drive shaft | Buy now |
| 5 | <u>9020914011</u> Washer | Buy now |
| 6 | <u>9020115017</u> Washer, plate | Buy now |
| 7 | <u>6E84558710</u> Shim (t:1.13mm) UR | Buy now |
| 7 | <u>6E84558730</u> Shim (t:1.20mm) UR | Buy now |
| 8 | <u>9333200005</u> Brg,cyl-cal roller 0.19g nt | Buy now |
| 9 | <u>9034008002</u> Plug, straight screw | Buy now |
| 10 | <u>9043008020</u> Gasket | Buy now |
| 11 | <u>6AH4431100</u> Housing, water pump | Buy now |
| 12 | <u>63V4432200</u> Insert, cartridge | Buy now |
| 13 | <u>6L24436700</u> Damper, water seal 3 | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|--|-------------------------|
| 14 | 63V4435201 Impeller | Buy now |
| 15 | 6644433800 Key, woodruff | Buy now |
| 16 | 9321049046 O-ring (620) | Buy now |
| 17 | 68T4432300 Outer plate, cartridge | Buy now |
| 18 | 9360412M07 Pin, dowel (688) | Buy now |
| 19 | 9708008045 Bolt, hexagon | Buy now |
| 20 | 63V4432800 Plate | Buy now |
| 21 | 69G45331015B Housing, bearing | Buy now |
| 22 | 6264531609 Bushing, drive shaft 1 | Buy now |
| 23 | 9310120001 Oil seal | Buy now |
| 24 | 69G45315A0 Packing, lower casing | Buy now |
| 25 | 9321006ME6 O-ring | Buy now |
| 26 | 9708008025 Screw, bind(j36) | Buy now |
| 27 | 6AH4415000 Shift cam assembly S(17.1") | Buy now |
| 27 | 6AH4415010 Shift cam assembly L(22.1") | Buy now |


Lower Casing & Drive 1



B3


| Ref | Part | |
|-----|---|-------------------------|
| 28 | 6AH4551000 Drive shaft assembly S(17.1") | Buy now |
| 28 | 6AH4551010 Drive shaft assembly L(22.1") | Buy now |
| 29 | 63V4555100 Pinion | Buy now |
| 30 | 9017908M06 Nut (6e7) | Buy now |
| 31 | 6E74556001 Gear | Buy now |
| 32 | 6E74557100 Gear 2 | Buy now |
| 33 | 6264557700 Shim (t:0.10mm) UR | Buy now |
| 33 | 6264557710 Shim (t:0.20mm) UR | Buy now |
| 33 | 6264557720 Shim (t:0.30mm) UR | Buy now |
| 33 | 6264557730 Shim (t:0.40mm) UR | Buy now |
| 33 | 6264557740 Shim (t:0.50mm) UR | Buy now |
| 34 | 9020117682 Washer, plate (2k7) | Buy now |
| 35 | 6834561100 Shaft propeller | Buy now |
| 36 | 6504563500 Plunger, shift | Buy now |
| 37 | 6824563100 Clutch, dog | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|--|-------------------------|
| 38 | 9025005010 Pin straight 648456320000 | Buy now |
| 39 | 6484563300 Ring, cross pin | Buy now |
| 40 | 90501150A0 Spring, compression | Buy now |
| 41 | 68345361024D Cap, lower casing | Buy now |
| 42 | 9330600501 Bearing(1ff) | Buy now |
| 43 | 93315317U2 Brg,cyl-cal roller 14g (683) | Buy now |
| 44 | 9310117054 Oil seal (17x30x6-650) | Buy now |
| 45 | 9321057M09 O-ring (683) | Buy now |
| 46 | 9321056M80 O-ring(6j8) | Buy now |
| 47 | 9707506020 Bolt(7u8) | Buy now |
| 48 | 9299506600 Washer, plain (646) | Buy now |
| 49 | 6644556701 Shim (t:0.10mm) UR | Buy now |
| 49 | 6644556710 Shim (t:0.12mm) UR | Buy now |
| 49 | 6644556720 Shim (t:0.15mm) UR | Buy now |
| 49 | 6644556730 Shim (t:0.18mm) UR | Buy now |


Lower Casing & Drive 1



B3

| Ref | Part | |
|-----|--|-------------------------|
| 49 | 6644556740 Shim (t:0.30mm) UR | Buy now |
| 49 | 6644556750 Shim (t:0.40mm) UR | Buy now |
| 49 | 6644556760 Shim (t:0.50mm) UR | Buy now |


Lower Casing & Drive 2



B6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH4436100 Tube, water 1 S(17.1") | Buy now |
| 1 | 6AH4436110 Tube, water 1 L(22.1") | Buy now |
| 2 | 6AH4436500 Damper, water seal 1 | Buy now |
| 3 | 9046511M10 Clamp | Buy now |
| 4 | 6AH4436800 Rubber, water seal 4 | Buy now |
| 5 | 9360412M07 Pin, dowel (688) | Buy now |
| 6 | 9707508030 Bolt, hexagon (fj1) | Buy now |
| 7 | 9299508600 Washer, plain (663) | Buy now |
| 8 | 6G14521400 Cover, water inlet | Buy now |
| 9 | 63V4521500 Cover, water inlet | Buy now |
| 10 | 9015205M04 Screw, countersunk | Buy now |
| 11 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 12 | 6AH4525100 Anode | Buy now |
| 13 | 9589506035 Bolt, flange(4nx) | Buy now |
| 14 | 9299006300 Washer, tooth | Buy now |


Lower Casing & Drive 2



B6

| Ref | Part | |
|-----|--|-------------------------|
| 15 | 63V4537500 Damper, seal | Buy now |
| 16 | 6E74598701 Spacer | Buy now |
| 17 | 9020110M01 Washer, plate(6m7) | Buy now |
| 18 | 9017110M01 Nut castle (683) | Buy now |
| 19 | 9149030020 Pin cotter | Buy now |
| 20 | 6AH45371004D Tab-trim | Buy now |
| 21 | 9011906M88 Bolt, with washer | Buy now |
| 22 | 63V4594110EL Propeller (3x9-1/4 x12 -j1) UR | Buy now |
| 22 | 63V4594310EL Propeller (3x9-1/4 x11 -j1) UR | Buy now |
| 22 | 63V4594510EL Propeller (3x9-1/4 x9 -j1) UR | Buy now |
| 22 | 63V4595210EL Propeller (3x9-1/4 x10 -j1) UR | Buy now |
| 22 | 6834594100EL Propeller (3x9-1/4"x12"-j) UR | Buy now |
| 22 | 6834594300EL Propeller (3x9-1/4"x10-1/2"-j) UR | Buy now |
| 22 | 6834595200EL Propeller (3X9-1/4"x9-3/4"-J) | Buy now |


Oil Pan



B2

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH15311005B Oil pan | Buy now |
| 2 | 6AH1531200 Gasket, oil pan | Buy now |
| 3 | 9360412M07 Pin, dowel (688) | Buy now |
| 4 | 6AH1531600 Damper, engine mount 1 | Buy now |
| 5 | 9046511M59 Clamp(63m) | Buy now |
| 6 | 9034014M06 Plug, straight screw(62y) | Buy now |
| 7 | 9043014M09 Gasket | Buy now |
| 8 | 6AH1341100 Strainer, oil | Buy now |
| 9 | 9701306016 Bolt, hexagon deep recess | Buy now |
| 10 | 9290306600 Washer, plain (646) | Buy now |
| 11 | 6AH1536200 Plug, oil level | Buy now |
| 12 | 9011908103 Bolt, with washer | Buy now |
| 13 | 9011908102 Bolt, with washer | Buy now |
| 14 | 6AH4512600 Plate, seal damper | Buy now |
| 15 | 6AH4511500 Gasket, upper casing | Buy now |


Oil Pan



| Ref | Part | |
|-----|------------------------------------|-------------------------|
| 16 | 6AH4513500 Pipe | Buy now |

B2


Oil Pump



B6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AG1217000 Camshaft assembly 1 | Buy now |
| 2 | 6AH115370094 Gear, driven | Buy now |
| 3 | 90105081A7 Bolt, washer based(jn9) | Buy now |
| 4 | 9020108784 Washer, plate (3l7) | Buy now |
| 5 | 9020115423 Washer, plate(663) | Buy now |
| 6 | 6AH1153600 Gear, drive | Buy now |
| 7 | 6AH1155700 Washer 1 | Buy now |
| 8 | 9017030003 Nut | Buy now |
| 9 | 9028003M01 Key woodruff 146115450000 | Buy now |
| 10 | 6AH4624100 Belt | Buy now |
| 11 | 6AH4629700 Cover, dust | Buy now |
| 12 | 9048010627 Grommet | Buy now |
| 13 | 6AH4261700 Damper, form | Buy now |
| 14 | 9048006M19 Grommet (6e3) | Buy now |
| 15 | 6AH1330000 Oil pump assembly | Buy now |


Oil Pump



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6AH1332900 Gasket, pump cover | Buy now |
| 17 | 9010506035 Bolt, flange | Buy now |
| 18 | 9310222009 Oil seal | Buy now |

B6


Power Tilt Assy



A5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH43840004D Power tilt assembly | Buy now |
| 2 | 6AH4380K00 Cylinder, tilt sub assembly | Buy now |
| 3 | 6AH2247100 Cylinder, shock absorber | Buy now |
| 4 | 93210320A7 O-ring | Buy now |
| 5 | 6H14388E11 Plug, tapper screw | Buy now |
| 6 | 9321007003 O-ring (11m) | Buy now |
| 7 | 6AH4381400 Piston, free | Buy now |
| 8 | 9321024709 O-ring(1hx) | Buy now |
| 9 | 6C54387100 Ring, back up | Buy now |
| 10 | 6AH4381000 Tilt piston sub assembly | Buy now |
| 11 | 6AH4380D00 Piston comp. | Buy now |
| 14 | 9350108001 Ball | Buy now |
| 15 | 6AH4386A00 Pin, absorber valve | Buy now |
| 16 | 6AH4385E00 Plate, piston | Buy now |
| 17 | 9290206200 Ybs66-6 washer, plain | Buy now |


Power Tilt Assy



A5

| Ref | Part | |
|-----|--|-------------------------|
| 18 | 6AH4387800 Bolt, socket | Buy now |
| 19 | 6AH4385700 Spring, absorber valve | Buy now |
| 20 | 6AH4380100 Rod | Buy now |
| 21 | 6AH4381100 Screw, cylinder end | Buy now |
| 22 | 6H14386600 O-ring | Buy now |
| 23 | 69A4387100 Ring, back up | Buy now |
| 24 | 69A4381200 Seal, dust | Buy now |
| 25 | 62X4386200 O-ring | Buy now |
| 26 | 6AH4383000 Gear pump assembly | Buy now |
| 27 | 69A4384100 Piston, shuttle | Buy now |
| 28 | 69A4384M00 Piston, shuttle 2 | Buy now |
| 29 | 62Y4389400 Spring, shuttle return | Buy now |
| 30 | 69A4384F00 Seal, main valve | Buy now |
| 31 | 6H14388300 O-ring | Buy now |
| 32 | 9900203600 Circlip(615) | Buy now |


Power Tilt Assy



A5

| Ref | Part | |
|-----|---|-------------------------|
| 33 | 69G4382G00 Valve seat | Buy now |
| 34 | 9321012N52 O-ring | Buy now |
| 35 | 6T44380800 Seat valve comp. 1 | Buy now |
| 36 | 69G4385300 Spring, main valve | Buy now |
| 37 | 69G4388F00 Spacer | Buy now |
| 38 | 69J4381C00 Filter 3 | Buy now |
| 39 | 6H14384G11 Seal, relief valve | Buy now |
| 40 | 6H14384410 Pin, valve support | Buy now |
| 41 | 6F24385500 Spring, up relief | Buy now |
| 42 | 6H14385610 Spring, down relief | Buy now |
| 44 | 69A4386A00 Pin, absorber valve | Buy now |
| 45 | 69A4382400 Spring, down relief 2 | Buy now |
| 46 | 69A4384800 Rod, manual release | Buy now |
| 47 | 9360215250 Pin, dowel | Buy now |
| 48 | 9321006001 O-ring (26h) | Buy now |


Power Tilt Assy



A5

| Ref | Part | |
|-----|--|-------------------------|
| 49 | 6AH4385400 Spring, manual release | Buy now |
| 50 | 69A4381G00 Pin 1 | Buy now |
| 53 | 69A4384H00 Spring | Buy now |
| 54 | 9360614081 Pin,dowel(296) | Buy now |
| 55 | 9131205025 Bolt | Buy now |
| 57 | 6AH4381J00 Plate | Buy now |
| 58 | N354386210 O-ring | Buy now |
| 59 | 69A2312900 Gasket, drain plug | Buy now |
| 60 | 69A4387800 Bolt, socket | Buy now |
| 61 | 69A4388000 Motor assembly | Buy now |
| 62 | 65W4380400 Stator assembly | Buy now |
| 63 | 65W4380500 Armature assembly | Buy now |
| 64 | 65W4386900 O-ring | Buy now |
| 65 | 65W4386K00 Spring, brush | Buy now |
| 66 | 65W4388200 Oil seal | Buy now |


Power Tilt Assy



A5

| Ref | Part | |
|-----|---|-------------------------|
| 67 | 69A4388100 Frame, End | Buy now |
| 68 | 65W4388700 Bolt, screw | Buy now |
| 69 | 65W4389200 Brush 2 | Buy now |
| 70 | 65W4389100 Brush 1 | Buy now |
| 71 | 65W4380F00 Plate, brush holder | Buy now |
| 72 | 65W4387900 Screw, with washer | Buy now |
| 73 | 65W4388E00 Bolt | Buy now |


Remote Control Assy



C4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 70348201A3 Remote control assembly (10p) AP WITHOUT PT/T SW. | Buy now |
| 1 | 70348205A5 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 7034826101 Arm, throttle | Buy now |
| 3 | 7034815300 Shaft, free accel. | Buy now |
| 4 | 7034823500 Bushing | Buy now |
| 5 | 7034826800 Spacer 3 | Buy now |
| 6 | 7034826400 Throttle, friction | Buy now |
| 7 | 9538005600 Nut, hexagon (663) | Buy now |
| 8 | 9738005025 Bolt | Buy now |
| 9 | 7034826500 Shaft Friction | Buy now |
| 10 | 9343006024 Circlip (701) | Buy now |
| 11 | 7034824500 Plate, lock | Buy now |
| 12 | 7034825200 Roller, cam | Buy now |
| 13 | 7014824800 Roller, free accel | Buy now |
| 14 | 7034819800 Washer, wave 3 | Buy now |


Remote Control Assy



C4

| Ref | Part | |
|-----|--|-------------------------|
| 15 | 7034824300 Bushing 3 | Buy now |
| 16 | 7034823600 Bushing | Buy now |
| 17 | 7034818900 Retainer | Buy now |
| 18 | 7034823400 Roller, detent | Buy now |
| 19 | 7034834501 Cable end, remote control 2 | Buy now |
| 20 | 7034835800 Anchor, cable | Buy now |
| 21 | 7034824400 Spring, free accel. | Buy now |
| 22 | 7034823800 Spring, detent | Buy now |
| 23 | 7034824600 Spacer 1 | Buy now |
| 24 | 7034822700 Spring, neutral lock | Buy now |
| 25 | 7038259400 Clamp WITH PT/T SW. | Buy now |
| 26 | 7034822600 Plate, stopper | Buy now |
| 27 | 7034822200 Grip, control lever SINGLE | Buy now |
| 28 | 7034822300 Lock, neutral | Buy now |
| 29 | 7034822500 Cover | Buy now |


Remote Control Assy



C4

| Ref | Part | |
|-----|--|-------------------------|
| 30 | 7034821900 Cover, lead | Buy now |
| 31 | 7034828100 Screw, flat head | Buy now |
| 32 | 7034828200 Screw | Buy now |
| 33 | 9738008030 Bolt, hexagon (fj1) | Buy now |
| 34 | 9299008600 Washer, plain (663) | Buy now |
| 35 | 9858004010 Screw, pan head (e56) | Buy now |
| 36 | 9858004006 Screw, pan head (7h3) | Buy now |
| 37 | 9858005010 Screw, pan head(62x) | Buy now |
| 38 | 9858003015 Screw, pan head (n151) | Buy now |
| 39 | 7034829110 Screw | Buy now |
| 40 | 9538006600 Nut(661) | Buy now |
| 41 | 7034829310 Spacer, remote control SINGLE | Buy now |
| 42 | 7014828700 Washer 1 | Buy now |
| 43 | 7034821500 Graphic | Buy now |
| 44 | 7038251012 Main switch assembly PRIME START | Buy now |


Remote Control Assy



C4

| Ref | Part | |
|-----|---|-------------------------|
| 45 | 6768257700 Cap, key | Buy now |
| 46 | 7038253100 Wire, lead | Buy now |
| 47 | 6888257501 Engine stop switch assembly | Buy now |
| 48 | 6828255600 Lanyard, stop switch | Buy now |
| 49 | 6888258A20 10p main harness mec 2m (6ft) (10P) | Buy now |
| 50 | 7038254000 Neutral switch assembly | Buy now |
| 51 | 70383383B0 Buzzer | Buy now |
| 52 | 7034828400 Grommet | Buy now |
| 53 | 7038259100 Band | Buy now |
| 54 | 7038259200 Band | Buy now |
| 55 | 7034822400 Cover, control lever WITHOUT PT/T SW. | Buy now |
| 55 | 7038256302 Trim & tilt switch assembly WITH PT/T SW. | Buy now |
| 56 | 7034822100 Grip | Buy now |
| 57 | 7034815200 Knob, free accel | Buy now |
| 58 | 7034821200 Rear housing | Buy now |


Remote Control Assy



C4

| Ref | Part | |
|-----|---|-------------------------|
| 59 | 7034821300 Back, panel | Buy now |
| 60 | 7034827100 Arm, shift | Buy now |
| 61 | 7034821101 Housing,1 | Buy now |
| 62 | 7034823200 Drive gear | Buy now |
| 63 | 7038254200 Cap FOR 703-48205-A5 | Buy now |
| 64 | 7034821800 Graphic | Buy now |

Remote Control Box




67MO100-8280

C3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 70348201A3 Remote control assembly (10p) AP WITHOUT PT/T SW. | Buy now |
| 1 | 70348205A5 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 7014831090 Cable, Remote Control L=11F UR | Buy now |
| 2 | 7014832000 Cable, Remote Control L=12F UR | Buy now |
| 2 | 7014832020 Cable, Remote Control L=13F UR | Buy now |
| 2 | 7014832050 Cable, Remote Control L=15F UR | Buy now |

Repair Kit 1




C7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AGW000100 Power head gasket kit | Buy now |
| 2 | 9310222009 Oil seal | Buy now |
| 3 | 6AG1118100 Gasket, cylinder head 1 | Buy now |
| 4 | 6AH1135600 Seal, cylinder 2 | Buy now |
| 5 | 6AH1116900 Gasket, breather cover | Buy now |
| 6 | 9321013M63 O-ring (6g8) | Buy now |
| 7 | 9310237004 Oil seal | Buy now |
| 8 | 9310225014 Oil seal | Buy now |
| 9 | 6AH1135100 Gasket, cylinder | Buy now |
| 11 | 6AH4111400 Gasket, exhaust outer cover | Buy now |
| 12 | 6AH1241400 Gasket, cover | Buy now |
| 13 | 6AH1364500 Gasket, manifold 1 | Buy now |
| 14 | 6AH1364600 Gasket, manifold 2 | Buy now |
| 15 | 9321035M86 O-ring(6l2) | Buy now |
| 16 | 6AH1332900 Gasket, pump cover | Buy now |


Repair Kit 1

| Ref | Part | |
|-----|--------------------------------------|-------------------------|
| 17 | 9321024M79 O-ring | Buy now |
| 18 | 9321020M65 O-ring | Buy now |



C7


Repair Kit 2



D1


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AHW009300 Carburetor repair kit | Buy now |
| 2 | 65W1412610 Gasket | Buy now |
| 3 | 6G11454601 Valve, needle | Buy now |
| 4 | 6761418600 Pin, valve | Buy now |
| 5 | 6H41454800 Pin, float arm | Buy now |
| 6 | 65W1437301 Cover, plunger cap | Buy now |
| 7 | 67C1439700 O-ring | Buy now |
| 8 | 6AH1438400 Gasket, float chamber | Buy now |
| 9 | 65W1439800 Washer | Buy now |
| 10 | 9798004114 Screw, pan head(ga5) | Buy now |
| 11 | 6AH1498500 Float | Buy now |
| 12 | 6631415900 Clip | Buy now |

Repair Kit 3



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AHW000120 Lower unit gasket kit | Buy now |
| 2 | 6AH1531200 Gasket, oil pan | Buy now |
| 3 | 9043014M09 Gasket | Buy now |
| 4 | 9310112M63 Oil seal | Buy now |
| 5 | 9043008143 Gasket (256-11198-00) | Buy now |
| 6 | 6AH4113400 Gasket, exhaust manifold | Buy now |
| 7 | 6AH4113800 Seal, ext. 1 | Buy now |
| 8 | 6AH4512600 Plate, seal damper | Buy now |
| 9 | 6AH4511500 Gasket, upper casing | Buy now |
| 10 | 6AH4436500 Damper, water seal 1 | Buy now |
| 11 | 6AH4436800 Rubber, water seal 4 | Buy now |
| 12 | 9043008020 Gasket | Buy now |
| 13 | 6L24436700 Damper, water seal 3 | Buy now |
| 14 | 9321049046 O-ring (620) | Buy now |
| 15 | 9310120001 Oil seal | Buy now |


Repair Kit 3



D2

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 69G45315A0 Packing, lower casing | Buy now |
| 17 | 9321006ME6 O-ring | Buy now |
| 18 | 9310117054 Oil seal (17x30x6-650) | Buy now |
| 19 | 9321057M09 O-ring (683) | Buy now |
| 20 | 9321056M80 O-ring(6j8) | Buy now |
| 21 | 6AHW007800 Water pump repair kit | Buy now |
| 22 | 6AH4431100 Housing, water pump | Buy now |
| 23 | 63V4432200 Insert, cartridge | Buy now |
| 25 | 63V4435201 Impeller | Buy now |
| 26 | 6644433800 Key, woodruff | Buy now |
| 28 | 68T4432300 Outer plate, cartridge | Buy now |
| 29 | 9360412M07 Pin, dowel (688) | Buy now |
| 30 | 9708008045 Bolt, hexagon | Buy now |
| 31 | 63V4432800 Plate | Buy now |


Starter



C2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH1571000 Starter assembly | Buy now |
| 2 | 6AH1571100 Case, starter | Buy now |
| 3 | 67D1576400 Collar 1 | Buy now |
| 4 | 6AH1579500 Guide, rope | Buy now |
| 5 | 63V1571400 Drum, sheave | Buy now |
| 6 | 63V1574100 Pawl, drive | Buy now |
| 7 | 63V1571300 Spring, starter | Buy now |
| 8 | 68T1571600 Plate, drive | Buy now |
| 9 | 63V1570501 Spring, drive pawl | Buy now |
| 10 | 63V1576701 Spring | Buy now |
| 11 | 68T1578400 Spring, return | Buy now |
| 12 | 63V1574400 Circlip | Buy now |
| 13 | 68T1579300 Screw | Buy now |
| 14 | 68T1576400 Collar 1 | Buy now |
| 15 | 6891575501 Handle, starter | Buy now |

Starter




*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.8M
*1: A PRELEVER SUR BOBINE 50M , REFERENCE 90890-44373,
LONGUEUR DE COUPE 1.8M

C2

| Ref | Part | |
|-----|---|-------------------------|
| 16 | * item_description *1 | Buy now |
| 17 | 6F51577902 Cover | Buy now |
| 18 | 6A01578900 Damper | Buy now |
| 19 | 66T1579400 Stopper | Buy now |
| 20 | 66T1573400 Spring, return | Buy now |
| 21 | 6AH1578200 Cover, sheave | Buy now |
| 22 | 6AH1579300 Screw | Buy now |
| 23 | 6AH1577000 Cable comp., starter stop | Buy now |
| 24 | 66T1573100 Retainer, spring | Buy now |
| 25 | 9044606M90 Hose | Buy now |
| 26 | 9709506020 Bolt(7u8) | Buy now |
| 27 | 9299506600 Washer, plain (646) | Buy now |
| 28 | 9011906169 Bolt, with washer | Buy now |
| 29 | 6AH1576200 Seal, rubber 2 | Buy now |
| 30 | 6AH2431600 Pipe 6 | Buy now |


Starter



C2

| Ref | Part | |
|-----|--|-------------------------|
| 31 | 6AH8133700 Cover, flywheel | Buy now |
| 32 | 6AH1442760 Label, instruction | Buy now |
| 33 | 6AH1343760 Mark, caution | Buy now |
| 34 | 6A18362541 Mark 5 | Buy now |
| 35 | 6A18362551 Mark 5 | Buy now |


Starting Motor



D6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH8180000 Starting motor assembly | Buy now |
| 2 | 6898185011 Armature assembly | Buy now |
| 3 | 6898180911 Washer kit | Buy now |
| 4 | 6898181011 Stator ass'y | Buy now |
| 5 | 6898184711 O-ring | Buy now |
| 6 | 6898184011 Brush holder assembly | Buy now |
| 7 | 6898181111 Brush 1 | Buy now |
| 8 | 6898181211 Brush 2 | Buy now |
| 9 | 6898181310 Spring, brush | Buy now |
| 10 | 6AH8182000 Rear bracket assembly | Buy now |
| 11 | 6898180712 Pinion assembly | Buy now |
| 12 | 68T8185700 Pinion stopper set | Buy now |
| 13 | 6AH8183000 Front bracket assembly | Buy now |
| 14 | 6898183100 Metal, front | Buy now |
| 15 | 6898182610 Bolt | Buy now |


Starting Motor



D6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9701308045 Bolt | Buy now |
| 17 | 9290308600 Washer, plain (663) | Buy now |
| 18 | 9701308035 Bolt | Buy now |
| 20 | 9709508016 Bolt, hexagon deep recess | Buy now |
| 21 | 9299508600 Washer, plain (663) | Buy now |
| 22 | 6AH8194200 Cover | Buy now |
| 23 | 6AH8258100 Stay, cord clamp | Buy now |
| 24 | 9709506014 Bolt(gj3) | Buy now |
| 25 | 9299506600 Washer, plain (646) | Buy now |


Steering



E3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AHW0084014D Handle steering assembly | Buy now |
| 2 | 6AH42101014D Handle, steering | Buy now |
| 3 | 9010906M86 Bolt | Buy now |
| 4 | 6AH2628800 Grommet, cable | Buy now |
| 5 | 66M4211900 Grip, steering handle | Buy now |
| 7 | 67D4217700 Rubber, handle | Buy now |
| 8 | 65W4213800 Lever, throttle | Buy now |
| 9 | 9014905M13 Screw, countersunk | Buy now |
| 10 | 65W4215900 Stay | Buy now |
| 11 | 6G14212600 Piece, friction | Buy now |
| 12 | 65W4212500 Bolt, friction adjusting | Buy now |
| 14 | 9149016010 Pin, cotter | Buy now |
| 15 | 6J04213700 Indicator, throttle | Buy now |
| 16 | 9026902M09 Rivet(615) | Buy now |
| 17 | 6X44418800 Washer | Buy now |


Steering



E3

| Ref | Part | |
|-----|---|-------------------------|
| 18 | 9050123215 Spring (655) | Buy now |
| 19 | 9038608004 Bush | Buy now |
| 20 | 6AH2631100 Cable, throttle 1 | Buy now |
| 21 | 6AH4455400 Plate | Buy now |
| 22 | 9709506014 Bolt(gj3) | Buy now |
| 23 | 9299506600 Washer, plain (646) | Buy now |
| 24 | 6AH2634E00 Protector 1 | Buy now |
| 25 | 6AH4255100 Grommet | Buy now |
| 26 | 9038645001 Bush | Buy now |
| 27 | 9020139008 Washer, plate | Buy now |
| 28 | 9020639001 Washer, wave | Buy now |
| 29 | 9038120001 Bush, solid | Buy now |
| 30 | 6AH42131004D Cover, handle steering | Buy now |
| 31 | 9759506555 Bolt, hexagon w/w deep recess | Buy now |
| 32 | 6AH4253200 Cover | Buy now |


Steering



E3

| Ref | Part | |
|-----|---|-------------------------|
| 33 | 9011106072 Bolt,hex. socket button | Buy now |
| 34 | 9778060520 Screw, tapping(6k8) | Buy now |
| 35 | 6AH4411100 Handle, gear shift | Buy now |
| 36 | 9011906M05 Bolt, with washer(6l2) | Buy now |
| 37 | 9038706M86 Collar | Buy now |
| 38 | 9020615M18 Washer, wave(6l2) | Buy now |
| 39 | 6AH4412400 Link, shift rod | Buy now |
| 40 | 9299006200 Ybs66-6 washer, plain | Buy now |
| 41 | 9046818008 Clip 620436610000 | Buy now |
| 42 | 6G84419100 Indicator, shift | Buy now |
| 43 | 6AH8257500 Engine stop switch assembly | Buy now |
| 44 | 6828255600 Lanyard, stop switch | Buy now |
| 45 | 6898257Y00 Cap | Buy now |
| 46 | 6E08362741 Label, caution 7 | Buy now |
| 47 | 6E08362751 - | Buy now |


Steering Friction



E5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH4250800 Steering friction assembly | Buy now |
| 2 | 68T4252501 Plate, friction | Buy now |
| 3 | 9011905018 Bolt, with washer | Buy now |
| 4 | 67C4256200 Shaft, steering lock | Buy now |
| 5 | 9020210M56 Washer, plate | Buy now |
| 6 | 68T4256100 Knob, steering lock | Buy now |
| 7 | 6894363300 Cover, tilt lever | Buy now |
| 8 | 65W4252800 Plate, friction | Buy now |
| 9 | 9038705M05 Collar | Buy now |
| 10 | 9038705M11 Collar | Buy now |
| 11 | 9709505020 Bolt, hexagon | Buy now |
| 12 | 9299505600 Washer, plain (646) | Buy now |
| 13 | 9020910M26 Washer | Buy now |
| 14 | 9018510M14 Nut, self-locking | Buy now |
| 15 | 6AH4252700 Plate, friction | Buy now |

Steering Friction




6AH1100-F210

E5

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9010108022 Bolt, hexagon deep recess | Buy now |
| 17 | 9020108065 Washer, plate | Buy now |
| 18 | 68T4315500 Mark 1 | Buy now |

Steering Guide




 FWD
6AH1100-F341

C2

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AH6135000 Steering guide attachment kit AP | Buy now |
| 2 | 9020110M20 Washer, plate (663) | Buy now |
| 3 | 9018509M01 Nut, nylon (663) | Buy now |
| 4 | 9017009M03 Nut (689) | Buy now |
| 5 | 9038710M42 Collar (688) | Buy now |
| 6 | 6E56135500 Bolt | Buy now |
| 7 | 9020110M63 Washer, plate | Buy now |
| 8 | 6E54314501 Cap, clamp bracket | Buy now |
| 9 | 9321016275 O-ring | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AG42610004D Top Cowling assembly | Buy now |
| 1 | 6AG42610104D Top Cowling assembly | Buy now |
| 2 | 6AH4261300 Molding, air duct | Buy now |
| 3 | 9778050616 Screw, pan head tapping (ak5) | Buy now |
| 4 | 6AH4265100 Hook | Buy now |
| 5 | 9026606M02 Rivet (697) | Buy now |
| 6 | 6AH4261500 Seal | Buy now |
| 7 | 60R4265200 Hook | Buy now |
| 8 | 9709505014 Bolt, w/ plain | Buy now |
| 9 | 9299505600 Washer, plain (646) | Buy now |
| 10 | 6AH4264900 Holder, clamp band | Buy now |
| 11 | 6AG4267800 Graphic, front | Buy now |
| 12 | 6AHW007000 Graphic set | Buy now |
| 13 | 6AG4267700 Graphic, front | Buy now |
| 14 | 6AH4269700 Tuning fork mark | Buy now |


Top Cowling



| Ref | Part | |
|-----|--|-------------------------|
| 15 | 6AH4273500 Protector | Buy now |
| 16 | 67F1343403 □□□, □□□□□ | Buy now |


A4

Upper Casing



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH41137005B Guide, exhaust | Buy now |
| 2 | 9310112M63 Oil seal | Buy now |
| 3 | 65W4271700 Rubber, seal 2 | Buy now |
| 4 | 9709508014 Bolt, hexagon deep recess | Buy now |
| 5 | 9043008143 Gasket (256-11198-00) | Buy now |
| 6 | 9360619M23 Pin, dowel | Buy now |
| 7 | 6AH4113400 Gasket, exhaust manifold | Buy now |
| 8 | 6AH14711005B Muffler 1 <i>S(17.1")</i> | Buy now |
| 8 | 6AH14711105B Muffler 1 <i>L(22.1")</i> | Buy now |
| 9 | 9707506025 Bolt | Buy now |
| 10 | 9299506600 Washer, plain (646) | Buy now |
| 11 | 6AH4113800 Seal, ext. 1 | Buy now |
| 12 | 6AH45111004D Casing, upper <i>S(17.1")</i> | Buy now |
| 12 | 6AH45111104D Casing, upper <i>L(22.1")</i> | Buy now |
| 13 | 9707508030 Bolt, hexagon (fj1) | Buy now |


Upper Casing



B1

| Ref | Part | |
|-----|--|-------------------------|
| 14 | 9299508600 Washer, plain (663) | Buy now |
| 15 | 9360412M07 Pin, dowel (688) | Buy now |
| 16 | 9709505010 Bolt (682) | Buy now |
| 17 | 9299505600 Washer, plain (646) | Buy now |
| 18 | 68T4532100 Plate | Buy now |
| 19 | 9709506008 Bolt (fj1) | Buy now |
| 20 | 9048014M54 Grommet | Buy now |
| 21 | 6824531800 Bushing, drive shaft L(22.1") | Buy now |
| 22 | 9342030042 Circlip (650) L(22.1") | Buy now |

Valve



B2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AH1211100 Valve, intake | Buy now |
| 2 | 6AH1212100 Valve, exhaust | Buy now |
| 3 | 62Y1211600 Seat, valve spring | Buy now |
| 4 | 3YF1211300 Spring, valve inner | Buy now |
| 5 | 30X1211700 Retainer, valve spring | Buy now |
| 6 | 30X1211800 Cotter, valve | Buy now |
| 7 | 51Y1211900 Seal, valve stem | Buy now |
| 8 | 66M1214600 Shaft, rocker | Buy now |
| 9 | 6AH1227900 Plate | Buy now |
| 10 | 9701306012 Bolt(gh1) | Buy now |
| 11 | 9038713006 Collar | Buy now |
| 12 | 90501120A5 Spring, compression | Buy now |
| 13 | 6AH1215100 Arm, valve rocker | Buy now |
| 14 | 64J1215900 Screw, valve adjusting | Buy now |
| 15 | 62Y1215800 Nut, lock | Buy now |

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.