



Yamaha F225AET 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING 1	3
BOTTOM COWLING 2	9
BRACKET 1	12
BRACKET 2	18
CONTROL 1	22
CONTROL 2	27
CONTROL 3	31
CRANKSHAFT. PISTON	33
CYLINDER. CRANKCASE 1	36
CYLINDER. CRANKCASE 2	43
CYLINDER. CRANKCASE 3	47
ELECTRICAL 1	49
ELECTRICAL 2	53
ELECTRICAL 3	57
FUEL 1	60
FUEL 2	64
FUEL INJECTION PUMP 1	65
FUEL INJECTION PUMP 2	70
GENERATOR	74
INTAKE	78
LOWER CASING. DRIVE 1	82
LOWER CASING. DRIVE 2	95
LOWER CASING. DRIVE 3	101
LOWER CASING. DRIVE 4	115
METER	121
OIL PAN	126
POWER TRIM & TILT ASSY 1	130
POWER TRIM & TILT ASSY 2	141
REMOTE CONTROL BOX	143
REPAIR KIT 1	144
REPAIR KIT 2	148
STARTING MOTOR	153
STEERING GUIDE ATTACHMENT 1	157
STEERING GUIDE ATTACHMENT 2	159
SWITCH. PANEL	161
THROTTLE BODY ASSY 1	164
THROTTLE BODY ASSY 2	170
THROTTLE BODY ASSY 3	175
TOP COWLING	179
UPPER CASING	183
VALVE	191


Bottom Cowling 1



F3


Ref	Part	
1	69J42710018D Bottom cowling assembly	Buy now
1	69J-42710-01-8D Bottom cowling assembly	Buy now
2	69J42738015B Plate, fitting	Buy now
2	69J-42738-01-5B Plate, fitting	Buy now
3	69J4274410 Stay	Buy now
3	69J-42744-10 Stay	Buy now
4	97885--06010 Screw pan head	Buy now
4	97885-06010 Screw pan head	Buy now
5	90109--06M82 Bolt	Buy now
5	90109-06M82 Bolt	Buy now
6	69J4272501 Grommet	Buy now
6	69J-42725-01 Grommet	Buy now
7	64D--42738--10--5B Plate, fitting	Buy now
7	64D-42738-10-5B Plate, fitting	Buy now
9	69J4261500 Seal	Buy now

Bottom Cowling 1




Ref	Part	
9	69J-42615-00 Seal	Buy now
10	69J-42716-00 Rubber seal 1	Buy now
10	69J-42716-00 Rubber seal 1	Buy now
11	90119-08M22 Bolt, with washer	Buy now
11	90119-08M22 Bolt, with washer	Buy now
12	90480-22M81 Grommet	Buy now
12	90480-22M81 Grommet	Buy now
13	90387-08M37 Coller (6e5)	Buy now
13	90387-08M37 Coller (6e5)	Buy now
14	6H14272620 Grommet	Buy now
14	6H1-42726-20 Grommet	Buy now
15	90465-11M10 Clamp	Buy now
15	90465-11M10 Clamp	Buy now
16	61A-42727-00 Grommet	Buy now
16	61A-42727-00 Grommet	Buy now

Bottom Cowling 1




Ref	Part	
17	69J--44391--00 Nipple, hose	Buy now
17	69J--44391--00 Nipple, hose	Buy now
18	69J--42717--00 Rubber, seal 2	Buy now
18	69J--42717--00 Rubber, seal 2	Buy now
19	61A--42717--00 Rubber, seal 2	Buy now
19	61A--42717--00 Rubber, seal 2	Buy now
20	6E5--82588--00 Plate	Buy now
20	6E5--82588--00 Plate	Buy now
21	90109--06M81 Bolt	Buy now
21	90109--06M81 Bolt	Buy now
22	90462--20001 Clamp	Buy now
22	90462--20001 Clamp	Buy now
23	90109--06M86 Bolt	Buy now
23	90109--06M86 Bolt	Buy now
24	69J8255400 Stay, Neutral Switch	Buy now

Bottom Cowling 1




Ref	Part	
24	69J-82554-00 Stay, Neutral Switch	Buy now
26	90464-09M47 Clamp(65j)	Buy now
26	90464-09M47 Clamp(65j)	Buy now
27	68F42828005B Plate, clamp	Buy now
27	68F-42828-00-5B Plate, clamp	Buy now
28	69J42828005B Plate, Clamp	Buy now
28	69J-42828-00-5B Plate, Clamp	Buy now
30	69J--42815-00--8D Lever, clamp	Buy now
30	69J-42815-00-8D Lever, clamp	Buy now
31	69J--42817-00--8D Lever, clamp	Buy now
31	69J-42817-00-8D Lever, clamp	Buy now
32	90386-15M73 Bush(6l2)	Buy now
32	90386-15M73 Bush(6l2)	Buy now
33	90206-15M18 Washer, wave(6l2)	Buy now
33	90206-15M18 Washer, wave(6l2)	Buy now

Bottom Cowling 1




Ref	Part	
34	68F4281800 Lever, clamp	Buy now
34	68F-42818-00 Lever, clamp	Buy now
35	97095--06020 Bolt(7u8)	Buy now
35	97095--06020 Bolt(7u8)	Buy now
36	90201--06068 Washer,plate (6k8)	Buy now
36	90201--06068 Washer,plate (6k8)	Buy now
37	68F42828105B Plate, clamp	Buy now
37	68F-42828-10-5B Plate, clamp	Buy now
39	69J--42816--00--8D Lever, clamp	Buy now
39	69J-42816-00-8D Lever, clamp	Buy now
42	67F4281800 Lever, clamp	Buy now
42	67F-42818-00 Lever, clamp	Buy now
45	64D--43144--00 Hook, spring	Buy now
45	64D-43144-00 Hook, spring	Buy now
47	90506--16M34 Spring, tension(64d)	Buy now

Bottom Cowling 1




Ref	Part	
47	90506-16M34 Spring, tension(64d)	Buy now
48	68F--42753--00 Fastner AP	Buy now
48	68F--42753--00 Fastner AP	Buy now
49	90464--20258 Clamp AP	Buy now
49	90464--20258 Clamp AP	Buy now
50	68V--82594--00 Clamp	Buy now
50	68V--82594--00 Clamp	Buy now
51	67F8237700 Label (sparkplug mark)	Buy now
51	67F--82377--00 Label (sparkplug mark)	Buy now
52	6A1--28176--00 Label Caution	Buy now
52	6A1--28176--00 Label Caution	Buy now
53	6E3--8257H--00 Plate Mark	Buy now
53	6E3--8257H--00 Plate Mark	Buy now

Bottom Cowling 2




Ref	Part	
1	69J--42741--00--8D Apron	Buy now
1	69J--42741--00--8D Apron	Buy now
2	90173--06001 Nut, square	Buy now
2	90173--06001 Nut, square	Buy now
3	69J--42771--00--8D Apron	Buy now
3	69J--42771--00--8D Apron	Buy now
4	9011106025 Bolt,hex. socket button	Buy now
4	90111--06025 Bolt,hex. socket button	Buy now
5	9011106026 Bolt,hex. socket button	Buy now
5	90111--06026 Bolt,hex. socket button	Buy now
6	90480--14M17 Grommet(6j8)	Buy now
6	90480--14M17 Grommet(6j8)	Buy now
7	69J4277400 Stay, apron 1	Buy now
7	69J--42774--00 Stay, apron 1	Buy now
8	69J--45151--00--8D Cover, upper casing	Buy now

Bottom Cowling 2



Ref	Part	
8	69J-45151-00-8D Cover, upper casing	Buy now
10	6E5-24379-00 Pipe, joint 4	Buy now
10	6E5-24379-00 Pipe, joint 4	Buy now
11	9044511012 Hose (I600)	Buy now
11	90445-11012 Hose (I600)	Buy now
12	68T-12572-00 Adapter	Buy now
12	68T-12572-00 Adapter	Buy now
13	6R3-12581-00 Joint, hose 1	Buy now
13	6R3-12581-00 Joint, hose 1	Buy now
14	6R3-12582-00 Joint, hose 2	Buy now
14	6R3-12582-00 Joint, hose 2	Buy now
15	6R3-12583-00 Gasket, hose joint	Buy now
15	6R3-12583-00 Gasket, hose joint	Buy now
16	90445-11028 Hose (I1050)	Buy now
16	90445-11028 Hose (I1050)	Buy now


Bottom Cowling 2



F5


Ref	Part	
17	90465--11M10 Clamp	Buy now
17	90465--11M10 Clamp	Buy now
18	97780--60520 Screw, tapping(6k8)	Buy now
18	97780--60520 Screw, tapping(6k8)	Buy now

Bracket 1




Ref	Part	
1	69J--43111--01--8D Bracket, clamp 1	Buy now
1	69J--43111--01--8D Bracket, clamp 1	Buy now
2	6G5--45251--02 Anode	Buy now
2	6G5--45251--02 Anode	Buy now
3	6G5--44526--00 Plate	Buy now
3	6G5--44526--00 Plate	Buy now
4	97095--06025 Bolt	Buy now
4	97095--06025 Bolt	Buy now
5	92995--06600 Washer, plain (646)	Buy now
5	92995--06600 Washer, plain (646)	Buy now
6	6H1--82148--00 Wire, lead	Buy now
6	6H1--82148--00 Wire, lead	Buy now
7	97095--06010 Bolt	Buy now
7	97095--06010 Bolt	Buy now
9	6E5--82148--00 Wire, lead 5	Buy now

Bracket 1




Ref	Part	
9	6E5-82148-00 Wire, lead 5	Buy now
10	97885-06012 Screw, pan head(62j)	Buy now
10	97885-06012 Screw, pan head(62j)	Buy now
12	61A-43132-00 Washer, friction	Buy now
12	61A-43132-00 Washer, friction	Buy now
13	97885-06010 Screw pan head	Buy now
13	97885-06010 Screw pan head	Buy now
14	69J-43112-01-8D Bracket, clamp 2	Buy now
14	69J-43112-01-8D Bracket, clamp 2	Buy now
15	61A-43133-00 Washer,friction	Buy now
15	61A-43133-00 Washer,friction	Buy now
17	93700-06M03 Nipple, grease(6a1)	Buy now
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	90465-08M83 Clamp	Buy now
18	90465-08M83 Clamp	Buy now

Bracket 1




Ref	Part	
21	6R3--43131--00 Bolt, clamp bracket	Buy now
21	6R3-43131-00 Bolt, clamp bracket	Buy now
22	90386--25M31 Bushing (6e5)	Buy now
22	90386-25M31 Bushing (6e5)	Buy now
23	90201--26M59 Washer, plate (6e5)	Buy now
23	90201-26M59 Washer, plate (6e5)	Buy now
24	90185--22M11 Nut, self-locking	Buy now
24	90185-22M11 Nut, self-locking	Buy now
25	90465--11M10 Clamp	Buy now
25	90465-11M10 Clamp	Buy now
27	97095--06014 Bolt(gj3)	Buy now
27	97095-06014 Bolt(gj3)	Buy now
29	97095--10045 Bolt(64d)	Buy now
29	97095-10045 Bolt(64d)	Buy now
30	92995--10100 Ybs67-10 washer, spring	Buy now

Bracket 1




Ref	Part	
30	92995-10100 Ybs67-10 washer, spring	Buy now
31	92995-10600 Washer, plate	Buy now
31	92995-10600 Washer, plate	Buy now
32	61A-43311-21-8D Bracket, swivel 1	Buy now
32	61A-43311-21-8D Bracket, swivel 1	Buy now
34	69J-82147-00 Wire, lead 5	Buy now
34	69J-82147-00 Wire, lead 5	Buy now
35	6G5-43144-00 Hook, spring	Buy now
35	6G5-43144-00 Hook, spring	Buy now
37	61A-43181-01 Lever, tilt stop 1	Buy now
37	61A-43181-01 Lever, tilt stop 1	Buy now
38	6G5-43185-02 Lever, tilt stop 2	Buy now
38	6G5-43185-02 Lever, tilt stop 2	Buy now
39	90386-10M16 Bushing (688)	Buy now
39	90386-10M16 Bushing (688)	Buy now

Bracket 1




Ref	Part	
40	6G5--43148--00 Collar, distance	Buy now
40	6G5--43148--00 Collar, distance	Buy now
41	90249--06M19 Pin(6e5)	Buy now
41	90249--06M19 Pin(6e5)	Buy now
42	90387--10M02 Collar(6e5)	Buy now
42	90387--10M02 Collar(6e5)	Buy now
43	91690--30020 Pin, spring (6h4)	Buy now
43	91690--30020 Pin, spring (6h4)	Buy now
44	90506--16003 Spring, tension	Buy now
44	90506--16003 Spring, tension	Buy now
45	6E5--43126--02 Pin, upper shock mount	Buy now
45	6E5--43126--02 Pin, upper shock mount	Buy now
46	90386--18M63 Bush(6e5)	Buy now
46	90386--18M63 Bush(6e5)	Buy now
47	90386--18M14 Bushing (6e5)	Buy now

Bracket 1




Ref	Part	
47	90386-18M14 Bushing (6e5)	Buy now
48	93410-18M02 Circlip (6f2)	Buy now
48	93410-18M02 Circlip (6f2)	Buy now
49	90101-12M05 Bolt (l:130mm)	Buy now
49	90101-12M05 Bolt (l:130mm)	Buy now
50	90201-13M01 Washer, plate(6e5)	Buy now
50	90201-13M01 Washer, plate(6e5)	Buy now
51	90201-12M05 Washe, plate(663)	Buy now
51	90201-12M05 Washe, plate(663)	Buy now
52	95380-12600 Nut (707)	Buy now
52	95380-12600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	69J8367200 Trim sender	Buy now
1	69J-83672-00 Trim sender	Buy now
2	97885--06016 Screw, pan head(6b0)	Buy now
2	97885-06016 Screw, pan head(6b0)	Buy now
3	61A-43376-00 Bolt, thrust receiver	Buy now
3	61A-43376-00 Bolt, thrust receiver	Buy now
4	95780-10300 Nut, nylon (6e5)	Buy now
4	95780-10300 Nut, nylon (6e5)	Buy now
5	69J-42510-00-8D Steering bracket assembly	Buy now
5	69J-42510-00-8D Steering bracket assembly	Buy now
6	90201--40M00 Washer, plate(61a)	Buy now
6	90201-40M00 Washer, plate(61a)	Buy now
7	90386--39M89 Bush(61a)	Buy now
7	90386-39M89 Bush(61a)	Buy now
8	93210--35321 O-ring (3m7)	Buy now

Bracket 2




Ref	Part	
8	93210-35321 O-ring (3m7)	Buy now
9	90202-40M47 Washer, plate(61a)	Buy now
9	90202-40M47 Washer, plate(61a)	Buy now
10	69J-44551-00-8D Housing, lower mount rubber 1	Buy now
10	69J-44551-00-8D Housing, lower mount rubber 1	Buy now
11	93410-37M04 Circlip (6e5)	Buy now
11	93410-37M04 Circlip (6e5)	Buy now
12	61A-44575-00 Damper, lower mount rubber	Buy now
12	61A-44575-00 Damper, lower mount rubber	Buy now
13	66K445550094 Mount damper, lower side	Buy now
13	66K-44555-00-94 Mount damper, lower side	Buy now
14	90202-32M19 Washer, plate (6e5)	Buy now
14	90202-32M19 Washer, plate (6e5)	Buy now
15	90201-16M55 Washer, plate (6e5)	Buy now
15	90201-16M55 Washer, plate (6e5)	Buy now

Bracket 2




Ref	Part	
16	6E5--82149--00 Wire, lead 3	Buy now
16	6E5--82149--00 Wire, lead 3	Buy now
17	9010914M48 Bolt	Buy now
17	90109--14M48 Bolt	Buy now
18	90201--15M58 Washer, plate (6e5)	Buy now
18	90201--15M58 Washer, plate (6e5)	Buy now
19	90185--14M00 Nut, self-locking(61a)	Buy now
19	90185--14M00 Nut, self-locking(61a)	Buy now
20	92995--14600 Washer (6e5)	Buy now
20	92995--14600 Washer (6e5)	Buy now
21	61A445520194 Housing, lower mount rubber	Buy now
21	61A--44552--01-94 Housing, lower mount rubber	Buy now
22	97095--10045 Bolt(64d)	Buy now
22	97095--10045 Bolt(64d)	Buy now
23	92995--10600 Washer, plate	Buy now

Bracket 2




Ref	Part	
23	92995-10600 Washer, plate	Buy now
24	66K445140094 Mount damper, upper side	Buy now
24	66K-44514-00-94 Mount damper, upper side	Buy now
25	90201-16M01 Washer, plate(61a)	Buy now
25	90201-16M01 Washer, plate(61a)	Buy now
26	90202-28M46 Washer, plate(61a)	Buy now
26	90202-28M46 Washer, plate(61a)	Buy now
27	90201-28M01 Washer, plate(61a)	Buy now
27	90201-28M01 Washer, plate(61a)	Buy now
28	90109-14M10 Bolt	Buy now
28	90109-14M10 Bolt	Buy now
31	69J-44533-00 Damper, upper mount rubber	Buy now
31	69J-44533-00 Damper, upper mount rubber	Buy now
32	61A-44511-00-94 Cover, upper mount	Buy now
32	61A-44511-00-94 Cover, upper mount	Buy now

Control 1




Ref	Part	
1	69J4853100 Bracket, remote control 1	Buy now
1	69J-48531-00 Bracket, remote control 1	Buy now
2	90109--06M86 Bolt	Buy now
2	90109-06M86 Bolt	Buy now
3	6E5--48344--00 Cable end, remote control	Buy now
3	6E5-48344-00 Cable end, remote control	Buy now
4	90468--18008 Clip 620436610000	Buy now
4	90468-18008 Clip 620436610000	Buy now
5	69J44117001S Bracket	Buy now
5	69J-44117-00-1S Bracket	Buy now
6	97095--06035 Bolt(j52)	Buy now
6	97095-06035 Bolt(j52)	Buy now
7	92995--06600 Washer, plain (646)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	69J44176011S Bracket	Buy now

Control 1




Ref	Part	
8	69J-44176-01-1S Bracket	Buy now
9	93700-06M01 Nipple, grease(61a)	Buy now
9	93700-06M01 Nipple, grease(61a)	Buy now
10	90386-12069 Bush(666)	Buy now
10	90386-12069 Bush(666)	Buy now
11	90109-08019 Bolt	Buy now
11	90109-08019 Bolt	Buy now
12	90508-20020 Spring, torsion	Buy now
12	90508-20020 Spring, torsion	Buy now
13	68F8259F00 Switch assembly	Buy now
13	68F-8259F-00 Switch assembly	Buy now
14	69J-8259F-00 Switch assembly	Buy now
14	69J-8259F-00 Switch assembly	Buy now
15	61A-82588-01 Plate	Buy now
15	61A-82588-01 Plate	Buy now

Control 1




Ref	Part	
16	97885--04016 Screw, panhead (796)	Buy now
16	97885--04016 Screw, panhead (796)	Buy now
17	92995--04100 Ybs67-4 washer, spring	Buy now
17	92995--04100 Ybs67-4 washer, spring	Buy now
18	90465--11M10 Clamp	Buy now
18	90465--11M10 Clamp	Buy now
19	90465--06M86 Clamp	Buy now
19	90465--06M86 Clamp	Buy now
20	90464--09010 Clamp	Buy now
20	90464--09010 Clamp	Buy now
21	69J4412100 Lever, Shift Rod	Buy now
21	69J--44121--00 Lever, Shift Rod	Buy now
22	69J--44122--00 Bushing, shift rod lever	Buy now
22	69J--44122--00 Bushing, shift rod lever	Buy now
23	90202--08M20 Washer, plate (6e5)	Buy now

Control 1




Ref	Part	
23	90202-08M20 Washer, plate (6e5)	Buy now
25	90386-06M12 Bushing (688)	Buy now
25	90386-06M12 Bushing (688)	Buy now
26	69J-44118-00 Bracket	Buy now
26	69J-44118-00 Bracket	Buy now
27	648-42715-00 Bushing 2	Buy now
27	648-42715-00 Bushing 2	Buy now
28	93501-04M02 Ball (697)	Buy now
28	93501-04M02 Ball (697)	Buy now
29	90501-12082 Spring 6484411600	Buy now
29	90501-12082 Spring 6484411600	Buy now
30	97075-06030 Bolt(jf7)	Buy now
30	97075-06030 Bolt(jf7)	Buy now
32	91690-30010 Pin, spring (663)	Buy now
32	91690-30010 Pin, spring (663)	Buy now

Control 1



Ref	Part	
33	69J-44120-00 Handle gear shift assembly X	Buy now
33	69J-44120-10 Handle gear shift assembly U	Buy now
33	69J-44120-00 Handle gear shift assembly X	Buy now
33	69J-44120-10 Handle gear shift assembly U	Buy now
34	93210-09165 O-ring	Buy now
34	93210-09165 O-ring	Buy now
35	90386-90M90 Bush(61a)	Buy now
35	90386-90M90 Bush(61a)	Buy now
36	90201-09M02 Washer, plate(61a)	Buy now
36	90201-09M02 Washer, plate(61a)	Buy now
37	91490-20015 Pin, cotter (648)	Buy now
37	91490-20015 Pin, cotter (648)	Buy now
38	6E5-42724-00 Grommet	Buy now
38	6E5-42724-00 Grommet	Buy now

Control 2




69J1100-2230

A4

Ref	Part	
1	69J4215400 Lever, throttle control	Buy now
1	69J-42154-00 Lever, throttle control	Buy now
2	68V-42171-00 Bushing	Buy now
2	68V-42171-00 Bushing	Buy now
3	90386--10025 Bushing (658)	Buy now
3	90386-10025 Bushing (658)	Buy now
4	93410-10082 Circlip	Buy now
4	93410-10082 Circlip	Buy now
5	69J421520094 Gear	Buy now
5	69J-42152-00-94 Gear	Buy now
6	91690--30025 Pin, spring	Buy now
6	91690-30025 Pin, spring	Buy now
7	91690--30018 926-51502-00 pin, spring (700)	Buy now
7	91690-30018 926-51502-00 pin, spring (700)	Buy now
8	69J4215300 Shaft Throttle Control	Buy now

Control 2




69J1100-2230

A4

Ref	Part	
8	69J-42153-00 Shaft Throttle Control	Buy now
9	69J416320094 Lever, magneto control	Buy now
9	69J-41632-00-94 Lever, magneto control	Buy now
10	663--85518-00 Joint, ball	Buy now
10	663-85518-00 Joint, ball	Buy now
11	90201-10M02 Washer, plate(6g9)	Buy now
11	90201-10M02 Washer, plate(6g9)	Buy now
12	6E5--48344-00 Cable end, remote control	Buy now
12	6E5-48344-00 Cable end, remote control	Buy now
13	90468-18008 Clip 620436610000	Buy now
13	90468-18008 Clip 620436610000	Buy now
14	69J416610094 Bracket	Buy now
14	69J-41661-00-94 Bracket	Buy now
15	97095-06045 Bolt, hexagon	Buy now
15	97095-06045 Bolt, hexagon	Buy now

Control 2




69J1100-2230

A4

Ref	Part	
16	92995--06600 Washer, plain (646)	Buy now
16	92995--06600 Washer, plain (646)	Buy now
17	9046506M67 Clamp	Buy now
17	90465--06M67 Clamp	Buy now
18	97095--06014 Bolt(gj3)	Buy now
18	97095--06014 Bolt(gj3)	Buy now
20	6764166200 Bracket 2	Buy now
20	676--41662--00 Bracket 2	Buy now
21	97095--06020 Bolt(7u8)	Buy now
21	97095--06020 Bolt(7u8)	Buy now
23	69J4121300 Cam, accel.	Buy now
23	69J--41213--00 Cam, accel.	Buy now
24	69J--44135--00 Spring	Buy now
24	69J--44135--00 Spring	Buy now
25	9010906040 Bolt	Buy now

Control 2




69J1100-2230

A4

Ref	Part	
25	90109-06040 Bolt	Buy now
26	90206-10M04 Washer, wave (676)	Buy now
26	90206-10M04 Washer, wave (676)	Buy now


Control 3



A5

Ref	Part	
1	69J4124100 Rod, link	Buy now
1	69J-41241-00 Rod, link	Buy now
2	682-41237-00 Joint, link 2	Buy now
2	682-41237-00 Joint, link 2	Buy now
3	95380-05600 Nut, hexagon (663)	Buy now
3	95380-05600 Nut, hexagon (663)	Buy now
4	69J4121000 Accel. arm assembly	Buy now
4	69J-41210-00 Accel. arm assembly	Buy now
5	69J4163500 Shaft, link connecting	Buy now
5	69J-41635-00 Shaft, link connecting	Buy now
6	91690-30008 Pin. spring(656)	Buy now
6	91690-30008 Pin. spring(656)	Buy now
7	95895-06030 Bolt, flange deep recess	Buy now
7	95895-06030 Bolt, flange deep recess	Buy now
8	90201-06M31 Washer (6a0)	Buy now

Control 3




69J1010-2230

A5


Ref	Part	
8	90201-06M31 Washer (6a0)	Buy now
9	69J4121100 Link, accel.	Buy now
9	69J-41211-00 Link, accel.	Buy now
10	69J4163600 Rod, magneto control	Buy now
10	69J-41636-00 Rod, magneto control	Buy now
11	9568005100 Nut, u (705)	Buy now
11	95680-05100 Nut, u (705)	Buy now

Crankshaft. Piston




Ref	Part	
1	69J1141100 Crankshaft & oil pump set	Buy now
1	69J-11411-00 Crankshaft & oil pump set	Buy now
2	93102-63004 Oil seal	Buy now
2	93102-63004 Oil seal	Buy now
3	69J1141600 Plane bearing, crankshaft 1 (UR #1	Buy now
3	69J1141610 Plane bearing, crankshaft 1 (UR #2	Buy now
3	69J1141620 Plane bearing, crankshaft 1 (# UR #3	Buy now
3	69J-11416-00 Plane bearing, crankshaft 1 (UR #1	Buy now
3	69J-11416-10 Plane bearing, crankshaft 1 (UR #2	Buy now
3	69J-11416-20 Plane bearing, crankshaft 1 (# UR #3	Buy now
4	69J1141700 Plane bearing, crankshaft 2 (# UR #1	Buy now
4	69J1141710 Plane bearing, crankshaft 2 (# UR #2	Buy now
4	69J1141720 Plane bearing, crankshaft 2 UR #3	Buy now
4	69J-11417-00 Plane bearing, crankshaft 2 (# UR #1	Buy now
4	69J-11417-10 Plane bearing, crankshaft 2 (# UR #2	Buy now

Crankshaft. Piston



Ref	Part	
4	69J-11417-20 Plane bearing, crankshaft 2 UR #3	Buy now
5	69J1142600 Bearing, thrust 1 (#1) UR #1	Buy now
5	69J1142610 Bearing, thrust 1 (#2) UR #2	Buy now
5	69J1142620 Bearing, thrust 1 (#3) UR #3	Buy now
5	69J-11426-00 Bearing, thrust 1 (#1) UR #1	Buy now
5	69J-11426-10 Bearing, thrust 1 (#2) UR #2	Buy now
5	69J-11426-20 Bearing, thrust 1 (#3) UR #3	Buy now
6	69J-11427-00 Bearing, thrust 2	Buy now
6	69J-11427-00 Bearing, thrust 2	Buy now
7	69JW116500 Connecting rod assembly	Buy now
7	69J-W1165-00 Connecting rod assembly	Buy now
8	69J1165400 Bolt, connecting rod	Buy now
8	69J-11654-00 Bolt, connecting rod	Buy now
9	69J1165600 Plane bearing, connecting rod UR YELLOW	Buy now
9	69J1165610 Plane bearing, connecting rod UR GREEN	Buy now

Crankshaft. Piston




69J1010-2030

B2

Ref	Part	
9	69J1165620 Plane bearing, connecting rod UR BLUE	Buy now
9	69J-11656-00 Plane bearing, connecting rod UR YELLOW	Buy now
9	69J-11656-10 Plane bearing, connecting rod UR GREEN	Buy now
9	69J-11656-20 Plane bearing, connecting rod UR BLUE	Buy now
10	69J1163100B0 Piston (std)	Buy now
10	69J-11631-00-B0 Piston (std)	Buy now
11	69J1160300 Piston ring set (std)	Buy now
11	69J-11603-00 Piston ring set (std)	Buy now
12	69J1163300 Pin, piston	Buy now
12	69J-11633-00 Pin, piston	Buy now
13	69J1163400 Clip, piston pin	Buy now
13	69J-11634-00 Clip, piston pin	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
3	93606--12019 Pin, dowel (614)	Buy now
3	93606--12019 Pin, dowel (614)	Buy now
4	9181418001 Pin, dowel	Buy now
4	91814--18001 Pin, dowel	Buy now
5	90340--14M06 Plug, straight screw(62y)	Buy now
5	90340--14M06 Plug, straight screw(62y)	Buy now
6	90430--14115 Gasket (663)	Buy now
6	90430--14115 Gasket (663)	Buy now
7	69J1512300 Plate, baffle 1	Buy now
7	69J--15123--00 Plate, baffle 1	Buy now
8	69J1518700 Bolt	Buy now
8	69J--15187--00 Bolt	Buy now
9	69J1548100 Bolt 1	Buy now
9	69J--15481--00 Bolt 1	Buy now
10	69J1548200 Bolt 2	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
10	69J-15482-00 Bolt 2	Buy now
11	9570706500 Nut, flange(4mv)	Buy now
11	95707-06500 Nut, flange(4mv)	Buy now
12	90119-08M66 Bolt, with washer	Buy now
12	90119-08M66 Bolt, with washer	Buy now
14	69J-15451-00 Gasket, crankcase cover 1	Buy now
14	69J-15451-00 Gasket, crankcase cover 1	Buy now
16	90119-08009 Bolt, with washer	Buy now
16	90119-08009 Bolt, with washer	Buy now
17	69J1116800 Cover Breather	Buy now
17	69J-11168-00 Cover Breather	Buy now
18	98507-04008 Screw, pan head(jg1)	Buy now
18	98507-04008 Screw, pan head(jg1)	Buy now
19	92907-04600 Washer(jf2)	Buy now
19	92907-04600 Washer(jf2)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
20	69J--11119--00 Hanger, engine	Buy now
20	69J--11119--00 Hanger, engine	Buy now
21	90119--06MA2 Bolt, with washer	Buy now
21	90119--06MA2 Bolt, with washer	Buy now
23	69J1131B00 Gasket, cover	Buy now
23	69J--1131B--00 Gasket, cover	Buy now
24	90119--06MA4 Bolt, with washer	Buy now
24	90119--06MA4 Bolt, with washer	Buy now
25	67F1241100 Thermostat	Buy now
25	67F--12411--00 Thermostat	Buy now
27	90109--06M86 Bolt	Buy now
27	90109--06M86 Bolt	Buy now
28	97095--06025 Bolt	Buy now
28	97095--06025 Bolt	Buy now
29	92995--06600 Washer, plain (646)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
29	92995-06600 Washer, plain (646)	Buy now
30	69J1243A00 Hose 1	Buy now
30	69J-1243A-00 Hose 1	Buy now
31	69J1243E00 Hose 2	Buy now
31	69J-1243E-00 Hose 2	Buy now
32	90465--11M10 Clamp	Buy now
32	90465-11M10 Clamp	Buy now
33	69J1135100 Gasket, cylinder	Buy now
33	69J-11351-00 Gasket, cylinder	Buy now
34	67F427610094 Stopper	Buy now
34	67F-42761-00-94 Stopper	Buy now
35	68F--44533--00 Damper, upper mount rubber	Buy now
35	68F-44533-00 Damper, upper mount rubber	Buy now
38	93210--25552 O-ring (22f)	Buy now
38	93210-25552 O-ring (22f)	Buy now


Cylinder. Crankcase 1



A6


Ref	Part	
39	93210--19MJ1 O-ring	Buy now
39	93210--19MJ1 O-ring	Buy now
40	69J113130094 Plug, blind	Buy now
40	69J-11313-00-94 Plug, blind	Buy now
41	93210--25647 O-ring (7or)	Buy now
41	93210--25647 O-ring (7or)	Buy now
42	97095--06020 Bolt(7u8)	Buy now
42	97095--06020 Bolt(7u8)	Buy now
44	69J--14664-00 Grommet, water shut	Buy now
44	69J--14664-00 Grommet, water shut	Buy now
45	69J1344000 Element assembly, oil cleaner	Buy now
45	69J--13440-00 Element assembly, oil cleaner	Buy now
46	69J1285800 Bolt, union	Buy now
46	69J--12858-00 Bolt, union	Buy now
47	69J134460094 Connector	Buy now

Cylinder. Crankcase 1



Ref	Part	
47	69J-13446-00-94 Connector	Buy now
48	69J1347700 Gasket	Buy now
48	69J-13477-00 Gasket	Buy now
49	97095--06045 Bolt, hexagon	Buy now
49	97095-06045 Bolt, hexagon	Buy now
51	69J1344700 Cover, oil element	Buy now
51	69J-13447-00 Cover, oil element	Buy now
52	97095--06040 Bolt (682)	Buy now
52	97095-06040 Bolt (682)	Buy now
54	6G8--15363--00 Plug, oil	Buy now
54	6G8-15363-00 Plug, oil	Buy now
55	93210--24M79 O-ring	Buy now
55	93210-24M79 O-ring	Buy now
56	69J153190015 Joint	Buy now
56	69J-15319-00-15 Joint	Buy now


Cylinder. Crankcase 1



A6


Ref	Part	
57	69J15364A0 Gasket, oil plug	Buy now
57	69J-15364-A0 Gasket, oil plug	Buy now
60	69J8256000 Thermo switch assembly	Buy now
60	69J-82560-00 Thermo switch assembly	Buy now
62	6E9--82588--00 Plate	Buy now
62	6E9--82588--00 Plate	Buy now
63	69J8365100 Sender, oil pressure	Buy now
63	69J-83651-00 Sender, oil pressure	Buy now

Cylinder. Crankcase 2



Ref	Part	
3	69J1113310 Guide, intake valve	Buy now
3	69J-11133-10 Guide, intake valve	Buy now
4	90344-51019 Plug, taper screw	Buy now
4	90344-51019 Plug, taper screw	Buy now
5	91809-08006 Pin, dowel	Buy now
5	91809-08006 Pin, dowel	Buy now
6	90119-07235 Bolt, with washer	Buy now
6	90119-07235 Bolt, with washer	Buy now
7	90119-07234 Bolt, with washer	Buy now
7	90119-07234 Bolt, with washer	Buy now
15	67F1132500 Anode	Buy now
15	67F-11325-00 Anode	Buy now
17	97075-06020 Bolt(7u8)	Buy now
17	97075-06020 Bolt(7u8)	Buy now
18	92995-06600 Washer, plain (646)	Buy now

Cylinder. Crankcase 2




69J1100-2042

B3

Ref	Part	
18	92995-06600 Washer, plain (646)	Buy now
19	67F-11328-00 Grommet, anode	Buy now
19	67F-11328-00 Grommet, anode	Buy now
20	97575-08540 Bolt, hexagon w/w deep recess	Buy now
20	97575-08540 Bolt, hexagon w/w deep recess	Buy now
21	69J1118101 Gasket, cylinder head 1	Buy now
21	69J-11181-01 Gasket, cylinder head 1	Buy now
22	9038710M08 Pin, dowel	Buy now
22	90387-10M08 Pin, dowel	Buy now
23	9015510001 Screw, flat fillister	Buy now
23	90155-10001 Screw, flat fillister	Buy now
24	90119-08M91 Bolt, with washer	Buy now
24	90119-08M91 Bolt, with washer	Buy now
25	90119-08021 Bolt, with washer	Buy now
25	90119-08021 Bolt, with washer	Buy now

Cylinder. Crankcase 2




69J1100-2042

B3


Ref	Part	
26	69J1118201 Gasket, cylinder head 2	Buy now
26	69J-11182-01 Gasket, cylinder head 2	Buy now
31	69J11191001S Cover, cylinder head 1	Buy now
31	69J-11191-00-1S Cover, cylinder head 1	Buy now
32	69J1113500 Plate, breather 3	Buy now
32	69J-11135-00 Plate, breather 3	Buy now
33	98507-04008 Screw, pan head(jg1)	Buy now
33	98507-04008 Screw, pan head(jg1)	Buy now
34	92907-04600 Washer(jf2)	Buy now
34	92907-04600 Washer(jf2)	Buy now
35	69J1119300 Gasket, head cover 1	Buy now
35	69J-11193-00 Gasket, head cover 1	Buy now
36	97095-06030 Bolt(jf7)	Buy now
36	97095-06030 Bolt(jf7)	Buy now
38	69J11192001S Cover Cylinder Head 2	Buy now

Cylinder. Crankcase 2




Ref	Part	
38	69J-11192-00-1S Cover Cylinder Head 2	Buy now
39	69J1119400 Gasket, head cover 2	Buy now
39	69J-11194-00 Gasket, head cover 2	Buy now
42	94702--00391 Plug, spark (lfr5a-11)	Buy now
42	94702--00391 Plug, spark (lfr5a-11)	Buy now

Cylinder. Crankcase 3



Ref	Part	
1	69J4111001S Inner Cover, Exhaust	Buy now
1	69J-41111-00-1S Inner Cover, Exhaust	Buy now
2	69J41121001S Inner Cover,Exhaust	Buy now
2	69J-41121-00-1S Inner Cover,Exhaust	Buy now
3	69J4113001S Outer Cover, Exhaust	Buy now
3	69J-41113-00-1S Outer Cover, Exhaust	Buy now
4	69J41123001S Outer Cover, Exhaust	Buy now
4	69J-41123-00-1S Outer Cover, Exhaust	Buy now
5	69J4111200 Gasket, exhaust inner cover	Buy now
5	69J-41112-00 Gasket, exhaust inner cover	Buy now
6	69J4111400 Gasket, exhaust outer cover	Buy now
6	69J-41114-00 Gasket, exhaust outer cover	Buy now
7	90119-06027 Bolt, with washer	Buy now
7	90119-06027 Bolt, with washer	Buy now
8	97095-08014 Bolt, hexagon deep recess	Buy now

Cylinder. Crankcase 3




69J2010-3050

B5


Ref	Part	
8	97095--08014 Bolt, hexagon deep recess	Buy now
9	90430--08143 Gasket (256-11198-00)	Buy now
9	90430--08143 Gasket (256-11198-00)	Buy now
10	90340--18M09 Plug, straight screw	Buy now
10	90340--18M09 Plug, straight screw	Buy now
11	90430--18130 Gasket (1j7)	Buy now
11	90430--18130 Gasket (1j7)	Buy now
12	69J1111E00 Hanger, engine 2	Buy now
12	69J--1111E--00 Hanger, engine 2	Buy now
13	90119--06MA2 Bolt, with washer	Buy now
13	90119--06MA2 Bolt, with washer	Buy now
14	90340--14M06 Plug, straight screw(62y)	Buy now
14	90340--14M06 Plug, straight screw(62y)	Buy now
15	90430--14115 Gasket (663)	Buy now
15	90430--14115 Gasket (663)	Buy now

Electrical 1




Ref	Part	
1	69J8231600 Bracket, ignition coil	Buy now
1	69J-82316-00 Bracket, ignition coil	Buy now
2	90480--09M21 Grommet (6e9)	Buy now
2	90480-09M21 Grommet (6e9)	Buy now
3	9011906041 Bolt, with washer	Buy now
3	90119-06041 Bolt, with washer	Buy now
4	69J8231000 Ignition coil assembly	Buy now
4	69J-82310-00 Ignition coil assembly	Buy now
5	97095--06020 Bolt(7u8)	Buy now
5	97095-06020 Bolt(7u8)	Buy now
6	92995--06600 Washer, plain (646)	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	90464--12002 Clamp	Buy now
7	90464-12002 Clamp	Buy now
8	90464--07M56 Clamp	Buy now

Electrical 1




Ref	Part	
8	90464-07M56 Clamp	Buy now
9	69J8231400 Cover, ignition coil	Buy now
9	69J-82314-00 Cover, ignition coil	Buy now
10	90110-06038 Bolt, hexagon socket head	Buy now
10	90110-06038 Bolt, hexagon socket head	Buy now
11	663--82317--01 Damper, ignition coil	Buy now
11	663--82317--01 Damper, ignition coil	Buy now
12	69J8196010 Rectifier & regulator assembly	Buy now
12	69J-81960-10 Rectifier & regulator assembly	Buy now
13	69J--81975--A0 Plate, rectifier fitting	Buy now
13	69J-81975-A0 Plate, rectifier fitting	Buy now
14	69J81972011S Cover, rectifier	Buy now
14	69J-81972-01-1S Cover, rectifier	Buy now
15	90119-06MA3 Bolt, with washer	Buy now
15	90119-06MA3 Bolt, with washer	Buy now

Electrical 1




Ref	Part	
16	90119--06MA5 Bolt, with washer	Buy now
16	90119--06MA5 Bolt, with washer	Buy now
18	92995--06100 Washer(6a1)	Buy now
18	92995--06100 Washer(6a1)	Buy now
20	69J1248200 Pipe 2	Buy now
20	69J-12482-00 Pipe 2	Buy now
21	69J1248100 Pipe 1	Buy now
21	69J-12481-00 Pipe 1	Buy now
22	90467--09M03 Clip(6k8)	Buy now
22	90467--09M03 Clip(6k8)	Buy now
23	90467--08M18 Clip	Buy now
23	90467--08M18 Clip	Buy now
24	69J8251900 Wire, earth lead	Buy now
24	69J-82519-00 Wire, earth lead	Buy now
25	97095--06012 Bolt(gh1)	Buy now

Electrical 1



Ref	Part	
25	97095-06012 Bolt(gh1)	Buy now
27	61A-85790-00 Thermosensor assembly	Buy now
27	61A-85790-00 Thermosensor assembly	Buy now
28	92990-10600 Washer, plate	Buy now
28	92990-10600 Washer, plate	Buy now
29	69J8362600 Mark. 6	Buy now
29	69J-83626-00 Mark. 6	Buy now
30	67F1213860 Mark Caution	Buy now
30	67F-12138-60 Mark Caution	Buy now

Electrical 2




69J1010-2160

E5


Ref	Part	
1	60L8591A01 Engine control unit assembly	Buy now
1	60L-8591A-01 Engine control unit assembly	Buy now
1	69J8591A02 Engine control unit assembly	Buy now
1	69J-8591A-02 Engine control unit assembly	Buy now
2	97095--06016 Bolt, hexagon deep recess	Buy now
2	97095-06016 Bolt, hexagon deep recess	Buy now
3	92995--06600 Washer, plain (646)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	69J8192500 Terminal	Buy now
4	69J-81925-00 Terminal	Buy now
5	97095--08020 Bolt, hexagon	Buy now
5	97095-08020 Bolt, hexagon	Buy now
6	92995--08600 Washer, plain (663)	Buy now
6	92995-08600 Washer, plain (663)	Buy now
7	97095--06014 Bolt(gj3)	Buy now

Electrical 2




Ref	Part	
7	97095-06014 Bolt(gj3)	Buy now
9	69J8210500 Battery cable	Buy now
9	69J-82105-00 Battery cable	Buy now
10	69J8194800 Bracket	Buy now
10	69J-81948-00 Bracket	Buy now
11	6A0-82317-00 Damper, ignition coil	Buy now
11	6A0-82317-00 Damper, ignition coil	Buy now
12	624-42542-00 Collar	Buy now
12	624-42542-00 Collar	Buy now
13	90119-06M59 Bolt, with washer	Buy now
13	90119-06M59 Bolt, with washer	Buy now
14	68V-8194A-00 Relay	Buy now
14	68V-8194A-00 Relay	Buy now
15	97095-06010 Bolt	Buy now
15	97095-06010 Bolt	Buy now

Electrical 2




Ref	Part	
16	92995--06100 Washer(6a1)	Buy now
16	92995--06100 Washer(6a1)	Buy now
18	68V--81953--00 Stay, relay	Buy now
18	68V--81953--00 Stay, relay	Buy now
19	97780--60620 Screw, tapping(6k8)	Buy now
19	97780--60620 Screw, tapping(6k8)	Buy now
20	6G5--82119--00 Cover, lead wire	Buy now
20	6G5--82119--00 Cover, lead wire	Buy now
21	69J8195010 Relay assembly	Buy now
21	69J--81950--10 Relay assembly	Buy now
25	97013--06025 Bolt(62y)	Buy now
25	97013--06025 Bolt(62y)	Buy now
26	92903--06600 Washer, plain (646)	Buy now
26	92903--06600 Washer, plain (646)	Buy now
27	69J8194200 Cover	Buy now

Electrical 2




Ref	Part	
27	69J-81942-00 Cover	Buy now
28	90169--05M00 Screw truss head tapping	Buy now
28	90169--05M00 Screw truss head tapping	Buy now
29	90464--07M56 Clamp	Buy now
29	90464--07M56 Clamp	Buy now
30	68V--81950--00 Relay assembly	Buy now
30	68V--81950--00 Relay assembly	Buy now
31	97780--60625 Screw, tapping(65j)	Buy now
31	97780--60625 Screw, tapping(65j)	Buy now
32	69J8191900 Graphic, regulator	Buy now
32	69J-81919-00 Graphic, regulator	Buy now

Electrical 3



Ref	Part	
1	69J8259020 Wire harness assembly	Buy now
1	69J-82590-20 Wire harness assembly	Buy now
2	67F--82151--20 Fuse (5a)	Buy now
2	67F--82151--20 Fuse (5a)	Buy now
3	97095--06020 Bolt(7u8)	Buy now
3	97095--06020 Bolt(7u8)	Buy now
4	92995--06100 Washer(6a1)	Buy now
4	92995--06100 Washer(6a1)	Buy now
5	92995--06600 Washer, plain (646)	Buy now
5	92995--06600 Washer, plain (646)	Buy now
6	97095--06035 Bolt(j52)	Buy now
6	97095--06035 Bolt(j52)	Buy now
8	69J--82563--00 Trim & tilt switch assembly	Buy now
8	69J--82563--00 Trim & tilt switch assembly	Buy now
9	69J42723008D Cover, bottom	Buy now


Electrical 3



E7


Ref	Part	
9	69J-42723-00-8D Cover, bottom	Buy now
10	69J-82587-00 Gasket	Buy now
10	69J-82587-00 Gasket	Buy now
11	69J-83614-00 Bracket	Buy now
11	69J-83614-00 Bracket	Buy now
12	90109-06M86 Bolt	Buy now
12	90109-06M86 Bolt	Buy now
13	69J8259N10 Wire harness assembly 3	Buy now
13	69J-8259N-10 Wire harness assembly 3	Buy now
14	69J8330600 Drive unit assembly	Buy now
14	69J-83306-00 Drive unit assembly	Buy now
15	90109-06M82 Bolt	Buy now
15	90109-06M82 Bolt	Buy now
16	90465-13M18 Clamp	Buy now
16	90465-13M18 Clamp	Buy now

Electrical 3



Ref	Part	
17	69J8194900 Wire, lead (isolator, 3.8m) AP	Buy now
17	69J-81949-00 Wire, lead (isolator, 3.8m) AP	Buy now


Fuel 1



D5


Ref	Part	
1	689--85547--00 Damper	Buy now
1	689--85547--00 Damper	Buy now
2	9044513004 Hose (I1900)	Buy now
2	90445--13004 Hose (I1900)	Buy now
3	6R3--24377--00 Pipe, joint 3	Buy now
3	6R3--24377--00 Pipe, joint 3	Buy now
4	90465--11M10 Clamp	Buy now
4	90465--11M10 Clamp	Buy now
5	61A--24311--00 Pipe, fuel 1	Buy now
5	61A--24311--00 Pipe, fuel 1	Buy now
6	65L--24560--00 Filter assembly	Buy now
6	65L--24560--00 Filter assembly	Buy now
7	61A--24521--00 Cup, filter	Buy now
7	61A--24521--00 Cup, filter	Buy now
8	65L--24531--01 Nut	Buy now

Fuel 1




Ref	Part	
8	65L-24531-01 Nut	Buy now
9	61A-24564-00 O-ring	Buy now
9	61A-24564-00 O-ring	Buy now
10	65L2457700 Spring	Buy now
10	65L-24577-00 Spring	Buy now
11	65L-24563-00 Element, filter	Buy now
11	65L-24563-00 Element, filter	Buy now
12	61A-24469-00 Float, water level	Buy now
12	61A-24469-00 Float, water level	Buy now
13	65L2456400 Gasket	Buy now
13	65L-24564-00 Gasket	Buy now
14	97095-06014 Bolt(gj3)	Buy now
14	97095-06014 Bolt(gj3)	Buy now
15	92995-06600 Washer, plain (646)	Buy now
15	92995-06600 Washer, plain (646)	Buy now

Fuel 1




Ref	Part	
16	97095--06016 Bolt, hexagon deep recess	Buy now
16	97095--06016 Bolt, hexagon deep recess	Buy now
17	92995--06100 Washer(6a1)	Buy now
17	92995--06100 Washer(6a1)	Buy now
18	90201--06068 Washer,plate (6k8)	Buy now
18	90201--06068 Washer,plate (6k8)	Buy now
19	65L--24558--00 Holder, filter	Buy now
19	65L--24558--00 Holder, filter	Buy now
20	69J2456600 Bracket, filter	Buy now
20	69J--24566--00 Bracket, filter	Buy now
21	90119--06037 Bolt, with washer	Buy now
21	90119--06037 Bolt, with washer	Buy now
22	69J2431300 Pipe 3	Buy now
22	69J--24313--00 Pipe 3	Buy now
24	69J2810000 Tool kit AP	Buy now

Fuel 1



Ref	Part	
24	69J-28100-00 Tool kit AP	Buy now
25	69J2819972A0 O/m f200aet/f225aet/fl200a '03 UR (E,F,S)	Buy now
25	69J2819972B0 O/m f200aet/f225aet/fl200a '03 UR (D,NL,I)	Buy now
25	69J-28199-72-A0 O/m f200aet/f225aet/fl200a '03 UR (E,F,S)	Buy now
25	69J-28199-72-B0 O/m f200aet/f225aet/fl200a '03 UR (D,NL,I)	Buy now
26	69J2819982A0 O/m f200aet/f225aet/fl200a '03 UR (DK,P,GR)	Buy now
26	69J-28199-82-A0 O/m f200aet/f225aet/fl200a '03 UR (DK,P,GR)	Buy now
26	69J2819982B0 O/m f200aet/f225aet/fl200a '03 UR (N,S,SS)	Buy now
26	69J-28199-82-B0 O/m f200aet/f225aet/fl200a '03 UR (N,S,SS)	Buy now

Fuel 2





69J2300-3140

D7


Ref	Part	
1	6YK--24307--42 Fuel pipe comp. 2 AP	Buy now
1	6YK-24307-42 Fuel pipe comp. 2 AP	Buy now

Fuel Injection Pump 1




Ref	Part	
1	69J1418011 Float chamber assembly	Buy now
1	69J-14180-11 Float chamber assembly	Buy now
2	69J1418200 Cover, Float Chamber	Buy now
2	69J-14182-00 Cover, Float Chamber	Buy now
3	69J2411R00 -	Buy now
3	69J-2411R-00 11 - 3	Buy now
4	69J2411T00 Plate 2	Buy now
4	69J-2411T-00 Plate 2	Buy now
5	4SV-24453-00 Screw	Buy now
5	4SV-24453-00 Screw	Buy now
6	69J1418100 Body, float chamber 1	Buy now
6	69J-14181-00 Body, float chamber 1	Buy now
7	2661419100 Plug, drain	Buy now
7	266-14191-00 Plug, drain	Buy now
8	59V1496200 Washer	Buy now

Fuel Injection Pump 1




Ref	Part	
8	59V-14962-00 Washer	Buy now
9	69J1498500 Float	Buy now
9	69J-14985-00 Float	Buy now
10	68V--14386-00 Pin,float	Buy now
10	68V-14386-00 Pin,float	Buy now
11	69J1454600 Valve, needle	Buy now
11	69J-14546-00 Valve, needle	Buy now
12	68V1376900 O-ring	Buy now
12	68V-13769-00 O-ring	Buy now
13	68V1425500 Plate, valve seat	Buy now
13	68V-14255-00 Plate, valve seat	Buy now
14	98507--04008 Screw, pan head(jg1)	Buy now
14	98507-04008 Screw, pan head(jg1)	Buy now
15	68V1435700 Washer, plain	Buy now
15	68V-14357-00 Washer, plain	Buy now

Fuel Injection Pump 1




Ref	Part	
16	68V1378100 Damper, pump	Buy now
16	68V-13781-00 Damper, pump	Buy now
17	69J1390701 Fuel pump comp.	Buy now
17	69J-13907-01 Fuel pump comp.	Buy now
18	68V1391500 Filter	Buy now
18	68V-13915-00 Filter	Buy now
19	68V1378400 Cover, pump	Buy now
19	68V-13784-00 Cover, pump	Buy now
20	68V1456700 Screw	Buy now
20	68V-14567-00 Screw	Buy now
21	68V1498400 Gasket, float chamber	Buy now
21	68V-14984-00 Gasket, float chamber	Buy now
22	69J-24379-00 Pipe, joint 4	Buy now
22	69J-24379-00 Pipe, joint 4	Buy now
23	69J1414800 Pipe	Buy now

Fuel Injection Pump 1



Ref	Part	
23	69J-14148-00 Pipe	Buy now
24	69J1419700 Pipe	Buy now
24	69J-14197-00 Pipe	Buy now
25	69J1498900 Orifice, air vent	Buy now
25	69J-14989-00 Orifice, air vent	Buy now
26	69J2441000 -	Buy now
26	69J-24410-00 11 - 26	Buy now
27	69J2449100 Bracket, fuel pump	Buy now
27	69J-24491-00 Bracket, fuel pump	Buy now
28	69J2449200 Bush, fuel pump	Buy now
28	69J-24492-00 Bush, fuel pump	Buy now
29	69J2459200 Bolt	Buy now
29	69J-24592-00 Bolt	Buy now
30	69J2442210 Plate	Buy now
30	69J-24422-10 Plate	Buy now


Fuel Injection Pump 1



D2


Ref	Part	
31	69J--14164--00 Nut, holding	Buy now
31	69J--14164--00 Nut, holding	Buy now
32	69J2184100 Cooler	Buy now
32	69J--21841--00 Cooler	Buy now
33	68V1426500 Collar	Buy now
33	68V--14265--00 Collar	Buy now
34	69J1444600 Bolt	Buy now
34	69J--14446--00 Bolt	Buy now
35	69J1359300 Damper	Buy now
35	69J--13593--00 Damper	Buy now
36	69J--13716--00 Collar	Buy now
36	69J--13716--00 Collar	Buy now
37	69J1422500 Cap	Buy now
37	69J--14225--00 Cap	Buy now

Fuel Injection Pump 2



Ref	Part	
1	69J2446000 Relief valve assembly	Buy now
1	69J-24460-00 Relief valve assembly	Buy now
2	69J2432400 -	Buy now
2	69J-24324-00 12 - 2	Buy now
3	69J2432100 -	Buy now
3	69J-24321-00 12 - 3	Buy now
4	69J2432200 -	Buy now
4	69J-24322-00 12 - 4	Buy now
5	69J2432300 Pipe 12	Buy now
5	69J-24323-00 Pipe 12	Buy now
6	69J2431700 Pipe 7	Buy now
6	69J-24317-00 Pipe 7	Buy now
7	69J2431600 Pipe 6	Buy now
7	69J-24316-00 Pipe 6	Buy now
8	69J2453700 Nipple	Buy now


Fuel Injection Pump 2



D4


Ref	Part	
8	69J-24537-00 Nipple	Buy now
9	68V-13577-00 Clip	Buy now
9	68V-13577-00 Clip	Buy now
10	68V-24519-00 Clip	Buy now
10	68V-24519-00 Clip	Buy now
11	69J-14137-00 Clip	Buy now
11	69J-14137-00 Clip	Buy now
12	68V-2481H-00 Clamp	Buy now
12	68V-2481H-00 Clamp	Buy now
13	6E5-24378-00 Pipe, joint 3	Buy now
13	6E5-24378-00 Pipe, joint 3	Buy now
14	69J2446100 Pipe, joint	Buy now
14	69J-24461-00 Pipe, joint	Buy now
15	69J2431500 Pipe 5	Buy now
15	69J-24315-00 Pipe 5	Buy now

Fuel Injection Pump 2



Ref	Part	
16	69J1397600 Pipe, fuel 6	Buy now
16	69J-13976-00 Pipe, fuel 6	Buy now
17	68V2438700 Clip	Buy now
17	68V-24387-00 Clip	Buy now
18	69J2450100 Filter, fuel	Buy now
18	69J-24501-00 Filter, fuel	Buy now
19	69J2459900 Cap	Buy now
19	69J-24599-00 Cap	Buy now
20	69J2432500 Pipe 14	Buy now
20	69J-24325-00 Pipe 14	Buy now
21	69J1410F00 Nipple 1	Buy now
21	69J-1410F-00 Nipple 1	Buy now
22	69J2436600 Clamp, fuel pipe 1	Buy now
22	69J-24366-00 Clamp, fuel pipe 1	Buy now
23	69J2436700 Clamp, fuel pipe 2	Buy now


Fuel Injection Pump 2



D4

Ref	Part	
23	69J-24367-00 Clamp, fuel pipe 2	Buy now
24	9858205008 Screw, pan head (7g3)	Buy now
24	98582-05008 Screw, pan head (7g3)	Buy now
25	69J1397400 Pipe, fuel 4	Buy now
25	69J-13974-00 Pipe, fuel 4	Buy now
26	69J2438100 Set bar, fuel joint	Buy now
26	69J-24381-00 Set bar, fuel joint	Buy now


Generator



E1

Ref	Part	
1	69J8145010 Rotor assembly	Buy now
1	69J-81450-10 Rotor assembly	Buy now
2	69J8146001 Base assembly	Buy now
2	69J-81460-01 Base assembly	Buy now
3	69J8558000 Coil, pulser	Buy now
3	69J-85580-00 Coil, pulser	Buy now
4	69J8141001 Stator assembly	Buy now
4	69J-81410-01 Stator assembly	Buy now
5	63D--81345--20 Screw, pan	Buy now
5	63D-81345-20 Screw, pan	Buy now
6	99530--08012 Pin, dowel(6g8)	Buy now
6	99530-08012 Pin, dowel(6g8)	Buy now
7	97095--06035 Bolt(j52)	Buy now
7	97095-06035 Bolt(j52)	Buy now
8	92995--06100 Washer(6a1)	Buy now


Generator



E1

Ref	Part	
8	92995-06100 Washer(6a1)	Buy now
9	92995-06600 Washer, plain (646)	Buy now
9	92995-06600 Washer, plain (646)	Buy now
10	90280-05015 Key, woodruff	Buy now
10	90280-05015 Key, woodruff	Buy now
11	90201-24014 Washer, plate	Buy now
11	90201-24014 Washer, plate	Buy now
12	90179-24002 Nut	Buy now
12	90179-24002 Nut	Buy now
13	69J8167300 Rotor	Buy now
13	69J-81673-00 Rotor	Buy now
14	67F8133200 Plate, timing	Buy now
14	67F-81332-00 Plate, timing	Buy now
15	97885-06010 Screw pan head	Buy now
15	97885-06010 Screw pan head	Buy now


Generator



E1

Ref	Part	
17	69J8132G00 Plate	Buy now
17	69J-8132G-00 Plate	Buy now
18	97095-06016 Bolt, hexagon deep recess	Buy now
18	97095-06016 Bolt, hexagon deep recess	Buy now
20	90465-13M18 Clamp	Buy now
20	90465-13M18 Clamp	Buy now
21	90465-14M66 Clamp	Buy now
21	90465-14M66 Clamp	Buy now
22	69J8133700 Cover, flywheel	Buy now
22	69J-81337-00 Cover, flywheel	Buy now
23	663-82317-01 Damper, ignition coil	Buy now
23	663-82317-01 Damper, ignition coil	Buy now
24	6A0-82317-00 Damper, ignition coil	Buy now
24	6A0-82317-00 Damper, ignition coil	Buy now
25	624-42542-00 Collar	Buy now


Generator



E1

Ref	Part	
25	624-42542-00 Collar	Buy now
26	90119-06M59 Bolt, with washer	Buy now
26	90119-06M59 Bolt, with washer	Buy now
27	67F-2812A-00 Puller, fuse	Buy now
27	67F-2812A-00 Puller, fuse	Buy now
28	69J8191920 Graphic Regulator	Buy now
28	69J-81919-20 Graphic Regulator	Buy now
29	69J1343761 Mark, Caution	Buy now
29	69J-13437-61 Mark, Caution	Buy now
30	6A1-83625-41 Mark 5	Buy now
30	6A1-83625-41 Mark 5	Buy now
31	6A1-83625-51 Mark 5	Buy now
31	6A1-83625-51 Mark 5	Buy now


Intake



C2

Ref	Part	
1	69J1414610 Plate	Buy now
1	69J-14146-10 Plate	Buy now
2	69J1416200 Bolt Holding	Buy now
2	69J-14162-00 Bolt Holding	Buy now
3	68V--24519--00 Clip	Buy now
3	68V-24519-00 Clip	Buy now
4	9011606032 Bolt, stud	Buy now
4	90116-06032 Bolt, stud	Buy now
5	69J1442A00 Cover, cleaner case 3	Buy now
5	69J-1442A-00 Cover, cleaner case 3	Buy now
6	69J1440900 Damper	Buy now
6	69J-14409-00 Damper	Buy now
7	97780-60620 Screw, tapping(6k8)	Buy now
7	97780-60620 Screw, tapping(6k8)	Buy now
8	69J1248300 Pipe 3	Buy now


Intake



C2

Ref	Part	
8	69J-12483-00 Pipe 3	Buy now
9	90467-09M03 Clip(6k8)	Buy now
9	90467-09M03 Clip(6k8)	Buy now
10	69J1364500 Gasket, manifold 1	Buy now
10	69J-13645-00 Gasket, manifold 1	Buy now
11	90119-08022 Bolt, with washer	Buy now
11	90119-08022 Bolt, with washer	Buy now
12	91690-50014 Pin, spring (647)	Buy now
12	91690-50014 Pin, spring (647)	Buy now
13	90119-06M24 Bolt, with washer	Buy now
13	90119-06M24 Bolt, with washer	Buy now
14	69J1444000 Silencer assembly, intake	Buy now
14	69J-14440-00 Silencer assembly, intake	Buy now
15	69J1444F00 Silencer assembly, intake 2	Buy now
15	69J-1444F-00 Silencer assembly, intake 2	Buy now


Intake



C2

Ref	Part	
16	69J1441900 Pipe	Buy now
16	69J-14419-00 Pipe	Buy now
17	90465--11M52 Clamp(6e7)	Buy now
17	90465-11M52 Clamp(6e7)	Buy now
18	69J1445700 Seal	Buy now
18	69J-14457-00 Seal	Buy now
19	90386--08001 Bush	Buy now
19	90386-08001 Bush	Buy now
20	9011906036 Bolt, with washer	Buy now
20	90119-06036 Bolt, with washer	Buy now
21	90387--06038 Collar	Buy now
21	90387-06038 Collar	Buy now
22	90179--06M28 Nut(63v)	Buy now
22	90179-06M28 Nut(63v)	Buy now
23	69J1537300 Pipe, breather	Buy now


Intake



C2


Ref	Part	
23	69J-15373-00 Pipe, breather	Buy now
24	69J1539400 Pipe, oil vent	Buy now
24	69J-15394-00 Pipe, oil vent	Buy now
25	69J1539300 Pipe, breather 2	Buy now
25	69J-15393-00 Pipe, breather 2	Buy now
26	69J1539700 Pipe	Buy now
26	69J-15397-00 Pipe	Buy now
27	5EL1446700 Seal	Buy now
27	5EL-14467-00 Seal	Buy now
28	69J1434800 Pipe 1	Buy now
28	69J-14348-00 Pipe 1	Buy now
29	65L-85886-00 Thermosensor	Buy now
29	65L-85886-00 Thermosensor	Buy now

Lower Casing. Drive 1




Ref	Part	
1	69J45300218D Lower unit assembly X	Buy now
1	69J45300318D Lower unit assembly U	Buy now
1	69J-45300-21-8D Lower unit assembly X	Buy now
1	69J-45300-31-8D Lower unit assembly U	Buy now
2	61A-45301-10-8D Casing, lower	Buy now
2	61A-45301-10-8D Casing, lower	Buy now
3	93311-832V2 Ball bearing	Buy now
3	93311-832V2 Ball bearing	Buy now
4	93332-000W1 Bearing(61a)	Buy now
4	93332-000W1 Bearing(61a)	Buy now
5	61A-45567-00-10 Shim (t:0.10mm) UR	Buy now
5	61A-45567-00-12 Shim (t:0.12mm) UR	Buy now
5	61A-45567-00-15 Shim (t:0.15mm) UR	Buy now
5	61A-45567-00-18 Shim (t:0.18mm) UR	Buy now
5	61A-45567-00-30 Shim (t:0.30mm) UR	Buy now

Lower Casing. Drive 1




Ref	Part	
5	61A455670040 Shim (t:0.40mm) UR	Buy now
5	61A455670050 Shim (t:0.50mm) UR	Buy now
5	61A-45567-00-10 Shim (t:0.10mm) UR	Buy now
5	61A-45567-00-12 Shim (t:0.12mm) UR	Buy now
5	61A-45567-00-15 Shim (t:0.15mm) UR	Buy now
5	61A-45567-00-18 Shim (t:0.18mm) UR	Buy now
5	61A-45567-00-30 Shim (t:0.30mm) UR	Buy now
5	61A-45567-00-40 Shim (t:0.40mm) UR	Buy now
5	61A-45567-00-50 Shim (t:0.50mm) UR	Buy now
6	663--44366--00 Damper, water seal 2	Buy now
6	663--44366--00 Damper, water seal 2	Buy now
7	90340--08002 Plug, straight screw	Buy now
7	90340--08002 Plug, straight screw	Buy now
8	688--45341--10 Plug, drain	Buy now
8	688--45341--10 Plug, drain	Buy now

Lower Casing. Drive 1



Ref	Part	
9	90430--08020 Gasket	Buy now
9	90430--08020 Gasket	Buy now
10	61A453760094 Guide, seal damper	Buy now
10	61A-45376-00-94 Guide, seal damper	Buy now
11	61A--45321--01 Plate	Buy now
11	61A-45321-01 Plate	Buy now
12	93210--64488 93210-64488	Buy now
12	93210--64488 93210-64488	Buy now
13	93106--09014 Oil seal	Buy now
13	93106-09014 Oil seal	Buy now
14	90119--06M10 Bolt, with washer	Buy now
14	90119-06M10 Bolt, with washer	Buy now
15	69J--44150--00 Shift cam assembly	Buy now
15	69J-44150-00 Shift cam assembly	Buy now
16	99001--08600 Circlip(2r6)	Buy now


Lower Casing. Drive 1



C5


Ref	Part	
16	99001-08600 Circlip(2r6)	Buy now
17	90501-11M10 Spring, compression (663)	Buy now
17	90501-11M10 Spring, compression (663)	Buy now
18	61A-44311-01 Housing, water pump	Buy now
18	61A-44311-01 Housing, water pump	Buy now
19	61A-44322-02 Insert, cartridge	Buy now
19	61A-44322-02 Insert, cartridge	Buy now
20	93210-86M38 O-ring (6e5)	Buy now
20	93210-86M38 O-ring (6e5)	Buy now
21	93210-37160 O-ring (6g8)	Buy now
21	93210-37160 O-ring (6g8)	Buy now
22	6E5-44365-00 Damper, water seal 1	Buy now
22	6E5-44365-00 Damper, water seal 1	Buy now
23	6E5-44312-00 Cover, water pump housing	Buy now
23	6E5-44312-00 Cover, water pump housing	Buy now

Lower Casing. Drive 1




Ref	Part	
24	6E5--44352--01 Impeller	Buy now
24	6E5--44352--01 Impeller	Buy now
25	90280--04M05 Key, woodruff (6e5)	Buy now
25	90280--04M05 Key, woodruff (6e5)	Buy now
26	61A--45538--00 Spacer, 1	Buy now
26	61A--45538--00 Spacer, 1	Buy now
27	61A--45527--00 Collar, drive shaft	Buy now
27	61A--45527--00 Collar, drive shaft	Buy now
28	90201--22M01 Washer, plate(61a)	Buy now
28	90201--22M01 Washer, plate(61a)	Buy now
29	90206--22M19 Washer, wave(61a)	Buy now
29	90206--22M19 Washer, wave(61a)	Buy now
30	6G5--44323--00 Outer plate, cartridge	Buy now
30	6G5--44323--00 Outer plate, cartridge	Buy now
31	6E5--44315--A0 Gasket,water pump	Buy now

Lower Casing. Drive 1




Ref	Part	
31	6E5-44315-A0 Gasket, water pump	Buy now
32	93606-12019 Pin, dowel (614)	Buy now
32	93606-12019 Pin, dowel (614)	Buy now
33	90119-08M14 Bolt, with washer	Buy now
33	90119-08M14 Bolt, with washer	Buy now
34	61A-45331-00-94 Housing, bearing	Buy now
34	61A-45331-00-94 Housing, bearing	Buy now
35	93101-28M16 Oil seal (6e5)	Buy now
35	93101-28M16 Oil seal (6e5)	Buy now
36	93317-330U2 Bearing, cylindrical(6k0)	Buy now
36	93317-330U2 Bearing, cylindrical(6k0)	Buy now
37	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now
37	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now
37	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
37	61A455870010 Shim (t:0.10mm) UR	Buy now

Lower Casing. Drive 1




Ref	Part	
37	61A455870015 Shim (t:0.15mm) UR	Buy now
37	61A455870018 Shim (t:0.18mm) UR	Buy now
37	61A455870030 Shim (t:0.30mm) UR	Buy now
37	61A-45587-00-10 Shim (t:0.10mm) UR	Buy now
37	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now
37	61A-45587-00-15 Shim (t:0.15mm) UR	Buy now
37	61A-45587-00-18 Shim (t:0.18mm) UR	Buy now
37	61A-45587-00-30 Shim (t:0.30mm) UR	Buy now
37	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now
37	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
38	93341-930U9 Bearing	Buy now
38	93341-930U9 Bearing	Buy now
39	93210-55M14 O-ring (70e)	Buy now
39	93210-55M14 O-ring (70e)	Buy now
40	6E5-45344-00 Cover, oil seal	Buy now

Lower Casing. Drive 1



Ref	Part	
40	6E5-45344-00 Cover, oil seal	Buy now
41	97095-08025 Bolt (62g)	Buy now
41	97095-08025 Bolt (62g)	Buy now
42	92995-08600 Washer, plain (663)	Buy now
42	92995-08600 Washer, plain (663)	Buy now
43	61A-45501-30 Drive shaft comp. U	Buy now
43	61A-45501-30 Drive shaft comp. U	Buy now
43	69J-45501-00 Drive shaft comp. X	Buy now
43	69J-45501-00 Drive shaft comp. X	Buy now
44	69J4555100 Pinion	Buy now
44	69J-45551-00 Pinion	Buy now
45	90201-16M00 Washer, plate(6t5)	Buy now
45	90201-16M00 Washer, plate(6t5)	Buy now
46	90170-16M19 Nut(6t5)	Buy now
46	90170-16M19 Nut(6t5)	Buy now


Lower Casing. Drive 1



C5


Ref	Part	
47	69J4556000 Gear	Buy now
47	69J-45560-00 Gear	Buy now
48	69J-45611-00 Shaft, propeller	Buy now
48	69J-45611-00 Shaft, propeller	Buy now
49	61A-45641-02 Shifter	Buy now
49	61A-45641-02 Shifter	Buy now
50	61A-45634-01 Slide, shift	Buy now
50	61A-45634-01 Slide, shift	Buy now
51	61A-45632-00 Pin, cross	Buy now
51	61A-45632-00 Pin, cross	Buy now
52	69J-45631-00 Clutch, dog	Buy now
52	69J-45631-00 Clutch, dog	Buy now
53	61A-45633-00 Ring, cross pin	Buy now
53	61A-45633-00 Ring, cross pin	Buy now
54	6H1-45668-00 Shaft, free 1	Buy now

Lower Casing. Drive 1




Ref	Part	
54	6H1-45668-00 Shaft, free 1	Buy now
55	61A-45635-00 Plunger, shift	Buy now
55	61A-45635-00 Plunger, shift	Buy now
56	90201-02M00 Washer, plate(61a)	Buy now
56	90201-02M00 Washer, plate(61a)	Buy now
57	90183-02M03 Nut, spring (6h1)	Buy now
57	90183-02M03 Nut, spring (6h1)	Buy now
58	90501-10M77 Spring, compression(61a)	Buy now
58	90501-10M77 Spring, compression(61a)	Buy now
59	93501-04011 Ball	Buy now
59	93501-04011 Ball	Buy now
60	69J453320094 Housing, bearing	Buy now
60	69J-45332-00-94 Housing, bearing	Buy now
61	93306-210U0 Bearing(61a)	Buy now
61	93306-210U0 Bearing(61a)	Buy now

Lower Casing. Drive 1




Ref	Part	
62	69J4557100 Gear	Buy now
62	69J-45571-00 Gear	Buy now
63	90201-31M00 Washer, plate(61a)	Buy now
63	90201-31M00 Washer, plate(61a)	Buy now
64	61A455770010 Shim (t:0.10mm) UR	Buy now
64	61A455770012 Shim (t:0.12mm) UR	Buy now
64	61A455770015 Shim (t:0.15mm) UR	Buy now
64	61A455770018 Shim (t:0.18mm) UR	Buy now
64	61A-45577-00-10 Shim (t:0.10mm) UR	Buy now
64	61A-45577-00-12 Shim (t:0.12mm) UR	Buy now
64	61A-45577-00-15 Shim (t:0.15mm) UR	Buy now
64	61A-45577-00-18 Shim (t:0.18mm) UR	Buy now
64	61A-45577-00-30 Shim (t:0.30mm) UR	Buy now
64	61A455770040 Shim (t:0.40mm) UR	Buy now
64	61A455770050 Shim (t:0.50mm) UR	Buy now

Lower Casing. Drive 1




Ref	Part	
64	61A-45577-00-30 Shim (t:0.30mm) UR	Buy now
64	61A-45577-00-40 Shim (t:0.40mm) UR	Buy now
64	61A-45577-00-50 Shim (t:0.50mm) UR	Buy now
65	93315-43061 Bearing	Buy now
65	93315-43061 Bearing	Buy now
66	93101-30M17 Oil seal (6e5)	Buy now
66	93101-30M17 Oil seal (6e5)	Buy now
67	93211-04384 O-ring (705)	Buy now
67	93211-04384 O-ring (705)	Buy now
68	9010508036 Bolt, flange	Buy now
68	90105-08036 Bolt, flange	Buy now
69	90201-08023 Washer, plate	Buy now
69	90201-08023 Washer, plate	Buy now
70	93700-09M00 Nipple, grease(6t4)	Buy now
70	93700-09M00 Nipple, grease(6t4)	Buy now

Lower Casing. Drive 1




Ref	Part	
71	69J--45361--00--8D Cap, lower casing	Buy now
71	69J--45361--00--8D Cap, lower casing	Buy now
72	97095--08020 Bolt, hexagon	Buy now
72	97095--08020 Bolt, hexagon	Buy now

Lower Casing. Drive 2



Ref	Part	
1	6E5--44365--00 Damper, water seal 1	Buy now
1	6E5--44365--00 Damper, water seal 1	Buy now
2	6E5--44366--00 Damper, water seal 2	Buy now
2	6E5--44366--00 Damper, water seal 2	Buy now
3	69J4436100 Tube, water 1 X	Buy now
3	69J4436110 Tube, water 1 U	Buy now
3	69J--44361--00 Tube, water 1 X	Buy now
3	69J--44361--10 Tube, water 1 U	Buy now
4	93608--12M05 Pin, dowel b (6e5)	Buy now
4	93608--12M05 Pin, dowel b (6e5)	Buy now
5	97095--10045 Bolt(64d) X	Buy now
5	97095--10045 Bolt(64d) X	Buy now
6	92995--10100 Ybs67-10 washer, spring X	Buy now
6	92995--10100 Ybs67-10 washer, spring X	Buy now
7	92995--10600 Washer, plate X	Buy now


Lower Casing. Drive 2



Ref	Part	
7	92995-10600 Washer, plate X	Buy now
8	90119-10009 Bolt, with washer U	Buy now
8	90119-10MA2 Bolt, with washer X	Buy now
8	90119-10009 Bolt, with washer U	Buy now
8	90119-10MA2 Bolt, with washer X	Buy now
9	69J-45375-00 Damper, seal	Buy now
9	69J-45375-00 Damper, seal	Buy now
10	61A4521410 Cover, water inlet 1	Buy now
10	61A-45214-10 Cover, water inlet 1	Buy now
11	61A4521510 Cover, water inlet 2	Buy now
11	61A-45215-10 Cover, water inlet 2	Buy now
12	90152-05003 Screw, countersunk	Buy now
12	90152-05003 Screw, countersunk	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now

Lower Casing. Drive 2

STD




69J2100-3320

D2

Ref	Part	
14	61A--45371--00 Anode	Buy now
14	61A--45371--00 Anode	Buy now
15	90105--10M00 Bolt, hexagon (663)	Buy now
15	90105--10M00 Bolt, hexagon (663)	Buy now
16	69J--45987--00 Spacer 1	Buy now
16	69J--45987--00 Spacer 1	Buy now
17	688--45997--01 Spacer 2	Buy now
17	688--45997--01 Spacer 2	Buy now
18	92990--18200 Washer (6e5)	Buy now
18	92990--18200 Washer (6e5)	Buy now
19	90171--18M04 Nut, castle (6e5)	Buy now
19	90171--18M04 Nut, castle (6e5)	Buy now
20	91490--40030 Pin, cotter (663)	Buy now
20	91490--40030 Pin, cotter (663)	Buy now
21	61A459720098 Propeller (3x14-1/2"x21"-t) UR	Buy now


Lower Casing. Drive 2



Ref	Part	
21	61A-45972-00-98 Propeller (3x14-1/2"x21"-t) UR	Buy now
21	6G5--45970--02--98 Propeller (3x15-1/4 x15 -m) UR	Buy now
21	6G5-45972-02-98 Propeller (3x13-3/4 x21 -m) UR	Buy now
21	6G5-45974-03-98 Propeller (3x13-3/4"x19"-m2) UR	Buy now
21	6G5--45978--03--98 Propeller (3x13-3/4"x17"-m2) UR	Buy now
21	6G5-45970-02-98 Propeller (3x15-1/4 x15 -m) UR	Buy now
21	6G5-45972-02-98 Propeller (3x13-3/4 x21 -m) UR	Buy now
21	6G5-45974-03-98 Propeller (3x13-3/4"x19"-m2) UR	Buy now
21	6G5-45978-03-98 Propeller (3x13-3/4"x17"-m2) UR	Buy now
21	61A459740098 Propeller (3x14-1/2"x19"-t) UR	Buy now
21	61A459780098 Propeller (3x15"x17"-t) UR	Buy now
21	61A-45974-00-98 Propeller (3x14-1/2"x19"-t) UR	Buy now
21	61A-45978-00-98 Propeller (3x15"x17"-t) UR	Buy now
21	66K--45972--B0 Prop (3X14-1/2"X25"-M2) UR	Buy now
21	66K-45972-B0 Prop (3X14-1/2"X25"-M2) UR	Buy now

Lower Casing. Drive 2

STD




69J2100-3320

D2


Ref	Part	
21	6R4--45970--A0 Propeller (3X15-1/4"X19"-M) UR	Buy now
21	6R4--45972--A0 Propeller (3X14-7/8"X21"-M) UR	Buy now
21	6R4--45974--A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
21	6R4--45976--A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
21	6R4--45978--A0 Propeller (3X15-1/4"X17"-M) UR	Buy now
21	6R4--45970--A0 Propeller (3X15-1/4"X19"-M) UR	Buy now
21	6R4--45972--A0 Propeller (3X14-7/8"X21"-M) UR	Buy now
21	6R4--45974--A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
21	6R4--45976--A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
21	6R4--45978--A0 Propeller (3X15-1/4"X17"-M) UR	Buy now

Lower Casing. Drive 3




Ref	Part	
1	69K45300218D Lower unit assembly X	Buy now
1	69K-45300-21-8D Lower unit assembly X	Buy now
2	61A-45301-10-8D Casing, lower	Buy now
2	61A-45301-10-8D Casing, lower	Buy now
3	93311-832V2 Ball bearing	Buy now
3	93311-832V2 Ball bearing	Buy now
4	61B-45538-01 Spacer 1	Buy now
4	61B-45538-01 Spacer 1	Buy now
5	93315-660W3 Bearing, cylindrical(61b)	Buy now
5	93315-660W3 Bearing, cylindrical(61b)	Buy now
6	93341-670V0 Bearing, thrust (61b)	Buy now
6	93341-670V0 Bearing, thrust (61b)	Buy now
7	61A-45567-00-10 Shim (t:0.10mm) UR	Buy now
7	61A-45567-00-12 Shim (t:0.12mm) UR	Buy now
7	61A-45567-00-15 Shim (t:0.15mm) UR	Buy now

Lower Casing. Drive 3



Ref	Part	
7	61A--45567--00--18 Shim (t:0.18mm) UR	Buy now
7	61A--45567--00--30 Shim (t:0.30mm) UR	Buy now
7	61A455670040 Shim (t:0.40mm) UR	Buy now
7	61A455670050 Shim (t:0.50mm) UR	Buy now
7	61A-45567-00-10 Shim (t:0.10mm) UR	Buy now
7	61A-45567-00-12 Shim (t:0.12mm) UR	Buy now
7	61A-45567-00-15 Shim (t:0.15mm) UR	Buy now
7	61A-45567-00-18 Shim (t:0.18mm) UR	Buy now
7	61A-45567-00-30 Shim (t:0.30mm) UR	Buy now
7	61A-45567-00-40 Shim (t:0.40mm) UR	Buy now
7	61A-45567-00-50 Shim (t:0.50mm) UR	Buy now
8	663--44366--00 Damper, water seal 2	Buy now
8	663--44366--00 Damper, water seal 2	Buy now
9	90340--08002 Plug, straight screw	Buy now
9	90340--08002 Plug, straight screw	Buy now


Lower Casing. Drive 3



D4

Ref	Part	
10	688--45341--10 Plug, drain	Buy now
10	688--45341--10 Plug, drain	Buy now
11	90430--08020 Gasket	Buy now
11	90430--08020 Gasket	Buy now
12	61A453760094 Guide, seal damper	Buy now
12	61A--45376--00-94 Guide, seal damper	Buy now
13	61A--45321--01 Plate	Buy now
13	61A--45321--01 Plate	Buy now
14	93210--64488 93210-64488	Buy now
14	93210--64488 93210-64488	Buy now
15	93106--09014 Oil seal	Buy now
15	93106--09014 Oil seal	Buy now
16	90119--06M10 Bolt, with washer	Buy now
16	90119--06M10 Bolt, with washer	Buy now
17	69K--44150--00 Shift cam assembly	Buy now


Lower Casing. Drive 3



D4

Ref	Part	
17	69K-44150-00 Shift cam assembly	Buy now
18	99001-08600 Circlip(2r6)	Buy now
18	99001-08600 Circlip(2r6)	Buy now
19	90501-11M10 Spring, compression (663)	Buy now
19	90501-11M10 Spring, compression (663)	Buy now
20	61A-44311-01 Housing, water pump	Buy now
20	61A-44311-01 Housing, water pump	Buy now
21	61A-44322-02 Insert, cartridge	Buy now
21	61A-44322-02 Insert, cartridge	Buy now
22	93210-86M38 O-ring (6e5)	Buy now
22	93210-86M38 O-ring (6e5)	Buy now
23	93210-37160 O-ring (6g8)	Buy now
23	93210-37160 O-ring (6g8)	Buy now
24	6E5-44365-00 Damper, water seal 1	Buy now
24	6E5-44365-00 Damper, water seal 1	Buy now


Lower Casing. Drive 3



D4

Ref	Part	
25	6E5--44312--00 Cover, water pump housing	Buy now
25	6E5--44312--00 Cover, water pump housing	Buy now
26	6E5--44352--01 Impeller	Buy now
26	6E5--44352--01 Impeller	Buy now
27	90280--04M05 Key, woodruff (6e5)	Buy now
27	90280--04M05 Key, woodruff (6e5)	Buy now
28	61A--45538--00 Spacer, 1	Buy now
28	61A--45538--00 Spacer, 1	Buy now
29	61A--45527--00 Collar, drive shaft	Buy now
29	61A--45527--00 Collar, drive shaft	Buy now
30	90201--22M01 Washer, plate(61a)	Buy now
30	90201--22M01 Washer, plate(61a)	Buy now
31	90206--22M19 Washer, wave(61a)	Buy now
31	90206--22M19 Washer, wave(61a)	Buy now
32	6G5--44323--00 Outer plate, cartridge	Buy now


Lower Casing. Drive 3



D4


Ref	Part	
32	6G5-44323-00 Outer plate, cartridge	Buy now
33	6E5-44315-A0 Gasket,water pump	Buy now
33	6E5-44315-A0 Gasket,water pump	Buy now
34	93606-12019 Pin, dowel (614)	Buy now
34	93606-12019 Pin, dowel (614)	Buy now
35	90119-08M14 Bolt, with washer	Buy now
35	90119-08M14 Bolt, with washer	Buy now
36	61A-45331-00-94 Housing, bearing	Buy now
36	61A-45331-00-94 Housing, bearing	Buy now
37	93101-28M16 Oil seal (6e5)	Buy now
37	93101-28M16 Oil seal (6e5)	Buy now
38	93317-330U2 Bearing, cylindrical(6k0)	Buy now
38	93317-330U2 Bearing, cylindrical(6k0)	Buy now
39	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now
39	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now

Lower Casing. Drive 3



Ref	Part	
39	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
39	61A455870010 Shim (t:0.10mm) UR	Buy now
39	61A455870015 Shim (t:0.15mm) UR	Buy now
39	61A455870018 Shim (t:0.18mm) UR	Buy now
39	61A455870030 Shim (t:0.30mm) UR	Buy now
39	61A-45587-00-10 Shim (t:0.10mm) UR	Buy now
39	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now
39	61A-45587-00-15 Shim (t:0.15mm) UR	Buy now
39	61A-45587-00-18 Shim (t:0.18mm) UR	Buy now
39	61A-45587-00-30 Shim (t:0.30mm) UR	Buy now
39	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now
39	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
40	93341-930U9 Bearing	Buy now
40	93341-930U9 Bearing	Buy now
41	93210-55M14 O-ring (70e)	Buy now


Lower Casing. Drive 3



D4

Ref	Part	
41	93210-55M14 O-ring (70e)	Buy now
42	6E5-45344-00 Cover, oil seal	Buy now
42	6E5-45344-00 Cover, oil seal	Buy now
43	97095-08025 Bolt (62g)	Buy now
43	97095-08025 Bolt (62g)	Buy now
44	92995-08600 Washer, plain (663)	Buy now
44	92995-08600 Washer, plain (663)	Buy now
45	69J-45501-00 Drive shaft comp. X	Buy now
45	69J-45501-00 Drive shaft comp. X	Buy now
46	69J4555100 Pinion	Buy now
46	69J-45551-00 Pinion	Buy now
47	90201-16M00 Washer, plate(6t5)	Buy now
47	90201-16M00 Washer, plate(6t5)	Buy now
48	90170-16M19 Nut(6t5)	Buy now
48	90170-16M19 Nut(6t5)	Buy now


Lower Casing. Drive 3



D4

Ref	Part	
49	69K4556000 Gear	Buy now
49	69K-45560-00 Gear	Buy now
50	93317428U7 Bearing	Buy now
50	93317-428U7 Bearing	Buy now
51	69K-45611-00 Shaft, propeller	Buy now
51	69K-45611-00 Shaft, propeller	Buy now
52	69K4564100 Shifter	Buy now
52	69K-45641-00 Shifter	Buy now
53	61A-45634-01 Slide, shift	Buy now
53	61A-45634-01 Slide, shift	Buy now
54	61A-45632-00 Pin, cross	Buy now
54	61A-45632-00 Pin, cross	Buy now
55	69J-45631-00 Clutch, dog	Buy now
55	69J-45631-00 Clutch, dog	Buy now
56	61A-45633-00 Ring, cross pin	Buy now


Lower Casing. Drive 3



D4


Ref	Part	
56	61A-45633-00 Ring, cross pin	Buy now
57	6H1-45668-00 Shaft, free 1	Buy now
57	6H1-45668-00 Shaft, free 1	Buy now
58	61A-45635-00 Plunger, shift	Buy now
58	61A-45635-00 Plunger, shift	Buy now
59	90201-02M00 Washer, plate(61a)	Buy now
59	90201-02M00 Washer, plate(61a)	Buy now
60	90183-02M03 Nut, spring (6h1)	Buy now
60	90183-02M03 Nut, spring (6h1)	Buy now
61	90501-10M77 Spring, compression(61a)	Buy now
61	90501-10M77 Spring, compression(61a)	Buy now
62	93501-04011 Ball	Buy now
62	93501-04011 Ball	Buy now
63	69K453320094 Housing, bearing	Buy now
63	69K-45332-00-94 Housing, bearing	Buy now

Lower Casing. Drive 3




Ref	Part	
64	93332--00048 Bearing(6k0)	Buy now
64	93332--00048 Bearing(6k0)	Buy now
65	69K4557100 Gear	Buy now
65	69K-45571-00 Gear	Buy now
66	93341--440U5 Bearing, thrust (6k0)	Buy now
66	93341--440U5 Bearing, thrust (6k0)	Buy now
67	6K1--45578--01--10 Shim (t:0.10mm) UR	Buy now
67	6K1--45578--01--12 Shim (t:0.12mm) UR	Buy now
67	6K1--45578--01--15 Shim (t:0.15mm) UR	Buy now
67	6K1--45578--01--10 Shim (t:0.10mm) UR	Buy now
67	6K1--45578--01--12 Shim (t:0.12mm) UR	Buy now
67	6K1--45578--01--15 Shim (t:0.15mm) UR	Buy now
67	6K1--45578--01--18 Shim (t:0.18mm) UR	Buy now
67	6K1--45578--01--30 Shim (t:0.30mm) UR	Buy now
67	6K1--45578--01--40 Shim (t:0.40mm) UR	Buy now

Lower Casing. Drive 3




Ref	Part	
67	6K1--45578--01--50 Shim (t:0.50mm) UR	Buy now
67	6K1--45578--01--18 Shim (t:0.18mm) UR	Buy now
67	6K1--45578--01--30 Shim (t:0.30mm) UR	Buy now
67	6K1--45578--01--40 Shim (t:0.40mm) UR	Buy now
67	6K1--45578--01--50 Shim (t:0.50mm) UR	Buy now
68	61B--45383--00 Washer, claw	Buy now
68	61B--45383--00 Washer, claw	Buy now
69	69K--45384--00 Nut	Buy now
69	69K--45384--00 Nut	Buy now
70	69K--45577--00 Shim (t:0.10mm) UR	Buy now
70	69K--45577--10 Shim (t:0.12mm) UR	Buy now
70	69K--45577--20 Shim (t:0.15mm) UR	Buy now
70	69K--45577--30 Shim (t:0.18mm) UR	Buy now
70	69K--45577--40 Shim (t:0.30mm) UR	Buy now
70	69K--45577--50 Shim (t:0.40mm) UR	Buy now

Lower Casing. Drive 3



Ref	Part	
70	69K-45577-60 Shim (t:0.50mm) UR	Buy now
70	69K-45577-00 Shim (t:0.10mm) UR	Buy now
70	69K-45577-10 Shim (t:0.12mm) UR	Buy now
70	69K-45577-20 Shim (t:0.15mm) UR	Buy now
70	69K-45577-30 Shim (t:0.18mm) UR	Buy now
70	69K-45577-40 Shim (t:0.30mm) UR	Buy now
70	69K-45577-50 Shim (t:0.40mm) UR	Buy now
70	69K-45577-60 Shim (t:0.50mm) UR	Buy now
71	93315-43061 Bearing	Buy now
71	93315-43061 Bearing	Buy now
72	93101-30M17 Oil seal (6e5)	Buy now
72	93101-30M17 Oil seal (6e5)	Buy now
73	93211-04384 O-ring (705)	Buy now
73	93211-04384 O-ring (705)	Buy now
74	9010508036 Bolt, flange	Buy now


Lower Casing. Drive 3



Ref	Part	
74	90105-08036 Bolt, flange	Buy now
75	90201-08023 Washer, plate	Buy now
75	90201-08023 Washer, plate	Buy now
76	93700-09M00 Nipple, grease(6t4)	Buy now
76	93700-09M00 Nipple, grease(6t4)	Buy now
77	69J-45361-00-8D Cap, lower casing	Buy now
77	69J-45361-00-8D Cap, lower casing	Buy now
78	97095-08020 Bolt, hexagon	Buy now
78	97095-08020 Bolt, hexagon	Buy now


D4

Lower Casing. Drive 4




Ref	Part	
1	6E5--44365--00 Damper, water seal 1	Buy now
1	6E5--44365--00 Damper, water seal 1	Buy now
2	6E5--44366--00 Damper, water seal 2	Buy now
2	6E5--44366--00 Damper, water seal 2	Buy now
3	69J4436100 Tube, water 1 X	Buy now
3	69J--44361--00 Tube, water 1 X	Buy now
4	93608--12M05 Pin, dowel b (6e5)	Buy now
4	93608--12M05 Pin, dowel b (6e5)	Buy now
5	97095--10045 Bolt(64d) X	Buy now
5	97095--10045 Bolt(64d) X	Buy now
6	92995--10100 Ybs67-10 washer, spring X	Buy now
6	92995--10100 Ybs67-10 washer, spring X	Buy now
7	92995--10600 Washer, plate X	Buy now
7	92995--10600 Washer, plate X	Buy now
8	90119--10MA2 Bolt, with washer X	Buy now

Lower Casing. Drive 4




Ref	Part	
8	90119-10MA2 Bolt, with washer X	Buy now
9	69J-45375-00 Damper, seal	Buy now
9	69J-45375-00 Damper, seal	Buy now
10	61A4521410 Cover, water inlet 1	Buy now
10	61A-45214-10 Cover, water inlet 1	Buy now
11	61A4521510 Cover, water inlet 2	Buy now
11	61A-45215-10 Cover, water inlet 2	Buy now
12	90152-05003 Screw, countersunk	Buy now
12	90152-05003 Screw, countersunk	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now
14	61A-45371-00 Anode	Buy now
14	61A-45371-00 Anode	Buy now
15	90105-10M00 Bolt, hexagon (663)	Buy now
15	90105-10M00 Bolt, hexagon (663)	Buy now

Lower Casing. Drive 4




Ref	Part	
16	69J--45987--00 Spacer 1	Buy now
16	69J--45987--00 Spacer 1	Buy now
17	688--45997--01 Spacer 2	Buy now
17	688--45997--01 Spacer 2	Buy now
18	92990--18200 Washer (6e5)	Buy now
18	92990--18200 Washer (6e5)	Buy now
19	90171--18M04 Nut, castle (6e5)	Buy now
19	90171--18M04 Nut, castle (6e5)	Buy now
20	91490--40030 Pin, cotter (663)	Buy now
20	91490--40030 Pin, cotter (663)	Buy now
21	61B459720098 Propeller (ss 3x14-1/2"x21"-tl) UR	Buy now
21	61B459740098 Propeller (3x14-1/2"x19"-tl) UR	Buy now
21	61B459780098 Propeller (3x5"x17"-tl) UR	Buy now
21	61B--45972--00--98 Propeller (ss 3x14-1/2"x21"-tl) UR	Buy now
21	61B--45974--00--98 Propeller (3x14-1/2"x19"-tl) UR	Buy now

Lower Casing. Drive 4




Ref	Part	
21	61B-45978-00-98 Propeller (3x5"x17"-tl) UR	Buy now
21	6K1-45970-01-98 Propeller (3x15-1/4"x15"-ml) UR	Buy now
21	6K1-45972-01-98 Propeller (3x13-3/4"x21"-ml) UR	Buy now
21	6K1-45974-02-98 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
21	6K1-45978-02-98 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
21	6K1-45970-01-98 Propeller (3x15-1/4"x15"-ml) UR	Buy now
21	6K1-45972-01-98 Propeller (3x13-3/4"x21"-ml) UR	Buy now
21	6K1-45974-02-98 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
21	6K1-45978-02-98 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
21	6R1-45970-A0 Propeller, Ss (3 X 15-1/4" X 19"-MI) UR	Buy now
21	6R1-45972-A0 Propeller (3X14-7/8"X21"-MI) UR	Buy now
21	6R1-45974-A0 Propeller (3X14-1/2"X23"-MI) UR	Buy now
21	6R1-45976-A0 Propeller (3X15-1/4"X15"-MI) UR	Buy now
21	6R1-45978-A0 Propeller (3X15-1/4"x17"-MI) UR	Buy now
21	6R1-45970-A0 Propeller, Ss (3 X 15-1/4" X 19"-MI) UR	Buy now

Lower Casing. Drive 4




Ref	Part	
21	6R1-45972-A0 Propeller (3X14-7/8"X21"-MI) UR	Buy now
21	6R1-45974-A0 Propeller (3X14-1/2"X23"-MI) UR	Buy now
21	6R1-45976-A0 Propeller (3X15-1/4"X15"-MI) UR	Buy now
21	6R1-45978-A0 Propeller (3X15-1/4"x17"-MI) UR	Buy now

Meter



Ref	Part	
1	6Y58350T02 Digital tachometer assembly AP	Buy now
1	6Y5-8350T-02 Digital tachometer assembly AP	Buy now
2	9E450--04433 Housing, connector (m-4-w) M-4-W	Buy now
2	9E450--04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450--04533 Housing, f-4-w(5pcs) F-4-W	Buy now
3	9E450--04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5--83500--S5 Meter assembly AP	Buy now
6	6Y5--83500--S5 Meter assembly AP	Buy now
7	6Y5--83570--S5 Speedometer assembly	Buy now
7	6Y5--83570--S5 Speedometer assembly	Buy now
10	6Y5--83533--T2 Grommet	Buy now


Meter



E6

Ref	Part	
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
20	90465-11M10 Clamp AP	Buy now
20	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a) FOR 6Y5-83553-M0	Buy now
16	1E6-82151-00 Fuse (10a) FOR 6Y5-83553-M0	Buy now


Meter



E6


Ref	Part	
17	6Y5-82117-00 Wire, lead AP	Buy now
17	6Y5-82117-00 Wire, lead AP	Buy now
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
18	68F-82553-90 Extension, wire lead (9m) AP	Buy now
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
18	68F-82553-90 Extension, wire lead (9m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now
21	6Y5-8350F-00 Fuel meter movement assembly AP	Buy now
21	6Y5-8350F-00 Fuel meter movement assembly AP	Buy now
23	6Y5-83553-F1 Wire, lead AP	Buy now
23	6Y5-83553-F1 Wire, lead AP	Buy now
24	6Y5-85752-01 Sender unit assembly, fuel meter AP	Buy now
24	6Y5-85752-01 Sender unit assembly, fuel meter AP	Buy now
25	90158-06002 33 - AP	Buy now

Meter



Ref	Part	
25	90158-06002 33 – AP	Buy now
27	703--82531--00 Wire, lead AP	Buy now
27	703-82531-00 Wire, lead AP	Buy now


Oil Pan



C4

Ref	Part	
1	69J1531200 Gasket, oil pan	Buy now
1	69J-15312-00 Gasket, oil pan	Buy now
2	69J15311005B Oil pan	Buy now
2	69J-15311-00-5B Oil pan	Buy now
3	97575--08560 Bolt, hexagon w/w deep recess	Buy now
3	97575--08560 Bolt, hexagon w/w deep recess	Buy now
4	97095--08035 Bolt(70w)	Buy now
4	97095--08035 Bolt(70w)	Buy now
5	92995--08600 Washer, plain (663)	Buy now
5	92995--08600 Washer, plain (663)	Buy now
6	93608--16M16 Pin, dowel(6t4)	Buy now
6	93608--16M16 Pin, dowel(6t4)	Buy now
7	90340--14M06 Plug, straight screw(62y)	Buy now
7	90340--14M06 Plug, straight screw(62y)	Buy now
8	90430--14M09 Gasket	Buy now


Oil Pan



C4

Ref	Part	
8	90430-14M09 Gasket	Buy now
9	69J-13411-00 Strainer, oil	Buy now
9	69J-13411-00 Strainer, oil	Buy now
10	9038706M64 Collar	Buy now
10	90387-06M64 Collar	Buy now
11	69J-13415-00 Seal, oil strainer	Buy now
11	69J-13415-00 Seal, oil strainer	Buy now
12	9702706025 Bolt, hexagon	Buy now
12	97027-06025 Bolt, hexagon	Buy now
13	9290706600 Washer(6ta)	Buy now
13	92907-06600 Washer(6ta)	Buy now
14	69J1330000 Oil pump assembly	Buy now
14	69J-13300-00 Oil pump assembly	Buy now
15	69J1332900 Gasket, pump cover	Buy now
15	69J-13329-00 Gasket, pump cover	Buy now


Oil Pan



C4

Ref	Part	
16	69J1333800 Oil seal	Buy now
16	69J-13338-00 Oil seal	Buy now
17	69J1311900 Oil seal	Buy now
17	69J-13119-00 Oil seal	Buy now
18	69J--13631--00 Oil seal	Buy now
18	69J-13631-00 Oil seal	Buy now
19	69J--11355--00 Seal, cylinder 1	Buy now
19	69J-11355-00 Seal, cylinder 1	Buy now
20	97095--06040 Bolt (682)	Buy now
20	97095-06040 Bolt (682)	Buy now
21	92995--06600 Washer, plain (646)	Buy now
21	92995-06600 Washer, plain (646)	Buy now
22	93210--25552 O-ring (22f)	Buy now
22	93210-25552 O-ring (22f)	Buy now
23	69J1536200 Plug, Oil Level	Buy now


Oil Pan



C4


Ref	Part	
23	69J-15362-00 Plug, Oil Level	Buy now
24	69J1537700 Guide Inlet	Buy now
24	69J-15377-00 Guide Inlet	Buy now
25	93210--19MJ3 O-ring	Buy now
25	93210--19MJ3 O-ring	Buy now
26	97095-06020 Bolt(7u8)	Buy now
26	97095-06020 Bolt(7u8)	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
1	69J43800004D Power trim & tilt assembly	Buy now
1	69J-43800-00-4D Power trim & tilt assembly	Buy now
2	69J4384000 Power tilt assembly	Buy now
2	69J-43840-00 Power tilt assembly	Buy now
3	69J4381000 Tilt piston sub assembly	Buy now
3	69J-43810-00 Tilt piston sub assembly	Buy now
4	69J4380100 Rod	Buy now
4	69J-43801-00 Rod	Buy now
5	93106-19N50 Oil seal	Buy now
5	93106-19N50 Oil seal	Buy now
6	6H1-43861-00 O-ring	Buy now
6	6H1-43861-00 O-ring	Buy now
7	6H1-43872-00 Ring, back up	Buy now
7	6H1-43872-00 Ring, back up	Buy now
8	61A4389H00 O-ring	Buy now


Power Trim & Tilt Assy 1



B3

Ref	Part	
8	61A-4389H-00 O-ring	Buy now
9	61A-43811-00 Screw, cylinder end	Buy now
9	61A-43811-00 Screw, cylinder end	Buy now
10	69J-4384H-00 Spring	Buy now
10	69J-4384H-00 Spring	Buy now
11	69J-4382E-00 Adaptor 2	Buy now
11	69J-4382E-00 Adaptor 2	Buy now
12	69J4380P00 Piston sub assembly	Buy now
12	69J-4380P-00 Piston sub assembly	Buy now
13	93505--32038 Ball(7fk)	Buy now
13	93505--32038 Ball(7fk)	Buy now
14	61A-43861-00 O-ring	Buy now
14	61A-43861-00 O-ring	Buy now
15	61A-43871-00 Ring, back up	Buy now
15	61A-43871-00 Ring, back up	Buy now


Power Trim & Tilt Assy 1



B3

Ref	Part	
17	6H1--43814--00 Piston, free	Buy now
17	6H1--43814--00 Piston, free	Buy now
18	61A--43813--01 Cylinder, tilt	Buy now
18	61A--43813--01 Cylinder, tilt	Buy now
19	61A--43835--01 Pipe	Buy now
19	61A--43835--01 Pipe	Buy now
20	69J--4388J--00 Plug 2	Buy now
20	69J--4388J--00 Plug 2	Buy now
21	69J--43833--00 Pipe	Buy now
21	69J--43833--00 Pipe	Buy now
22	93210--17239 O-ring (1j7)	Buy now
22	93210--17239 O-ring (1j7)	Buy now
23	69J4388E00 Bolt ,screw	Buy now
23	69J--4388E--00 Bolt ,screw	Buy now
24	90386--18M14 Bushing (6e5)	Buy now


Power Trim & Tilt Assy 1



B3

Ref	Part	
24	90386-18M14 Bushing (6e5)	Buy now
25	61A-43818-00 Pin, lower shock mount	Buy now
25	61A-43818-00 Pin, lower shock mount	Buy now
26	61A-43876-00 Ring, snap	Buy now
26	61A-43876-00 Ring, snap	Buy now
27	93210-18397 O-ring (6g5)	Buy now
27	93210-18397 O-ring (6g5)	Buy now
28	69J-43845-00 Screw, manual release	Buy now
28	69J-43845-00 Screw, manual release	Buy now
29	6H1-43875-00 Ring, snap	Buy now
29	6H1-43875-00 Ring, snap	Buy now
30	69J-4381C-00 Filter 3	Buy now
30	69J-4381C-00 Filter 3	Buy now
31	69J4389900 Plate stopper	Buy now
31	69J-43899-00 Plate stopper	Buy now


Power Trim & Tilt Assy 1



B3

Ref	Part	
32	69J--4389J--00 O-ring	Buy now
32	69J--4389J--00 O-ring	Buy now
33	69J4383000 Gear pump assembly	Buy now
33	69J-43830-00 Gear pump assembly	Buy now
37	93503--16003 Ball	Buy now
37	93503-16003 Ball	Buy now
38	69J--4384M--00 Piston, shuttle 2	Buy now
38	69J-4384M-00 Piston, shuttle 2	Buy now
39	69A--4384F--00 Seal, main valve	Buy now
39	69A-4384F-00 Seal, main valve	Buy now
40	9900103600 Circlip(6I5)	Buy now
40	99001-03600 Circlip(6I5)	Buy now
41	69J--43894--00 Spring, shuttle return	Buy now
41	69J-43894-00 Spring, shuttle return	Buy now
42	69J--43841--00 Piston, shuttle	Buy now


Power Trim & Tilt Assy 1



B3

Ref	Part	
42	69J-43841-00 Piston, shuttle	Buy now
43	6H1-43883-00 O-ring	Buy now
43	6H1-43883-00 O-ring	Buy now
44	65W-4386A-00 Pin, absorber valve	Buy now
44	65W-4386A-00 Pin, absorber valve	Buy now
45	69J-43853-00 Spring, main valve	Buy now
45	69J-43853-00 Spring, main valve	Buy now
46	69J-43893-00 Washer	Buy now
46	69J-43893-00 Washer	Buy now
47	93501-08001 Ball	Buy now
47	93501-08001 Ball	Buy now
48	93210-08391 O-ring	Buy now
48	93210-08391 O-ring	Buy now
49	69J-43851-00 Seat, relief valve	Buy now
49	69J-43851-00 Seat, relief valve	Buy now


Power Trim & Tilt Assy 1



B3


Ref	Part	
50	69J4384400 Pin, valve support	Buy now
50	69J-43844-00 Pin, valve support	Buy now
51	93210-064A5 O-ring(61a)	Buy now
51	93210-064A5 O-ring(61a)	Buy now
52	69J-43855-00 Spring, up relief	Buy now
52	69J-43855-00 Spring, up relief	Buy now
53	69J4384300 Screw, valve lock	Buy now
53	69J-43843-00 Screw, valve lock	Buy now
54	6H1-4384G-11 Seal, relief valve	Buy now
54	6H1-4384G-11 Seal, relief valve	Buy now
55	6H1-43844-10 Pin, valve support	Buy now
55	6H1-43844-10 Pin, valve support	Buy now
56	6H1-43856-10 Spring, down relief	Buy now
56	6H1-43856-10 Spring, down relief	Buy now
57	69J-43854-00 Spring, manual release	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
57	69J-43854-00 Spring, manual release	Buy now
58	69J-4384G-00 Seal, relief valve	Buy now
58	69J-4384G-00 Seal, relief valve	Buy now
59	CS3-4387G-00 Washer	Buy now
59	CS3-4387G-00 Washer	Buy now
60	91318-05025 Bolt,socket	Buy now
60	91318-05025 Bolt,socket	Buy now
61	93604-35236 Pin, dowel	Buy now
61	93604-35236 Pin, dowel	Buy now
62	69J-43871-00 Ring, back up	Buy now
62	69J-43871-00 Ring, back up	Buy now
63	69J-43816-00 Filter 1	Buy now
63	69J-43816-00 Filter 1	Buy now
64	69J-4381J-00 Plate	Buy now
64	69J-4381J-00 Plate	Buy now


Power Trim & Tilt Assy 1



B3

Ref	Part	
65	91318--05040 Bolt,socket	Buy now
65	91318--05040 Bolt,socket	Buy now
66	69J--43831--00 Connector, shaft	Buy now
66	69J--43831--00 Connector, shaft	Buy now
67	69J--4388H--00 Plug	Buy now
67	69J--4388H--00 Plug	Buy now
68	69J--43817--00 Filter 2	Buy now
68	69J--43817--00 Filter 2	Buy now
69	69J--4388F--00 Spacer	Buy now
69	69J--4388F--00 Spacer	Buy now
70	6H1--43869--00 O-ring	Buy now
70	6H1--43869--00 O-ring	Buy now
71	69J--43828--00 Body, reservoir	Buy now
71	69J--43828--00 Body, reservoir	Buy now
72	69J--43888--00 Bolt, socket	Buy now


Power Trim & Tilt Assy 1



B3


Ref	Part	
72	69J-43888-00 Bolt, socket	Buy now
73	93210-09165 O-ring	Buy now
73	93210-09165 O-ring	Buy now
74	6H1-43829-00 Plug, reservoir	Buy now
74	6H1-43829-00 Plug, reservoir	Buy now
76	6T44387500 Ring, snap	Buy now
76	6T4-43875-00 Ring, snap	Buy now
77	61A-43822-00 Seal, trim dust	Buy now
77	61A-43822-00 Seal, trim dust	Buy now
78	61A-43821-00 Screw, trim cylinder end	Buy now
78	61A-43821-00 Screw, trim cylinder end	Buy now
79	69J-43820-00 Trim piston sub assembly	Buy now
79	69J-43820-00 Trim piston sub assembly	Buy now
80	61A-43874-00 Ring, back up	Buy now
80	61A-43874-00 Ring, back up	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
81	61A--43864--00 O-ring	Buy now
81	61A--43864--00 O-ring	Buy now
82	61A--4384H--10 Spring	Buy now
82	61A--4384H--10 Spring	Buy now
83	61A--43875--10 Ring, snap	Buy now
83	61A--43875--10 Ring, snap	Buy now
84	69J4388000 Motor assembly REFER TO FIG.28	Buy now
84	69J--43880--00 Motor assembly REFER TO FIG.28	Buy now

Power Trim & Tilt Assy 2




69J1010-2270

B7

Ref	Part	
1	69J4388000 Motor assembly	Buy now
1	69J-43880-00 Motor assembly	Buy now
2	90206--14N50 Washer, wave	Buy now
2	90206--14N50 Washer, wave	Buy now
3	93399--999T6 Bearing	Buy now
3	93399--999T6 Bearing	Buy now
4	69J--43805--00 Armature assembly	Buy now
4	69J--43805--00 Armature assembly	Buy now
5	69J--43804--00 Stator assembly	Buy now
5	69J--43804--00 Stator assembly	Buy now
6	69J--43861--00 O-ring	Buy now
6	69J--43861--00 O-ring	Buy now
7	69J--43886--00 Bolt	Buy now
7	69J--43886--00 Bolt	Buy now
8	69J--43882--00 Oil seal	Buy now

Power Trim & Tilt Assy 2





69J1010-2270

B7


Ref	Part	
8	69J-43882-00 Oil seal	Buy now
9	69J-43891-00 Brush 1	Buy now
9	69J-43891-00 Brush 1	Buy now
10	69J-4386K-00 Spring, brush	Buy now
10	69J-4386K-00 Spring, brush	Buy now
11	69J4388100 Frame, end	Buy now
11	69J-43881-00 Frame, end	Buy now

Remote Control Box



Ref	Part	
1	703--48205--17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
1	703--48205--17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	704--48207--23 Remote Control assembly AP WITH PT/T SW.	Buy now
2	704--48207--23 Remote Control assembly AP WITH PT/T SW.	Buy now
3	701--48320--40 27 – UR	Buy now
3	701--48320--50 Cable, Remote Control L=15F UR	Buy now
3	701--48320--60 Cable, Remote Control L=16F UR	Buy now
3	701--48320--80 Cable, Remote Control L=17F UR	Buy now
3	701--48350--00 Cable, Remote Control L=21F UR	Buy now
3	701--48320--40 Cable, Remote Control L=19F UR	Buy now
3	701--48320--50 Cable, Remote Control L=15F UR	Buy now
3	701--48320--60 Cable, Remote Control L=16F UR	Buy now
3	701--48320--80 Cable, Remote Control L=17F UR	Buy now
3	701--48350--00 Cable, Remote Control L=21F UR	Buy now

Repair Kit 1




69J1100-2411

F2

Ref	Part	
1	69JW000101 Power head gasket kit	Buy now
1	69J-W0001-01 Power head gasket kit	Buy now
2	90430--14115 Gasket (663)	Buy now
2	90430-14115 Gasket (663)	Buy now
3	69J--15451--00 Gasket, crankcase cover 1	Buy now
3	69J-15451-00 Gasket, crankcase cover 1	Buy now
4	69J1131B00 Gasket, cover	Buy now
4	69J-1131B-00 Gasket, cover	Buy now
5	69J1135100 Gasket, cylinder	Buy now
5	69J-11351-00 Gasket, cylinder	Buy now
6	93210--25552 O-ring (22f)	Buy now
6	93210-25552 O-ring (22f)	Buy now
7	93210--19MJ1 O-ring	Buy now
7	93210-19MJ1 O-ring	Buy now
8	93210--25647 O-ring (7or)	Buy now


Repair Kit 1



F2

Ref	Part	
8	93210-25647 O-ring (7or)	Buy now
9	69J1347700 Gasket	Buy now
9	69J-13477-00 Gasket	Buy now
10	93210-24M79 O-ring	Buy now
10	93210-24M79 O-ring	Buy now
11	69J15364A0 Gasket, oil plug	Buy now
11	69J-15364-A0 Gasket, oil plug	Buy now
12	93102-63004 Oil seal	Buy now
12	93102-63004 Oil seal	Buy now
13	69J1118101 Gasket, cylinder head 1	Buy now
13	69J-11181-01 Gasket, cylinder head 1	Buy now
14	69J1118201 Gasket, cylinder head 2	Buy now
14	69J-11182-01 Gasket, cylinder head 2	Buy now
15	69J1119300 Gasket, head cover 1	Buy now
15	69J-11193-00 Gasket, head cover 1	Buy now

Repair Kit 1




69J1100-2411

F2


Ref	Part	
16	69J1119400 Gasket, head cover 2	Buy now
16	69J-11194-00 Gasket, head cover 2	Buy now
17	69J4111200 Gasket, exhaust inner cover	Buy now
17	69J-41112-00 Gasket, exhaust inner cover	Buy now
18	69J4111400 Gasket, exhaust outer cover	Buy now
18	69J-41114-00 Gasket, exhaust outer cover	Buy now
19	90430-08143 Gasket (256-11198-00)	Buy now
19	90430-08143 Gasket (256-11198-00)	Buy now
20	90430-18130 Gasket (1j7)	Buy now
20	90430-18130 Gasket (1j7)	Buy now
21	9310238M59 Oil seal	Buy now
21	93102-38M59 Oil seal	Buy now
22	69J1355700 Gasket	Buy now
22	69J-13557-00 Gasket	Buy now
23	69J1364500 Gasket, manifold 1	Buy now

Repair Kit 1




Ref	Part	
23	69J-13645-00 Gasket, manifold 1	Buy now
24	69J1333800 Oil seal	Buy now
24	69J-13338-00 Oil seal	Buy now
25	69J--11355--00 Seal, cylinder 1	Buy now
25	69J--11355--00 Seal, cylinder 1	Buy now
26	93210--19MJ3 O-ring	Buy now
26	93210--19MJ3 O-ring	Buy now
27	69J--14664--00 Grommet, water shut	Buy now
27	69J-14664-00 Grommet, water shut	Buy now

Repair Kit 2



Ref	Part	
1	69JW000120 Lower unit gasket kit	Buy now
1	69J-W0001-20 Lower unit gasket kit	Buy now
2	93210--28543 O-ring(72f)	Buy now
2	93210-28543 O-ring(72f)	Buy now
3	93210--33MG4 O-ring	Buy now
3	93210-33MG4 O-ring	Buy now
4	69J41134A0 Gasket, exhaust manifold	Buy now
4	69J-41134-A0 Gasket, exhaust manifold	Buy now
5	69J--41138--00 Seal, ext. 1	Buy now
5	69J-41138-00 Seal, ext. 1	Buy now
6	69J--41135--A0 Gasket, exhaust manifold	Buy now
6	69J-41135-A0 Gasket, exhaust manifold	Buy now
7	69J41136A0 Gasket, exhaust manifold 4	Buy now
7	69J-41136-A0 Gasket, exhaust manifold 4	Buy now
8	69J--45127--00 Seal	Buy now


Repair Kit 2



F3


Ref	Part	
8	69J-45127-00 Seal	Buy now
9	69J--45123--00 Gasket, muffler	Buy now
9	69J-45123-00 Gasket, muffler	Buy now
10	69J4511300 Gasket, upper casing	Buy now
10	69J-45113-00 Gasket, upper casing	Buy now
11	69J1531200 Gasket, oil pan	Buy now
11	69J-15312-00 Gasket, oil pan	Buy now
12	90430--14M09 Gasket	Buy now
12	90430-14M09 Gasket	Buy now
13	69J--13415--00 Seal, oil strainer	Buy now
13	69J-13415-00 Seal, oil strainer	Buy now
14	90430--08020 Gasket	Buy now
14	90430-08020 Gasket	Buy now
15	93210--64488 93210-64488	Buy now
15	93210-64488 93210-64488	Buy now

Repair Kit 2




Ref	Part	
16	93106--09014 Oil seal	Buy now
16	93106--09014 Oil seal	Buy now
17	93210--86M38 O-ring (6e5)	Buy now
17	93210--86M38 O-ring (6e5)	Buy now
18	93210--37160 O-ring (6g8)	Buy now
18	93210--37160 O-ring (6g8)	Buy now
19	6E5--44365--00 Damper, water seal 1	Buy now
19	6E5--44365--00 Damper, water seal 1	Buy now
20	6E5--44315--A0 Gasket,water pump	Buy now
20	6E5--44315--A0 Gasket,water pump	Buy now
21	93101--28M16 Oil seal (6e5)	Buy now
21	93101--28M16 Oil seal (6e5)	Buy now
22	93210--55M14 O-ring (70e)	Buy now
22	93210--55M14 O-ring (70e)	Buy now
23	93101--30M17 Oil seal (6e5)	Buy now

Repair Kit 2




Ref	Part	
23	93101-30M17 Oil seal (6e5)	Buy now
24	93211-04384 O-ring (705)	Buy now
24	93211-04384 O-ring (705)	Buy now
25	6E5-44366-00 Damper, water seal 2	Buy now
25	6E5-44366-00 Damper, water seal 2	Buy now
26	61A-W0078-A3 Water pump repair kit	Buy now
26	61A-W0078-A3 Water pump repair kit	Buy now
27	61A-44322-02 Insert, cartridge	Buy now
27	61A-44322-02 Insert, cartridge	Buy now
30	6E5-44352-01 Impeller	Buy now
30	6E5-44352-01 Impeller	Buy now
31	6G5-44323-00 Outer plate, cartridge	Buy now
31	6G5-44323-00 Outer plate, cartridge	Buy now
33	93606-12019 Pin, dowel (614)	Buy now
33	93606-12019 Pin, dowel (614)	Buy now

Repair Kit 2



Ref	Part	
34	90119--08M14 Bolt, with washer	Buy now
34	90119--08M14 Bolt, with washer	Buy now
35	90280--04M05 Key, woodruff (6e5)	Buy now
35	90280--04M05 Key, woodruff (6e5)	Buy now


Starting Motor



F1

Ref	Part	
1	69J8180000 Starting motor assembly	Buy now
1	69J-81800-00 Starting motor assembly	Buy now
2	67F--81850--00 Armature assembly	Buy now
2	67F--81850--00 Armature assembly	Buy now
3	67F--81810--00 Stator assembly	Buy now
3	67F--81810--00 Stator assembly	Buy now
4	69J--81840--00 Brush holder assembly	Buy now
4	69J--81840--00 Brush holder assembly	Buy now
5	69J--81801--00 Brush set	Buy now
5	69J--81801--00 Brush set	Buy now
6	67F--81813--00 Spring, brush	Buy now
6	67F--81813--00 Spring, brush	Buy now
7	68F--81820--00 Rear bracket assembly	Buy now
7	68F--81820--00 Rear bracket assembly	Buy now
8	67F--81808--00 Pinion assembly	Buy now


Starting Motor



F1

Ref	Part	
8	67F-81808-00 Pinion assembly	Buy now
9	67F-81857-00 Pinion stopper set	Buy now
9	67F-81857-00 Pinion stopper set	Buy now
10	67F-81807-00 Gear assembly, starting motor	Buy now
10	67F-81807-00 Gear assembly, starting motor	Buy now
11	67F-81832-00 Clutch, over run	Buy now
11	67F-81832-00 Clutch, over run	Buy now
12	67F-81836-00 Shaft, pinion	Buy now
12	67F-81836-00 Shaft, pinion	Buy now
13	67F-81821-00 Bracket, center 1	Buy now
13	67F-81821-00 Bracket, center 1	Buy now
14	67F-81841-00 Bearing	Buy now
14	67F-81841-00 Bearing	Buy now
15	67F-81891-00 Gear, ring	Buy now
15	67F-81891-00 Gear, ring	Buy now


Starting Motor



F1

Ref	Part	
16	67F--8183R--00 Gasket	Buy now
16	67F--8183R--00 Gasket	Buy now
17	67F--81830--00 Bracket, center 2	Buy now
17	67F--81830--00 Bracket, center 2	Buy now
18	67F8183T00 Gear, Idler	Buy now
18	67F--8183T--00 Gear, Idler	Buy now
19	67F--81809--00 Washer kit	Buy now
19	67F--81809--00 Washer kit	Buy now
20	69J--81842--00 Cover	Buy now
20	69J--81842--00 Cover	Buy now
21	69J8183900 Lever assembly	Buy now
21	69J--81839--00 Lever assembly	Buy now
22	69J8194100 Starter relay assembly	Buy now
22	69J--81941--00 Starter relay assembly	Buy now
23	69J8186900 Cover Dust	Buy now


Starting Motor



F1

Ref	Part	
23	69J-81869-00 Cover Dust	Buy now
24	6K7-81826-10 Bolt	Buy now
24	6K7-81826-10 Bolt	Buy now
25	69J-81828-00 Bolt 2	Buy now
25	69J-81828-00 Bolt 2	Buy now
26	67F-81846-00 Screw	Buy now
26	67F-81846-00 Screw	Buy now
27	97013-08045 Bolt	Buy now
27	97013-08045 Bolt	Buy now
28	92903-08600 Washer, plain (663)	Buy now
28	92903-08600 Washer, plain (663)	Buy now
29	95333-08600 Nut(6I2)	Buy now
29	95333-08600 Nut(6I2)	Buy now
30	92903-08100 Ybs67-8 washer, spring	Buy now
30	92903-08100 Ybs67-8 washer, spring	Buy now

Steering Guide Attachment 1




67H0100-9290

E3

Ref	Part	
1	6E5--61350--02 Steering guide attachment kit AP	Buy now
1	6E5--61350--02 Steering guide attachment kit AP	Buy now
2	6E5--61351--01 Rod, steering link	Buy now
2	6E5--61351--01 Rod, steering link	Buy now
3	90387--10M61 Collar (6e5)	Buy now
3	90387--10M61 Collar (6e5)	Buy now
4	90560--12M01 Spacer (6e5)	Buy now
4	90560--12M01 Spacer (6e5)	Buy now
5	6E5--61355--00 Bolt	Buy now
5	6E5--61355--00 Bolt	Buy now
6	90185--09M01 Nut, nylon (663)	Buy now
6	90185--09M01 Nut, nylon (663)	Buy now
7	90201--10M20 Washer, plate (663)	Buy now
7	90201--10M20 Washer, plate (663)	Buy now
8	6E5--43145--01 Cap, clamp bracket	Buy now

Steering Guide Attachment 1




67H0100-9290

E3

Ref	Part	
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now
9	93210-16275 O-ring	Buy now

Steering Guide Attachment 2




67H0100-0300

E4

Ref	Part	
1	6E5--61301--01 Tie bar assembly (l:600-800mm) AP	Buy now
1	6E5--61301--01 Tie bar assembly (l:600-800mm) AP	Buy now
2	6E5--61313--00 Adjuster	Buy now
2	6E5--61313--00 Adjuster	Buy now
3	6E5--61311--11 Tie bar	Buy now
3	6E5--61311--11 Tie bar	Buy now
4	6E5--61315--00 Tie bar, 2	Buy now
4	6E5--61315--00 Tie bar, 2	Buy now
5	6E5--61303--00 Steering axle comp.	Buy now
5	6E5--61303--00 Steering axle comp.	Buy now
6	90170--14M06 Nut (6e5)	Buy now
6	90170--14M06 Nut (6e5)	Buy now
7	95380--14700 Nut (6e5)	Buy now
7	95380--14700 Nut (6e5)	Buy now
8	90201--10M76 Washer, plate (6e5)	Buy now

Steering Guide Attachment 2




67H0100-0300

E4

Ref	Part	
8	90201-10M76 Washer, plate (6e5)	Buy now
9	90101-09M70 Bolt (6e5)	Buy now
9	90101-09M70 Bolt (6e5)	Buy now
10	90170-09M05 Nut, hexagon (6e5)	Buy now
10	90170-09M05 Nut, hexagon (6e5)	Buy now
11	90185-09M01 Nut, nylon (663)	Buy now
11	90185-09M01 Nut, nylon (663)	Buy now


Switch. Panel



F1


Ref	Part	
1	6K1--82570--07 Panel switch assembly AP	Buy now
1	6K1--82570--07 Panel switch assembly AP	Buy now
2	6K1--82571--01 Plate, panel switch	Buy now
2	6K1--82571--01 Plate, panel switch	Buy now
3	6K1--82510--06 Main switch assembly	Buy now
3	6K1--82510--06 Main switch assembly	Buy now
4	703--82577--00 Cap, key	Buy now
4	703--82577--00 Cap, key	Buy now
5	6K1--82575--00 Engine stop switch assembly	Buy now
5	6K1--82575--00 Engine stop switch assembly	Buy now
6	682--82556--00 Lanyard, stop switch	Buy now
6	682--82556--00 Lanyard, stop switch	Buy now
7	6K1--83614--01 Bracket	Buy now
7	6K1--83614--01 Bracket	Buy now
8	98980--05010 Screw, bind(6k1)	Buy now

Switch. Panel



Ref	Part	
8	98980-05010 Screw, bind(6k1)	Buy now
20	92990-05100 Ybs67-5 washer, spring AP	Buy now
20	92990-05100 Ybs67-5 washer, spring AP	Buy now
19	95380-05600 Nut, hexagon (663) AP	Buy now
19	95380-05600 Nut, hexagon (663) AP	Buy now
11	688-83383-11 Buzzer	Buy now
11	688-83383-11 Buzzer	Buy now
12	6K1-85830-01 Control unit assembly	Buy now
12	6K1-85830-01 Control unit assembly	Buy now
13	98980-06020 Screw, bind (j17)	Buy now
13	98980-06020 Screw, bind (j17)	Buy now
14	95380-06600 Nut(661)	Buy now
14	95380-06600 Nut(661)	Buy now
15	92990-06100 Washer(6a1)	Buy now
15	92990-06100 Washer(6a1)	Buy now


Switch. Panel



F1

Ref	Part	
16	92990--06600 Washer, plain (646)	Buy now
16	92990--06600 Washer, plain (646)	Buy now
17	6K1--81980--00 Diode assembly	Buy now
17	6K1--81980--00 Diode assembly	Buy now
18	90149--05M05 Screw(6k0) AP	Buy now
18	90149--05M05 Screw(6k0) AP	Buy now
21	92990--05600 Washer, plain (646) AP	Buy now
21	92990--05600 Washer, plain (646) AP	Buy now
22	6K1--8258A--40 Extension, wire harness AP	Buy now
22	6K1--8258A--40 Extension, wire harness AP	Buy now
23	61B--8258A--01 Extension, wire harness AP	Buy now
23	61B--8258A--01 Extension, wire harness AP	Buy now


Throttle Body Assy 1



C4

Ref	Part	
1	60L1375000 Throttle body assembly	Buy now
1	60L-13750-00 Throttle body assembly	Buy now
1	69J1375000 Throttle body assembly	Buy now
1	69J-13750-00 Throttle body assembly	Buy now
2	60L1375100 Body, Throttle 1	Buy now
2	60L-13751-00 Body, Throttle 1	Buy now
2	69J1375100 Body, Throttle 1	Buy now
2	69J-13751-00 Body, Throttle 1	Buy now
3	3CF--14594--00 Nut	Buy now
3	3CF--14594--00 Nut	Buy now
4	92990--08100 Ybs67-8 washer, spring	Buy now
4	92990--08100 Ybs67-8 washer, spring	Buy now
5	60L1375300 Body, Throttle 3	Buy now
5	60L-13753-00 Body, Throttle 3	Buy now
5	69J1375300 Body, Throttle 3	Buy now


Throttle Body Assy 1



C4

Ref	Part	
5	69J-13753-00 Body, Throttle 3	Buy now
8	60L1375500 Body, Throttle 5	Buy now
8	60L-13755-00 Body, Throttle 5	Buy now
8	69J1375500 Body, Throttle 5	Buy now
8	69J-13755-00 Body, Throttle 5	Buy now
11	69J1357600 Spacer	Buy now
11	69J-13576-00 Spacer	Buy now
12	68V--81145--01 Screw 1	Buy now
12	68V-81145-01 Screw 1	Buy now
13	68V--14565--00 Screw	Buy now
13	68V-14565-00 Screw	Buy now
14	68V--14323--00 Screw, air adjusting	Buy now
14	68V-14323-00 Screw, air adjusting	Buy now
15	68V--14331--00 Spring, throttle valve	Buy now
15	68V-14331-00 Spring, throttle valve	Buy now


Throttle Body Assy 1



C4

Ref	Part	
16	69J1426100 Holder	Buy now
16	69J-14261-00 Holder	Buy now
17	69J8588500 Throttle sensor assembly	Buy now
17	69J-85885-00 Throttle sensor assembly	Buy now
18	69J1316000 Delivery pipe assembly 1	Buy now
18	69J-13160-00 Delivery pipe assembly 1	Buy now
20	69J1429500 Pipe, fuel	Buy now
20	69J-14295-00 Pipe, fuel	Buy now
21	69J1425100 Nipple	Buy now
21	69J-14251-00 Nipple	Buy now
22	68V1439700 O-ring	Buy now
22	68V-14397-00 O-ring	Buy now
23	68V-81147-00 Screw 3	Buy now
23	68V-81147-00 Screw 3	Buy now
24	69J1364100 Manifold 1	Buy now


Throttle Body Assy 1



C4

Ref	Part	
24	69J-13641-00 Manifold 1	Buy now
25	97095--06010 Bolt	Buy now
25	97095-06010 Bolt	Buy now
26	90430--06014 Gasket 256113960000	Buy now
26	90430-06014 Gasket 256113960000	Buy now
27	69J1355700 Gasket	Buy now
27	69J-13557-00 Gasket	Buy now
28	99530--10114 Pin, dowel(3vd)	Buy now
28	99530-10114 Pin, dowel(3vd)	Buy now
29	69J1449600 Bolt	Buy now
29	69J-14496-00 Bolt	Buy now
30	68V1447500 Washer	Buy now
30	68V-14475-00 Washer	Buy now
31	69J1376100 Injector assembly	Buy now
31	69J-13761-00 Injector assembly	Buy now


Throttle Body Assy 1



C4

Ref	Part	
32	68V1410B00 Packing kit	Buy now
32	68V-1410B-00 Packing kit	Buy now
33	68V-13766-00 Rubber, injector	Buy now
33	68V-13766-00 Rubber, injector	Buy now
34	68V1426400 Collar	Buy now
34	68V-14264-00 Collar	Buy now
35	68V1442800 Bolt	Buy now
35	68V-14428-00 Bolt	Buy now
36	69J-14321-00 Screw, throttle	Buy now
36	69J-14321-00 Screw, throttle	Buy now
37	69J1397300 Pipe Fuel 3	Buy now
37	69J-13973-00 Pipe Fuel 3	Buy now
38	68F2430000 Fuel pipe joint	Buy now
38	68F-24300-00 Fuel pipe joint	Buy now
39	69J1397200 Pipe, fuel 2	Buy now


Throttle Body Assy 1



C4

Ref	Part	
39	69J-13972-00 Pipe, fuel 2	Buy now
40	69J2438100 Set bar, fuel joint	Buy now
40	69J-24381-00 Set bar, fuel joint	Buy now
41	68V2438700 Clip	Buy now
41	68V-24387-00 Clip	Buy now
42	60L1428600 Spring	Buy now
42	60L-14286-00 Spring	Buy now
42	69J1428600 Spring	Buy now
42	69J-14286-00 Spring	Buy now
43	68V--8182L-00 O-ring 1	Buy now
43	68V-8182L-00 O-ring 1	Buy now
44	69J1414900 Pipe	Buy now
44	69J-14149-00 Pipe	Buy now


Throttle Body Assy 2



C6

Ref	Part	
1	60L1375A00 Throttle Body assembly 2	Buy now
1	60L-1375A-00 Throttle Body assembly 2	Buy now
1	69J1375A00 Throttle body assembly 2	Buy now
1	69J-1375A-00 Throttle body assembly 2	Buy now
2	60L1375200 Body, throttle 2	Buy now
2	60L-13752-00 Body, throttle 2	Buy now
2	69J1375200 Body, throttle 2	Buy now
2	69J-13752-00 Body, throttle 2	Buy now
3	3CF-14594-00 Nut	Buy now
3	3CF-14594-00 Nut	Buy now
4	92990-08100 Ybs67-8 washer, spring	Buy now
4	92990-08100 Ybs67-8 washer, spring	Buy now
5	68V-14323-00 Screw, air adjusting	Buy now
5	68V-14323-00 Screw, air adjusting	Buy now
6	68V-14331-00 Spring, throttle valve	Buy now


Throttle Body Assy 2



C6

Ref	Part	
6	68V-14331-00 Spring, throttle valve	Buy now
7	60L1375400 Body, throttle 4	Buy now
7	60L-13754-00 Body, throttle 4	Buy now
7	69J1375400 Body Throttle 4	Buy now
7	69J-13754-00 Body Throttle 4	Buy now
10	60L1375600 Body, throttle 6	Buy now
10	60L-13756-00 Body, throttle 6	Buy now
10	69J1375600 Body Throttle 6	Buy now
10	69J-13756-00 Body Throttle 6	Buy now
14	68V-81147-00 Screw 3	Buy now
14	68V-81147-00 Screw 3	Buy now
15	69J1496000 Body assembly	Buy now
15	69J-14960-00 Body assembly	Buy now
16	68V1347300 O-ring	Buy now
16	68V-13473-00 O-ring	Buy now


Throttle Body Assy 2



C6

Ref	Part	
17	68V1312A00 Valve, control	Buy now
17	68V-1312A-00 Valve, control	Buy now
18	68V--81146--01 Screw 2	Buy now
18	68V-81146-01 Screw 2	Buy now
19	68V8238000 Sensor, pressure	Buy now
19	68V-82380-00 Sensor, pressure	Buy now
20	69J1364200 Manifold 2	Buy now
20	69J-13642-00 Manifold 2	Buy now
21	97095--06010 Bolt	Buy now
21	97095-06010 Bolt	Buy now
22	90430--06014 Gasket 256113960000	Buy now
22	90430-06014 Gasket 256113960000	Buy now
23	69J1355700 Gasket	Buy now
23	69J-13557-00 Gasket	Buy now
24	99530--10114 Pin, dowel(3vd)	Buy now


Throttle Body Assy 2



C6

Ref	Part	
24	99530-10114 Pin, dowel(3vd)	Buy now
25	69J1449600 Bolt	Buy now
25	69J-14496-00 Bolt	Buy now
26	68V1447500 Washer	Buy now
26	68V-14475-00 Washer	Buy now
27	69J1376100 Injector assembly	Buy now
27	69J-13761-00 Injector assembly	Buy now
28	68V1410B00 Packing kit	Buy now
28	68V-1410B-00 Packing kit	Buy now
29	68V--13766--00 Rubber, injector	Buy now
29	68V-13766-00 Rubber, injector	Buy now
30	69J--14321--00 Screw, throttle	Buy now
30	69J-14321-00 Screw, throttle	Buy now
31	69J1357300 Bolt 1	Buy now
31	69J-13573-00 Bolt 1	Buy now


Throttle Body Assy 2



C6


Ref	Part	
32	69J1357400 Bolt 2	Buy now
32	69J-13574-00 Bolt 2	Buy now
33	69J1354700 Hose 3	Buy now
33	69J-13547-00 Hose 3	Buy now
34	69J1415900 Clip	Buy now
34	69J-14159-00 Clip	Buy now
35	69J1425500 Plate	Buy now
35	69J-14255-00 Plate	Buy now

Throttle Body Assy 3




Ref	Part	
1	69J1317000 Delivery pipe assembly 2	Buy now
1	69J-13170-00 Delivery pipe assembly 2	Buy now
2	69J1343500 Nipple	Buy now
2	69J-13435-00 Nipple	Buy now
3	68V1439700 O-ring	Buy now
3	68V-14397-00 O-ring	Buy now
4	68V-81147-00 Screw 3	Buy now
4	68V-81147-00 Screw 3	Buy now
5	68V1422500 Cap	Buy now
5	68V-14225-00 Cap	Buy now
6	69J1390600 Regulator, pressure	Buy now
6	69J-13906-00 Regulator, pressure	Buy now
7	68V-14565-00 Screw	Buy now
7	68V-14565-00 Screw	Buy now
8	68V-14356-00 Washer, spring	Buy now

Throttle Body Assy 3




Ref	Part	
8	68V-14356-00 Washer, spring	Buy now
9	68V1447500 Washer	Buy now
9	68V-14475-00 Washer	Buy now
10	68V1426400 Collar	Buy now
10	68V-14264-00 Collar	Buy now
11	68V1442800 Bolt	Buy now
11	68V-14428-00 Bolt	Buy now
12	68F2430000 Fuel pipe joint	Buy now
12	68F-24300-00 Fuel pipe joint	Buy now
13	68V2438700 Clip	Buy now
13	68V-24387-00 Clip	Buy now
14	69J1354600 Hose 2	Buy now
14	69J-13546-00 Hose 2	Buy now
15	69J1354500 Hose 1	Buy now
15	69J-13545-00 Hose 1	Buy now

Throttle Body Assy 3



Ref	Part	
16	69J1397400 Pipe, fuel 4	Buy now
16	69J-13974-00 Pipe, fuel 4	Buy now
17	68V1354400 Hose Vacuum Sensing 2	Buy now
17	68V-13544-00 Hose Vacuum Sensing 2	Buy now
18	5JW1434900 Pipe	Buy now
18	5JW-14349-00 Pipe	Buy now
19	69J1354200 Hose, vacuum sensing 1	Buy now
19	69J-13542-00 Hose, vacuum sensing 1	Buy now
20	69J1353200 Hose, vacuum sensing 3	Buy now
20	69J-13532-00 Hose, vacuum sensing 3	Buy now
21	69J1353300 Hose, vacuum sensing 4	Buy now
21	69J-13533-00 Hose, vacuum sensing 4	Buy now
22	68V2437700 Pipe, joint 1	Buy now
22	68V-24377-00 Pipe, joint 1	Buy now
23	69J1359500 Joint	Buy now


Throttle Body Assy 3



D1

Ref	Part	
23	69J-13595-00 Joint	Buy now
24	69J1413900 Clip, Pipe	Buy now
24	69J-14139-00 Clip, Pipe	Buy now
25	69J1397500 Pipe, fuel 5	Buy now
25	69J-13975-00 Pipe, fuel 5	Buy now
26	68V--24519-00 Clip	Buy now
26	68V-24519-00 Clip	Buy now
27	69J8259L00 Wire harness assembly 1	Buy now
27	69J-8259L-00 Wire harness assembly 1	Buy now


Top Cowling



A4


Ref	Part	
1	60L42610008D Top Cowling assembly	Buy now
1	60L-42610-00-8D Top Cowling assembly	Buy now
1	69J42610008D Top cowling assembly	Buy now
1	69J-42610-00-8D Top cowling assembly	Buy now
2	69J4261300 Molding, air duct	Buy now
2	69J-42613-00 Molding, air duct	Buy now
3	69J4262900 Seal	Buy now
3	69J-42629-00 Seal	Buy now
4	90179-06M28 Nut(63v)	Buy now
4	90179-06M28 Nut(63v)	Buy now
5	68F426470194 Holder, clamp band	Buy now
5	68F-42647-01-94 Holder, clamp band	Buy now
6	69J426470094 Holder, clamp band	Buy now
6	69J-42647-00-94 Holder, clamp band	Buy now
7	69J-42663-00 Damper 2	Buy now

Top Cowling




Ref	Part	
7	69J-42663-00 Damper 2	Buy now
8	92990-06100 Washer(6a1)	Buy now
8	92990-06100 Washer(6a1)	Buy now
9	95380-06600 Nut(661)	Buy now
9	95380-06600 Nut(661)	Buy now
10	68F4265100 Hook	Buy now
10	68F-42651-00 Hook	Buy now
11	97095-06016 Bolt, hexagon deep recess	Buy now
11	97095-06016 Bolt, hexagon deep recess	Buy now
12	92995-06600 Washer, plain (646)	Buy now
12	92995-06600 Washer, plain (646)	Buy now
13	68F--42663--00 Damper 2	Buy now
13	68F-42663-00 Damper 2	Buy now
14	68F426480194 Holder, clamp band	Buy now
14	68F-42648-01-94 Holder, clamp band	Buy now

Top Cowling




Ref	Part	
15	67F4265200 Hook	Buy now
15	67F--42652--00 Hook	Buy now
16	67F--13448--00 Cap	Buy now
16	67F--13448--00 Cap	Buy now
17	60L4267800 Graphic, front	Buy now
17	60L--42678--00 Graphic, front	Buy now
17	69J4267800 Graphic, rear	Buy now
17	69J--42678--00 Graphic, rear	Buy now
18	69JW007000 Graphic set	Buy now
18	69J--W0070--00 Graphic set	Buy now
19	60L4267700 Graphic, front	Buy now
19	60L--42677--00 Graphic, front	Buy now
19	69J4267700 Graphic, front	Buy now
19	69J--42677--00 Graphic, front	Buy now
20	69J4268100 Mark, cowling	Buy now

Top Cowling



Ref	Part	
20	69J-42681-00 Mark, cowling	Buy now
21	69J4268200 Mark, cowling	Buy now
21	69J-42682-00 Mark, cowling	Buy now
22	69J--24378--00 Pipe, joint 4	Buy now
22	69J-24378-00 Pipe, joint 4	Buy now
23	90445--11020 Hose (I400)	Buy now
23	90445-11020 Hose (I400)	Buy now
24	9044511021 Hose (I310)	Buy now
24	90445-11021 Hose (I310)	Buy now
25	69J4261700 Damper, form	Buy now
25	69J-42617-00 Damper, form	Buy now
26	67F--13434--02 Label, Caution	Buy now
26	67F-13434-02 Label, Caution	Buy now


Upper Casing



C1

Ref	Part	
1	69J411370094 Guide, exhaust	Buy now
1	69J-41137-00-94 Guide, exhaust	Buy now
2	90119--08M79 Bolt, hexagon (fj1)	Buy now
2	90119--08M79 Bolt, hexagon (fj1)	Buy now
3	97075--10045 Bolt(64d)	Buy now
3	97075--10045 Bolt(64d)	Buy now
4	92995--10600 Washer, plate	Buy now
4	92995--10600 Washer, plate	Buy now
5	97075--10035 Bolt	Buy now
5	97075--10035 Bolt	Buy now
7	93608--16M16 Pin, dowel(6t4)	Buy now
7	93608--16M16 Pin, dowel(6t4)	Buy now
8	6E5--42724--00 Grommet	Buy now
8	6E5--42724--00 Grommet	Buy now
9	69J1137100 Pressure control valve assembly	Buy now


Upper Casing



C1

Ref	Part	
9	69J-11371-00 Pressure control valve assembly	Buy now
10	93210-28543 O-ring(72f)	Buy now
10	93210-28543 O-ring(72f)	Buy now
11	93210-33MG4 O-ring	Buy now
11	93210-33MG4 O-ring	Buy now
12	69J-12233-00 Plate, guide stopper 1	Buy now
12	69J-12233-00 Plate, guide stopper 1	Buy now
13	90387-06037 Collar 8121444900	Buy now
13	90387-06037 Collar 8121444900	Buy now
14	97095-06020 Bolt(7u8)	Buy now
14	97095-06020 Bolt(7u8)	Buy now
15	92995-06600 Washer, plain (646)	Buy now
15	92995-06600 Washer, plain (646)	Buy now
16	69J411310094 Manifold, ext. 1	Buy now
16	69J-41131-00-94 Manifold, ext. 1	Buy now


Upper Casing



C1

Ref	Part	
18	69J41132005B Manifold, exhaust	Buy now
18	69J-41132-00-5B Manifold, exhaust	Buy now
19	69J41134A0 Gasket, exhaust manifold	Buy now
19	69J-41134-A0 Gasket, exhaust manifold	Buy now
20	97575-08590 Bolt, hexagon w/w deep recess	Buy now
20	97575-08590 Bolt, hexagon w/w deep recess	Buy now
21	69J-41138-00 Seal, ext. 1	Buy now
21	69J-41138-00 Seal, ext. 1	Buy now
22	69J-41135-A0 Gasket, exhaust manifold	Buy now
22	69J-41135-A0 Gasket, exhaust manifold	Buy now
23	69J45181005B Plate	Buy now
23	69J-45181-00-5B Plate	Buy now
24	69J41136A0 Gasket, exhaust manifold 4	Buy now
24	69J-41136-A0 Gasket, exhaust manifold 4	Buy now
25	69J14711005B Muffler 1	Buy now


Upper Casing



C1

Ref	Part	
25	69J-14711-00-5B Muffler 1	Buy now
26	97075-08035 Bolt(70w)	Buy now
26	97075-08035 Bolt(70w)	Buy now
27	92995-08600 Washer, plain (663)	Buy now
27	92995-08600 Washer, plain (663)	Buy now
28	93606-19M23 Pin, dowel	Buy now
28	93606-19M23 Pin, dowel	Buy now
29	69J-45127-00 Seal	Buy now
29	69J-45127-00 Seal	Buy now
30	69J-45123-00 Gasket, muffler	Buy now
30	69J-45123-00 Gasket, muffler	Buy now
31	69J45111018D Casing, upper	Buy now
31	69J-45111-01-8D Casing, upper	Buy now
32	69J-42769-00 Seal, rubber	Buy now
32	69J-42769-00 Seal, rubber	Buy now


Upper Casing



C1


Ref	Part	
33	69J4511300 Gasket, upper casing	Buy now
33	69J-45113-00 Gasket, upper casing	Buy now
34	90119-10007 Bolt, with washer	Buy now
34	90119-10007 Bolt, with washer	Buy now
36	69J--15316--00 Damper 1	Buy now
36	69J-15316-00 Damper 1	Buy now
37	69J45152008D Cover, upper casing 2	Buy now
37	69J-45152-00-8D Cover, upper casing 2	Buy now
38	97095-06014 Bolt(gj3)	Buy now
38	97095-06014 Bolt(gj3)	Buy now
39	69J4531800 Bushing, drive shaft	Buy now
39	69J-45318-00 Bushing, drive shaft	Buy now
40	93420--36M01 Circlip (6a0)	Buy now
40	93420-36M01 Circlip (6a0)	Buy now
41	61A--45155--00 Cap	Buy now

Upper Casing




Ref	Part	
41	61A-45155-00 Cap	Buy now
42	97095-06010 Bolt	Buy now
42	97095-06010 Bolt	Buy now
44	6E5-83558-00 End, nipple	Buy now
44	6E5-83558-00 End, nipple	Buy now
45	90465-11M10 Clamp	Buy now
45	90465-11M10 Clamp	Buy now
46	90445-07010 Hose (I1457) X	Buy now
46	90445-07012 Hose (I1457) U	Buy now
46	90445-07010 Hose (I1457) X	Buy now
46	90445-07012 Hose (I1457) U	Buy now
47	61A-45378-00 Nipple, hose	Buy now
47	61A-45378-00 Nipple, hose	Buy now
48	93606-12019 Pin, dowel (614)	Buy now
48	93606-12019 Pin, dowel (614)	Buy now

Upper Casing




Ref	Part	
49	90119--06M17 Bolt, with washer	Buy now
49	90119--06M17 Bolt, with washer	Buy now
50	69J--14624--01 Cover, exhaust	Buy now
50	69J--14624--01 Cover, exhaust	Buy now
51	97880--06016 Screw pan head	Buy now
51	97880--06016 Screw pan head	Buy now
52	92990--06600 Washer, plain (646)	Buy now
52	92990--06600 Washer, plain (646)	Buy now
53	69J45211018D Extension U	Buy now
53	69J--45211--01--8D Extension U	Buy now
54	6E5--44366--00 Damper, water seal 2 U	Buy now
54	6E5--44366--00 Damper, water seal 2 U	Buy now
55	93608--12M05 Pin, dowel b (6e5) U	Buy now
55	93608--12M05 Pin, dowel b (6e5) U	Buy now
56	69J--45159--00 Damper U	Buy now

Upper Casing



Ref	Part	
56	69J-45159-00 Damper U	Buy now
57	90116-10012 Bolt, stud U	Buy now
57	90116-10012 Bolt, stud U	Buy now
58	92990-10600 Washer, plate U	Buy now
58	92990-10600 Washer, plate U	Buy now
59	92990-10100 Ybs67-10 washer, spring U	Buy now
59	92990-10100 Ybs67-10 washer, spring U	Buy now
60	95380-10600 Nut(624) U	Buy now
60	95380-10600 Nut(624) U	Buy now
61	90119-10008 Bolt, with washer U	Buy now
61	90119-10008 Bolt, with washer U	Buy now


Valve



B6


Ref	Part	
1	69J1211100 Valve, intake	Buy now
1	69J-12111-00 Valve, intake	Buy now
2	69J1212100 Valve, exhaust	Buy now
2	69J-12121-00 Valve, exhaust	Buy now
3	69J1211300 Spring, valve inner	Buy now
3	69J-12113-00 Spring, valve inner	Buy now
4	69J1211700 Retainer, valve spring	Buy now
4	69J-12117-00 Retainer, valve spring	Buy now
5	69J1211800 Cotter, valve	Buy now
5	69J-12118-00 Cotter, valve	Buy now
6	69J1211900 Seal, valve stem	Buy now
6	69J-12119-00 Seal, valve stem	Buy now
7	69J1215300 Lifter, valve	Buy now
7	69J-12153-00 Lifter, valve	Buy now
8	69J1216800 Pad, adjusting (2.320) UR	Buy now

Valve




Ref	Part	
8	69J1216810 Pad, adjusting (2.340) UR	Buy now
8	69J1216820 Pad, adjusting (2.360) UR	Buy now
8	69J1216830 Pad, adjusting (2.380) UR	Buy now
8	69J1216840 Pad, adjusting (2.400) UR	Buy now
8	69J1216850 Pad, adjusting (2.420) UR	Buy now
8	69J1216860 Pad, adjusting (2.440) UR	Buy now
8	69J1216870 Pad, adjusting (2.460) UR	Buy now
8	69J1216880 Pad, adjusting (2.480) UR	Buy now
8	69J1216890 Pad, adjusting (2.500) UR	Buy now
8	69J12168A0 Pad, adjusting (2.520) UR	Buy now
8	69J12168B0 Pad, adjusting (2.540) UR	Buy now
8	69J12168C0 Pad, adjusting (2.560) UR	Buy now
8	69J12168D0 Pad, adjusting (2.580) UR	Buy now
8	69J12168E0 Pad, adjusting (2.600) UR	Buy now
8	69J12168F0 Pad, adjusting (2.620) UR	Buy now

Valve




Ref	Part	
8	69J12168G0 Pad, adjusting (2.640) UR	Buy now
8	69J12168H0 Pad Adjusting (2.660) UR	Buy now
8	69J12168J0 Pad, adjusting (2.680) UR	Buy now
8	69J12168K0 Pad, adjusting (2.700) UR	Buy now
8	69J-12168-00 Pad, adjusting (2.320) UR	Buy now
8	69J-12168-10 Pad, adjusting (2.340) UR	Buy now
8	69J-12168-20 Pad, adjusting (2.360) UR	Buy now
8	69J-12168-30 Pad, adjusting (2.380) UR	Buy now
8	69J-12168-40 Pad, adjusting (2.400) UR	Buy now
8	69J-12168-50 Pad, adjusting (2.420) UR	Buy now
8	69J-12168-60 Pad, adjusting (2.440) UR	Buy now
8	69J-12168-70 Pad, adjusting (2.460) UR	Buy now
8	69J-12168-80 Pad, adjusting (2.480) UR	Buy now
8	69J-12168-90 Pad, adjusting (2.500) UR	Buy now
8	69J-12168-A0 Pad, adjusting (2.520) UR	Buy now

Valve




Ref	Part	
8	69J-12168-B0 Pad, adjusting (2.540) UR	Buy now
8	69J-12168-C0 Pad, adjusting (2.560) UR	Buy now
8	69J-12168-D0 Pad, adjusting (2.580) UR	Buy now
8	69J-12168-E0 Pad, adjusting (2.600) UR	Buy now
8	69J-12168-F0 Pad, adjusting (2.620) UR	Buy now
8	69J-12168-G0 Pad, adjusting (2.640) UR	Buy now
8	69J-12168-H0 Pad Adjusting (2.660) UR	Buy now
8	69J-12168-J0 Pad, adjusting (2.680) UR	Buy now
8	69J-12168-K0 Pad, adjusting (2.700) UR	Buy now
8	69J12168L0 Pad, adjusting (2.720) UR	Buy now
8	69J12168M0 Pad, adjusting (2.740) UR	Buy now
8	69J12168N0 Pad, adjusting (2.760) UR	Buy now
8	69J12168P0 Pad Adjusting (2.780) UR	Buy now
8	69J12168R0 Pad, adjusting (2.800) UR	Buy now
8	69J12168S0 Pad, adjusting (2.820) UR	Buy now

Valve



Ref	Part	
8	69J12168T0 Pad Adjusting (2.840) UR	Buy now
8	69J12168U0 Pad, adjusting (2.860) UR	Buy now
8	69J12168V0 Pad, adjusting (2.880) UR	Buy now
8	69J12168W0 Pad, adjusting (2.900) UR	Buy now
8	69J12168X0 Pad, adjusting (2.920) UR	Buy now
8	69J12168Y0 Pad, adjusting (2.940) UR	Buy now
8	69J1216900 Pad, adjusting (2.960) UR	Buy now
8	69J-12168-L0 Pad, adjusting (2.720) UR	Buy now
8	69J-12168-M0 Pad, adjusting (2.740) UR	Buy now
8	69J-12168-N0 Pad, adjusting (2.760) UR	Buy now
8	69J-12168-P0 Pad Adjusting (2.780) UR	Buy now
8	69J-12168-R0 Pad, adjusting (2.800) UR	Buy now
8	69J-12168-S0 Pad, adjusting (2.820) UR	Buy now
8	69J-12168-T0 Pad Adjusting (2.840) UR	Buy now
8	69J-12168-U0 Pad, adjusting (2.860) UR	Buy now


Valve



B6

Ref	Part	
8	69J-12168-V0 Pad, adjusting (2.880) UR	Buy now
8	69J-12168-W0 Pad, adjusting (2.900) UR	Buy now
8	69J-12168-X0 Pad, adjusting (2.920) UR	Buy now
8	69J-12168-Y0 Pad, adjusting (2.940) UR	Buy now
8	69J-12169-00 Pad, adjusting (2.960) UR	Buy now
9	69J1217100 Camshaft 1	Buy now
9	69J-12171-00 Camshaft 1	Buy now
10	69J1218100 Camshaft 2	Buy now
10	69J-12181-00 Camshaft 2	Buy now
11	69J1217200 Camshaft 3	Buy now
11	69J-12172-00 Camshaft 3	Buy now
12	69J1218200 Camshaft 4	Buy now
12	69J-12182-00 Camshaft 4	Buy now
13	94581--99044 Chain	Buy now
13	94581-99044 Chain	Buy now


Valve



B6

Ref	Part	
14	69J1221000 Tensioner assembly, cam chain	Buy now
14	69J-12210-00 Tensioner assembly, cam chain	Buy now
15	69J1223000 Tensioner assembly, cam chain 2	Buy now
15	69J-12230-00 Tensioner assembly, cam chain 2	Buy now
16	97013-06025 Bolt(62y)	Buy now
16	97013-06025 Bolt(62y)	Buy now
17	93605-10108 Pin, dowel (8g8)	Buy now
17	93605-10108 Pin, dowel (8g8)	Buy now
18	69J1153700 Gear, driven	Buy now
18	69J-11537-00 Gear, driven	Buy now
19	9011910M06 Bolt	Buy now
19	90119-10M06 Bolt	Buy now
20	9310238M59 Oil seal	Buy now
20	93102-38M59 Oil seal	Buy now
21	69J4624100 Belt	Buy now

Valve



B6

Ref	Part	
21	69J-46241-00 Belt	Buy now
22	69J1159000 Tensioner assembly	Buy now
22	69J-11590-00 Tensioner assembly	Buy now
23	69J1153600 Gear Drive	Buy now
23	69J-11536-00 Gear Drive	Buy now
24	9011005010 Bolt, hexagon socket head	Buy now
24	90110-05010 Bolt, hexagon socket head	Buy now
25	90280--04008 Key woodruff 604115450000	Buy now
25	90280-04008 Key woodruff 604115450000	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.