



# Yamaha F25AE 2003

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>BOTTOM COWLING</b>	3
<b>BRACKET 1</b>	6
<b>BRACKET 2</b>	10
<b>BRACKET 3</b>	13
<b>CARBURETOR</b>	15
<b>CONTROL</b>	18
<b>CRANKSHAFT. PISTON</b>	21
<b>CYLINDER. CRANKCASE 1</b>	23
<b>CYLINDER. CRANKCASE 2</b>	25
<b>ELECTRICAL 1</b>	27
<b>ELECTRICAL 2</b>	29
<b>ELECTRICAL 3</b>	32
<b>FUEL</b>	33
<b>FUEL TANK</b>	36
<b>GENERATOR</b>	37
<b>INTAKE</b>	40
<b>LOWER CASING. DRIVE 1</b>	42
<b>LOWER CASING. DRIVE 2</b>	46
<b>OIL PAN</b>	48
<b>OIL PUMP</b>	50
<b>POWER TRIM &amp; TILT ASSY</b>	52
<b>REMOTE CONTROL ASSY</b>	57
<b>REMOTE CONTROL ATTACHMENT</b>	62
<b>REMOTE CONTROL BOX</b>	64
<b>REPAIR KIT 1</b>	65
<b>REPAIR KIT 2</b>	67
<b>REPAIR KIT 3</b>	68
<b>STARTER</b>	70
<b>STARTING MOTOR</b>	73
<b>STEERING</b>	74
<b>STEERING GUIDE</b>	77
<b>TOP COWLING</b>	78
<b>UPPER CASING</b>	80
<b>VALVE</b>	81

# Bottom Cowling




Ref	Part	
2	<a href="#">90119-06M08</a> Bolt, with washer	<a href="#">Buy now</a>
3	<a href="#">90480-09M12</a> Grommet (6a0)	<a href="#">Buy now</a>
4	<a href="#">90387-06060</a> Collar (688)	<a href="#">Buy now</a>
5	<a href="#">65W-42717-00</a> Rubber, seal 2	<a href="#">Buy now</a>
6	<a href="#">62Y-42716-00</a> Rubber seal 1	<a href="#">Buy now</a>
8	<a href="#">90109-06M82</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">65W-42725-00</a> Grommet	<a href="#">Buy now</a>
9	<a href="#">65W-42725-21</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">62Y-42727-00</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">65W-42727-00</a> Grommet	<a href="#">Buy now</a>
12	<a href="#">90386-12M37</a> Bushing (6f5)	<a href="#">Buy now</a>
13	<a href="#">90386-12MA2</a> Bush	<a href="#">Buy now</a>
14	<a href="#">90206-12052</a> Washer, wave (666)	<a href="#">Buy now</a>
15	<a href="#">90201-12M07</a> Washer, plate	<a href="#">Buy now</a>
16	<a href="#">65W-42816-03</a> Lever, Clamp	<a href="#">Buy now</a>

# Bottom Cowling




Ref	Part	
17	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
18	<a href="#">6H3-44391-01</a> Nipple, hose	<a href="#">Buy now</a>
19	<a href="#">65W-26326-00</a> Grommet	<a href="#">Buy now</a>
19	<a href="#">65W-26326-10</a> Grommet	<a href="#">Buy now</a>
20	<a href="#">682-42727-00</a> Grommet	<a href="#">Buy now</a>
21	<a href="#">65W-42724-10</a> Grommet <b>FOR FLUSHING KIT</b>	<a href="#">Buy now</a>
21	<a href="#">6H1-42726-20</a> Grommet <b>FOR FLUSHING KIT</b>	<a href="#">Buy now</a>
22	<a href="#">6G1-42725-00</a> Grommet	<a href="#">Buy now</a>
23	<a href="#">65W-42726-00</a> Grommet	<a href="#">Buy now</a>
23	<a href="#">65W-42726-10</a> Grommet	<a href="#">Buy now</a>
24	<a href="#">90465-25M57</a> Clamp(63v)	<a href="#">Buy now</a>
25	<a href="#">65W-42741-01</a> Apron	<a href="#">Buy now</a>
26	<a href="#">97095-06014</a> Bolt(gj3)	<a href="#">Buy now</a>
27	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
28	<a href="#">90109-06M81</a> Bolt	<a href="#">Buy now</a>

# Bottom Cowling



Ref	Part	
35	<a href="#">90109-06M86</a> Bolt <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
30	<a href="#">66T-43144-00</a> Hook, spring	<a href="#">Buy now</a>
31	<a href="#">90506-16M34</a> Spring, tension(64d)	<a href="#">Buy now</a>
32	<a href="#">68T-12572-00</a> Adapter <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
33	<a href="#">69W-12535-00</a> Plate <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
34	<a href="#">90167-06002</a> Screw, tapping <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
36	<a href="#">90445-11M82</a> Hose <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
37	<a href="#">90465-11M10</a> Clamp <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
38	<a href="#">6R3-12580-00</a> Joint assembly <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
39	<a href="#">62Y-82377-00</a> Label	<a href="#">Buy now</a>
40	<a href="#">6G8-13444-51</a> Mark	<a href="#">Buy now</a>
41	<a href="#">6A1-28176-00</a> Label Caution	<a href="#">Buy now</a>
42	<a href="#">6E3-8257H-00</a> Plate Mark	<a href="#">Buy now</a>

## Bracket 1




65W1010-2210

E6

Ref	Part	
2	<a href="#">90149-14M12</a> Screw(6h4)	<a href="#">Buy now</a>
4	<a href="#">648-43114-01</a> Pad, transom clamp	<a href="#">Buy now</a>
5	<a href="#">90243-04007</a> Pin (663)	<a href="#">Buy now</a>
11	<a href="#">90387-08M29</a> Collar	<a href="#">Buy now</a>
12	<a href="#">90101-08M76</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">95380-08600</a> Nut (661)	<a href="#">Buy now</a>
14	<a href="#">92990-08100</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
16	<a href="#">93700-06M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
17	<a href="#">63D-43131-01</a> Bolt, clamp bracket	<a href="#">Buy now</a>
18	<a href="#">90386-22M15</a> Bushing (688)	<a href="#">Buy now</a>
19	<a href="#">90201-22M03</a> Washer, plate(64j)	<a href="#">Buy now</a>
20	<a href="#">6J8-43113-01</a> Plate, clamp bracket	<a href="#">Buy now</a>
21	<a href="#">90185-22M11</a> Nut, self-locking	<a href="#">Buy now</a>
22	<a href="#">6G5-43145-01</a> Cap, clamp bracket	<a href="#">Buy now</a>
23	<a href="#">65W-43627-01</a> Stopper	<a href="#">Buy now</a>

# Bracket 1




65W1010-2210

E6

Ref	Part	
24	<a href="#">90386-12M98</a> Bush	<a href="#">Buy now</a>
25	<a href="#">90206-14M23</a> Washer, Wave	<a href="#">Buy now</a>
26	<a href="#">90109-08M87</a> Bolt	<a href="#">Buy now</a>
27	<a href="#">90387-12M04</a> Collar	<a href="#">Buy now</a>
28	<a href="#">90249-12M39</a> Pin	<a href="#">Buy now</a>
29	<a href="#">90386-12MA0</a> Bush, solid	<a href="#">Buy now</a>
30	<a href="#">90249-12M34</a> Pin	<a href="#">Buy now</a>
31	<a href="#">93430-10M00</a> Circlip	<a href="#">Buy now</a>
32	<a href="#">682-43318-01</a> Cover	<a href="#">Buy now</a>
33	<a href="#">65W-43630-11</a> Tilt lever assembly	<a href="#">Buy now</a>
34	<a href="#">90386-07MA2</a> Bush	<a href="#">Buy now</a>
35	<a href="#">90387-07M05</a> Collar	<a href="#">Buy now</a>
36	<a href="#">90249-10M31</a> Pin	<a href="#">Buy now</a>
37	<a href="#">90386-10M99</a> Bush	<a href="#">Buy now</a>
38	<a href="#">99080-08600</a> Circlip	<a href="#">Buy now</a>


# Bracket 1



E6

Ref	Part	
39	<a href="#">66T-43350-02</a> Receiver assembly	<a href="#">Buy now</a>
40	<a href="#">90506-20M37</a> Spring, tension	<a href="#">Buy now</a>
41	<a href="#">66T-43631-11</a> Lever, tilt	<a href="#">Buy now</a>
42	<a href="#">90157-05014</a> Screw, pan head	<a href="#">Buy now</a>
43	<a href="#">65W-43616-00</a> Rod, tilt lock	<a href="#">Buy now</a>
44	<a href="#">65W-43614-01</a> Plate, tilt lock	<a href="#">Buy now</a>
45	<a href="#">65W-43615-01</a> Plate, tilt lock	<a href="#">Buy now</a>
46	<a href="#">65W-43613-00</a> Arm, tilt lock	<a href="#">Buy now</a>
47	<a href="#">90249-07M32</a> Pin	<a href="#">Buy now</a>
48	<a href="#">90387-07M29</a> Collar	<a href="#">Buy now</a>
49	<a href="#">90249-07M33</a> Pin	<a href="#">Buy now</a>
50	<a href="#">90506-30M00</a> Spring, tension (676)	<a href="#">Buy now</a>
51	<a href="#">91490-20015</a> Pin, cotter (648)	<a href="#">Buy now</a>
52	<a href="#">65W-43160-00</a> Tilt rod assembly	<a href="#">Buy now</a>
53	<a href="#">90101-10M58</a> Bolt	<a href="#">Buy now</a>

## Bracket 1




65W1010-2210

E6

Ref	Part	
54	<a href="#">92995-10600</a> Washer, plate	<a href="#">Buy now</a>
55	<a href="#">90201-12426</a> Washe, plate(663)	<a href="#">Buy now</a>
56	<a href="#">95380-10600</a> Nut(624)	<a href="#">Buy now</a>

## Bracket 2




 65W1010-2220

**F2**

Ref	Part	
3	<a href="#">65W-43192-00</a> Knob, stopper	<a href="#">Buy now</a>
4	<a href="#">65W-43191-00</a> Shaft, stopper	<a href="#">Buy now</a>
5	<a href="#">91690-30018</a> 926-51502-00 pin, spring (700)	<a href="#">Buy now</a>
6	<a href="#">90386-14MA1</a> Bush	<a href="#">Buy now</a>
8	<a href="#">93700-06M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
9	<a href="#">63D-43131-01</a> Bolt, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">90386-22M15</a> Bushing (688)	<a href="#">Buy now</a>
11	<a href="#">90201-22M03</a> Washer, plate(64j)	<a href="#">Buy now</a>
12	<a href="#">90185-22M11</a> Nut, self-locking	<a href="#">Buy now</a>
13	<a href="#">6G5-43145-01</a> Cap, clamp bracket	<a href="#">Buy now</a>
14	<a href="#">90386-12MA0</a> Bush, solid	<a href="#">Buy now</a>
15	<a href="#">90386-12M98</a> Bush	<a href="#">Buy now</a>
16	<a href="#">90249-12M38</a> Pin	<a href="#">Buy now</a>
17	<a href="#">93430-10M00</a> Circlip	<a href="#">Buy now</a>
18	<a href="#">90465-13M11</a> Clamp (6e5)	<a href="#">Buy now</a>

## Bracket 2




 65W1010-2220

**F2**

Ref	Part	
19	<a href="#">65W-45251-00</a> Anode	<a href="#">Buy now</a>
20	<a href="#">90101-06020</a> Bolt	<a href="#">Buy now</a>
21	<a href="#">6H1-82148-00</a> Wire, lead	<a href="#">Buy now</a>
22	<a href="#">6U0-82127-00</a> Wire, lead 5	<a href="#">Buy now</a>
23	<a href="#">97095-06014</a> Bolt(gj3)	<a href="#">Buy now</a>
24	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
25	<a href="#">97080-08016</a> Bolt	<a href="#">Buy now</a>
26	<a href="#">90201-08M00</a> Washer, plate(6e0)	<a href="#">Buy now</a>
27	<a href="#">90386-18M44</a> Bushing (6g5)	<a href="#">Buy now</a>
28	<a href="#">90386-18MA0</a> Bush	<a href="#">Buy now</a>
29	<a href="#">90249-18M35</a> Pin, lower shock mount	<a href="#">Buy now</a>
30	<a href="#">90110-10M02</a> Bolt, hexagon socket head	<a href="#">Buy now</a>
31	<a href="#">92995-10600</a> Washer, plate	<a href="#">Buy now</a>
32	<a href="#">90185-10M13</a> Nut, self-locking	<a href="#">Buy now</a>
33	<a href="#">90101-12M65</a> Bolt	<a href="#">Buy now</a>

## Bracket 2




 65W1010-2220

**F2**

Ref	Part	
34	<a href="#">92995-12200</a> Ybs66-12 washer,plain	<a href="#">Buy now</a>
35	<a href="#">90201-12426</a> Washe, plate(663)	<a href="#">Buy now</a>
36	<a href="#">95380-12600</a> Nut (707)	<a href="#">Buy now</a>


## Bracket 3



**F4**

Ref	Part	
1	<a href="#">648-42528-00</a> Plate, friction	<a href="#">Buy now</a>
2	<a href="#">65W-43373-00</a> Seal, damper	<a href="#">Buy now</a>
3	<a href="#">90105-08M76</a> Bolt, washer based	<a href="#">Buy now</a>
4	<a href="#">90185-10051</a> Nut, self-locking	<a href="#">Buy now</a>
5	<a href="#">90116-10M28</a> Bolt, stud	<a href="#">Buy now</a>
7	<a href="#">90209-52M00</a> Washer (676)	<a href="#">Buy now</a>
8	<a href="#">90386-52M02</a> Bushing (676)	<a href="#">Buy now</a>
9	<a href="#">90386-44M03</a> Bushing (676)	<a href="#">Buy now</a>
10	<a href="#">93210-43M10</a> O-ring	<a href="#">Buy now</a>
11	<a href="#">90386-44M99</a> Bush	<a href="#">Buy now</a>
12	<a href="#">90185-08045</a> Nut, self-locking	<a href="#">Buy now</a>
13	<a href="#">92995-08200</a> Ybs66-8 washer, plain	<a href="#">Buy now</a>
14	<a href="#">90101-08M86</a> Bolt (6h4)	<a href="#">Buy now</a>
16	<a href="#">66T-44526-30</a> Plate	<a href="#">Buy now</a>
17	<a href="#">97075-08030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>


## Bracket 3



Ref	Part	
18	<a href="#">92995-08100</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
20	<a href="#">65W-44555-00</a> Mount damper, lower side	<a href="#">Buy now</a>
21	<a href="#">65W-44575-01</a> Damper, lower mount rubber	<a href="#">Buy now</a>
22	<a href="#">97075-10080</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
23	<a href="#">92995-10600</a> Washer, plate	<a href="#">Buy now</a>
24	<a href="#">90119-10M14</a> Bolt, with washer	<a href="#">Buy now</a>
25	<a href="#">90179-10M33</a> Nut	<a href="#">Buy now</a>
26	<a href="#">65W-82127-10</a> Wire, lead 2	<a href="#">Buy now</a>
27	<a href="#">65W-48511-00</a> Hook, steering	<a href="#">Buy now</a>
28	<a href="#">90201-10120</a> Washer, plate	<a href="#">Buy now</a>

F4

# Carburetor




65W0300-0070

B5

Ref	Part	
1	<a href="#">65W-14901-00</a> Carburetor assembly 1 <b>FOR STD</b>	<a href="#">Buy now</a>
1	<a href="#">65W-14901-10</a> Carburetor assembly 1 <b>FOR STD</b>	<a href="#">Buy now</a>
1	<a href="#">65W-14901-31</a> Carburetor assembly 1 <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>
2	<a href="#">98580-04006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
3	<a href="#">65W-14572-00</a> Plate	<a href="#">Buy now</a>
4	<a href="#">65W-14126-00</a> Gasket <b>FOR STD</b>	<a href="#">Buy now</a>
4	<a href="#">65W-14126-10</a> Gasket <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>
5	<a href="#">97803-04010</a> Screw, pan head (e56)	<a href="#">Buy now</a>
6	<a href="#">65W-14948-07</a> Jet (#50) <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>
6	<a href="#">676-14948-07</a> Jet (#50) <b>FOR STD</b>	<a href="#">Buy now</a>
7	<a href="#">679-14966-00</a> Rubber cap	<a href="#">Buy now</a>
8	<a href="#">90501-10326</a> Spring coil(663)(carb)	<a href="#">Buy now</a>
9	<a href="#">63V-14523-00</a> Screw, stop	<a href="#">Buy now</a>
10	<a href="#">65W-14947-00</a> Jet Needle <b>FOR STD</b>	<a href="#">Buy now</a>
10	<a href="#">65W-14947-20</a> Jet, Needle <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>

# Carburetor




65W0300-0070

B5

Ref	Part	
11	<a href="#">65W-14943-28</a> Jet, Main (#105) *ECM- "F25A ONLY"	<a href="#">Buy now</a>
11	<a href="#">65W-14943-29</a> Jet, main (#112) FOR STD	<a href="#">Buy now</a>
12	<a href="#">63V-14985-00</a> Float	<a href="#">Buy now</a>
13	<a href="#">6G1-14546-00</a> Valve, needle	<a href="#">Buy now</a>
14	<a href="#">676-14186-00</a> Pin, valve	<a href="#">Buy now</a>
15	<a href="#">663-14159-00</a> Clip	<a href="#">Buy now</a>
16	<a href="#">98580-04008</a> Screw, pan head (713)	<a href="#">Buy now</a>
17	<a href="#">6H4-14548-00</a> Pin, float arm	<a href="#">Buy now</a>
18	<a href="#">65W-14373-00</a> Cover, plunger cap	<a href="#">Buy now</a>
19	<a href="#">65W-14379-00</a> Rod, starter	<a href="#">Buy now</a>
20	<a href="#">65W-1414F-00</a> Jet, pilot (# 52) FOR STD	<a href="#">Buy now</a>
21	<a href="#">65W-14147-00</a> O-ring FOR STD	<a href="#">Buy now</a>
22	<a href="#">65W-14335-00</a> Spring, plunger	<a href="#">Buy now</a>
23	<a href="#">65W-14371-00</a> Plunger, starter	<a href="#">Buy now</a>
24	<a href="#">65W-14384-00</a> Gasket, float chamber	<a href="#">Buy now</a>


# Carburetor



65W0300-0070


**B5**

Ref	Part	
25	<a href="#">65W-14980-00</a> Body, float chamber <b>FOR STD</b>	<a href="#">Buy now</a>
25	<a href="#">65W-14980-20</a> Body, float chamber <b>FOR STD</b>	<a href="#">Buy now</a>
26	<a href="#">65W-14398-00</a> Washer	<a href="#">Buy now</a>
27	<a href="#">65W-14992-00</a> Screw, drain	<a href="#">Buy now</a>
28	<a href="#">97980-04114</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
29	<a href="#">65W-14380-00</a> Prime starter assembly <b>FOR STD</b>	<a href="#">Buy now</a>
29	<a href="#">65W-14380-20</a> Prime starter assembly <b>FOR STD</b>	<a href="#">Buy now</a>
30	<a href="#">65W-14346-00</a> Plate	<a href="#">Buy now</a>
31	<a href="#">65W-14923-10</a> Screw, pilot <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>
32	<a href="#">67C-14397-00</a> O-ring <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>
33	<a href="#">67C-14555-00</a> Spring <b>*ECM—"F25A ONLY"</b>	<a href="#">Buy now</a>




E3

Ref	Part	
1	<a href="#">65W-41638-00</a> Pulley	<a href="#">Buy now</a>
2	<a href="#">65W-41283-00</a> Lever, free accel.	<a href="#">Buy now</a>
3	<a href="#">661-41262-02</a> Joint, choke lever	<a href="#">Buy now</a>
4	<a href="#">90387-06064</a> Collar	<a href="#">Buy now</a>
5	<a href="#">65W-41211-00</a> Link Accel.	<a href="#">Buy now</a>
6	<a href="#">65W-14497-01</a> Stay, Throttle Wire	<a href="#">Buy now</a>
7	<a href="#">90201-06M31</a> Washer (6a0)	<a href="#">Buy now</a>
8	<a href="#">97095-06055</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
9	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">97095-06010</a> Bolt	<a href="#">Buy now</a>
11	<a href="#">65W-44121-00</a> Lever, shift rod	<a href="#">Buy now</a>
12	<a href="#">65W-44122-00</a> Bushing, Shift Rod Lever	<a href="#">Buy now</a>
13	<a href="#">90254-03M05</a> Pin, spring	<a href="#">Buy now</a>
14	<a href="#">6F5-41662-00</a> Bracket 2	<a href="#">Buy now</a>
15	<a href="#">90109-06M81</a> Bolt	<a href="#">Buy now</a>



E3


Ref	Part	
16	<a href="#">65W-44116-00</a> Spring	<a href="#">Buy now</a>
17	<a href="#">90109-06M86</a> Bolt	<a href="#">Buy now</a>
18	<a href="#">65W-44143-00</a> Rod, shift S	<a href="#">Buy now</a>
18	<a href="#">65W-44143-10</a> Rod, shift L	<a href="#">Buy now</a>
19	<a href="#">90170-06015</a> Connector, shift rod	<a href="#">Buy now</a>
20	<a href="#">95380-06700</a> Nut	<a href="#">Buy now</a>
21	<a href="#">90468-18008</a> Clip 620436610000	<a href="#">Buy now</a>
22	<a href="#">65W-44142-00</a> Joint	<a href="#">Buy now</a>
24	<a href="#">65W-44125-00</a> Lever, shift rod	<a href="#">Buy now</a>
25	<a href="#">90387-06M29</a> Coller (6a0)	<a href="#">Buy now</a>
27	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
29	<a href="#">65W-44192-00</a> Joint, rod 1	<a href="#">Buy now</a>
30	<a href="#">90201-05M06</a> Washer, plate(61u)	<a href="#">Buy now</a>
31	<a href="#">90468-10005</a> Pin, hair 6264123500	<a href="#">Buy now</a>
33	<a href="#">663-48344-00</a> Cable end, remote control	<a href="#">Buy now</a>



Ref	Part	
35	<a href="#">6H3-48538-00</a> Clamp, cable	<a href="#">Buy now</a>

E3


# Crankshaft. Piston



A7

Ref	Part	
1	<a href="#">93102-43M42</a> Oil seal(62y)	<a href="#">Buy now</a>
2	<a href="#">93102-35M47</a> Oil seal(62y)	<a href="#">Buy now</a>
3	<a href="#">65W-11411-01</a> Crankshaft	<a href="#">Buy now</a>
4	<a href="#">62Y-11416-00</a> Plane bearing, crankshaft 1 <b>UR BROWN</b>	<a href="#">Buy now</a>
4	<a href="#">62Y-11416-10</a> Plane bearing, crankshaft 1 <b>UR BLACK</b>	<a href="#">Buy now</a>
4	<a href="#">62Y-11416-20</a> Plane bearing, crankshaft 1 <b>UR BLUE</b>	<a href="#">Buy now</a>
5	<a href="#">67C-11650-00</a> Connecting rod assembly	<a href="#">Buy now</a>
6	<a href="#">62Y-11654-00</a> Bolt, connecting rod	<a href="#">Buy now</a>
7	<a href="#">62Y-11656-00</a> Plane bearing, connecting rod <b>UR BROWN</b>	<a href="#">Buy now</a>
7	<a href="#">62Y-11656-10</a> Plane bearing, connecting rod <b>UR BLACK</b>	<a href="#">Buy now</a>
7	<a href="#">62Y-11656-20</a> Plane bearing, connecting rod <b>UR BLUE</b>	<a href="#">Buy now</a>
8	<a href="#">65W-11631-00-96</a> Piston (std)	<a href="#">Buy now</a>
8	<a href="#">65W-11635-00</a> Piston (0.25mm o/s) <b>AP</b>	<a href="#">Buy now</a>
8	<a href="#">65W-11636-00</a> Piston (0.50mm o/s) <b>AP</b>	<a href="#">Buy now</a>
9	<a href="#">67C-11603-00</a> Piston ring set (std)	<a href="#">Buy now</a>

## Crankshaft. Piston




65W0010-0031

A7

Ref	Part	
9	<a href="#">67C-11604-00</a> Piston ring set (0.25mm o/s) AP	<a href="#">Buy now</a>
9	<a href="#">67C-11605-00</a> Piston ring set (0.50mm o/s) AP	<a href="#">Buy now</a>
10	<a href="#">62Y-11633-00</a> Pin, piston	<a href="#">Buy now</a>
11	<a href="#">93450-17129</a> Circlip(1ar)	<a href="#">Buy now</a>
12	<a href="#">65W-11665-00</a> Con-rod assembly, balance	<a href="#">Buy now</a>
13	<a href="#">65W-11642-11</a> Piston, Balance	<a href="#">Buy now</a>
14	<a href="#">90170-20137</a> Nut, hexagon(663)	<a href="#">Buy now</a>


# Cylinder. Crankcase 1



**A5**

Ref	Part	
3	<a href="#">99530-08012</a> Pin, dowel(6g8)	<a href="#">Buy now</a>
4	<a href="#">90119-08M01</a> Bolt, with washer(62y)	<a href="#">Buy now</a>
5	<a href="#">90119-06MA5</a> Bolt, with washer	<a href="#">Buy now</a>
6	<a href="#">65W-15121-00</a> Crankcase 2	<a href="#">Buy now</a>
7	<a href="#">65W-15663-00</a> Seal	<a href="#">Buy now</a>
8	<a href="#">65W-12228-00</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">65W-11168-01</a> Cover Breather	<a href="#">Buy now</a>
10	<a href="#">65W-11169-01</a> Gasket, breather cover	<a href="#">Buy now</a>
12	<a href="#">65W-11119-00</a> Hanger Engine	<a href="#">Buy now</a>
13	<a href="#">90105-08M87</a> Bolt, washer based	<a href="#">Buy now</a>
14	<a href="#">90340-14M06</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
15	<a href="#">90430-14115</a> Gasket (663)	<a href="#">Buy now</a>
16	<a href="#">65W-11351-10</a> Gasket, cylinder	<a href="#">Buy now</a>
17	<a href="#">6G8-12411-02</a> Thermostat	<a href="#">Buy now</a>
19	<a href="#">62Y-12414-00</a> Gasket, cover	<a href="#">Buy now</a>


# Cylinder. Crankcase 1



Ref	Part	
20	<a href="#">65W-13286-00</a> Cleaner	<a href="#">Buy now</a>
21	<a href="#">90401-20M00</a> Bolt, union(62y)	<a href="#">Buy now</a>
22	<a href="#">5GH-13440-00</a> Element assembly, oil cleaner	<a href="#">Buy now</a>
24	<a href="#">62Y-11372-01</a> Nipple, hose <b>FOR FLUSHING KIT</b>	<a href="#">Buy now</a>
25	<a href="#">65W-41114-00</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
27	<a href="#">90445-09068</a> Hose (I420)	<a href="#">Buy now</a>
28	<a href="#">688-24378-00</a> Pipe, joint	<a href="#">Buy now</a>
29	<a href="#">90445-09095</a> Hose (L260)	<a href="#">Buy now</a>
30	<a href="#">90445-09105</a> Hose (I420)	<a href="#">Buy now</a>
31	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
32	<a href="#">90467-08004</a> Clip, pipe 6162435600	<a href="#">Buy now</a>

A5


# Cylinder. Crankcase 2



**B1**

Ref	Part	
3	<a href="#">62Y-11133-10</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">93450-09M01</a> Circlip (6g8)	<a href="#">Buy now</a>
5	<a href="#">62Y-11325-00</a> Anode	<a href="#">Buy now</a>
6	<a href="#">66M-11328-00</a> Grommet, anode	<a href="#">Buy now</a>
8	<a href="#">66M-12535-00</a> Plate	<a href="#">Buy now</a>
9	<a href="#">97095-05012</a> Bolt, hexagon	<a href="#">Buy now</a>
10	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
12	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">90430-06014</a> Gasket 256113960000	<a href="#">Buy now</a>
14	<a href="#">90109-06M65</a> Bolt(62y)	<a href="#">Buy now</a>
15	<a href="#">65W-11181-20</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
16	<a href="#">99530-08012</a> Pin, dowel(6g8)	<a href="#">Buy now</a>
17	<a href="#">90119-09M00</a> Bolt, with washer(62y)	<a href="#">Buy now</a>
18	<a href="#">90119-06MA3</a> Bolt, with washer	<a href="#">Buy now</a>


## Cylinder. Crankcase 2



Ref	Part	
20	<a href="#">65W-11356-00</a> Seal, cylinder 2	<a href="#">Buy now</a>
21	<a href="#">97595-06520</a> Bolt(7u8)	<a href="#">Buy now</a>
22	<a href="#">97095-08014</a> Bolt, hexagon deep recess *ECM—"F25A ONLY"	<a href="#">Buy now</a>
23	<a href="#">90430-08143</a> Gasket (256-11198-00) *ECM—"F25A ONLY"	<a href="#">Buy now</a>
24	<a href="#">6G8-15363-00</a> Plug, oil	<a href="#">Buy now</a>
25	<a href="#">93210-24M79</a> O-ring	<a href="#">Buy now</a>
26	<a href="#">62Y-12138-60</a> Mark Caution	<a href="#">Buy now</a>
27	<a href="#">94701-00375</a> Plug, spark (dpr6ea-9)(62y)	<a href="#">Buy now</a>

B1


# Electrical 1



65W2300-3120

**C7**

Ref	Part	
1	<a href="#">65W-85540-20</a> C.d.i. unit assembly	<a href="#">Buy now</a>
2	<a href="#">65W-8252V-00</a> Screw, special	<a href="#">Buy now</a>
3	<a href="#">65W-85542-00</a> Bracket	<a href="#">Buy now</a>
4	<a href="#">65W-85547-00</a> Damper	<a href="#">Buy now</a>
5	<a href="#">65W-86129-20</a> Collar	<a href="#">Buy now</a>
6	<a href="#">65W-8252V-10</a> Screw, special	<a href="#">Buy now</a>
7	<a href="#">65W-85570-00</a> Ignition coil assembly	<a href="#">Buy now</a>
8	<a href="#">6G8-82370-30</a> Plug cap assembly	<a href="#">Buy now</a>
9	<a href="#">90480-25161</a> Grommet(656)	<a href="#">Buy now</a>
10	<a href="#">97095-06030</a> Bolt(jf7)	<a href="#">Buy now</a>
11	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">90464-07M05</a> Clamp (6g5)	<a href="#">Buy now</a>
13	<a href="#">65W-81941-00</a> Starter relay assembly	<a href="#">Buy now</a>
14	<a href="#">65W-8191C-00</a> Collar	<a href="#">Buy now</a>
15	<a href="#">65W-81922-00</a> Grommet	<a href="#">Buy now</a>




65W2300-3120

Ref	Part	
16	<a href="#">65W-8182A-00</a> Nut	<a href="#">Buy now</a>
17	<a href="#">65W-8182B-00</a> Nut, special	<a href="#">Buy now</a>
18	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
18	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
20	<a href="#">65W-82117-00</a> Wire, lead	<a href="#">Buy now</a>
21	<a href="#">6G5-82119-10</a> Cover, lead wire	<a href="#">Buy now</a>
22	<a href="#">65W-81960-00</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
23	<a href="#">6K3-83557-00</a> Tube	<a href="#">Buy now</a>
24	<a href="#">97095-06040</a> Bolt (682)	<a href="#">Buy now</a>
26	<a href="#">65W-82504-00</a> Oil pressure switch assembly	<a href="#">Buy now</a>
27	<a href="#">65W-82127-00</a> Wire, lead 2	<a href="#">Buy now</a>
28	<a href="#">65W-8339X-00</a> Clamp, cord	<a href="#">Buy now</a>

C7


## Electrical 2



D2

Ref	Part	
1	<a href="#">65W-85790-00</a> Thermosensor assembly	<a href="#">Buy now</a>
2	<a href="#">65W-85757-00</a> Retainer	<a href="#">Buy now</a>
3	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
4	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">65W-82590-10</a> Wire Harness assembly (7P)	<a href="#">Buy now</a>
6	<a href="#">65W-82590-30</a> Wire Harness assembly	<a href="#">Buy now</a>
6	<a href="#">65W-82590-40</a> Wire Harness assembly	<a href="#">Buy now</a>
7	<a href="#">90465-08M08</a> Clamp (6e5)	<a href="#">Buy now</a>
8	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
11	<a href="#">90465-06M88</a> Clamp	<a href="#">Buy now</a>
12	<a href="#">6N7-83557-00</a> Tube I.DIA.) 22MM	<a href="#">Buy now</a>
15	<a href="#">97095-05016</a> Bolt(6a1)	<a href="#">Buy now</a>
16	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">65W-82105-00</a> Battery cable	<a href="#">Buy now</a>


## Electrical 2



D2


Ref	Part	
18	<a href="#">6G8-82150-00</a> Fuse holder assembly	<a href="#">Buy now</a>
19	<a href="#">663-82151-00</a> Fuse	<a href="#">Buy now</a>
20	<a href="#">6G5-82152-00</a> Holder, fuse	<a href="#">Buy now</a>
21	<a href="#">6H1-82563-10</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
22	<a href="#">6E5-82587-00</a> Gasket	<a href="#">Buy now</a>
23	<a href="#">62Y-83614-00</a> Bracket	<a href="#">Buy now</a>
24	<a href="#">90109-06M86</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">61A-81950-00</a> Relay assembly	<a href="#">Buy now</a>
26	<a href="#">97075-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
28	<a href="#">65W-81948-00</a> Bracket	<a href="#">Buy now</a>
29	<a href="#">6A0-82317-00</a> Damper, ignition coil	<a href="#">Buy now</a>
30	<a href="#">624-42542-00</a> Collar	<a href="#">Buy now</a>
31	<a href="#">95895-06030</a> Bolt, flange deep recess	<a href="#">Buy now</a>
32	<a href="#">90201-12M16</a> Washer, plate (679)	<a href="#">Buy now</a>
33	<a href="#">65W-81949-00</a> Wire Lead	<a href="#">Buy now</a>

## Electrical 2



Ref	Part	
34	<a href="#">682-82119-01</a> Cover, lead wire	<a href="#">Buy now</a>
35	<a href="#">97575-06516</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>


D2



65W2300-3140

D4


Ref	Part	
1	<a href="#">65W-82575-01</a> Engine stop switch assembly	<a href="#">Buy now</a>
2	<a href="#">682-82556-00</a> Lanyard, stop switch	<a href="#">Buy now</a>
3	<a href="#">689-8257Y-00</a> Cap	<a href="#">Buy now</a>
4	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
5	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>



C1

Ref	Part	
1	<a href="#">62Y-24410-03</a> Fuel pump assembly	<a href="#">Buy now</a>
2	<a href="#">62Y-24413-01</a> Body 4	<a href="#">Buy now</a>
3	<a href="#">62Y-24421-01</a> Valve, check	<a href="#">Buy now</a>
4	<a href="#">62Y-24411-02</a> Diaphragm	<a href="#">Buy now</a>
5	<a href="#">62Y-24423-00</a> Spring, diaphragm	<a href="#">Buy now</a>
6	<a href="#">62Y-13131-01</a> Plunger	<a href="#">Buy now</a>
7	<a href="#">62Y-24454-00</a> Spring	<a href="#">Buy now</a>
8	<a href="#">62Y-24444-01</a> Screw	<a href="#">Buy now</a>
9	<a href="#">62Y-24471-00</a> Diaphragm	<a href="#">Buy now</a>
10	<a href="#">6A0-14325-00</a> Screw, pan head	<a href="#">Buy now</a>
11	<a href="#">95380-03600</a> Nut (6g8)	<a href="#">Buy now</a>
12	<a href="#">62Y-24452-00</a> Packing	<a href="#">Buy now</a>
13	<a href="#">95380-05600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
14	<a href="#">62Y-24374-01</a> Pin	<a href="#">Buy now</a>
15	<a href="#">62Y-24422-00</a> Plate	<a href="#">Buy now</a>

## Fuel




65W2300-3090

C1

Ref	Part	
16	<a href="#">93210-24M79</a> O-ring	<a href="#">Buy now</a>
17	<a href="#">65W-24474-00</a> Cover	<a href="#">Buy now</a>
18	<a href="#">97095-06030</a> Bolt(jf7)	<a href="#">Buy now</a>
19	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
20	<a href="#">65W-24251-00</a> Strainer 1	<a href="#">Buy now</a>
21	<a href="#">65W-24481-00</a> Plug	<a href="#">Buy now</a>
22	<a href="#">90445-10M33</a> Hose (l1040)	<a href="#">Buy now</a>
23	<a href="#">90445-10M03</a> Hose (l400)	<a href="#">Buy now</a>
24	<a href="#">90445-10M43</a> Hose (l400)	<a href="#">Buy now</a>
25	<a href="#">6G1-24304-02</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
26	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
28	<a href="#">90467-10M04</a> Clip, pipe 1 (6e9)	<a href="#">Buy now</a>
29	<a href="#">90467-09M03</a> Clip(6k8)	<a href="#">Buy now</a>
30	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
31	<a href="#">90465-13M18</a> Clamp	<a href="#">Buy now</a>

## Fuel




65W2300-3090

Ref	Part	
32	<u><a href="#">62Y-28100-00</a></u> Tool kit	<a href="#">Buy now</a>
33	<u><a href="#">65W-28199-77-A0</a></u> O/m f20ae/aet/25amh/ae/aet '03 UR (E,F,S)	<a href="#">Buy now</a>
33	<u><a href="#">65W-28199-77-B0</a></u> O/m f20ae/aet/25amh/ae/aet '03 UR (D,NL,I)	<a href="#">Buy now</a>
34	<u><a href="#">65W-28199-87-A0</a></u> O/m f20ae/f25ae/f20aet/ '03 UR (DK,P,GR)	<a href="#">Buy now</a>
34	<u><a href="#">65W-28199-87-B0</a></u> O/m f20ae/f25ae/f20aet/ '03 UR (N,S,SS)	<a href="#">Buy now</a>

C1


# Fuel Tank



Ref	Part	
1	<a href="#">6YK-24201-01</a> Fuel Tank assembly (25L) AP PLASTIC, 25L,	<a href="#">Buy now</a>
1	<a href="#">6YK-24201-10</a> Fuel Tank assembly (25L) AP *ECM—"F25A ONLY"	<a href="#">Buy now</a>
2	<a href="#">6YL-24268-01</a> Gasket, fuel meter	<a href="#">Buy now</a>
3	<a href="#">6YK-24610-00</a> Cap assembly WITH INDICATOR	<a href="#">Buy now</a>
3	<a href="#">6YK-24610-10</a> Cap assembly *ECM—"F25A-ONLY"	<a href="#">Buy now</a>
4	<a href="#">6YL-24641-00</a> Gasket, cap 1	<a href="#">Buy now</a>
5	<a href="#">6YK-24260-01</a> Fuel meter assembly	<a href="#">Buy now</a>
6	<a href="#">90157-05M16</a> Screw, pan head	<a href="#">Buy now</a>
7	<a href="#">6YL-24329-00</a> Seal	<a href="#">Buy now</a>
8	<a href="#">6YL-24306-52</a> Fuel pipe comp. 1 AP	<a href="#">Buy now</a>

B4


# Generator



**C5**

Ref	Part	
1	<a href="#">65W-85550-01</a> Rotor assembly	<a href="#">Buy now</a>
1	<a href="#">65W-85550-11</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">65W-85510-00</a> Stator assembly	<a href="#">Buy now</a>
2	<a href="#">65W-85510-10</a> Stator assembly	<a href="#">Buy now</a>
3	<a href="#">65W-85580-00</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">65W-11545-00</a> Key, woodruff	<a href="#">Buy now</a>
5	<a href="#">90201-21M18</a> Washer, plate (663)	<a href="#">Buy now</a>
6	<a href="#">90170-20137</a> Nut, hexagon(663)	<a href="#">Buy now</a>
7	<a href="#">91380-05025</a> Bolt, hex. socket head	<a href="#">Buy now</a>
7	<a href="#">91380-05030</a> Bolt,socket	<a href="#">Buy now</a>
8	<a href="#">97095-05016</a> Bolt(6a1)	<a href="#">Buy now</a>
9	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">90446-10M82</a> Hose	<a href="#">Buy now</a>
11	<a href="#">65W-85410-01</a> Emergency signal light assembly	<a href="#">Buy now</a>
12	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>


# Generator



**C5**

Ref	Part	
13	<a href="#">65W-81337-00</a> Cover Flywheel	<a href="#">Buy now</a>
14	<a href="#">65W-81639-00</a> Cover	<a href="#">Buy now</a>
15	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
16	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">6G1-42725-00</a> Grommet	<a href="#">Buy now</a>
18	<a href="#">65W-84342-00</a> Seat, emblem	<a href="#">Buy now</a>
19	<a href="#">65W-82594-10</a> Clamp	<a href="#">Buy now</a>
20	<a href="#">90465-13M18</a> Clamp	<a href="#">Buy now</a>
21	<a href="#">65W-15758-00</a> Guide, Rope	<a href="#">Buy now</a>
21	<a href="#">65W-15758-10</a> Guide Rope	<a href="#">Buy now</a>
22	<a href="#">65W-15762-00</a> Seal, rubber 2	<a href="#">Buy now</a>
23	<a href="#">65W-15771-00</a> Stay 1	<a href="#">Buy now</a>
24	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
25	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>
27	<a href="#">65W-13437-61</a> Mark, Caution	<a href="#">Buy now</a>


# Generator



Ref	Part	
28	<a href="#">6A1-83625-41</a> Mark 5	<a href="#">Buy now</a>
29	<a href="#">6A1-83625-51</a> Mark 5	<a href="#">Buy now</a>

**C5**


# Intake



**B4**

Ref	Part	
1	<a href="#">65W-14440-00</a> Silencer assembly, intake	<a href="#">Buy now</a>
2	<a href="#">65W-13640-00</a> Manifold	<a href="#">Buy now</a>
3	<a href="#">65W-13323-00</a> Insert	<a href="#">Buy now</a>
4	<a href="#">65W-14496-00</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">65W-14271-00</a> Insulator	<a href="#">Buy now</a>
6	<a href="#">65W-14198-00</a> Gasket	<a href="#">Buy now</a>
7	<a href="#">65W-14262-00</a> Flange	<a href="#">Buy now</a>
8	<a href="#">65W-14457-10</a> Seal	<a href="#">Buy now</a>
9	<a href="#">65W-13645-00</a> Gasket, manifold 1	<a href="#">Buy now</a>
10	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
11	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">65W-24377-00</a> Pipe, joint 3	<a href="#">Buy now</a>
13	<a href="#">65W-15397-10</a> Pipe	<a href="#">Buy now</a>
14	<a href="#">90465-13M36</a> Clamp(6h4)	<a href="#">Buy now</a>
15	<a href="#">90446-24M54</a> Hose	<a href="#">Buy now</a>


## Intake



Ref	Part	
16	<a href="#">90465-11M52</a> Clamp(6e7)	<a href="#">Buy now</a>
17	<a href="#">65W-15370-00</a> Breather assembly	<a href="#">Buy now</a>
18	<a href="#">65W-15370-10</a> Breather assembly	<a href="#">Buy now</a>


B4

## Lower Casing. Drive 1



Ref	Part	
3	<a href="#">93332-000W5</a> Bearing(61n)	<a href="#">Buy now</a>
5	<a href="#">61N-45536-00</a> Sleeve, drive shaft	<a href="#">Buy now</a>
6	<a href="#">93315-220V7</a> Bearing, cylindrical(6j8)	<a href="#">Buy now</a>
7	<a href="#">61N-44362-00</a> Tube, water <i>S</i>	<a href="#">Buy now</a>
7	<a href="#">61N-44362-10</a> Tube, water <i>L</i>	<a href="#">Buy now</a>
8	<a href="#">93210-22164</a> O-ring <i>S</i>	<a href="#">Buy now</a>
9	<a href="#">93210-26130</a> O-ring <i>S</i>	<a href="#">Buy now</a>
10	<a href="#">65W-44328-11</a> Plate <i>L</i>	<a href="#">Buy now</a>
11	<a href="#">61N-44311-01</a> Housing, water pump	<a href="#">Buy now</a>
12	<a href="#">6L2-44367-00</a> Damper, water seal 3	<a href="#">Buy now</a>
13	<a href="#">61N-44322-01</a> Insert, cartridge	<a href="#">Buy now</a>
14	<a href="#">6H4-44352-02</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">93210-45161</a> O-ring	<a href="#">Buy now</a>
16	<a href="#">61N-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
17	<a href="#">97095-06040</a> Bolt (682)	<a href="#">Buy now</a>


# Lower Casing. Drive 1



A7


Ref	Part	
18	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">65W-44176-00</a> Bracket	<a href="#">Buy now</a>
20	<a href="#">93210-06ME6</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
24	<a href="#">93604-10M03</a> Pin, dowel (688)	<a href="#">Buy now</a>
25	<a href="#">61N-45127-00</a> Seal	<a href="#">Buy now</a>
26	<a href="#">61N-45315-00</a> Packing, lower casing	<a href="#">Buy now</a>
27	<a href="#">93101-22067</a> Oil seal (22x36x6-663)	<a href="#">Buy now</a>
28	<a href="#">90340-08002</a> Plug, straight screw	<a href="#">Buy now</a>
29	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>
30	<a href="#">61N-45251-01</a> Anode	<a href="#">Buy now</a>
31	<a href="#">95895-06035</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
32	<a href="#">92990-06300</a> Washer, tooth	<a href="#">Buy now</a>
33	<a href="#">688-45341-10</a> Plug, drain	<a href="#">Buy now</a>
35	<a href="#">61N-45510-00</a> Drive shaft assembly S	<a href="#">Buy now</a>

## Lower Casing. Drive 1




Ref	Part	
35	<a href="#">61N-45510-10</a> Drive shaft assembly L	<a href="#">Buy now</a>
36	<a href="#">90280-03024</a> Key, woodruff(662)	<a href="#">Buy now</a>
37	<a href="#">61N-45551-00</a> Pinion	<a href="#">Buy now</a>
38	<a href="#">90179-10M14</a> Nut(6j8)	<a href="#">Buy now</a>
39	<a href="#">93332-00005</a> Brg,cyl-cal roller 0.19g nt	<a href="#">Buy now</a>
40	<a href="#">6L2-45567-00-14</a> Shim (t:1.4mm) UR	<a href="#">Buy now</a>
41	<a href="#">61N-45560-00</a> Gear	<a href="#">Buy now</a>
42	<a href="#">6L2-45611-00</a> Shaft, propeller	<a href="#">Buy now</a>
43	<a href="#">648-45635-00</a> Plunger,shift	<a href="#">Buy now</a>
44	<a href="#">664-45631-02</a> Clutch, dog	<a href="#">Buy now</a>
45	<a href="#">90250-05010</a> Pin straight 648456320000	<a href="#">Buy now</a>
46	<a href="#">648-45633-00</a> Ring, cross pin	<a href="#">Buy now</a>
47	<a href="#">90501-10065</a> Spring compression648456360000	<a href="#">Buy now</a>
48	<a href="#">90201-20417</a> Washer, plate(663)	<a href="#">Buy now</a>
49	<a href="#">61N-45571-00</a> Gear	<a href="#">Buy now</a>

# Lower Casing. Drive 1



Ref	Part	
50	<a href="#">6L2-45577-00-10</a> Shim (t:1.0mm) <b>UR</b>	<a href="#">Buy now</a>
50	<a href="#">6L2-45577-00-11</a> Shim (t:1.1mm) <b>UR</b>	<a href="#">Buy now</a>
50	<a href="#">6L2-45577-00-12</a> Shim (t:1.2mm) <b>UR</b>	<a href="#">Buy now</a>
50	<a href="#">6L2-45577-00-13</a> Shim (t:1.3mm) <b>UR</b>	<a href="#">Buy now</a>
51	<a href="#">61N-45361-01-4D</a> Cap, lower casing	<a href="#">Buy now</a>
52	<a href="#">93306-00612</a> Bearing(2hr)	<a href="#">Buy now</a>
53	<a href="#">93210-64ME7</a> O-ring	<a href="#">Buy now</a>
54	<a href="#">93315-22004</a> Brg,cyl-cal roller 21g nt	<a href="#">Buy now</a>
55	<a href="#">93101-20M07</a> Oil seal	<a href="#">Buy now</a>
56	<a href="#">93210-65M50</a> O-ring	<a href="#">Buy now</a>
57	<a href="#">97075-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
59	<a href="#">65W-44150-00</a> Shift cam assembly <b>S</b>	<a href="#">Buy now</a>
59	<a href="#">65W-44150-10</a> Shift cam assembly <b>L</b>	<a href="#">Buy now</a>


## Lower Casing. Drive 2



B3

Ref	Part	
1	<a href="#">65W-44361-01</a> Tube, water S	<a href="#">Buy now</a>
1	<a href="#">65W-44361-11</a> Tube, water L	<a href="#">Buy now</a>
2	<a href="#">90202-12060</a> Washer, plate(663)	<a href="#">Buy now</a>
3	<a href="#">90430-10002</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">93606-11M24</a> Pin, dowel	<a href="#">Buy now</a>
5	<a href="#">90105-10M12</a> Bolt (689)	<a href="#">Buy now</a>
6	<a href="#">92995-10600</a> Washer, plate	<a href="#">Buy now</a>
7	<a href="#">61N-45371-00</a> Tab-trim	<a href="#">Buy now</a>
8	<a href="#">90119-06M48</a> Bolt, with washer(61n)	<a href="#">Buy now</a>
9	<a href="#">6L2-45214-00</a> Cover, water inlet	<a href="#">Buy now</a>
10	<a href="#">6L2-45215-00</a> Cover, water inlet	<a href="#">Buy now</a>
11	<a href="#">90151-05M05</a> Screw, countersunk	<a href="#">Buy now</a>
12	<a href="#">90185-05002</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
13	<a href="#">6L2-45987-01</a> Spacer	<a href="#">Buy now</a>
14	<a href="#">689-45997-00</a> Spacer	<a href="#">Buy now</a>


## Lower Casing. Drive 2



**B3**

Ref	Part	
15	<a href="#">92990-14200</a> Washer, plain	<a href="#">Buy now</a>
16	<a href="#">90171-14013</a> Nut(664)	<a href="#">Buy now</a>
17	<a href="#">91490-30022</a> Pin, cotter	<a href="#">Buy now</a>
18	<a href="#">664-45941-01-EL</a> Propeller (3x9-7/8" x9"-f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45943-01-EL</a> Propeller (3x9-7/8 x8 -f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45945-00-EL</a> Propeller (3x9-7/8 x10-1/2 -f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45947-01-EL</a> Propeller (3x9-7/8 x11-1/4 -f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45949-02-EL</a> Propeller (3x9-7/8 x13 -f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45952-00-EL</a> Propeller (3x9-7/8 x14 -f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45954-00-EL</a> Propeller (3x9-7/8 x12 -f) <b>UR</b>	<a href="#">Buy now</a>
18	<a href="#">664-45970-00-98</a> Propeller (3x9-1/8 x13 -f) <b>UR STAINLESS STEEL,</b>	<a href="#">Buy now</a>
18	<a href="#">664-45972-00-98</a> Propeller (3x9-1/8 x12 -f) <b>UR STAINLESS STEEL,</b>	<a href="#">Buy now</a>

# Oil Pan




65W1010-2270

A6

Ref	Part	
1	<a href="#">65W-15362-01</a> Plug, oil level	<a href="#">Buy now</a>
2	<a href="#">62Y-11575-00</a> Relief valve ass'y	<a href="#">Buy now</a>
3	<a href="#">62Y-13475-00</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">97013-06025</a> Bolt(62y)	<a href="#">Buy now</a>
5	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">65W-13411-00</a> Strainer, oil	<a href="#">Buy now</a>
7	<a href="#">97013-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
9	<a href="#">93608-12M05</a> Pin, dowel b (6e5)	<a href="#">Buy now</a>
10	<a href="#">65W-15311-01-5B</a> Oil pan	<a href="#">Buy now</a>
11	<a href="#">69W-15312-00</a> Gasket, oil pan	<a href="#">Buy now</a>
12	<a href="#">93606-12019</a> Pin, dowel (614)	<a href="#">Buy now</a>
13	<a href="#">65W-15316-00</a> Damper 1	<a href="#">Buy now</a>
14	<a href="#">90340-14M06</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
15	<a href="#">90430-14M09</a> Gasket	<a href="#">Buy now</a>
16	<a href="#">97075-06025</a> Bolt	<a href="#">Buy now</a>

## Oil Pan




65W1010-2270

Ref	Part	
17	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>

A6

# Oil Pump




B7

Ref	Part	
1	<a href="#">93102-37M40</a> Oil seal(62y)	<a href="#">Buy now</a>
2	<a href="#">65W-12170-10</a> Camshaft assembly 1 <b>COMPONENT OF</b>	<a href="#">Buy now</a>
2	<a href="#">65W-12171-00</a> Camshaft 1	<a href="#">Buy now</a>
3	<a href="#">65W-11537-01</a> Gear, driven	<a href="#">Buy now</a>
4	<a href="#">93605-14143</a> Pin (2h7)	<a href="#">Buy now</a>
5	<a href="#">90201-10M06</a> Washer, plate(62y)	<a href="#">Buy now</a>
6	<a href="#">95895-10040</a> Bolt, flange deep recess	<a href="#">Buy now</a>
7	<a href="#">65W-46241-00</a> Belt	<a href="#">Buy now</a>
8	<a href="#">65W-11536-10</a> Gear, drive	<a href="#">Buy now</a>
9	<a href="#">65W-11476-00</a> Spring	<a href="#">Buy now</a>
10	<a href="#">90280-04M06</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
11	<a href="#">65W-13300-00</a> Oil pump assembly	<a href="#">Buy now</a>
12	<a href="#">93210-33MH2</a> O-ring(62y)	<a href="#">Buy now</a>
13	<a href="#">93210-12MG9</a> O-ring(62y)	<a href="#">Buy now</a>
14	<a href="#">93210-14515</a> O-ring (11h)	<a href="#">Buy now</a>


# Oil Pump

Ref	Part	
15	<a href="#">90119-06MA6</a> Bolt, with washer	<a href="#">Buy now</a>



**B7**


# Power Trim & Tilt Assy



**F6**

Ref	Part	
2	<a href="#">65W-43880-00</a> Motor assembly (hitachi)	<a href="#">Buy now</a>
3	<a href="#">65W-43804-00</a> Stator assembly	<a href="#">Buy now</a>
4	<a href="#">65W-43805-00</a> Armature assembly	<a href="#">Buy now</a>
5	<a href="#">65W-43869-00</a> O-ring	<a href="#">Buy now</a>
6	<a href="#">65W-43881-00</a> Frame, End	<a href="#">Buy now</a>
7	<a href="#">65W-4386K-00</a> Spring, brush	<a href="#">Buy now</a>
8	<a href="#">65W-43882-00</a> Oil seal	<a href="#">Buy now</a>
9	<a href="#">65W-43892-00</a> Brush 2	<a href="#">Buy now</a>
10	<a href="#">65W-43891-00</a> Brush 1	<a href="#">Buy now</a>
11	<a href="#">65W-4380F-00</a> Plate, brush holder	<a href="#">Buy now</a>
12	<a href="#">65W-43879-00</a> Screw, with washer	<a href="#">Buy now</a>
13	<a href="#">65W-43887-00</a> Bolt, screw	<a href="#">Buy now</a>
14	<a href="#">65W-4388E-00</a> Bolt	<a href="#">Buy now</a>
15	<a href="#">65W-43840-00</a> Power tilt assembly	<a href="#">Buy now</a>
16	<a href="#">65W-4380K-00</a> Cylinder, tilt sub assembly	<a href="#">Buy now</a>


# Power Trim & Tilt Assy



**F6**

Ref	Part	
17	<a href="#">65W-43810-00</a> Tilt piston sub assembly	<a href="#">Buy now</a>
18	<a href="#">65W-43812-00</a> Seal, dust	<a href="#">Buy now</a>
19	<a href="#">65W-43865-00</a> O-ring	<a href="#">Buy now</a>
20	<a href="#">6H1-43861-10</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">65W-43871-00</a> Ring, back up	<a href="#">Buy now</a>
22	<a href="#">65W-4381B-00</a> Free piston sub assembly	<a href="#">Buy now</a>
24	<a href="#">93210-11368</a> O-ring (2h7)	<a href="#">Buy now</a>
25	<a href="#">6H1-43816-00</a> Filter 1	<a href="#">Buy now</a>
26	<a href="#">93210-064A5</a> O-ring(61a)	<a href="#">Buy now</a>
27	<a href="#">65W-4380L-00</a> Housing, trim & tilt sub assembly	<a href="#">Buy now</a>
28	<a href="#">65W-43888-00</a> Bolt, hexagon socket head(1jk)	<a href="#">Buy now</a>
29	<a href="#">93210-50768</a> O-ring	<a href="#">Buy now</a>
30	<a href="#">6T4-43802-03</a> Valve sub assembly	<a href="#">Buy now</a>
31	<a href="#">6H1-43866-00</a> O-ring	<a href="#">Buy now</a>
32	<a href="#">6H1-43867-00</a> O-ring	<a href="#">Buy now</a>


# Power Trim & Tilt Assy



**F6**

Ref	Part	
33	<a href="#">62X-43841-00</a> Piston, shuttle	<a href="#">Buy now</a>
34	<a href="#">93210-09165</a> O-ring	<a href="#">Buy now</a>
35	<a href="#">65W-43831-00</a> Connector, shaft	<a href="#">Buy now</a>
36	<a href="#">65W-43830-00</a> Gear pump assembly	<a href="#">Buy now</a>
37	<a href="#">6T4-43853-00</a> Spring, main valve	<a href="#">Buy now</a>
38	<a href="#">91318-04025</a> Bolt(62x)	<a href="#">Buy now</a>
39	<a href="#">65W-43817-00</a> Filter 2	<a href="#">Buy now</a>
40	<a href="#">65W-43861-00</a> O-ring	<a href="#">Buy now</a>
41	<a href="#">65W-43862-00</a> O-ring	<a href="#">Buy now</a>
42	<a href="#">6H1-43875-00</a> Ring, snap	<a href="#">Buy now</a>
43	<a href="#">6H1-43845-00</a> Screw, manual release	<a href="#">Buy now</a>
44	<a href="#">93210-18397</a> O-ring (6g5)	<a href="#">Buy now</a>
45	<a href="#">6H1-43847-00</a> Seat, manual valve	<a href="#">Buy now</a>
46	<a href="#">65W-43854-00</a> Spring, manual release	<a href="#">Buy now</a>
47	<a href="#">65W-4382A-00</a> Adaptor 1	<a href="#">Buy now</a>


# Power Trim & Tilt Assy



**F6**

Ref	Part	
48	<a href="#">65W-43844-00</a> Pin, valve support	<a href="#">Buy now</a>
49	<a href="#">65W-43851-00</a> Seat, relief valve	<a href="#">Buy now</a>
50	<a href="#">93210-08006</a> O-ring	<a href="#">Buy now</a>
51	<a href="#">93210-03478</a> O-ring(31m)	<a href="#">Buy now</a>
52	<a href="#">65W-43855-00</a> Spring, up relief	<a href="#">Buy now</a>
53	<a href="#">93210-11073</a> O-ring (p95)	<a href="#">Buy now</a>
54	<a href="#">65W-43843-00</a> Screw, valve lock	<a href="#">Buy now</a>
55	<a href="#">6H1-43856-10</a> Spring, down relief	<a href="#">Buy now</a>
56	<a href="#">6H1-43844-10</a> Pin, valve support	<a href="#">Buy now</a>
57	<a href="#">6H1-4384F-10</a> Seal, main valve	<a href="#">Buy now</a>
58	<a href="#">65W-4386A-00</a> Pin, absorber valve	<a href="#">Buy now</a>
59	<a href="#">93501-08001</a> Ball	<a href="#">Buy now</a>
60	<a href="#">65W-43853-00</a> Spring, absorber valve	<a href="#">Buy now</a>
61	<a href="#">6H1-43829-00</a> Plug, reservoir	<a href="#">Buy now</a>
62	<a href="#">62X-43878-00</a> Bolt, socket	<a href="#">Buy now</a>


## Power Trim & Tilt Assy



**F6**

Ref	Part	
63	<a href="#">93210-10M74</a> O-ring	<a href="#">Buy now</a>
64	<a href="#">9321010M74</a> O-ring	<a href="#">Buy now</a>
65	<a href="#">6T44380800</a> Seat valve comp. 1	<a href="#">Buy now</a>


## Remote Control Assy



B7

Ref	Part	
1	<a href="#">703-48203-A2</a> Remote control assembly (7p) AP	<a href="#">Buy now</a>
1	<a href="#">703-48205-A4</a> Remote control assembly (10p, ptt) AP WITH PT/T SW.	<a href="#">Buy now</a>
2	<a href="#">703-48261-01</a> Arm, throttle	<a href="#">Buy now</a>
3	<a href="#">703-48153-00</a> Shaft, free accel.	<a href="#">Buy now</a>
4	<a href="#">703-48235-00</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">703-48268-00</a> Spacer 3	<a href="#">Buy now</a>
6	<a href="#">703-48264-00</a> Throttle, friction	<a href="#">Buy now</a>
7	<a href="#">95380-05600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
8	<a href="#">97380-05025</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">703-48265-00</a> Shaft Friction	<a href="#">Buy now</a>
10	<a href="#">93430-06024</a> Circlip (701)	<a href="#">Buy now</a>
11	<a href="#">703-48245-00</a> Plate, lock	<a href="#">Buy now</a>
12	<a href="#">703-48252-00</a> Roller, cam	<a href="#">Buy now</a>
13	<a href="#">701-48248-00</a> Roller, free accel	<a href="#">Buy now</a>
14	<a href="#">703-48198-00</a> Washer, wave 3	<a href="#">Buy now</a>


## Remote Control Assy



B7

Ref	Part	
15	<a href="#">703-48243-00</a> Bushing 3	<a href="#">Buy now</a>
16	<a href="#">703-48236-00</a> Bushing	<a href="#">Buy now</a>
17	<a href="#">703-48189-00</a> Retainer	<a href="#">Buy now</a>
18	<a href="#">703-48234-00</a> Roller, detent	<a href="#">Buy now</a>
19	<a href="#">703-48345-01</a> Cable end, remote control 2	<a href="#">Buy now</a>
20	<a href="#">703-48358-00</a> Anchor, cable	<a href="#">Buy now</a>
21	<a href="#">703-48244-00</a> Spring, free accel.	<a href="#">Buy now</a>
22	<a href="#">703-48238-00</a> Spring, detent	<a href="#">Buy now</a>
23	<a href="#">703-48246-00</a> Spacer 1	<a href="#">Buy now</a>
24	<a href="#">703-48227-00</a> Spring, neutral lock	<a href="#">Buy now</a>
25	<a href="#">703-82594-00</a> Clamp <b>WITH PT/T SW.</b>	<a href="#">Buy now</a>
26	<a href="#">703-48226-00</a> Plate, stopper	<a href="#">Buy now</a>
27	<a href="#">703-48222-00</a> Grip, control lever <b>SINGLE</b>	<a href="#">Buy now</a>
28	<a href="#">703-48223-00</a> Lock, neutral	<a href="#">Buy now</a>
29	<a href="#">703-48225-00</a> Cover	<a href="#">Buy now</a>


## Remote Control Assy



B7

Ref	Part	
30	<a href="#">703-48219-00</a> Cover, lead	<a href="#">Buy now</a>
31	<a href="#">703-48281-00</a> Screw, flat head	<a href="#">Buy now</a>
32	<a href="#">703-48282-00</a> Screw	<a href="#">Buy now</a>
33	<a href="#">97380-08030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
34	<a href="#">92990-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
35	<a href="#">98580-04010</a> Screw, pan head (e56)	<a href="#">Buy now</a>
36	<a href="#">98580-04006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
37	<a href="#">98580-05010</a> Screw, pan head(62x)	<a href="#">Buy now</a>
38	<a href="#">98580-03015</a> Screw, pan head (n151)	<a href="#">Buy now</a>
39	<a href="#">703-48291-10</a> Screw	<a href="#">Buy now</a>
40	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
41	<a href="#">703-48293-10</a> Spacer, remote control <b>SINGLE</b>	<a href="#">Buy now</a>
42	<a href="#">701-48287-00</a> Washer 1	<a href="#">Buy now</a>
43	<a href="#">703-48215-00</a> Graphic	<a href="#">Buy now</a>
44	<a href="#">703-82510-03</a> Main switch assembly <b>FOR 703-48203-A2</b>	<a href="#">Buy now</a>


## Remote Control Assy



B7

Ref	Part	
44	<u><a href="#">703-82510-12</a></u> Main switch assembly <b>FOR PRIME START</b>	<a href="#">Buy now</a>
45	<u><a href="#">676-82577-00</a></u> Cap, key	<a href="#">Buy now</a>
46	<u><a href="#">703-82531-00</a></u> Wire, lead	<a href="#">Buy now</a>
47	<u><a href="#">688-82575-01</a></u> Engine stop switch assembly	<a href="#">Buy now</a>
48	<u><a href="#">682-82556-00</a></u> Lanyard, stop switch	<a href="#">Buy now</a>
49	<u><a href="#">688-82586-21</a></u> Extension, wire harness <b>L)5M (7P)</b>	<a href="#">Buy now</a>
49	<u><a href="#">688-8258A-20</a></u> 10p main harness mec 2m (6ft) <b>L)5M (10P)</b>	<a href="#">Buy now</a>
50	<u><a href="#">703-82540-00</a></u> Neutral switch assembly	<a href="#">Buy now</a>
51	<u><a href="#">703-83383-A0</a></u> Buzzer	<a href="#">Buy now</a>
52	<u><a href="#">703-48284-00</a></u> Grommet	<a href="#">Buy now</a>
53	<u><a href="#">703-82591-00</a></u> Band	<a href="#">Buy now</a>
54	<u><a href="#">703-82592-00</a></u> Band	<a href="#">Buy now</a>
55	<u><a href="#">703-48224-00</a></u> Cover, control lever <b>WITHOUT PT/T SW.</b>	<a href="#">Buy now</a>
55	<u><a href="#">703-82563-02</a></u> Trim & tilt switch assembly <b>WITH PT/T SW.</b>	<a href="#">Buy now</a>
56	<u><a href="#">703-48221-00</a></u> Grip	<a href="#">Buy now</a>


## Remote Control Assy



B7


Ref	Part	
57	<a href="#">703-48152-00</a> Knob, free accel	<a href="#">Buy now</a>
58	<a href="#">703-48212-00</a> Rear housing	<a href="#">Buy now</a>
59	<a href="#">703-48213-00</a> Back, panel	<a href="#">Buy now</a>
60	<a href="#">703-48271-00</a> Arm, shift	<a href="#">Buy now</a>
61	<a href="#">703-48211-01</a> Housing,1	<a href="#">Buy now</a>
62	<a href="#">703-48232-00</a> Drive gear	<a href="#">Buy now</a>
63	<a href="#">703-82542-00</a> Cap	<a href="#">Buy now</a>
64	<a href="#">703-48218-00</a> Graphic	<a href="#">Buy now</a>

# Remote Control Attachment



Ref	Part	
1	<a href="#">65W-48501-00</a> Remote cont. attachment assembly. AP	<a href="#">Buy now</a>
2	<a href="#">65W-44142-00</a> Joint	<a href="#">Buy now</a>
3	<a href="#">90254-03M05</a> Pin, spring	<a href="#">Buy now</a>
4	<a href="#">65W-44125-00</a> Lever, shift rod	<a href="#">Buy now</a>
5	<a href="#">90387-06M29</a> Coller (6a0)	<a href="#">Buy now</a>
6	<a href="#">90201-06M31</a> Washer (6a0)	<a href="#">Buy now</a>
7	<a href="#">97595-06525</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
8	<a href="#">65W-44192-00</a> Joint, rod 1	<a href="#">Buy now</a>
9	<a href="#">90201-05M06</a> Washer, plate(61u)	<a href="#">Buy now</a>
10	<a href="#">90468-10005</a> Pin, hair 6264123500	<a href="#">Buy now</a>
11	<a href="#">90468-18008</a> Clip 620436610000	<a href="#">Buy now</a>
12	<a href="#">663-48344-00</a> Cable end, remote control	<a href="#">Buy now</a>
14	<a href="#">6H3-48538-00</a> Clamp, cable	<a href="#">Buy now</a>
15	<a href="#">65W-42725-20</a> Grommet	<a href="#">Buy now</a>
16	<a href="#">62Y-42727-00</a> Grommet	<a href="#">Buy now</a>


## Remote Control Attachment



Ref	Part	
17	<a href="#">65W-26326-10</a> Grommet	<a href="#">Buy now</a>
18	<a href="#">65W-42726-10</a> Grommet	<a href="#">Buy now</a>
19	<a href="#">65W-48511-00</a> Hook, steering	<a href="#">Buy now</a>
20	<a href="#">90201-10120</a> Washer, plate	<a href="#">Buy now</a>

E5

## Remote Control Box




67M0100-8280

**B6**

Ref	Part	
1	<a href="#">703-48203-A2</a> Remote control assembly (7p) AP	<a href="#">Buy now</a>
1	<a href="#">703-48205-A4</a> Remote control assembly (10p, ptt) AP WITH PT/T SW.	<a href="#">Buy now</a>
2	<a href="#">701-48310-90</a> Cable, Remote Control L=11F UR	<a href="#">Buy now</a>
2	<a href="#">701-48320-00</a> Cable, Remote Control L=12F UR	<a href="#">Buy now</a>
2	<a href="#">701-48320-20</a> Cable, Remote Control L=13F UR	<a href="#">Buy now</a>
2	<a href="#">701-48320-50</a> Cable, Remote Control L=15F UR	<a href="#">Buy now</a>


# Repair Kit 1



**C3**

Ref	Part	
1	<a href="#">65W-W0001-02</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">65W-15663-00</a> Seal	<a href="#">Buy now</a>
3	<a href="#">65W-11169-01</a> Gasket, breather cover	<a href="#">Buy now</a>
4	<a href="#">90430-14115</a> Gasket (663)	<a href="#">Buy now</a>
5	<a href="#">65W-11351-10</a> Gasket, cylinder	<a href="#">Buy now</a>
6	<a href="#">62Y-12414-00</a> Gasket, cover	<a href="#">Buy now</a>
7	<a href="#">65W-41114-00</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
8	<a href="#">90430-06014</a> Gasket 256113960000	<a href="#">Buy now</a>
9	<a href="#">65W-11181-20</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
10	<a href="#">65W-11356-00</a> Seal, cylinder 2	<a href="#">Buy now</a>
11	<a href="#">93210-24M79</a> O-ring	<a href="#">Buy now</a>
12	<a href="#">93102-43M42</a> Oil seal(62y)	<a href="#">Buy now</a>
13	<a href="#">93102-35M47</a> Oil seal(62y)	<a href="#">Buy now</a>
14	<a href="#">65W-14198-00</a> Gasket	<a href="#">Buy now</a>
15	<a href="#">65W-14457-10</a> Seal	<a href="#">Buy now</a>


# Repair Kit 1



Ref	Part	
16	<a href="#">65W-13645-00</a> Gasket, manifold 1	<a href="#">Buy now</a>
17	<a href="#">93102-37M40</a> Oil seal(62y)	<a href="#">Buy now</a>
18	<a href="#">90280-04M06</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
19	<a href="#">93210-33MH2</a> O-ring(62y)	<a href="#">Buy now</a>
20	<a href="#">93210-12MG9</a> O-ring(62y)	<a href="#">Buy now</a>
21	<a href="#">93210-14515</a> O-ring (11h)	<a href="#">Buy now</a>

C3


## Repair Kit 2



Ref	Part	
1	<a href="#">65W-W0093-00</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">65W-14126-00</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">6G1-14546-00</a> Valve, needle	<a href="#">Buy now</a>
4	<a href="#">676-14186-00</a> Pin, valve	<a href="#">Buy now</a>
5	<a href="#">6H4-14548-00</a> Pin, float arm	<a href="#">Buy now</a>
6	<a href="#">65W-14373-00</a> Cover, plunger cap	<a href="#">Buy now</a>
7	<a href="#">65W-14147-00</a> O-ring	<a href="#">Buy now</a>
8	<a href="#">65W-14335-00</a> Spring, plunger	<a href="#">Buy now</a>
9	<a href="#">65W-14384-00</a> Gasket, float chamber	<a href="#">Buy now</a>
10	<a href="#">65W-14398-00</a> Washer	<a href="#">Buy now</a>
11	<a href="#">97980-04114</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
12	<a href="#">63V-14985-00</a> Float	<a href="#">Buy now</a>
13	<a href="#">663-14159-00</a> Clip	<a href="#">Buy now</a>

C4


# Repair Kit 3



C5

Ref	Part	
1	<a href="#">65W-W0001-23</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">62Y-13475-00</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">69W-15312-00</a> Gasket, oil pan	<a href="#">Buy now</a>
4	<a href="#">90430-14M09</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">93110-16004</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">67C-41133-00</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
7	<a href="#">65W-45128-00</a> Seal 2	<a href="#">Buy now</a>
8	<a href="#">93210-26130</a> O-ring L	<a href="#">Buy now</a>
10	<a href="#">93210-22164</a> O-ring S	<a href="#">Buy now</a>
11	<a href="#">6L2-44367-00</a> Damper, water seal 3	<a href="#">Buy now</a>
12	<a href="#">93210-45161</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">93210-06ME6</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">61N-45315-00</a> Packing, lower casing	<a href="#">Buy now</a>
15	<a href="#">93101-22067</a> Oil seal (22x36x6-663)	<a href="#">Buy now</a>
16	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>


# Repair Kit 3



Ref	Part	
18	<a href="#">93210-64ME7</a> O-ring	<a href="#">Buy now</a>
19	<a href="#">93101-20M07</a> Oil seal	<a href="#">Buy now</a>
20	<a href="#">93210-65M50</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">90430-10002</a> Gasket	<a href="#">Buy now</a>
22	<a href="#">61N-W0078-11</a> Water pump repair kit	<a href="#">Buy now</a>
23	<a href="#">61N-44311-01</a> Housing, water pump	<a href="#">Buy now</a>
25	<a href="#">61N-44322-01</a> Insert, cartridge	<a href="#">Buy now</a>
26	<a href="#">6H4-44352-02</a> Impeller	<a href="#">Buy now</a>
28	<a href="#">61N-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
29	<a href="#">97095-06040</a> Bolt (682)	<a href="#">Buy now</a>
30	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
31	<a href="#">90280-03024</a> Key, woodruff(662)	<a href="#">Buy now</a>

**C5**


# Starter



**C3**

Ref	Part	
1	<a href="#">97095-06025</a> Bolt	<a href="#">Buy now</a>
2	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
3	<a href="#">65W-W1571-01</a> Starter assembly	<a href="#">Buy now</a>
4	<a href="#">65W-15711-01</a> Case, Starter	<a href="#">Buy now</a>
5	<a href="#">65W-15732-00</a> Washer, wave 1	<a href="#">Buy now</a>
6	<a href="#">65W-15713-00</a> Spring, starter	<a href="#">Buy now</a>
7	<a href="#">65W-15714-01</a> Drum, sheave	<a href="#">Buy now</a>
8	<a href="#">65W-15734-00</a> Spring Return	<a href="#">Buy now</a>
9	<a href="#">65W-15744-00</a> Circlip	<a href="#">Buy now</a>
10	<a href="#">65W-15715-00</a> Spring, friction	<a href="#">Buy now</a>
11	<a href="#">65W-15716-00</a> Plate, drive	<a href="#">Buy now</a>
12	<a href="#">65W-15793-00</a> Screw	<a href="#">Buy now</a>
13	* item_description	<a href="#">Buy now</a>
14	<a href="#">65W-15752-00</a> Roller Wire	<a href="#">Buy now</a>
15	<a href="#">65W-15753-00</a> Bush	<a href="#">Buy now</a>


# Starter




**C3**

Ref	Part	
16	<a href="#">65W-15791-00</a> Washer Lock	<a href="#">Buy now</a>
17	<a href="#">65W-15481-00</a> Bolt 1	<a href="#">Buy now</a>
18	<a href="#">65W-15735-01</a> Guide, cam	<a href="#">Buy now</a>
19	<a href="#">65W-15767-01</a> Spring	<a href="#">Buy now</a>
20	<a href="#">65W-15794-00</a> Stopper	<a href="#">Buy now</a>
21	<a href="#">65W-15784-00</a> Spring, return	<a href="#">Buy now</a>
22	<a href="#">65W-15414-00</a> Cover 1	<a href="#">Buy now</a>
23	<a href="#">65W-15768-00</a> Bolt	<a href="#">Buy now</a>
24	<a href="#">65W-15741-10</a> Pawl, drive	<a href="#">Buy now</a>
25	<a href="#">689-15755-01</a> Handle, starter	<a href="#">Buy now</a>
26	<a href="#">6F5-15779-02</a> Cover	<a href="#">Buy now</a>
27	<a href="#">6A0-15789-00</a> Damper	<a href="#">Buy now</a>
28	<a href="#">65W-15723-10</a> Pulley, starter	<a href="#">Buy now</a>
29	<a href="#">90110-08M03</a> Bolt, Hexagon Socket Head	<a href="#">Buy now</a>
30	<a href="#">65W-15645-00</a> Shim Kick Shaft	<a href="#">Buy now</a>

# Starter




# Starting Motor



D5

Ref	Part	
1	<a href="#">65W-81800-01</a> Starting motor assembly	<a href="#">Buy now</a>
2	<a href="#">65W-81826-00</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">65W-81857-01</a> Retainer	<a href="#">Buy now</a>
4	<a href="#">65W-81830-00</a> Front Bracket assembly	<a href="#">Buy now</a>
5	<a href="#">65W-81807-00</a> Gear assembly, starting motor	<a href="#">Buy now</a>
6	<a href="#">65W-81850-01</a> Armature assembly	<a href="#">Buy now</a>
7	<a href="#">65W-81820-00</a> Rear bracket assembly	<a href="#">Buy now</a>
8	<a href="#">65W-81801-00</a> Brush set	<a href="#">Buy now</a>
9	<a href="#">65W-81840-00</a> Brush holder assembly	<a href="#">Buy now</a>
10	<a href="#">65W-81825-00</a> Screw	<a href="#">Buy now</a>
11	<a href="#">90119-08M39</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">90109-08M77</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">90109-08M78</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">95380-08700</a> Nut(661)	<a href="#">Buy now</a>
15	<a href="#">92990-08600</a> Washer, plain (663)	<a href="#">Buy now</a>


# Steering



**E1**

Ref	Part	
2	<a href="#">65W-44111-00</a> Handle, gear shift	<a href="#">Buy now</a>
3	<a href="#">90119-06M85</a> Bolt, with washer	<a href="#">Buy now</a>
4	<a href="#">90206-12M00</a> Washer, wave (676)	<a href="#">Buy now</a>
5	<a href="#">90201-12M07</a> Washer, plate	<a href="#">Buy now</a>
6	<a href="#">65W-42123-00</a> Bolt, handle joint	<a href="#">Buy now</a>
7	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
8	<a href="#">65W-44124-00</a> Link, shift rod	<a href="#">Buy now</a>
9	<a href="#">92990-06200</a> Ybs66-6 washer, plain	<a href="#">Buy now</a>
10	<a href="#">90468-18008</a> Clip 620436610000	<a href="#">Buy now</a>
11	<a href="#">6E0-44191-11</a> Indicator, shift	<a href="#">Buy now</a>
13	<a href="#">90109-06M86</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">65W-42138-00</a> Lever, throttle	<a href="#">Buy now</a>
15	<a href="#">65W-42159-00</a> Stay	<a href="#">Buy now</a>
16	<a href="#">6G1-42126-00</a> Piece, friction	<a href="#">Buy now</a>
17	<a href="#">65W-42125-00</a> Bolt, friction adjusting	<a href="#">Buy now</a>


# Steering



E1

Ref	Part	
18	<a href="#">91490-16010</a> Pin, cotter	<a href="#">Buy now</a>
19	<a href="#">66M-42177-00</a> Rubber, handle	<a href="#">Buy now</a>
20	<a href="#">66M-42119-00</a> Grip, steering handle	<a href="#">Buy now</a>
21	<a href="#">610-42137-00</a> Indicator, throttle	<a href="#">Buy now</a>
22	<a href="#">90269-02M09</a> Rivet(615)	<a href="#">Buy now</a>
23	<a href="#">90149-05M13</a> Screw, countersunk	<a href="#">Buy now</a>
24	<a href="#">92903-10600</a> Washer, plate	<a href="#">Buy now</a>
25	<a href="#">90501-23215</a> Spring (655)	<a href="#">Buy now</a>
26	<a href="#">90386-08032</a> Bushing (650)	<a href="#">Buy now</a>
27	<a href="#">65W-26311-00</a> Cable, throttle 1	<a href="#">Buy now</a>
28	<a href="#">90446-10M86</a> Hose	<a href="#">Buy now</a>
29	<a href="#">90446-14M88</a> Hose	<a href="#">Buy now</a>
30	<a href="#">90386-40MA0</a> Bushing	<a href="#">Buy now</a>
31	<a href="#">90201-43M00</a> Washer, plate	<a href="#">Buy now</a>
32	<a href="#">90206-43M22</a> Washer, wave	<a href="#">Buy now</a>


# Steering



E1

Ref	Part	
33	<a href="#">90202-43M57</a> Washer, plate	<a href="#">Buy now</a>
34	<a href="#">90386-40M99</a> Bush	<a href="#">Buy now</a>
35	<a href="#">65W-42131-01</a> Cover, handle steering	<a href="#">Buy now</a>
36	<a href="#">95780-10300</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
37	<a href="#">95380-10700</a> Nut (682)	<a href="#">Buy now</a>
39	<a href="#">65W-44173-00</a> Lever, shift control	<a href="#">Buy now</a>
40	<a href="#">90254-03M05</a> Pin, spring	<a href="#">Buy now</a>
41	<a href="#">6E0-83627-41</a> Label, caution 7	<a href="#">Buy now</a>
42	<a href="#">6E0-83627-51</a> Label, Caution 7	<a href="#">Buy now</a>

# Steering Guide




65W0010-8210

Ref	Part	
1	<a href="#">65W-61350-00</a> Steering guide attachment kit AP	<a href="#">Buy now</a>
2	<a href="#">65W-61351-00</a> Rod, steering link	<a href="#">Buy now</a>
3	<a href="#">90201-10M20</a> Washer, plate (663)	<a href="#">Buy now</a>
4	<a href="#">90185-09M01</a> Nut, nylon (663)	<a href="#">Buy now</a>
5	<a href="#">90170-09M03</a> Nut (689)	<a href="#">Buy now</a>
6	<a href="#">90387-10M42</a> Coller (688)	<a href="#">Buy now</a>
7	<a href="#">90101-09M01</a> Bolt(62x)	<a href="#">Buy now</a>
8	<a href="#">90201-10M63</a> Washer, plate	<a href="#">Buy now</a>
9	<a href="#">6E5-43145-01</a> Cap, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">93210-16275</a> O-ring	<a href="#">Buy now</a>

B5


# Top Cowling



A4

Ref	Part	
2	<a href="#">65W-42613-00</a> Molding Air Duct	<a href="#">Buy now</a>
3	<a href="#">97780-60520</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
4	<a href="#">65W-42651-00</a> Hook	<a href="#">Buy now</a>
5	<a href="#">90109-06MA4</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">65W-42652-00</a> Hook	<a href="#">Buy now</a>
7	<a href="#">90266-04M04</a> Rivet(6e7)	<a href="#">Buy now</a>
8	<a href="#">65W-42615-01</a> Seal	<a href="#">Buy now</a>
9	<a href="#">65W-42678-20</a> Graphic, front <b>F25A</b>	<a href="#">Buy now</a>
9	<a href="#">65W-42678-40</a> Graphic, front <b>F20A</b>	<a href="#">Buy now</a>
10	<a href="#">65W-W0070-20</a> Graphic set	<a href="#">Buy now</a>
11	<a href="#">65W-42681-20</a> Mark, cowling	<a href="#">Buy now</a>
12	<a href="#">65W-42682-20</a> Mark, cowling	<a href="#">Buy now</a>
13	<a href="#">90202-05M38</a> Washer, plate(6l2)	<a href="#">Buy now</a>
14	<a href="#">95680-06100</a> U-nut (6a5)	<a href="#">Buy now</a>
15	<a href="#">65W-42677-00</a> Graphic, front <b>F25A</b>	<a href="#">Buy now</a>


## Top Cowling



Ref	Part	
15	<a href="#">65W-42677-10</a> Graphic, front <b>F20A</b>	<a href="#">Buy now</a>
16	<a href="#">67F-13434-02</a> Label, Caution	<a href="#">Buy now</a>

A4


## Upper Casing



A5

Ref	Part	
1	<a href="#">65W-41137-04-94</a> Guide, Exhaust	<a href="#">Buy now</a>
2	<a href="#">93110-16004</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">68U-41131-00-5B</a> Manifold, ext. 1	<a href="#">Buy now</a>
4	<a href="#">67C-41133-00</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
5	<a href="#">97075-06050</a> Bolt(jf7)	<a href="#">Buy now</a>
6	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
7	<a href="#">65W-45111-00-4D</a> Casing, upper S	<a href="#">Buy now</a>
7	<a href="#">65W-45111-10-4D</a> Casing, upper L	<a href="#">Buy now</a>
8	<a href="#">90119-08M79</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
9	<a href="#">90119-08M82</a> Bolt, with washer(697)	<a href="#">Buy now</a>
10	<a href="#">65W-45151-00</a> Cover, upper casing	<a href="#">Buy now</a>
11	<a href="#">97880-05016</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
12	<a href="#">92990-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">90157-06M06</a> Screw, pan head(6m7)	<a href="#">Buy now</a>
14	<a href="#">65W-45128-00</a> Seal 2	<a href="#">Buy now</a>

# Valve



 65W1010-2050

**B3**

Ref	Part	
1	<a href="#">67C-12111-00</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">62Y-12121-00</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">62Y-12116-00</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">51Y-12114-00</a> Spring, valve outer	<a href="#">Buy now</a>
5	<a href="#">30X-12117-00</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">30X-12118-00</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">51Y-12119-00</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">65W-12146-00</a> Shaft Rocker	<a href="#">Buy now</a>
9	<a href="#">65W-12151-00</a> Arm, valve rocker	<a href="#">Buy now</a>
10	<a href="#">62Y-12159-00</a> Screw Valve Adjusting	<a href="#">Buy now</a>
11	<a href="#">62Y-12158-00</a> Nut, lock	<a href="#">Buy now</a>
12	<a href="#">62Y-12238-00</a> Plate Bolt Stopper	<a href="#">Buy now</a>
13	<a href="#">62Y-12216-00</a> Spring	<a href="#">Buy now</a>
14	<a href="#">62Y-12231-00</a> Guide, stopper 1	<a href="#">Buy now</a>
15	<a href="#">90109-08M63</a> Bolt(6y)	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.