



Yamaha F350AET 2017

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

| | |
|-------------------------------------|-----|
| SCHEDULED SERVICE PARTS | 3 |
| BOTTOM COWLING 1 | 5 |
| BOTTOM COWLING 2 | 8 |
| BOTTOM COWLING 3 | 11 |
| BRACKET 1 | 12 |
| BRACKET 2 | 15 |
| CONTROL | 17 |
| CRANKSHAFT & PISTON | 19 |
| CYLINDER & CRANKCASE 1 | 21 |
| CYLINDER & CRANKCASE 2 | 24 |
| CYLINDER & CRANKCASE 3 | 26 |
| CYLINDER & CRANKCASE 4 | 27 |
| ELECTRICAL 1 | 28 |
| ELECTRICAL 2 | 30 |
| ELECTRICAL 3 | 33 |
| ELECTRICAL 4 | 34 |
| ELECTRICAL 5 | 37 |
| FUEL 1 | 40 |
| FUEL 2 | 43 |
| FUEL INJECTION PUMP 1 | 44 |
| FUEL INJECTION PUMP 2 | 47 |
| GENERATOR | 49 |
| INTAKE 1 | 51 |
| INTAKE 2 | 53 |
| INTAKE 3 | 55 |
| LOWER CASING & DRIVE 1 | 57 |
| LOWER CASING & DRIVE 2 | 64 |
| LOWER CASING & DRIVE 3 | 67 |
| LOWER CASING & DRIVE 4 | 74 |
| OIL PAN | 77 |
| OPTIONAL PARTS 1 | 79 |
| OPTIONAL PARTS 2 | 81 |
| POWER TRIM & TILT ASSY 1 | 82 |
| POWER TRIM & TILT ASSY 2 | 86 |
| REPAIR KIT 1 | 87 |
| REPAIR KIT 2 | 89 |
| STARTING MOTOR | 92 |
| THROTTLE BODY ASSY 1 | 94 |
| THROTTLE BODY ASSY 2 | 96 |
| TOP COWLING | 97 |
| UPPER CASING | 99 |
| VALVE | 103 |


Scheduled Service Parts



6AW7100-M010


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 63P1132501 Anode | Buy now |
| 2 | 6AW1241100 Thermostat | Buy now |
| 3 | 6AW1132R00 Anode 6 | Buy now |
| 4 | 6AW1132P00 Anode 5 | Buy now |
| 5 | N261344002 Element assembly, oil cleaner | Buy now |
| 6 | 67F1132501 Anode | Buy now |
| 7 | 9470200400 Plug, spark (lfr6a-11) | Buy now |
| 8 | 6CB2450101 Filter, fuel | Buy now |
| 9 | 6CB1301600 O-ring | Buy now |
| 10 | 63P1391500 Filter | Buy now |
| 11 | 6CB1498400 Gasket, float chamber | Buy now |
| 12 | 6P32456400 Gasket | Buy now |
| 13 | 6P32456301 Element, filter (with tag) | Buy now |
| 14 | 6E51132500 Anode | Buy now |
| 15 | 6AW4525100 Anode | Buy now |

Scheduled Service Parts



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AW1132S00 Anode 7 | Buy now |
| 17 | 6AW1132T00 Anode 8 | Buy now |
| 18 | 6AW1132U00 Anode 9 | Buy now |
| 19 | 63P1132511 Anode | Buy now |
| 20 | 9043014M09 Gasket | Buy now |
| 21 | 9043008003 Gasket | Buy now |
| 22 | 6AW4537300 Anode | Buy now |
| 23 | 6AWW007800 Water pump repair kit | Buy now |

Bottom Cowling 1




6AWB100-R250

Fig. 7, CYLINDER & CRANKCASE 4
Ref. No. 11
Fig. 23, ELECTRICAL 5
Ref. No. 26, 28, 43
Fig. 25, BOTTOM COWLING 1
Ref. No. 4, 6, 15, 27
Fig. 26, BOTTOM COWLING 2
Ref. No. 14, 17, 26, 40, 41

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW42710028D Bottom cowling assembly | Buy now |
| 2 | 6AW4272501 Grommet | Buy now |
| 3 | 6AW4276100 Stopper | Buy now |
| 4 | 9010906M86 Bolt | Buy now |
| 5 | 6AW4273500 Protector | Buy now |
| 7 | 6AW4261500 Seal | Buy now |
| 8 | 63P4271600 Rubber seal 1 | Buy now |
| 9 | 6AW42815008D Lever, clamp | Buy now |
| 10 | 6AW42816018D Lever, clamp | Buy now |
| 11 | 6AW42817018D Lever, clamp | Buy now |
| 12 | 6AW42828009S Plate, clamp | Buy now |
| 13 | 6AW42829009S Plate, clamp 2 | Buy now |
| 14 | 6AW4272200 Gasket 2 | Buy now |
| 15 | 9010906M81 Bolt | Buy now |
| 16 | 9038115002 Bush, solid | Buy now |

Bottom Cowling 1




6AWB100-R250

Fig. 7, CYLINDER & CRANKCASE 4
Ref. No. 11
Fig. 23, ELECTRICAL 5
Ref. No. 26, 28, 43
Fig. 25, BOTTOM COWLING 1
Ref. No. 4, 6, 15, 27
Fig. 26, BOTTOM COWLING 2
Ref. No. 14, 17, 26, 40, 41

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9020215M37 Washer, plate(6l2) | Buy now |
| 18 | 9020615M18 Washer, wave(6l2) | Buy now |
| 19 | 90201156j2 Washer, plate(j41) | Buy now |
| 20 | 6AW4281801 Lever, clamp | Buy now |
| 21 | 6AW4281901 Lever, clamp | Buy now |
| 22 | 6AW4281A01 Lever, clamp 6 | Buy now |
| 23 | 9020106M30 Washer, plate (6a1) | Buy now |
| 24 | 9010506155 Bolt, flange | Buy now |
| 25 | 9050622001 Spring, tension | Buy now |
| 26 | 66T4314400 Hook, spring | Buy now |
| 28 | 6AW4285100 Cover, clamp | Buy now |
| 29 | 9011106094 Bolt,hex. socket button | Buy now |
| 30 | 9048022M81 Grommet | Buy now |
| 31 | 9038708M37 Coller (6e5) | Buy now |
| 32 | 9011908M22 Bolt, with washer | Buy now |

Bottom Cowling 1




6AWB100-R250

Fig. 7, CYLINDER & CRANKCASE 4
Ref. No. 11
Fig. 23, ELECTRICAL 5
Ref. No. 26, 28, 43
Fig. 25, BOTTOM COWLING 1
Ref. No. 4, 6, 15, 27
Fig. 26, BOTTOM COWLING 2
Ref. No. 14, 17, 26, 40, 41


| Ref | Part | |
|-----|--|-------------------------|
| 33 | 61A4271700 Rubber, seal 2 | Buy now |
| 34 | 6P24439100 Nipple, hose | Buy now |
| 35 | 6H14272621 Grommet | Buy now |
| 36 | 9046511M10 Clamp | Buy now |
| 37 | 6H44274800 Grommet | Buy now |
| 38 | 6AW4272600 Grommet | Buy now |
| 39 | 9048016007 Grommet | Buy now |
| 40 | 68F4275300 Fastner AP | Buy now |
| 41 | 9046420258 Clamp AP | Buy now |
| 42 | 6EE4279440 Label, warning (general) | Buy now |
| 43 | 6EE4279450 Label, warning (general) | Buy now |
| 44 | 6AH8199600 Mark | Buy now |

Bottom Cowling 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW1257200 Adapter | Buy now |
| 2 | 9778060520 Screw, tapping(6k8) | Buy now |
| 3 | 6R31258100 Joint, hose 1 | Buy now |
| 4 | 6AW1258200 Joint, hose 2 | Buy now |
| 5 | 6R31258300 Gasket, hose joint | Buy now |
| 6 | 9044514015 Hose | Buy now |
| 7 | 6AW4278500 Pipe | Buy now |
| 8 | 9044514013 Hose | Buy now |
| 9 | 6AW4216900 Joint | Buy now |
| 10 | 66V2431400 Pipe 4 | Buy now |
| 11 | 90445116J1 Hose (I210) | Buy now |
| 12 | 9046511M10 Clamp | Buy now |
| 13 | 6E58258800 Plate | Buy now |
| 14 | 9010906M81 Bolt | Buy now |
| 15 | 9046508M82 Clamp | Buy now |

Bottom Cowling 2




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6AW4274400 Stay | Buy now |
| 17 | 9010906M86 Bolt | Buy now |
| 18 | 6AW4273300 Box, drain | Buy now |
| 19 | 6AW4273400 Box, drain 2 | Buy now |
| 20 | 69J4271700 Rubber, seal 2 | Buy now |
| 21 | 9589506016 Bolt, flange deep recess | Buy now |
| 22 | 6AW4278600 Hose, drain 1 | Buy now |
| 23 | 6AW4278700 Hose, drain 2 | Buy now |
| 24 | 6AW42723009S Cover, bottom | Buy now |
| 25 | 6AW4272100 Gasket 1 | Buy now |
| 27 | 6AW4276900 Seal, rubber | Buy now |
| 28 | 6AW4262900 Seal | Buy now |
| 29 | 6AW1475000 Silencer assembly | Buy now |
| 31 | 6AW1475E00 Pipe 2 | Buy now |
| 32 | 6AW1476300 Spacer | Buy now |

Bottom Cowling 2




| Ref | Part | |
|-----|--|-------------------------|
| 33 | 9587506025 Bolt, flange deep recess | Buy now |
| 34 | 6AW1475F00 Pipe 3 | Buy now |
| 35 | 6AW1476400CA Spacer | Buy now |
| 37 | 6AW8339X00 Clamp, cord | Buy now |
| 38 | 9046412001 Clamp | Buy now |
| 39 | 6AW4276700 Bracket | Buy now |
| 41 | 9033830256 Plug(8cj) | Buy now |

Bottom Cowling 3




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW42741008D Apron | Buy now |
| 2 | 9048014M17 Grommet(6j8) | Buy now |
| 3 | 6AW42771008D Apron | Buy now |
| 5 | 69J4277410 Stay, apron 1 | Buy now |
| 6 | 9038607001 Bush | Buy now |
| 7 | 9011106144 Bolt,hex. socket button | Buy now |
| 9 | 9011106142 Bolt,hex. socket button | Buy now |
| 10 | 9017306001 Nut, square | Buy now |
| 11 | 6AW45151018D Cover, upper casing | Buy now |
| 12 | 6AW4277500 Stay, apron 2 | Buy now |
| 13 | 9759506514 Bolt(gj3) | Buy now |

Bracket 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW43111008D Bracket, clamp 1 | Buy now |
| 2 | 9131410020 Bolt,socket | Buy now |
| 3 | 9020110049 Washer, plate | Buy now |
| 4 | 6AW4525100 Anode | Buy now |
| 5 | 6G54452600 Plate | Buy now |
| 6 | 9759506530 Bolt, hexagon w/w deep recess | Buy now |
| 7 | 6H18214800 Wire, lead | Buy now |
| 8 | 9759506510 Bolt, hexagon w/w deep recess | Buy now |
| 10 | 9798506212 Screw, with washer(6h3) | Buy now |
| 11 | 61A4313200 Washer, friction | Buy now |
| 12 | 9788506010 Screw pan head | Buy now |
| 13 | 6AW43112008D Bracket, clamp 2 | Buy now |
| 16 | 6AW4311300 Plate, clamp bracket | Buy now |
| 17 | 61A4313300 Washer,friction | Buy now |
| 19 | 9046508M83 Clamp | Buy now |

Bracket 1




| Ref | Part | |
|-----|---|-------------------------|
| 21 | 6R34313110 Bolt, clamp bracket | Buy now |
| 22 | 9038625003 Bush | Buy now |
| 23 | 9020126014 Washer, plate | Buy now |
| 24 | 9018522007 Nut, self-locking | Buy now |
| 25 | 9341021089 Circlip | Buy now |
| 26 | 9046511M10 Clamp | Buy now |
| 28 | 9759506514 Bolt(gj3) | Buy now |
| 29 | 9011910039 Bolt, with washer | Buy now |
| 30 | 9011610047 Bolt, stud | Buy now |
| 31 | 9578010300 Nut, nylon (6e5) | Buy now |
| 32 | 9020110048 Washer, plate | Buy now |
| 33 | 6AW43311008D Bracket, swivel 1 | Buy now |
| 34 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 35 | 6E58214700 Wire, lead 5 | Buy now |
| 37 | 6AW4411600 Spring | Buy now |

Bracket 1




| Ref | Part | |
|-----|--|-------------------------|
| 39 | 6AW4318101 Lever, tilt stop 1 | Buy now |
| 40 | 6AW4318501 Lever, tilt stop 2 | Buy now |
| 41 | 9038610M16 Bushing (688) | Buy now |
| 42 | 6AW4314800 Collar, distance | Buy now |
| 43 | 9169030020 Pin, spring (6h4) | Buy now |
| 44 | 6AW4312601 Pin, upper shock mount | Buy now |
| 45 | 9038618M63 Bush(6e5) | Buy now |
| 46 | 9038618M14 Bushing (6e5) | Buy now |
| 47 | 9341018M05 Circlip (6f2) | Buy now |
| 48 | 9010112031 Bolt (150mm) | Buy now |
| 49 | 9020112060 Washer, plate | Buy now |
| 50 | 9020112426 Washer, plate(663) | Buy now |
| 51 | 9020113M19 Washer, plate (663) | Buy now |
| 52 | 9538012600 Nut (707) | Buy now |

Bracket 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW8367200 Trim sender | Buy now |
| 2 | 9788506016 Screw, pan head(6b0) | Buy now |
| 3 | 6AW4337600 Bolt, thrust receiver | Buy now |
| 4 | 9578010300 Nut, nylon (6e5) | Buy now |
| 5 | 6AW42510018D Steering bracket assembly | Buy now |
| 6 | 9020146008 Washer, plate | Buy now |
| 7 | 9321043001 O-ring | Buy now |
| 8 | 9020245001 Washer, plate | Buy now |
| 9 | 9038645002 Bush | Buy now |
| 10 | 6AW4455100CA Housing, lower mount rubber 1 | Buy now |
| 11 | 9341044087 Circlip | Buy now |
| 12 | 6AW4457500 Damper, lower mount rubber | Buy now |
| 13 | 6AW4455500 Mount damper, lower side | Buy now |
| 14 | 9020232M19 Washer, plate (6e5) | Buy now |
| 15 | 9020116016 Washer, plate | Buy now |

Bracket 2




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AW8214900 Wire, lead 3 | Buy now |
| 17 | 9010114004 Bolt | Buy now |
| 18 | 9020115M58 Washer, plate (6e5) | Buy now |
| 19 | 9018514M00 Nut, self-locking(61a) | Buy now |
| 20 | 9299514600 Washer (6e5) | Buy now |
| 21 | 6AW4455200CA Housing, lower mount rubber 2 | Buy now |
| 22 | 9011910024 Bolt, with washer | Buy now |
| 23 | 6AW4451401 Mount damper, upper side | Buy now |
| 24 | 6AW4453200 Stopper, upper mount | Buy now |
| 25 | 6AW4452600 Plate | Buy now |
| 26 | 9010516003 Bolt, flange | Buy now |
| 27 | 9018516008 Nut, self-locking | Buy now |
| 28 | 9020116030 Washer, plate | Buy now |
| 29 | 6AW4453300 Damper, upper mount rubber | Buy now |
| 30 | 6AW4451101CA Cover, upper mount | Buy now |

Control




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW4417600 Bracket | Buy now |
| 2 | 9011008085 Bolt, hexagon socket head | Buy now |
| 3 | 9299008600 Washer, plain (663) | Buy now |
| 4 | 6AW4412200 Bushing, shift rod lever | Buy now |
| 5 | 6AW4412100 Lever, shift rod | Buy now |
| 6 | 9020111008 Washer, plate | Buy now |
| 7 | 90468180A0 Clip | Buy now |
| 8 | 9046818008 Clip 620436610000 | Buy now |
| 9 | 6AW4412000 Handle gear shift assembly | Buy now |
| 10 | 6AW4411801 Bracket | Buy now |
| 11 | 9759506525 Bolt, hexagon w/w deep recess | Buy now |
| 12 | 9038019001 Bush, solid | Buy now |
| 13 | 9020219001 Washer, plate | Buy now |
| 14 | 9341019088 Circlip | Buy now |
| 15 | 9321009165 O-ring | Buy now |

Control




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AW4820A11 Actuator unit | Buy now |
| 17 | 9046511M10 Clamp | Buy now |
| 18 | 9708008030 Bolt, hexagon (fj1) | Buy now |
| 19 | 9290008600 Washer, plain (663) | Buy now |
| 20 | 9038708M31 Collar | Buy now |
| 21 | 6AW2431410 Pipe 4 | Buy now |
| 23 | 6AW2431400 Pipe 4 | Buy now |
| 24 | 9046416001 Clamp | Buy now |
| 25 | 9046410M59 Clamp | Buy now |
| 26 | 6G82437600 Pipe, joint 1 | Buy now |

Crankshaft & Piston




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW1141110 Crankshaft | Buy now |
| 2 | 9360612019 Pin, dowel (614) | Buy now |
| 3 | 9310285004 Oil seal | Buy now |
| 4 | 6AW1141600 Plane bearing, crankshaft 1 UR YELLOW | Buy now |
| 4 | 6AW1141610 Plane bearing, crankshaft 1 UR GREEN | Buy now |
| 4 | 6AW1141620 Plane bearing, crankshaft 1 UR BROWN | Buy now |
| 4 | 6AW1141630 Plane bearing, crankshaft 1 UR BLACK | Buy now |
| 4 | 6AW1141640 Plane bearing, crankshaft 1 UR BLUE | Buy now |
| 5 | 6AW1141700 Plane bearing, crankshaft 2 UR YELLOW | Buy now |
| 5 | 6AW1141710 Plane bearing, crankshaft 2 UR GREEN | Buy now |
| 5 | 6AW1141720 Plane bearing, crankshaft 2 UR BROWN | Buy now |
| 5 | 6AW1141730 Plane bearing, crankshaft 2 UR BLACK | Buy now |
| 5 | 6AW1141740 Plane bearing, crankshaft 2 UR BLUE | Buy now |
| 6 | 6AW1142601 Bearing, thrust 1 | Buy now |
| 7 | 6AW1142701 Bearing, thrust 2 | Buy now |

Crankshaft & Piston




| Ref | Part | |
|-----|--|-------------------------|
| 8 | 6AWW116500 Connecting rod assembly | Buy now |
| 9 | 63P1165410 Bolt, connecting rod | Buy now |
| 10 | 6AW116311093 Piston (std) | Buy now |
| 11 | 6AW1160300 Piston ring set (std) | Buy now |
| 12 | 63P1163310 Pin, piston | Buy now |
| 13 | 63P1163400 Clip, piston pin | Buy now |
| 14 | 6AW1165600 Plane bearing, connecting rod UR GREEN | Buy now |
| 14 | 6AW1165610 Plane bearing, connecting rod UR BLUE | Buy now |
| 14 | 6AW1165620 Plane bearing, connecting rod UR RED | Buy now |
| 14 | 6AW1165630 Plane bearing, connecting rod UR PURPLE | Buy now |

Cylinder & Crankcase 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW1100000 Long block assembly | Buy now |
| 2 | 6AW1510004 Crankcase assembly | Buy now |
| 3 | 9360612019 Pin, dowel (614) | Buy now |
| 4 | 9181418002 Pin, dowel | Buy now |
| 5 | 6P21518700 Bolt | Buy now |
| 6 | 9010508175 Bolt, flange | Buy now |
| 7 | 6AW15411029S Cover, crankcase 1 | Buy now |
| 8 | 6AW1545100 Gasket, crankcase cover 1 | Buy now |
| 11 | 6AW15319009S Joint | Buy now |
| 12 | 6AW1536400 Gasket, oil plug | Buy now |
| 13 | 9010506155 Bolt, flange | Buy now |
| 14 | 9360408062 Pin,dowel (626) | Buy now |
| 15 | 6AW15421009S Cover, crankcase 2 | Buy now |
| 16 | 6AW1546100 Gasket, crankcase cover 2 | Buy now |
| 17 | 9010506037 Bolt, flange | Buy now |

Cylinder & Crankcase 1




| Ref | Part | |
|-----|---|-------------------------|
| 18 | 63P1132501 Anode | Buy now |
| 19 | 9015106M02 Screw, countersunk | Buy now |
| 20 | 6AW1241100 Thermostat | Buy now |
| 21 | 6AW1241200 Seal, thermostat | Buy now |
| 22 | 6AW12413009S Cover, thermostat | Buy now |
| 23 | 6AW12422009S Cover, housing | Buy now |
| 24 | 6AW1241B009S Cover, thermostat 2 | Buy now |
| 25 | 6AW1242B009S Cover, housing 2 | Buy now |
| 26 | 6AW1242700 Gasket, housing cover 1 | Buy now |
| 27 | 6AW1132R00 Anode 6 | Buy now |
| 28 | 9043005002 Gasket | Buy now |
| 29 | 9010505012 Screw, hexagon | Buy now |
| 30 | 9010506028 Bolt, washer based | Buy now |
| 31 | 6AW1135100 Gasket, cylinder | Buy now |
| 32 | 9321026658 O-ring(36y) | Buy now |

Cylinder & Crankcase 1




| Ref | Part | |
|-----|---|-------------------------|
| 33 | 6AW1466400 Grommet, water shut | Buy now |
| 34 | 6AW1131M009S Cover | Buy now |
| 35 | 6AW1138100 Gasket 1 | Buy now |
| 36 | 9010506039 Bolt, flange | Buy now |
| 37 | 6AW1132P00 Anode 5 | Buy now |
| 38 | 9878006530 Screw, flat head | Buy now |
| 39 | 9046212008 Clamp | Buy now |
| 40 | 9589506012 Bolt, flange deep recess | Buy now |
| 41 | N261344002 Element assembly, oil cleaner | Buy now |
| 42 | 9040119001 Bolt, union | Buy now |
| 43 | 6AW13446009S Connector | Buy now |
| 44 | 6AW1347700 Gasket | Buy now |
| 45 | 9589506045 Bolt, flange deep recess | Buy now |
| 46 | 6G81536300 Plug, oil | Buy now |
| 47 | 9321024M79 O-ring | Buy now |

Cylinder & Crankcase 2




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AWW009A019S Cylinder head complete | Buy now |
| 2 | 6AW1111010 Cylinder head assembly | Buy now |
| 3 | 6S51113310 Guide, valve 1 | Buy now |
| 4 | 9180908006 Pin, dowel | Buy now |
| 5 | 9011907001 Bolt, with washer | Buy now |
| 6 | 9011907234 Bolt, with washer | Buy now |
| 7 | 9034018M09 Plug, straight screw | Buy now |
| 8 | 90201186F1 Washer, plate (22f) | Buy now |
| 9 | 6AWW009C019S Cylinder head 2 complete | Buy now |
| 10 | 6AW1112010 Cylinder head assembly 2 | Buy now |
| 17 | 67F1130100 Anode cover assembly | Buy now |
| 18 | 67F1132501 Anode | Buy now |
| 19 | 67F1132800 Grommet, anode | Buy now |
| 20 | 9010506M07 Bolt (689) | Buy now |
| 21 | 9043006M03 Gasket (6f5) | Buy now |

Cylinder & Crankcase 2



| Ref | Part | |
|-----|--|-------------------------|
| 22 | 9589508025 Bolt, flange deep recess | Buy now |
| 23 | 6AW1118100 Gasket, cylinder head 1 | Buy now |
| 24 | 9038711005 Collar | Buy now |
| 25 | 9015511002 Screw | Buy now |
| 26 | 9010508220 Bolt, flange | Buy now |
| 27 | 9011908115 Bolt, with washer | Buy now |
| 28 | 6AW1118200 Gasket, cylinder head 2 | Buy now |
| 29 | 6AW1119110 Cover, cylinder head 1 | Buy now |
| 30 | 6AW1119310 Gasket, head cover 1 | Buy now |
| 31 | 9589506030 Bolt, flange deep recess | Buy now |
| 32 | 6AW1119210 Cover, cylinder head 2 | Buy now |
| 33 | 6AW1119410 Gasket, head cover 2 | Buy now |
| 35 | 6AW1514200 Guide 1 | Buy now |
| 36 | 9589506014 Bolt, flange deep recess | Buy now |
| 37 | 9470200400 Plug, spark (lfr6a-11) | Buy now |


Cylinder & Crankcase 3



6AW6100-L050


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW1118610 Cover, cylinder head side 2 | Buy now |
| 2 | 9048012314 Grommet(3aa) | Buy now |
| 3 | 6AW1118710 Cover, cylinder head side 3 | Buy now |
| 5 | 6CB8612000 Solenoid valve assembly | Buy now |
| 6 | 6CB1242F00 Gasket, filter | Buy now |
| 7 | 9010506035 Bolt, flange | Buy now |
| 8 | 6AW1135A00 Bracket | Buy now |
| 9 | 9010508240 Bolt, flange | Buy now |
| 10 | 6P28578000 Sensor, knock | Buy now |

Cylinder & Crankcase 4




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW1243A00 Hose 1 | Buy now |
| 2 | 6AW1247700 Pipe 7 | Buy now |
| 3 | 9046511M59 Clamp(63m) | Buy now |
| 4 | 6AW1243E00 Hose 2 | Buy now |
| 5 | 6AW1248400 Pipe 4 | Buy now |
| 7 | 6AW1244G00 Hose, 4 | Buy now |
| 8 | 6AW1249110 Clamp 1 | Buy now |
| 9 | 9759506514 Bolt(gj3) | Buy now |
| 10 | 6AW1247600 Pipe 6 | Buy now |
| 11 | 9010906M86 Bolt | Buy now |
| 12 | 6AW1244J00 Hose 6 | Buy now |
| 13 | 6AW1137800 Hose 2 | Buy now |
| 14 | 93210207A0 O-ring | Buy now |
| 15 | 9589506014 Bolt, flange deep recess | Buy now |
| 16 | 9589506010 Bolt, flange(7ht) | Buy now |

Electrical 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW8591A50 Engine control unit assembly | Buy now |
| 2 | 9011906M82 Bolt, with washer | Buy now |
| 3 | 6AW8599100 Bracket, unit | Buy now |
| 4 | 9046514M66 Clamp | Buy now |
| 5 | 60V8556400 Grommet | Buy now |
| 6 | 9038706176 Collar | Buy now |
| 7 | 68F8511900 Bolt | Buy now |
| 8 | 6AW8591C00 Case, ecu | Buy now |
| 9 | 9759506512 Bolt, hexagon w/w deep recess | Buy now |
| 10 | 9046418246 Clamp(4tr) | Buy now |
| 11 | 9046416240 Clamp | Buy now |
| 12 | 9046513M24 Band, switch cord | Buy now |
| 13 | 6AW8254401 Clamp | Buy now |
| 15 | 6AW8258800 Plate | Buy now |
| 18 | 6AW8365100 Sender, oil pressure | Buy now |

Electrical 1




| Ref | Part | |
|-----|---|-------------------------|
| 19 | 63P8588600 Sensor, air temperature | Buy now |
| 20 | 63P1443500 Grommet | Buy now |

Electrical 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW8195000 Relay assembly | Buy now |
| 2 | 9759506610 Bolt, hexagon w/w deep recess | Buy now |
| 3 | 9751306520 Bolt, with washer(61b) | Buy now |
| 4 | 6G58211910 Cover, lead wire | Buy now |
| 5 | 6AW8194A00 Relay | Buy now |
| 6 | 68V8195300 Stay, relay | Buy now |
| 7 | 9778060620 Screw, tapping(6k8) | Buy now |
| 9 | 6G58211900 Cover, lead wire | Buy now |
| 10 | 6AW8195200 Holder, relay | Buy now |
| 11 | 9046412183 Clamp(jn2) | Buy now |
| 12 | 9046411121 Clamp(4gy) | Buy now |
| 13 | 6A08231700 Damper, ignition coil | Buy now |
| 14 | 9038706119 Collar | Buy now |
| 15 | 9011906M59 Bolt, with washer | Buy now |
| 16 | 6AW8194200 Cover | Buy now |

Electrical 2



| Ref | Part | |
|-----|--|-------------------------|
| 17 | 9589506016 Bolt, flange deep recess | Buy now |
| 18 | 6AW8217003 Fuse box assembly | Buy now |
| 19 | 6P28215100 Fuse (60a) | Buy now |
| 20 | 6AW8195A00 Relay assembly | Buy now |
| 21 | 67F8215140 Fuse (10a) | Buy now |
| 22 | 67F8215150 Fuse (15a) | Buy now |
| 23 | 67F8215100 Fuse | Buy now |
| 24 | 67F8215110 Fuse | Buy now |
| 25 | 6P28554400 Case | Buy now |
| 26 | 6P28163910 Cover | Buy now |
| 27 | 68F8284600 Screw, pan head (m5) | Buy now |
| 28 | 6P28211300 Screw (m3) | Buy now |
| 29 | 67F2812A00 Puller, fuse | Buy now |
| 30 | 9778050620 Screw, tapping | Buy now |
| 31 | 6AW8217100 Stay, fuse box | Buy now |


Electrical 2



6AWB100-R200

| Ref | Part | |
|-----|--|-------------------------|
| 35 | 6AW8257200 Grommet 1 | Buy now |
| 36 | 6AW8257300 Grommet 2 | Buy now |
| 37 | 6AW8194800 Bracket | Buy now |
| 38 | 9589506020 Bolt, flange(jk3) | Buy now |
| 39 | 6AW8167800 Clamp 2 | Buy now |
| 41 | 6AW8144300 Clamp, lead 1 | Buy now |
| 42 | 9778050514 Screw, panhead tapping (682) | Buy now |
| 43 | 9046511M10 Clamp | Buy now |
| 44 | 9046409008 Clamp | Buy now |
| 45 | 6AW8191920 Graphic, regulator | Buy now |
| 46 | 6AW8191931 Graphic, regulator | Buy now |


Electrical 3




6AWB100-R210


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6CB8231000 Ignition coil assembly | Buy now |
| 2 | 6AW8153900 Plate, coil | Buy now |
| 3 | 9589506025 Bolt, flange deep recess | Buy now |
| 4 | 6P28589600 Sensor, cam position | Buy now |
| 5 | 6P28507500 O-ring | Buy now |
| 6 | 9759506520 Bolt(7u8) | Buy now |
| 7 | 6AW8366G10 Bracket 3 | Buy now |
| 8 | 9589506016 Bolt, flange deep recess | Buy now |
| 9 | 9046418246 Clamp(4tr) | Buy now |
| 10 | 9046407009 Clamp | Buy now |
| 11 | 6AW8366B01 Sensor, water pressure | Buy now |
| 12 | 60V8366D00 Adaptor, input | Buy now |
| 13 | 9759506516 Bolt, with washer(6r6) | Buy now |
| 14 | 6AW8235310 Hose | Buy now |

Electrical 4




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW8196002 Rectifier & regulator assembly | Buy now |
| 2 | 9046412002 Clamp | Buy now |
| 3 | 6AW8197500 Plate, rectifier fitting | Buy now |
| 4 | 6AW81972009S Cover, rectifier | Buy now |
| 5 | 6E51132500 Anode | Buy now |
| 6 | 9878004015 Screw, flat head(ga5) | Buy now |
| 7 | 9011906MA3 Bolt, with washer | Buy now |
| 8 | 9011906MA5 Bolt, with washer | Buy now |
| 9 | 6AW8258100 Stay, cord clamp | Buy now |
| 10 | 6AW8235A00 Case 1 | Buy now |
| 11 | 9046514M66 Clamp | Buy now |
| 12 | 9046413249 Clamp | Buy now |
| 13 | 9046411121 Clamp(4gy) | Buy now |
| 14 | 9759506516 Bolt, with washer(6r6) | Buy now |
| 15 | 6AW8361401 Bracket | Buy now |

Electrical 4




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9759506514 Bolt(gj3) | Buy now |
| 17 | 9046444002 Clamp | Buy now |
| 18 | 6AW8132800 Clamp | Buy now |
| 21 | 6AW8121800 Terminal | Buy now |
| 23 | 6AW8192501 Terminal | Buy now |
| 24 | 9759508520 Bolt(6td) | Buy now |
| 25 | 9010108022 Bolt, hexagon deep recess | Buy now |
| 26 | 9299008600 Washer, plain (663) | Buy now |
| 27 | 6AW8259M00 Wire harness assembly 2 | Buy now |
| 28 | 6AW8211701 Wire, lead | Buy now |
| 29 | 9759506616 Bolt, hexagon w/w deep recess | Buy now |
| 30 | 9759506510 Bolt, hexagon w/w deep recess | Buy now |
| 31 | 9759508516 Bolt, hexagon w/w deep recess AP | Buy now |
| 32 | 6AW8210501 Wire harness AP | Buy now |
| 33 | 6AW8211900 Cover, lead wire (black) | Buy now |

Electrical 4




| Ref | Part | |
|-----|--|-------------------------|
| 34 | 6AW8211920 Cover, lead wire (red) | Buy now |

Electrical 5




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW8259031 Wire harness assembly | Buy now |
| 2 | 6AW8A7A100 Protector 1 | Buy now |
| 3 | 6AW8A7A200 Protector 2 | Buy now |
| 4 | 6AW8A7A300 Protector 3 | Buy now |
| 5 | 6AW8A7A400 Protector 4 | Buy now |
| 6 | 6AW8A7A500 Protector 5 | Buy now |
| 7 | 9046409M47 Clamp(65j) | Buy now |
| 8 | 6AW8258901 Protector, wire harness | Buy now |
| 9 | 9759506535 Bolt(j52) | Buy now |
| 10 | 9759506525 Bolt, hexagon w/w deep recess | Buy now |
| 11 | 9759506616 Bolt, hexagon w/w deep recess | Buy now |
| 12 | 9046425005 Clamp | Buy now |
| 13 | 9046513M18 Clamp | Buy now |
| 14 | 9046420181 Clamp(4ap) | Buy now |
| 15 | 9046418246 Clamp(4tr) | Buy now |

Electrical 5




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9048019368 Grommet(75v) | Buy now |
| 17 | 9759506512 Bolt, hexagon w/w deep recess | Buy now |
| 18 | 9048012314 Grommet(3aa) | Buy now |
| 20 | 9010906MA1 Bolt | Buy now |
| 21 | 6AW8238800 Plate | Buy now |
| 22 | 9759506514 Bolt(gj3) | Buy now |
| 23 | 6AW8167700 Clamp 1 | Buy now |
| 25 | 6AW8257G00 Clamp, cord | Buy now |
| 26 | 9010906M86 Bolt | Buy now |
| 27 | 6AW4274300 Bracket | Buy now |
| 29 | 6AW8184510 Plate | Buy now |
| 31 | 9046411121 Clamp(4gy) | Buy now |
| 32 | 61A8579000 Thermosensor assembly | Buy now |
| 33 | 9299010600 Washer, plate | Buy now |
| 34 | 6AW8256000 Thermo switch assembly | Buy now |

Electrical 5




| Ref | Part | |
|-----|--|-------------------------|
| 35 | 6E98258800 Plate | Buy now |
| 36 | 9759506516 Bolt, with washer(6r6) | Buy now |
| 37 | 6AW8256301 Trim & tilt switch assembly | Buy now |
| 38 | 69J4272301 Cover, bottom | Buy now |
| 39 | 69J8258700 Gasket | Buy now |
| 40 | 6AX8361400 Bracket | Buy now |
| 42 | 63P8361401 Bracket | Buy now |
| 44 | 9046514M66 Clamp | Buy now |
| 46 | 9046408051 Clamp (26h) | Buy now |
| 47 | 69J8194902 Wire, lead (isolator, 3.8m) AP | Buy now |

Fuel 1




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6898554700 Damper | Buy now |
| 2 | 6AW2437701 Pipe, joint 2 | Buy now |
| 3 | 6AW2431111 Pipe, fuel 1 | Buy now |
| 4 | 6E52435151 Band 1 | Buy now |
| 5 | 9046511M10 Clamp | Buy now |
| 6 | 6P32456022 Filter assembly | Buy now |
| 7 | 6P32456221 Cup, filter (with tag) | Buy now |
| 8 | 6P32451900 Clip | Buy now |
| 9 | 6P32446900 Float, water level | Buy now |
| 10 | 6P32456400 Gasket | Buy now |
| 11 | 6P32456301 Element, filter (with tag) | Buy now |
| 12 | 9011906M17 Bolt, with washer | Buy now |
| 13 | 9038706289 Collar | Buy now |
| 14 | 9048010M23 Grommet(6k7) | Buy now |
| 15 | 6AW2459600 Cover | Buy now |

Fuel 1




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9759506512 Bolt, hexagon w/w deep recess | Buy now |
| 17 | 9046411121 Clamp(4gy) | Buy now |
| 18 | 9046420181 Clamp(4ap) | Buy now |
| 19 | 6AW2431310 Pipe 3 | Buy now |
| 20 | 6AW2442200 Plate | Buy now |
| 21 | 9589506012 Bolt, flange deep recess | Buy now |
| 22 | 9046411009 Clamp | Buy now |
| 23 | 6AW4411700 Bracket | Buy now |
| 24 | 9589506025 Bolt, flange deep recess | Buy now |
| 25 | 69J2810001 Tool kit AP | Buy now |
| 26 | 6AW281997DE0 Manual,owner's UR (E) | Buy now |
| 26 | 6AW281997DF0 Manual,owner's UR (F) | Buy now |
| 26 | 6AW281997DD0 Manual,owner's UR (NL) | Buy now |
| 26 | 6AW281997DG0 Manual,owner's UR (D) | Buy now |
| 26 | 6AW281997DH0 Manual,owner's UR (I) | Buy now |

Fuel 1



| Ref | Part | |
|-----|---|-------------------------|
| 26 | 6AW281997DS0 Manual,owner's UR (ES) | Buy now |
| 27 | 6AW281998DK0 Manual,owner's UR (DK) | Buy now |
| 27 | 6AW281998DL0 Manual,owner's UR (SF) | Buy now |
| 27 | 6AW281998DM0 Manual,owner's UR (S) | Buy now |
| 27 | 6AW281998DN0 Manual,owner's UR (N) | Buy now |
| 27 | 6AW281998DP0 Manual,owner's UR (P) | Buy now |
| 27 | 6AW281998DR0 Manual,owner's UR (GR) | Buy now |


Fuel 2




6AW6100-L160


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW2436001 Primer pump assembly AP | Buy now |

Fuel Injection Pump 1




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW1418021 Float chamber assembly | Buy now |
| 2 | 6AW1418211 Cover, float chamber | Buy now |
| 3 | 6CB2450101 Filter, fuel | Buy now |
| 4 | 6CB2446000 Relief valve assembly | Buy now |
| 5 | 6CB1301600 O-ring | Buy now |
| 6 | 6CB1421600 Screw | Buy now |
| 7 | 6CB2421700 Cover | Buy now |
| 8 | 6CB1390601 Regulator, pressure | Buy now |
| 9 | 6CB1456400 Screw | Buy now |
| 10 | 6CB1414600 Plate | Buy now |
| 11 | 68V2437910 Pipe, joint 4 | Buy now |
| 12 | 68V1421600 Screw | Buy now |
| 13 | 68V1475H00 Pipe 5 | Buy now |
| 14 | 68V1475J00 Pipe | Buy now |
| 15 | 6CB1418109 Body, Float Chamber 1 | Buy now |

Fuel Injection Pump 1




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6P21419100 Plug, drain | Buy now |
| 17 | 6CB1423900 Seal | Buy now |
| 18 | 6CB2445210 Cover | Buy now |
| 19 | 6CB1442901 Screw | Buy now |
| 20 | 6CB2448200 Gasket 1 | Buy now |
| 21 | 63P1456700 Screw | Buy now |
| 22 | 69J1371600 Collar | Buy now |
| 23 | 6CB1359300 Damper | Buy now |
| 24 | 6AW1390710 Fuel pump comp. | Buy now |
| 25 | 63P1391500 Filter | Buy now |
| 26 | 6AW1313200 Joint | Buy now |
| 27 | 6CB1498500 Float | Buy now |
| 28 | 6CB1454600 Valve, needle | Buy now |
| 29 | 6CB1447B00 Bush and joint set | Buy now |
| 30 | 6AW1378100 Damper, pump | Buy now |

Fuel Injection Pump 1




| Ref | Part | |
|-----|---|-------------------------|
| 31 | 6CB2441000 Fuel pump assembly | Buy now |
| 32 | 6AW2449110 Bracket, fuel pump | Buy now |
| 33 | 6AW1378400 Cover, pump | Buy now |
| 34 | 4SV2445300 Screw | Buy now |
| 35 | 9850704008 Screw, pan head(jg1) | Buy now |
| 36 | 6CB2449200 Bush, fuel pump | Buy now |
| 37 | 6P21438600 Pin, float | Buy now |
| 38 | 6CB2459200 Bolt | Buy now |
| 39 | 6CB1498400 Gasket, float chamber | Buy now |

Fuel Injection Pump 2




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6P21414900 Pipe | Buy now |
| 2 | 6AW2432320 Pipe 12 | Buy now |
| 3 | 6AW2432420 Pipe 13 | Buy now |
| 4 | 6AW2431720 Pipe 7 | Buy now |
| 5 | 69J1413700 Clip | Buy now |
| 6 | 68V1357700 Clip | Buy now |
| 7 | 6E52437800 Pipe, joint 3 | Buy now |
| 8 | 6AW1353200 Hose, vacuum sensing 3 | Buy now |
| 9 | 6P22437600 Pipe, joint 1 | Buy now |
| 10 | 9044618002 Hose | Buy now |
| 11 | 9046412224 Clamp(4pe) | Buy now |
| 12 | 6AW1397130 Pipe, fuel 1 | Buy now |
| 13 | 6AW1397330 Pipe, fuel 3 | Buy now |
| 14 | 6AW1397430 Pipe, fuel 4 | Buy now |
| 15 | 6AW2430010 Fuel pipe joint | Buy now |

Fuel Injection Pump 2




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AW2430000 Fuel pipe joint | Buy now |
| 18 | 6CB2446100 Pipe, joint | Buy now |
| 19 | 9046412012 Clamp | Buy now |

Generator




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AWW814501 F350 rotor kit | Buy now |
| 2 | 6AWW901100 Bolt set | Buy now |
| 3 | 6AW8146000 Base assembly | Buy now |
| 4 | 6AW8558000 Coil, pulser | Buy now |
| 5 | 63D8134500 Screw, pan | Buy now |
| 6 | 9953008012 Pin, dowel(6g8) | Buy now |
| 7 | 9759506630 Bolt, hexagon w/w deep recess | Buy now |
| 8 | 9046210042 Clamp | Buy now |
| 9 | 6AW8133702 Cover, flywheel | Buy now |
| 10 | 6638231701 Damper, ignition coil | Buy now |
| 11 | 9048012314 Grommet(3aa) | Buy now |
| 12 | 9048015M31 Grommet (6g1) | Buy now |
| 13 | 9038706285 Collar | Buy now |
| 14 | 9589506020 Bolt, flange(jk3) | Buy now |
| 15 | 6AW8132G00 Plate | Buy now |

Generator




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9757506514 Bolt, hexagon w/w deep recess | Buy now |
| 17 | 6AW1343762 Mark, caution | Buy now |
| 18 | 6EE8199440 Label, safety | Buy now |
| 19 | 6EE8199450 Label, safety | Buy now |

Intake 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9587508035 Bolt, flange | Buy now |
| 2 | 9953010114 Pin, dowel(3vd) | Buy now |
| 3 | 6AW1378200 Stay | Buy now |
| 4 | 9759506512 Bolt, hexagon w/w deep recess | Buy now |
| 5 | 9046409023 Clamp | Buy now |
| 6 | 6AW1364110 Manifold 1 | Buy now |
| 7 | 6AW1364500 Gasket, manifold 1 | Buy now |
| 8 | 6AW1364600 Gasket, manifold 2 | Buy now |
| 9 | 9011908022 Bolt, with washer | Buy now |
| 10 | 9011906MA6 Bolt, with washer | Buy now |
| 11 | 9046417006 Clamp | Buy now |
| 17 | 6P22417000 Canister assembly | Buy now |
| 18 | 6AW2134X10 Bracket, canister | Buy now |
| 19 | 9589506016 Bolt, flange deep recess | Buy now |
| 20 | 69J2134X00 Bracket, canister | Buy now |

Intake 1




| Ref | Part | |
|-----|--|-------------------------|
| 21 | 9011906M17 Bolt, with washer | Buy now |
| 22 | 9048010M23 Grommet(6k7) | Buy now |
| 23 | 9038706289 Collar | Buy now |
| 24 | 69J2419A01 Holder | Buy now |
| 25 | 9759506516 Bolt, with washer(6r6) | Buy now |
| 26 | 9011906269 Bolt, with washer | Buy now |
| 27 | 6AW2441900 Brkt., separator | Buy now |
| 29 | 9038706276 Collar | Buy now |
| 30 | 9011606046 Bolt, stud | Buy now |
| 31 | 9017906M28 Nut(63v) | Buy now |

Intake 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW1444000 Silencer assembly, intake | Buy now |
| 2 | 9011906M35 Bolt, with washer | Buy now |
| 3 | 6AW1441J00 Pipe, silencer | Buy now |
| 4 | 9046499004 Clamp | Buy now |
| 5 | 6AW1441900 Pipe | Buy now |
| 6 | 6C58612000 Solenoid valve assembly | Buy now |
| 7 | 9538006600 Nut(661) | Buy now |
| 8 | 6AW8611A00 Holder solenoid | Buy now |
| 9 | 9011106144 Bolt, hex. socket button | Buy now |
| 10 | 9046418246 Clamp(4tr) | Buy now |
| 11 | 6AW1537300 Pipe, breather | Buy now |
| 12 | 6AW1444500 Grommet | Buy now |
| 13 | 9778060620 Screw, tapping(6k8) | Buy now |
| 14 | 6AW1539300 Pipe, breather 2 | Buy now |
| 15 | 9757506514 Bolt, hexagon w/w deep recess | Buy now |

Intake 2




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6AW1531A00 Hose, breather 1 | Buy now |
| 17 | 6AW1531A10 Hose, breather 1 | Buy now |
| 18 | 6AW1532A00 Hose, breather 2 | Buy now |
| 19 | 9044632002 Hose | Buy now |

Intake 3




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9046412224 Clamp(4pe) | Buy now |
| 2 | 6AW1475A10 Pipe 1 | Buy now |
| 3 | 6AW2431210 Pipe 2 | Buy now |
| 4 | 6AW1354510 Hose 1 | Buy now |
| 5 | 6882437800 Pipe, joint | Buy now |
| 6 | 6AW1354810 Hose, air 4 | Buy now |
| 7 | 6E52174400 Breezer | Buy now |
| 8 | 6CB1354800 Hose, air 4 | Buy now |
| 10 | 6AW1354710 Hose 3 | Buy now |
| 11 | 9044509104 Hose (I1500) | Buy now |
| 12 | 9046511M10 Clamp | Buy now |
| 13 | 6CE2437601 Pipe, joint 1 | Buy now |
| 14 | 6AW1258900 Hose 6 | Buy now |
| 15 | 9046432002 Clamp | Buy now |
| 16 | 9046409M42 Clamp(6b0) | Buy now |

Intake 3




| Ref | Part | |
|-----|---|-------------------------|
| 17 | 6AW1257620 Hose 1 | Buy now |
| 18 | 9046711136 Clip | Buy now |
| 19 | 9046460067 Clamp(56r) | Buy now |
| 21 | 6AW1257700 Hose 2 | Buy now |
| 22 | 6AW1257800 Hose 3 | Buy now |
| 23 | 68F1448500 Pipe, joint | Buy now |
| 24 | 6AW1257910 Hose 4 | Buy now |
| 25 | 9046410010 Clamp | Buy now |
| 26 | 9044509120 Hose (l1500) | Buy now |
| 27 | 9046708M10 Clip, pipe 6162435600 | Buy now |
| 28 | 6AW1248300 Pipe 3 | Buy now |
| 29 | 9044509026 Hose (l420) | Buy now |
| 31 | 6AW1248210 Pipe 2 | Buy now |
| 32 | 6AW1258800 Hose 5 | Buy now |
| 33 | 9046430005 Clamp | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW45300208D Lower unit assembly X(25.1"),RH | Buy now |
| 1 | 6AW45300318D Lower unit assembly U(30.1"),RH | Buy now |
| 2 | 6AW45311018D Casing, lower | Buy now |
| 3 | 9331193590 Bearing | Buy now |
| 4 | 9334067011 Bearing | Buy now |
| 5 | 9339000031 Bearing | Buy now |
| 6 | 6AW4556700 Shim (t:2.00mm) UR | Buy now |
| 6 | 6AW4556710 Shim (t:2.03mm) UR | Buy now |
| 6 | 6AW4556720 Shim (t:2.06mm) UR | Buy now |
| 6 | 6AW4556730 Shim (t:2.09mm) UR | Buy now |
| 6 | 6AW4556740 Shim (t:2.12mm) UR | Buy now |
| 6 | 6AW4556750 Shim (t:2.15mm) UR | Buy now |
| 7 | 9034008002 Plug, straight screw | Buy now |
| 8 | 6884534110 Plug, drain | Buy now |
| 9 | 9043008003 Gasket | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|---|-------------------------|
| 10 | 6AW4532100 Plate | Buy now |
| 11 | 9321048214 O-ring | Buy now |
| 12 | 9310112M70 Oil seal | Buy now |
| 13 | 9011908M26 Bolt, with washer | Buy now |
| 14 | 6AW4415000 Shift cam assembly X(25.1"),RH | Buy now |
| 14 | 6AW4415010 Shift cam assembly U(30.1"),RH | Buy now |
| 15 | 9900210600 Circlip | Buy now |
| 16 | 90501127J4 Spring, compression(jn9) | Buy now |
| 17 | 6AW4431101 Housing, water pump | Buy now |
| 18 | 9310924001 Oil seal | Buy now |
| 19 | 9342035085 Circlip | Buy now |
| 20 | 6AW4432200 Insert, cartridge | Buy now |
| 21 | 9321094003 O-ring | Buy now |
| 22 | 9321037160 O-ring (6g8) | Buy now |
| 23 | 6AW4436500 Damper, water seal 1 | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|---|-------------------------|
| 24 | 6AW4431200 Cover, water pump housing | Buy now |
| 25 | 6AW4435200 Impeller | Buy now |
| 26 | 6AW4433600 Key | Buy now |
| 27 | 6AW4432300 Outer plate, cartridge | Buy now |
| 28 | 6AW4431500 Gasket, water pump | Buy now |
| 29 | 9360612019 Pin, dowel (614) | Buy now |
| 30 | 9011908M14 Bolt, with washer | Buy now |
| 31 | 6AW4572300 Plate, seal | Buy now |
| 32 | 6AW4533500CA Housing, oil seal | Buy now |
| 33 | 9310128018 Oil seal | Buy now |
| 34 | 9020168008 Washer, plate | Buy now |
| 35 | 6AW4558700 Shim (t:0.10mm) UR | Buy now |
| 35 | 6AW4558710 Shim (t:0.12mm) UR | Buy now |
| 35 | 6AW4558720 Shim (t:0.15mm) UR | Buy now |
| 35 | 6AW4558730 Shim (t:0.18mm) UR | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|---|-------------------------|
| 35 | 6AW4558740 Shim (t:0.30mm) UR | Buy now |
| 35 | 6AW4558750 Shim (t:0.40mm) UR | Buy now |
| 35 | 6AW4558760 Shim (t:0.50mm) UR | Buy now |
| 36 | 9339999962 Bearing | Buy now |
| 37 | 90201301U7 Washer, plate | Buy now |
| 38 | 9021430003 Washer, claw | Buy now |
| 39 | 9017030M18 Nut(6t5) | Buy now |
| 40 | 9321069MG6 O-ring | Buy now |
| 41 | 6AW4534400 Cover, oil seal | Buy now |
| 42 | 9759508520 Bolt(6td) | Buy now |
| 43 | 6AW4550100 Drive shaft comp. X(25.1") | Buy now |
| 43 | 6AW4550110 Drive shaft comp. U(30.1") | Buy now |
| 44 | 6T54553900 Spacer 2 | Buy now |
| 45 | 6AW4524400 Nut | Buy now |
| 46 | 6AW4555000 Gear set | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|--|-------------------------|
| 47 | 9020118023 Washer, plate | Buy now |
| 48 | 9017918009 Nut | Buy now |
| 49 | 9020135015 Washer, plate | Buy now |
| 50 | 6AW4561100 Shaft, propeller | Buy now |
| 51 | 6AW4564100 Shifter | Buy now |
| 52 | 61A4563401 Slide, shift | Buy now |
| 53 | 6AW4563200 Pin, cross | Buy now |
| 54 | 6AW4563100 Clutch, dog | Buy now |
| 55 | 6AW4563300 Ring, cross pin | Buy now |
| 56 | 6H14566800 Shaft, free 1 | Buy now |
| 57 | 61A4563500 Plunger, shift | Buy now |
| 58 | 9020102M00 Washer, plate(61a) | Buy now |
| 59 | 9018302M03 Nut, spring (6h1) | Buy now |
| 60 | 9050110M77 Spring, compression(61a) | Buy now |
| 61 | 9350104011 Ball | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|---|-------------------------|
| 62 | 6AW4561200 Washer, thrust | Buy now |
| 63 | 6AW4533200 Housing, bearing | Buy now |
| 64 | 9330621101 Bearing | Buy now |
| 65 | 6AW4557600 Washer, thrust 2 | Buy now |
| 66 | 6AW4557100 Gear | Buy now |
| 67 | 6AW4557700 Shim (t:0.10mm) UR | Buy now |
| 67 | 6AW4557710 Shim (t:0.12mm) UR | Buy now |
| 67 | 6AW4557720 Shim (t:0.15mm) UR | Buy now |
| 67 | 6AW4557730 Shim (t:0.18mm) UR | Buy now |
| 67 | 6AW4557740 Shim (t:0.30mm) UR | Buy now |
| 67 | 6AW4557750 Shim (t:0.40mm) UR | Buy now |
| 67 | 6AW4557760 Shim (t:0.50mm) UR | Buy now |
| 68 | 9331163591 Bearing | Buy now |
| 69 | 9900947500 Circlip(48y) | Buy now |
| 70 | 9310135018 Oil seal | Buy now |

Lower Casing & Drive 1




| Ref | Part | |
|-----|---|-------------------------|
| 71 | 9321110232 O-ring (278) | Buy now |
| 72 | 9028205008 Key, straight | Buy now |
| 73 | 6AW4538300 Washer, claw | Buy now |
| 74 | 6AW4538400 Nut | Buy now |

Lower Casing & Drive 2




| Ref | Part | |
|-----|---|-------------------------|
| 5 | 6AW4436500 Damper, water seal 1 U(30.1") | Buy now |
| 2 | 6AW4436600 Damper, water seal 2 | Buy now |
| 3 | 6AW4436100 Tube, water 1 | Buy now |
| 4 | 6CE4436200 Tube, water 2 U(30.1") | Buy now |
| 6 | 6AW4431200 Cover, water pump housing U(30.1") | Buy now |
| 7 | 6AW4436300 Tube, water 3 U(30.1") | Buy now |
| 8 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 9 | 9011610041 Bolt, stud U(30.1") | Buy now |
| 9 | 9011910038 Bolt, with washer X(25.1") | Buy now |
| 10 | 9020110048 Washer, plate U(30.1") | Buy now |
| 11 | 9017010009 Nut U(30.1") | Buy now |
| 12 | 9011910008 Bolt, with washer U(30.1") | Buy now |
| 13 | 9011910009 Bolt, with washer U(30.1") | Buy now |
| 13 | 9757510570 Bolt, hexagon w/w deep recess X(25.1") | Buy now |
| 14 | 61A4537600 Guide, seal damper | Buy now |

Lower Casing & Drive 2




| Ref | Part | |
|-----|---|-------------------------|
| 15 | 6AW4537500 Damper, seal | Buy now |
| 16 | 6AW4521400 Cover, water inlet 1 | Buy now |
| 17 | 6AW4521500 Cover, water inlet 2 | Buy now |
| 18 | 9015205003 Screw, countersunk | Buy now |
| 19 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 20 | 6AW4522400 Cover, water inlet 3 | Buy now |
| 22 | 6AW4522500 Cover, water inlet 4 | Buy now |
| 23 | 9011005050 Bolt, hexagon socket head | Buy now |
| 24 | 6AW4537300 Anode | Buy now |
| 25 | 9299010300 Washer | Buy now |
| 26 | 9010510257 Bolt, flange | Buy now |
| 27 | 6AW4561900 Cap | Buy now |
| 28 | 9011010018 Bolt, hexagon socket head | Buy now |
| 29 | 6AW4436700 Damper, water seal 3 | Buy now |
| 30 | 6AW4436200 Tube, water 2 | Buy now |

Lower Casing & Drive 2




| Ref | Part | |
|-----|---|-------------------------|
| 31 | 6AW4437500 Grommet, water tube 1 | Buy now |
| 32 | 6AW4437600 Grommet, water tube 2 | Buy now |
| 33 | 6AW4598700 Spacer 1 | Buy now |
| 34 | 6AW4599700 Spacer 2 | Buy now |
| 35 | 9020119M01 Washer, plate(6u1) | Buy now |
| 36 | 9017118M04 Nut, castle (6e5) | Buy now |
| 37 | 9149040030 Pin, cotter (663) | Buy now |
| 38 | 6AW4597020 Sws xl sds (3x16-1/4x15"-x) UR SDS PROP. | Buy now |
| 38 | 6AW4597220 Sws xl sds (3x16-1/4 x17"-x) UR SDS PROP. | Buy now |
| 38 | 6AW4597420 Sws xl sds (3x15-1/2x19"-x) UR SDS PROP. | Buy now |
| 38 | 6AW4597620 Sws xl sds (3x15-1/4x21"-x) UR SDS PROP. | Buy now |
| 38 | 6AW4597820 Sws xl sds (3x15-1/4x23"-x) UR SDS PROP. | Buy now |
| 39 | 6AW45C8110 Propeller damper rubber assembly | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AX45300208D Lower unit assembly X(25.1"),LH | Buy now |
| 1 | 6AX45300318D Lower unit assembly U(30.1"),LH | Buy now |
| 2 | 6AW45311018D Casing, lower | Buy now |
| 3 | 9331193590 Bearing | Buy now |
| 4 | 9334067011 Bearing | Buy now |
| 5 | 9339000031 Bearing | Buy now |
| 6 | 6AW4556700 Shim (t:2.00mm) UR | Buy now |
| 6 | 6AW4556710 Shim (t:2.03mm) UR | Buy now |
| 6 | 6AW4556720 Shim (t:2.06mm) UR | Buy now |
| 6 | 6AW4556730 Shim (t:2.09mm) UR | Buy now |
| 6 | 6AW4556740 Shim (t:2.12mm) UR | Buy now |
| 6 | 6AW4556750 Shim (t:2.15mm) UR | Buy now |
| 7 | 9034008002 Plug, straight screw | Buy now |
| 8 | 6884534110 Plug, drain | Buy now |
| 9 | 9043008003 Gasket | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|---|-------------------------|
| 10 | 6AW4532100 Plate | Buy now |
| 11 | 9321048214 O-ring | Buy now |
| 12 | 9310112M70 Oil seal | Buy now |
| 13 | 9011908M26 Bolt, with washer | Buy now |
| 14 | 6AX4415000 Shift cam assembly X(25.1"),LH | Buy now |
| 14 | 6AX4415010 Shift cam assembly U(30.1"),LH | Buy now |
| 15 | 9900210600 Circlip | Buy now |
| 16 | 90501127J4 Spring, compression(jn9) | Buy now |
| 17 | 6AW4431101 Housing, water pump | Buy now |
| 18 | 9310924001 Oil seal | Buy now |
| 19 | 9342035085 Circlip | Buy now |
| 20 | 6AW4432200 Insert, cartridge | Buy now |
| 21 | 9321094003 O-ring | Buy now |
| 22 | 9321037160 O-ring (6g8) | Buy now |
| 23 | 6AW4436500 Damper, water seal 1 | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|--|-------------------------|
| 24 | 6AW4431200 Cover, water pump housing | Buy now |
| 25 | 6AW4435200 Impeller | Buy now |
| 26 | 6AW4433600 Key | Buy now |
| 27 | 6AW4432300 Outer plate, cartridge | Buy now |
| 28 | 6AW4431500 Gasket, water pump | Buy now |
| 29 | 9360612019 Pin, dowel (614) | Buy now |
| 30 | 9011908M14 Bolt, with washer | Buy now |
| 31 | 6AW4572300 Plate, seal | Buy now |
| 32 | 6AW4533500CA Housing, oil seal | Buy now |
| 33 | 9310128018 Oil seal | Buy now |
| 34 | 9020168008 Washer, plate | Buy now |
| 35 | 6AW4558700 Shim (t:0.10mm) UR | Buy now |
| 35 | 6AW4558710 Shim (t:0.12mm) UR | Buy now |
| 35 | 6AW4558720 Shim (t:0.15mm) UR | Buy now |
| 35 | 6AW4558730 Shim (t:0.18mm) UR | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|---|-------------------------|
| 35 | 6AW4558740 Shim (t:0.30mm) UR | Buy now |
| 35 | 6AW4558750 Shim (t:0.40mm) UR | Buy now |
| 35 | 6AW4558760 Shim (t:0.50mm) UR | Buy now |
| 36 | 9339999962 Bearing | Buy now |
| 37 | 90201301U7 Washer, plate | Buy now |
| 38 | 9021430003 Washer, claw | Buy now |
| 39 | 9017030M18 Nut(6t5) | Buy now |
| 40 | 9321069MG6 O-ring | Buy now |
| 41 | 6AW4534400 Cover, oil seal | Buy now |
| 42 | 9759508520 Bolt(6td) | Buy now |
| 43 | 6AW4550100 Drive shaft comp. X(25.1") | Buy now |
| 43 | 6AW4550110 Drive shaft comp. U(30.1") | Buy now |
| 44 | 6T54553900 Spacer 2 | Buy now |
| 45 | 6AW4524400 Nut | Buy now |
| 46 | 6AX4555000 Gear set | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|--|-------------------------|
| 47 | 9020118023 Washer, plate | Buy now |
| 48 | 9017918009 Nut | Buy now |
| 49 | 6AX4556002 Gear (26t) | Buy now |
| 50 | 6AX4561100 Shaft, propeller | Buy now |
| 51 | 6AX4564100 Shifter | Buy now |
| 52 | 61A4563401 Slide, shift | Buy now |
| 53 | 6AW4563200 Pin, cross | Buy now |
| 54 | 6AW4563100 Clutch, dog | Buy now |
| 55 | 6AW4563300 Ring, cross pin | Buy now |
| 56 | 6H14566800 Shaft, free 1 | Buy now |
| 57 | 61A4563500 Plunger, shift | Buy now |
| 58 | 9020102M00 Washer, plate(61a) | Buy now |
| 59 | 9018302M03 Nut, spring (6h1) | Buy now |
| 60 | 9050110M77 Spring, compression(61a) | Buy now |
| 61 | 9350104011 Ball | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|---|-------------------------|
| 62 | 93341440U5 Bearing, thrust (6k0) | Buy now |
| 63 | 6K14557801 Shim (t:0.10mm) UR | Buy now |
| 63 | 6K14557810 Shim (t:0.12mm) UR | Buy now |
| 63 | 6K14557820 Shim (t:0.15mm) UR | Buy now |
| 63 | 6K14557830 Shim (t:0.18mm) UR | Buy now |
| 63 | 6K14557840 Shim (t:0.30mm) UR | Buy now |
| 63 | 6K14557850 Shim (t:0.40mm) UR | Buy now |
| 63 | 6K14557860 Shim (t:0.50mm) UR | Buy now |
| 64 | 6AX4533200 Housing, bearing | Buy now |
| 65 | 93332000A2 Bearing | Buy now |
| 66 | 6AW4557600 Washer, thrust 2 | Buy now |
| 67 | 6AW4557700 Shim (t:0.10mm) UR | Buy now |
| 67 | 6AW4557710 Shim (t:0.12mm) UR | Buy now |
| 67 | 6AW4557720 Shim (t:0.15mm) UR | Buy now |
| 67 | 6AW4557730 Shim (t:0.18mm) UR | Buy now |

Lower Casing & Drive 3




| Ref | Part | |
|-----|---|-------------------------|
| 67 | 6AW4557740 Shim (t:0.30mm) UR | Buy now |
| 67 | 6AW4557750 Shim (t:0.40mm) UR | Buy now |
| 67 | 6AW4557760 Shim (t:0.50mm) UR | Buy now |
| 68 | 9331163591 Bearing | Buy now |
| 69 | 9900947500 Circlip(48y) | Buy now |
| 70 | 9310135018 Oil seal | Buy now |
| 71 | 9321110232 O-ring (278) | Buy now |
| 72 | 9028205008 Key, straight | Buy now |
| 73 | 6AW4538300 Washer, claw | Buy now |
| 74 | 6AW4538400 Nut | Buy now |

Lower Casing & Drive 4




| Ref | Part | |
|-----|---|-------------------------|
| 5 | 6AW4436500 Damper, water seal 1 U(30.1") | Buy now |
| 2 | 6AW4436600 Damper, water seal 2 | Buy now |
| 3 | 6AW4436100 Tube, water 1 | Buy now |
| 4 | 6CE4436200 Tube, water 2 U(30.1") | Buy now |
| 6 | 6AW4431200 Cover, water pump housing U(30.1") | Buy now |
| 7 | 6AW4436300 Tube, water 3 U(30.1") | Buy now |
| 8 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 9 | 9011610041 Bolt, stud U(30.1") | Buy now |
| 9 | 9011910038 Bolt, with washer X(25.1") | Buy now |
| 10 | 9020110048 Washer, plate U(30.1") | Buy now |
| 11 | 9017010009 Nut U(30.1") | Buy now |
| 12 | 9011910008 Bolt, with washer U(30.1") | Buy now |
| 13 | 9011910009 Bolt, with washer U(30.1") | Buy now |
| 13 | 9757510570 Bolt, hexagon w/w deep recess X(25.1") | Buy now |
| 14 | 61A4537600 Guide, seal damper | Buy now |

Lower Casing & Drive 4




| Ref | Part | |
|-----|---|-------------------------|
| 15 | 6AW4537500 Damper, seal | Buy now |
| 16 | 6AW4521400 Cover, water inlet 1 | Buy now |
| 17 | 6AW4521500 Cover, water inlet 2 | Buy now |
| 18 | 9015205003 Screw, countersunk | Buy now |
| 19 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 20 | 6AW4522400 Cover, water inlet 3 | Buy now |
| 22 | 6AW4522500 Cover, water inlet 4 | Buy now |
| 23 | 9011005050 Bolt, hexagon socket head | Buy now |
| 24 | 6AW4537300 Anode | Buy now |
| 25 | 9299010300 Washer | Buy now |
| 26 | 9010510257 Bolt, flange | Buy now |
| 27 | 6AW4561900 Cap | Buy now |
| 28 | 9011010018 Bolt, hexagon socket head | Buy now |
| 29 | 6AW4436700 Damper, water seal 3 | Buy now |
| 30 | 6AW4436200 Tube, water 2 | Buy now |

Lower Casing & Drive 4




| Ref | Part | |
|-----|--|-------------------------|
| 31 | 6AW4437500 Grommet, water tube 1 | Buy now |
| 32 | 6AW4437600 Grommet, water tube 2 | Buy now |
| 33 | 6AW4598700 Spacer 1 | Buy now |
| 34 | 6AW4599700 Spacer 2 | Buy now |
| 35 | 9020119M01 Washer, plate(6u1) | Buy now |
| 36 | 9017118M04 Nut, castle (6e5) | Buy now |
| 37 | 9149040030 Pin, cotter (663) | Buy now |
| 38 | 6AX4597020 Sws xl sds (3x16-1/4x15"-xl) UR SDS PROP. | Buy now |
| 38 | 6AX4597220 Sws xl sds (3x16-1/4x17"-xl) UR SDS PROP. | Buy now |
| 38 | 6AX4597420 Sws xl sds (3x15-1/2x19"-xl) UR SDS PROP. | Buy now |
| 38 | 6AX4597620 Sws xl sds (3x15-1/4x21"-xl) UR SDS PROP. | Buy now |
| 38 | 6AX4597820 Sws xl sds (3x15-1/4x23"-xl) UR SDS PROP. | Buy now |
| 39 | 6AW45C8110 Propeller damper rubber assembly | Buy now |

Oil Pan




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW1531200 Gasket, oil pan | Buy now |
| 2 | 6AW1531100CA Oil pan | Buy now |
| 3 | 9757508570 Bolt, hexagon w/w deep recess | Buy now |
| 4 | 9360816M16 Pin, dowel(6t4) | Buy now |
| 5 | 9034014M06 Plug, straight screw(62y) | Buy now |
| 6 | 9043014M09 Gasket | Buy now |
| 7 | 6AW1341100 Strainer, oil | Buy now |
| 8 | 9038706263 Collar | Buy now |
| 9 | 6AW1341500 Seal, oil strainer | Buy now |
| 10 | 9581206025 Bolt, flange | Buy now |
| 11 | 6AW1330002 Oil pump assembly | Buy now |
| 12 | 6CB1332900 Gasket, pump cover | Buy now |
| 13 | 6AW1311900 Oil seal | Buy now |
| 14 | 6AW1363100 Oil seal | Buy now |
| 15 | 69J1135500 Seal, cylinder 1 | Buy now |

Oil Pan



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9707506050 Bolt(jf7) | Buy now |
| 17 | 9299506600 Washer, plain (646) | Buy now |
| 18 | 9321026658 O-ring(36y) | Buy now |
| 19 | 6AW1536201 Plug, oil level | Buy now |
| 20 | 6AW1537700 Guide, inlet | Buy now |
| 21 | 9321019MJ3 O-ring | Buy now |
| 22 | 9589506016 Bolt, flange deep recess | Buy now |
| 23 | 6AW1349001 Relief valve assembly | Buy now |


Optional Parts 1



6CJ1100-K370

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6Y88626700 Case complete 1 | Buy now |
| 2 | 6Y88626002 Remote control unit assembly | Buy now |
| 3 | 6AA8626100 Xmtr. comp. | Buy now |
| 4 | 9798006216 Screw, with washer(6h2) | Buy now |
| 5 | 6X48338300 Buzzer | Buy now |
| 6 | 6X48338600 Stay, buzzer | Buy now |
| 7 | 9778060620 Screw, tapping(6k8) | Buy now |
| 8 | 6Y88250910 Wire, sub lead | Buy now |
| 9 | 9321004279 O-ring (4a0) | Buy now |
| 10 | 9046511M10 Clamp | Buy now |
| 11 | 6Y88454G00 Patch 1 | Buy now |
| 12 | 9016706M00 Screw, tapping (6h4) UR | Buy now |
| 12 | 9788006035 Screw, pan head(6h4) UR | Buy now |
| 13 | 9020106M30 Washer, plate (6a1) | Buy now |
| 14 | 9578006300 Nut, nylon (6g1) | Buy now |


Optional Parts 1



6CJ1100-K370

| Ref | Part | |
|-----|---|-------------------------|
| 15 | 6Y88252111 Pigtail bus wire 0.6m-2ft | Buy now |
| 16 | 6Y84827700 Sticker 1 | Buy now |


Optional Parts 2



6AX4110-K350


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6Y88131501 Lead wire assembly AP | Buy now |
| 2 | 6TA8215100 Fuse (12v 5a) | Buy now |

Power Trim & Tilt Assy 1




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW4380005 Power trim & tilt assembly | Buy now |
| 2 | 6AW4382503 Housing, trim & tilt | Buy now |
| 3 | 6AW4389H00 O-ring | Buy now |
| 4 | 6AW4387100 Ring, back up | Buy now |
| 5 | 6AW4380R01 Cylinder end sub assembly | Buy now |
| 6 | 6AW4382101 Screw, trim cylinder end | Buy now |
| 7 | 6AW4384J00 Seal, trim down | Buy now |
| 8 | 6E54386200 O-ring 2 | Buy now |
| 9 | 6AW4382200 Seal, trim dust | Buy now |
| 10 | 6AW4382001 Trim piston sub assembly | Buy now |
| 11 | 6G54386400 O-ring 4 | Buy now |
| 13 | 6AW4381300 Cylinder, tilt | Buy now |
| 14 | 6AW4381001 Tilt piston sub assembly | Buy now |
| 16 | 64E4386600 O-ring 6 | Buy now |
| 17 | 6AW4381400 Piston, free | Buy now |

Power Trim & Tilt Assy 1




| Ref | Part | |
|-----|--|-------------------------|
| 18 | 64E4385800 Ball | Buy now |
| 19 | 6AW4381A01 Shaft | Buy now |
| 20 | 6AW4387G00 Washer | Buy now |
| 21 | 64E4386800 O-ring 8 | Buy now |
| 22 | 64E4383100 Connector, shaft | Buy now |
| 23 | 6AW4387900 Screw, With Washer | Buy now |
| 24 | 6AW4382800 Body, reservoir | Buy now |
| 25 | 6AW4388700 Bolt | Buy now |
| 26 | 6AW4382900 Plug, reservoir | Buy now |
| 27 | 6AW4389700 O-ring | Buy now |
| 28 | 6AW4388E00 Bolt ,screw | Buy now |
| 29 | 64E4381711 Filter 2 | Buy now |
| 30 | 6AW4387800 Bolt, socket | Buy now |
| 31 | 6AW4388800 Bolt, socket | Buy now |
| 32 | 6AW4383000 Gear pump assembly | Buy now |

Power Trim & Tilt Assy 1




| Ref | Part | |
|-----|---|-------------------------|
| 33 | 6AW4388600 Bolt | Buy now |
| 34 | 6AW4385800 Ball | Buy now |
| 35 | 6AW4380200 Valve Sub assembly | Buy now |
| 36 | 6E54389600 O-ring | Buy now |
| 37 | 6AW4385600 Spring Down Relief | Buy now |
| 38 | 6AW4388J00 Plug 2 | Buy now |
| 39 | 6AW4386900 O-ring | Buy now |
| 40 | 6AW4384H00 Spring | Buy now |
| 41 | 6AW4384400 Pin Valve Support | Buy now |
| 42 | 6G54386300 O-ring 3 | Buy now |
| 43 | 6AW4382G00 Valve seat | Buy now |
| 44 | 6AW4386001 Manual valve sub-assembly | Buy now |
| 46 | 72X85075L0 O-ring (nsd161) | Buy now |
| 47 | 64E4387A00 O-ring | Buy now |
| 48 | 64E4387300 Ring, back up | Buy now |

Power Trim & Tilt Assy 1




| Ref | Part | |
|-----|---|-------------------------|
| 49 | 6AW4387500 Ring, snap | Buy now |
| 50 | 6AW4381G00 Pin 1 | Buy now |
| 51 | 6AW4386100 O-ring | Buy now |
| 52 | 6AW4381700 Filter 2 | Buy now |
| 53 | 6AW4380900 Seat valve comp. 2 | Buy now |
| 54 | 64E4381600 Filter 1 | Buy now |
| 55 | 6AX4388J00 Plug 2 | Buy now |
| 56 | 64E4386500 O-ring 10 | Buy now |
| 57 | 6AW4388H00 Plug | Buy now |
| 58 | 6AW4389J00 O-ring | Buy now |
| 59 | 6AW4389900 Plate stopper | Buy now |
| 60 | 6H18214800 Wire, lead | Buy now |
| 61 | 9759506510 Bolt, hexagon w/w deep recess | Buy now |
| 62 | 6AW8214800 Wire, lead 4 | Buy now |

Power Trim & Tilt Assy 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW4388002 Motor assembly | Buy now |
| 2 | 6AW4388200 Oil seal | Buy now |
| 3 | 6AW4380500 Armature assembly | Buy now |
| 4 | 6AW4384300 Screw | Buy now |
| 5 | 6AW4380401 Stator assembly | Buy now |
| 6 | 6AW4388112 Frame, end | Buy now |
| 7 | 6AX4388700 Bolt | Buy now |
| 8 | 6AW4313800 Nut | Buy now |
| 9 | 6AW4384200 Screw | Buy now |
| 10 | 6AW4380J00 Holder Brush | Buy now |
| 11 | 6AW4386K00 Spring, brush | Buy now |

Repair Kit 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AWW000101 Power head gasket kit | Buy now |
| 2 | 6AW1118100 Gasket, cylinder head 1 | Buy now |
| 3 | 6AW1118200 Gasket, cylinder head 2 | Buy now |
| 4 | 6AW1119310 Gasket, head cover 1 | Buy now |
| 5 | 6AW1119410 Gasket, head cover 2 | Buy now |
| 6 | 6AW1545100 Gasket, crankcase cover 1 | Buy now |
| 7 | 6AW1536400 Gasket, oil plug | Buy now |
| 8 | 6AW1546100 Gasket, crankcase cover 2 | Buy now |
| 9 | 6AW1242700 Gasket, housing cover 1 | Buy now |
| 10 | 9043005002 Gasket | Buy now |
| 11 | 93210207A0 O-ring | Buy now |
| 12 | 6AW1135100 Gasket, cylinder | Buy now |
| 13 | 9321026658 O-ring(36y) | Buy now |
| 14 | 6AW1466400 Grommet, water shut | Buy now |
| 15 | 6AW1138100 Gasket 1 | Buy now |

Repair Kit 1




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9310285004 Oil seal | Buy now |
| 17 | 9310238008 Oil seal | Buy now |
| 18 | 69J1135500 Seal, cylinder 1 | Buy now |
| 20 | 6AW1347700 Gasket | Buy now |
| 21 | 9321024M79 O-ring | Buy now |
| 22 | 6CB1242F00 Gasket, filter | Buy now |

Repair Kit 2




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AWW000121 Lower unit gasket kit | Buy now |
| 2 | 6AW1531200 Gasket, oil pan | Buy now |
| 3 | 9043014M09 Gasket | Buy now |
| 4 | 6AW1341500 Seal, oil strainer | Buy now |
| 5 | 9321019MJ3 O-ring | Buy now |
| 6 | 93210347A1 O-ring | Buy now |
| 7 | 9321028543 O-ring(72f) | Buy now |
| 8 | 9321019758 O-ring(m01) | Buy now |
| 9 | 6AW4113402 Gasket, exhaust manifold | Buy now |
| 10 | 6AW4113800 Seal, ext. 1 | Buy now |
| 11 | 6AW4113500 Gasket, exhaust manifold | Buy now |
| 12 | 6AW4113600 Gasket, exhaust manifold 4 | Buy now |
| 13 | 6AW4512700 Seal | Buy now |
| 14 | 69J4512300 Gasket, muffler | Buy now |
| 15 | 6AW4511300 Gasket, upper casing | Buy now |

Repair Kit 2




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6AW4436600 Damper, water seal 2 | Buy now |
| 17 | 9043008003 Gasket | Buy now |
| 18 | 9321048214 O-ring | Buy now |
| 19 | 9310112M70 Oil seal | Buy now |
| 20 | 9310924001 Oil seal | Buy now |
| 21 | 9321094003 O-ring | Buy now |
| 22 | 9321037160 O-ring (6g8) | Buy now |
| 23 | 6AW4436500 Damper, water seal 1 | Buy now |
| 24 | 6AW4431500 Gasket, water pump | Buy now |
| 25 | 9310128018 Oil seal | Buy now |
| 26 | 9321069MG6 O-ring | Buy now |
| 27 | 9310135018 Oil seal | Buy now |
| 28 | 9321110232 O-ring (278) | Buy now |
| 29 | 6AWW007800 Water pump repair kit | Buy now |
| 30 | 6AW4432200 Insert, cartridge | Buy now |

Repair Kit 2




| Ref | Part | |
|-----|--|-------------------------|
| 33 | 6AW4435200 Impeller | Buy now |
| 34 | 6AW4433600 Key | Buy now |
| 35 | 6AW4432300 Outer plate, cartridge | Buy now |
| 37 | 9360612019 Pin, dowel (614) | Buy now |
| 38 | 9011908M14 Bolt, with washer | Buy now |

Starting Motor




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW8180000 Starting motor assembly | Buy now |
| 2 | 6AW8183000 Front bracket assembly | Buy now |
| 3 | 6AW8180700 Gear assembly, starting motor | Buy now |
| 4 | 6AW8183600 Spring, lever | Buy now |
| 5 | 6AW8189100 Gear, ring | Buy now |
| 6 | 6AW8183T00 Gear, idler | Buy now |
| 7 | 6AW8183200 Clutch, over run | Buy now |
| 8 | 6AW8180800 Pinion assembly | Buy now |
| 9 | 6AW8185700 Pinion stopper set | Buy now |
| 10 | 6AW8186200 Cap | Buy now |
| 11 | 6AW8183R00 Packing set | Buy now |
| 12 | 6AW8185400 Ball, steel | Buy now |
| 13 | 6AW8185000 Armature assembly | Buy now |
| 14 | 6AW8183900 Lever assembly | Buy now |
| 15 | 6AW8184200 Packing | Buy now |

Starting Motor




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6AW8181000 Stator assembly | Buy now |
| 17 | 6AW8184000 Brush holder assembly | Buy now |
| 18 | 6AW8182000 Rear bracket assembly | Buy now |
| 19 | 6AW8182600 Bolt | Buy now |
| 20 | 6AW8184600 Screw | Buy now |
| 21 | 6AW8194100 Starter relay assembly | Buy now |
| 22 | 9751308545 Bolt, with washer | Buy now |
| 23 | 9017908003 Nut | Buy now |

Throttle Body Assy 1



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW1375001 Throttle body assembly | Buy now |
| 2 | 6AW1375100 Body, throttle 1 | Buy now |
| 3 | 6AW1371101 Mixing body | Buy now |
| 4 | 6AW1355600 Gasket, manifold | Buy now |
| 5 | 6AW1355700 Gasket | Buy now |
| 6 | 6AW1436000 Throttle damper assembly | Buy now |
| 7 | 6P21358800 Nut | Buy now |
| 8 | 6P21357800 Washer | Buy now |
| 9 | 6P21449600 Bolt | Buy now |
| 10 | 6P28238000 Sensor, pressure | Buy now |
| 11 | 6P21357300 Bolt 1 | Buy now |
| 12 | 68V1435600 Washer, spring | Buy now |
| 13 | 4N01425100 Nipple | Buy now |
| 14 | 5JW2431100 Pipe, fuel 1 | Buy now |
| 15 | 6AW8236400 Hose 2 | Buy now |


Throttle Body Assy 1



6AW1110-G100


| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6AW8236500 Hose 3 | Buy now |
| 17 | 6AW1118800 Clip, pipe | Buy now |
| 18 | 6AW8236600 Hose 4 | Buy now |

Throttle Body Assy 2



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW1316010 Delivery pipe assembly 1 | Buy now |
| 2 | 6AW1316110 Pipe, delivery 1 | Buy now |
| 3 | 6AW1376100 Injector | Buy now |
| 4 | 6AW1410B00 Packing kit | Buy now |
| 5 | 6AW1357710 Clip | Buy now |
| 6 | 9010506M08 Bolt (689) | Buy now |
| 7 | 6AW1317010 Delivery pipe assembly 2 | Buy now |
| 8 | 6AW1317110 Pipe, delivery 2 | Buy now |


Top Cowling




6AWB300-R020

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6AW4261030 Top cowling assembly | Buy now |
| 2 | 6AW4261A00 Top cowling w/o graphics | Buy now |
| 3 | 9778060516 Screw, panhead tapping (j20) | Buy now |
| 4 | 9299506200 Ybs66-6 washer, plain | Buy now |
| 5 | 6AW4253200 Cover | Buy now |
| 6 | 6AW42647009S Holder, clamp band | Buy now |
| 7 | 6AW4266300 Damper 2 | Buy now |
| 8 | 6AW4264A00 Hook assembly | Buy now |
| 9 | 6AW4264610 Plate, clamp | Buy now |
| 10 | 9578008300 Nut, nylon (6j8) | Buy now |
| 11 | 9299006100 Washer(6a1) | Buy now |
| 12 | 9538006600 Nut(661) | Buy now |
| 13 | 6AW4247700 Plate, lock | Buy now |
| 14 | 9798505210 Screw, With Washer | Buy now |
| 15 | 6AW4262820 Seal | Buy now |


Top Cowling




6AWB300-R020


| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6AW4269710 Tuning fork mark | Buy now |
| 17 | 6AH4273500 Protector | Buy now |
| 18 | 6AW4267810 Graphic, rear | Buy now |
| 19 | 6AW4267A00 Graphic, rear 2 | Buy now |
| 20 | 6AW4267510 Graphic, side 1 | Buy now |
| 21 | 6AW4267610 Graphic, side 2 | Buy now |
| 22 | 6AW4267710 Graphic, front | Buy now |
| 23 | 6AW4268110 Mark, cowling | Buy now |
| 24 | 6AW4268210 Mark, cowling | Buy now |

Upper Casing




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AW4113711CA Guide, exhaust | Buy now |
| 2 | 6H11137200 Nipple, hose | Buy now |
| 3 | 6AW1475G00 Pipe 4 | Buy now |
| 4 | 6AW1475J00 Pipe | Buy now |
| 5 | 6AW1244H00 Hose 5 | Buy now |
| 6 | 6AW1243F00 Hose,3 | Buy now |
| 7 | 9046511M59 Clamp(63m) | Buy now |
| 8 | 9011908102 Bolt, with washer | Buy now |
| 9 | 9757510545 Bolt, hexagon w/w deep recess | Buy now |
| 10 | 9011910040 Bolt, with washer | Buy now |
| 11 | 9757510585 Bolt, hexagon w/w deep recess | Buy now |
| 12 | 9360816M16 Pin, dowel(6t4) | Buy now |
| 13 | 6AW4272400 Grommet | Buy now |
| 14 | 6AW1137110 Pressure control valve assembly | Buy now |
| 15 | 93210347A1 O-ring | Buy now |

Upper Casing




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9321028543 O-ring(72f) | Buy now |
| 17 | 69J1223300 Plate, guide stopper 1 | Buy now |
| 18 | 9038706037 Collar 8121444900 | Buy now |
| 19 | 9759506520 Bolt(7u8) | Buy now |
| 20 | 6AW1119700 Plug, blind | Buy now |
| 21 | 9321019758 O-ring(m01) | Buy now |
| 22 | 6AW1132S00 Anode 7 | Buy now |
| 23 | 9878005550 Screw, flat head | Buy now |
| 24 | 6AW1132T00 Anode 8 | Buy now |
| 25 | 6AW1132U00 Anode 9 | Buy now |
| 27 | 63P1132511 Anode | Buy now |
| 28 | 9015106M02 Screw, countersunk | Buy now |
| 29 | 6AW4113101CA Manifold, ext. 1 | Buy now |
| 31 | 6AW41132009S Manifold, exhaust | Buy now |
| 32 | 6AW4113402 Gasket, exhaust manifold | Buy now |

Upper Casing




| Ref | Part | |
|-----|--|-------------------------|
| 33 | 9011908117 Bolt, with washer | Buy now |
| 34 | 6AW4113800 Seal, ext. 1 | Buy now |
| 35 | 6AW4113500 Gasket, exhaust manifold | Buy now |
| 36 | 6AW45181019S Plate | Buy now |
| 37 | 6AW4113600 Gasket, exhaust manifold 4 | Buy now |
| 38 | 6AW14711009S Muffler 1 | Buy now |
| 39 | 9757508535 Bolt(70w) | Buy now |
| 40 | 9360619M23 Pin, dowel | Buy now |
| 41 | 6AW4512700 Seal | Buy now |
| 42 | 69J4512300 Gasket, muffler | Buy now |
| 43 | 6AW45111108D Casing, upper | Buy now |
| 44 | 6AW4511300 Gasket, upper casing | Buy now |
| 45 | 9011910007 Bolt, with washer | Buy now |
| 47 | 69J1531600 Damper 1 | Buy now |
| 48 | 69J4515210 Cover, upper casing 2 | Buy now |

Upper Casing




| Ref | Part | |
|-----|--|-------------------------|
| 49 | 9709506012 Bolt(gh1) | Buy now |
| 50 | 6AW4531800 Bushing, drive shaft | Buy now |
| 51 | 9342038091 Circlip | Buy now |
| 52 | 9589506010 Bolt, flange(7ht) | Buy now |
| 53 | 6AW45211108D Extension U(30.1") | Buy now |
| 54 | 6AW4436600 Damper, water seal 2 U(30.1") | Buy now |
| 55 | 9360812M05 Pin, dowel b (6e5) U(30.1") | Buy now |
| 56 | 6AW4515900 Damper U(30.1") | Buy now |

Valve




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6CB1211100 Valve, intake | Buy now |
| 2 | 6CB1212100 Valve, exhaust | Buy now |
| 3 | K0FA374300 Seat, valve spring | Buy now |
| 4 | 6CB1211300 Spring, valve inner | Buy now |
| 5 | K0FA374100 Retainer, valve spring | Buy now |
| 6 | K0FA374200 Lock, valve spring retainer | Buy now |
| 7 | 51Y1211900 Seal, valve stem | Buy now |
| 8 | K0FA375100 Lifter, valvek (3.000) UR | Buy now |
| 8 | K0FA375110 Lifter, valve (3.025) UR | Buy now |
| 8 | K0FA375120 Lifter, valve (3.050) UR | Buy now |
| 8 | K0FA375130 Lifter, valve (3.075) UR | Buy now |
| 8 | K0FA375140 Lifter, valve (3.100) UR | Buy now |
| 8 | K0FA375150 Lifter, valve (3.122) UR | Buy now |
| 8 | K0FA375160 Lifter, valve (3.142) UR | Buy now |
| 8 | K0FA375170 Lifter, valve (3.162) UR | Buy now |

Valve




| Ref | Part | |
|-----|---|-------------------------|
| 8 | K0FA375180 Lifter, valve (3.182) UR | Buy now |
| 8 | K0FA375190 Lifter, valve (3.202) UR | Buy now |
| 8 | K0FA3751A0 Lifter, valve (3.222) UR | Buy now |
| 8 | K0FA3751B0 Lifter, valve (3.242) UR | Buy now |
| 8 | K0FA3751C0 Lifter, valve (3.262) UR | Buy now |
| 8 | K0FA3751D0 Lifter, valve (3.282) UR | Buy now |
| 8 | K0FA3751E0 Lifter, valve (3.302) UR | Buy now |
| 8 | K0FA3751F0 Lifter, valve (3.322) UR | Buy now |
| 8 | K0FA3751G0 Lifter, valve (3.342) UR | Buy now |
| 8 | K0FA3751H0 Lifter, valve (3.362) UR | Buy now |
| 8 | K0FA3751J0 Lifter, valve (3.382) UR | Buy now |
| 8 | K0FA3751K0 Lifter, valve (3.402) UR | Buy now |
| 8 | K0FA3751L0 Lifter, valve (3.422) UR | Buy now |
| 8 | K0FA3751M0 Lifter, valve (3.442) UR | Buy now |
| 8 | K0FA3751N0 Lifter, valve (3.462) UR | Buy now |

Valve




| Ref | Part | |
|-----|---|-------------------------|
| 8 | K0FA3751P0 Lifter, valve (3.482) UR | Buy now |
| 8 | K0FA3751R0 Lifter, valve (3.502) UR | Buy now |
| 8 | K0FA3751S0 Lifter, valve (3.522) UR | Buy now |
| 8 | K0FA3751T0 Lifter, valve (3.542) UR | Buy now |
| 8 | K0FA375300 Lifter, valve (3.562) UR | Buy now |
| 8 | K0FA375310 Lifter, valve (3.582) UR | Buy now |
| 8 | K0FA375320 Lifter, valve (3.602) UR | Buy now |
| 8 | K0FA375330 Lifter, valve (3.625) UR | Buy now |
| 8 | K0FA375340 Lifter, valve (3.650) UR | Buy now |
| 8 | K0FA375350 Lifter, valve (3.675) UR | Buy now |
| 8 | K0FA375360 Lifter, valve (3.700) UR | Buy now |
| 8 | K0FA375370 Lifter, valve (3.725) UR | Buy now |
| 9 | 6AW1217110 Camshaft 1 | Buy now |
| 10 | 6AW1218110 Camshaft 2 | Buy now |
| 11 | 6AW1217210 Camshaft 3 | Buy now |

Valve



| Ref | Part | |
|-----|---|-------------------------|
| 12 | 6AW1218210 Camshaft 4 | Buy now |
| 13 | 6AW1153700 Gear, driven | Buy now |
| 14 | 6AW1156700 Gear, driven 2 | Buy now |
| 15 | 9011910050 Bolt, with washer | Buy now |
| 16 | 6AW1264500 Pulley assembly 1 | Buy now |
| 17 | 6P21262300 Bolt | Buy now |
| 18 | 6P21266300 Gasket | Buy now |
| 19 | 6AW1264A00 Pulley assembly 2 | Buy now |
| 22 | 6P21261500 Bolt | Buy now |
| 23 | 9310238008 Oil seal | Buy now |
| 24 | 6AWW462400 Belt (with rotor bolts) | Buy now |
| 25 | 6P21159001 Tensioner assembly | Buy now |
| 26 | 6P21551200 Gear, idler 1 | Buy now |
| 27 | 9953014016 Pin, dowel | Buy now |
| 28 | 9011910M07 Bolt (6f5) | Buy now |

Valve



| Ref | Part | |
|-----|--|-------------------------|
| 29 | 9020110M01 Washer, plate(6m7) | Buy now |
| 30 | 6AW1554400 Stay 1 | Buy now |
| 31 | 9010508178 Bolt, flange | Buy now |

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.