



Yamaha F8CMH 2014

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


| | |
|-----------------------------------|----|
| SCHEDULED SERVICE PARTS | 3 |
| BOTTOM COWLING | 4 |
| BRACKET 1 | 7 |
| BRACKET 2 | 10 |
| CARBURETOR | 12 |
| CONTROL | 14 |
| CRANKSHAFT & PISTON | 16 |
| CYLINDER & CRANKCASE 1 | 18 |
| CYLINDER & CRANKCASE 2 | 20 |
| ELECTRICAL 1 | 22 |
| ELECTRICAL 2 | 24 |
| FUEL | 25 |
| FUEL TANK | 28 |
| GENERATOR | 29 |
| INTAKE | 30 |
| LOWER CASING & DRIVE 1 | 32 |
| LOWER CASING & DRIVE 2 | 37 |
| OIL PAN | 39 |
| OIL PUMP | 41 |
| OPTIONAL PARTS 1 | 43 |
| OPTIONAL PARTS 2 | 46 |
| REMO CON ATTACHMENT | 47 |
| REPAIR KIT 1 | 49 |
| REPAIR KIT 2 | 51 |
| REPAIR KIT 3 | 52 |
| STARTER | 54 |
| STEERING | 57 |
| STEERING GUIDE | 59 |
| TOP COWLING | 60 |
| UPPER CASING | 61 |
| VALVE | 62 |

Scheduled Service Parts



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 66M1241101 Thermostat | Buy now |
| 2 | 60RE2414A0 Gasket, cover | Buy now |
| 3 | 6G81132500 Anode | Buy now |
| 4 | 9470200274 Plug, spark (br6hs-10) | Buy now |
| 5 | 68T2425101 Strainer 1 | Buy now |
| 6 | 9043010M11 Gasket | Buy now |
| 7 | 68T4525100 Anode | Buy now |
| 8 | 9043008020 Gasket | Buy now |
| 9 | 68TW007800 Water pump repair kit | Buy now |


Bottom Cowling



60RA300-M150


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RG2710004D Bottom cowling assembly WITH TAPPING BOLT | Buy now |
| 2 | 68F8511900 Bolt | Buy now |
| 3 | 9048021M82 Grommet | Buy now |
| 4 | 9038706176 Collar | Buy now |
| 5 | 68T4271610 Rubber, seal 1 | Buy now |
| 6 | 68T4280100 Cowling clamp comp. | Buy now |
| 37 | 9709506012 Bolt(gh1) FLUSHING KIT | Buy now |
| 38 | 9299506600 Washer, plain (646) FLUSHING KIT | Buy now |
| 9 | 6BL4439100 Nipple, hose | Buy now |
| 10 | 6824272700 Grommet | Buy now |
| 11 | 68T42738004D Plate, fitting | Buy now |
| 12 | 9010906M81 Bolt | Buy now |
| 13 | 68T4272500 Grommet | Buy now |
| 14 | 68T2639300 Holder | Buy now |
| 15 | 68T2636700 Protector | Buy now |

Bottom Cowling




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 60RG272400 Grommet | Buy now |
| 17 | 9048006M19 Grommet (6e3) FOR RUS | Buy now |
| 19 | 6884272610 Grommet FLUSHING KIT | Buy now |
| 19 | 6H44272600 Grommet FOR RUS | Buy now |
| 20 | 60SG271700 Rubber, seal 2 | Buy now |
| 21 | 60RG274100 Apron | Buy now |
| 22 | 9788506030 Screw, pan head(6e0) | Buy now |
| 23 | 9299506100 Washer(6a1) | Buy now |
| 25 | 9538006600 Nut(661) | Buy now |
| 26 | 68T4271700 Rubber, seal 2 | Buy now |
| 27 | 60RH434200 Seat, emblem | Buy now |
| 28 | 60SE248100 Pipe 1 FLUSHING KIT | Buy now |
| 29 | 9046511M10 Clamp FLUSHING KIT | Buy now |
| 30 | 9044713M00 Hose, with spring FLUSHING KIT | Buy now |
| 31 | 6R31258200 Joint, hose 2 FLUSHING KIT | Buy now |

Bottom Cowling



| Ref | Part | |
|-----|---|-------------------------|
| 32 | 6R31258300 Gasket, hose joint FLUSHING KIT | Buy now |
| 33 | 6R31258100 Joint, hose 1 FLUSHING KIT | Buy now |
| 34 | 68T1257200 Adapter FLUSHING KIT | Buy now |
| 35 | 9016706002 Screw, tapping FLUSHING KIT | Buy now |
| 36 | 68T1253520 Plate FLUSHING KIT | Buy now |
| 39 | 6AH4279440 Label, warning (ge) | Buy now |
| 40 | 6AH4279450 Label, warning (ge) | Buy now |


Bracket 1



68R3110-C200

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60RG3111014D Bracket clamp 1 | Buy now |
| 2 | 60RG3112014D Bracket clamp 2 | Buy now |
| 3 | 6L8G311801 Handle, transom cl | Buy now |
| 4 | 9024304M01 Pin(6a1) | Buy now |
| 5 | 6E74311600 Screw, transom clamp | Buy now |
| 6 | 6484311401 Pad, transom clamp | Buy now |
| 7 | 63V4313110 Bolt, clamp bracket FOR RIDE GUIDE | Buy now |
| 8 | 9038622MA4 Bush | Buy now |
| 9 | 66R4311300 Plate, clamp bracket | Buy now |
| 10 | 9018522043 Nut, self-locking | Buy now |
| 11 | 9038706M13 Collar(6h6) | Buy now |
| 12 | 9010106M18 Bolt(6l5) | Buy now |
| 13 | 9299506600 Washer, plain (646) | Buy now |
| 14 | 9538006700 Nut | Buy now |
| 15 | 6L24316001 Tilt rod assembly | Buy now |


Bracket 1



68R3110-C200

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6894316500 Plate, tilt lock | Buy now |
| 17 | 9169030008 Pin. spring(656) | Buy now |
| 18 | 9050210M07 Spring, conical(6k3) | Buy now |
| 19 | 60RG3311004D Bracket, Swivel 1 S(17.1") | Buy now |
| 19 | 60RG3311104D Bracket swivel1 L(22.1") | Buy now |
| 20 | 60RG363100 Lever Tilt | Buy now |
| 21 | 60RG361600 Rod Tilt Lock | Buy now |
| 22 | 68T4364600 Shaft, lever | Buy now |
| 23 | 68T4364100 Lever, tilt | Buy now |
| 24 | 68T4361700 Rod, tilt lock | Buy now |
| 25 | 9908005600 Circlip(22k) | Buy now |
| 26 | 68T4335000 Receiver assembly | Buy now |
| 27 | 9050618M41 Spring, tension S(17.1") | Buy now |
| 27 | 9050620005 Spring, tension L(22.1") | Buy now |
| 28 | 63V4319100 Shaft, stopper | Buy now |


Bracket 1



68R3110-C200


| Ref | Part | |
|-----|---|-------------------------|
| 30 | 68T4361400 Plate, tilt lock | Buy now |
| 31 | 9050620806 Spring Tension S(17.1") | Buy now |
| 31 | 9050623803 - L(22.1") | Buy now |
| 32 | 68T4361500 Plate, tilt lock | Buy now |
| 33 | 68T4361100 Shaft, tilt lock | Buy now |
| 34 | 9343004M03 Circlip (eu0) | Buy now |
| 35 | 68T4365900 Shaft, reverse lock | Buy now |
| 37 | 68T4362700 Stopper | Buy now |
| 38 | 9010906M84 Bolt | Buy now |
| 39 | 9020610M24 Washer, wave | Buy now |

Bracket 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 2 | 68T8212700 Wire, lead 2 | Buy now |
| 3 | 63V4252800 Plate, friction | Buy now |
| 4 | 6894337301 Seal, damper | Buy now |
| 5 | 9010506M07 Bolt (689) | Buy now |
| 6 | 60RG2511014D Bracket, steering S(17.1") | Buy now |
| 6 | 60RG2511114D Bracket, steering L(22.1") | Buy now |
| 7 | 63V4253700 Bushing, pivot shaft | Buy now |
| 8 | 9038630048 Bush | Buy now |
| 9 | 9321029M94 O-ring(6h1) | Buy now |
| 10 | 9038630M60 Bush(6j8) | Buy now |
| 11 | 9011608M54 Bolt, stud(63v) | Buy now |
| 12 | 68T4451700 Mount rubber | Buy now |
| 13 | 68T4452600 Plate | Buy now |
| 14 | 9538008600 Nut (661) | Buy now |

Bracket 2




| Ref | Part | |
|-----|---|-------------------------|
| 15 | 9757506525 Bolt, hexagon w/w deep recess | Buy now |
| 16 | 68T44551004D Housing, lower mount rubber 1 | Buy now |
| 17 | 60RG455700 Mount Damper Lower Front | Buy now |
| 18 | 60RG455500 Mount damper, lower side | Buy now |
| 19 | 9011906012 Bolt, with washer | Buy now |
| 20 | 9011906013 Bolt, with washer | Buy now |
| 21 | 9017906M28 Nut(63v) | Buy now |

Carburetor



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60S1430120 Carburetor assembly 1 | Buy now |
| 2 | 69W1432100 Screw, throttle | Buy now |
| 3 | 62Y1421200 Spring, pilot adjusting | Buy now |
| 4 | 6DR1432100 Screw, throttle | Buy now |
| 5 | 62Y1432100 Screw, throttle | Buy now |
| 6 | 6DR1438500 Float | Buy now |
| 7 | 6DR1432A00 Plug | Buy now |
| 8 | 6DR1456100 O-ring | Buy now |
| 9 | 4FP1438600 Pin, float | Buy now |
| 10 | 6DR1433600 Needle | Buy now |
| 11 | 60S1434337 Jet, main (#73) | Buy now |
| 12 | 60S1434220 Jet, pilot (#40) | Buy now |
| 13 | 60S1434100 Nozzle, main | Buy now |
| 14 | 60S1438100 Body, float chamber | Buy now |
| 15 | 6DR1498400 Gasket, float chamber | Buy now |


Carburetor



60RA700-M080


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 62Y1438330 Screw, drain | Buy now |
| 17 | 6521439700 Ring, o | Buy now |
| 18 | 6DR1432310 Screw, air adjusting | Buy now |
| 19 | 6DR1433400 Spring, air adjusting | Buy now |
| 20 | 6DR1428500 Washer | Buy now |
| 21 | 6DR1439700 O-ring | Buy now |
| 22 | 6DR1481800 Cover gasket | Buy now |
| 23 | 6DR1415700 Cover, mixing | Buy now |
| 24 | 6DR1486200 Plug | Buy now |

Control




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60RG411100 Handle, gear shift | Buy now |
| 2 | 9321012327 O-ring(3ld) | Buy now |
| 3 | 9709505016 Bolt(6a1) | Buy now |
| 4 | 9299505600 Washer, plain (646) | Buy now |
| 5 | 68T4412102 Lever, shift rod | Buy now |
| 6 | 6G1416620194 Bracket | Buy now |
| 7 | 9010906M81 Bolt | Buy now |
| 8 | 9046410M60 Clamp | Buy now |
| 9 | 9169030014 Pin, spring (647) | Buy now |
| 10 | 65W4411600 Spring | Buy now |
| 11 | 66R4411400 Stopper | Buy now |
| 12 | 9010906M86 Bolt | Buy now |
| 13 | 60RG414300 Rod, shift 1 S(17.1") | Buy now |
| 13 | 60RG414310 Rod, shift 1 L(22.1") | Buy now |
| 14 | 9046818001 Clip | Buy now |

Control



| Ref | Part | |
|-----|---|-------------------------|
| 15 | 61N4414600 Connector, shift rod | Buy now |
| 16 | 9538006700 Nut | Buy now |
| 17 | 68T4163800 Pulley | Buy now |
| 18 | 68T4128300 Lever, free accel. | Buy now |
| 19 | 9038706M59 Collar (6h3) | Buy now |
| 20 | 6AU4121100 Link, accel. | Buy now |
| 21 | 68T1449700 Stay, throttle wire | Buy now |
| 22 | 9020106M62 Washer, plate (6e5) | Buy now |
| 23 | 9759506545 Bolt, hexagon w/w deep recess | Buy now |
| 24 | 9709506012 Bolt(gh1) | Buy now |
| 25 | 9299506600 Washer, plain (646) | Buy now |
| 26 | 6J84126200 Joint, choke lever | Buy now |
| 27 | 6471439560 Cap, over flow pipe | Buy now |


Crankshaft & Piston



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 9310230M22 Oil seal (6g8) | Buy now |
| 2 | 9310125M69 Oil seal | Buy now |
| 3 | 60RE141100 - | Buy now |
| 4 | 68T1141601 Plane bearing, crankshaft 1 UR BROWN | Buy now |
| 4 | 68T1141611 Plane bearing, crankshaft 1 UR BLACK | Buy now |
| 4 | 68T1141621 Plane bearing, crankshaft 1 UR BLUE | Buy now |
| 5 | 68T1165000 Connecting rod kit | Buy now |
| 6 | 67D1165400 Bolt, connecting rod | Buy now |
| 7 | 60RE16310096 Piston (std) | Buy now |
| 7 | 60RE163500 Piston (0.25mm o/s) AP | Buy now |
| 7 | 60RE163600 Piston (0.50mm o/s) AP | Buy now |
| 8 | 60RE160300 Piston ring set (std) | Buy now |
| 8 | 60RE160400 Ring piston AP | Buy now |
| 8 | 60RE160500 Piston ring set (0.50mm o/s) AP | Buy now |
| 9 | 60RE163300 Pin, piston | Buy now |


Crankshaft & Piston

| Ref | Part | |
|-----|--|-------------------------|
| 10 | 9345015023 Circlip 131116340000 | Buy now |




68R0010-0031

Cylinder & Crankcase 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RWE09B001S Cylinder block ass'y | Buy now |
| 2 | 60RE5100001S Crank case assembly | Buy now |
| 3 | 9181212001 Pin, dowel | Buy now |
| 4 | 9011908M29 Bolt, with washer | Buy now |
| 5 | 68T1135100 Gasket, cylinder | Buy now |
| 6 | 66M1241101 Thermostat | Buy now |
| 7 | 6881241200 Seal, thermostat | Buy now |
| 8 | 68T12413001S Cover, thermostat | Buy now |
| 9 | 60RE2414A0 Gasket, cover | Buy now |
| 10 | 9011906MA2 Bolt, with washer | Buy now |
| 11 | 60RE248100 Pipe 1 | Buy now |
| 12 | 9046511M10 Clamp | Buy now |
| 13 | 60RG1113001S Outer cover, exhaust | Buy now |
| 14 | 68T41114A0 Gasket, exhaust outer cover | Buy now |
| 15 | 9011906MA3 Bolt, with washer | Buy now |

Cylinder & Crankcase 1




| Ref | Part | |
|-----|--------------------------------------|-------------------------|
| 16 | 60RE248200 Pipe 2 | Buy now |

Cylinder & Crankcase 2




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60RWE09A011S Cylinder head assembly | Buy now |
| 2 | 60RE1111001S Head, cylinder 1 | Buy now |
| 3 | 67D1113310 Guide, valve 1 | Buy now |
| 4 | 68T1118100 Gasket, cylinder head 1 | Buy now |
| 5 | 9953010114 Pin, dowel(3vd) | Buy now |
| 6 | 9010508M36 Bolt (6g8) | Buy now |
| 7 | 9010508M78 Bolt, washer based | Buy now |
| 8 | 9011906049 Bolt, with washer | Buy now |
| 9 | 60RE1191001S Cover, cylinder head 1 | Buy now |
| 10 | 6502437800 Pipe, joint 2 | Buy now |
| 11 | 68T1135600 Seal, cylinder 2 | Buy now |
| 12 | 9709506020 Bolt(7u8) | Buy now |
| 13 | 9299506600 Washer, plain (646) | Buy now |
| 14 | 68T1116800 Cover, breather | Buy now |
| 15 | 68T11169A0 Gasket, breather cover | Buy now |

Cylinder & Crankcase 2



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9850704010 Screw, pan head(6g8) | Buy now |
| 17 | 9290704600 Washer(jf2) | Buy now |
| 18 | 6G81132500 Anode | Buy now |
| 19 | 9898005025 Screw, panhead (a93) | Buy now |
| 20 | 6G81119701 Plug, blind | Buy now |
| 21 | 9321013M63 O-ring (6g8) | Buy now |
| 22 | 69ME536300 Plug, oil | Buy now |
| 23 | 9321024M79 O-ring | Buy now |
| 24 | 9470200274 Plug, spark (br6hs-10) | Buy now |


Electrical 1



60N4300-G130


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68T8554000 C.d.i. unit assembly | Buy now |
| 2 | 68T8252200 Clamp, coupler | Buy now |
| 3 | 9778040512 Screw, pan head tapping | Buy now |
| 4 | 9709506020 Bolt(7u8) | Buy now |
| 5 | 9299506600 Washer, plain (646) | Buy now |
| 6 | 9709506012 Bolt(gh1) | Buy now |
| 8 | 6808557002 Ignition coil assembly | Buy now |
| 9 | 9048025161 Grommet(656) | Buy now |
| 10 | 9709506025 Bolt | Buy now |
| 12 | 6E38237021 Plug cap assembly | Buy now |
| 13 | 68T8196000 Rectifier & regulator assembly | Buy now |
| 16 | 9046511M10 Clamp | Buy now |
| 17 | 67F8250400 Oil pressure switch assembly | Buy now |
| 18 | 68T8212710 Wire, lead 2 | Buy now |
| 19 | 68T8541000 Emergency signal light assembly | Buy now |

Electrical 1



| Ref | Part | |
|-----|---|-------------------------|
| 20 | 68T8182201 Bracket, starting motor | Buy now |
| 21 | 9011908046 Bolt, with washer | Buy now |
| 22 | 9011908020 Bolt, with washer | Buy now |
| 23 | 9046508M99 Clamp | Buy now |


Electrical 2



 6AU1300-G140


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 65W8257501 Engine stop switch assembly | Buy now |
| 2 | 6828255600 Lanyard, stop switch | Buy now |
| 3 | 6898257Y00 Cap | Buy now |
| 4 | 6G14272500 Grommet | Buy now |

Fuel




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6G12430402 Fuel pipe joint comp. 1 | Buy now |
| 2 | 60RF432900 Seal | Buy now |
| 3 | 9709506025 Bolt | Buy now |
| 4 | 9299506600 Washer, plain (646) | Buy now |
| 5 | 9044510809 Hose | Buy now |
| 6 | 9046511M10 Clamp | Buy now |
| 7 | 9046709M09 Clip(6k8) | Buy now |
| 8 | 68T2425101 Strainer 1 | Buy now |
| 9 | 9044510811 Hose (I400) | Buy now |
| 11 | 9044614M66 Hose(64x) | Buy now |
| 13 | 68T2441001 Fuel pump assembly | Buy now |
| 14 | 66M2441301 Body 2 | Buy now |
| 15 | 6A02442101 Valve, check | Buy now |
| 16 | 6E71432500 Screw, pan head | Buy now |
| 17 | 66M2441101 Diaphragm | Buy now |

Fuel




| Ref | Part | |
|-----|---|-------------------------|
| 18 | 66M2442300 Spring, diaphragm | Buy now |
| 19 | 66M1313100 Plunger | Buy now |
| 20 | 66M2437400 Pin | Buy now |
| 21 | 66M2445400 Spring | Buy now |
| 22 | 66M2447101 Diaphragm | Buy now |
| 23 | 66M2444400 Screw | Buy now |
| 24 | 9538004600 Nut,hex | Buy now |
| 25 | 9759506630 Bolt, hexagon w/w deep recess | Buy now |
| 26 | 9321020M65 O-ring | Buy now |
| 27 | 9044510810 Pipe, fuel 1 | Buy now |
| 29 | 9044713014 Tube | Buy now |
| 31 | 9046410M53 Clamp | Buy now |
| 32 | 68T2810000 Tool kit AP | Buy now |
| 33 | 60RF819979D0 Manual,owner's UR (NL) | Buy now |
| 33 | 60RF819979E0 Manual,owner's UR (E) | Buy now |

Fuel



| Ref | Part | |
|-----|---|-------------------------|
| 33 | 60RF819979F0 Manual,owner's UR (F) | Buy now |
| 33 | 60RF819979G0 Manual,owner's UR (D) | Buy now |
| 33 | 60RF819979H0 Manual,owner's UR (I) | Buy now |
| 33 | 60RF819979S0 Manual,owner's UR (ES) | Buy now |
| 34 | 60RF819989K0 Manual,owner's UR (DK) | Buy now |
| 34 | 60RF819989L0 Manual,owner's UR (SF) | Buy now |
| 34 | 60RF819989M0 Manual,owner's UR (S) | Buy now |
| 34 | 60RF819989N0 Manual,owner's UR (N) | Buy now |
| 34 | 60RF819989P0 Manual,owner's UR (P) | Buy now |
| 34 | 60RF819989R0 Manual,owner's UR (GR) | Buy now |


Fuel Tank



66M4100-D270

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6YL2420105 Fuel Tank assembly (12L) AP | Buy now |
| 2 | 6YL2461001 Cap assembly | Buy now |
| 3 | 6YL2426001 Fuel meter assembly | Buy now |
| 4 | 9015705M16 Screw, pan head | Buy now |
| 5 | 6YL2432900 Seal | Buy now |
| 6 | 6YL2426801 Gasket, fuel meter | Buy now |
| 7 | 6YL2430654 Fuel pipe comp. 1 AP | Buy now |


Generator



60N1300-D110


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6DR8555010 Rotor assembly | Buy now |
| 2 | 68T8552000 Coil, charge | Buy now |
| 3 | 68T8558001 Coil, pulser | Buy now |
| 4 | 68T8553310 Coil, lighting | Buy now |
| 5 | 6H28558200 Attachment, pulser | Buy now |
| 6 | 9011906014 Bolt, with washer(61b) | Buy now |
| 7 | 9709505010 Bolt (682) | Buy now |
| 8 | 9011906MA1 Bolt, with washer(63m) | Buy now |
| 9 | 9046511M10 Clamp | Buy now |
| 10 | 9028004M06 Key, woodruff(6a1) | Buy now |
| 11 | 9017012066 Nut, hexagon 6481155500 | Buy now |
| 12 | 9020112472 Washer, plate (4n0) | Buy now |

Intake




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RE3641001S Manifold 1 FOR RUS | Buy now |
| 1 | 60RE3641201S Manifold 1 FLUSHING KIT | Buy now |
| 2 | 6502437800 Pipe, joint 2 FOR RUS | Buy now |
| 2 | 67F1248200 Pipe 2 FLUSHING KIT | Buy now |
| 3 | 68T1364500 Gasket, manifold 1 | Buy now |
| 4 | 9011906MA5 Bolt, with washer | Buy now |
| 5 | 9011906MA3 Bolt, with washer | Buy now |
| 6 | 9169050014 Pin, spring (647) | Buy now |
| 7 | 9044509811 Hose (I1500) FOR RUS | Buy now |
| 7 | 9044509812 Hose (L93) FLUSHING KIT | Buy now |
| 8 | 60RE3646A0 Gasket, manifold 2 | Buy now |
| 9 | 68T1427100 Insulator | Buy now |
| 10 | 60RE444000 Silencer assembly, intake | Buy now |
| 11 | 9321031MJ5 O-ring | Buy now |
| 12 | 9038706M70 Collar (6h5) | Buy now |

Intake




| Ref | Part | |
|-----|--|-------------------------|
| 13 | 9010506188 Bolt, flange | Buy now |
| 14 | 60RE248300 Pipe 3 | Buy now |
| 15 | 9046508M99 Clamp | Buy now |
| 16 | 9046508M83 Clamp FLUSHING KIT | Buy now |
| 17 | 9709506010 Bolt FLUSHING KIT | Buy now |
| 18 | 9299506600 Washer, plain (646) FLUSHING KIT | Buy now |
| 19 | 6H44127102 Knob, choke | Buy now |
| 20 | 6894127300 Grommet | Buy now |
| 21 | 68T4125600 Rod, choke 1 | Buy now |
| 22 | 6J84126200 Joint, choke lever | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RG5300014D Lower unit assembly S(17.1") | Buy now |
| 1 | 60RG5300114D Lower unit assembly L(22.1") | Buy now |
| 2 | 60RG5311004D Casing, lower | Buy now |
| 3 | 6G14531709 Bushing, drive shaft 2 | Buy now |
| 4 | 9038714M49 Collar (6g1) | Buy now |
| 5 | 93306004YH Bearing (7k2) | Buy now |
| 6 | 68T4525100 Anode | Buy now |
| 7 | 9589506016 Bolt, flange deep recess | Buy now |
| 8 | 9299006300 Washer, tooth | Buy now |
| 9 | 9034008002 Plug, straight screw | Buy now |
| 10 | 9043008020 Gasket | Buy now |
| 11 | 6N0G5361004D Cap, lower casing | Buy now |
| 12 | 6G14536209 Bushing, lower casing cap | Buy now |
| 14 | 9310115074 Oil seal (655) | Buy now |
| 15 | 9321049046 O-ring (620) | Buy now |


Lower Casing & Drive 1



60N4300-G230


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9321053M08 O-ring(50m) | Buy now |
| 17 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 18 | 9299506600 Washer, plain (646) | Buy now |
| 19 | 63V4430100 Water pump housing comp. | Buy now |
| 20 | 63V4432200 Insert, cartridge | Buy now |
| 21 | 68T4436600 Damper, water seal 2 | Buy now |
| 22 | 68T4435200 Impeller | Buy now |
| 23 | 6644433800 Key, woodruff | Buy now |
| 24 | 9321044398 O-ring(55x) | Buy now |
| 25 | 68T4432300 Outer plate, cartridge | Buy now |
| 26 | 9360412M07 Pin, dowel (688) | Buy now |
| 27 | 9709508045 Bolt, hexagon | Buy now |
| 28 | 63V4432801 Plate | Buy now |
| 29 | 60RG5331005B Housing, bearing | Buy now |
| 30 | 6G14531609 Bushing, drive shaft 1 | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|--|-------------------------|
| 31 | 9310111M23 Oil seal (6g1) | Buy now |
| 32 | 68T45315A0 Packing, lower casing | Buy now |
| 33 | 9321006ME6 O-ring | Buy now |
| 34 | 9708008025 Screw, bind(j36) | Buy now |
| 35 | 60RG415000 Shift cam assembly | Buy now |
| 36 | 60RG551100 Shaft, drive S(17.1") | Buy now |
| 36 | 60RG551110 Shaft, drive L(22.1") | Buy now |
| 37 | 9046709M05 Clip (6g1) | Buy now |
| 38 | 9900107600 Circlip(6l2) | Buy now |
| 39 | 6N0G5551A0 Pinion | Buy now |
| 40 | 6G14553300 Shim (t:1.9mm) UR | Buy now |
| 40 | 6G14553310 Shim (t:2.0mm) UR | Buy now |
| 40 | 6G14553320 Shim (t:2.1mm) UR | Buy now |
| 40 | 6G14553330 Shim (t:2.2mm) UR | Buy now |
| 41 | 60RG556000 Gear | Buy now |


Lower Casing & Drive 1




| Ref | Part | |
|-----|---|-------------------------|
| 42 | 6644558701 Shim (t:0.10mm) UR | Buy now |
| 42 | 6644558710 Shim (t:0.12mm) UR | Buy now |
| 42 | 6644558720 Shim (t:0.15mm) UR | Buy now |
| 42 | 6644558730 Shim (t:0.18mm) UR | Buy now |
| 42 | 6644558740 Shim (t:0.30mm) UR | Buy now |
| 42 | 6644558750 Shim (t:0.40mm) UR | Buy now |
| 42 | 6644558760 Shim (t:0.50mm) UR | Buy now |
| 43 | 60RG557100 Gear | Buy now |
| 44 | 9020115M89 Washer, plate (6g1) | Buy now |
| 45 | 6474556700 Shim, gear adjust UN | Buy now |
| 46 | 68T4563100 Clutch, dog | Buy now |
| 47 | 6G14563200 Cross, pin | Buy now |
| 48 | 6544563300 Ring, cross pin | Buy now |
| 49 | 9050112M05 Spring, compression | Buy now |
| 50 | 6G14563500 Plunger, shift | Buy now |

Lower Casing & Drive 1

| Ref | Part | |
|-----|--|-------------------------|
| 51 | 68T4561100 Shaft, propeller | Buy now |




Lower Casing & Drive 2




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 68T4436100 Tube, water 1 S(17.1") | Buy now |
| 1 | 68T4436110 Tube, water 1 L(22.1") | Buy now |
| 2 | 63V4436510 Damper, water seal 1 | Buy now |
| 3 | 9360412M07 Pin, dowel (688) | Buy now |
| 4 | 9757508535 Bolt(70w) | Buy now |
| 5 | 6G14521400 Cover, water inlet | Buy now |
| 6 | 6G14521500 Cover, water inlet | Buy now |
| 7 | 9015205M03 Screw, countersunk | Buy now |
| 8 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 9 | 63V4537500 Damper, seal | Buy now |
| 10 | 6N0G598710 Spacer | Buy now |
| 11 | 9020110M01 Washer, plate(6m7) | Buy now |
| 12 | 9017110M01 Nut castle (683) | Buy now |
| 13 | 9149030020 Pin cotter | Buy now |
| 14 | 6G14594100 Propeller (3x8-1/2"x8-1/2"-n) UR | Buy now |

Lower Casing & Drive 2




| Ref | Part | |
|-----|---|-------------------------|
| 14 | 6G14594300 Propeller (3x8-1/2 x7-1/2 -n) UR | Buy now |
| 14 | 6G14594700 Propeller (3x8-1/2"x6-1/2"-n) | Buy now |
| 14 | 6G14595200 Propeller (3x8-1/2 x8 -n) UR | Buy now |
| 15 | 6G1W459101 Propeller (3x9 x7 -n) UR | Buy now |
| 15 | 6G1W459200 Propeller (3x9 x5 -n) | Buy now |
| 16 | 6G14561601 Nut, propeller | Buy now |
| 17 | 9020110M02 Washer, plate(6g9) | Buy now |

Oil Pan




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RG11370094 Guide, exhaust | Buy now |
| 2 | 60SG271700 Rubber, seal 2 | Buy now |
| 3 | 60RG518100 Plate | Buy now |
| 4 | 9709508014 Bolt, hexagon deep recess | Buy now |
| 5 | 9043008800 Gasket (256-11198-00) | Buy now |
| 6 | 9310112M70 Oil seal | Buy now |
| 7 | 68T1342101 Strainer 2 | Buy now |
| 8 | 9046711M08 Clip(72x) | Buy now |
| 9 | 6G81157500 Relief valve ass'y | Buy now |
| 10 | 9321012M62 O-ring (6g8) | Buy now |
| 11 | 9360619M23 Pin, dowel | Buy now |
| 12 | 60RE5311005B Oil pan | Buy now |
| 13 | 6H11137200 Nipple, hose | Buy now |
| 14 | 9034010M10 Plug, straight screw | Buy now |
| 15 | 9043010M11 Gasket | Buy now |

Oil Pan



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 60RE531600 Damper, engine mount 1 | Buy now |
| 17 | 68T1531700 Spacer, engine mount | Buy now |
| 18 | 9788505008 Screw, pan head | Buy now |
| 19 | 68T1347500 Gasket | Buy now |
| 20 | 9360412M07 Pin, dowel (688) | Buy now |
| 21 | 9011908005 Bolt, with washer | Buy now |
| 22 | 9757508530 Bolt, hexagon w/w deep recess | Buy now |
| 23 | 68T1536200 Plug, oil level | Buy now |


Oil Pump



6AU4300-K080


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9310218M21 Oil seal (6g8) | Buy now |
| 2 | 60RE217100 Camshaft | Buy now |
| 3 | 60RE15370094 Gear, driven | Buy now |
| 4 | 9010506M14 Bolt (6e0) | Buy now |
| 5 | 9020113201 Washer 6474283300 | Buy now |
| 6 | 9020106M94 Washer (6g8) | Buy now |
| 7 | 60RG624100 Belt | Buy now |
| 8 | 60RE153600 Gear, drive | Buy now |
| 9 | 68T1155700 Washer 1 | Buy now |
| 10 | 6G81158701 Washer, lock | Buy now |
| 11 | 9017024M09 Nut (6g8) | Buy now |
| 12 | 9028003M01 Key woodruff 146115450000 | Buy now |
| 13 | 60RG629700 Cover, dust | Buy now |
| 14 | 9048010627 Grommet | Buy now |
| 15 | 68T1330000 Oil pump assembly | Buy now |

Oil Pump




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 68T1332900 Gasket, pump cover | Buy now |
| 17 | 9709506030 Bolt(jf7) | Buy now |
| 18 | 9299506600 Washer, plain (646) | Buy now |

Optional Parts 1




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 68RW818001 Electric starter kit AP | Buy now |
| 2 | 68T818000 Starting motor assembly | Buy now |
| 3 | 68T8185700 Pinion stopper set | Buy now |
| 4 | 6898180712 Pinion assembly | Buy now |
| 5 | 6F58183010 Front cover assembly | Buy now |
| 6 | 6898183100 Metal, front | Buy now |
| 7 | 6898184711 O-ring | Buy now |
| 8 | 6898180911 Washer kit | Buy now |
| 9 | 6898185011 Armature assembly | Buy now |
| 10 | 6898181011 Stator ass'y | Buy now |
| 11 | 6898184011 Brush holder assembly | Buy now |
| 12 | 6898181111 Brush 1 | Buy now |
| 13 | 6898181211 Brush 2 | Buy now |
| 14 | 6898181310 Spring, brush | Buy now |
| 15 | 6898182011 Rear cover ass'y | Buy now |

Optional Parts 1




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6898182610 Bolt | Buy now |
| 17 | 9011908M76 Bolt, with washer(6e5) | Buy now |
| 18 | 9709508016 Bolt, hexagon deep recess | Buy now |
| 19 | 9299508600 Washer, plain (663) | Buy now |
| 20 | 6G88211700 Wire, lead | Buy now |
| 21 | 9044610M86 Hose | Buy now |
| 22 | 68T8194000 Starter relay assembly | Buy now |
| 23 | 9759506610 Bolt, hexagon w/w deep recess | Buy now |
| 24 | 68T8194501 Plate, switch fitting | Buy now |
| 25 | 9709506012 Bolt(gh1) | Buy now |
| 26 | 9299506600 Washer, plain (646) | Buy now |
| 27 | 9046512M56 Clamp(62t) | Buy now |
| 28 | 6F58254001 Neutral switch assembly | Buy now |
| 29 | 68T8187000 Starting switch assembly | Buy now |
| 30 | 68T8182100 Cover, switch | Buy now |

Optional Parts 1



| Ref | Part | |
|-----|---|-------------------------|
| 31 | 9046511M10 Clamp | Buy now |
| 32 | 68T8215000 Fuse holder assembly | Buy now |
| 33 | 66V8215100 Fuse (10a) | Buy now |
| 34 | 68T8217101 Stay, fuse box | Buy now |
| 35 | 67F2812A00 Puller, fuse | Buy now |
| 36 | 68T8210501 Battery cable (l: 2.1m) | Buy now |
| 37 | 68T8259400 Clamp | Buy now |
| 38 | 9015105003 Screw, countersunk | Buy now |


Optional Parts 2



 60N5110-H260


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68T8194900 Wire, lead AP | Buy now |
| 2 | 66V8215100 Fuse (10a) | Buy now |
| 3 | 68T8217101 Stay, fuse box AP | Buy now |
| 4 | 67F2812A00 Puller, fuse AP | Buy now |
| 5 | 9709506012 Bolt(gh1) AP | Buy now |
| 6 | 9299506600 Washer, plain (646) AP | Buy now |

Remo Con Attachment




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RG850100 Remote cont. attachment assembly. AP | Buy now |
| 2 | 68T4853100 Bracket, remote control 1 | Buy now |
| 3 | 6824853850 Clamp, cable | Buy now |
| 4 | 9169030012 Pin, spring | Buy now |
| 5 | 9709506012 Bolt(gh1) | Buy now |
| 6 | 9299506600 Washer, plain (646) | Buy now |
| 7 | 9538006600 Nut(661) | Buy now |
| 8 | 60RG411110 Handle, gear shift | Buy now |
| 9 | 9321012327 O-ring(3ld) | Buy now |
| 10 | 9709505016 Bolt(6a1) | Buy now |
| 11 | 9299505600 Washer, plain (646) | Buy now |
| 12 | 6634834400 Cable end, remote control | Buy now |
| 13 | 9046818008 Clip 620436610000 | Buy now |
| 16 | 68T4272510 Grommet | Buy now |
| 17 | 63V4851101 Hook, steering AP | Buy now |

Remo Con Attachment




| Ref | Part | |
|-----|--|-------------------------|
| 18 | 9757508535 Bolt(70w) AP | Buy now |
| 19 | 9018508057 Nut, nylon (6j8) AP | Buy now |

Repair Kit 1




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68TW000100 Power head gasket kit | Buy now |
| 2 | 9310218M21 Oil seal (6g8) | Buy now |
| 3 | 68T1118100 Gasket, cylinder head 1 | Buy now |
| 4 | 68T1135600 Seal, cylinder 2 | Buy now |
| 5 | 68T11169A0 Gasket, breather cover | Buy now |
| 6 | 9321013M63 O-ring (6g8) | Buy now |
| 7 | 9310230M22 Oil seal (6g8) | Buy now |
| 8 | 9310125M69 Oil seal | Buy now |
| 9 | 68T1135100 Gasket, cylinder | Buy now |
| 10 | 60RE2414A0 Gasket, cover | Buy now |
| 11 | 68T41114A0 Gasket, exhaust outer cover | Buy now |
| 12 | 9028003M01 Key woodruff 146115450000 | Buy now |
| 13 | 68T1364500 Gasket, manifold 1 | Buy now |
| 14 | 60RE3646A0 Gasket, manifold 2 | Buy now |
| 15 | 9321031MJ5 O-ring | Buy now |

Repair Kit 1




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 68T1332900 Gasket, pump cover | Buy now |
| 17 | 9321024M79 O-ring | Buy now |
| 18 | 9321020M65 O-ring | Buy now |

Repair Kit 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6DRW009300 Carburetor repair kit | Buy now |
| 2 | 62Y1432100 Screw, throttle | Buy now |
| 3 | 6DR1438500 Float | Buy now |
| 4 | 6DR1456100 O-ring | Buy now |
| 5 | 4FP1438600 Pin, float | Buy now |
| 6 | 6DR1433600 Needle | Buy now |
| 7 | 6DR1498400 Gasket, float chamber | Buy now |
| 8 | 6521439700 Ring, o | Buy now |
| 9 | 6DR1439700 O-ring | Buy now |
| 10 | 6DR1481800 Cover gasket | Buy now |

Repair Kit 3




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68TW000120 Lower unit gasket kit | Buy now |
| 2 | 9310112M70 Oil seal | Buy now |
| 3 | 9043010M11 Gasket | Buy now |
| 4 | 68T1347500 Gasket | Buy now |
| 5 | 9043008020 Gasket | Buy now |
| 6 | 9310115074 Oil seal (655) | Buy now |
| 7 | 9321049046 O-ring (620) | Buy now |
| 8 | 9321053M08 O-ring(50m) | Buy now |
| 9 | 9321044398 O-ring(55x) | Buy now |
| 10 | 9310111M23 Oil seal (6g1) | Buy now |
| 11 | 68T45315A0 Packing, lower casing | Buy now |
| 12 | 9321006ME6 O-ring | Buy now |
| 13 | 68TW007800 Water pump repair kit | Buy now |
| 14 | 63V4432200 Insert, cartridge | Buy now |
| 15 | 68T4436600 Damper, water seal 2 | Buy now |

Repair Kit 3




| Ref | Part | |
|-----|--|-------------------------|
| 16 | 68T4435200 Impeller | Buy now |
| 17 | 6644433800 Key, woodruff | Buy now |
| 19 | 68T4432300 Outer plate, cartridge | Buy now |
| 20 | 9709508045 Bolt, hexagon | Buy now |

Starter




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 68T1571013 Starter assembly | Buy now |
| 2 | 68T1571103 Case, starter | Buy now |
| 3 | 68T1579500 Guide, rope | Buy now |
| 4 | 63V1571400 Drum, sheave | Buy now |
| 5 | 63V1574100 Pawl, drive | Buy now |
| 6 | 63V1571300 Spring, starter | Buy now |
| 7 | 68T1571600 Plate, drive | Buy now |
| 8 | 63V1570501 Spring, drive pawl | Buy now |
| 9 | 63V1576701 Spring | Buy now |
| 10 | 68T1578400 Spring, return | Buy now |
| 11 | 63V1574400 Circlip | Buy now |
| 12 | 68T1579300 Screw | Buy now |
| 13 | 68T1576400 Collar 1 | Buy now |
| 14 | 6G11575500 Handle, starter | Buy now |
| 15 | * item_description *1 | Buy now |

Starter




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6G11577900 Cover | Buy now |
| 17 | 6A01578900 Damper | Buy now |
| 18 | 68T1579400 Stopper | Buy now |
| 19 | 66T1573400 Spring, return | Buy now |
| 20 | 68T1577000 Cable comp., starter stop | Buy now |
| 21 | 66T1573100 Retainer, spring | Buy now |
| 22 | 9709506020 Bolt(7u8) | Buy now |
| 23 | 9299506600 Washer, plain (646) | Buy now |
| 24 | 68T1576200 Seal, rubber 2 | Buy now |
| 25 | 68T1577410 Stay 4 | Buy now |
| 26 | 9010906M86 Bolt | Buy now |
| 27 | 6AH8199540 Label, warning | Buy now |
| 28 | 6AH8199550 Label, warning | Buy now |
| 29 | 60RE343761 Mark caution nv/sav | Buy now |
| 30 | 60RH571160 Mark caution | Buy now |

Starter




| Ref | Part | |
|-----|---|-------------------------|
| 31 | 6AH8199440 Label, safety | Buy now |
| 32 | 6AH8199450 Label, safety | Buy now |

Steering




| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60RG2111004D Handle steering | Buy now |
| 2 | 6G14213801 Lever, throttle | Buy now |
| 3 | 68DG215900 Stay | Buy now |
| 4 | 9788505012 Screw,pan head (646) | Buy now |
| 5 | 6G14212600 Piece, friction | Buy now |
| 6 | 6G14212501 Bolt, friction adjusting | Buy now |
| 7 | 9149016010 Pin, cotter | Buy now |
| 8 | 68DG217710 Rubber, handle | Buy now |
| 9 | 68DG211901 Grip, steering han | Buy now |
| 10 | 60RG213700 Indicator throttle | Buy now |
| 11 | 9026902M09 Rivet(615) | Buy now |
| 12 | 9015205011 Screw, countersunk | Buy now |
| 13 | 9020110M02 Washer, plate(6g9) | Buy now |
| 14 | 9050123800 Spring (655) | Buy now |
| 15 | 9038608032 Bushing (650) | Buy now |

Steering



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60RF630100 Trottle cable | Buy now |
| 17 | 9038634M97 Bush(63v) | Buy now |
| 18 | 9020636M21 Washer, wave(63v) | Buy now |
| 19 | 9020236M55 Washer, plate(63v) | Buy now |
| 20 | 9038633M96 Bush(63v) | Buy now |
| 21 | 68T4213101 Cover, handle steering | Buy now |
| 22 | 9011608015 Bolt, stud | Buy now |
| 23 | 9018508057 Nut, nylon (6j8) | Buy now |
| 24 | 60RG2121004D Bracket & washer set | Buy now |
| 25 | 9011610040 Bolt, stud | Buy now |
| 26 | 9017910M33 Nut | Buy now |
| 27 | 60RE571Y60 - | Buy now |


Steering Guide



6AU1100-G300


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68T6135010 Steering guide attachment kit AP | Buy now |
| 2 | 9020110M20 Washer, plate (663) | Buy now |
| 3 | 9018509M01 Nut, nylon (663) | Buy now |
| 4 | 9017009M03 Nut (689) | Buy now |
| 5 | 9038710M42 Collet (688) | Buy now |
| 6 | 6E56135500 Bolt | Buy now |
| 7 | 9020110M63 Washer, plate | Buy now |
| 8 | 6E54314501 Cap, clamp bracket | Buy now |
| 9 | 9321016275 O-ring | Buy now |

Top Cowling



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60RG261050 Top cowling assembly | Buy now |
| 2 | 60RG261A00 Top cowling comp | Buy now |
| 3 | 60RG261300 Molding Air Duct | Buy now |
| 4 | 9778060516 Screw, panhead tapping (j20) | Buy now |
| 5 | 6G14265102 Hook | Buy now |
| 6 | 9026604M04 Rivet(6e7) | Buy now |
| 7 | 60R4261500 Seal | Buy now |
| 8 | 60R4265200 Hook | Buy now |
| 9 | 9759505514 Bolt, w/ plain | Buy now |
| 10 | 68T4264900 Holder, clamp band | Buy now |
| 11 | 60R4267810 Graphic, rear | Buy now |
| 12 | 60R4267500 Graphic, side 1 | Buy now |
| 13 | 60R4267600 Graphic, side 2 | Buy now |
| 14 | 60R4267710 Graphic, front | Buy now |


Upper Casing



6AU4110-K250

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60RG5111004D Casing upper S(17.1") | Buy now |
| 1 | 60RG5111104D Casing, upper L(22.1") | Buy now |
| 2 | 60RE471100CA Muffler 1 | Buy now |
| 3 | 9757506514 Bolt, hexagon w/w deep recess | Buy now |
| 4 | 9048014M54 Grommet | Buy now |
| 5 | 68T4532100 Plate | Buy now |
| 6 | 9709506008 Bolt (fj1) | Buy now |
| 7 | 9788505008 Screw, pan head | Buy now |
| 8 | 9360412M07 Pin, dowel (688) | Buy now |
| 9 | 9757508535 Bolt(70w) | Buy now |

Valve



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6AU1211100 Valve, intake | Buy now |
| 2 | 6AU1212100 Valve, exhaust | Buy now |
| 3 | 68T1211600 Seat, valve spring | Buy now |
| 4 | 60R1211300 Spring, valve inne | Buy now |
| 5 | 7NJ1211700 Retainer, valve spring | Buy now |
| 6 | 7NJ1211800 Cotter, valve | Buy now |
| 7 | 51Y1211900 Seal, valve stem | Buy now |
| 8 | 68T1214600 Shaft, rocker | Buy now |
| 9 | 9038713M56 Collar (6g8) | Buy now |
| 10 | 9038714M03 Collar | Buy now |
| 11 | 9050112M40 Spring, compression (6g8) | Buy now |
| 12 | 68T1215100 Arm, valve rocker | Buy now |
| 13 | 6G81215900 Screw, valve adjusting | Buy now |
| 14 | 6G81215800 Nut, lock | Buy now |

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.