



Yamaha FL115AET 2012

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


BOTTOM COWLING	3
BRACKET 1	7
BRACKET 2	10
CONTROL	13
CRANKSHAFT & PISTON	16
CYLINDER & CRANKCASE 1	18
CYLINDER & CRANKCASE 2	22
ELECTRICAL 1	25
ELECTRICAL 2	27
ELECTRICAL 3	30
FUEL 1	32
FUEL 2	37
FUEL INJECTION PUMP 1	38
FUEL INJECTION PUMP 2	41
GENERATOR	42
INTAKE 1	44
INTAKE 2	46
INTAKE 3	49
LOWER CASING & DRIVE 1	51
LOWER CASING & DRIVE 2	57
LOWER CASING & DRIVE 3	62
LOWER CASING & DRIVE 4	69
OIL PAN	71
OPTIONAL PARTS 1	73
OPTIONAL PARTS 2	75
POWER TRIM & TILT ASSY 1	76
POWER TRIM & TILT ASSY 2	79
REPAIR KIT 1	82
REPAIR KIT 2	84
STARTING MOTOR	86
STEERING GUIDE	89
TOP COWLING	91
UPPER CASING	93
VALVE	95

Bottom Cowling




Ref	Part	
1	68V42710028D Bottom cowling assembly	Buy now
2	9011908M22 Bolt, with washer	Buy now
3	9048022M15 Grommet (6e5)	Buy now
4	9038708M37 Coller (6e5)	Buy now
5	67F42815008D Lever, clamp	Buy now
6	67F42816008D Lever, clamp	Buy now
7	67F42828008D Plate, clamp	Buy now
8	9010906M82 Bolt	Buy now
9	68V4281801 Lever, clamp	Buy now
10	9038615M73 Bush(6l2)	Buy now
11	9020615M18 Washer, wave(6l2)	Buy now
12	9020106068 Washer,plate (6k8)	Buy now
13	9709506016 Bolt, hexagon deep recess	Buy now
14	64D4314400 Hook, spring	Buy now
15	9010906M80 Bolt	Buy now

Bottom Cowling




Ref	Part	
16	9050616M34 Spring, tension(64d)	Buy now
17	68V42738008D Plate, fitting	Buy now
19	68V4272500 Grommet	Buy now
20	67F4275601 Stay, clamp	Buy now
37	9010906M86 Bolt FLUSHING KIT	Buy now
22	6H14272621 Grommet FLUSHING KIT	Buy now
23	6BL4439100 Nipple, hose	Buy now
24	6H44274800 Grommet	Buy now
25	67F4271700 Rubber, seal 2	Buy now
26	6E58258800 Plate	Buy now
27	9010906M81 Bolt	Buy now
28	9046508M23 Clamp (6h3)	Buy now
30	68T1257200 Adapter FLUSHING KIT	Buy now
31	67F1253501 Plate FLUSHING KIT	Buy now
32	9016706002 Screw, tapping FLUSHING KIT	Buy now

Bottom Cowling



Ref	Part	
33	9046206018 Clamp FLUSHING KIT	Buy now
34	9709506008 Bolt (fj1) FLUSHING KIT	Buy now
35	9299506100 Washer(6a1) FLUSHING KIT	Buy now
36	9299506200 Ybs66-6 washer, plain FLUSHING KIT	Buy now
38	6R31258100 Joint, hose 1 FLUSHING KIT	Buy now
39	6R31258200 Joint, hose 2 FLUSHING KIT	Buy now
40	6R31258300 Gasket, hose joint FLUSHING KIT	Buy now
41	68V2431200 Pipe 2 FLUSHING KIT	Buy now
42	9046511M10 Clamp FLUSHING KIT	Buy now
43	61A4271600 Rubber seal 1	Buy now
44	67F42741018D Apron	Buy now
45	9538006600 Nut(661)	Buy now
46	9015906M28 Screw, with washer	Buy now
48	9048013M24 Grommet (6e9)	Buy now
49	9038706M43 Coller (6e9)	Buy now

Bottom Cowling




68VB100-L180



Ref	Part	
50	6P24439100 Nipple, hose	Buy now
51	68F4275300 Fastner AP	Buy now
52	9046420258 Clamp AP	Buy now
53	9046418004 Clamp	Buy now
54	6AH4279440 Label, warning (ge)	Buy now
55	6AH4279450 Label, warning (ge)	Buy now


Bracket 1



68VB110-L200

Ref	Part	
1	68V43111018D Bracket, clamp	Buy now
2	6G54525102 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506030 Bolt(jf7)	Buy now
5	9299506100 Washer(6a1)	Buy now
6	6E58214800 Wire, lead 5	Buy now
7	9709506010 Bolt	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	68V43112018D Bracket, clamp	Buy now
11	9788506012 Screw, pan head(62j)	Buy now
13	9370006M03 Nipple, grease(6a1)	Buy now
14	64E4313120 Bolt Clamp Bracket	Buy now
15	9709508020 Bolt, hexagon	Buy now
16	9299508100 Ybs67-8 washer, spring	Buy now
17	9038625M31 Bushing (6e5)	Buy now


Bracket 1



68VB110-L200

Ref	Part	
18	<u>9020126M59</u> Washer, plate (6e5)	Buy now
19	<u>9018522M11</u> Nut, self-locking	Buy now
20	<u>9046511M10</u> Clamp	Buy now
21	<u>64E43311108D</u> Bracket, swivel L(20.3")	Buy now
21	<u>64E43311208D</u> Bracket, swivel X(25.3")	Buy now
22	<u>9046508M63</u> Clamp(61u)	Buy now
24	<u>66K8214900</u> Wire, lead 3 L(20.3")	Buy now
24	<u>68V8214930</u> Wire, lead 3 X(25.3")	Buy now
25	<u>66T4314400</u> Hook, spring	Buy now
27	<u>6G54318102</u> Lever, tilt stop 1	Buy now
28	<u>6G54318502</u> Lever, tilt stop 2	Buy now
29	<u>9038610M16</u> Bushing (688)	Buy now
30	<u>6G54314800</u> Collar, distance	Buy now
31	<u>9024906M19</u> Pin(6e5)	Buy now
32	<u>9038710M05</u> Collar(6e5)	Buy now


Bracket 1



68VB110-L200

Ref	Part	
33	9169030020 Pin, spring (6h4)	Buy now
34	9050614M24 Spring, tension(6e5)	Buy now
35	64E4312600 Pin, upper shock mount	Buy now
36	9038622M98 Bush(61u)	Buy now
37	9341022M11 Circlip(61u)	Buy now
38	9010112M05 Bolt (l:130mm) UR	Buy now
38	9010112M77 Bolt (l:150mm) UR F(L)115AET1	Buy now
39	9020113M01 Washer, plate(6e5)	Buy now
40	9020112426 Washe, plate(663)	Buy now
41	9538012600 Nut (707)	Buy now


Bracket 2



FWD
68V9110-J200


Ref	Part	
1	64E4313910 Cam, trim sender	Buy now
2	9015905059 Screw, with washer	Buy now
3	67H8367201 Trim sender	Buy now
4	9788506016 Screw, pan head(6b0)	Buy now
5	9046511M10 Clamp	Buy now
6	63P4337600 Bolt, thrust receiver	Buy now
7	9578010300 Nut, nylon (6e5)	Buy now
8	9299510600 Washer, plate	Buy now
9	68V42510118D Steering bracket assembly L(20.3")	Buy now
9	68V42510318D Steering bracket assembly X(25.3")	Buy now
10	9020138M60 Washer, plate (6e5)	Buy now
11	9321037MH7 O-ring(61u)	Buy now
12	9038638M32 Bush(6e5)	Buy now
13	9020240M47 Washer, plate(61a)	Buy now
14	68V44551008D Housing, lower mount rubber	Buy now

Bracket 2



Ref	Part	
15	9341037M04 Circlip (6e5)	Buy now
16	61A4457500 Damper, lower mount rubber	Buy now
17	61A44550194 Mount damper, lower side	Buy now
18	9020232M19 Washer, plate (6e5)	Buy now
19	9020116M55 Washer, plate (6e5)	Buy now
20	9020115M58 Washer, plate (6e5)	Buy now
21	9010914007 Bolt	Buy now
22	9538014600 Nut,hex. (ge6)	Buy now
23	9299514600 Washer (6e5)	Buy now
24	68V44553008D Cover, lower mount	Buy now
25	9011910049 Bolt, with washer	Buy now
26	67F4451401 Mount damper, upper side	Buy now
27	9011908091 Bolt, with washer	Buy now
28	9010912007 Bolt	Buy now
29	67F4452600 Plate	Buy now


Bracket 2



68V9110-J200


Ref	Part	
30	9020112M09 Washer, plate	Buy now
31	67F4453300 Damper, upper mount rubber	Buy now
32	9018512M12 Nut, self-locking(6e5)	Buy now
33	68V4851100 Hook, steering	Buy now
34	9011610175 Bolt, stud	Buy now
35	9018510051 Nut, self-locking	Buy now

Control




Ref	Part	
1	67F4853800 Clamp, cable 1	Buy now
2	9010906M86 Bolt	Buy now
3	6634834400 Cable end, remote control	Buy now
4	9046818008 Clip 620436610000	Buy now
5	68V4411702 Bracket	Buy now
6	60V8259F00 Switch assembly	Buy now
7	61A8258801 Plate	Buy now
8	9798504116 Screw, with washer(61b)	Buy now
9	9709506040 Bolt (682)	Buy now
10	9299506600 Washer, plain (646)	Buy now
11	9046210027 Clamp	Buy now
12	68V4412201 Bushing, shift rod lever	Buy now
13	9020207M07 Washer, plate (688)	Buy now
15	68V4412100 Lever, shift rod	Buy now
16	9038606M12 Bushing (688)	Buy now

Control




Ref	Part	
17	68V4412010 Handle gear shift assembly L(20.3")	Buy now
17	68V4412030 Handle gear shift assembly X(25.3")	Buy now
18	9321009165 O-ring	Buy now
19	9038690M90 Bush(61a)	Buy now
20	9020109M02 Washer, plate(61a)	Buy now
21	9149020015 Pin, cotter (648)	Buy now
22	68V441180094 Bracket	Buy now
23	9757506525 Bolt, hexagon w/w deep recess	Buy now
24	9350104M02 Ball (697)	Buy now
25	9050112082 Spring 6484411600	Buy now
26	6484271500 Bushing 2	Buy now
29	68V4215410 Lever, throttle control	Buy now
30	68V4217100 Bushing	Buy now
31	9020610M04 Washer, wave (676)	Buy now
32	9038706M21 Collar	Buy now

Control




Ref	Part	
33	9017906M28 Nut(63v)	Buy now
34	68V4121300 Cam, accel.	Buy now
35	67F4413500 Spring	Buy now
37	9709506035 Bolt(j52)	Buy now
38	9299506100 Washer(6a1)	Buy now
40	9020106M62 Washer, plate (6e5)	Buy now
42	6884121101 Link, accel	Buy now
43	9538005600 Nut, hexagon (663)	Buy now
44	6824123700 Joint, link 2	Buy now

Crankshaft & Piston



Ref	Part	
1	68V1141100 Crankshaft	Buy now
2	9310248017 Oil seal	Buy now
3	9310148002 Oil seal	Buy now
4	6D81141600 Plane bearing, crankshaft 1 UR GREEN	Buy now
4	6D81141610 Plane bearing, crankshaft 1 UR BLUE	Buy now
4	6D81141620 Plane bearing, crankshaft 1 UR RED	Buy now
5	6D81141700 Plane bearing, crankshaft 2 UR YELLOW	Buy now
5	6D81141710 Plane bearing, crankshaft 2 UR GREEN	Buy now
5	6D81141720 Plane bearing, crankshaft 2 UR BLUE	Buy now
5	6D81141730 Plane bearing, crankshaft 2 UR RED	Buy now
6	6D81141800 Plane bearing, crankshaft 3 UR GREEN	Buy now
6	6D81141810 Plane bearing, crankshaft 3 UR BLUE	Buy now
6	6D81141820 Plane bearing, crankshaft 3 UR RED	Buy now
7	68VW116402 Piston/con-rod assembly std	Buy now
7	68VW116412 Piston/con-rod assembly(0.25mm os) AP	Buy now


Crankshaft & Piston



68VA110-K030


Ref	Part	
8	K1CA327500 Bolt, connecting rod	Buy now
9	6D81160301 Piston ring set (std)	Buy now
9	6D81160401 Piston ring set (0.25mm o/s) AP	Buy now
10	68V1165600 Plane bearing, connecting rod UR YELLOW	Buy now
10	68V1165610 Plane bearing, connecting rod UR GREEN	Buy now
10	68V1165620 Plane bearing, connecting rod UR BLUE	Buy now
10	68V1165630 Plane bearing, connecting rod UR RED	Buy now

Cylinder & Crankcase 1




Ref	Part	
1	68VW009B119S Cylinder block assembly (68v-13)	Buy now
2	68V1510010 Crankcase assembly	Buy now
3	9360612019 Pin, dowel (614)	Buy now
4	68V4458101 Bolt	Buy now
5	9011910M88 Bolt, with washer	Buy now
6	9011908M66 Bolt, with washer	Buy now
7	9034014M06 Plug, straight screw(62y)	Buy now
8	9043014115 Gasket (663)	Buy now
9	62Y1111900 Hanger, engine	Buy now
10	68V1111900 Hanger, engine	Buy now
11	9709506020 Bolt(7u8)	Buy now
12	9299506600 Washer, plain (646)	Buy now
13	67F1514200 Guide 1	Buy now
14	6E51132500 Anode	Buy now
15	9878004016 Screw, flat head(ga5)	Buy now

Cylinder & Crankcase 1



Ref	Part	
16	6D841113409S Outer cover, exhaust	Buy now
17	6761137200 Nipple, hose	Buy now
18	9034018M09 Plug, straight screw	Buy now
19	9043018130 Gasket (1j7)	Buy now
20	67F41114A2 Gasket, exhaust outer cover	Buy now
21	9011906MA4 Bolt, with washer	Buy now
22	68V4254110 Pipe 1	Buy now
23	9046511M10 Clamp	Buy now
24	9046418004 Clamp	Buy now
25	9046410010 Clamp	Buy now
26	6882437800 Pipe, joint	Buy now
27	61A2431600 Pipe 6	Buy now
29	6G51241600 Valve, pressure control	Buy now
30	9050116M11 Spring, compression (688)	Buy now
31	9048020M05 Grommet (688)	Buy now


Cylinder & Crankcase 1




Ref	Part	
32	67F1246A019S Cover 1	Buy now
33	67F12435A0 Gasket	Buy now
34	9011906MA2 Bolt, with washer	Buy now
35	69J1130100 Anode cover assembly	Buy now
36	67F1132501 Anode	Buy now
37	67F1132800 Grommet, anode	Buy now
38	9010506M07 Bolt (689)	Buy now
39	9043006M03 Gasket (6f5)	Buy now
40	9757508540 Bolt, hexagon w/w deep recess	Buy now
41	67F1243A00 Hose 1	Buy now
42	9046511M59 Clamp(63m)	Buy now
43	9046720M15 Clip	Buy now
44	68V1135100 Gasket, cylinder	Buy now
45	5GH1344000 Element assembly, oil cleaner	Buy now
46	9040120007 Bolt, union	Buy now

Cylinder & Crankcase 1

Ref	Part	
48	9046416001 Clamp	Buy now




Cylinder & Crankcase 2




Ref	Part	
1	68VW009A079S Cylinder head complete	Buy now
2	68V11110209S Cylinder head assembly	Buy now
3	67F1113310 Guide, intake valve	Buy now
4	9034451019 Plug, taper screw	Buy now
5	9011907235 Bolt, with washer	Buy now
6	9180908006 Pin, dowel	Buy now
7	9011907234 Bolt, with washer	Buy now
8	69J1130100 Anode cover assembly	Buy now
9	67F1132501 Anode	Buy now
10	67F1132800 Grommet, anode	Buy now
11	9010506M07 Bolt (689)	Buy now
12	9043006M03 Gasket (6f5)	Buy now
13	9757508540 Bolt, hexagon w/w deep recess	Buy now
14	67F1118103 Gasket, cylinder head 1	Buy now
15	9953014016 Pin, dowel	Buy now

Cylinder & Crankcase 2




Ref	Part	
16	9015510005 Screw, flat fillister	Buy now
17	9011908M91 Bolt, with washer	Buy now
18	6D811191019S Cover, cylinder head 1	Buy now
19	67F1116800 Cover, breather	Buy now
20	9850704008 Screw, pan head(jg1)	Buy now
21	9290704600 Washer(jf2)	Buy now
22	9048012072 Grommet(53y)	Buy now
23	6D81135601 Seal, cylinder 2	Buy now
24	9709506030 Bolt(jf7)	Buy now
25	9299506600 Washer, plain (646)	Buy now
26	67F1119201 Cover, cylinder head 2	Buy now
27	9015906M29 Screw, with washer	Buy now
28	60V1241100 Thermostat	Buy now
29	67F1241200 Seal, thermostat	Buy now
30	68V12413009S Cover, thermostat	Buy now

Cylinder & Crankcase 2




Ref	Part	
31	9709506025 Bolt	Buy now
33	6G81536300 Plug, oil	Buy now
34	9321024M79 O-ring	Buy now
35	68V8362600 Mark 6	Buy now
36	9470200400 Plug, spark (lfr6a-11)	Buy now

Electrical 1




Ref	Part	
1	68V8591A80 Engine control unit assembly	Buy now
2	68V8253B00 Plate, lock	Buy now
3	60V8551600 Spacer	Buy now
4	9038706M60 Collar (6h3)	Buy now
5	9011906071 Bolt, with washer	Buy now
6	68V8253C00 Spring, plate lock	Buy now
7	9709506012 Bolt(gh1)	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	68V8231000 Ignition coil assembly	Buy now
10	68V8231010 Ignition coil assembly	Buy now
11	9709506025 Bolt	Buy now
12	9299506100 Washer(6a1)	Buy now
14	68V8238800 Plate	Buy now
15	9046406001 Clamp	Buy now
16	68V8238810 Plate	Buy now

Electrical 1




Ref	Part	
17	9046412183 Clamp(jn2)	Buy now
18	67F8236100 Clamp, cord	Buy now
19	67F8236200 Clamp, cord 2	Buy now
20	68V8196010 Rectifier & regulator assembly	Buy now
24	9046409M47 Clamp(65j)	Buy now
25	9709506016 Bolt, hexagon deep recess	Buy now

Electrical 2




Ref	Part	
1	9046513M18 Clamp	Buy now
2	68V8210500 Battery cable FOR F(L)115AET	Buy now
3	9010506M14 Bolt (6e0) FOR F(L)115AET	Buy now
4	60E8195000 Relay assembly	Buy now
5	9778060625 Screw, tapping(65j)	Buy now
6	68V8194A00 Relay	Buy now
7	68F8195300 Stay, relay	Buy now
8	9778060620 Screw, tapping(6k8)	Buy now
9	9759506610 Bolt, hexagon w/w deep recess	Buy now
10	6P28183X00 Cap, terminal	Buy now
11	63P8195000 Relay assembly	Buy now
14	9709506020 Bolt(7u8)	Buy now
15	9299506600 Washer, plain (646)	Buy now
16	68V8194802 Bracket	Buy now
17	6A08231700 Damper, ignition coil	Buy now

Electrical 2




Ref	Part	
18	9038706119 Collar	Buy now
19	9011906M59 Bolt, with washer	Buy now
20	68V8259400 Clamp	Buy now
21	68V8194210 Cover	Buy now
22	67F2812A00 Puller, fuse	Buy now
23	68V8259070 Wire harness assembly	Buy now
24	67F8215B10 Cap (yellow)	Buy now
25	67F8215B20 Cap (green)	Buy now
26	67F8215100 Fuse	Buy now
27	67F8215110 Fuse	Buy now
28	6P28258200 Cap 1 (female)	Buy now
29	6P28258210 Cap 1 (male)	Buy now
30	9709506016 Bolt, hexagon deep recess	Buy now
31	9299506100 Washer(6a1)	Buy now
35	9038706M05 Collar(6h4)	Buy now

Electrical 2




Ref	Part	
36	9046512M53 Clamp(62e)	Buy now
39	9046418004 Clamp	Buy now
40	9046412010 Clamp	Buy now
41	6D88258101 Stay, cord clamp	Buy now
42	9709506014 Bolt(gj3)	Buy now
44	9046430003 Clamp	Buy now
47	9046513M11 Clamp (6e5)	Buy now
49	68V8191910 Graphic, regulator	Buy now
51	9701306020 Bolt(62y) AP F(L)115AET1	Buy now
52	9290306100 Washer(6a1) AP F(L)115AET1	Buy now
53	9290306600 Washer, plain (646) AP F(L)115AET1	Buy now

Electrical 3




Ref	Part	
1	68V8132G00 Plate	Buy now
2	9048006M19 Grommet (6e3)	Buy now
3	9709506016 Bolt, hexagon deep recess	Buy now
4	9299506600 Washer, plain (646)	Buy now
5	68V8258820 Plate	Buy now
6	9709506012 Bolt(gh1)	Buy now
9	9299506100 Washer(6a1)	Buy now
11	67F8579000 Thermosensor assembly	Buy now
12	67F8575700 Retainer	Buy now
13	68V8575300 Gasket, sender unit	Buy now
16	68V8250400 Oil pressure switch assembly	Buy now
17	63D8256310 Trim & tilt switch assembly	Buy now
18	6E58258700 Gasket	Buy now
19	67F8361400 Bracket	Buy now
20	9010906M86 Bolt	Buy now

Electrical 3




Ref	Part	
21	6D88252H01 Plate, holder	Buy now
24	6CJ8578000 Sensor, knock	Buy now

Fuel 1




Ref	Part	
1	6898554700 Damper	Buy now
2	6R32437700 Pipe, joint 3 FOR F(L)115AET	Buy now
3	9046511M10 Clamp FOR F(L)115AET	Buy now
4	68V2431410 Pipe 4 FOR F(L)115AET	Buy now
4	68V2431430 Pipe 4 FOR F(L)115AET1	Buy now
5	6D82456000 Filter assembly	Buy now
6	6D82456300 Element, filter (with tag)	Buy now
7	6D82456400 Gasket	Buy now
8	6D82456200 Cup, filter (with tag)	Buy now
9	6D82446900 Float, water level	Buy now
10	6D82451900 Clip	Buy now
12	60C2456600 Bracket, filter	Buy now
13	9538008600 Nut (661)	Buy now
14	9709506016 Bolt, hexagon deep recess	Buy now
15	9299506600 Washer, plain (646)	Buy now

Fuel 1




Ref	Part	
16	68V243110 Pipe, fuel 1 FOR F(L)115AET	Buy now
16	68V2431120 Pipe, Fuel 1 FOR F(L)115AET1	Buy now
17	9046412224 Clamp(4pe)	Buy now
18	6D82441010 Fuel pump assembly	Buy now
19	68V2441200 Body 1	Buy now
20	68V2445400 Spring	Buy now
21	63P1313100 Plunger	Buy now
22	68V2442300 Spring, diaphragm	Buy now
23	68V2441100 Diaphragm	Buy now
24	68V2437400 Pin	Buy now
25	68V2441310 Body 2	Buy now
26	6D82441400 Body 3	Buy now
27	68V2444400 Screw	Buy now
28	68V2414900 Nut	Buy now
30	9321030682 O-ring (371)	Buy now

Fuel 1




Ref	Part	
31	9011906M83 Bolt, with washer	Buy now
32	6R32437710 Pipe, joint 3 FOR F(L)115AET1	Buy now
34	68V2445200 Cover FOR F(L)115AET1	Buy now
35	67F2810001 Tool kit AP	Buy now
36	63P281997BD0 O/m fl115aetx/ f150betx '12 UR (NL)	Buy now
36	63P281997BE0 O/m fl115aetx/ f150betx '12 UR (E)	Buy now
36	63P281997BF0 O/m fl115aetx/ f150betx '12 UR (F)	Buy now
36	63P281997BG0 O/m fl115aetx/ f150betx '12 UR (D)	Buy now
36	63P281997BH0 O/m fl115aetx/ f150betx '12 UR (I)	Buy now
36	63P281997BS0 O/m fl115aetx/ f150betx '12 UR (ES)	Buy now
37	63P281998BK0 O/m fl115aetx/ f150betx '12 UR (DK)	Buy now
37	63P281998BL0 O/m fl115aetx/ f150betx '12 UR (SF)	Buy now
37	63P281998BM0 Manual,owner's UR (S)	Buy now
37	63P281998BN0 O/m fl115aetx/ f150betx '12 UR (N)	Buy now
37	63P281998BP0 O/m fl115aetx/ f150betx '12 UR (P)	Buy now

Fuel 1



Ref	Part	
37	63P281998BR0 O/m fl115aetx/ f150betx '12 UR (GR)	Buy now
38	4EB2314400 Seal, dust	Buy now
38	68V2447110 Diaphragm	Buy now


Fuel 2



68VB300-L120


Ref	Part	
1	6YK2430644 Fuel pipe comp. 1 AP F(L)115AET	Buy now
2	6YK2436071 Primer pump assembly AP F(L)115AET1	Buy now

Fuel Injection Pump 1



Ref	Part	
1	68V1418021 Float chamber assembly (68v-22) FOR F(L)115AET	Buy now
1	68V1418041 Float Chamber assembly FOR F(L)115AET1	Buy now
2	68V1418220 Cover, float chamber (68v-21)	Buy now
3	6CB2450101 Filter, fuel	Buy now
4	68V2448100 Plug	Buy now
5	6CB1301600 O-ring	Buy now
6	6CB1421600 Screw	Buy now
7	6CB2421700 Cover	Buy now
8	6CB1390601 Regulator, pressure	Buy now
9	6CB1456400 Screw	Buy now
10	6CB1414600 Plate	Buy now
11	63P1456700 Screw	Buy now
12	69J1371600 Collar	Buy now
13	6CB1359300 Damper	Buy now
14	68V1418120 Body, float chamber 1	Buy now


Fuel Injection Pump 1




Ref	Part	
15	6P21419100 Plug, drain	Buy now
16	6CB1423900 Seal	Buy now
17	6CB2445200 Cover set	Buy now
18	6CB1442900 Screw	Buy now
19	68V1390720 Fuel pump comp.	Buy now
20	63P1391500 Filter	Buy now
21	6AW1313200 Joint	Buy now
22	6CB1498500 Float	Buy now
23	6CB1454600 Valve, needle	Buy now
24	6CB1447B00 Bush and joint set	Buy now
25	6AW1378100 Damper, pump	Buy now
26	6CB1498400 Gasket, float chamber	Buy now
27	6P21438600 Pin, float	Buy now
28	6AW1378400 Cover, pump	Buy now
29	4SV2445300 Screw	Buy now

Fuel Injection Pump 1

Ref	Part	
30	9850704008 Screw, pan head(jg1)	Buy now




Fuel Injection Pump 2




Ref	Part	
1	68V2432400 Pipe 13 FOR F(L)115AET	Buy now
1	68V2432410 Pipe 13 FOR F(L)115AET1	Buy now
2	68V1248200 Pipe 2	Buy now
3	6AW1419700 Pipe	Buy now
4	68V1357700 Clip	Buy now
5	9046511M10 Clamp	Buy now
6	68V1397130 Pipe, fuel 1	Buy now
7	6AW2430000 Fuel pipe joint	Buy now
8	9046411008 Clamp	Buy now
9	9046412010 Clamp	Buy now
10	9046409129 Clamp(3ld)	Buy now
12	68V2486400 Tube	Buy now
13	68V1248410 Pipe 4	Buy now

Generator




Ref	Part	
1	68V8145000 Rotor assembly	Buy now
2	68V8146000 Base assembly	Buy now
3	68V8558000 Coil, pulser	Buy now
4	68V8141000 Stator assembly	Buy now
5	63D8134520 Screw, pan	Buy now
6	9760704110 Screw, pan head with washer (s)	Buy now
7	4458132820 Clamp, read	Buy now
8	68V8167300 Rotor	Buy now
9	9953008012 Pin, dowel(6g8)	Buy now
10	9709506030 Bolt(jf7)	Buy now
11	9299506100 Washer(6a1)	Buy now
12	9299506600 Washer, plain (646)	Buy now
13	9028004M08 Key, woodruff	Buy now
14	9020124014 Washer, plate	Buy now
15	9017924002 Nut	Buy now

Generator




Ref	Part	
16	6D88133200 Plate, timing	Buy now
17	9798506210 Screw pan head	Buy now
18	68V8133700 Cover, flywheel	Buy now
19	9038706M71 Collar (6g8)	Buy now
20	9048015M31 Grommet (6g1)	Buy now
21	9048012314 Grommet(3aa)	Buy now
22	9011906M92 Bolt, with washer	Buy now
23	68V1343762 Mark, caution	Buy now
24	6AH8199540 Label, warning	Buy now
25	6AH8199550 Label, warning	Buy now
26	6AH8199440 Label, safety	Buy now
27	6AH8199450 Label, safety	Buy now
28	6AG8199600 Mark	Buy now

Intake 1




Ref	Part	
1	68V1444010 Silencer assembly, intake	Buy now
2	9587506020 Bolt, flange(jk3)	Buy now
3	68V1375120 Body, throttle 1	Buy now
4	68V1441J10 Pipe, silencer	Buy now
5	68V1389800 Holder	Buy now
6	68V1449610 Bolt	Buy now
7	68V1427100 Insulator	Buy now
8	68V1355600 Gasket, manifold	Buy now
9	68V1363500 Joint, intake 1	Buy now
10	68F8368810 Sensor assembly	Buy now
11	68V8114700 Screw 3	Buy now
12	68VW136410 Manifold Intake 1	Buy now
13	68V1364510 Gasket, manifold 1	Buy now
14	68V1364600 Gasket, manifold 2	Buy now
15	68V1364700 Gasket, manifold 3	Buy now

Intake 1




Ref	Part	
16	9046411012 Clamp	Buy now
17	9046420181 Clamp(4ap)	Buy now
18	68V1316110 Pipe, delivery 1	Buy now
19	6P21444600 Bolt	Buy now
20	68V1376110 Injector	Buy now
21	68V1416A00 O-ring	Buy now
22	68V1376610 Rubber, injector	Buy now
23	68V1358400 Pipe, intake manifold	Buy now
24	68V1357710 Clip	Buy now
25	68V8114501 Screw 1	Buy now
26	68V8182L00 O-ring 1	Buy now
27	9011906266 Bolt, with washer	Buy now
28	68V8588510 Throttle sensor assembly	Buy now

Intake 2




Ref	Part	
1	68V1537300 Pipe, breather	Buy now
2	9046720M15 Clip	Buy now
3	6D88254400 Clamp	Buy now
4	9587506025 Bolt, flange deep recess	Buy now
5	68V8238900 Plate 2	Buy now
6	9709506012 Bolt(gh1)	Buy now
7	9299506600 Washer, plain (646)	Buy now
8	9046420011 Clamp	Buy now
9	6C51371300 Valve, idle speed control	Buy now
10	6CJ1137200 Nipple, hose	Buy now
11	9321033003 O-ring	Buy now
12	9798005214 Screw, with washer	Buy now
13	68V1315200 Stay 2	Buy now
14	9011906M17 Bolt, with washer	Buy now
15	9048010M23 Grommet(6k7)	Buy now

Intake 2




Ref	Part	
16	9038706M60 Collar (6h3)	Buy now
17	68V1389700 Pipe, air	Buy now
18	68V1389200 Hose, air 2	Buy now
19	68V1354310 Hose, air	Buy now
20	9010508M87 Bolt, washer based	Buy now
21	9010508242 Bolt, flange	Buy now
22	9038709017 Collar	Buy now
23	9169050014 Pin, spring (647)	Buy now
24	68V1429110 Bracket 1	Buy now
25	9589508020 Bolt, flange deep recess	Buy now
27	68V1364200 Manifold 2	Buy now
28	9589506030 Bolt, flange deep recess	Buy now
29	9011906M24 Bolt, with washer	Buy now
30	68V2145700 Plate, pipe guide	Buy now
33	9046418246 Clamp(4tr)	Buy now

Intake 2




Ref	Part	
34	6P22417000 Canister assembly	Buy now
35	68V2419A00 Holder	Buy now
36	68V2134X00 Bracket, canister	Buy now
37	9709506016 Bolt, hexagon deep recess	Buy now
42	9046426002 Clamp	Buy now

Intake 3




Ref	Part	
1	6C58612000 Solenoid valve assembly	Buy now
2	9538006600 Nut(661)	Buy now
3	68V2416A00 Hose	Buy now
4	9046410011 Clamp	Buy now
5	6AW1354510 Hose 1	Buy now
6	6882437800 Pipe, joint	Buy now
7	68V1354610 Hose 2	Buy now
8	6E52174400 Breezer	Buy now
9	6CB1354700 Hose 3	Buy now
10	68V1354800 Hose, air 4	Buy now
11	68V1248300 Pipe 3	Buy now
12	68V1475F00 Pipe 3	Buy now
13	6G82437600 Pipe, joint 1	Buy now
14	6CB1498900 Orifice, air vent	Buy now
15	68V1475G00 Pipe 4	Buy now

Intake 3




Ref	Part	
16	68V1475A00 Pipe 1	Buy now
17	68V2475H00 Bracket, seat lever 1	Buy now
18	9589506010 Bolt, flange(7ht)	Buy now
19	9046411012 Clamp	Buy now
20	9046420006 Clamp	Buy now
21	68V2475J00 Bracket, seat lever 2	Buy now
23	9046407009 Clamp	Buy now
24	68V1353210 Hose, vacuum sensing 3	Buy now
25	9046104011 Clamp 6208236100	Buy now
27	9046410006 Clamp	Buy now
28	9046418004 Clamp	Buy now
29	9046412224 Clamp(4pe)	Buy now

Lower Casing & Drive 1




Ref	Part	
1	68V45300138D Lower unit assembly L(20.3"),RH	Buy now
1	68V45300338D Lower unit assembly X(25.3"),RH	Buy now
2	6E545301078D Casing, lower	Buy now
3	93315628U9 Brg,cyl-cal roller (6e5)	Buy now
4	93332000U7 Brg,tapered roller 76mm (6e5)	Buy now
5	6E54556701 Shim (t:0.10mm) UR	Buy now
5	6E54556710 Shim (t:0.12mm) UR	Buy now
5	6E54556720 Shim (t:0.15mm) UR	Buy now
5	6E54556730 Shim (t:0.18mm) UR	Buy now
5	6E54556740 Shim (t:0.30mm) UR	Buy now
5	6E54556750 Shim (t:0.40mm) UR	Buy now
5	6E54556760 Shim (t:0.50mm) UR	Buy now
6	9034008002 Plug, straight screw	Buy now
7	6884534110 Plug, drain	Buy now
8	9043008020 Gasket	Buy now

Lower Casing & Drive 1




Ref	Part	
9	6E54553600 Sleeve, drive shaft	Buy now
10	6E54537800 Nipple, hose	Buy now
11	9044507ME8 Hose (I250) L(20.3")	Buy now
11	9044507ME9 Hose (I250) X(25.3")	Buy now
12	6E58355810 End, nipple	Buy now
13	6E54532100 Plate	Buy now
14	9321058144 O-ring(47x)	Buy now
15	9310609014 Oil seal	Buy now
16	9011906M10 Bolt, with washer	Buy now
17	6L64415002 Shift cam assembly	Buy now
18	9900108600 Circlip(2r6)	Buy now
19	61A4553800 Spacer, 1	Buy now
20	9020122M01 Washer, plate(61a)	Buy now
21	9020622M19 Washer, wave(61a)	Buy now
22	61A4552700 Collar, drive shaft	Buy now

Lower Casing & Drive 1




Ref	Part	
23	61A4431101 Housing, water pump	Buy now
24	61A4432202 Insert, cartridge	Buy now
25	9321086M38 O-ring (6e5)	Buy now
26	9321037160 O-ring (6g8)	Buy now
27	6E54435201 Impeller	Buy now
28	9028004M05 Key, woodruff (6e5)	Buy now
29	68V4432300 Outer plate, cartridge	Buy now
30	6E544315A0 Gasket,water pump	Buy now
31	9360612019 Pin, dowel (614)	Buy now
32	9011908M14 Bolt, with washer	Buy now
33	6E545331009S Housing, bearing	Buy now
34	9310128M16 Oil seal (6e5)	Buy now
35	93317330U2 Bearing, cylindrical(6k0)	Buy now
36	6E54558701 Shim (t:0.10mm) UR	Buy now
36	6E54558710 Shim (t:0.12mm) UR	Buy now

Lower Casing & Drive 1




Ref	Part	
36	6E54558720 Shim (t:0.15mm) UR	Buy now
36	6E54558730 Shim (t:0.18mm) UR	Buy now
36	6E54558740 Shim (t:0.30mm) UR	Buy now
36	6E54558750 Shim (t:0.40mm) UR	Buy now
36	6E54558760 Shim (t:0.50mm) UR	Buy now
37	93341930V2 Bearing, thrust(64d)	Buy now
38	9321055M14 O-ring (70e)	Buy now
39	6E54534400 Cover, oil seal	Buy now
40	9709508025 Bolt (62g)	Buy now
41	9299508600 Washer, plain (663)	Buy now
42	68V4550110 Drive shaft comp. L(20.3")	Buy now
42	68V4550130 Drive shaft comp. X(25.3")	Buy now
43	68V455100 Pinion	Buy now
44	9017016M01 Nut, hexagon (688)	Buy now
45	68V4556000 Gear	Buy now

Lower Casing & Drive 1



Ref	Part	
46	93315425U7 Brg,cyl-cal roller (6e5)	Buy now
47	6E54561101 Shaft, propeller	Buy now
48	6E54563402 Slide, shift	Buy now
49	9050116M37 Spring (6g5)	Buy now
50	9350732009 Ball (12r)	Buy now
51	9351132017 Ball (498)	Buy now
52	9350316003 Ball	Buy now
53	9025008M07 Pin, straight (6g5)	Buy now
54	68V4563101 Clutch, dog	Buy now
55	6E54563301 Ring, cross pin	Buy now
56	6E54533200CA Housing, bearing	Buy now
57	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
58	68V4557100 Gear	Buy now
59	6E54557600 Washer, thrust 2	Buy now
60	93315430U8 Bearing	Buy now


Lower Casing & Drive 1



Ref	Part	
61	9310130M17 Oil seal (6e5)	Buy now
62	9321086M39 O-ring (6e5)	Buy now
63	6L64557700 Shim (t:0.10mm) UR	Buy now
63	6L64557710 Shim (t:0.12mm) UR	Buy now
63	6L64557720 Shim (t:0.15mm) UR	Buy now
63	6L64557730 Shim (t:0.18mm) UR	Buy now
63	6L64557740 Shim (t:0.30mm) UR	Buy now
63	6L64557750 Shim (t:0.40mm) UR	Buy now
63	6L64557760 Shim (t:0.50mm) UR	Buy now
64	9020130M92 Washer (6g5)	Buy now
65	9028204010 Key, strait(663)	Buy now
66	6884538302 Washer, claw	Buy now
67	6884538402 Nut	Buy now

Lower Casing & Drive 2


REGULAR ROTATION



 68VA110-K260

Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	68V4436111 Tube, water 1 L(20.3")	Buy now
2	68V4436130 Tube, water 1 X(25.3")	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	6E54431200 Cover, water pump housing	Buy now
5	9360812M05 Pin, dowel b (6e5)	Buy now
6	9707510045 Bolt(64d)	Buy now
7	9299510100 Ybs67-10 washer, spring	Buy now
8	9011910M89 Bolt, with washer	Buy now
9	6634537600 Guide, seal damper	Buy now
10	6884537500 Damper, seal 2	Buy now
11	6884521402 Cover, water inlet	Buy now
12	6884521502 Cover, water inlet	Buy now
13	9015205M07 Screw, countersunk	Buy now
14	9018505002 Nut nylon (sus)(ex4)	Buy now


Lower Casing & Drive 2



68VA110-K260

Ref	Part	
15	6E54537101 Trim tab	Buy now
16	9010510M00 Bolt, hexagon (663)	Buy now
17	90445076K2 Hose (I1700)	Buy now
18	6E58355800 End, nipple	Buy now
19	9046511M10 Clamp	Buy now
22	63P4598700 Spacer 1	Buy now
23	6884599701 Spacer 2	Buy now
24	9299018200 Washer (6e5)	Buy now
25	9017118M04 Nut, castle (6e5)	Buy now
26	9149040030 Pin, cotter (663)	Buy now
27	62A4597010 Propeller (3X13-1/2"X21"-K) UR	Buy now
27	62A4597210 Propeller (3X13-1/2"X23"-K) UR	Buy now
27	62A4597410 Propeller (3X13-1/2"X19"-K) UR	Buy now
27	62A4597600 Propeller (3X13-1/2"X17"-K) UR	Buy now
27	6884593002 Propeller (3x13x17) UR	Buy now


Lower Casing & Drive 2



Lower Casing & Drive 2


Ref	Part	
27	6E54595600 Propeller (3x13"x25"-k) UR	Buy now
27	6E54595800 Propeller (3x13-5/8"x14"-k) UR	Buy now

REGULAR ROTATION




68VA110-K260

Lower Casing & Drive 3




Ref	Part	
1	68W45300338D Lower unit assembly X(25.3"),LH	Buy now
2	6E545301078D Casing, lower	Buy now
3	93315628U9 Brg,cyl-cal roller (6e5)	Buy now
4	93315345W0 Bearing, cylindrical(6l6)	Buy now
5	93341360U8 Bearing, thrust (6l6)	Buy now
6	6L64553800 Spacer, 1	Buy now
7	6E54556701 Shim (t:0.10mm) UR	Buy now
7	6E54556710 Shim (t:0.12mm) UR	Buy now
7	6E54556720 Shim (t:0.15mm) UR	Buy now
7	6E54556730 Shim (t:0.18mm) UR	Buy now
7	6E54556740 Shim (t:0.30mm) UR	Buy now
7	6E54556750 Shim (t:0.40mm) UR	Buy now
7	6E54556760 Shim (t:0.50mm) UR	Buy now
8	9034008002 Plug, straight screw	Buy now
9	6884534110 Plug, drain	Buy now

Lower Casing & Drive 3




Ref	Part	
10	9043008020 Gasket	Buy now
11	6E54553600 Sleeve, drive shaft	Buy now
12	6E54537800 Nipple, hose	Buy now
13	9044507ME9 Hose (I250) X(25.3")	Buy now
14	6E58355810 End, nipple	Buy now
15	6E54532100 Plate	Buy now
16	9321058144 O-ring(47x)	Buy now
17	9310609014 Oil seal	Buy now
18	9011906M10 Bolt, with washer	Buy now
19	6E54415003 Shift cam assembly	Buy now
20	9900108600 Circlip(2r6)	Buy now
21	61A4553800 Spacer, 1	Buy now
22	9020122M01 Washer, plate(61a)	Buy now
23	9020622M19 Washer, wave(61a)	Buy now
24	61A4552700 Collar, drive shaft	Buy now

Lower Casing & Drive 3




Ref	Part	
25	61A4431101 Housing, water pump	Buy now
26	61A4432202 Insert, cartridge	Buy now
27	9321086M38 O-ring (6e5)	Buy now
28	9321037160 O-ring (6g8)	Buy now
29	6E54435201 Impeller	Buy now
30	9028004M05 Key, woodruff (6e5)	Buy now
31	68V4432300 Outer plate, cartridge	Buy now
32	6E544315A0 Gasket,water pump	Buy now
33	9360612019 Pin, dowel (614)	Buy now
34	9011908M14 Bolt, with washer	Buy now
35	6E545331009S Housing, bearing	Buy now
36	9310128M16 Oil seal (6e5)	Buy now
37	93317330U2 Bearing, cylindrical(6k0)	Buy now
38	6E54558701 Shim (t:0.10mm) UR	Buy now
38	6E54558710 Shim (t:0.12mm) UR	Buy now

Lower Casing & Drive 3




Ref	Part	
38	6E54558720 Shim (t:0.15mm) UR	Buy now
38	6E54558730 Shim (t:0.18mm) UR	Buy now
38	6E54558740 Shim (t:0.30mm) UR	Buy now
38	6E54558750 Shim (t:0.40mm) UR	Buy now
38	6E54558760 Shim (t:0.50mm) UR	Buy now
39	93341930V2 Bearing, thrust(64d)	Buy now
40	9321055M14 O-ring (70e)	Buy now
41	6E54534400 Cover, oil seal	Buy now
42	9709508025 Bolt (62g)	Buy now
43	9299508600 Washer, plain (663)	Buy now
44	68V4550130 Drive shaft comp. X(25.3")	Buy now
45	68V4555100 Pinion	Buy now
46	9017016M01 Nut, hexagon (688)	Buy now
47	68W4556000 Gear	Buy now
48	93315425U7 Brg,cyl-cal roller (6e5)	Buy now

Lower Casing & Drive 3




Ref	Part	
49	9020126M00 Washer, plate(6k0)	Buy now
50	68W4561100 Shaft, propeller	Buy now
51	6E54563402 Slide, shift	Buy now
52	9050116M37 Spring (6g5)	Buy now
53	9350732009 Ball (12r)	Buy now
54	9351132017 Ball (498)	Buy now
55	9350316003 Ball	Buy now
56	9025008M07 Pin, straight (6g5)	Buy now
57	68V4563101 Clutch, dog	Buy now
58	6E54563301 Ring, cross pin	Buy now
59	6L64533200CA Housing, bearing	Buy now
60	93332000V7 Bearing(6l6)	Buy now
61	68W4557010 Gear	Buy now
62	6L64557600 Washer, thrust	Buy now
63	93341440U5 Bearing, thrust (6k0)	Buy now

Lower Casing & Drive 3




Ref	Part	
64	6K14557801 Shim (t:0.10mm) UR	Buy now
64	6K14557810 Shim (t:0.12mm) UR	Buy now
64	6K14557820 Shim (t:0.15mm) UR	Buy now
64	6K14557830 Shim (t:0.18mm) UR	Buy now
64	6K14557840 Shim (t:0.30mm) UR	Buy now
64	6K14557850 Shim (t:0.40mm) UR	Buy now
64	6K14557860 Shim (t:0.50mm) UR	Buy now
65	9331543061 Bearing	Buy now
66	9310130M17 Oil seal (6e5)	Buy now
67	9321086M39 O-ring (6e5)	Buy now
68	6L64557700 Shim (t:0.10mm) UR	Buy now
68	6L64557710 Shim (t:0.12mm) UR	Buy now
68	6L64557720 Shim (t:0.15mm) UR	Buy now
68	6L64557730 Shim (t:0.18mm) UR	Buy now
68	6L64557740 Shim (t:0.30mm) UR	Buy now

Lower Casing & Drive 3




Ref	Part	
68	6L64557750 Shim (t:0.40mm) UR	Buy now
68	6L64557760 Shim (t:0.50mm) UR	Buy now
69	9028204010 Key, strait(663)	Buy now
70	6884538302 Washer, claw	Buy now
71	6884538402 Nut	Buy now

Lower Casing & Drive 4



Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	68V4436130 Tube, water 1 X(25.3")	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	6E54431200 Cover, water pump housing	Buy now
5	9360812M05 Pin, dowel b (6e5)	Buy now
6	9707510045 Bolt(64d)	Buy now
7	9299510100 Ybs67-10 washer, spring	Buy now
8	9011910M89 Bolt, with washer	Buy now
9	6634537600 Guide, seal damper	Buy now
10	6884537500 Damper, seal 2	Buy now
11	6884521402 Cover, water inlet	Buy now
12	6884521502 Cover, water inlet	Buy now
13	9015205M07 Screw, countersunk	Buy now
14	9018505002 Nut nylon (sus)(ex4)	Buy now
15	6L64537100 Tab-trim	Buy now


Lower Casing & Drive 4



68W0100-1310


Ref	Part	
16	9010510M00 Bolt, hexagon (663)	Buy now
17	90445076K2 Hose (1700)	Buy now
18	6E58355800 End, nipple	Buy now
19	9046511M10 Clamp	Buy now
22	63P4598700 Spacer 1	Buy now
23	6884599701 Spacer 2	Buy now
24	9299018200 Washer (6e5)	Buy now
25	9017118M04 Nut, castle (6e5)	Buy now
26	9149040030 Pin, cotter (663)	Buy now
27	6L64593001 Propeller (3x13"x17"-kl) UR	Buy now
27	6L64597000 Propeller (3x13 x19 -kl) UR	Buy now
27	6L64597200 Propeller (ss 3x13"x21"-kl) UR	Buy now

Oil Pan




Ref	Part	
1	68V1531100CA Oil pan	Buy now
2	63P1531600 Damper 1	Buy now
3	9034014M06 Plug, straight screw(62y)	Buy now
4	9043014M09 Gasket	Buy now
5	9757506525 Bolt, hexagon w/w deep recess	Buy now
6	9360612019 Pin, dowel (614)	Buy now
7	68V1531200 Gasket, oil pan	Buy now
8	67F1341100 Strainer, oil	Buy now
9	9581206025 Bolt, flange	Buy now
10	9038706263 Collar	Buy now
11	67F1341500 Seal, oil strainer	Buy now
12	67F1330010 Oil pump assembly	Buy now
13	67F1331402 Shaft, pump	Buy now
14	67F1347301 O-ring	Buy now
15	67F1332900 Gasket, pump cover	Buy now

Oil Pan




Ref	Part	
16	67F1349500 Screw	Buy now
17	67F1311901 Oil seal	Buy now
18	67F1376900 O-ring	Buy now
19	67F1391400 Housing, pump	Buy now
20	67F1363103 Oil seal	Buy now
21	67F1314900 Oil seal	Buy now
22	67F1333900 Gasket, pump cover	Buy now
23	67F1333800 Seal	Buy now
24	9709506045 Bolt, hexagon	Buy now
25	9299506600 Washer, plain (646)	Buy now
26	9360412M07 Pin, dowel (688)	Buy now
27	9321019MJ1 O-ring	Buy now
28	6D81536200 Plug, oil level	Buy now

Optional Parts 1




Ref	Part	
1	6Y88626700 Case complete 1	Buy now
2	6Y88626002 Remote control unit assembly	Buy now
3	6AA8626100 Xmtr. comp.	Buy now
4	9798006216 Screw, with washer(6h2)	Buy now
5	6X48338300 Buzzer	Buy now
6	6X48338600 Stay, buzzer	Buy now
7	9778060620 Screw, tapping(6k8)	Buy now
8	6Y88250910 Wire, sub lead	Buy now
9	9321004279 O-ring (4a0)	Buy now
10	9046511M10 Clamp	Buy now
11	6Y88454G00 Patch 1	Buy now
12	9016706M00 Screw, tapping (6h4) UR	Buy now
12	9788006035 Screw, pan head(6h4) UR	Buy now
13	9020106M30 Washer, plate (6a1)	Buy now
14	9578006300 Nut, nylon (6g1)	Buy now

Optional Parts 1



Ref	Part	
15	6Y88252111 Pigtail bus wire 0.6m-2ft	Buy now
16	6Y84827700 Sticker 1	Buy now
18	6H58131500 Wire, lead	Buy now


Optional Parts 2



 68VB110-L300


Ref	Part	
1	63P825E000 Tilt limit switch assembly	Buy now
2	9709506016 Bolt, hexagon deep recess	Buy now
3	9299506600 Washer, plain (646)	Buy now
4	9015905059 Screw, with washer	Buy now
5	9038705004 Collar	Buy now
6	9046511M10 Clamp	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
1	68V4380005 Power trim & tilt assembly	Buy now
2	64E4382503 Housing, trim & tilt	Buy now
3	6AW4388J00 Plug 2	Buy now
4	9321010M74 O-ring	Buy now
5	64E4381700 Filter 2	Buy now
6	64E4381002 Tilt piston sub assembly	Buy now
7	64E4381102 Screw, cylinder end	Buy now
8	64E4389800 Seal, dust 2	Buy now
9	64E4386700 O-ring 7	Buy now
10	64E4386600 O-ring 6	Buy now
11	6E54386200 O-ring 2	Buy now
12	64E4388300 O-ring 10	Buy now
13	6E54387200 Ring, back-up 2	Buy now
14	6E54381402 Piston, free	Buy now
16	64E4382002 Trim piston sub assembly	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
17	64E4382102 Screw, trim cylinder end	Buy now
18	64E4382200 Seal, trim dust	Buy now
19	64E4384J00 Seal, trim down	Buy now
20	6G54386400 O-ring 4	Buy now
21	6E54386400 O-ring 4	Buy now
22	6E54387401 Ring, back-up 4	Buy now
23	64E4382801 Body, reservoir	Buy now
24	64E4382901 Plug, reservoir	Buy now
25	64E4389700 O-ring	Buy now
26	64E4388E01 Bolt ,screw (l:14mm)	Buy now
27	64E4386900 O-ring 9	Buy now
28	64E4381G00 Pin 1	Buy now
29	6E54385800 Ball 1	Buy now
30	64E4382G00 Valve seat	Buy now
31	9020110060 Washer, plate	Buy now

Power Trim & Tilt Assy 1



Ref	Part	
32	9757510530 Bolt, with washer	Buy now
33	6BC4381800 Pin, lower shock mount	Buy now
34	9038622M98 Bush(61u)	Buy now
35	64E4384N00 Plug, Orifice	Buy now


Power Trim & Tilt Assy 2



60C1200-1211


Ref	Part	
1	64E4388E11 Bolt ,screw (l:34.7mm)	Buy now
2	64E4383100 Connector, shaft	Buy now
3	64E4386800 O-ring 8	Buy now
4	68V4383001 Gear pump assembly	Buy now
5	72X4385800 Ball	Buy now
6	64E4384300 Screw, valve lock	Buy now
7	6AW4384100 Piston, shuttle	Buy now
8	64E4380200 Valve sub assembly	Buy now
9	6E54389600 O-ring	Buy now
10	6G54386300 O-ring 3	Buy now
11	66Y4385100 Seat, relief valve	Buy now
12	64E4385800 Ball	Buy now
13	64E4385900 Pin, Valve Support	Buy now
14	68V4385500 Spring Up Relief	Buy now
15	64E4385000 Valve sub assembly	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
16	64E4386500 O-ring 10	Buy now
17	64E4381600 Filter 1	Buy now
18	6AW4385800 Ball	Buy now
19	64E4381711 Filter 2	Buy now
20	64E4386001 Manual valve sub-assembly	Buy now
21	72X85075L0 O-ring (nsd161)	Buy now
22	64E4382700 Ring set	Buy now
23	64E4387A00 O-ring	Buy now
24	64E4387300 Ring, back up	Buy now
25	6AW4387500 Ring, snap	Buy now
26	64E4387911 Screw, with washer	Buy now
27	64E4387901 Screw, with washer	Buy now
28	68V4388004 Motor assembly	Buy now
29	6H14386K10 Spring, brush	Buy now
30	64E4380J00 Holder Brush	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
31	64E4389100 Brush 1	Buy now
32	9760704310 Screw, pan head(6g8)	Buy now
33	64E4380F00 Holder, brush 2	Buy now
34	64E4389200 Breaker comp. (brush 2)	Buy now
35	6G54386501 O-ring	Buy now
36	9310208M43 Oil seal(6b0)	Buy now
37	64E4380501 Armature assembly	Buy now
38	64E4384310 Screw valve lock	Buy now

Repair Kit 1




Ref	Part	
1	68VW000106 Power head gasket kit	Buy now
2	9321024M79 O-ring	Buy now
3	67F1118103 Gasket, cylinder head 1	Buy now
4	9310238008 Oil seal	Buy now
5	9043014115 Gasket (663)	Buy now
6	67F12435A0 Gasket	Buy now
7	68V8575300 Gasket, sender unit	Buy now
8	67F41114A2 Gasket, exhaust outer cover	Buy now
9	9310248017 Oil seal	Buy now
10	9310148002 Oil seal	Buy now
11	9043018130 Gasket (1j7)	Buy now
12	68V1135100 Gasket, cylinder	Buy now
13	68V1364510 Gasket, manifold 1	Buy now
14	9321030682 O-ring (371)	Buy now
15	6D81135601 Seal, cylinder 2	Buy now

Repair Kit 1




Ref	Part	
16	68V1364600 Gasket, manifold 2	Buy now
17	68V1364700 Gasket, manifold 3	Buy now


Repair Kit 2



Repair Kit 2




Starting Motor



68VB300-L170


Ref	Part	
1	68V8180001 Starting motor assembly	Buy now
2	67F8185000 Armature assembly	Buy now
3	67F8181000 Stator assembly	Buy now
4	68F8184000 Brush holder assembly	Buy now
5	67F8180100 Brush set	Buy now
6	67F8181300 Spring, brush	Buy now
7	68F8182000 Rear bracket assembly	Buy now
8	67F8180800 Pinion assembly	Buy now
9	67F8185700 Pinion stopper set	Buy now
10	67F8180700 Gear assembly, starting motor	Buy now
11	67F8183200 Clutch, over run	Buy now
12	67F8183600 Shaft, pinion	Buy now
13	67F8182100 Bracket, center 1	Buy now
14	67F8184100 Bearing	Buy now
15	67F8189100 Gear, ring	Buy now

Starting Motor




Ref	Part	
16	67F8183R00 Gasket	Buy now
17	67F818300 Bracket, center 2	Buy now
18	60V8183T00 Gear, idler	Buy now
19	67F8180900 Washer kit	Buy now
20	67F8184200 Cover	Buy now
21	67F8183900 Lever assembly	Buy now
22	68V8194101 Starter relay assembly	Buy now
23	67F8186900 Cover, dust	Buy now
24	6K78182611 Bolt	Buy now
25	67F8182800 Bolt 2	Buy now
26	67F8184600 Screw	Buy now
27	9017908003 Nut	Buy now
28	60V8192500 Terminal	Buy now
29	68F8258200 Cover, wire harness	Buy now
30	9701308045 Bolt	Buy now

Starting Motor




Ref	Part	
31	9290308600 Washer, plain (663)	Buy now
32	9533308600 Nut(6l2) FOR F(L)115AET	Buy now
33	9290308100 Ybs67-8 washer, spring FOR F(L)115AET	Buy now
34	67F8362701 Label, caution 7 FOR F(L)115AET1	Buy now

Steering Guide




Ref	Part	
1	6E56135002 Steering guide attachment kit AP	Buy now
2	6E56135101 Rod, steering link	Buy now
3	9038710M61 Collar (6e5)	Buy now
4	9056012M01 Spacer (6e5)	Buy now
5	6E56135500 Bolt	Buy now
6	9018509M01 Nut, nylon (663)	Buy now
7	9020110M20 Washer, plate (663)	Buy now
8	6E54314501 Cap, clamp bracket	Buy now
9	9321016275 O-ring	Buy now
10	6E56130101 Tie bar assembly (l:600-800mm) AP	Buy now
11	6E56131300 Adjuster	Buy now
12	6E56131111 Tie bar	Buy now
13	6E56131500 Tie bar, 2	Buy now
14	6E56130300 Steering axle comp.	Buy now
15	9017014M06 Nut (6e5)	Buy now

Steering Guide



Ref	Part	
16	9538014700 Nut (6e5)	Buy now
17	9020110M76 Washer, plate (6e5)	Buy now
18	9010109M70 Bolt (6e5)	Buy now
19	9017009M05 Nut, hexagon (6e5)	Buy now


Top Cowling




Ref	Part	
1	68V4261050 Top cowling assembly	Buy now
2	68V4264710 Holder, clamp band	Buy now
3	9299006100 Washer(6a1)	Buy now
4	9538006600 Nut(661)	Buy now
5	68V4265200 Hook	Buy now
6	9709506012 Bolt(gh1)	Buy now
7	9299506600 Washer, plain (646)	Buy now
11	67F4264900 Holder, clamp band	Buy now
14	67F4266200 Damper	Buy now
15	68V4261310 Molding, air duct	Buy now
17	68V4261500 Seal	Buy now
18	68V4267730 Graphic, front	Buy now
19	68V4267840 Graphic, rear	Buy now
20	6D6W007000 Graphic Set	Buy now
21	6D64268100 Mark, cowling	Buy now

Top Cowling

Ref	Part	
22	67F1343420 Label, Caution	Buy now




Upper Casing




Ref	Part	
1	67F4113702CA Guide, exhaust	Buy now
2	9757508540 Bolt, hexagon w/w deep recess	Buy now
3	9360816M16 Pin, dowel(6t4)	Buy now
4	6G14272700 Grommet	Buy now
5	67F4113101CA Manifold, ext. 1	Buy now
6	67F41133A1 Gasket, exhaust manifold 1	Buy now
7	9707506070 Bolt(4kg)	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	68V1471110CA Muffler 1 L(20.3")	Buy now
9	68V1471130CA Muffler 1 X(25.3")	Buy now
10	68V4512300 Gasket, muffler	Buy now
11	9707506030 Bolt(jf7)	Buy now
13	9360619M23 Pin, dowel	Buy now
14	67F41134A0 Gasket, exhaust manifold	Buy now
15	67F4518100CA Plate	Buy now

Upper Casing




Ref	Part	
16	67F4113800 Seal, ext. 1	Buy now
17	67F4512700 Seal	Buy now
18	68V45111118D Casing, upper L(20.3")	Buy now
18	68V45111318D Casing, upper X(25.3")	Buy now
19	9011910M08 Bolt, with washer	Buy now
21	6E54531800 Bushing, drive shaft 3	Buy now
22	9342036M01 Circlip (6a0)	Buy now
23	67F4515100 Cover, upper casing	Buy now
24	9798006216 Screw, with washer(6h2)	Buy now
25	6C54515500 Cap	Buy now
26	67F4511300 Gasket, upper casing	Buy now
27	9589506010 Bolt, flange(7ht)	Buy now
28	9011908M58 Bolt, with washer	Buy now
29	67F4272400 Grommet	Buy now

Valve




Ref	Part	
1	6D81211100 Valve, intake	Buy now
2	6D81212100 Valve, exhaust	Buy now
3	6D81211600 Seat, valve spring	Buy now
4	6D81211300 Spring, valve inner	Buy now
5	26H1211700 Retainer, valve spring	Buy now
6	4G01211800 Cotter, valve	Buy now
7	KOAA372100 Seal, valve stem	Buy now
8	KOAA372200 Seal, valve stem 2	Buy now
9	6D81215300 Lifter, valve (12) UR	Buy now
9	6D81215310 Lifter, valve (14) UR	Buy now
9	6D81215320 Lifter, valve (16) UR	Buy now
9	6D81215330 Lifter, valve (18) UR	Buy now
9	6D81215340 Lifter, valve (20) UR	Buy now
9	6D81215350 Lifter, valve (22) UR	Buy now
9	6D81215360 Lifter, valve (24) UR	Buy now

Valve




Ref	Part	
9	6D81215370 Lifter, valve (26) UR	Buy now
9	6D81215380 Lifter, valve (28) UR	Buy now
9	6D81215390 Lifter, valve (30) UR	Buy now
9	6D812153A0 Lifter, valve (32) UR	Buy now
9	6D812153B0 Lifter, valve (34) UR	Buy now
9	6D812153C0 Lifter, valve (36) UR	Buy now
9	6D812153D0 Lifter, valve (38) UR	Buy now
9	6D812153E0 Lifter, valve (40) UR	Buy now
9	6D812153F0 Lifter, valve (42) UR	Buy now
9	6D812153G0 Lifter, valve (44) UR	Buy now
9	6D812153H0 Lifter, valve (46) UR	Buy now
9	6D812153J0 Lifter, valve (48) UR	Buy now
9	6D812153K0 Lifter, valve (50) UR	Buy now
9	6D812153L0 Lifter, valve (52) UR	Buy now
9	6D812153M0 Lifter, valve (54) UR	Buy now

Valve



Ref	Part	
9	6D812153N0 Lifter, valve (56) UR	Buy now
9	6D812153P0 Lifter, valve (58) UR	Buy now
9	6D812153R0 Lifter, valve (60) UR	Buy now
9	6D812153S0 Lifter, valve (62) UR	Buy now
9	6D812153T0 Lifter, valve (64) UR	Buy now
9	6D812153U0 Lifter, valve (66) UR	Buy now
9	6D812153V0 Lifter, valve (68) UR	Buy now
10	6D91217100 Camshaft 1	Buy now
11	68V1218100 Camshaft 2	Buy now
12	9360510108 Pin, dowel (8g8)	Buy now
13	67F1153700 Gear, driven	Buy now
14	9011910050 Bolt, with washer	Buy now
15	9310238008 Oil seal	Buy now
16	67F4624100 Belt	Buy now
17	67F1159000 Tensioner assembly	Buy now

Valve



Ref	Part	
18	9050616M39 Spring, tension	Buy now
19	9044515M03 Hose (I23)	Buy now
20	67F1159500 Plate, valve	Buy now
21	9011910M72 Bolt, with washer(6m6)	Buy now
22	6D81153600 Gear, drive	Buy now
23	9017040008 Nut	Buy now
24	9028004008 Key woodruff 604115450000	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.