



Yamaha FT60BET 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

| | |
|-------------------------------------|----|
| BOTTOM COWLING | 3 |
| BRACKET 1 | 7 |
| BRACKET 2 | 10 |
| CARBURETOR | 13 |
| CONTROL | 16 |
| CRANKSHAFT. PISTON | 19 |
| CYLINDER. CRANKCASE 1 | 21 |
| CYLINDER. CRANKCASE 2 | 23 |
| ELECTRICAL 1 | 25 |
| ELECTRICAL 2 | 27 |
| FUEL | 30 |
| FUEL TANK | 33 |
| GENERATOR | 34 |
| INTAKE | 36 |
| LOWER CASING. DRIVE 1 | 39 |
| LOWER CASING. DRIVE 2 | 45 |
| METER | 47 |
| OIL PAN | 48 |
| OIL PUMP | 50 |
| POWER TRIM & TILT ASSY 1 | 52 |
| POWER TRIM & TILT ASSY 2 | 57 |
| REMOTE CONTROL ASSY | 59 |
| REMOTE CONTROL BOX | 64 |
| REPAIR KIT 1 | 65 |
| REPAIR KIT 2 | 67 |
| REPAIR KIT 3 | 68 |
| STARTING MOTOR | 71 |
| STEERING GUIDE | 73 |
| TOP COWLING | 74 |
| UPPER CASING | 76 |
| VALVE | 78 |


Bottom Cowling



D2


| Ref | Part | |
|-----|----------------------------------------------------------------------------------------|-------------------------|
| 1 | 67C-42710-12-4D Bottom Cowling assembly WITH TAPPING BOLT | Buy now |
| 2 | 90119-06M08 Bolt, with washer | Buy now |
| 3 | 90480-09M12 Grommet (6a0) | Buy now |
| 4 | 90387-06M69 Collar (688) | Buy now |
| 5 | 62Y-42716-00 Rubber seal 1 | Buy now |
| 6 | 65W-42717-00 Rubber, seal 2 | Buy now |
| 7 | 67C-42738-00-4D Plate, fitting | Buy now |
| 8 | 62Y-42725-30 Grommet | Buy now |
| 9 | 62Y-42727-00 Grommet | Buy now |
| 10 | 90109-06M81 Bolt | Buy now |
| 11 | 67C-42815-00-4D Lever, clamp | Buy now |
| 12 | 90386-12M37 Bushing (6f5) | Buy now |
| 13 | 90386-12MA2 Bush | Buy now |
| 14 | 90206-12052 Washer, wave (666) | Buy now |
| 15 | 90201-12M07 Washer, plate | Buy now |

Bottom Cowling




| Ref | Part | |
|-----|-----------------------------------------------------|-------------------------|
| 16 | 67C-42816-01 Lever, clamp | Buy now |
| 17 | 97095-06012 Bolt(gh1) | Buy now |
| 18 | 66T-43144-00 Hook, spring | Buy now |
| 19 | 90109-06M86 Bolt | Buy now |
| 20 | 90506-18M40 Spring, tension | Buy now |
| 21 | 6H3-44391-01 Nipple, hose | Buy now |
| 22 | 688-42726-10 Grommet | Buy now |
| 23 | 90464-09M13 Clamp (6h1) | Buy now |
| 24 | 6E7-82317-00 Damper | Buy now |
| 25 | 68U-42727-00 Grommet | Buy now |
| 26 | 6H3-42727-00 Grommet | Buy now |
| 27 | 61N-24329-00 Seal | Buy now |
| 28 | 67C-42741-10-4D Apron | Buy now |
| 29 | 95380-06600 Nut(661) | Buy now |
| 30 | 97880-06025 Screw, pan head(6b0) | Buy now |

Bottom Cowling



| Ref | Part | |
|-----|----------------------------------------------------------------------|-------------------------|
| 31 | 92990-06100 Washer(6a1) | Buy now |
| 32 | 92990-06600 Washer, plain (646) | Buy now |
| 46 | 90109-06M80 Bolt FLUSHING KIT | Buy now |
| 34 | 90480-13M24 Grommet (6e9) | Buy now |
| 35 | 90387-06M43 Coller (6e9) | Buy now |
| 36 | 90464-09M49 Clamp | Buy now |
| 48 | 90465-11M10 Clamp FLUSHING KIT | Buy now |
| 38 | 90101-06020 Bolt | Buy now |
| 39 | 90179-06M28 Nut(63v) | Buy now |
| 41 | 92995-06100 Washer(6a1) | Buy now |
| 42 | 65W-42724-10 Grommet FLUSHING KIT | Buy now |
| 43 | 68T-12572-00 Adapter FLUSHING KIT | Buy now |
| 44 | 69W-12535-00 Plate FLUSHING KIT | Buy now |
| 45 | 90167-06002 Screw, tapping FLUSHING KIT | Buy now |
| 47 | 67C-24312-00 Pipe 2 FLUSHING KIT | Buy now |


Bottom Cowling



D2

| Ref | Part | |
|-----|-----------------------------------------------------------------------|-------------------------|
| 49 | 6R3-12580-00 Joint assembly FLUSHING KIT | Buy now |
| 50 | 69W-82377-00 Label (Sparkplug Mark) | Buy now |
| 51 | 62Y-13444-50 Mark | Buy now |
| 52 | 6A1-28176-00 Label Caution | Buy now |
| 53 | 6E3-8257H-00 Plate Mark | Buy now |


Bracket 1



D6

| Ref | Part | |
|-----|-----------------------------------------------------|-------------------------|
| 3 | 63D-82148-00 Wire, lead 5 | Buy now |
| 4 | 97885-06008 Screw, pan head(6a3) | Buy now |
| 5 | 65W-45251-00 Anode | Buy now |
| 6 | 90101-06020 Bolt | Buy now |
| 10 | 93700-06M03 Nipple, grease(6a1) | Buy now |
| 11 | 63D-43131-01 Bolt, clamp bracket | Buy now |
| 12 | 90386-22M15 Bushing (688) | Buy now |
| 13 | 90201-22M03 Washer, plate(64j) | Buy now |
| 14 | 90185-22M11 Nut, self-locking | Buy now |
| 15 | 6G5-43145-01 Cap, clamp bracket | Buy now |
| 16 | 6H5-43181-03 Lever, tilt stop 1 | Buy now |
| 17 | 6H5-43185-03 Lever, tilt stop 2 | Buy now |
| 18 | 90386-10M16 Bushing (688) | Buy now |
| 19 | 90386-10025 Bushing (658) | Buy now |
| 20 | 91690-30020 Pin, spring (6h4) | Buy now |


Bracket 1



D6

| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 21 | 6G5-43148-00 Collar, distance | Buy now |
| 22 | 90249-06M19 Pin(6e5) | Buy now |
| 23 | 90506-14M24 Spring, tension(6e5) | Buy now |
| 24 | 97095-06010 Bolt | Buy now |
| 25 | 6G5-43144-00 Hook, spring | Buy now |
| 26 | 688-43160-01 Tilt rod ass'y | Buy now |
| 27 | 688-43165-00 Stopper, tilt rod | Buy now |
| 28 | 91690-30012 Pin, spring | Buy now |
| 29 | 90502-16M02 Spring, conical (688) | Buy now |
| 32 | 6E5-43126-02 Pin, upper shock mount | Buy now |
| 33 | 90386-18M92 Bush(62x) | Buy now |
| 34 | 90386-18M35 Bush (688) | Buy now |
| 35 | 93410-18M02 Circlip (6f2) | Buy now |
| 36 | 68S-43818-00 Pin Lower Shock Mount | Buy now |
| 37 | 97080-08016 Bolt | Buy now |

Bracket 1




69W1010-2190

| Ref | Part | |
|-----|------------------------------------------------------|-------------------------|
| 38 | 90201-08M04 Washer, plate(6r8) | Buy now |
| 39 | 90387-18002 Collar | Buy now |
| 40 | 90387-18003 Collar | Buy now |
| 41 | 90101-12M65 Bolt | Buy now |
| 42 | 92995-12200 Ybs66-12 washer,plain | Buy now |
| 43 | 90201-12426 Washe, plate(663) | Buy now |
| 44 | 95380-12600 Nut (707) | Buy now |


D6

Bracket 2



| Ref | Part | |
|-----|------------------------------------------------------------|-------------------------|
| 2 | 90201-30M00 Washer, plate(6h1) | Buy now |
| 3 | 90386-30M78 Bush(6h0) | Buy now |
| 4 | 90386-30M77 Bush(6h0) | Buy now |
| 5 | 93210-29M94 O-ring(6h1) | Buy now |
| 6 | 90386-30M60 Bush(6j8) | Buy now |
| 7 | 90116-10M28 Bolt, stud | Buy now |
| 8 | 90185-10051 Nut, self-locking | Buy now |
| 9 | 93410-28M06 Circlip (688) | Buy now |
| 11 | 90101-08M15 Bolt | Buy now |
| 12 | 69W-44526-01 Plate | Buy now |
| 13 | 90185-08045 Nut, self-locking | Buy now |
| 14 | 97075-08030 Bolt, hexagon (fj1) | Buy now |
| 15 | 92995-08100 Ybs67-8 washer, spring | Buy now |
| 17 | 64J-44575-00 Damper, lower mount rubber | Buy now |
| 19 | 97095-08020 Bolt, hexagon | Buy now |


Bracket 2



E1

| Ref | Part | |
|-----|-----------------------------------------------------|-------------------------|
| 20 | 92995-08600 Washer, plain (663) | Buy now |
| 25 | 90109-12MA3 Bolt | Buy now |
| 26 | 95380-12700 Nut(6t4) | Buy now |
| 27 | 90201-12M16 Washer, plate (679) | Buy now |
| 28 | 90202-21100 Washer plate (663) | Buy now |
| 29 | 90201-13M19 Washer, plate (663) | Buy now |
| 30 | 90201-22M05 Washer, plate | Buy now |
| 31 | 63D-83672-01 Trim sender | Buy now |
| 32 | 703-82119-00 Cover, lead wire | Buy now |
| 33 | 97885-06016 Screw, pan head(6b0) | Buy now |
| 34 | 90465-13M18 Clamp | Buy now |
| 35 | 90465-11M10 Clamp | Buy now |
| 36 | 90446-17M91 Hose | Buy now |
| 37 | 90465-06M86 Clamp | Buy now |
| 39 | 90445-07M53 Hose (I1160) | Buy now |


Bracket 2



E1

| Ref | Part | |
|-----|-----------------------------------------------------|-------------------------|
| 40 | 6E5-83558-00 End, nipple | Buy now |
| 41 | 67C-82127-10 Wire, lead 2 | Buy now |
| 42 | 97885-06008 Screw, pan head(6a3) | Buy now |
| 43 | 65W-48511-00 Hook, steering | Buy now |
| 44 | 92995-10600 Washer, plate | Buy now |


Carburetor



B6

| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 1 | 69W-14901-01 Carburetor assembly 1 | Buy now |
| 2 | 69W-14902-01 Carburetor assembly 2 | Buy now |
| 3 | 69W-14903-01 Carburetor assembly 3 | Buy now |
| 4 | 69W-14904-01 Carburetor assembly 4 | Buy now |
| 5 | 69W-14381-00 Body Float Chamber #1 | Buy now |
| 6 | 69W-14381-10 Body Float Chamber #2 | Buy now |
| 7 | 69W-14381-20 Body, float chamber #3 | Buy now |
| 8 | 69W-14381-30 Body, float chamber #4 | Buy now |
| 9 | 69W-14384-00 Gasket, float chamber | Buy now |
| 10 | 6L2-14385-00 Float | Buy now |
| 11 | 6E5-14386-01 Pin, float | Buy now |
| 12 | 62Y-14392-00 Valve, needle | Buy now |
| 13 | 62Y-14321-00 Screw, throttle | Buy now |
| 14 | 62Y-14157-30 Cover, mixing | Buy now |
| 15 | 69W-14399-00 Gasket | Buy now |


Carburetor



B6


| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 16 | 69W-14341-00 Nozzle Main | Buy now |
| 17 | 69W-14343-62 Jet, main (#124) | Buy now |
| 18 | 64J-14342-20 Jet, pilot (#39) | Buy now |
| 19 | 66M-14355-00 Plug | Buy now |
| 20 | 69W-14323-00 Screw, air adjusting | Buy now |
| 21 | 62Y-14334-00 Spring, air adjusting | Buy now |
| 22 | 62Y-14321-10 Screw, throttle | Buy now |
| 23 | 2T4-14397-00 O-ring | Buy now |
| 24 | 62Y-14383-30 Screw, drain | Buy now |
| 25 | 652-14397-00 Ring, o | Buy now |
| 26 | 62Y-14212-00 Spring, pilot adjusting | Buy now |
| 27 | 98980-04006 Screw, bind(6l2) | Buy now |
| 28 | 69W-24311-00 Pipe, fuel 1 #1,3 | Buy now |
| 29 | 62Y-14398-30 Gasket #1,3 | Buy now |
| 30 | 62Y-14567-30 Screw #1 | Buy now |

Carburetor



B6

| Ref | Part | |
|-----|---------------------------------------------------------------|-------------------------|
| 30 | 62Y-14567-40 Screw #3 | Buy now |
| 31 | 69W-14380-01 Prime starter assembly #1 | Buy now |
| 31 | 69W-14380-11 Prime starter assembly #3 | Buy now |
| 32 | 62Y-14227-00 O-ring | Buy now |
| 33 | 62Y-24313-90 Pipe 3 #3 | Buy now |
| 34 | 62Y-14597-00 Washer #4 | Buy now |
| 35 | 664-14327-01 Screw #4 | Buy now |
| 36 | 69W-14212-00 Spring, pilot adjusting #4 | Buy now |
| 37 | 69W-14321-00 Screw, throttle #4 | Buy now |
| 38 | 69W-14115-00 Plug, screw | Buy now |
| 39 | 90430-08209 Gasket(3gh) | Buy now |




69W1100-2190

D4

| Ref | Part | |
|-----|-----------------------------------------------------------------|-------------------------|
| 1 | 69W-44121-00 Lever, shift rod | Buy now |
| 2 | 62Y-44117-01-4D Bracket | Buy now |
| 3 | 97095-06020 Bolt(7u8) | Buy now |
| 4 | 92995-06600 Washer, plain (646) | Buy now |
| 5 | 97095-06025 Bolt | Buy now |
| 7 | 62Y-44120-01 Handle gear shift assembly L | Buy now |
| 8 | 62Y-42715-01 Bushing | Buy now |
| 9 | 62Y-44118-00 Bracket | Buy now |
| 10 | 62Y-44112-00 Stay, handle gear shift | Buy now |
| 12 | 90501-12082 Spring 6484411600 | Buy now |
| 13 | 93501-04M02 Ball (697) | Buy now |
| 14 | 90386-90M90 Bush(61a) | Buy now |
| 15 | 90201-10M20 Washer, plate (663) | Buy now |
| 16 | 91490-20015 Pin, cotter (648) | Buy now |
| 17 | 90468-18008 Clip 620436610000 | Buy now |


Control



D4

| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 18 | 688-44122-00 Bushing, shift rod lever | Buy now |
| 19 | 90202-07M07 Washer, plate (688) | Buy now |
| 20 | 6F5-41237-00 Joint, link | Buy now |
| 21 | 69W-41241-00 Rod, link | Buy now |
| 22 | 662-41237-01 Joint, link | Buy now |
| 23 | 95380-05700 Nut (656) | Buy now |
| 24 | 69W-42159-00 Stay | Buy now |
| 25 | 62Y-42154-00 Lever, throttle control | Buy now |
| 26 | 69W-42171-00 Bushing | Buy now |
| 27 | 91490-16010 Pin, cotter | Buy now |
| 28 | 62Y-44135-00 Spring | Buy now |
| 29 | 90387-06M45 Collar(62y) | Buy now |
| 30 | 95895-06035 Bolt, flange(4nx) | Buy now |
| 31 | 62Y-42335-20 Lever, accel. control | Buy now |
| 32 | 62Y-44116-01 Spring | Buy now |


Control



D4


| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 33 | 90109-06M30 Bolt(62y) | Buy now |
| 34 | 69W-48344-00 Cable end, remote control | Buy now |
| 36 | 62Y-48538-00 Clamp, cable 1 | Buy now |

Crankshaft. Piston



| Ref | Part | |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1 | 69W-11411-00 Crankshaft & nut set | Buy now |
| 2 | 62Y-11416-30 Plane bearing, crankshaft 1 UR YELLOW | Buy now |
| 2 | 62Y-11416-40 Plane bearing, crankshaft 1 UR RED | Buy now |
| 2 | 62Y-11416-50 Plane bearing, crankshaft 1 UR PINK | Buy now |
| 2 | 62Y-11416-60 Plane bearing, crankshaft 1 UR GREEN | Buy now |
| 3 | 62Y-11650-10 Connecting rod assembly | Buy now |
| 4 | 62Y-11654-00 Bolt, connecting rod | Buy now |
| 5 | 62Y-11656-30 Plane bearing, connecting rod UR YELLOW | Buy now |
| 5 | 62Y-11656-40 Plane bearing, connecting rod UR RED | Buy now |
| 5 | 62Y-11656-50 Plane bearing, connecting rod UR PINK | Buy now |
| 5 | 62Y-11656-60 Plane bearing, connecting rod UR GREEN | Buy now |
| 6 | 69W-11631-00-97 Piston (std) | Buy now |
| 6 | 69W-11635-00 Piston (0.25mm o/s) AP | Buy now |
| 6 | 69W-11636-00 Piston (0.50mm o/s) AP | Buy now |
| 7 | 67C-11603-00 Piston ring set (std) | Buy now |


Crankshaft. Piston



| Ref | Part | |
|-----|--------------------------------------------------------------------|-------------------------|
| 7 | 67C-11604-00 Piston ring set (0.25mm o/s) AP | Buy now |
| 7 | 67C-11605-00 Piston ring set (0.50mm o/s) AP | Buy now |
| 8 | 62Y-11633-00 Pin, piston | Buy now |
| 9 | 93450-17129 Circlip(1ar) | Buy now |
| 10 | 93102-43M42 Oil seal(62y) | Buy now |
| 11 | 93101-35002 Oil seal | Buy now |


A7

Cylinder. Crankcase 1



| Ref | Part | |
|-----|---------------------------------------------------------------------|-------------------------|
| 3 | 93606-12019 Pin, dowel (614) | Buy now |
| 4 | 90119-08M01 Bolt, with washer(62y) | Buy now |
| 5 | 97013-06035 Bolt(3rv) | Buy now |
| 6 | 92903-06600 Washer, plain (646) | Buy now |
| 7 | 90344-51003 Plug, taper screw | Buy now |
| 8 | 90340-14M06 Plug, straight screw(62y) | Buy now |
| 9 | 90430-14115 Gasket (663) | Buy now |
| 10 | 67C-11351-00 Gasket, cylinder | Buy now |
| 11 | 6G8-12411-02 Thermostat | Buy now |
| 13 | 62Y-12414-00 Gasket, cover | Buy now |
| 15 | 62Y-11372-01 Nipple, hose FLUSHING KIT | Buy now |
| 16 | 90445-09068 Hose (l420) | Buy now |
| 17 | 688-24378-00 Pipe, joint | Buy now |
| 18 | 90445-09095 Hose (L260) | Buy now |
| 19 | 90445-09105 Hose (l420) | Buy now |

Cylinder. Crankcase 1




69W2300-3020

| Ref | Part | |
|-----|---------------------------------------------------------------|-------------------------|
| 20 | 90465-11M10 Clamp | Buy now |
| 21 | 90467-08M18 Clip | Buy now |
| 22 | 62Y-41114-00 Gasket, exhaust outer cover | Buy now |
| 23 | 90119-06MA5 Bolt, with washer | Buy now |
| 24 | 62Y-11325-00 Anode | Buy now |
| 25 | 66M-11328-00 Grommet, anode | Buy now |
| 27 | 66M-12535-00 Plate | Buy now |
| 28 | 97095-05012 Bolt, hexagon | Buy now |
| 29 | 92995-05600 Washer, plain (646) | Buy now |
| 30 | 97095-06020 Bolt(7u8) | Buy now |
| 31 | 92995-06600 Washer, plain (646) | Buy now |
| 32 | 5GH-13440-00 Element assembly, oil cleaner | Buy now |
| 33 | 90401-20M00 Bolt, union(62y) | Buy now |

A5


Cylinder. Crankcase 2



B1

| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 3 | 62Y-11133-30 Guide, valve 1 | Buy now |
| 4 | 93450-09M01 Circlip (6g8) | Buy now |
| 5 | 62Y-11325-00 Anode | Buy now |
| 6 | 66M-11328-00 Grommet, anode | Buy now |
| 8 | 66M-12535-00 Plate | Buy now |
| 9 | 97095-05012 Bolt, hexagon | Buy now |
| 10 | 92995-05600 Washer, plain (646) | Buy now |
| 11 | 97095-06020 Bolt(7u8) | Buy now |
| 12 | 92995-06600 Washer, plain (646) | Buy now |
| 13 | 97095-06010 Bolt | Buy now |
| 14 | 90430-06014 Gasket 256113960000 | Buy now |
| 15 | 90109-06M65 Bolt(62y) | Buy now |
| 17 | 69W-11181-00 Gasket, cylinder head 1 | Buy now |
| 18 | 99530-08012 Pin, dowel(6g8) | Buy now |
| 19 | 90119-09M00 Bolt, with washer(62y) | Buy now |


Cylinder. Crankcase 2



B-

| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 20 | 90119-06MA3 Bolt, with washer | Buy now |
| 22 | 62Y-14485-00 Pipe, joint | Buy now |
| 23 | 62Y-11168-00 Cover, breather | Buy now |
| 24 | 98507-04010 Screw, pan head(6g8) | Buy now |
| 25 | 92907-04600 Washer(jf2) | Buy now |
| 26 | 62Y-11356-00 Seal, cylinder 2 | Buy now |
| 27 | 97595-06520 Bolt(7u8) | Buy now |
| 28 | 62Y-11119-00 Hanger, engine | Buy now |
| 31 | 90430-08143 Gasket (256-11198-00) | Buy now |
| 32 | 97095-08014 Bolt, hexagon deep recess | Buy now |
| 33 | 6G8-15363-00 Plug, oil | Buy now |
| 34 | 93210-24M79 O-ring | Buy now |
| 35 | 62Y-12138-60 Mark Caution | Buy now |
| 36 | 94701-00406 Plug, spark (dpr5ea-9) | Buy now |


Electrical 1



C5

| Ref | Part | |
|-----|------------------------------------------------------------|-------------------------|
| 1 | 62Y-85570-00 Ignition coil assembly | Buy now |
| 2 | 90465-06M90 Clamp | Buy now |
| 3 | 90464-07M41 Clamp(62y) | Buy now |
| 4 | 90480-25161 Grommet(656) | Buy now |
| 5 | 97095-06030 Bolt(jf7) | Buy now |
| 6 | 92995-06100 Washer(6a1) | Buy now |
| 7 | 92995-06600 Washer, plain (646) | Buy now |
| 8 | 6G8-82370-30 Plug cap assembly | Buy now |
| 9 | 62Y-81822-01-94 Bracket, starting motor | Buy now |
| 10 | 97095-08035 Bolt(70w) | Buy now |
| 11 | 92995-08600 Washer, plain (663) | Buy now |
| 12 | 90116-08M14 Bolt, stud (6e5) | Buy now |
| 13 | 95380-08600 Nut (661) | Buy now |
| 14 | 92990-08100 Ybs67-8 washer, spring | Buy now |
| 15 | 62Y-85599-00 Cover | Buy now |

Electrical 1




69W1010-2110

C5

| Ref | Part | |
|-----|--------------------------------------------------------------|-------------------------|
| 16 | 90159-06M08 Screw, with washer(6k7) | Buy now |
| 17 | 64J-82504-00 Oil pressure switch assembly | Buy now |
| 18 | 62Y-82560-01 Thermo switch assembly | Buy now |
| 19 | 6E9-82588-00 Plate | Buy now |
| 20 | 97095-06012 Bolt(gh1) | Buy now |
| 22 | 62Y-83626-00 Mark. 6 | Buy now |


Electrical 2



69W1010-2120

C6


| Ref | Part | |
|-----|----------------------------------------------------------------|-------------------------|
| 1 | 69W-85540-00 C.d.i. unit assembly | Buy now |
| 2 | 97095-06020 Bolt(7u8) | Buy now |
| 3 | 92995-06100 Washer(6a1) | Buy now |
| 4 | 92995-06600 Washer, plain (646) | Buy now |
| 5 | 64J-81960-00 Rectifier & regulator assembly | Buy now |
| 6 | 97095-06025 Bolt | Buy now |
| 9 | 97095-06012 Bolt(gh1) | Buy now |
| 11 | 62Y-82105-00 Battery cable | Buy now |
| 12 | 6E5-82117-01 Wire, lead | Buy now |
| 13 | 6G1-81941-10 Starter relay | Buy now |
| 14 | 6G1-81952-00 Holder, relay | Buy now |
| 15 | 6L2-81945-00 Plate, switch fitting | Buy now |
| 16 | 97095-06014 Bolt(gj3) | Buy now |
| 18 | 6H1-81950-00 Relay aasy | Buy now |
| 21 | 90465-13M11 Clamp (6e5) | Buy now |



C6

| Ref | Part | |
|-----|-------------------------------------------------------------|-------------------------|
| 22 | 6H2-81949-01 Wire, lead | Buy now |
| 23 | 61A-81949-00 Wire, lead | Buy now |
| 24 | 682-82119-01 Cover, lead wire | Buy now |
| 25 | 90465-13M24 Band, switch cord | Buy now |
| 26 | 62Y-81948-00 Bracket | Buy now |
| 27 | 6A0-82317-00 Damper, ignition coil | Buy now |
| 28 | 624-42542-00 Collar | Buy now |
| 29 | 90201-12M16 Washer, plate (679) | Buy now |
| 30 | 95895-06025 Bolt, flange deep recess | Buy now |
| 31 | 69W-82590-00 Wire harness assembly | Buy now |
| 32 | 663-82151-00 Fuse | Buy now |
| 33 | 6G5-82152-00 Holder, fuse | Buy now |
| 34 | 688-82594-00 Clamp | Buy now |
| 36 | 703-82119-00 Cover, lead wire | Buy now |
| 37 | 63D-82563-10 Trim & tilt switch assembly | Buy now |

Electrical 2




69W1010-2120

| Ref | Part | |
|-----|-----------------------------------------|-------------------------|
| 38 | 6E5-82587-00 Gasket | Buy now |
| 39 | 62Y-83614-00 Bracket | Buy now |
| 40 | 90109-06M86 Bolt | Buy now |


C6

Fuel




C2

| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 1 | 6G1-24304-02 Fuel pipe joint comp. 1 | Buy now |
| 2 | 97095-06025 Bolt | Buy now |
| 3 | 92995-06600 Washer, plain (646) | Buy now |
| 4 | 90445-10020 Hose (I590) | Buy now |
| 5 | 90467-09M17 Clip(6k8) | Buy now |
| 6 | 64J-24560-00 Filter assembly | Buy now |
| 7 | 68V-24563-00 Element, filter | Buy now |
| 8 | 68V-24521-00 Cup, filter | Buy now |
| 9 | 93210-32738 O-ring(1wg) | Buy now |
| 10 | 68V-24469-00 Float, water level | Buy now |
| 11 | 62Y-24566-00 Bracket, filter | Buy now |
| 12 | 97095-08014 Bolt, hexagon deep recess | Buy now |
| 13 | 92995-08600 Washer, plain (663) | Buy now |
| 14 | 95380-08600 Nut (661) | Buy now |
| 15 | 90445-10M48 Hose (I400) | Buy now |



C2


| Ref | Part | |
|-----|----------------------------------------------------|-------------------------|
| 17 | 90467-10M04 Clip, pipe 1 (6e9) | Buy now |
| 18 | 62Y-24410-03 Fuel pump assembly | Buy now |
| 19 | 62Y-24413-01 Body 4 | Buy now |
| 20 | 62Y-24421-01 Valve, check | Buy now |
| 21 | 62Y-24411-02 Diaphragm | Buy now |
| 22 | 62Y-24423-00 Spring, diaphragm | Buy now |
| 23 | 62Y-13131-01 Plunger | Buy now |
| 24 | 62Y-24454-00 Spring | Buy now |
| 25 | 62Y-24444-01 Screw | Buy now |
| 26 | 62Y-24471-00 Diaphragm | Buy now |
| 27 | 6A0-14325-00 Screw, pan head | Buy now |
| 28 | 95380-03600 Nut (6g8) | Buy now |
| 29 | 62Y-24452-00 Packing | Buy now |
| 30 | 95380-05600 Nut, hexagon (663) | Buy now |
| 31 | 62Y-24374-01 Pin | Buy now |



C2

| Ref | Part | |
|-----|----------------------------------------------------------------------------------|-------------------------|
| 32 | 62Y-24422-00 Plate | Buy now |
| 33 | 93210-24M79 O-ring | Buy now |
| 34 | 65W-24474-00 Cover | Buy now |
| 35 | 97095-06030 Bolt(jf7) | Buy now |
| 38 | 62Y-28100-00 Tool kit | Buy now |
| 39 | 62Y-28199-7D-A0 Om f40c/f50a/ft50c/f60a/ft60b UR (E,F,S) | Buy now |
| 39 | 62Y-28199-7D-B0 Om f40c/f50a/ft50c/f60a/ft60b UR (D,NL,I) | Buy now |
| 40 | 62Y-28199-8D-A0 Om f40c/f50a/ft50c/f60a/ft60b UR (DK,P,GR) | Buy now |
| 40 | 62Y-28199-8D-B0 Om f40c/f50a/ft50c/f60a/ft60b UR (N,S,SS) | Buy now |


Fuel Tank



F7

| Ref | Part | |
|-----|-----------------------------------------------------------------------------|-------------------------|
| 1 | 6YK-24201-01 Fuel Tank assembly (25L) AP PLASTIC, 25L | Buy now |
| 2 | 6YL-24268-01 Gasket, fuel meter | Buy now |
| 3 | 6YK-24610-00 Cap assembly WITH INDICATOR | Buy now |
| 4 | 6YL-24641-00 Gasket, cap 1 | Buy now |
| 5 | 6YK-24260-01 Fuel meter assembly | Buy now |
| 6 | 90157-05M16 Screw, pan head | Buy now |
| 7 | 6YL-24329-00 Seal | Buy now |
| 8 | 6YL-24306-52 Fuel pipe comp. 1 AP | Buy now |



Generator



C4

| Ref | Part | |
|-----|-------------------------------------------------------|-------------------------|
| 1 | 69W-85550-10 Rotor assembly | Buy now |
| 2 | 64J-85510-00 Stator assembly | Buy now |
| 3 | 62Y-85561-00-94 Base, magneto | Buy now |
| 4 | 95023-06025 Bolt, flange(4kg) | Buy now |
| 5 | 62Y-85580-00 Coil, pulser | Buy now |
| 6 | 97880-05012 Screw,pan head (646) | Buy now |
| 7 | 92990-05100 Ybs67-5 washer, spring | Buy now |
| 8 | 92990-05600 Washer, plain (646) | Buy now |
| 9 | 90465-13M97 Clamp | Buy now |
| 10 | 97880-06025 Screw, pan head(6b0) | Buy now |
| 11 | 92990-06600 Washer, plain (646) | Buy now |
| 12 | 99530-08012 Pin, dowel(6g8) | Buy now |
| 13 | 62Y-81337-11 Cover, flywheel | Buy now |
| 14 | 6K7-81338-01 Stay | Buy now |
| 15 | 663-82317-01 Damper, ignition coil | Buy now |

Generator




 69W1300-2100

C4

| Ref | Part | |
|-----|----------------------------------------------------|-------------------------|
| 16 | 90480-12072 Grommet(53y) | Buy now |
| 17 | 6H4-11545-00 Key, woodruff | Buy now |
| 18 | 90170-20137 Nut, hexagon(663) | Buy now |
| 19 | 90201-21M18 Washer, plate (663) | Buy now |
| 20 | 62Y-13437-61 Mark, caution | Buy now |
| 21 | 6A1-83625-41 Mark 5 | Buy now |
| 22 | 6A1-83625-51 Mark 5 | Buy now |


Intake



B4

| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 1 | 69W-14369-00 Diaphragm assembly 2 | Buy now |
| 2 | 650-14327-01 Screw | Buy now |
| 3 | 69W-13586-00 Joint, carburetor 1 | Buy now |
| 4 | 69W-14440-00 Silencer assembly Intake | Buy now |
| 5 | 97595-06590 Bolt(62y) | Buy now |
| 6 | 90387-06M70 Collar (6h5) | Buy now |
| 7 | 62Y-24312-00 Pipe, fuel 1 | Buy now |
| 8 | 62Y-24313-30 Pipe 3 | Buy now |
| 9 | 62Y-24313-40 Pipe 3 | Buy now |
| 10 | 62Y-24313-50 Pipe 3 | Buy now |
| 11 | 62Y-24313-61 Pipe 3 | Buy now |
| 12 | 62Y-24313-70 Pipe 3 | Buy now |
| 13 | 69W-23153-00 Ring, snap | Buy now |
| 14 | 69W-24313-80 Pipe 3 | Buy now |
| 15 | 64J-14585-00 Rod, choke | Buy now |


Intake



B4

| Ref | Part | |
|-----|------------------------------------------------|-------------------------|
| 16 | 69W-14561-00 O-ring | Buy now |
| 17 | 93210-35M86 O-ring(6l2) | Buy now |
| 18 | 64J-14349-11 Pipe | Buy now |
| 19 | 69W-14349-00 Pipe | Buy now |
| 20 | 69W-14349-10 Pipe | Buy now |
| 21 | 90465-11M10 Clamp | Buy now |
| 22 | 90465-13M36 Clamp(6h4) | Buy now |
| 23 | 62Y-24378-00 Pipe, joint 4 | Buy now |
| 24 | 93210-38MH3 O-ring(62y) | Buy now |
| 25 | 62Y-14291-30 Bracket 1 | Buy now |
| 26 | 62Y-1532B-00 Pipe, breather | Buy now |
| 27 | 69W-82509-00 Wire, sub lead | Buy now |
| 28 | 64J-14349-40 Pipe | Buy now |
| 30 | 62Y-82544-00 Clamp | Buy now |
| 31 | 62Y-24314-00 Pipe 4 | Buy now |

Intake




69W1100-2060

| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 32 | 69W-14271-00 Insulator | Buy now |
| 33 | 90338-04M17 Plug(62y) | Buy now |
| 35 | 90387-06M15 Collar(6g8) | Buy now |
| 36 | 97095-06030 Bolt(jf7) | Buy now |
| 37 | 92995-06600 Washer, plain (646) | Buy now |
| 38 | 97095-06025 Bolt | Buy now |
| 40 | 93608-16M16 Pin, dowel(6t4) | Buy now |
| 41 | 62Y-1531A-00 Hose, breather 1 | Buy now |
| 42 | 62Y-15373-10 Pipe, breather | Buy now |
| 43 | 97095-06016 Bolt, hexagon deep recess | Buy now |

B4


Lower Casing. Drive 1



F3


| Ref | Part | |
|-----|--------------------------------------------------------------|-------------------------|
| 1 | 68S-45300-30-4D Lower unit assembly L | Buy now |
| 2 | 67F-45301-00-4D Casing, lower | Buy now |
| 3 | 93315-52563 Bearing | Buy now |
| 4 | 688-45536-01 Sleeve, drive shaft | Buy now |
| 5 | 688-45587-01-10 Shim (t:0.10mm) UR | Buy now |
| 5 | 688-45587-01-12 Shim (t:0.12mm) UR | Buy now |
| 5 | 688-45587-01-15 Shim (t:0.15mm) UR | Buy now |
| 5 | 688-45587-01-18 Shim (t:0.18mm) UR | Buy now |
| 5 | 688-45587-01-30 Shim (t:0.30mm) UR | Buy now |
| 5 | 688-45587-01-40 Shim (t:0.40mm) UR | Buy now |
| 5 | 688-45587-01-50 Shim (t:0.50mm) UR | Buy now |
| 6 | 93332-000U3 Brg,tapered roller 50mm (688) | Buy now |
| 7 | 688-45567-01-10 Shim (t:0.10mm) UR | Buy now |
| 7 | 688-45567-01-12 Shim (t:0.12mm) UR | Buy now |
| 7 | 688-45567-01-15 Shim (t:0.15mm) UR | Buy now |

Lower Casing. Drive 1



| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 7 | 688-45567-01-18 Shim (t:0.18mm) UR | Buy now |
| 7 | 688-45567-01-30 Shim (t:0.30mm) UR | Buy now |
| 7 | 688-45567-01-40 Shim (t:0.40mm) UR | Buy now |
| 7 | 688-45567-01-50 Shim (t:0.50mm) UR | Buy now |
| 8 | 93332-00095 Bearing | Buy now |
| 9 | 90340-08002 Plug, straight screw | Buy now |
| 10 | 688-45341-10 Plug, drain | Buy now |
| 11 | 90430-08020 Gasket | Buy now |
| 12 | 688-45321-00 Plate | Buy now |
| 13 | 93210-49046 O-ring (620) | Buy now |
| 14 | 93106-09014 Oil seal | Buy now |
| 15 | 97095-06016 Bolt, hexagon deep recess | Buy now |
| 16 | 92995-06600 Washer, plain (646) | Buy now |
| 17 | 6E5-45378-00 Nipple, hose | Buy now |
| 18 | 90445-07ME8 Hose (I250) L | Buy now |


Lower Casing. Drive 1



F3

| Ref | Part | |
|-----|------------------------------------------------------------|-------------------------|
| 19 | 6E5-83558-10 End, nipple | Buy now |
| 20 | 90465-11M10 Clamp | Buy now |
| 21 | 6H3-44311-00 Housing, water pump 1 | Buy now |
| 22 | 663-44322-00 Insert, cartridge | Buy now |
| 23 | 6H3-44315-A0 Gasket,water pump 1 | Buy now |
| 24 | 663-44366-00 Damper, water seal 2 | Buy now |
| 25 | 6H3-44352-00 Impellar | Buy now |
| 26 | 90280-03M03 Key, woodruff (697) | Buy now |
| 27 | 6H3-44341-00-94 Housing, water pump set | Buy now |
| 28 | 93101-23070 Oil seal (663) | Buy now |
| 29 | 93210-46044 O-ring | Buy now |
| 30 | 688-44316-A0 Gasket,water pump 2 | Buy now |
| 31 | 6H3-44323-00 Outer plate, cartridge | Buy now |
| 32 | 6H3-44324-A0 Gasket,cartridge Out,plate | Buy now |
| 33 | 93604-10M03 Pin, dowel (688) | Buy now |


Lower Casing. Drive 1



F3

| Ref | Part | |
|-----|---------------------------------------------------------------------|-------------------------|
| 34 | 90119-08M33 Bolt, with washer(6b0) | Buy now |
| 35 | 90119-08M14 Bolt, with washer | Buy now |
| 36 | 64J-45501-30 Drive shaft comp. (l, d: 18mm) L | Buy now |
| 37 | 68S-45551-00 Pinion | Buy now |
| 38 | 90170-16M01 Nut, hexagon (688) | Buy now |
| 39 | 68S-45560-00 Gear | Buy now |
| 40 | 93317-322V0 Bearing | Buy now |
| 41 | 67F-45611-00 Shaft, propeller | Buy now |
| 42 | 67F-45631-00 Clutch, dog | Buy now |
| 43 | 67F-45634-00 Slide, shift | Buy now |
| 44 | 6H1-45668-00 Shaft, free 1 | Buy now |
| 45 | 6H1-45635-00 Plunger, shift | Buy now |
| 46 | 90501-12M48 Spring (6h1) | Buy now |
| 47 | 90201-03313 Washer, plate 8077743700 | Buy now |
| 48 | 93503-16003 Ball | Buy now |


Lower Casing. Drive 1



F3

| Ref | Part | |
|-----|-------------------------------------------------------------|-------------------------|
| 49 | 90183-02M03 Nut, spring (6h1) | Buy now |
| 50 | 90250-07M02 Pin, straight (688) | Buy now |
| 51 | 688-45633-00 Ping, cross pin | Buy now |
| 52 | 93210-07003 O-ring (11m) | Buy now |
| 53 | 99001-08600 Circlip(2r6) | Buy now |
| 54 | 68S-45571-00 Gear | Buy now |
| 55 | 67F-45331-00-94 Housing, bearing | Buy now |
| 56 | 93306-207U0 Brg,r-b 6207 72mm 280g (688) | Buy now |
| 57 | 67F-45576-00 Washer, thrust 2 | Buy now |
| 58 | 93210-86M39 O-ring (6e5) | Buy now |
| 59 | 93317-325U0 Brg,needle | Buy now |
| 60 | 93101-25M03 Oil seal | Buy now |
| 61 | 90282-04010 Key, strait(663) | Buy now |
| 62 | 688-45383-02 Washer, claw | Buy now |
| 63 | 688-45384-00 Nut | Buy now |


Lower Casing. Drive 1



F3


| Ref | Part | |
|-----|----------------------------------------------------|-------------------------|
| 64 | 64J-44150-00 Shift cam assembly | Buy now |
| 65 | 90201-25M05 Washer, plate | Buy now |

Lower Casing. Drive 2



| Ref | Part | |
|-----|---------------------------------------------------------------|-------------------------|
| 1 | 62Y-44361-00 Tube, water L | Buy now |
| 2 | 663-44367-00 Damper, water seal 3 | Buy now |
| 3 | 90202-12060 Washer, plate(663) | Buy now |
| 4 | 90430-12072 Gasket | Buy now |
| 5 | 93606-12019 Pin, dowel (614) | Buy now |
| 6 | 97075-10040 Bolt, hexagon deep recess L | Buy now |
| 7 | 92995-10100 Ybs67-10 washer, spring L | Buy now |
| 8 | 92995-10600 Washer, plate L | Buy now |
| 9 | 90119-08M84 Bolt, with washer L | Buy now |
| 10 | 663-45376-00-94 Guide, seal damper | Buy now |
| 11 | 688-45375-00 Damper, seal 2 | Buy now |
| 12 | 6H1-45214-00 Cover, water inlet | Buy now |
| 13 | 6H1-45215-00 Cover, water inlet | Buy now |
| 14 | 90151-05M00 Screw, countersunk(692) | Buy now |
| 15 | 90185-05002 Nut nylon (sus)(ex4) | Buy now |

Lower Casing. Drive 2





 64J0100-1290

F6

| Ref | Part | |
|-----|----------------------------------------------------------------------|-------------------------|
| 16 | 67F-45371-00 Tab-trim | Buy now |
| 17 | 90105-10M67 Bolt, hexagon (663) | Buy now |
| 18 | 688-45987-01 Spacer | Buy now |
| 19 | 67F-45997-00 Spacer 2 | Buy now |
| 20 | 90389-25M00 Bush | Buy now |
| 21 | 90171-16011 Nut, castle (663) | Buy now |
| 22 | 91490-40025 Pin, cotter (663) | Buy now |
| 23 | 68S-45941-00-EL Propeller (3x14 x11 -k) UR | Buy now |
| 23 | 6E5-45949-00-EL Propeller (3x13-5/8"x13"-k) UR | Buy now |

Meter




69W1300-2280

B2


| Ref | Part | |
|-----|---------------------------------------------------------------------------|-------------------------|
| 1 | 6Y5-8350T-02 Digital tachometer assembly AP | Buy now |
| 2 | 9E450-04433 Housing, connector (m-4-w) M-4-W | Buy now |
| 3 | 9E450-04533 Housing, f-4-w(5pcs) F-4-W | Buy now |
| 4 | 92990-04100 Ybs67-4 washer, spring | Buy now |
| 5 | 95380-04600 Nut,hex | Buy now |
| 6 | 6Y5-83553-00 Wire, lead (l=2.5m) AP | Buy now |
| 7 | 1E6-82151-00 Fuse (10a) | Buy now |
| 8 | 68F-82553-70 Extension, wire lead (7m) AP | Buy now |

Oil Pan



| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 1 | 62Y-11575-00 Relief valve ass'y | Buy now |
| 2 | 62Y-13475-00 Gasket | Buy now |
| 3 | 97013-06025 Bolt(62y) | Buy now |
| 4 | 92903-06600 Washer, plain (646) | Buy now |
| 5 | 62Y-13411-00 Strainer, oil | Buy now |
| 6 | 97013-06016 Bolt, hexagon deep recess | Buy now |
| 8 | 93608-12M05 Pin, dowel b (6e5) | Buy now |
| 9 | 64J-15311-01-5B Oil pan | Buy now |
| 10 | 90480-12M25 Grommet (6e9) | Buy now |
| 11 | 69W-15312-00 Gasket, oil pan | Buy now |
| 12 | 93606-12019 Pin, dowel (614) | Buy now |
| 13 | 67C-15316-00 Damper 1 | Buy now |
| 14 | 90340-14M06 Plug, straight screw(62y) | Buy now |
| 15 | 90430-14M09 Gasket | Buy now |
| 16 | 97075-06025 Bolt | Buy now |


Oil Pan



F2

| Ref | Part | |
|-----|----------------------------------------------------|-------------------------|
| 17 | 92995-06600 Washer, plain (646) | Buy now |
| 18 | 67C-15362-00 Plug, oil level | Buy now |


Oil Pump



C1


| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 1 | 62Y-12171-00 Camshaft 1 | Buy now |
| 2 | 62Y-11537-10 Gear, driven | Buy now |
| 3 | 93605-14143 Pin (2h7) | Buy now |
| 4 | 90201-10M06 Washer, plate(62y) | Buy now |
| 5 | 95895-10040 Bolt, flange deep recess | Buy now |
| 6 | 62Y-46241-00 Belt | Buy now |
| 7 | 62Y-11590-10 Tensioner assembly | Buy now |
| 8 | 90508-20018 Spring, torsion | Buy now |
| 9 | 90249-07M29 Pin(62y) | Buy now |
| 10 | 95895-08020 Bolt, flange deep recess | Buy now |
| 11 | 90109-06M64 Bolt(62y) | Buy now |
| 12 | 62Y-11536-10 Gear, drive | Buy now |
| 13 | 62Y-11557-00 Washer 1 | Buy now |
| 14 | 90170-35M32 Nut | Buy now |
| 15 | 90280-04M06 Key, woodruff(6a1) | Buy now |

Oil Pump



| Ref | Part | |
|-----|---------------------------------------------------|-------------------------|
| 16 | 69W-13300-00 Oil pump assembly | Buy now |
| 17 | 93210-33MH2 O-ring(62y) | Buy now |
| 18 | 93210-12MG9 O-ring(62y) | Buy now |
| 19 | 93210-14515 O-ring (11h) | Buy now |
| 20 | 90119-06025 Bolt, with washer | Buy now |
| 21 | 93102-37M40 Oil seal(62y) | Buy now |


Power Trim & Tilt Assy 1



E3

| Ref | Part | |
|-----|---------------------------------------------------------------|-------------------------|
| 1 | 68S-43800-00-8D Power trim & tilt assembly | Buy now |
| 2 | 68S-4380K-00 Cylinder, tilt sub assembly | Buy now |
| 3 | 68S-43810-00 Tilt Piston Sub assembly | Buy now |
| 4 | 62X-43861-00 O-ring | Buy now |
| 5 | 62X-43862-00 O-ring | Buy now |
| 6 | 93210-29375 O-ring (j10) | Buy now |
| 7 | 62X-43871-00 Ring, back up | Buy now |
| 8 | 93210-44383 O-ring (705) | Buy now |
| 9 | 93210-48214 O-ring | Buy now |
| 10 | 62X-4388A-00 Piston, trim | Buy now |
| 11 | 62Y-22471-00 Cylinder, shock absorber | Buy now |
| 12 | 67F-43875-00 Ring, snap | Buy now |
| 13 | 69W-4381B-00 Free piston sub assembly | Buy now |
| 14 | 62X-43899-00 Plate stopper | Buy now |
| 15 | 93503-16003 Ball | Buy now |


Power Trim & Tilt Assy 1



E3

| Ref | Part | |
|-----|-----------------------------------------------------|-------------------------|
| 16 | 62X-4384H-00 Spring | Buy now |
| 17 | 1UF-22434-00 Plate, valve 1 | Buy now |
| 18 | 62X-43875-00 Ring, snap | Buy now |
| 19 | 6H1-43831-10 Connector, shaft | Buy now |
| 21 | 69W-43830-00 Gear pump assembly | Buy now |
| 22 | 69J-43841-00 Piston, shuttle | Buy now |
| 23 | 69J-4384M-00 Piston, shuttle 2 | Buy now |
| 24 | 69A-4384F-00 Seal, main valve | Buy now |
| 25 | 6H1-43883-00 O-ring | Buy now |
| 26 | 99002-03600 Circlip(615) | Buy now |
| 27 | 93505-32038 Ball(7fk) | Buy now |
| 28 | 65W-4386A-00 Pin, absorber valve | Buy now |
| 29 | 69J-43853-00 Spring, main valve | Buy now |
| 30 | 69J-4389J-00 O-ring | Buy now |
| 31 | 69J-43851-00 Seat, relief valve | Buy now |


Power Trim & Tilt Assy 1



E3

| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 32 | 69J-43855-00 Spring, up relief | Buy now |
| 33 | 6H1-4384F-10 Seal, main valve | Buy now |
| 34 | 69W-43856-00 Spring, down relief | Buy now |
| 35 | 6H1-43844-10 Pin, valve support | Buy now |
| 37 | 69J-43843-00 Screw, valve lock | Buy now |
| 38 | 93210-08391 O-ring | Buy now |
| 39 | 93501-08001 Ball | Buy now |
| 40 | 93604-26256 Pin, dowel | Buy now |
| 41 | 62Y-43816-00 Filter 1 | Buy now |
| 42 | 69W-4382L-00 Cap, relief valve | Buy now |
| 43 | 91318-05020 Bolt, socket | Buy now |
| 44 | 91318-05008 Bolt,socket | Buy now |
| 46 | 69W-4384G-00 Seal, relief valve | Buy now |
| 47 | 69W-43854-00 Spring, manual release | Buy now |
| 48 | 69J-43894-00 Spring, shuttle return | Buy now |


Power Trim & Tilt Assy 1



E3

| Ref | Part | |
|-----|-------------------------------------------------------|-------------------------|
| 49 | 62Y-4387J-00 Washer, special 2 | Buy now |
| 50 | 62Y-22434-00 Plate, valve 1 | Buy now |
| 51 | 62Y-43871-00 Ring, back up | Buy now |
| 52 | 62Y-4387G-00 Washer | Buy now |
| 53 | 69J-43893-00 Washer | Buy now |
| 54 | 69J-43844-00 Pin, valve support | Buy now |
| 55 | 93210-064A5 O-ring(61a) | Buy now |
| 56 | 6H1-43816-00 Filter 1 | Buy now |
| 58 | 91318-06040 Bolt,socket | Buy now |
| 59 | 93210-18397 O-ring (6g5) | Buy now |
| 60 | 6H1-43875-00 Ring, snap | Buy now |
| 61 | 62Y-43845-00 Screw, manual release | Buy now |
| 62 | 93210-09165 O-ring | Buy now |
| 63 | 6H1-43829-00 Plug, reservoir | Buy now |
| 64 | 62X-43865-00 O-ring | Buy now |


Power Trim & Tilt Assy 1



E3

| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 65 | 69W-43899-01 Plate stopper | Buy now |
| 66 | 62Y4382200 Seal, trim dust | Buy now |
| 67 | 68S4382100 Screw, trim cylinder end | Buy now |
| 68 | 62X4387200 Ring, back up | Buy now |
| 69 | 6C54386300 O-ring | Buy now |


Power Trim & Tilt Assy 2



| Ref | Part | |
|-----|-----------------------------------------------------------|-------------------------|
| 1 | 62X-43888-00 Bolt,socket | Buy now |
| 2 | 69W-43880-00 Motor assembly | Buy now |
| 3 | 69W-43805-00 Armature assembly | Buy now |
| 4 | 62X-43804-01 Stator assembly | Buy now |
| 5 | 62Y-43892-00 Brush 2 | Buy now |
| 6 | 62Y-43891-00 Brush 1 | Buy now |
| 7 | 69W-82181-00 Circuit breaker comp. | Buy now |
| 8 | 62X-43807-00 Wire sub assembly | Buy now |
| 9 | 69W-4380F-00 Plate, brush holder | Buy now |
| 10 | 62X-4386K-00 Spring, brush | Buy now |
| 11 | 97880-05020 Screw, pan head (e22) | Buy now |
| 12 | 9760204216 Screw, pan head with washer | Buy now |
| 13 | 69W-43881-00 Frame, end | Buy now |
| 14 | 93102-08414 Oil seal(61a) | Buy now |
| 15 | 90201-083J8 Washer, plate(62x) | Buy now |


Power Trim & Tilt Assy 2

| Ref | Part | |
|-----|--------------------------------------------|-------------------------|
| 16 | 93210-52449 O-ring(50m) | Buy now |



E6


Remote Control Assy



A6

| Ref | Part | |
|-----|----------------------------------------------------------------------------------------------|-------------------------|
| 1 | <u>703-48207-17</u> 703 mec rc side mount push AP WITH PT/T SW. | Buy now |
| 2 | <u>703-48261-01</u> Arm, throttle | Buy now |
| 3 | <u>703-48153-00</u> Shaft, free accel. | Buy now |
| 4 | <u>703-48235-00</u> Bushing | Buy now |
| 5 | <u>703-48268-00</u> Spacer 3 | Buy now |
| 6 | <u>703-48264-00</u> Throttle, friction | Buy now |
| 7 | <u>95380-05600</u> Nut, hexagon (663) | Buy now |
| 8 | <u>97380-05025</u> Bolt | Buy now |
| 9 | <u>703-48265-00</u> Shaft Friction | Buy now |
| 10 | <u>93430-06024</u> Circlip (701) | Buy now |
| 11 | <u>703-48245-00</u> Plate, lock | Buy now |
| 12 | <u>703-48252-00</u> Roller, cam | Buy now |
| 13 | <u>701-48248-00</u> Roller, free accel | Buy now |
| 14 | <u>703-48198-00</u> Washer, wave 3 | Buy now |
| 15 | <u>703-48243-00</u> Bushing 3 | Buy now |


Remote Control Assy




A6

| Ref | Part | |
|-----|----------------------------------------------------------------------|-------------------------|
| 16 | 703-48236-00 Bushing | Buy now |
| 17 | 703-48189-00 Retainer | Buy now |
| 18 | 703-48234-00 Roller, detent | Buy now |
| 19 | 703-48345-01 Cable end, remote control 2 | Buy now |
| 20 | 703-48358-00 Anchor, cable | Buy now |
| 21 | 703-48244-00 Spring, free accel. | Buy now |
| 22 | 703-48238-00 Spring, detent | Buy now |
| 23 | 703-48246-00 Spacer 1 | Buy now |
| 24 | 703-48227-00 Spring, neutral lock | Buy now |
| 25 | 703-82594-00 Clamp WITH PT/T SW. | Buy now |
| 26 | 703-48226-00 Plate, stopper | Buy now |
| 27 | 703-48222-00 Grip, control lever SINGLE | Buy now |
| 28 | 703-48223-00 Lock, neutral | Buy now |
| 29 | 703-48225-00 Cover | Buy now |
| 30 | 703-48219-00 Cover, lead | Buy now |

Remote Control Assy




Remote Control Assy



A6

| Ref | Part | |
|-----|-------------------------------------------------------------------------------------------|-------------------------|
| 46 | <u>703-82531-00</u> Wire, lead | Buy now |
| 47 | <u>688-82575-01</u> Engine stop switch assembly | Buy now |
| 48 | <u>682-82556-00</u> Lanyard, stop switch | Buy now |
| 49 | <u>688-8258A-20</u> 10p main harness mec 2m (6ft) L)5M (10P) | Buy now |
| 50 | <u>703-82540-00</u> Neutral switch assembly | Buy now |
| 51 | <u>703-83383-A0</u> Buzzer | Buy now |
| 52 | <u>703-48284-10</u> Grommet | Buy now |
| 53 | <u>703-82591-00</u> Band | Buy now |
| 54 | <u>703-82592-00</u> Band | Buy now |
| 55 | <u>703-82563-12</u> Trim & tilt switch assembly | Buy now |
| 56 | <u>703-48221-00</u> Grip | Buy now |
| 57 | <u>703-48152-00</u> Knob, free accel | Buy now |
| 58 | <u>703-48212-00</u> Rear housing | Buy now |
| 59 | <u>703-48213-00</u> Back, panel | Buy now |
| 60 | <u>703-48271-00</u> Arm, shift | Buy now |



Remote Control Assy



| Ref | Part | |
|-----|--------------------------------------------|-------------------------|
| 61 | 703-48211-01 Housing,1 | Buy now |
| 62 | 703-48232-00 Drive gear | Buy now |

A6

Remote Control Box




67M0100-8280

A5

| Ref | Part | |
|-----|-----------------------------------------------------------------------------|-------------------------|
| 1 | 703-48207-17 703 mec rc side mount push AP WITH PT/T SW. | Buy now |
| 2 | 701-48310-90 Cable, Remote Control L=11F UR | Buy now |
| 2 | 701-48320-00 Cable, Remote Control L=12F UR | Buy now |
| 2 | 701-48320-20 Cable, Remote Control L=13F UR | Buy now |
| 2 | 701-48320-50 Cable, Remote Control L=15F UR | Buy now |


Repair Kit 1



B3

| Ref | Part | |
|-----|-------------------------------------------------------------|-------------------------|
| 1 | 69W-W0001-00 Power head gasket kit | Buy now |
| 2 | 90430-14115 Gasket (663) | Buy now |
| 3 | 67C-11351-00 Gasket, cylinder | Buy now |
| 4 | 62Y-12414-00 Gasket, cover | Buy now |
| 5 | 62Y-41114-00 Gasket, exhaust outer cover | Buy now |
| 6 | 90430-06014 Gasket 256113960000 | Buy now |
| 7 | 69W-11181-00 Gasket, cylinder head 1 | Buy now |
| 8 | 62Y-11356-00 Seal, cylinder 2 | Buy now |
| 9 | 93210-24M79 O-ring | Buy now |
| 10 | 93102-43M42 Oil seal(62y) | Buy now |
| 11 | 93101-35002 Oil seal | Buy now |
| 12 | 69W-14561-00 O-ring | Buy now |
| 13 | 93210-35M86 O-ring(6l2) | Buy now |
| 14 | 93210-38MH3 O-ring(62y) | Buy now |
| 16 | 93102-37M40 Oil seal(62y) | Buy now |


Repair Kit 1



| Ref | Part | |
|-----|---------------------------------------------------|-------------------------|
| 17 | 90280-04M06 Key, woodruff(6a1) | Buy now |
| 18 | 93210-33MH2 O-ring(62y) | Buy now |
| 19 | 93210-12MG9 O-ring(62y) | Buy now |
| 20 | 93210-14515 O-ring (11h) | Buy now |

B3


Repair Kit 2



B4

| Ref | Part | |
|-----|-------------------------------------------------------|-------------------------|
| 1 | 69W-W0093-10 Carburetor repair kit | Buy now |
| 2 | 69W-14384-00 Gasket, float chamber | Buy now |
| 3 | 6L2-14385-00 Float | Buy now |
| 4 | 6E5-14386-01 Pin, float | Buy now |
| 5 | 62Y-14392-00 Valve, needle | Buy now |
| 6 | 62Y-14321-00 Screw, throttle | Buy now |
| 7 | 69W-14399-00 Gasket | Buy now |
| 8 | 69W-14323-00 Screw, air adjusting | Buy now |
| 9 | 2T4-14397-00 O-ring | Buy now |
| 10 | 652-14397-00 Ring, o | Buy now |
| 11 | 62Y-14398-30 Gasket | Buy now |
| 12 | 69W-14561-00 O-ring | Buy now |
| 13 | 93210-35M86 O-ring(6l2) | Buy now |
| 14 | 93210-38MH3 O-ring(62y) | Buy now |
| 15 | 62Y-14227-00 O-ring | Buy now |


Repair Kit 3



B5

| Ref | Part | |
|-----|------------------------------------------------------------|-------------------------|
| 1 | 68S-W0001-20 Lower unit gasket kit | Buy now |
| 2 | 62Y-13475-00 Gasket | Buy now |
| 3 | 69W-15312-00 Gasket, oil pan | Buy now |
| 4 | 90430-14M09 Gasket | Buy now |
| 5 | 93103-18011 Oil seal | Buy now |
| 6 | 64J-41133-10 Gasket, exhaust manifold 1 | Buy now |
| 7 | 62Y-41134-01 Gasket, exhaust manifold | Buy now |
| 8 | 62Y-45127-00 Seal | Buy now |
| 9 | 67C-45123-00 Gasket, muffler | Buy now |
| 10 | 90430-08020 Gasket | Buy now |
| 11 | 93210-49046 O-ring (620) | Buy now |
| 12 | 93106-09014 Oil seal | Buy now |
| 13 | 6H3-44315-A0 Gasket,water pump 1 | Buy now |
| 14 | 93101-23070 Oil seal (663) | Buy now |
| 15 | 93210-46044 O-ring | Buy now |


Repair Kit 3



B5

| Ref | Part | |
|-----|------------------------------------------------------------|-------------------------|
| 16 | 688-44316-A0 Gasket,water pump 2 | Buy now |
| 17 | 6H3-44324-A0 Gasket,cartridge Out,plate | Buy now |
| 18 | 93210-86M39 O-ring (6e5) | Buy now |
| 19 | 93101-25M03 Oil seal | Buy now |
| 20 | 663-44366-00 Damper, water seal 2 | Buy now |
| 21 | 93210-07003 O-ring (11m) | Buy now |
| 22 | 6H3-W0078-02 Water pump repair kit | Buy now |
| 23 | 663-44322-00 Insert, cartridge | Buy now |
| 24 | 6H3-44352-00 Impeller | Buy now |
| 26 | 6H3-44323-00 Outer plate, cartridge | Buy now |
| 30 | 90119-08M14 Bolt, with washer | Buy now |
| 31 | 90119-08M33 Bolt, with washer(6b0) | Buy now |
| 32 | 90280-03M03 Key, woodruff (697) | Buy now |
| 33 | 6H3-W0078-0A Chrome pump kit | Buy now |
| 34 | 670-44322-01 Insert, cartridge | Buy now |

Repair Kit 3




68S1100-3340

B5

| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 35 | 670-44321-00 Inner plate, cartridge | Buy now |
| 36 | 6H3-44323-40 Outer plate, cartridge | Buy now |

Starting Motor




69W1010-2140

D1

| Ref | Part | |
|-----|---------------------------------------------------------------|-------------------------|
| 1 | 69W-81800-00 Starting motor assembly | Buy now |
| 2 | 6N7-81850-10 Armature assembly | Buy now |
| 3 | 61A-81809-00 Washer kit | Buy now |
| 4 | 61A-81824-00 Washer 2 | Buy now |
| 5 | 6N7-81810-00 Stator assembly | Buy now |
| 6 | 6K7-8182G-10 Bush, terminal | Buy now |
| 7 | 6N7-81840-00 Brush holder assembly | Buy now |
| 8 | 6N7-81801-00 Brush set | Buy now |
| 9 | 6N7-81813-00 Spring, brush | Buy now |
| 10 | 6N7-81820-00 Rear bracket assembly | Buy now |
| 11 | 69W-81807-00 Gear assembly, starting motor | Buy now |
| 12 | 6N7-81857-00 Pinion stopper set | Buy now |
| 13 | 6N7-81830-00 Front bracket assembly | Buy now |
| 14 | 6K7-81826-10 Bolt | Buy now |
| 15 | 6E5-8182E-10 Washer, spring | Buy now |


Starting Motor



| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 16 | 6E5-8182F-10 Washer,plain | Buy now |
| 17 | 6E5-8182A-10 Nut | Buy now |
| 18 | 6E5-8182K-10 Nut | Buy now |
| 19 | 97095-08016 Bolt, hexagon deep recess | Buy now |
| 20 | 92995-08600 Washer, plain (663) | Buy now |
| 21 | 90119-08M76 Bolt, with washer(6e5) | Buy now |
| 22 | 90119-08M77 Bolt, with washer(6e5) | Buy now |

D1

Steering Guide




65W0010-8210

A4

| Ref | Part | |
|-----|---------------------------------------------------------------------|-------------------------|
| 1 | 65W-61350-00 Steering guide attachment kit AP | Buy now |
| 2 | 65W-61351-00 Rod, steering link | Buy now |
| 3 | 90201-10M20 Washer, plate (663) | Buy now |
| 4 | 90185-09M01 Nut, nylon (663) | Buy now |
| 5 | 90170-09M03 Nut (689) | Buy now |
| 6 | 90387-10M42 Coller (688) | Buy now |
| 7 | 90101-09M01 Bolt(62x) | Buy now |
| 8 | 90201-10M63 Washer, plate | Buy now |
| 9 | 6E5-43145-01 Cap, clamp bracket | Buy now |
| 10 | 93210-16275 O-ring | Buy now |

Top Cowling




A4

| Ref | Part | |
|-----|---------------------------------------------------------|-------------------------|
| 1 | 68S-42610-00-4D Top Cowling assembly | Buy now |
| 2 | 67C-42613-00-4D Molding, air duct | Buy now |
| 3 | 90179-06M24 Nut(6j8) | Buy now |
| 4 | 62Y-42651-00 Hook | Buy now |
| 5 | 90266-06M02 Rivet (697) | Buy now |
| 6 | 67C-42652-00 Hook | Buy now |
| 7 | 90109-06047 Bolt | Buy now |
| 8 | 95680-06100 U-nut (6a5) | Buy now |
| 9 | 69W-42677-00 Graphic, front | Buy now |
| 10 | 68S-42678-00 Graphic, front | Buy now |
| 11 | 69W-W0070-00 Graphic set | Buy now |
| 12 | 69W-42681-00 Mark, cowling | Buy now |
| 13 | 69W-42682-00 Mark, cowling | Buy now |
| 14 | 69W-42615-00 Seal | Buy now |
| 15 | 61N-42628-00 Seal | Buy now |


Top Cowling

| Ref | Part | |
|-----|------------------------------------------------|-------------------------|
| 16 | 67F-13434-02 Label, Caution | Buy now |



A4


Upper Casing



E7

| Ref | Part | |
|-----|------------------------------------------------------------|-------------------------|
| 2 | 62Y-11325-00 Anode | Buy now |
| 3 | 66M-11328-00 Grommet, anode | Buy now |
| 5 | 66M-12535-00 Plate | Buy now |
| 6 | 97095-05012 Bolt, hexagon | Buy now |
| 7 | 92995-05600 Washer, plain (646) | Buy now |
| 8 | 97013-06020 Bolt(62y) | Buy now |
| 9 | 92903-06600 Washer, plain (646) | Buy now |
| 10 | 93103-18011 Oil seal | Buy now |
| 11 | 69W-41131-00 Manifold, Ext. 1 | Buy now |
| 12 | 64J-46132-10 Gasket 1 | Buy now |
| 13 | 64J-41133-10 Gasket, exhaust manifold 1 | Buy now |
| 14 | 64J-41116-00 Protector | Buy now |
| 15 | 97075-06050 Bolt(jf7) | Buy now |
| 16 | 92995-06600 Washer, plain (646) | Buy now |
| 17 | 90201-06015 Washer, plate | Buy now |


Upper Casing



E7

| Ref | Part | |
|-----|----------------------------------------------------------|-------------------------|
| 20 | 97075-06025 Bolt | Buy now |
| 22 | 62Y-41134-01 Gasket, exhaust manifold | Buy now |
| 23 | 62Y-45127-00 Seal | Buy now |
| 24 | 67C-45123-00 Gasket, muffler | Buy now |
| 26 | 90119-08M79 Bolt, hexagon (fj1) | Buy now |
| 27 | 90119-08M82 Bolt, with washer(697) | Buy now |
| 28 | 67C-45151-00 Cover, upper casing | Buy now |
| 29 | 97880-05016 Screw, pan head(6b0) | Buy now |
| 30 | 92990-05600 Washer, plain (646) | Buy now |
| 31 | 6H3-45155-00 Cap | Buy now |
| 32 | 69W-45318-00 Bushing, drive shaft | Buy now |
| 33 | 93420-36M01 Circlip (6a0) | Buy now |
| 34 | 90340-14M06 Plug, straight screw(62y) | Buy now |
| 35 | 90430-14M09 Gasket | Buy now |

Valve




62Y1010-2050

B3

| Ref | Part | |
|-----|--------------------------------------------------------|-------------------------|
| 1 | 69W-12111-00 Valve, intake | Buy now |
| 2 | 69W-12121-00 Valve, exhaust | Buy now |
| 3 | 62Y-12116-00 Seat, valve spring | Buy now |
| 4 | 51Y-12114-00 Spring, valve outer | Buy now |
| 5 | 30X-12117-00 Retainer, valve spring | Buy now |
| 6 | 30X-12118-00 Cotter, valve | Buy now |
| 7 | 51Y-12119-00 Seal, valve stem | Buy now |
| 8 | 62Y-12146-00 Shaft, rocker | Buy now |
| 9 | 62Y-12151-00 Arm, valve rocker | Buy now |
| 10 | 64J-12159-00 Screw, valve adjusting | Buy now |
| 11 | 62Y-12158-00 Nut, lock | Buy now |
| 12 | 62Y-12238-00 Plate Bolt Stopper | Buy now |
| 13 | 62Y-12279-00 Plate | Buy now |
| 14 | 62Y-12216-00 Spring | Buy now |
| 15 | 62Y-12231-00 Guide, stopper 1 | Buy now |

Valve

| Ref | Part | |
|-----|------------------------------------------|-------------------------|
| 16 | 90109-08M63 Bolt(62y) | Buy now |



62Y1010-2050

B3

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.