



# Yamaha FT9.9GE 2010

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>BOTTOM COWLING</b>	3
<b>BRACKET 1</b>	6
<b>BRACKET 2</b>	9
<b>BRACKET 3</b>	12
<b>CARBURETOR</b>	14
<b>CONTROL 1</b>	16
<b>CONTROL 2</b>	18
<b>CRANKSHAFT &amp; PISTON</b>	21
<b>CYLINDER &amp; CRANKCASE 1</b>	23
<b>CYLINDER &amp; CRANKCASE 2</b>	25
<b>ELECTRICAL 1</b>	27
<b>ELECTRICAL 2</b>	29
<b>ELECTRICAL 3</b>	31
<b>ELECTRICAL 4</b>	34
<b>FUEL</b>	35
<b>FUEL TANK</b>	38
<b>GENERATOR</b>	39
<b>INTAKE</b>	41
<b>LOWER CASING &amp; DRIVE 1</b>	43
<b>LOWER CASING &amp; DRIVE 2</b>	47
<b>OIL PAN</b>	49
<b>OIL PUMP</b>	51
<b>POWER TILT ASSY</b>	53
<b>REMOTE CONTROL ASSY</b>	58
<b>REMOTE CONTROL BOX</b>	63
<b>REPAIR KIT 1</b>	64
<b>REPAIR KIT 2</b>	66
<b>REPAIR KIT 3</b>	67
<b>STARTER</b>	69
<b>STARTING MOTOR</b>	71
<b>STEERING</b>	73
<b>STEERING FRICTION</b>	77
<b>STEERING GUIDE</b>	79
<b>TOP COWLING</b>	80
<b>UPPER CASING</b>	82
<b>VALVE</b>	83

## Bottom Cowling




Ref	Part	
1	<a href="#">68T42710014D</a> Bottom cowling assembly <b>WITH TAPPING BOLT</b>	<a href="#">Buy now</a>
2	<a href="#">68F8511900</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">9048021M82</a> Grommet	<a href="#">Buy now</a>
4	<a href="#">9038706176</a> Collar	<a href="#">Buy now</a>
5	<a href="#">68T4271610</a> Rubber, seal 1	<a href="#">Buy now</a>
6	<a href="#">6AU4280100</a> Cowling clamp comp.	<a href="#">Buy now</a>
38	<a href="#">9709506012</a> Bolt(gh1) <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
39	<a href="#">9299506600</a> Washer, plain (646) <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
9	<a href="#">6BL4439100</a> Nipple, hose	<a href="#">Buy now</a>
10	<a href="#">6824272700</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">68T42738004D</a> Plate, fitting	<a href="#">Buy now</a>
12	<a href="#">9010906M81</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">68T4272500</a> Grommet	<a href="#">Buy now</a>
13	<a href="#">68T4272510</a> Grommet	<a href="#">Buy now</a>
14	<a href="#">68T2639300</a> Holder	<a href="#">Buy now</a>

# Bottom Cowling




Ref	Part	
15	<a href="#">68T2636700</a> Protector	<a href="#">Buy now</a>
16	<a href="#">68T4272420</a> Grommet	<a href="#">Buy now</a>
17	<a href="#">6884272610</a> Grommet <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
17	<a href="#">69G4272600</a> Grommet <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
18	<a href="#">65W4271700</a> Rubber, seal 2	<a href="#">Buy now</a>
19	<a href="#">68T4274100</a> Apron	<a href="#">Buy now</a>
20	<a href="#">9788506030</a> Screw, pan head(6e0)	<a href="#">Buy now</a>
21	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>
23	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
24	<a href="#">68T4271700</a> Rubber, seal 2	<a href="#">Buy now</a>
25	<a href="#">68T4277100</a> Apron	<a href="#">Buy now</a>
26	<a href="#">9033806M20</a> Plug	<a href="#">Buy now</a>
27	<a href="#">65W8434200</a> Seat, emblem	<a href="#">Buy now</a>
28	<a href="#">9048006M19</a> Grommet (6e3)	<a href="#">Buy now</a>
29	<a href="#">6E51248100</a> Pipe 1 <b>FLUSHING KIT</b>	<a href="#">Buy now</a>

# Bottom Cowling




# Bracket 1




Ref	Part	
1	<a href="#">6AH43111004D</a> Bracket, clamp 1	<a href="#">Buy now</a>
2	<a href="#">6AH43112004D</a> Bracket, clamp 2	<a href="#">Buy now</a>
3	<a href="#">6E04311801</a> Handle, transom clamp	<a href="#">Buy now</a>
4	<a href="#">9024304M01</a> Pin(6a1)	<a href="#">Buy now</a>
5	<a href="#">6E74311600</a> Screw, transom clamp	<a href="#">Buy now</a>
6	<a href="#">6484311401</a> Pad, transom clamp	<a href="#">Buy now</a>
7	<a href="#">63W4313101</a> Bolt, clamp bracket	<a href="#">Buy now</a>
7	<a href="#">69A4313100</a> Bolt, clamp bracket <b>FOR REMOTE CONTROL</b>	<a href="#">Buy now</a>
8	<a href="#">9038622MA4</a> Bush	<a href="#">Buy now</a>
9	<a href="#">66R4311300</a> Plate, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">9018522043</a> Nut, self-locking	<a href="#">Buy now</a>
11	<a href="#">9038706M13</a> Collar(6h6)	<a href="#">Buy now</a>
12	<a href="#">9010106M18</a> Bolt(6l5)	<a href="#">Buy now</a>
13	<a href="#">9299006600</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">9538006700</a> Nut	<a href="#">Buy now</a>

# Bracket 1




Ref	Part	
15	<a href="#">6L24316001</a> Tilt rod assembly	<a href="#">Buy now</a>
16	<a href="#">6894316500</a> Plate, tilt lock	<a href="#">Buy now</a>
17	<a href="#">9169030008</a> Pin. spring(656)	<a href="#">Buy now</a>
18	<a href="#">9050210M07</a> Spring, conical(6k3)	<a href="#">Buy now</a>
19	<a href="#">6AU43311104D</a> Bracket, swivel 1	<a href="#">Buy now</a>
20	<a href="#">6AH4363100</a> Lever, tilt	<a href="#">Buy now</a>
21	<a href="#">6AH4361600</a> Rod, tilt lock	<a href="#">Buy now</a>
22	<a href="#">68T4364600</a> Shaft, lever	<a href="#">Buy now</a>
23	<a href="#">6AH4364100</a> Lever, tilt	<a href="#">Buy now</a>
24	<a href="#">6AH4361700</a> Rod, tilt lock	<a href="#">Buy now</a>
25	<a href="#">9908005600</a> Circlip(22k)	<a href="#">Buy now</a>
26	<a href="#">6AH4335000</a> Receiver assembly	<a href="#">Buy now</a>
27	<a href="#">9050620025</a> Spring, tension	<a href="#">Buy now</a>
28	<a href="#">63V4319100</a> Shaft, stopper	<a href="#">Buy now</a>
30	<a href="#">6AH4361400</a> Plate, tilt lock	<a href="#">Buy now</a>

# Bracket 1



Ref	Part	
31	<a href="#">9050623016</a> Spring, tension	<a href="#">Buy now</a>
32	<a href="#">6AH4361500</a> Plate, tilt lock	<a href="#">Buy now</a>
33	<a href="#">68T4361100</a> Shaft, tilt lock	<a href="#">Buy now</a>
34	<a href="#">9038706138</a> Collar	<a href="#">Buy now</a>
35	<a href="#">9343004M03</a> Circlip (eu0)	<a href="#">Buy now</a>
36	<a href="#">68T4365900</a> Shaft, reverse lock	<a href="#">Buy now</a>
38	<a href="#">6AH4362700</a> Stopper	<a href="#">Buy now</a>
39	<a href="#">9010906M84</a> Bolt	<a href="#">Buy now</a>
40	<a href="#">9020610M24</a> Washer, wave	<a href="#">Buy now</a>
41	<a href="#">9010108M88</a> Bolt (6g8)	<a href="#">Buy now</a>
42	<a href="#">9299008600</a> Washer, plain (663)	<a href="#">Buy now</a>
43	<a href="#">9018508057</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
44	<a href="#">9020108MA4</a> Washer, plate (6g8)	<a href="#">Buy now</a>


## Bracket 2



60S3110-F240

Ref	Part	
1	<a href="#">69A43111014D</a> Bracket, clamp 1	<a href="#">Buy now</a>
2	<a href="#">69A43112014D</a> Bracket, clamp 2	<a href="#">Buy now</a>
3	<a href="#">6E04311801</a> Handle, transom clamp	<a href="#">Buy now</a>
4	<a href="#">9024304M01</a> Pin(6a1)	<a href="#">Buy now</a>
5	<a href="#">6E74311600</a> Screw, transom clamp	<a href="#">Buy now</a>
6	<a href="#">6484311401</a> Pad, transom clamp	<a href="#">Buy now</a>
7	<a href="#">69A4313100</a> Bolt, clamp bracket <b>FOR REMOTE CONTROL</b>	<a href="#">Buy now</a>
8	<a href="#">9038622MA4</a> Bush	<a href="#">Buy now</a>
9	<a href="#">69A4311300</a> Plate, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">9018522043</a> Nut, self-locking	<a href="#">Buy now</a>
11	<a href="#">69G4331114D</a> Bracket, swivel 1	<a href="#">Buy now</a>
12	<a href="#">9788508010</a> Rivet	<a href="#">Buy now</a>
13	<a href="#">65W4319200</a> Knob, stopper	<a href="#">Buy now</a>
14	<a href="#">65W4319100</a> Shaft, stopper	<a href="#">Buy now</a>
15	<a href="#">9169030018</a> 926-51502-00 pin, spring (700)	<a href="#">Buy now</a>


## Bracket 2



 FWD  
60S3110-F240

Ref	Part	
16	<a href="#">9038614MA1</a> Bush	<a href="#">Buy now</a>
17	<a href="#">6G54314501</a> Cap, clamp bracket	<a href="#">Buy now</a>
18	<a href="#">9044710001</a> Hose, with spring	<a href="#">Buy now</a>
19	<a href="#">9046513M97</a> Clamp	<a href="#">Buy now</a>
20	<a href="#">69G4381800</a> Pin, lower shock mount	<a href="#">Buy now</a>
21	<a href="#">9038616MA7</a> Bush	<a href="#">Buy now</a>
22	<a href="#">9038616MA8</a> Bush	<a href="#">Buy now</a>
23	<a href="#">9038716M02</a> Collar	<a href="#">Buy now</a>
24	<a href="#">9020108M00</a> Washer, plate(6e0)	<a href="#">Buy now</a>
25	<a href="#">9708008016</a> Bolt	<a href="#">Buy now</a>
26	<a href="#">9024912M36</a> Pin	<a href="#">Buy now</a>
27	<a href="#">9038112M10</a> Bush, solid	<a href="#">Buy now</a>
28	<a href="#">9038112M11</a> Bush, solid	<a href="#">Buy now</a>
29	<a href="#">9908010600</a> Circlip	<a href="#">Buy now</a>
30	<a href="#">9011008M05</a> Bolt, hexagon socket head	<a href="#">Buy now</a>


## Bracket 2



  
 60S3110-F240


Ref	Part	
31	<a href="#">9010908010</a> Bolt	<a href="#">Buy now</a>
32	<a href="#">9018508057</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
33	<a href="#">9299008600</a> Washer, plain (663)	<a href="#">Buy now</a>
34	<a href="#">65W4525100</a> Anode	<a href="#">Buy now</a>
35	<a href="#">9010106020</a> Bolt	<a href="#">Buy now</a>
36	<a href="#">63V8212700</a> Wire, lead 2	<a href="#">Buy now</a>
37	<a href="#">9709506010</a> Bolt	<a href="#">Buy now</a>
38	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
39	<a href="#">69A4315500</a> Mark 1	<a href="#">Buy now</a>
40	<a href="#">9010108M88</a> Bolt (6g8)	<a href="#">Buy now</a>
43	<a href="#">9020108MA4</a> Washer, plate (6g8)	<a href="#">Buy now</a>

## Bracket 3




Ref	Part	
1	<a href="#">9370006M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
2	<a href="#">68T8212700</a> Wire, lead 2	<a href="#">Buy now</a>
3	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">9709506014</a> Bolt(gj3)	<a href="#">Buy now</a>
6	<a href="#">6AU42511104D</a> Bracket, steering	<a href="#">Buy now</a>
7	<a href="#">9038640001</a> Bush	<a href="#">Buy now</a>
8	<a href="#">9020940008</a> Washer	<a href="#">Buy now</a>
9	<a href="#">9038630048</a> Bush	<a href="#">Buy now</a>
10	<a href="#">9321029M94</a> O-ring(6h1)	<a href="#">Buy now</a>
11	<a href="#">9038630M60</a> Bush(6j8)	<a href="#">Buy now</a>
12	<a href="#">9011608M54</a> Bolt, stud(63v)	<a href="#">Buy now</a>
13	<a href="#">68T445171094</a> Mount rubber	<a href="#">Buy now</a>
14	<a href="#">68T4452600</a> Plate	<a href="#">Buy now</a>
15	<a href="#">9538008600</a> Nut (661)	<a href="#">Buy now</a>
16	<a href="#">9707506025</a> Bolt	<a href="#">Buy now</a>

## Bracket 3




Ref	Part	
18	<a href="#">6AU44551004D</a> Housing, lower mount rubber 1	<a href="#">Buy now</a>
19	<a href="#">6AU4455700</a> Mount damper, lower front	<a href="#">Buy now</a>
20	<a href="#">6824455530</a> Mount damper, lower side	<a href="#">Buy now</a>
21	<a href="#">9011906012</a> Bolt, with washer	<a href="#">Buy now</a>
22	<a href="#">9011906198</a> Bolt, with washer	<a href="#">Buy now</a>
23	<a href="#">9017906M28</a> Nut(63v)	<a href="#">Buy now</a>
24	<a href="#">63V4851101</a> Hook, steering	<a href="#">Buy now</a>
25	<a href="#">9707508035</a> Bolt(70w)	<a href="#">Buy now</a>
26	<a href="#">9299508600</a> Washer, plain (663)	<a href="#">Buy now</a>
27	<a href="#">9018508057</a> Nut, nylon (6j8)	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
1	<a href="#">6AU1430121</a> Carburetor & bolt set 6dr21	<a href="#">Buy now</a>
1	<a href="#">6AU1430151</a> Carburetor & bolt set 6dr51	<a href="#">Buy now</a>
2	<a href="#">6E51432100</a> Screw, throttle	<a href="#">Buy now</a>
3	<a href="#">6J81433400</a> Spring, throttle	<a href="#">Buy now</a>
4	<a href="#">9798004110</a> Screw, pan head (e56)	<a href="#">Buy now</a>
5	<a href="#">9798004112</a> Screw, pan head (686)	<a href="#">Buy now</a>
6	<a href="#">6AU1438500</a> Float	<a href="#">Buy now</a>
7	<a href="#">67D1496600</a> Rubber cap	<a href="#">Buy now</a>
8	<a href="#">67D1438600</a> Pin, float	<a href="#">Buy now</a>
9	<a href="#">68T1454600</a> Valve, needle	<a href="#">Buy now</a>
10	<a href="#">6AU1492E43</a> Jet, main (#86)	<a href="#">Buy now</a>
11	<a href="#">6AU1492F20</a> Jet, air slow (#40)	<a href="#">Buy now</a>
12	<a href="#">6AU1492A00</a> Nozzle, main	<a href="#">Buy now</a>
13	<a href="#">6AU1498400</a> Gasket, float chamber	<a href="#">Buy now</a>
14	<a href="#">6AU1498250</a> Holder	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
15	<a href="#">6AU1431B00</a> Ball	<a href="#">Buy now</a>
16	<a href="#">6AU1433550</a> Spring, plunger	<a href="#">Buy now</a>
17	<a href="#">6AU1437150</a> Plunger, Starter	<a href="#">Buy now</a>
18	<a href="#">6AU1431A30</a> Guide	<a href="#">Buy now</a>
19	<a href="#">6AU1491800</a> Ring	<a href="#">Buy now</a>
20	<a href="#">681495900</a> Gasket, drin screw	<a href="#">Buy now</a>
21	<a href="#">66T1499100</a> Plug, drain	<a href="#">Buy now</a>
22	<a href="#">68T1432320</a> Screw Air Adjusting	<a href="#">Buy now</a>
23	<a href="#">67D1453600</a> Gasket	<a href="#">Buy now</a>
24	<a href="#">67D1452700</a> Plate	<a href="#">Buy now</a>
25	<a href="#">68T1412600</a> Plug	<a href="#">Buy now</a>
26	<a href="#">6AU1437930</a> Rod, starter	<a href="#">Buy now</a>
27	<a href="#">6AU1437300</a> Cover, plunger cap	<a href="#">Buy now</a>

# Control 1




Ref	Part	
1	<a href="#">68T4272600</a> Grommet	<a href="#">Buy now</a>
2	<a href="#">68T4412102</a> Lever, shift rod	<a href="#">Buy now</a>
3	<a href="#">6G1416620194</a> Bracket	<a href="#">Buy now</a>
4	<a href="#">9010906M81</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">9046410M60</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">9169030014</a> Pin, spring (647)	<a href="#">Buy now</a>
7	<a href="#">65W4411600</a> Spring	<a href="#">Buy now</a>
8	<a href="#">66R4411700</a> Bracket	<a href="#">Buy now</a>
9	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
10	<a href="#">68T4414310</a> Rod, shift 1	<a href="#">Buy now</a>
11	<a href="#">9046818001</a> Clip	<a href="#">Buy now</a>
12	<a href="#">9017006015</a> Connector, shift rod	<a href="#">Buy now</a>
13	<a href="#">9538006700</a> Nut	<a href="#">Buy now</a>
14	<a href="#">68T4853800</a> Clamp, cable 1	<a href="#">Buy now</a>
15	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>

# Control 1




Ref	Part	
16	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">63D4853800</a> Clamp, cable 1	<a href="#">Buy now</a>
18	<a href="#">68T4163800</a> Pulley	<a href="#">Buy now</a>
19	<a href="#">68T4128300</a> Lever, free accel.	<a href="#">Buy now</a>
20	<a href="#">9038706M59</a> Collar (6h3)	<a href="#">Buy now</a>
21	<a href="#">6AU4121100</a> Link, accel.	<a href="#">Buy now</a>
22	<a href="#">68T1449700</a> Stay, throttle wire	<a href="#">Buy now</a>
23	<a href="#">9020106M62</a> Washer, plate (6e5)	<a href="#">Buy now</a>
24	<a href="#">9709506045</a> Bolt, hexagon	<a href="#">Buy now</a>
28	<a href="#">6614126202</a> Joint, choke lever	<a href="#">Buy now</a>
29	<a href="#">6471439560</a> Cap, over flow pipe	<a href="#">Buy now</a>
30	<a href="#">68T1577400</a> Stay 4	<a href="#">Buy now</a>

## Control 2




Ref	Part	
1	<a href="#">68T4853100</a> Bracket, remote control 1	<a href="#">Buy now</a>
2	<a href="#">6824853850</a> Clamp, cable	<a href="#">Buy now</a>
3	<a href="#">9169030012</a> Pin, spring	<a href="#">Buy now</a>
4	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
5	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
7	<a href="#">68T4412102</a> Lever, shift rod	<a href="#">Buy now</a>
8	<a href="#">6G1416620194</a> Bracket	<a href="#">Buy now</a>
9	<a href="#">9010906M81</a> Bolt	<a href="#">Buy now</a>
10	<a href="#">9046410M60</a> Clamp	<a href="#">Buy now</a>
11	<a href="#">9169030014</a> Pin, spring (647)	<a href="#">Buy now</a>
12	<a href="#">65W4411600</a> Spring	<a href="#">Buy now</a>
13	<a href="#">66R4411400</a> Stopper	<a href="#">Buy now</a>
14	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
15	<a href="#">68T4414310</a> Rod, shift 1	<a href="#">Buy now</a>

## Control 2




Ref	Part	
16	<a href="#">9046818001</a> Clip	<a href="#">Buy now</a>
17	<a href="#">9017006015</a> Connector, shift rod	<a href="#">Buy now</a>
18	<a href="#">9538006700</a> Nut	<a href="#">Buy now</a>
19	<a href="#">6AU4411110</a> Handle, gear shift	<a href="#">Buy now</a>
20	<a href="#">9321012327</a> O-ring(3ld)	<a href="#">Buy now</a>
21	<a href="#">9709505016</a> Bolt(6a1)	<a href="#">Buy now</a>
22	<a href="#">9299505600</a> Washer, plain (646)	<a href="#">Buy now</a>
23	<a href="#">6634834400</a> Cable end, remote control	<a href="#">Buy now</a>
24	<a href="#">9046818008</a> Clip 620436610000	<a href="#">Buy now</a>
25	<a href="#">68T4163800</a> Pulley	<a href="#">Buy now</a>
26	<a href="#">68T4128300</a> Lever, free accel.	<a href="#">Buy now</a>
27	<a href="#">9038706M59</a> Collar (6h3)	<a href="#">Buy now</a>
28	<a href="#">6AU4121100</a> Link, accel.	<a href="#">Buy now</a>
29	<a href="#">68T1449700</a> Stay, throttle wire	<a href="#">Buy now</a>
30	<a href="#">9020106M62</a> Washer, plate (6e5)	<a href="#">Buy now</a>

## Control 2



Ref	Part	
31	<a href="#">9709506045</a> Bolt, hexagon	<a href="#">Buy now</a>
35	<a href="#">6614126202</a> Joint, choke lever	<a href="#">Buy now</a>
36	<a href="#">6471439560</a> Cap, over flow pipe	<a href="#">Buy now</a>
39	<a href="#">68T1577410</a> Stay 4	<a href="#">Buy now</a>
41	<a href="#">9046508027</a> Clamp	<a href="#">Buy now</a>


# Crankshaft & Piston



Ref	Part	
1	<a href="#">9310230M22</a> Oil seal (6g8)	<a href="#">Buy now</a>
2	<a href="#">9310125M69</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">6AU1141100</a> Crankshaft	<a href="#">Buy now</a>
4	<a href="#">68T1141600</a> Plane bearing, crankshaft 1 <b>UR BROWN</b>	<a href="#">Buy now</a>
4	<a href="#">68T1141610</a> Plane bearing, crankshaft 1 <b>UR BLACK</b>	<a href="#">Buy now</a>
4	<a href="#">68T1141620</a> Plane bearing, crankshaft 1 <b>UR BLUE</b>	<a href="#">Buy now</a>
5	<a href="#">6AU1165000</a> Connecting rod assembly	<a href="#">Buy now</a>
6	<a href="#">67D1165400</a> Bolt, connecting rod	<a href="#">Buy now</a>
7	<a href="#">6AU116310096</a> Piston (std)	<a href="#">Buy now</a>
7	<a href="#">6AU1163500</a> Piston (0.25mm o/s) <b>AP</b>	<a href="#">Buy now</a>
7	<a href="#">6AU1163600</a> Piston (0.50mm o/s) <b>AP</b>	<a href="#">Buy now</a>
8	<a href="#">68T1160301</a> Piston ring set (std)	<a href="#">Buy now</a>
8	<a href="#">68T1160401</a> Piston ring set (0.25mm o/s) <b>AP</b>	<a href="#">Buy now</a>
8	<a href="#">68T1160501</a> Piston ring set (0.50mm o/s) <b>AP</b>	<a href="#">Buy now</a>
9	<a href="#">68T1163300</a> Pin, piston	<a href="#">Buy now</a>


## Crankshaft & Piston

Ref	Part	
10	<a href="#">9345015023</a> Circlip 131116340000	<a href="#">Buy now</a>




68R0010-0031

# Cylinder & Crankcase 1




Ref	Part	
1	<a href="#">6AUW009B001S</a> Cylinder block assembly	<a href="#">Buy now</a>
2	<a href="#">6AU15100001S</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">9953012016</a> Pin, dowel	<a href="#">Buy now</a>
4	<a href="#">9011908M29</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">68T1135100</a> Gasket, cylinder	<a href="#">Buy now</a>
6	<a href="#">66M1241101</a> Thermostat	<a href="#">Buy now</a>
7	<a href="#">6881241200</a> Seal, thermostat	<a href="#">Buy now</a>
8	<a href="#">68T12413001S</a> Cover, thermostat	<a href="#">Buy now</a>
9	<a href="#">6G812414A0</a> Gasket, cover	<a href="#">Buy now</a>
10	<a href="#">9011906MA2</a> Bolt, with washer	<a href="#">Buy now</a>
11	<a href="#">68T1248100</a> Pipe 1	<a href="#">Buy now</a>
12	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">6AU41113001S</a> Outer cover, exhaust	<a href="#">Buy now</a>
14	<a href="#">6E92437800</a> Pipe, Joint 4	<a href="#">Buy now</a>
15	<a href="#">68T41114A0</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>

# Cylinder & Crankcase 1




Ref	Part	
16	<a href="#">9011906MA3</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">68T1248200</a> Pipe 2	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
1	<a href="#">6AUW009A01S</a> Cylinder head complete	<a href="#">Buy now</a>
2	<a href="#">6AU1111001S</a> Head, cylinder 1	<a href="#">Buy now</a>
3	<a href="#">6AU1113310</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">68T1118100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
5	<a href="#">9951010114</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
6	<a href="#">9010508M36</a> Bolt (6g8)	<a href="#">Buy now</a>
7	<a href="#">9010508M78</a> Bolt, washer based	<a href="#">Buy now</a>
8	<a href="#">9011906049</a> Bolt, with washer	<a href="#">Buy now</a>
9	<a href="#">68T11191001S</a> Cover, cylinder head 1	<a href="#">Buy now</a>
10	<a href="#">6502437800</a> Pipe, joint 2	<a href="#">Buy now</a>
11	<a href="#">68T1135600</a> Seal, cylinder 2	<a href="#">Buy now</a>
12	<a href="#">9709506020</a> Bolt(7u8)	<a href="#">Buy now</a>
13	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">68T1116800</a> Cover, breather	<a href="#">Buy now</a>
15	<a href="#">68T11169A0</a> Gasket, breather cover	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
16	<a href="#">9850704010</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
17	<a href="#">9290704600</a> Washer(jf2)	<a href="#">Buy now</a>
18	<a href="#">6G81132500</a> Anode	<a href="#">Buy now</a>
19	<a href="#">9788005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
20	<a href="#">6G81119701</a> Plug, blind	<a href="#">Buy now</a>
21	<a href="#">9321013M63</a> O-ring (6g8)	<a href="#">Buy now</a>
22	<a href="#">6G81536300</a> Plug, oil	<a href="#">Buy now</a>
23	<a href="#">9321024M79</a> O-ring	<a href="#">Buy now</a>
24	<a href="#">9470200274</a> Plug, spark (br6hs-10)	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
1	<a href="#">68T8554000</a> C.d.i. unit assembly	<a href="#">Buy now</a>
2	<a href="#">68T8252200</a> Clamp, coupler	<a href="#">Buy now</a>
3	<a href="#">9778040512</a> Screw, pan head tapping	<a href="#">Buy now</a>
4	<a href="#">9709506020</a> Bolt(7u8)	<a href="#">Buy now</a>
5	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">68T8554200</a> Bracket	<a href="#">Buy now</a>
7	<a href="#">9709508012</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
8	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
10	<a href="#">6808557002</a> Ignition coil assembly	<a href="#">Buy now</a>
11	<a href="#">9048025003</a> Grommet	<a href="#">Buy now</a>
12	<a href="#">9709506025</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">6E38237021</a> Plug cap assembly	<a href="#">Buy now</a>
15	<a href="#">6648197062</a> Rectifier assembly	<a href="#">Buy now</a>
15	<a href="#">68T8196000</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
16	<a href="#">9788005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
17	<a href="#">9299005600</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">6A08211900</a> Cover, lead wire	<a href="#">Buy now</a>
19	<a href="#">67F8250400</a> Oil pressure switch assembly	<a href="#">Buy now</a>
20	<a href="#">68T8212710</a> Wire, lead 2	<a href="#">Buy now</a>
21	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
22	<a href="#">68T8541000</a> Emergency signal light assembly	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
1	<a href="#">69G8258000</a> Wire harness assembly 2	<a href="#">Buy now</a>
2	<a href="#">69G8210500</a> Battery cable (l: 3.0m)	<a href="#">Buy now</a>
3	<a href="#">68T4272440</a> Grommet	<a href="#">Buy now</a>
4	<a href="#">6G88211700</a> Wire, lead	<a href="#">Buy now</a>
5	<a href="#">9044610M86</a> Hose	<a href="#">Buy now</a>
6	<a href="#">68T8194000</a> Starter relay assembly	<a href="#">Buy now</a>
7	<a href="#">9709506010</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>
9	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">68T8194501</a> Plate, switch fitting	<a href="#">Buy now</a>
11	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
13	<a href="#">9046512M56</a> Clamp(62t)	<a href="#">Buy now</a>
14	<a href="#">68T8611200</a> Stay, solenoid	<a href="#">Buy now</a>
15	<a href="#">9048013018</a> Grommet (462)	<a href="#">Buy now</a>
18	<a href="#">68T8611100</a> Coil, solenoid	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
19	<a href="#">68T4123700</a> Joint, link	<a href="#">Buy now</a>
20	<a href="#">9169030010</a> Pin, spring (663)	<a href="#">Buy now</a>
21	<a href="#">9788004008</a> Screw, pan head (713)	<a href="#">Buy now</a>
22	<a href="#">9299004600</a> Washer, plain (646)	<a href="#">Buy now</a>
23	<a href="#">68T8611700</a> Hook, wire pull	<a href="#">Buy now</a>
24	<a href="#">9321003261</a> O-ring (663)	<a href="#">Buy now</a>
25	<a href="#">68T8215000</a> Fuse holder assembly	<a href="#">Buy now</a>
26	<a href="#">66V8215100</a> Fuse (10a)	<a href="#">Buy now</a>
27	<a href="#">68T8217101</a> Stay, fuse box	<a href="#">Buy now</a>
28	<a href="#">67F2812A00</a> Puller, fuse	<a href="#">Buy now</a>

## Electrical 3




Ref	Part	
1	<a href="#">69G8210500</a> Battery cable (l: 3.0m)	<a href="#">Buy now</a>
2	<a href="#">69G8259010</a> Wire harness assembly	<a href="#">Buy now</a>
3	<a href="#">68T4272440</a> Grommet	<a href="#">Buy now</a>
4	<a href="#">6N68258200</a> Cover, wire harness	<a href="#">Buy now</a>
5	<a href="#">6G88211700</a> Wire, lead	<a href="#">Buy now</a>
6	<a href="#">9044610M86</a> Hose	<a href="#">Buy now</a>
7	<a href="#">68T8194000</a> Starter relay assembly	<a href="#">Buy now</a>
8	<a href="#">9709506010</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>
10	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">68T8194501</a> Plate, switch fitting	<a href="#">Buy now</a>
12	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
14	<a href="#">9046513M11</a> Clamp (6e5)	<a href="#">Buy now</a>
16	<a href="#">68T8611200</a> Stay, solenoid	<a href="#">Buy now</a>
17	<a href="#">9048013018</a> Grommet (462)	<a href="#">Buy now</a>

## Electrical 3



Ref	Part	
20	<a href="#">68T8611100</a> Coil, solenoid	<a href="#">Buy now</a>
21	<a href="#">68T4123700</a> Joint, link	<a href="#">Buy now</a>
22	<a href="#">9169030010</a> Pin, spring (663)	<a href="#">Buy now</a>
23	<a href="#">9788004008</a> Screw, pan head (713)	<a href="#">Buy now</a>
24	<a href="#">9299004600</a> Washer, plain (646)	<a href="#">Buy now</a>
25	<a href="#">68T8611700</a> Hook, wire pull	<a href="#">Buy now</a>
26	<a href="#">9321003261</a> O-ring (663)	<a href="#">Buy now</a>
27	<a href="#">69G8195000</a> Relay assembly	<a href="#">Buy now</a>
28	<a href="#">9038706M03</a> Collar (676)	<a href="#">Buy now</a>
29	<a href="#">9011906M56</a> Bolt, with washer	<a href="#">Buy now</a>
30	<a href="#">69G8194801</a> Bracket	<a href="#">Buy now</a>
31	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
32	<a href="#">69G8192500</a> Terminal	<a href="#">Buy now</a>
33	<a href="#">9017006M30</a> Nut(62x)	<a href="#">Buy now</a>
34	<a href="#">9020406M00</a> Washer, spring(62x)	<a href="#">Buy now</a>


## Electrical 3



6AV1300-G140

Ref	Part	
35	<a href="#">6G58211900</a> Cover, lead wire	<a href="#">Buy now</a>
36	<a href="#">68T8215000</a> Fuse holder assembly	<a href="#">Buy now</a>
37	<a href="#">66V8215100</a> Fuse (10a)	<a href="#">Buy now</a>
38	<a href="#">68T8217101</a> Stay, fuse box	<a href="#">Buy now</a>
39	<a href="#">67F2812A00</a> Puller, fuse	<a href="#">Buy now</a>


## Electrical 4




68R0100-0130

Ref	Part	
1	<a href="#">65W8257501</a> Engine stop switch assembly	<a href="#">Buy now</a>
2	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
3	<a href="#">6898257Y00</a> Cap	<a href="#">Buy now</a>
4	<a href="#">6G14272500</a> Grommet	<a href="#">Buy now</a>

# Fuel




Ref	Part	
1	<a href="#">6G12430402</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">61N2432900</a> Seal	<a href="#">Buy now</a>
3	<a href="#">9709506025</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">9044510046</a> Hose	<a href="#">Buy now</a>
6	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
7	<a href="#">9046709M09</a> Clip(6k8)	<a href="#">Buy now</a>
8	<a href="#">68T2425101</a> Strainer 1	<a href="#">Buy now</a>
9	<a href="#">9044510M50</a> Hose (l400)	<a href="#">Buy now</a>
11	<a href="#">9044516010</a> Hose	<a href="#">Buy now</a>
12	<a href="#">68T2441001</a> Fuel pump assembly	<a href="#">Buy now</a>
13	<a href="#">66M2441301</a> Body 2	<a href="#">Buy now</a>
14	<a href="#">6A02442101</a> Valve, check	<a href="#">Buy now</a>
15	<a href="#">6E71432500</a> Screw, pan head	<a href="#">Buy now</a>
16	<a href="#">66M2441101</a> Diaphragm	<a href="#">Buy now</a>




Ref	Part	
17	<a href="#">66M2442300</a> Spring, diaphragm	<a href="#">Buy now</a>
18	<a href="#">66M1313100</a> Plunger	<a href="#">Buy now</a>
19	<a href="#">66M2437400</a> Pin	<a href="#">Buy now</a>
20	<a href="#">66M2445400</a> Spring	<a href="#">Buy now</a>
21	<a href="#">66M2447101</a> Diaphragm	<a href="#">Buy now</a>
22	<a href="#">66M2444400</a> Screw	<a href="#">Buy now</a>
23	<a href="#">9538004600</a> Nut,hex	<a href="#">Buy now</a>
24	<a href="#">9709506030</a> Bolt(jf7)	<a href="#">Buy now</a>
25	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>
27	<a href="#">9321020M65</a> O-ring	<a href="#">Buy now</a>
28	<a href="#">6AU2431100</a> Pipe, fuel 1	<a href="#">Buy now</a>
30	<a href="#">9044614M66</a> Hose(64x)	<a href="#">Buy now</a>
32	<a href="#">9046410M53</a> Clamp	<a href="#">Buy now</a>
33	<a href="#">68T2810000</a> Tool kit	<a href="#">Buy now</a>
34	<a href="#">6AU2819973D0</a> Manual,owner's UR (NL)	<a href="#">Buy now</a>

# Fuel




Ref	Part	
34	<a href="#">6AU2819973E0</a> Manual,owner's UR (E)	<a href="#">Buy now</a>
34	<a href="#">6AU2819973F0</a> Manual,owner's UR (F)	<a href="#">Buy now</a>
34	<a href="#">6AU2819973G0</a> Manual,owner's UR (D)	<a href="#">Buy now</a>
34	<a href="#">6AU2819973H0</a> Manual,owner's UR (I)	<a href="#">Buy now</a>
34	<a href="#">6AU2819973S0</a> Manual,owner's UR (ES)	<a href="#">Buy now</a>
35	<a href="#">6AU2819983K0</a> Manual,owner's UR (DK)	<a href="#">Buy now</a>
35	<a href="#">6AU2819983L0</a> Manual,owner's UR (SF)	<a href="#">Buy now</a>
35	<a href="#">6AU2819983M0</a> Manual,owner's UR (S)	<a href="#">Buy now</a>
35	<a href="#">6AU2819983N0</a> Manual,owner's UR (N)	<a href="#">Buy now</a>
35	<a href="#">6AU2819983P0</a> Manual,owner's UR (P)	<a href="#">Buy now</a>
35	<a href="#">6AU2819983R0</a> Manual,owner's UR (GR)	<a href="#">Buy now</a>

# Fuel Tank




Ref	Part	
1	<a href="#">6YL2420105</a> Fuel Tank assembly (12L) <b>AP</b>	<a href="#">Buy now</a>
2	<a href="#">6YL2461001</a> Cap assembly	<a href="#">Buy now</a>
3	<a href="#">6YL2426001</a> Fuel meter assembly	<a href="#">Buy now</a>
4	<a href="#">9015705M16</a> Screw, pan head	<a href="#">Buy now</a>
5	<a href="#">6YL2432900</a> Seal	<a href="#">Buy now</a>
6	<a href="#">6YL2426801</a> Gasket, fuel meter	<a href="#">Buy now</a>
7	<a href="#">6YL2430654</a> Fuel pipe comp. 1 <b>AP</b>	<a href="#">Buy now</a>

# Generator




Ref	Part	
1	<a href="#">68T8555001</a> Rotor assembly	<a href="#">Buy now</a>
1	<a href="#">68T8555011</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">68T8552000</a> Coil, charge	<a href="#">Buy now</a>
3	<a href="#">68T8558001</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">68T8553300</a> Coil, lighting	<a href="#">Buy now</a>
4	<a href="#">68T8553310</a> Coil, lighting	<a href="#">Buy now</a>
5	<a href="#">6H28558200</a> Attachment, pulser	<a href="#">Buy now</a>
6	<a href="#">9011906014</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
7	<a href="#">9709505010</a> Bolt (682)	<a href="#">Buy now</a>
8	<a href="#">9011906MA1</a> Bolt, with washer(63m)	<a href="#">Buy now</a>
9	<a href="#">68T8132800</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">9701306012</a> Bolt(gh1)	<a href="#">Buy now</a>
11	<a href="#">9290306600</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">9028004M06</a> Key, woodruff(6a1)	<a href="#">Buy now</a>

# Generator



Ref	Part	
14	<a href="#">9017012066</a> Nut, hexagon 6481155500	<a href="#">Buy now</a>
15	<a href="#">9020112472</a> Washer, plate (4n0)	<a href="#">Buy now</a>
16	<a href="#">6AV8133700</a> Cover, flywheel	<a href="#">Buy now</a>
17	<a href="#">9709506020</a> Bolt(7u8)	<a href="#">Buy now</a>
18	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">6AH8199540</a> Label, warning	<a href="#">Buy now</a>
20	<a href="#">6AH8199550</a> Label, warning	<a href="#">Buy now</a>
21	<a href="#">6AU1343760</a> Mark, caution	<a href="#">Buy now</a>
22	<a href="#">68T8571160</a> Mark, caution	<a href="#">Buy now</a>
23	<a href="#">6AH8199440</a> Label, safety	<a href="#">Buy now</a>
24	<a href="#">6AH8199450</a> Label, safety	<a href="#">Buy now</a>
25	<a href="#">6AG8199600</a> Mark	<a href="#">Buy now</a>


# Intake



FWD  
6AU1300-G060

Ref	Part	
1	<a href="#">68T13641201S</a> Manifold 1 <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
2	<a href="#">67F1248200</a> Pipe 2	<a href="#">Buy now</a>
3	<a href="#">68T1364500</a> Gasket, manifold 1	<a href="#">Buy now</a>
4	<a href="#">9011906MA5</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">9011906MA3</a> Bolt, with washer	<a href="#">Buy now</a>
6	<a href="#">9169050014</a> Pin, spring (647)	<a href="#">Buy now</a>
7	<a href="#">9044509M20</a> Hose (L95) <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
8	<a href="#">68T13646A0</a> Gasket, manifold 2	<a href="#">Buy now</a>
9	<a href="#">68T1427100</a> Insulator	<a href="#">Buy now</a>
10	<a href="#">6AU1444000</a> Silencer assembly, intake	<a href="#">Buy now</a>
11	<a href="#">9321031MJ5</a> O-ring	<a href="#">Buy now</a>
12	<a href="#">9038706M70</a> Collar (6h5)	<a href="#">Buy now</a>
13	<a href="#">9759506585</a> Bolt, flange	<a href="#">Buy now</a>
14	<a href="#">68T1248300</a> Pipe 3	<a href="#">Buy now</a>
15	<a href="#">9046508M99</a> Clamp	<a href="#">Buy now</a>


# Intake



6AU1300-G060


Ref	Part	
16	<a href="#">9046508M83</a> Clamp <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
17	<a href="#">9709506010</a> Bolt <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
18	<a href="#">9299506600</a> Washer, plain (646) <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
19	<a href="#">6H44127101</a> Knob, choke	<a href="#">Buy now</a>
20	<a href="#">6894127300</a> Grommet	<a href="#">Buy now</a>
21	<a href="#">68T4125600</a> Rod, choke 1	<a href="#">Buy now</a>
22	<a href="#">6J84126200</a> Joint, choke lever	<a href="#">Buy now</a>

# Lower Casing & Drive 1



Ref	Part	
1	<a href="#">69G45300114D</a> Lower unit assembly L(21.7")	<a href="#">Buy now</a>
1	<a href="#">69G45300214D</a> Lower unit assembly X(24.3")	<a href="#">Buy now</a>
2	<a href="#">66R45311014D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93315314V8</a> Bearing, needle (6e7)	<a href="#">Buy now</a>
4	<a href="#">66R4553600</a> Sleeve, drive shaft	<a href="#">Buy now</a>
5	<a href="#">9334141416</a> Bearing	<a href="#">Buy now</a>
6	<a href="#">66R4558700</a> Shim (t:1.13mm) UR	<a href="#">Buy now</a>
6	<a href="#">66R4558710</a> Shim (t:1.2mm) UR	<a href="#">Buy now</a>
7	<a href="#">9333200005</a> Brg,cyl-cal roller 0.19g nt	<a href="#">Buy now</a>
8	<a href="#">9034008002</a> Plug, straight screw	<a href="#">Buy now</a>
9	<a href="#">9043008020</a> Gasket	<a href="#">Buy now</a>
10	<a href="#">63V4430100</a> Water pump housing comp.	<a href="#">Buy now</a>
11	<a href="#">63V4432200</a> Insert, cartridge	<a href="#">Buy now</a>
12	<a href="#">68T4436600</a> Damper, water seal 2	<a href="#">Buy now</a>
13	<a href="#">63V4435201</a> Impeller	<a href="#">Buy now</a>


# Lower Casing & Drive 1



6AV1300-G280


Ref	Part	
14	<a href="#">6644433800</a> Key, woodruff	<a href="#">Buy now</a>
15	<a href="#">9321044398</a> O-ring(55x)	<a href="#">Buy now</a>
16	<a href="#">68T4432300</a> Outer plate, cartridge	<a href="#">Buy now</a>
17	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
18	<a href="#">9708008045</a> Bolt, hexagon	<a href="#">Buy now</a>
19	<a href="#">63V4432800</a> Plate	<a href="#">Buy now</a>
20	<a href="#">69G45331015B</a> Housing, bearing	<a href="#">Buy now</a>
21	<a href="#">6264531609</a> Bushing, drive shaft 1	<a href="#">Buy now</a>
22	<a href="#">9310120048</a> Oil seal (20x30x6-648)	<a href="#">Buy now</a>
23	<a href="#">69G45315A0</a> Packing, lower casing	<a href="#">Buy now</a>
24	<a href="#">9321006ME6</a> O-ring	<a href="#">Buy now</a>
25	<a href="#">9708008025</a> Screw, bind(j36)	<a href="#">Buy now</a>
26	<a href="#">69G4415010</a> Shift cam assembly L(21.7")	<a href="#">Buy now</a>
26	<a href="#">69G4415020</a> Shift cam assembly X(24.3")	<a href="#">Buy now</a>
27	<a href="#">69G4551010</a> Drive shaft assembly L(21.7")	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
27	<a href="#">69G4551020</a> Drive shaft assembly X(24.3")	<a href="#">Buy now</a>
28	<a href="#">66R4555100</a> Pinion	<a href="#">Buy now</a>
29	<a href="#">9017908M06</a> Nut (6e7)	<a href="#">Buy now</a>
30	<a href="#">66R4556001</a> Gear	<a href="#">Buy now</a>
31	<a href="#">66R4557100</a> Gear	<a href="#">Buy now</a>
32	<a href="#">6264557700</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
32	<a href="#">6264557710</a> Shim (t:0.20mm) UR	<a href="#">Buy now</a>
32	<a href="#">6264557720</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
32	<a href="#">6264557730</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
32	<a href="#">6264557740</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
33	<a href="#">9020117682</a> Washer, plate (2k7)	<a href="#">Buy now</a>
34	<a href="#">6834561100</a> Shaft propeller	<a href="#">Buy now</a>
35	<a href="#">6504563500</a> Plunger, shift	<a href="#">Buy now</a>
36	<a href="#">69G4563100</a> Clutch, dog	<a href="#">Buy now</a>
37	<a href="#">9025005010</a> Pin straight 648456320000	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
38	<a href="#">6484563300</a> Ring, cross pin	<a href="#">Buy now</a>
39	<a href="#">9050114M09</a> Spring, compression	<a href="#">Buy now</a>
40	<a href="#">66R45361004D</a> Cap, lower casing	<a href="#">Buy now</a>
41	<a href="#">9330600501</a> Bearing(1ff)	<a href="#">Buy now</a>
42	<a href="#">93315317U2</a> Brg,cyl-cal roller 14g (683)	<a href="#">Buy now</a>
43	<a href="#">9310117054</a> Oil seal (17x30x6-650)	<a href="#">Buy now</a>
44	<a href="#">9321074M68</a> O-ring (6g8)	<a href="#">Buy now</a>
45	<a href="#">9321074316</a> O-ring (1j7)	<a href="#">Buy now</a>
46	<a href="#">9709506025</a> Bolt	<a href="#">Buy now</a>
47	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
1	<a href="#">68T4436110</a> Tube, water 1 L(21.7")	<a href="#">Buy now</a>
1	<a href="#">69G4436120</a> Tube, water 1 X(24.3")	<a href="#">Buy now</a>
2	<a href="#">63V4436510</a> Damper, water seal 1	<a href="#">Buy now</a>
3	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
4	<a href="#">9707508035</a> Bolt(70w) L(21.7")	<a href="#">Buy now</a>
5	<a href="#">9299508600</a> Washer, plain (663) L(21.7")	<a href="#">Buy now</a>
6	<a href="#">6G14521400</a> Cover, water inlet	<a href="#">Buy now</a>
7	<a href="#">63V4521500</a> Cover, water inlet	<a href="#">Buy now</a>
8	<a href="#">9015205M04</a> Screw, countersunk	<a href="#">Buy now</a>
9	<a href="#">9018505002</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
10	<a href="#">61N4525101</a> Anode	<a href="#">Buy now</a>
11	<a href="#">9589506030</a> Bolt, flange deep recess	<a href="#">Buy now</a>
12	<a href="#">9299006300</a> Washer, tooth	<a href="#">Buy now</a>
13	<a href="#">63V4537500</a> Damper, seal	<a href="#">Buy now</a>
14	<a href="#">6G84598702</a> Spacer	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
15	<a href="#">9345010M04</a> Circlip(6g8)	<a href="#">Buy now</a>
16	<a href="#">9020131MA3</a> Washer, plate (6g8)	<a href="#">Buy now</a>
17	<a href="#">6G84599700</a> Spacer	<a href="#">Buy now</a>
18	<a href="#">9020110M02</a> Washer, plate(6g9)	<a href="#">Buy now</a>
19	<a href="#">9017110M07</a> Nut, castle(6g8)	<a href="#">Buy now</a>
20	<a href="#">9149030025</a> Pin cotter	<a href="#">Buy now</a>
21	<a href="#">69G4594300EL</a> Propeller (3x11-3/4 x7-r)	<a href="#">Buy now</a>

# Oil Pan




Ref	Part	
1	<a href="#">68T411370094</a> Guide, exhaust	<a href="#">Buy now</a>
2	<a href="#">65W4271700</a> Rubber, seal 2	<a href="#">Buy now</a>
3	<a href="#">68T4518100</a> Plate	<a href="#">Buy now</a>
4	<a href="#">9709508014</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">9043008143</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
6	<a href="#">9310112M70</a> Oil seal	<a href="#">Buy now</a>
7	<a href="#">68T1342101</a> Strainer 2	<a href="#">Buy now</a>
8	<a href="#">9046711M08</a> Clip(72x)	<a href="#">Buy now</a>
9	<a href="#">6G81157500</a> Relief valve ass'y	<a href="#">Buy now</a>
10	<a href="#">9321012M62</a> O-ring (6g8)	<a href="#">Buy now</a>
11	<a href="#">9360619M23</a> Pin, dowel	<a href="#">Buy now</a>
12	<a href="#">68T15311015B</a> Oil pan	<a href="#">Buy now</a>
13	<a href="#">6H11137200</a> Nipple, hose	<a href="#">Buy now</a>
14	<a href="#">9048010M28</a> Grommet(6k7)	<a href="#">Buy now</a>
15	<a href="#">9034010M10</a> Plug, straight screw	<a href="#">Buy now</a>

# Oil Pan



Ref	Part	
16	<a href="#">9043010M11</a> Gasket	<a href="#">Buy now</a>
17	<a href="#">68T1531600</a> Damper, engine mount 1	<a href="#">Buy now</a>
18	<a href="#">68T1531700</a> Spacer, engine mount	<a href="#">Buy now</a>
19	<a href="#">9788505008</a> Screw, pan head	<a href="#">Buy now</a>
20	<a href="#">68T1347500</a> Gasket	<a href="#">Buy now</a>
21	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
22	<a href="#">9011908005</a> Bolt, with washer	<a href="#">Buy now</a>
23	<a href="#">9707508030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
24	<a href="#">9299508600</a> Washer, plain (663)	<a href="#">Buy now</a>
25	<a href="#">68T1536200</a> Plug, oil level	<a href="#">Buy now</a>


# Oil Pump



60S1300-D080


Ref	Part	
1	<a href="#">9310218M21</a> Oil seal (6g8)	<a href="#">Buy now</a>
2	<a href="#">68T1217100</a> Camshaft 1	<a href="#">Buy now</a>
3	<a href="#">66M115370094</a> Gear, driven	<a href="#">Buy now</a>
4	<a href="#">9010506M14</a> Bolt (6e0)	<a href="#">Buy now</a>
5	<a href="#">9020113201</a> Washer 6474283300	<a href="#">Buy now</a>
6	<a href="#">9020106M94</a> Washer (6g8)	<a href="#">Buy now</a>
7	<a href="#">68T4624100</a> Belt	<a href="#">Buy now</a>
8	<a href="#">68T1153600</a> Gear, drive	<a href="#">Buy now</a>
9	<a href="#">68T1155700</a> Washer 1	<a href="#">Buy now</a>
10	<a href="#">6G81158701</a> Washer, lock	<a href="#">Buy now</a>
11	<a href="#">9017024M09</a> Nut (6g8)	<a href="#">Buy now</a>
12	<a href="#">9028003M01</a> Key woodruff 146115450000	<a href="#">Buy now</a>
13	<a href="#">6AU4629700</a> Cover, dust	<a href="#">Buy now</a>
14	<a href="#">9048010627</a> Grommet	<a href="#">Buy now</a>
15	<a href="#">68T1330000</a> Oil pump assembly	<a href="#">Buy now</a>

# Oil Pump




Ref	Part	
16	<a href="#">68T1332900</a> Gasket, pump cover	<a href="#">Buy now</a>
17	<a href="#">9709506030</a> Bolt(jf7)	<a href="#">Buy now</a>
18	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">6G91213860</a> Mark Caution	<a href="#">Buy now</a>

## Power Tilt Assy




Ref	Part	
1	<a href="#">69G43840024D</a> Power tilt assembly	<a href="#">Buy now</a>
2	<a href="#">69A4380K00</a> Cylinder, tilt sub assembly	<a href="#">Buy now</a>
3	<a href="#">69A2247100</a> Case, cylinder	<a href="#">Buy now</a>
4	<a href="#">9321027666</a> O-ring(47x)	<a href="#">Buy now</a>
5	<a href="#">6H14388E11</a> Plug, tapper screw	<a href="#">Buy now</a>
6	<a href="#">9321007003</a> O-ring (11m)	<a href="#">Buy now</a>
7	<a href="#">69A4381400</a> Piston, free	<a href="#">Buy now</a>
8	<a href="#">9321021276</a> O-ring	<a href="#">Buy now</a>
9	<a href="#">69A4387200</a> Ring, back up	<a href="#">Buy now</a>
10	<a href="#">69A4381000</a> Piston sub assembly	<a href="#">Buy now</a>
11	<a href="#">69A4380D00</a> Piston comp.	<a href="#">Buy now</a>
14	<a href="#">9350532038</a> Ball(7fk)	<a href="#">Buy now</a>
15	<a href="#">65W4386A00</a> Pin, absorber valve	<a href="#">Buy now</a>
16	<a href="#">9360406136</a> Pin, dowel	<a href="#">Buy now</a>
17	<a href="#">69A4385700</a> Spring, absorber valve	<a href="#">Buy now</a>

# Power Tilt Assy




Ref	Part	
18	<a href="#">69A4380100</a> Rod	<a href="#">Buy now</a>
19	<a href="#">69A4381101</a> Screw, cylinder end	<a href="#">Buy now</a>
20	<a href="#">6H14386600</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">69A4387100</a> Ring, back up	<a href="#">Buy now</a>
22	<a href="#">69A4381200</a> Seal, dust	<a href="#">Buy now</a>
23	<a href="#">69A4386900</a> O-ring	<a href="#">Buy now</a>
24	<a href="#">69A4383000</a> Gear pump assembly	<a href="#">Buy now</a>
25	<a href="#">69A4380C00</a> Gear housing assembly	<a href="#">Buy now</a>
26	<a href="#">69A4384100</a> Piston, shuttle	<a href="#">Buy now</a>
27	<a href="#">69A4384M00</a> Piston, shuttle 2	<a href="#">Buy now</a>
28	<a href="#">62Y4389400</a> Spring, shuttle return	<a href="#">Buy now</a>
29	<a href="#">69A4384F00</a> Seal, main valve	<a href="#">Buy now</a>
30	<a href="#">6H14388300</a> O-ring	<a href="#">Buy now</a>
31	<a href="#">9900203600</a> Circlip(615)	<a href="#">Buy now</a>
32	<a href="#">69G4382G00</a> Valve seat	<a href="#">Buy now</a>

## Power Tilt Assy




Ref	Part	
33	<a href="#">9321012N52</a> O-ring	<a href="#">Buy now</a>
34	<a href="#">6T44380800</a> Seat valve comp. 1	<a href="#">Buy now</a>
35	<a href="#">69G4385300</a> Spring, main valve	<a href="#">Buy now</a>
36	<a href="#">69J4381C00</a> Filter 3	<a href="#">Buy now</a>
37	<a href="#">6H14384G11</a> Seal, relief valve	<a href="#">Buy now</a>
38	<a href="#">6H14384410</a> Pin, valve support	<a href="#">Buy now</a>
39	<a href="#">69A4385500</a> Spring, up relief	<a href="#">Buy now</a>
40	<a href="#">6H14385610</a> Spring, down relief	<a href="#">Buy now</a>
41	<a href="#">9350108001</a> Ball	<a href="#">Buy now</a>
42	<a href="#">69A4386A00</a> Pin, absorber valve	<a href="#">Buy now</a>
43	<a href="#">69A4382400</a> Spring, down relief 2	<a href="#">Buy now</a>
44	<a href="#">69A4384800</a> Rod, manual release	<a href="#">Buy now</a>
45	<a href="#">9360215250</a> Pin, dowel	<a href="#">Buy now</a>
46	<a href="#">9321006001</a> O-ring (26h)	<a href="#">Buy now</a>
47	<a href="#">69A4385400</a> Spring, manual release	<a href="#">Buy now</a>

## Power Tilt Assy




Ref	Part	
48	<a href="#">69A4381G00</a> Pin 1	<a href="#">Buy now</a>
51	<a href="#">69A4384H00</a> Spring	<a href="#">Buy now</a>
52	<a href="#">9360614081</a> Pin,dowel(296)	<a href="#">Buy now</a>
53	<a href="#">9131205025</a> Bolt	<a href="#">Buy now</a>
54	<a href="#">69A4381601</a> Filter 1	<a href="#">Buy now</a>
55	<a href="#">N354386210</a> O-ring	<a href="#">Buy now</a>
56	<a href="#">69A2312900</a> Gasket, drain plug	<a href="#">Buy now</a>
57	<a href="#">69A4387800</a> Bolt, socket	<a href="#">Buy now</a>
58	<a href="#">69G4388001</a> Motor assembly	<a href="#">Buy now</a>
59	<a href="#">65W4380401</a> Stator assembly	<a href="#">Buy now</a>
60	<a href="#">65W4388701</a> Bolt	<a href="#">Buy now</a>
61	<a href="#">65W4380501</a> Armature assembly	<a href="#">Buy now</a>
62	<a href="#">65W4387G00</a> Washer	<a href="#">Buy now</a>
63	<a href="#">69G4388101</a> Frame, end	<a href="#">Buy now</a>
64	<a href="#">65W8218100</a> Circuit breaker comp.	<a href="#">Buy now</a>

## Power Tilt Assy




Ref	Part	
65	<a href="#">65W4389201</a> Brush 2	<a href="#">Buy now</a>
66	<a href="#">65W4389101</a> Brush 1	<a href="#">Buy now</a>
67	<a href="#">65W4386K01</a> Spring, brush	<a href="#">Buy now</a>
68	<a href="#">65W4386L00</a> Spring, brush 2	<a href="#">Buy now</a>
69	<a href="#">65W4380F01</a> Plate, brush holder	<a href="#">Buy now</a>
70	<a href="#">65W4387901</a> Screw, with washer	<a href="#">Buy now</a>
71	<a href="#">65W4388201</a> Oil seal	<a href="#">Buy now</a>
72	<a href="#">69G4388F00</a> Spacer	<a href="#">Buy now</a>

## Remote Control Assy




Ref	Part	
1	<a href="#">7034820116</a> Remote control assembly (10p) <b>AP WITHOUT PT/T SW.</b>	<a href="#">Buy now</a>
1	<a href="#">7034820517</a> Remote control assembly (10p, ptt) <b>AP WITH PT/T SW.</b>	<a href="#">Buy now</a>
2	<a href="#">7034826101</a> Arm, throttle	<a href="#">Buy now</a>
3	<a href="#">7034815300</a> Shaft, free accel.	<a href="#">Buy now</a>
4	<a href="#">7034823500</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">7034826800</a> Spacer 3	<a href="#">Buy now</a>
6	<a href="#">7034826400</a> Throttle, friction	<a href="#">Buy now</a>
7	<a href="#">9538005600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
8	<a href="#">9738005025</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">7034826500</a> Shaft Friction	<a href="#">Buy now</a>
10	<a href="#">9343006024</a> Circlip (701)	<a href="#">Buy now</a>
11	<a href="#">7034824500</a> Plate, lock	<a href="#">Buy now</a>
12	<a href="#">7034825200</a> Roller, cam	<a href="#">Buy now</a>
13	<a href="#">7014824800</a> Roller, free accel	<a href="#">Buy now</a>
14	<a href="#">7034819800</a> Washer, wave 3	<a href="#">Buy now</a>

## Remote Control Assy




Ref	Part	
15	<a href="#">7034824300</a> Bushing 3	<a href="#">Buy now</a>
16	<a href="#">7034823600</a> Bushing	<a href="#">Buy now</a>
17	<a href="#">7034818900</a> Retainer	<a href="#">Buy now</a>
18	<a href="#">7034823400</a> Roller, detent	<a href="#">Buy now</a>
19	<a href="#">7034834501</a> Cable end, remote control 2	<a href="#">Buy now</a>
20	<a href="#">7034835800</a> Anchor, cable	<a href="#">Buy now</a>
21	<a href="#">7034824400</a> Spring, free accel.	<a href="#">Buy now</a>
22	<a href="#">7034823800</a> Spring, detent	<a href="#">Buy now</a>
23	<a href="#">7034824600</a> Spacer 1	<a href="#">Buy now</a>
24	<a href="#">7034822700</a> Spring, neutral lock	<a href="#">Buy now</a>
25	<a href="#">7038259400</a> Clamp <b>WITH PT/T SW.</b>	<a href="#">Buy now</a>
26	<a href="#">7034822600</a> Plate, stopper	<a href="#">Buy now</a>
27	<a href="#">7034822200</a> Grip, control lever <b>SINGLE</b>	<a href="#">Buy now</a>
28	<a href="#">7034822300</a> Lock, neutral	<a href="#">Buy now</a>
29	<a href="#">7034822500</a> Cover	<a href="#">Buy now</a>

## Remote Control Assy




Ref	Part	
30	<a href="#">7034821900</a> Cover, lead	<a href="#">Buy now</a>
31	<a href="#">7034828100</a> Screw, flat head	<a href="#">Buy now</a>
32	<a href="#">7034828200</a> Screw	<a href="#">Buy now</a>
33	<a href="#">9738008030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
34	<a href="#">9299008600</a> Washer, plain (663)	<a href="#">Buy now</a>
35	<a href="#">9858004010</a> Screw, pan head (e56)	<a href="#">Buy now</a>
36	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
37	<a href="#">9858005010</a> Screw, pan head(62x)	<a href="#">Buy now</a>
38	<a href="#">9858003015</a> Screw, pan head (n151)	<a href="#">Buy now</a>
39	<a href="#">7034829110</a> Screw	<a href="#">Buy now</a>
40	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
41	<a href="#">7034829310</a> Spacer, remote control <b>SINGLE</b>	<a href="#">Buy now</a>
42	<a href="#">7014828700</a> Washer 1	<a href="#">Buy now</a>
43	<a href="#">7034821500</a> Graphic	<a href="#">Buy now</a>
44	<a href="#">7038251043</a> Main switch assembly	<a href="#">Buy now</a>

# Remote Control Assy





Ref	Part	
45	<a href="#">7038257700</a> Cap, key	<a href="#">Buy now</a>
46	<a href="#">7038253100</a> Wire, lead	<a href="#">Buy now</a>
47	<a href="#">6888257501</a> Engine stop switch assembly	<a href="#">Buy now</a>
48	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
49	<a href="#">6888258A20</a> 10p main harness mec 2m (6ft) <b>(10P)</b>	<a href="#">Buy now</a>
50	<a href="#">7038254000</a> Neutral switch assembly	<a href="#">Buy now</a>
51	<a href="#">7038338302</a> Buzzer	<a href="#">Buy now</a>
52	<a href="#">7034828400</a> Grommet	<a href="#">Buy now</a>
53	<a href="#">7038259100</a> Band	<a href="#">Buy now</a>
54	<a href="#">7038259200</a> Band	<a href="#">Buy now</a>
55	<a href="#">7034822400</a> Cover, control lever <b>WITHOUT PT/T SW.</b>	<a href="#">Buy now</a>
55	<a href="#">7038256302</a> Trim & tilt switch assembly <b>WITH PT/T SW.</b>	<a href="#">Buy now</a>
56	<a href="#">7034822100</a> Grip	<a href="#">Buy now</a>
57	<a href="#">7034815200</a> Knob, free accel	<a href="#">Buy now</a>
58	<a href="#">7034821200</a> Rear housing	<a href="#">Buy now</a>

## Remote Control Assy



Ref	Part	
59	<u><a href="#">7034821300</a></u> Back, panel	<a href="#">Buy now</a>
60	<u><a href="#">7034827100</a></u> Arm, shift	<a href="#">Buy now</a>
61	<u><a href="#">7034821101</a></u> Housing,1	<a href="#">Buy now</a>
62	<u><a href="#">7034823200</a></u> Drive gear	<a href="#">Buy now</a>
63	<u><a href="#">7038254200</a></u> Cap <b>FOR 703-48201-16</b>	<a href="#">Buy now</a>


## Remote Control Box



67MO100-8280


Ref	Part	
1	<a href="#">7034820116</a> Remote control assembly (10p) <b>AP WITHOUT PT/T SW.</b>	<a href="#">Buy now</a>
1	<a href="#">7034820517</a> Remote control assembly (10p, ptt) <b>AP WITH PT/T SW.</b>	<a href="#">Buy now</a>
2	<a href="#">7014831080</a> Cable, Remote Control L=10F <b>UR</b>	<a href="#">Buy now</a>
2	<a href="#">7014831090</a> Cable, Remote Control L=11F <b>UR</b>	<a href="#">Buy now</a>
2	<a href="#">7014832000</a> Cable, Remote Control L=12F <b>UR</b>	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">6AUW000100</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310218M21</a> Oil seal (6g8)	<a href="#">Buy now</a>
3	<a href="#">68T1118100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
4	<a href="#">68T1135600</a> Seal, cylinder 2	<a href="#">Buy now</a>
5	<a href="#">68T11169A0</a> Gasket, breather cover	<a href="#">Buy now</a>
6	<a href="#">9321013M63</a> O-ring (6g8)	<a href="#">Buy now</a>
7	<a href="#">9310230M22</a> Oil seal (6g8)	<a href="#">Buy now</a>
8	<a href="#">9310125M69</a> Oil seal	<a href="#">Buy now</a>
9	<a href="#">68T1135100</a> Gasket, cylinder	<a href="#">Buy now</a>
10	<a href="#">6G812414A0</a> Gasket, cover	<a href="#">Buy now</a>
11	<a href="#">68T41114A0</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
12	<a href="#">9028003M01</a> Key woodruff 146115450000	<a href="#">Buy now</a>
13	<a href="#">68T1364500</a> Gasket, manifold 1	<a href="#">Buy now</a>
14	<a href="#">68T13646A0</a> Gasket, manifold 2	<a href="#">Buy now</a>
15	<a href="#">9321031MJ5</a> O-ring	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
16	<a href="#">68T1332900</a> Gasket, pump cover	<a href="#">Buy now</a>
17	<a href="#">9321024M79</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9321020M65</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 2




Ref	Part	
1	<a href="#">6AUW009300</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">9798004112</a> Screw, pan head (686)	<a href="#">Buy now</a>
3	<a href="#">6AU1438500</a> Float	<a href="#">Buy now</a>
4	<a href="#">67D1438600</a> Pin, float	<a href="#">Buy now</a>
5	<a href="#">68T1454600</a> Valve, needle	<a href="#">Buy now</a>
6	<a href="#">6AU1498400</a> Gasket, float chamber	<a href="#">Buy now</a>
7	<a href="#">6J81495900</a> Gasket, drin screw	<a href="#">Buy now</a>
8	<a href="#">67D1453600</a> Gasket	<a href="#">Buy now</a>

# Repair Kit 3




Ref	Part	
1	<a href="#">69GW000120</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310112M70</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">9043010M11</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">68T1347500</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">9043008020</a> Gasket	<a href="#">Buy now</a>
6	<a href="#">9310117054</a> Oil seal (17x30x6-650)	<a href="#">Buy now</a>
7	<a href="#">9321074316</a> O-ring (1j7)	<a href="#">Buy now</a>
8	<a href="#">9321074M68</a> O-ring (6g8)	<a href="#">Buy now</a>
9	<a href="#">9321044398</a> O-ring(55x)	<a href="#">Buy now</a>
10	<a href="#">9310120048</a> Oil seal (20x30x6-648)	<a href="#">Buy now</a>
11	<a href="#">69G45315A0</a> Packing, lower casing	<a href="#">Buy now</a>
12	<a href="#">9321006ME6</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">69GW007800</a> Water pump repair kit	<a href="#">Buy now</a>
14	<a href="#">63V4432200</a> Insert, cartridge	<a href="#">Buy now</a>
15	<a href="#">68T4436600</a> Damper, water seal 2	<a href="#">Buy now</a>

## Repair Kit 3



Ref	Part	
16	<a href="#">63V4435201</a> Impeller	<a href="#">Buy now</a>
17	<a href="#">6644433800</a> Key, woodruff	<a href="#">Buy now</a>
19	<a href="#">68T4432300</a> Outer plate, cartridge	<a href="#">Buy now</a>
20	<a href="#">9708008045</a> Bolt, hexagon	<a href="#">Buy now</a>


# Starter



\*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.8M  
 \*1: A PRELEVER SUR BOBINE 50M, REFERENCE 90890-44373,  
 LONGUEUR DE COUPE 1.8M


Ref	Part	
1	<a href="#">68T1571013</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">68T1571103</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">68T1579500</a> Guide, rope	<a href="#">Buy now</a>
4	<a href="#">63V1571400</a> Drum, sheave	<a href="#">Buy now</a>
5	<a href="#">63V1574100</a> Pawl, drive	<a href="#">Buy now</a>
6	<a href="#">63V1571300</a> Spring, starter	<a href="#">Buy now</a>
7	<a href="#">68T1571600</a> Plate, drive	<a href="#">Buy now</a>
8	<a href="#">63V1570501</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">63V1576701</a> Spring	<a href="#">Buy now</a>
10	<a href="#">68T1578400</a> Spring, return	<a href="#">Buy now</a>
11	<a href="#">63V1574400</a> Circlip	<a href="#">Buy now</a>
12	<a href="#">68T1579300</a> Screw	<a href="#">Buy now</a>
13	<a href="#">68T1576400</a> Collar 1	<a href="#">Buy now</a>
14	<a href="#">6G11575500</a> Handle, starter	<a href="#">Buy now</a>
15	* item_description *1	<a href="#">Buy now</a>

# Starter




Ref	Part	
16	<a href="#">6G11577900</a> Cover	<a href="#">Buy now</a>
17	<a href="#">6A01578900</a> Damper	<a href="#">Buy now</a>
18	<a href="#">68T1579400</a> Stopper	<a href="#">Buy now</a>
19	<a href="#">66T1573400</a> Spring, return	<a href="#">Buy now</a>
20	<a href="#">68T1577000</a> Cable comp., starter stop	<a href="#">Buy now</a>
21	<a href="#">66T1573100</a> Retainer, spring	<a href="#">Buy now</a>
22	<a href="#">9709506020</a> Bolt(7u8)	<a href="#">Buy now</a>
23	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
24	<a href="#">68T1576200</a> Seal, rubber 2	<a href="#">Buy now</a>
25	<a href="#">6AH8199540</a> Label, warning	<a href="#">Buy now</a>
26	<a href="#">6AH8199550</a> Label, warning	<a href="#">Buy now</a>
27	<a href="#">6AU1343760</a> Mark, caution	<a href="#">Buy now</a>
28	<a href="#">68T8571160</a> Mark, caution	<a href="#">Buy now</a>
29	<a href="#">6AH8199440</a> Label, safety	<a href="#">Buy now</a>
30	<a href="#">6AH8199450</a> Label, safety	<a href="#">Buy now</a>

# Starting Motor



Ref	Part	
1	<a href="#">68T818220194</a> Bracket, starting motor	<a href="#">Buy now</a>
2	<a href="#">9011908046</a> Bolt, with washer	<a href="#">Buy now</a>
3	<a href="#">9011908020</a> Bolt, with washer	<a href="#">Buy now</a>
4	<a href="#">68T8180000</a> Starting motor assembly	<a href="#">Buy now</a>
5	<a href="#">68T8185700</a> Pinion stopper set	<a href="#">Buy now</a>
6	<a href="#">6898180712</a> Pinion assembly	<a href="#">Buy now</a>
7	<a href="#">6F58183010</a> Front cover assembly	<a href="#">Buy now</a>
8	<a href="#">6898183100</a> Metal, front	<a href="#">Buy now</a>
9	<a href="#">6898184711</a> O-ring	<a href="#">Buy now</a>
10	<a href="#">6898180911</a> Washer kit	<a href="#">Buy now</a>
11	<a href="#">6898185011</a> Armature assembly	<a href="#">Buy now</a>
12	<a href="#">6898181011</a> Stator ass'y	<a href="#">Buy now</a>
13	<a href="#">6898184011</a> Brush holder assembly	<a href="#">Buy now</a>
14	<a href="#">6898181111</a> Brush 1	<a href="#">Buy now</a>
15	<a href="#">6898181211</a> Brush 2	<a href="#">Buy now</a>


# Starting Motor



FWD  
6AU1100-G160


Ref	Part	
16	<a href="#">6898181310</a> Spring, brush	<a href="#">Buy now</a>
17	<a href="#">6898182011</a> Rear cover ass'y	<a href="#">Buy now</a>
18	<a href="#">6898182610</a> Bolt	<a href="#">Buy now</a>
19	<a href="#">9011908M76</a> Bolt, with washer(6e5)	<a href="#">Buy now</a>
20	<a href="#">9709508016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
21	<a href="#">9299508600</a> Washer, plain (663)	<a href="#">Buy now</a>
22	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
23	<a href="#">9046508M99</a> Clamp	<a href="#">Buy now</a>
24	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
25	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>

# Steering




Ref	Part	
1	<a href="#">69GW0084004D</a> Handle steering assembly	<a href="#">Buy now</a>
2	<a href="#">66R42101014D</a> Handle, steering	<a href="#">Buy now</a>
3	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">9010906M80</a> Bolt	<a href="#">Buy now</a>
7	<a href="#">69G4213800</a> Lever, throttle	<a href="#">Buy now</a>
8	<a href="#">65W4215900</a> Stay	<a href="#">Buy now</a>
9	<a href="#">6G14212600</a> Piece, friction	<a href="#">Buy now</a>
10	<a href="#">65W4212500</a> Bolt, friction adjusting	<a href="#">Buy now</a>
11	<a href="#">9149016010</a> Pin, cotter	<a href="#">Buy now</a>
12	<a href="#">67D4217700</a> Rubber, handle	<a href="#">Buy now</a>
13	<a href="#">67D4211900</a> Grip, steering handle	<a href="#">Buy now</a>
14	<a href="#">6AU4213700</a> Indicator, throttle	<a href="#">Buy now</a>
15	<a href="#">9026902M09</a> Rivet(615)	<a href="#">Buy now</a>
16	<a href="#">9014905M13</a> Screw, countersunk	<a href="#">Buy now</a>
17	<a href="#">9020110M02</a> Washer, plate(6g9)	<a href="#">Buy now</a>

## Steering




Ref	Part	
18	<a href="#">9050123215</a> Spring (655)	<a href="#">Buy now</a>
19	<a href="#">9038608032</a> Bushing (650)	<a href="#">Buy now</a>
20	<a href="#">68T2630111</a> Throttle cable assembly	<a href="#">Buy now</a>
21	<a href="#">9044707005</a> Hose, with spring	<a href="#">Buy now</a>
22	<a href="#">66R4217100</a> Bushing	<a href="#">Buy now</a>
23	<a href="#">9020143M00</a> Washer, plate	<a href="#">Buy now</a>
24	<a href="#">9020643M22</a> Washer, wave	<a href="#">Buy now</a>
25	<a href="#">9020243M57</a> Washer, plate	<a href="#">Buy now</a>
26	<a href="#">9038640M99</a> Bush	<a href="#">Buy now</a>
27	<a href="#">66M4213101</a> Cover, handle steering	<a href="#">Buy now</a>
28	<a href="#">9578010300</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
29	<a href="#">9538010700</a> Nut (682)	<a href="#">Buy now</a>
30	<a href="#">66R44111004D</a> Handle, gear shift	<a href="#">Buy now</a>
31	<a href="#">66R4417300</a> Lever, shift control	<a href="#">Buy now</a>
32	<a href="#">9015906M18</a> Screw, with washer(6b0)	<a href="#">Buy now</a>

# Steering



Ref	Part	
33	<a href="#">66R4212900</a> Bushing, rubber	<a href="#">Buy now</a>
34	<a href="#">9709508030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
35	<a href="#">9299508600</a> Washer, plain (663)	<a href="#">Buy now</a>
36	<a href="#">9038626MA3</a> Bush	<a href="#">Buy now</a>
37	<a href="#">9020626M25</a> Washer, wave	<a href="#">Buy now</a>
38	<a href="#">9020226M59</a> Washer, plate	<a href="#">Buy now</a>
39	<a href="#">68T4411301</a> Cam plate, handle	<a href="#">Buy now</a>
40	<a href="#">66R4411600</a> Spring	<a href="#">Buy now</a>
41	<a href="#">66R4411800</a> Bracket	<a href="#">Buy now</a>
42	<a href="#">66R4853800</a> Clamp, cable 1	<a href="#">Buy now</a>
43	<a href="#">63D4853800</a> Clamp, cable 1	<a href="#">Buy now</a>
44	<a href="#">68T4832101</a> Cable	<a href="#">Buy now</a>
45	<a href="#">9044615002</a> Hose	<a href="#">Buy now</a>
46	<a href="#">68T8259410</a> Clamp	<a href="#">Buy now</a>
47	<a href="#">9015105003</a> Screw, countersunk	<a href="#">Buy now</a>


# Steering



6AU1100-G180

Ref	Part	
48	<a href="#">9908004600</a> Circlip (eu0)	<a href="#">Buy now</a>
49	<a href="#">66R4411400</a> Stopper	<a href="#">Buy now</a>
50	<a href="#">6E04419111</a> Indicator, shift	<a href="#">Buy now</a>
51	<a href="#">66R4834400</a> Cable end, remote control	<a href="#">Buy now</a>
52	<a href="#">9020106M62</a> Washer, plate (6e5)	<a href="#">Buy now</a>
53	<a href="#">9017005M38</a> Nut	<a href="#">Buy now</a>
54	<a href="#">9149020012</a> Pin, cotter (648)	<a href="#">Buy now</a>
55	<a href="#">6AU42121104D</a> Bracket	<a href="#">Buy now</a>
56	<a href="#">9011610040</a> Bolt, stud	<a href="#">Buy now</a>
57	<a href="#">9017910M33</a> Nut	<a href="#">Buy now</a>


# Steering Friction



6AU1100-G190

Ref	Part	
1	<a href="#">6AH4250800</a> Steering friction assembly	<a href="#">Buy now</a>
2	<a href="#">68T4252501</a> Plate, friction	<a href="#">Buy now</a>
3	<a href="#">9011905018</a> Bolt, with washer	<a href="#">Buy now</a>
4	<a href="#">67C4256200</a> Shaft, steering lock	<a href="#">Buy now</a>
5	<a href="#">9020210M56</a> Washer, plate	<a href="#">Buy now</a>
6	<a href="#">68T4256100</a> Knob, steering lock	<a href="#">Buy now</a>
7	<a href="#">6894363300</a> Cover, tilt lever	<a href="#">Buy now</a>
8	<a href="#">65W4252800</a> Plate, friction	<a href="#">Buy now</a>
9	<a href="#">9038705M05</a> Collar	<a href="#">Buy now</a>
10	<a href="#">9038705M11</a> Collar	<a href="#">Buy now</a>
11	<a href="#">9709505020</a> Bolt, hexagon	<a href="#">Buy now</a>
12	<a href="#">9299505600</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">9020910M26</a> Washer	<a href="#">Buy now</a>
14	<a href="#">9018510M14</a> Nut, self-locking	<a href="#">Buy now</a>
15	<a href="#">6AH4252700</a> Plate, friction	<a href="#">Buy now</a>


## Steering Friction



6AU1100-G190

Ref	Part	
16	<a href="#">9010108022</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
17	<a href="#">9020108065</a> Washer, plate	<a href="#">Buy now</a>
18	<a href="#">68T4315500</a> Mark 1	<a href="#">Buy now</a>


# Steering Guide



6AU1100-G300


Ref	Part	
1	<a href="#">68T6135010</a> Steering guide attachment kit AP	<a href="#">Buy now</a>
2	<a href="#">9020110M20</a> Washer, plate (663)	<a href="#">Buy now</a>
3	<a href="#">9018509M01</a> Nut, nylon (663)	<a href="#">Buy now</a>
4	<a href="#">9017009M03</a> Nut (689)	<a href="#">Buy now</a>
5	<a href="#">9038710M42</a> Coller (688)	<a href="#">Buy now</a>
6	<a href="#">6E56135500</a> Bolt	<a href="#">Buy now</a>
7	<a href="#">9020110M63</a> Washer, plate	<a href="#">Buy now</a>
8	<a href="#">6E54314501</a> Cap, clamp bracket	<a href="#">Buy now</a>
9	<a href="#">9321016275</a> O-ring	<a href="#">Buy now</a>

# Top Cowling




Ref	Part	
1	<a href="#">6AV42610004D</a> Top Cowling assembly	<a href="#">Buy now</a>
1	<a href="#">6AV42610104D</a> Top Cowling assembly	<a href="#">Buy now</a>
1	<a href="#">6AV42610304D</a> Top cowling assembly	<a href="#">Buy now</a>
2	<a href="#">6AU4261300</a> Molding Air Duct	<a href="#">Buy now</a>
3	<a href="#">9778060516</a> Screw, panhead tapping (j20)	<a href="#">Buy now</a>
4	<a href="#">6G14265102</a> Hook	<a href="#">Buy now</a>
5	<a href="#">9026604M04</a> Rivet(6e7)	<a href="#">Buy now</a>
6	<a href="#">68T4261500</a> Seal	<a href="#">Buy now</a>
7	<a href="#">68T4265200</a> Hook	<a href="#">Buy now</a>
8	<a href="#">9709505014</a> Bolt, w/ plain	<a href="#">Buy now</a>
9	<a href="#">9299505600</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">68T4264900</a> Holder, clamp band	<a href="#">Buy now</a>
11	<a href="#">66R4267820</a> Graphic, rear	<a href="#">Buy now</a>
12	<a href="#">68TW007020</a> Graphic Set	<a href="#">Buy now</a>
12	<a href="#">68TW007060</a> Graphic set	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
13	<a href="#">6AU4267700</a> Graphic, front	<a href="#">Buy now</a>
13	<a href="#">6AV4268600</a> Emblem, front	<a href="#">Buy now</a>
14	<a href="#">69A4267500</a> Graphic, side 1	<a href="#">Buy now</a>
15	<a href="#">67F1343410</a> [],	<a href="#">Buy now</a>

# Upper Casing



Ref	Part	
1	<a href="#">6AU45111104D</a> Casing, upper	<a href="#">Buy now</a>
2	<a href="#">6AU14711005B</a> Muffler 1	<a href="#">Buy now</a>
3	<a href="#">9757506514</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">9048014M54</a> Grommet	<a href="#">Buy now</a>
5	<a href="#">68T4532100</a> Plate	<a href="#">Buy now</a>
6	<a href="#">9709506008</a> Bolt (fj1)	<a href="#">Buy now</a>
7	<a href="#">9788505008</a> Screw, pan head	<a href="#">Buy now</a>
15	<a href="#">9360412M07</a> Pin, dowel (688) X(24.3")	<a href="#">Buy now</a>
9	<a href="#">9707508035</a> Bolt(70w)	<a href="#">Buy now</a>
10	<a href="#">9299508600</a> Washer, plain (663)	<a href="#">Buy now</a>
11	<a href="#">69G45211204D</a> Extension X(24.3")	<a href="#">Buy now</a>
12	<a href="#">63V4512700</a> Seal X(24.3")	<a href="#">Buy now</a>
13	<a href="#">9299008600</a> Washer, plain (663) X(24.3")	<a href="#">Buy now</a>
14	<a href="#">9538008600</a> Nut (661) X(24.3")	<a href="#">Buy now</a>
16	<a href="#">9011608M62</a> Bolt, stud X(24.3")	<a href="#">Buy now</a>

# Valve



Ref	Part	
1	<a href="#">67D1211100</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">67D1212100</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">68T1211600</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">60R1211300</a> Spring, valve inne	<a href="#">Buy now</a>
5	<a href="#">7NJ1211700</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">7NJ1211800</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">51Y1211900</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">68T1214600</a> Shaft, rocker	<a href="#">Buy now</a>
9	<a href="#">9038713M56</a> Collar (6g8)	<a href="#">Buy now</a>
10	<a href="#">9038714M03</a> Collar	<a href="#">Buy now</a>
11	<a href="#">9050112M40</a> Spring, compression (6g8)	<a href="#">Buy now</a>
12	<a href="#">68T1215100</a> Arm, valve rocker	<a href="#">Buy now</a>
13	<a href="#">6G81215900</a> Screw, valve adjusting	<a href="#">Buy now</a>
14	<a href="#">6G81215800</a> Nut, lock	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.