



# Yamaha Helm Master EX 2021

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

|                                           |    |
|-------------------------------------------|----|
| <b>2ND HELM HARNESS</b>                   | 3  |
| <b>BATTERY MANAGEMENT SYSTEM</b>          | 4  |
| <b>CL5 DISPLAY</b>                        | 5  |
| <b>CONVERSION HARNESS</b>                 | 6  |
| <b>DEC 1 (SINGLE)</b>                     | 7  |
| <b>DEC 10 (SINGLE/2ND ST)</b>             | 8  |
| <b>DEC 11 (MULTIPLE/2ND ST)</b>           | 9  |
| <b>DEC 12 (FLUSH MOUNT/2ND ST)</b>        | 10 |
| <b>DEC 2 (MULTIPLE)</b>                   | 11 |
| <b>DEC 3 (FLUSH SIDE MOUNT)</b>           | 12 |
| <b>DEC 4 (SINGLE/MAIN ST)</b>             | 13 |
| <b>DEC 5 (TWIN/MAIN ST)</b>               | 14 |
| <b>DEC 6 (TRIPLE/MAIN ST)</b>             | 16 |
| <b>DEC 7 (QUAD/MAIN ST)</b>               | 18 |
| <b>DEC 8 (QUINT/MAIN ST)</b>              | 20 |
| <b>DEC 9 (FLUSH MOUNT/MAIN ST)</b>        | 22 |
| <b>DES 1</b>                              | 23 |
| <b>DES 2</b>                              | 24 |
| <b>IMMOBILIZER KIT</b>                    | 26 |
| <b>JOYSTICK AND AUTOPILOT</b>             | 27 |
| <b>MFD INTERFACE</b>                      | 30 |
| <b>SWITCH &amp; PANEL 1 (EKS, SINGLE)</b> | 31 |
| <b>SWITCH &amp; PANEL 2 (EKS, TWIN)</b>   | 32 |
| <b>SWITCH &amp; PANEL 3 (EKS, TRIPLE)</b> | 34 |
| <b>SWITCH &amp; PANEL 4 (EKS, QUAD)</b>   | 36 |
| <b>SWITCH &amp; PANEL 5 (EKS, QUINT)</b>  | 38 |
| <b>SWITCH &amp; PANEL 6 (EKS,KEY/REC)</b> | 40 |
| <b>SWITCH &amp; PANEL 7</b>               | 41 |


## 2Nd Helm Harness



6X91100-U160


| Ref | Part                                                                                     |                         |
|-----|------------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98258A00</a><br>2nd st harness (p) 5m-16ft<br>UR                           | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98258A10</a><br>2nd st harness (p) 8m-26ft<br>UR                           | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98258A20</a><br>2nd st harness (p) 12m-38ft<br>UR                          | <a href="#">Buy now</a> |
| 2   | <a href="#">6Y88537101</a><br>End of line resister                                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98258A30</a><br>2nd st harness (s) 5m-16ft<br>UR EXCEPT SINGLE ENGINE      | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98258A40</a><br>2nd st harness (s) 8m-26ft<br>UR EXCEPT SINGLE ENGINE      | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98258A50</a><br>2nd st harness (s) 12m-38ft<br>UR EXCEPT SINGLE ENGINE     | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258A60</a><br>2nd st harness (c) 5m-16ft<br>UR TRIPLE/QUAD/QUINT ENGINE  | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258A70</a><br>2nd st harness (c) 8m-26ft<br>UR TRIPLE/QUAD/QUINT ENGINE  | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258A80</a><br>2nd st harness (c) 12m-38ft<br>UR TRIPLE/QUAD/QUINT ENGINE | <a href="#">Buy now</a> |

# Battery Management System




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98271610</a><br>Cord switch                       | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98339600</a><br>Switching Unit assembly           | <a href="#">Buy now</a> |
| 3   | <a href="#">6X982570A0</a><br>Battery switch panel<br>YMUS ONLY | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98257120</a><br>Panel, switch                     | <a href="#">Buy now</a> |
| 5   | <a href="#">6X92248020</a><br>Seal assembly                     | <a href="#">Buy now</a> |
| 6   | <a href="#">6X98258200</a><br>Cap 1 (12p)                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6X98258210</a><br>Cap 1 (6p)                        | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98258220</a><br>Cap 1 (6p)                        | <a href="#">Buy now</a> |
| 9   | <a href="#">6X98258230</a><br>Cap 1 (9p)                        | <a href="#">Buy now</a> |
| 10  | <a href="#">6X98258240</a><br>Cap 1 (8p)                        | <a href="#">Buy now</a> |
| 11  | <a href="#">6X98258250</a><br>Cap 1 (8p)                        | <a href="#">Buy now</a> |
| 12  | <a href="#">6X98258260</a><br>Cap 1 (3p)                        | <a href="#">Buy now</a> |
| 13  | <a href="#">6X98258270</a><br>Cap 1 (2p)                        | <a href="#">Buy now</a> |
| 14  | <a href="#">6X98258280</a><br>Cap 1 (6p)                        | <a href="#">Buy now</a> |

## CI5 Display



| Ref | Part                                                                   |                         |
|-----|------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YM8371012</a><br>CI5 display(with wi-fi)<br>WITHOUT Wi-Fi | <a href="#">Buy now</a> |
| 2   | <a href="#">6YM2248000</a><br>Seal assembly                            | <a href="#">Buy now</a> |
| 3   | <a href="#">6YM8395600</a><br>Cap 1                                    | <a href="#">Buy now</a> |
| 4   | <a href="#">6YD8395700</a><br>Cap 2                                    | <a href="#">Buy now</a> |
| 5   | <a href="#">6YM8351200</a><br>Ring, speed meter                        | <a href="#">Buy now</a> |
| 6   | <a href="#">6YM8727800</a><br>Cover, meter                             | <a href="#">Buy now</a> |
| 7   | <a href="#">6YM8355300</a><br>Conversion harness cl5-pigtail           | <a href="#">Buy now</a> |
| 8   | <a href="#">6YD8356N00</a><br>Wire, lead                               | <a href="#">Buy now</a> |

# Conversion Harness




6X91100-U170

| Ref | Part                                                                                |                         |
|-----|-------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98355360</a><br>Wire, lead<br>TRIPLE/QUAD, MAIN STATION               | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98355320</a><br>Conversion harness single, 2nd<br>SINGLE, 2ND STATION | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98355330</a><br>Conversion harness twin 2nd st<br>TWIN, 2ND STATION   | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98355340</a><br>Wire, lead<br>TRIPLE, 2ND STATION                     | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98355350</a><br>Wire, lead<br>QUAD, 2ND STATION                       | <a href="#">Buy now</a> |

## Dec 1 (Single)

SINGLE ENGINE




6X91100-U010

| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0101</a><br>Remote control box<br>NOT FOR SALE | <a href="#">Buy now</a> |
| 2   | <a href="#">6X94822A00</a><br>Grip, lever singl                  | <a href="#">Buy now</a> |
| 3   | <a href="#">6X94812700</a><br>Screw 1                            | <a href="#">Buy now</a> |
| 4   | <a href="#">9299005300</a><br>Washer, tooth                      | <a href="#">Buy now</a> |
| 5   | <a href="#">6X94840000</a><br>Cover assembly                     | <a href="#">Buy now</a> |
| 6   | <a href="#">6X94269700</a><br>Tuning fork mark                   | <a href="#">Buy now</a> |
| 7   | <a href="#">6X94811C00</a><br>Cover, single                      | <a href="#">Buy now</a> |
| 8   | <a href="#">6X94816700</a><br>Plug                               | <a href="#">Buy now</a> |
| 9   | <a href="#">6X94817600</a><br>Grommet                            | <a href="#">Buy now</a> |
| 10  | <a href="#">9778050145</a><br>Screw, pan head tapping<br>UR      | <a href="#">Buy now</a> |
| 10  | <a href="#">9858005060</a><br>Screw, panhead<br>UR               | <a href="#">Buy now</a> |
| 11  | <a href="#">7044828700</a><br>Washer 1                           | <a href="#">Buy now</a> |
| 12  | <a href="#">9538005600</a><br>Nut, hexagon (663)                 | <a href="#">Buy now</a> |

## Dec 10 (Single/2Nd St)

DIGITAL ELECTRONIC CONTROL  
(SINGLE ENGINE / 2ND STATION)




6X91100-U070

| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0101</a><br>Remote control box<br>NOT FOR SALE | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258010</a><br>Wire harness assembly 2            | <a href="#">Buy now</a> |

## Dec 11 (Multiple/2Nd St)

DIGITAL ELECTRONIC CONTROL  
(TWIN, TRIPLE, QUAD, QUINT ENGINE / 2ND STATION)




6X91100-V090

| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0201</a><br>Remote Control Box<br>NOT FOR SALE | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258050</a><br>Wire harness assembly 2            | <a href="#">Buy now</a> |

## Dec 12 (Flush Mount/2Nd St)

DIGITAL ELECTRONIC CONTROL  
(FLUSH SIDE MOUNT/ 2ND STATION)




6X9110B-V120

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0000</a><br>-<br>NOT FOR SALE       | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258030</a><br>Wire harness assembly 2 | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98258270</a><br>Cap 1 (2p)              | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258280</a><br>Cap 1 (6p)              | <a href="#">Buy now</a> |


## Dec 2 (Multiple)

TWIN, TRIPLE, QUAD, QUINT ENGINE



| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0201</a><br>Remote Control Box<br>NOT FOR SALE | <a href="#">Buy now</a> |
| 2   | <a href="#">6X94822B00</a><br>Grip, lever multi                  | <a href="#">Buy now</a> |
| 3   | <a href="#">6X94812700</a><br>Screw 1                            | <a href="#">Buy now</a> |
| 4   | <a href="#">9299005300</a><br>Washer, tooth                      | <a href="#">Buy now</a> |
| 5   | <a href="#">6X94822200</a><br>Grip, control lever                | <a href="#">Buy now</a> |
| 6   | <a href="#">6X94840000</a><br>Cover assembly                     | <a href="#">Buy now</a> |
| 7   | <a href="#">6X94269700</a><br>Tuning fork mark                   | <a href="#">Buy now</a> |
| 8   | <a href="#">6X94811900</a><br>Cover                              | <a href="#">Buy now</a> |
| 9   | <a href="#">6X94816700</a><br>Plug                               | <a href="#">Buy now</a> |
| 10  | <a href="#">6X94816800</a><br>Plug 2                             | <a href="#">Buy now</a> |
| 11  | <a href="#">6X94817600</a><br>Grommet                            | <a href="#">Buy now</a> |
| 12  | <a href="#">9778050145</a><br>Screw, pan head tapping<br>UR      | <a href="#">Buy now</a> |
| 12  | <a href="#">9858005060</a><br>Screw, panhead<br>UR               | <a href="#">Buy now</a> |
| 13  | <a href="#">7044828700</a><br>Washer 1                           | <a href="#">Buy now</a> |
| 14  | <a href="#">9538005600</a><br>Nut, hexagon (663)                 | <a href="#">Buy now</a> |

## Dec 3 (Flush Side Mount)




6X9110B-V030

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0000</a><br>-<br>NOT FOR SALE           | <a href="#">Buy now</a> |
| 2   | <a href="#">6X94816600</a><br>Plug                        | <a href="#">Buy now</a> |
| 3   | <a href="#">6X78257501</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 4   | <a href="#">6X94823B00</a><br>Packing 2                   | <a href="#">Buy now</a> |
| 5   | <a href="#">9778006230</a><br>Screw, tapping<br>UR        | <a href="#">Buy now</a> |
| 5   | <a href="#">9878006035</a><br>Screw flat head<br>UR       | <a href="#">Buy now</a> |
| 6   | <a href="#">7014828700</a><br>Washer 1                    | <a href="#">Buy now</a> |
| 7   | <a href="#">6X04815600</a><br>Nut 1                       | <a href="#">Buy now</a> |
| 8   | <a href="#">6X94282100</a><br>Band, clamp                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6X94269700</a><br>Tuning fork mark            | <a href="#">Buy now</a> |

## Dec 4 (Single/Main St)


### DIGITAL ELECTRONIC CONTROL (SINGLE ENGINE / MAIN STATION)



| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0101</a><br>Remote control box<br><b>NOT FOR SALE</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258002</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 3   | <a href="#">6Y88537101</a><br>End of line resister                      | <a href="#">Buy now</a> |
| 4   | <a href="#">68V8258210</a><br>Cap 1 (2p)                                | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98258200</a><br>Cap 1 (12p)                               | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6X68559041</a><br>Control unit assembly                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6X94821100</a><br>Housing,1                                 | <a href="#">Buy now</a> |
| 9   | <a href="#">9760705212</a><br>Screw,w/washer                            | <a href="#">Buy now</a> |
| 10  | <a href="#">9046513M11</a><br>Clamp (6e5)                               | <a href="#">Buy now</a> |
| 11  | <a href="#">9016706M00</a><br>Screw, tapping (6h4)                      | <a href="#">Buy now</a> |
| 12  | <a href="#">9788006035</a><br>Screw, pan head(6h4)                      | <a href="#">Buy now</a> |
| 13  | <a href="#">9578006300</a><br>Nut, nylon (6g1)                          | <a href="#">Buy now</a> |
| 14  | <a href="#">9020106M30</a><br>Washer, plate (6a1)                       | <a href="#">Buy now</a> |

## Dec 5 (Twin/Main St)


### DIGITAL ELECTRONIC CONTROL (TWIN ENGINE / MAIN STATION)



| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0201</a><br>Remote Control Box<br><b>NOT FOR SALE</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258042</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 3   | <a href="#">68V8258210</a><br>Cap 1 (2p)                                | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258200</a><br>Cap 1 (12p)                               | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98258210</a><br>Cap 1 (6p)                                | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6X68559041</a><br>Control unit assembly                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6X94821100</a><br>Housing,1                                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6X94821A00</a><br>Hsg. , 2                                  | <a href="#">Buy now</a> |
| 10  | <a href="#">9760705212</a><br>Screw,w/washer                            | <a href="#">Buy now</a> |
| 11  | <a href="#">9046513M11</a><br>Clamp (6e5)                               | <a href="#">Buy now</a> |
| 12  | <a href="#">6Y88537101</a><br>End of line resistor                      | <a href="#">Buy now</a> |
| 13  | <a href="#">9850706016</a><br>Screw, pan head(3tj)                      | <a href="#">Buy now</a> |
| 14  | <a href="#">9016706M00</a><br>Screw, tapping (6h4)                      | <a href="#">Buy now</a> |
| 15  | <a href="#">9788006035</a><br>Screw, pan head(6h4)                      | <a href="#">Buy now</a> |

Dec 5 (Twin/Main St)


DIGITAL ELECTRONIC CONTROL  
(TWIN ENGINE / MAIN STATION)



| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 16  | <a href="#">9578006300</a><br>Nut, nylon (6g1)    | <a href="#">Buy now</a> |
| 17  | <a href="#">9020106M30</a><br>Washer, plate (6a1) | <a href="#">Buy now</a> |

## Dec 6 (Triple/Main St)


### DIGITAL ELECTRONIC CONTROL (TRIPLE ENGINE / MAIN STATION)



| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0201</a><br>Remote Control Box<br><b>NOT FOR SALE</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258042</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 3   | <a href="#">68V8258210</a><br>Cap 1 (2p)                                | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258200</a><br>Cap 1 (12p)                               | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98258210</a><br>Cap 1 (6p)                                | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6X982580C2</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 9   | <a href="#">6X68559041</a><br>Control unit assembly                     | <a href="#">Buy now</a> |
| 10  | <a href="#">6X94821100</a><br>Housing,1                                 | <a href="#">Buy now</a> |
| 11  | <a href="#">6X94821A00</a><br>Hsg. , 2                                  | <a href="#">Buy now</a> |
| 12  | <a href="#">9760705212</a><br>Screw,w/washer                            | <a href="#">Buy now</a> |
| 13  | <a href="#">9046513M11</a><br>Clamp (6e5)                               | <a href="#">Buy now</a> |
| 14  | <a href="#">6Y88537101</a><br>End of line resistor                      | <a href="#">Buy now</a> |
| 15  | <a href="#">9850706016</a><br>Screw, pan head(3tj)                      | <a href="#">Buy now</a> |
| 16  | <a href="#">9016706M00</a><br>Screw, tapping (6h4)                      | <a href="#">Buy now</a> |

Dec 6 (Triple/Main St)


DIGITAL ELECTRONIC CONTROL  
(TRIPLE ENGINE / MAIN STATION)



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 17  | <a href="#">9788006035</a><br>Screw, pan head(6h4) | <a href="#">Buy now</a> |
| 18  | <a href="#">9578006300</a><br>Nut, nylon (6g1)     | <a href="#">Buy now</a> |
| 19  | <a href="#">9020106M30</a><br>Washer, plate (6a1)  | <a href="#">Buy now</a> |

## Dec 7 (Quad/Main St)


### DIGITAL ELECTRONIC CONTROL (QUAD ENGINE / MAIN STATION)



| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0201</a><br>Remote Control Box<br><b>NOT FOR SALE</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258042</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 3   | <a href="#">68V8258210</a><br>Cap 1 (2p)                                | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98258200</a><br>Cap 1 (12p)                               | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98258210</a><br>Cap 1 (6p)                                | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6X982580C2</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 9   | <a href="#">6X982580D2</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 11  | <a href="#">6X68559041</a><br>Control unit assembly                     | <a href="#">Buy now</a> |
| 12  | <a href="#">6X94821100</a><br>Housing,1                                 | <a href="#">Buy now</a> |
| 13  | <a href="#">6X94821A00</a><br>Hsg. , 2                                  | <a href="#">Buy now</a> |
| 14  | <a href="#">9760705212</a><br>Screw,w/washer                            | <a href="#">Buy now</a> |
| 15  | <a href="#">9046513M11</a><br>Clamp (6e5)                               | <a href="#">Buy now</a> |
| 16  | <a href="#">6Y88537101</a><br>End of line resistor                      | <a href="#">Buy now</a> |
| 17  | <a href="#">9850706016</a><br>Screw, pan head(3tj)                      | <a href="#">Buy now</a> |

## Dec 7 (Quad/Main St)


### DIGITAL ELECTRONIC CONTROL (QUAD ENGINE / MAIN STATION)



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 18  | <a href="#">9016706M00</a><br>Screw, tapping (6h4) | <a href="#">Buy now</a> |
| 19  | <a href="#">9788006035</a><br>Screw, pan head(6h4) | <a href="#">Buy now</a> |
| 20  | <a href="#">9578006300</a><br>Nut, nylon (6g1)     | <a href="#">Buy now</a> |
| 21  | <a href="#">9020106M30</a><br>Washer, plate (6a1)  | <a href="#">Buy now</a> |

## Dec 8 (Quint/Main St)


### DIGITAL ELECTRONIC CONTROL (QUINT ENGINE / MAIN STATION)



| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0201</a><br>Remote Control Box<br><b>NOT FOR SALE</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">6X982580E0</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 3   | <a href="#">6Y88537101</a><br>End of line resistor                      | <a href="#">Buy now</a> |
| 4   | <a href="#">68V8258210</a><br>Cap 1 (2p)                                | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)                        | <a href="#">Buy now</a> |
| 6   | <a href="#">6X982580F0</a><br>Wire harness assembly 2                   | <a href="#">Buy now</a> |
| 7   | <a href="#">6X98258200</a><br>Cap 1 (12p)                               | <a href="#">Buy now</a> |
| 9   | <a href="#">6X68198000</a><br>Diode assembly                            | <a href="#">Buy now</a> |
| 10  | <a href="#">6X68559041</a><br>Control unit assembly                     | <a href="#">Buy now</a> |
| 11  | <a href="#">6X94821100</a><br>Housing,1                                 | <a href="#">Buy now</a> |
| 12  | <a href="#">6X94821A00</a><br>Hsg. , 2                                  | <a href="#">Buy now</a> |
| 13  | <a href="#">9760705212</a><br>Screw,w/washer                            | <a href="#">Buy now</a> |
| 14  | <a href="#">9046513M11</a><br>Clamp (6e5)                               | <a href="#">Buy now</a> |
| 15  | <a href="#">9850706016</a><br>Screw, pan head(3tj)                      | <a href="#">Buy now</a> |
| 16  | <a href="#">9016706M00</a><br>Screw, tapping (6h4)                      | <a href="#">Buy now</a> |

Dec 8 (Quint/Main St)



DIGITAL ELECTRONIC CONTROL  
(QUINT ENGINE / MAIN STATION)



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 17  | <a href="#">9788006035</a><br>Screw, pan head(6h4) | <a href="#">Buy now</a> |
| 18  | <a href="#">9578006300</a><br>Nut, nylon (6g1)     | <a href="#">Buy now</a> |
| 19  | <a href="#">9020106M30</a><br>Washer, plate (6a1)  | <a href="#">Buy now</a> |

## Dec 9 (Flush Mount/Main St)


DIGITAL ELECTRONIC CONTROL  
(FLUSH SIDE MOUNT/ MAIN STATION)




6X9110B-V090

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X948A0000</a><br>-<br>NOT FOR SALE       | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98258021</a><br>Wire harness assembly 2 | <a href="#">Buy now</a> |
| 3   | <a href="#">6Y88537101</a><br>End of line resistor    | <a href="#">Buy now</a> |
| 4   | <a href="#">68V8258210</a><br>Cap 1 (2p)              | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98258200</a><br>Cap 1 (12p)             | <a href="#">Buy now</a> |
| 6   | <a href="#">6X98258260</a><br>Cap 1 (3p)              | <a href="#">Buy now</a> |
| 7   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)      | <a href="#">Buy now</a> |
| 8   | <a href="#">6X68559041</a><br>Control unit assembly   | <a href="#">Buy now</a> |
| 9   | <a href="#">6X94821100</a><br>Housing,1               | <a href="#">Buy now</a> |
| 10  | <a href="#">9760705212</a><br>Screw,w/washer          | <a href="#">Buy now</a> |
| 11  | <a href="#">9046513M11</a><br>Clamp (6e5)             | <a href="#">Buy now</a> |
| 12  | <a href="#">9016706M00</a><br>Screw, tapping (6h4)    | <a href="#">Buy now</a> |
| 13  | <a href="#">9788006035</a><br>Screw, pan head(6h4)    | <a href="#">Buy now</a> |
| 14  | <a href="#">9578006300</a><br>Nut, nylon (6g1)        | <a href="#">Buy now</a> |
| 15  | <a href="#">9020106M30</a><br>Washer, plate (6a1)     | <a href="#">Buy now</a> |


# Des 1



| Ref | Part                                                                                    |                         |
|-----|-----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X94240100</a><br>Bolt-on des kit                                           | <a href="#">Buy now</a> |
| 2   | <a href="#">6X94240200</a><br>Repair kit, 1                                             | <a href="#">Buy now</a> |
| 3   | <a href="#">6X94240300</a><br>Repair kit, 2                                             | <a href="#">Buy now</a> |
| 4   | <a href="#">6X94240400</a><br>Repair kit, 3                                             | <a href="#">Buy now</a> |
| 5   | <a href="#">6X94240500</a><br>Repair kit, 4                                             | <a href="#">Buy now</a> |
| 6   | <a href="#">6X94240600</a><br>Repair kit, 5                                             | <a href="#">Buy now</a> |
| 7   | <a href="#">6X9438A000</a><br>Steering actuator harness 2.4m<br>UR 2.4M-8FT             | <a href="#">Buy now</a> |
| 7   | <a href="#">6X9438A010</a><br>Steering actuator harness 4.5m<br>UR 4.5M-15FT            | <a href="#">Buy now</a> |
| 7   | <a href="#">6X9438A020</a><br>Steer act harness 2.4m u-shape<br>UR 2.4M-8FT             | <a href="#">Buy now</a> |
| 7   | <a href="#">6X9438A030</a><br>Steer act harness 4.5m u-shape<br>UR 4.5M-15FT            | <a href="#">Buy now</a> |
| 7   | <a href="#">6X9438A040</a><br>Str act harn 2.4m no blkhd fit<br>UR 2.4M-8FT NO BULKHEAD | <a href="#">Buy now</a> |
| 8   | <a href="#">6X94240700</a><br>Repair kit, 6                                             | <a href="#">Buy now</a> |
| 9   | <a href="#">6X94240800</a><br>-<br>EXCEPT FOR 6X9-438A0-40                              | <a href="#">Buy now</a> |




| Ref | Part                                                                                       |                         |
|-----|--------------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98258A90</a><br>Extn.wire harness 2<br>SCU to 16-PIN                         | <a href="#">Buy now</a> |
| 2   | <a href="#">6GR8111500</a><br>Scu link harness p/s 5ft<br>UR PORT/STBD ENGINE              | <a href="#">Buy now</a> |
| 2   | <a href="#">6GR8111510</a><br>Scu link harness p/s 10ft<br>UR PORT/STBD ENGINE             | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98111500</a><br>Scu link harness 0.3m-1ft p/s<br>UR PORT/STBD ENGINE         | <a href="#">Buy now</a> |
| 3   | <a href="#">6Y88537101</a><br>End of line resister                                         | <a href="#">Buy now</a> |
| 4   | <a href="#">6GR8111520</a><br>Scu link harness center 5ft<br>UR CENTER ENGINE              | <a href="#">Buy now</a> |
| 4   | <a href="#">6GR8111530</a><br>Scu link harness center 10ft<br>UR CENTER ENGINE             | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98111510</a><br>Scu link harness 0.3m-1ft (c)<br>UR CENTER ENGINE            | <a href="#">Buy now</a> |
| 5   | <a href="#">6X9615A000</a><br>Compact helm kit                                             | <a href="#">Buy now</a> |
| 6   | <a href="#">6GR615A000</a><br>Helm unit assembly tilt (2)<br>ASK TO MARINE DIV             | <a href="#">Buy now</a> |
| 7   | <a href="#">6GR6154A00</a><br>Tilt Helm Unit (1)<br>ASK TO MARINE DIV                      | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98258AA1</a><br>Helm Harness 0.9M-3Ft<br>SINGLE ENGINE (2ND ST)              | <a href="#">Buy now</a> |
| 10  | <a href="#">6X98258AB1</a><br>Helm harness 2nd station 0.9m<br>MULTIPLE ENGINES (2ND ST)   | <a href="#">Buy now</a> |
| 12  | <a href="#">6X68258A91</a><br>16P Dbw Harness 1.5M-5Ft<br>1.5M-5FT MAIN-HARNESS (16P)      | <a href="#">Buy now</a> |
| 13  | <a href="#">6GR8258A00</a><br>Helm harness (main/single 0.9m<br>UR SINGLE ENGINE (MAIN ST) | <a href="#">Buy now</a> |



| Ref | Part                                                                                          |                         |
|-----|-----------------------------------------------------------------------------------------------|-------------------------|
| 13  | <a href="#">6GR8258A40</a><br>Helm harness (main/single)1.8m<br>UR SINGLE ENGINE (MAIN ST)    | <a href="#">Buy now</a> |
| 14  | <a href="#">6GR8258A10</a><br>Helm harness multi engines 0.9<br>UR MULTIPLE ENGINES (MAIN ST) | <a href="#">Buy now</a> |
| 14  | <a href="#">6GR8258A50</a><br>Helm harness multi engines 1.8<br>UR MULTIPLE ENGINES (MAIN ST) | <a href="#">Buy now</a> |
| 14  | <a href="#">6GR8258A60</a><br>Helm harness multi engines 2.7<br>UR MULTIPLE ENGINES (MAIN ST) | <a href="#">Buy now</a> |


# Immobilizer Kit



6X91100-U180


| Ref | Part                                                                                    |                         |
|-----|-----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98626002</a><br>Remote Control Unit assembly<br>UR RADIO FREQUENCY 433MHz | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98626012</a><br>Remote control unit assembly<br>UR RADIO FREQUENCY 315MHz | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98626100</a><br>Xmtr. comp.<br>FOR 6X9-86260-02                           | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98626110</a><br>Xmtr. Comp.<br>FOR 6X9-86260-12                           | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98626700</a><br>Case complete 1                                           | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98194800</a><br>Bracket                                                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98554601</a><br>Band                                                      | <a href="#">Buy now</a> |
| 6   | <a href="#">6X98250910</a><br>Wire, sub lead                                            | <a href="#">Buy now</a> |
| 7   | <a href="#">7038338311</a><br>Buzzer                                                    | <a href="#">Buy now</a> |
| 8   | <a href="#">9588006016</a><br>Bolt, flange(jl8)                                         | <a href="#">Buy now</a> |

# Joystick And Autopilot




| Ref | Part                                                                           |                         |
|-----|--------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98591T12</a><br>Bcu (ap/joystick single)<br>UR ASK TO MARINE DIV | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98591T22</a><br>Bcu (ap/joystick twin)<br>UR ASK TO MARINE DIV   | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98591T32</a><br>Bcu (ap/joystick triple)<br>UR ASK TO MARINE DIV | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98591T42</a><br>-<br>UR ASK TO MARINE DIV                        | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98591T50</a><br>Bcu (ap/joystick quint)<br>UR ASK TO MARINE DIV  | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98810700</a><br>Gps unit                                         | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98252H00</a><br>Plate, holder                                    | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98255H00</a><br>Holder, socket                                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98A41000</a><br>Sensor unit                                      | <a href="#">Buy now</a> |
| 6   | <a href="#">6YM8355300</a><br>Conversion harness c15-pigtail                   | <a href="#">Buy now</a> |
| 7   | <a href="#">6X98253V00</a><br>Control panel assembly                           | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98257180</a><br>Panel, switch                                    | <a href="#">Buy now</a> |
| 9   | <a href="#">6X92248080</a><br>Seal assembly                                    | <a href="#">Buy now</a> |
| 10  | <a href="#">6X9482A000</a><br>Joystick assembly blue<br>ASK TO MARINE DIV      | <a href="#">Buy now</a> |
| 11  | <a href="#">6X94269700</a><br>Tuning fork mark                                 | <a href="#">Buy now</a> |

# Joystick And Autopilot




| Ref | Part                                                                          |                         |
|-----|-------------------------------------------------------------------------------|-------------------------|
| 12  | <a href="#">6X94815600</a><br>Nut 1                                           | <a href="#">Buy now</a> |
| 13  | <a href="#">6X94823A00</a><br>Packing                                         | <a href="#">Buy now</a> |
| 14  | <a href="#">6X98238601</a><br>Extension wire harness                          | <a href="#">Buy now</a> |
| 15  | <a href="#">68V8258210</a><br>Cap 1 (2p)                                      | <a href="#">Buy now</a> |
| 16  | <a href="#">6X98258220</a><br>Cap 1 (6p)                                      | <a href="#">Buy now</a> |
| 17  | <a href="#">6X98238610</a><br>Extension, wire harness<br>2ND STATION          | <a href="#">Buy now</a> |
| 19  | <a href="#">6X98355310</a><br>Wire, lead<br>6PIN-4PIN (MAIN BUS-PIGTAIL)      | <a href="#">Buy now</a> |
| 20  | <a href="#">6ES8372001</a><br>L.e.d ass'y                                     | <a href="#">Buy now</a> |
| 21  | <a href="#">6X98258620</a><br>Extension prop lights 6m<br>UR 6.1M-20FT        | <a href="#">Buy now</a> |
| 21  | <a href="#">6X98258630</a><br>Extension prop lights 9m<br>UR 9.1M-30FT        | <a href="#">Buy now</a> |
| 21  | <a href="#">6X98258640</a><br>Extension prop lights 12m<br>UR 12.2M-40FT      | <a href="#">Buy now</a> |
| 22  | <a href="#">6X98238620</a><br>Bcu harness (quint/main st)<br>FOR QUINT ENGINE | <a href="#">Buy now</a> |
| 23  | <a href="#">6YG8A2D010</a><br>Gateway<br>FOR OTHER COMPATIBLE MFD             | <a href="#">Buy now</a> |
| 24  | <a href="#">6YG8252100</a><br>Wire, lead                                      | <a href="#">Buy now</a> |
| 25  | <a href="#">6X98258600</a><br>Extension, wire harness<br>UR                   | <a href="#">Buy now</a> |

# Joystick And Autopilot




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 25  | <a href="#">6X98258610</a><br>Extension, wire harness<br>UR | <a href="#">Buy now</a> |

# Mfd Interface




| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YM8A2D010</a><br>Mfd Interface<br>COMPATIBLE GARMIN MFD | <a href="#">Buy now</a> |
| 2   | <a href="#">6YM8395600</a><br>Cap 1                                  | <a href="#">Buy now</a> |
| 3   | <a href="#">6YD8395700</a><br>Cap 2                                  | <a href="#">Buy now</a> |
| 4   | <a href="#">6YM8A2D002</a><br>-<br>OTHER COMPATIBLE MFD WITH Wi-F    | <a href="#">Buy now</a> |
| 7   | <a href="#">6YM8626100</a><br>-<br>FOR 6YM-8A2D0-02 WITH Wi-Fi       | <a href="#">Buy now</a> |
| 8   | <a href="#">6YM8212900</a><br>Cover, Battery                         | <a href="#">Buy now</a> |
| 9   | <a href="#">6YM8432M00</a><br>-                                      | <a href="#">Buy now</a> |
| 10  | <a href="#">6YM60BJ000</a><br>Cradle assembly                        | <a href="#">Buy now</a> |
| 11  | <a href="#">6YM8355310</a><br>Wire, lead                             | <a href="#">Buy now</a> |
| 12  | <a href="#">6YM8356N00</a><br>Wire, lead                             | <a href="#">Buy now</a> |
| 13  | <a href="#">6YM8533A00</a><br>-<br>FOR OTHER COMPATIBLE MFD          | <a href="#">Buy now</a> |
| 14  | <a href="#">6YG8A2D011</a><br>Gateway<br>FOR OTHER COMPATIBLE MFD    | <a href="#">Buy now</a> |

## Switch & Panel 1 (Eks, Single)




| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98257000</a><br>Panel switch assembly<br>MAIN STATION               | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98257100</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6X92248000</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 4   | <a href="#">6X982570B0</a><br>Power sw start/stop 2nd st<br>2ND STATION           | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98257120</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6X92248020</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6X98257070</a><br>Panel switch assembly<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98257170</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6X92248070</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 10  | <a href="#">6828255600</a><br>Lanyard, stop switch                                | <a href="#">Buy now</a> |
| 11  | <a href="#">6X98271621</a><br>Cord switch<br>MAIN STATION                         | <a href="#">Buy now</a> |
| 12  | <a href="#">7038338311</a><br>Buzzer                                              | <a href="#">Buy now</a> |
| 13  | <a href="#">9046513M39</a><br>Clamp(6e8)                                          | <a href="#">Buy now</a> |
| 14  | <a href="#">6X98195000</a><br>Relay assembly                                      | <a href="#">Buy now</a> |
| 15  | <a href="#">6X98271660</a><br>Cord switch<br>2ND STATION                          | <a href="#">Buy now</a> |

## Switch & Panel 2 (Eks, Twin)




| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98257010</a><br>Panel switch assembly<br>MAIN STATION               | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98257110</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6X92248010</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98257080</a><br>Power sw start/stop 2nd st<br>2ND STATION           | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98257120</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6X92248020</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6X98257030</a><br>Twin panel p+s start stop<br>2ND STATION            | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98257130</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6X92248030</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 10  | <a href="#">6X98257080</a><br>Panel switch assembly<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 11  | <a href="#">6X98257170</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 12  | <a href="#">6X92248070</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 13  | <a href="#">6828255600</a><br>Lanyard, stop switch                                | <a href="#">Buy now</a> |
| 14  | <a href="#">6X98271631</a><br>Cord switch<br>MAIN STATION                         | <a href="#">Buy now</a> |
| 15  | <a href="#">7038338311</a><br>Buzzer                                              | <a href="#">Buy now</a> |

## Switch & Panel 2 (Eks, Twin)




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 16  | <a href="#">9046513M39</a><br>Clamp(6e8)                        | <a href="#">Buy now</a> |
| 17  | <a href="#">6X98195000</a><br>Relay assembly                    | <a href="#">Buy now</a> |
| 18  | <a href="#">6X68198000</a><br>Diode assembly                    | <a href="#">Buy now</a> |
| 19  | <a href="#">6X98271671</a><br>Eks harness<br><b>2ND STATION</b> | <a href="#">Buy now</a> |
| 22  | <a href="#">6X68198010</a><br>Diode assembly                    | <a href="#">Buy now</a> |

## Switch & Panel 3 (Eks, Triple)




| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98257000</a><br>Panel switch assembly<br>MAIN STATION               | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98257100</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6X92248000</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98257040</a><br>Panel switch assembly<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98257140</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6X92248040</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6X982570C0</a><br>Panel switch assembly<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98257170</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6X92248070</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 10  | <a href="#">6828255600</a><br>Lanyard, stop switch                                | <a href="#">Buy now</a> |
| 11  | <a href="#">6X982570B0</a><br>Power sw start/stop 2nd st<br>2ND STATION           | <a href="#">Buy now</a> |
| 12  | <a href="#">6X98257120</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 13  | <a href="#">6X92248020</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 14  | <a href="#">6X98271641</a><br>Cord switch<br>MAIN STATION                         | <a href="#">Buy now</a> |
| 15  | <a href="#">7038338311</a><br>Buzzer                                              | <a href="#">Buy now</a> |

## Switch & Panel 3 (Eks, Triple)




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 16  | <a href="#">9046513M39</a><br>Clamp(6e8)                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6X68198010</a><br>Diode assembly             | <a href="#">Buy now</a> |
| 18  | <a href="#">6X68198000</a><br>Diode assembly             | <a href="#">Buy now</a> |
| 19  | <a href="#">6X98195000</a><br>Relay assembly             | <a href="#">Buy now</a> |
| 20  | <a href="#">6X98271680</a><br>Cord switch<br>2ND STATION | <a href="#">Buy now</a> |

## Switch & Panel 4 (Eks, Quad)




| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98257000</a><br>Panel switch assembly<br>MAIN STATION               | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98257100</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6X92248000</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98257050</a><br>Panel switch assembly<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98257150</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6X92248050</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6X982570D0</a><br>Emergency stop switch<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98257170</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6X92248070</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 10  | <a href="#">6828255600</a><br>Lanyard, stop switch                                | <a href="#">Buy now</a> |
| 11  | <a href="#">6X982570B0</a><br>Power sw start/stop 2nd st<br>2ND STATION           | <a href="#">Buy now</a> |
| 12  | <a href="#">6X98257120</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 13  | <a href="#">6X92248020</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 14  | <a href="#">6X98271691</a><br>Cord switch<br>MAIN STATION                         | <a href="#">Buy now</a> |
| 15  | <a href="#">7038338311</a><br>Buzzer                                              | <a href="#">Buy now</a> |

## Switch & Panel 4 (Eks, Quad)




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 16  | <a href="#">9046513M39</a><br>Clamp(6e8)                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6X68198040</a><br>Diode assembly             | <a href="#">Buy now</a> |
| 18  | <a href="#">6X68198000</a><br>Diode assembly             | <a href="#">Buy now</a> |
| 19  | <a href="#">6X98195000</a><br>Relay assembly             | <a href="#">Buy now</a> |
| 20  | <a href="#">6X982716A0</a><br>Cord switch<br>2ND STATION | <a href="#">Buy now</a> |

## Switch & Panel 5 (Eks, Quint)



| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98257000</a><br>Panel switch assembly<br>MAIN STATION               | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98257100</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6X92248000</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98257060</a><br>Panel Switch assembly<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98257160</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6X92248060</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 7   | <a href="#">6X982570D0</a><br>Emergency stop switch<br>MAIN STATION & 2ND STATION | <a href="#">Buy now</a> |
| 8   | <a href="#">6X98257170</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6X92248070</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 10  | <a href="#">6828255600</a><br>Lanyard, stop switch                                | <a href="#">Buy now</a> |
| 11  | <a href="#">6X982570B0</a><br>Power sw start/stop 2nd st<br>2ND STATION           | <a href="#">Buy now</a> |
| 12  | <a href="#">6X98257120</a><br>Panel, switch                                       | <a href="#">Buy now</a> |
| 13  | <a href="#">6X92248020</a><br>Seal assembly                                       | <a href="#">Buy now</a> |
| 14  | <a href="#">6X982716B0</a><br>Eks Harness<br>MAIN STATION                         | <a href="#">Buy now</a> |
| 15  | <a href="#">7038338311</a><br>Buzzer                                              | <a href="#">Buy now</a> |


## Switch & Panel 5 (Eks, Quint)



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 16  | <a href="#">9046513M39</a><br>Clamp(6e8)                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6X68198010</a><br>Diode assembly             | <a href="#">Buy now</a> |
| 18  | <a href="#">6X68198000</a><br>Diode assembly             | <a href="#">Buy now</a> |
| 19  | <a href="#">6X98195000</a><br>Relay assembly             | <a href="#">Buy now</a> |
| 20  | <a href="#">6X982716C0</a><br>Eks Harness<br>2ND STATION | <a href="#">Buy now</a> |


## Switch & Panel 6 (Eks,Key/Rec)

ELECTRONIC KEY SWITCH



| Ref | Part                                                                                    |                         |
|-----|-----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X98626002</a><br>Remote Control Unit assembly<br>UR RADIO FREQUENCY 433MHz | <a href="#">Buy now</a> |
| 1   | <a href="#">6X98626012</a><br>Remote control unit assembly<br>UR RADIO FREQUENCY 315MHz | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98626100</a><br>Xmtr. comp.<br>FOR 6X9-86260-02                           | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98626110</a><br>Xmtr. Comp.<br>FOR 6X9-86260-12                           | <a href="#">Buy now</a> |
| 3   | <a href="#">6X98626700</a><br>Case complete 1                                           | <a href="#">Buy now</a> |
| 4   | <a href="#">6X98194800</a><br>Bracket                                                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6X98554601</a><br>Band                                                      | <a href="#">Buy now</a> |
| 6   | <a href="#">6X98250901</a><br>Wire, sub lead                                            | <a href="#">Buy now</a> |
| 7   | <a href="#">5J8215190</a><br>Fuse (5a)                                                  | <a href="#">Buy now</a> |
| 8   | <a href="#">69J8215B00</a><br>Cap (brown)                                               | <a href="#">Buy now</a> |
| 9   | <a href="#">7038338311</a><br>Buzzer                                                    | <a href="#">Buy now</a> |
| 10  | <a href="#">9588006016</a><br>Bolt, flange(jl8)                                         | <a href="#">Buy now</a> |

# Switch & Panel 7



| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X982570A0</a><br>Battery switch panel<br>YMUS ONLY | <a href="#">Buy now</a> |
| 2   | <a href="#">6X98257120</a><br>Panel, switch                     | <a href="#">Buy now</a> |
| 3   | <a href="#">6X92248020</a><br>Seal assembly                     | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.