



Yamaha Z250FETO 2004

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

| | |
|-------------------------------------|-----|
| BOTTOM COWLING | 3 |
| BRACKET 1 | 8 |
| BRACKET 2 | 11 |
| CONTROL | 14 |
| CRANKSHAFT & PISTON | 19 |
| CYLINDER & CRANKCASE 1 | 22 |
| CYLINDER & CRANKCASE 2 | 26 |
| CYLINDER & CRANKCASE 3 | 28 |
| ELECTRICAL 1 | 30 |
| ELECTRICAL 2 | 33 |
| ELECTRICAL 3 | 35 |
| ELECTRICAL 4 | 39 |
| FUEL 1 | 40 |
| FUEL 2 | 44 |
| FUEL INJECTION NOZZLE | 45 |
| FUEL INJECTION PUMP | 48 |
| FUEL PUMP DRIVE GEAR | 51 |
| GENERATOR | 53 |
| INTAKE | 55 |
| LOWER CASING & DRIVE 1 | 57 |
| LOWER CASING & DRIVE 2 | 64 |
| METER | 66 |
| OIL PUMP | 68 |
| OIL TANK | 72 |
| POWER TRIM & TILT ASSY 1 | 75 |
| POWER TRIM & TILT ASSY 2 | 78 |
| REMOTE CONTROL ASSY | 81 |
| REMOTE CONTROL BOX | 86 |
| REPAIR KIT 1 | 87 |
| REPAIR KIT 2 | 89 |
| STARTING MOTOR | 91 |
| STEERING GUIDE | 94 |
| TOP COWLING | 95 |
| UPPER CASING | 98 |
| VAPOR SEPARATOR 1 | 100 |
| VAPOR SEPARATOR 2 | 104 |


Bottom Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V42710008D Bottom cowling assembly | Buy now |
| 2 | 6E52437700 Pipe, joint | Buy now |
| 3 | 61A4272700 Grommet | Buy now |
| 4 | 68F428280094 Plate, clamp | Buy now |
| 5 | 68F428281094 Plate, clamp | Buy now |
| 6 | 9010906M82 Bolt | Buy now |
| 7 | 60V42815008D Lever Clamp | Buy now |
| 8 | 60V42816008D Lever, clamp | Buy now |
| 9 | 60V42817008D Lever, clamp | Buy now |
| 10 | 68F4281800 Lever, clamp | Buy now |
| 11 | 67F4281800 Lever, clamp | Buy now |
| 12 | 9038615M73 Bush(6l2) | Buy now |
| 13 | 9020615M18 Washer, wave(6l2) | Buy now |
| 14 | 9020106068 Washer,plate (6k8) | Buy now |
| 15 | 9709506016 Bolt, hexagon deep recess | Buy now |


Bottom Cowling



A4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 64D4314400 Hook, spring | Buy now |
| 17 | 9010906M80 Bolt | Buy now |
| 18 | 9050616M34 Spring, tension(64d) | Buy now |
| 19 | 60V4261500 Seal | Buy now |
| 20 | 6E54439100 Nipple, hose | Buy now |
| 21 | 60V4272500 Grommet | Buy now |
| 22 | 60V42738008D Plate, fitting | Buy now |
| 23 | 9010906M81 Bolt | Buy now |
| 24 | 64D42738105B Plate, fitting | Buy now |
| 26 | 9048022M81 Grommet | Buy now |
| 27 | 9038708M37 Coller (6e5) | Buy now |
| 28 | 9020108M54 Washer, plate (6e5) | Buy now |
| 29 | 9707508035 Bolt(70w) | Buy now |
| 30 | 9011908M22 Bolt, with washer | Buy now |
| 31 | 6884272610 Grommet | Buy now |


Bottom Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 32 | 6E58258800 Plate | Buy now |
| 33 | 9589506020 Bolt, flange(jk3) | Buy now |
| 34 | 60V42723005B Cover, bottom | Buy now |
| 35 | 60V42721A0 Gasket 1 | Buy now |
| 36 | 60V4271800 Rubber, seal 3 | Buy now |
| 38 | 60V42741008D Apron | Buy now |
| 39 | 60V4275600 Stay, clamp | Buy now |
| 40 | 9788004016 Screw, with washer(61b) | Buy now |
| 41 | 9299004600 Washer, plain (646) | Buy now |
| 42 | 9011106034 Bolt,hex. socket button | Buy now |
| 43 | 9709506020 Bolt(7u8) | Buy now |
| 44 | 9299506600 Washer, plain (646) | Buy now |
| 45 | 60V1258100 Joint, hose 1 | Buy now |
| 46 | 60V1257600 Hose 1 | Buy now |
| 47 | 60V1258800 Hose 5 | Buy now |


Bottom Cowling



A4

| Ref | Part | |
|-----|--|-------------------------|
| 48 | <u>60X2437600</u> Pipe, joint 1 | Buy now |
| 62 | <u>9046511M10</u> Clamp FLUSHING KIT | Buy now |
| 50 | <u>60V4277100</u> Apron | Buy now |
| 51 | <u>9707508055</u> - | Buy now |
| 52 | <u>9299508600</u> Washer, plain (663) | Buy now |
| 53 | <u>61A4271700</u> Rubber, seal 2 | Buy now |
| 54 | <u>61A4271600</u> Rubber seal 1 | Buy now |
| 55 | <u>60V4277400</u> Stay, Apron 1 | Buy now |
| 56 | <u>9589506016</u> Bolt, flange deep recess | Buy now |
| 57 | <u>6H44272600</u> Grommet | Buy now |
| 58 | <u>6R31257200</u> Adapter FLUSHING KIT | Buy now |
| 59 | <u>9016905M00</u> Screw truss head tapping FLUSHING KIT | Buy now |
| 60 | <u>6R31258000</u> Joint assembly FLUSHING KIT | Buy now |
| 61 | <u>9044511M36</u> Hose (I700) FLUSHING KIT | Buy now |
| 63 | <u>68F4275300</u> Fastner AP | Buy now |


Bottom Cowling



A4

| Ref | Part | |
|-----|--|-------------------------|
| 64 | 9046420258 Clamp AP | Buy now |
| 65 | 68H4279101 Mark 1 | Buy now |
| 66 | 60V2415E60 Label, Caution | Buy now |
| 67 | 6A12817600 Label Caution | Buy now |
| 68 | 6E38257H00 Plate Mark | Buy now |


Bracket 1



B3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 64E43111028D Bracket, clamp | Buy now |
| 2 | 6G54525102 Anode | Buy now |
| 3 | 6G54452600 Plate | Buy now |
| 4 | 9709506030 Bolt(jf7) | Buy now |
| 5 | 9299506100 Washer(6a1) | Buy now |
| 6 | 6E58214800 Wire, lead 5 | Buy now |
| 7 | 9709506010 Bolt | Buy now |
| 8 | 9299506600 Washer, plain (646) | Buy now |
| 9 | 64E43112028D Bracket, clamp | Buy now |
| 11 | 9788006012 Screw, pan head(62j) | Buy now |
| 12 | 9299006600 Washer, plain (646) | Buy now |
| 13 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 14 | 64E4313101 Bolt, clamp bracket | Buy now |
| 15 | 9709508020 Bolt, hexagon | Buy now |
| 16 | 9299508100 Ybs67-8 washer, spring | Buy now |


Bracket 1



B3

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9038625M31 Bushing (6e5) | Buy now |
| 18 | 9020126M59 Washer, plate (6e5) | Buy now |
| 19 | 9018522M11 Nut, self-locking | Buy now |
| 20 | 9046511M10 Clamp | Buy now |
| 21 | 64E43311108D Bracket, swivel | Buy now |
| 22 | 9046508M63 Clamp(61u) | Buy now |
| 24 | 66K8214900 Wire, lead 3 | Buy now |
| 25 | 6G54314400 Hook, spring | Buy now |
| 27 | 6G54318102 Lever, tilt stop 1 | Buy now |
| 28 | 6G54318502 Lever, tilt stop 2 | Buy now |
| 29 | 9038610M16 Bushing (688) | Buy now |
| 30 | 6G54314800 Collar, distance | Buy now |
| 31 | 9038710M05 Collar(6e5) | Buy now |
| 32 | 9169030020 Pin, spring (6h4) | Buy now |
| 33 | 9050616003 Spring, tension | Buy now |


Bracket 1



| Ref | Part | |
|-----|--|-------------------------|
| 34 | 64E4312600 Pin, upper shock mount | Buy now |
| 35 | 9038622M98 Bush(61u) | Buy now |
| 36 | 9341022M11 Circlip(61u) | Buy now |
| 37 | 9010112M05 Bolt (l:130mm) UR | Buy now |
| 37 | 9010112M77 Bolt (l:150mm) UR | Buy now |
| 38 | 9020113M01 Washer, plate(6e5) | Buy now |
| 39 | 9020112M05 Washe, plate(663) | Buy now |
| 40 | 9538012600 Nut (707) | Buy now |
| 41 | 9024906M19 Pin(6e5) | Buy now |

B3


Bracket 2



B5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 64E4313902 Cam, trim sender (with screw) | Buy now |
| 2 | 9778060525 Screw, tapping(65j) | Buy now |
| 3 | 64E8367202 Trim sender | Buy now |
| 4 | 9788506016 Screw, pan head(6b0) | Buy now |
| 5 | 9046511M10 Clamp | Buy now |
| 6 | 9321037MH7 O-ring(61u) | Buy now |
| 7 | 9020240M47 Washer, plate(61a) | Buy now |
| 8 | 64E4337600 Bolt, thrust receiver | Buy now |
| 9 | 9578010300 Nut, nylon (6e5) | Buy now |
| 10 | 66K42510018D Steering bracket assembly | Buy now |
| 11 | 9020138M60 Washer, plate (6e5) | Buy now |
| 12 | 9038638M32 Bush(6e5) | Buy now |
| 13 | 60X44551008D Housing, lower mount rubber | Buy now |
| 14 | 9341037M04 Circlip (6e5) | Buy now |
| 15 | 6E54457500 Damper, lower mount rubber | Buy now |


Bracket 2



B5

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60X445550094 Mount damper, lower side | Buy now |
| 17 | 9020232M19 Washer, plate (6e5) | Buy now |
| 18 | 9020116M55 Washer, plate (6e5) | Buy now |
| 19 | 9010914M80 Bolt | Buy now |
| 20 | 9020115M58 Washer, plate (6e5) | Buy now |
| 21 | 9538014800 Nut, crown (6e5) | Buy now |
| 22 | 9299514600 Washer (6e5) | Buy now |
| 23 | 9010110M70 Bolt(6j9) | Buy now |
| 24 | 60X4455300NA Cover, lower mount | Buy now |
| 25 | 65N43155N0 Mark 1 | Buy now |
| 26 | 65N43156N0 Mark 2 | Buy now |
| 27 | 69J445140094 Mount damper, upper side | Buy now |
| 28 | 9020116M01 Washer, plate(61a) | Buy now |
| 29 | 9020228M46 Washer, plate(61a) | Buy now |
| 30 | 9020128M01 Washer, plate(61a) | Buy now |


Bracket 2



| Ref | Part | |
|-----|--|-------------------------|
| 31 | 9010914M10 Bolt | Buy now |
| 32 | 9018514M00 Nut, self-locking(61a) | Buy now |
| 34 | 61A445110094 Cover, upper mount | Buy now |
| 35 | 9709510045 Bolt(64d) | Buy now |
| 36 | 9299510600 Washer, plate | Buy now |

B5

Control




60V1100-3230

A7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V4853110 - | Buy now |
| 2 | 6634853800 Clamp, cable 1 | Buy now |
| 3 | 9169030010 Pin, spring (663) | Buy now |
| 4 | 9010906M80 Bolt | Buy now |
| 5 | 60V44117001S Bracket | Buy now |
| 6 | 60V4419400 Cap | Buy now |
| 7 | 9709506020 Bolt(7u8) | Buy now |
| 8 | 60V44176001S Bracket | Buy now |
| 9 | 9370006M01 Nipple, grease(61a) | Buy now |
| 10 | 9038612069 Bush(666) | Buy now |
| 11 | 9038708M09 Collar(61a) | Buy now |
| 12 | 9709508035 Bolt(70w) | Buy now |
| 13 | 9299508200 Ybs66-8 washer, plain | Buy now |
| 14 | 9050820M31 Spring, torsion(61a) | Buy now |
| 15 | 61A8259F00 Switch assembly | Buy now |

Control




60V1100-3230

A7

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 61A8258801 Plate | Buy now |
| 17 | 9788504016 Screw, panhead (796) | Buy now |
| 18 | 9299504100 Ybs67-4 washer, spring | Buy now |
| 19 | 60V8259F00 Switch assembly | Buy now |
| 23 | 61A4412100 Lever, shift rod | Buy now |
| 24 | 68J4412201 Bushing, shift rod lever | Buy now |
| 25 | 9020208M20 Washer, plate (6e5) | Buy now |
| 26 | 9046818008 Clip 620436610000 | Buy now |
| 27 | 6E54834400 Cable end, remote control | Buy now |
| 28 | 9020206007 Washer plate 626441880000 | Buy now |
| 29 | 61A44118008D Bracket | Buy now |
| 30 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 31 | 61A4411600 Spring | Buy now |
| 32 | 9709506030 Bolt(jf7) | Buy now |
| 33 | 9299506100 Washer(6a1) | Buy now |

Control




60V1100-3230

A7

| Ref | Part | |
|-----|--|-------------------------|
| 34 | 9299506600 Washer, plain (646) | Buy now |
| 35 | 66K4412000 Handle Gear Shift assembly | Buy now |
| 36 | 9321009165 O-ring | Buy now |
| 37 | 61A4411200 Stay, handle gear shift | Buy now |
| 38 | 9701306012 Bolt(gh1) | Buy now |
| 39 | 9290306100 Washer(6a1) | Buy now |
| 40 | 9290306600 Washer, plain (646) | Buy now |
| 41 | 9531308600 Nut(612) | Buy now |
| 42 | 9038690M90 Bush(61a) | Buy now |
| 43 | 9149020012 Pin, cotter (648) | Buy now |
| 44 | 9020109M02 Washer, plate(61a) | Buy now |
| 45 | 61A1531500 Seal, crankcase | Buy now |
| 46 | 61A4272400 Grommet | Buy now |
| 47 | 61A4413800 Washer | Buy now |
| 48 | 9788506008 Screw, pan head(6a3) | Buy now |

Control




60V1100-3230

A7

| Ref | Part | |
|-----|--|-------------------------|
| 49 | 65L4163201 Lever, magneto control | Buy now |
| 52 | 9701308045 Bolt | Buy now |
| 53 | 9299008200 Ybs66-8 washer, plain | Buy now |
| 54 | 9020612M00 Washer, wave (676) | Buy now |
| 55 | 9038708M16 Collar | Buy now |
| 56 | 61A4123700 Joint, link | Buy now |
| 57 | 9538005600 Nut, hexagon (663) | Buy now |
| 58 | 6H44123700 Joint, link | Buy now |
| 59 | 60V4123000 Cam accelerator comp | Buy now |
| 60 | 9020106M31 Washer (6a0) | Buy now |
| 61 | 9038706M29 Coller (6a0) | Buy now |
| 62 | 9020610M04 Washer, wave (676) | Buy now |
| 63 | 9011906MA4 Bolt, with washer | Buy now |
| 64 | 69L4274400 Stay | Buy now |
| 65 | 9015706006 Screw Pan Head | Buy now |


Control



| Ref | Part | |
|-----|--|-------------------------|
| 66 | 9538006600 Nut(661) | Buy now |
| 67 | 6884419400 Cap | Buy now |
| 68 | 9015905M25 Screw,pan head (646) | Buy now |

A7


Crankshaft & Piston



B1


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D01141100 Crankshaft | Buy now |
| 2 | 61A1144700 Seal, crank | Buy now |
| 3 | 93311940V0 Bearing, cylindrical(61a) | Buy now |
| 4 | 9310240M38 Oil seal(61a) | Buy now |
| 5 | 60V1147900 O-ring | Buy now |
| 6 | 93306209U1 Bearing(61a) | Buy now |
| 7 | 93310959U0 Bearing, cylindrical(61a) | Buy now |
| 8 | 61A1153600 Gear, drive | Buy now |
| 9 | 93306308U0 Bearing(61a) | Buy now |
| 10 | 9341040M03 Circlip(n02) | Buy now |
| 11 | 61A1158601 Pulley, crankshaft balance | Buy now |
| 12 | 60V1155500 Nut, crankshaft 1 | Buy now |
| 13 | 9310422M07 Oil seal(61a) | Buy now |
| 14 | 60V153590094 Housing, oil seal | Buy now |
| 15 | 9310240010 Oil seal | Buy now |

Crankshaft & Piston



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9342061M07 Circlip(61a) | Buy now |
| 17 | 60V1535300 Gasket, drain | Buy now |
| 18 | 9709506020 Bolt(7u8) | Buy now |
| 19 | 9299506100 Washer(6a1) | Buy now |
| 20 | 60V116310185 Piston (Std) | Buy now |
| 20 | 60V1163501 Piston (0.25Mm O/S) AP | Buy now |
| 20 | 60V1163601 Piston (0.50 o/s) AP | Buy now |
| 21 | 60V1160300 Piston ring set (std) | Buy now |
| 21 | 60V1160400 Piston ring set (0.25mm o/s) AP | Buy now |
| 21 | 60V1160500 Piston ring set (0.50mm o/s) AP | Buy now |
| 22 | 60V116420185 Piston 2 (std) | Buy now |
| 22 | 60V1164501 Piston 2 (0.25mm o/s) AP | Buy now |
| 22 | 60V1164601 Piston 2 (0.50mm o/s) AP | Buy now |
| 24 | 61A1163302 Pin, piston | Buy now |
| 25 | 60X1163400 Clip, piston pin | Buy now |

Crankshaft & Piston




60V1010-3030

| Ref | Part | |
|-----|---|-------------------------|
| 26 | 69L1165000 Connecting Rod assembly | Buy now |
| 27 | 9010909001 Bolt | Buy now |
| 28 | 9331032657 Bearing | Buy now |
| 29 | 9020126M03 Washer, plate(61a) | Buy now |
| 30 | 9331084106 Bearing | Buy now |

B1


Cylinder & Crankcase 1



A6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60XW0090111S Crank cylinder assembly | Buy now |
| 2 | 60X15100011S Crankcase assembly | Buy now |
| 3 | 6E51137201 Nipple, hose | Buy now |
| 4 | 6241448500 Pipe, joint | Buy now |
| 5 | 60V1137000 Check valve assembly | Buy now |
| 6 | 9038406M07 Bush, bimetal formed(6r3) | Buy now |
| 7 | 9038316M01 Bush, formed(61a) | Buy now |
| 8 | 6501137001 Check valve assembly | Buy now |
| 9 | 60V1137010 Check valve assembly | Buy now |
| 10 | 9011608012 Bolt, stud | Buy now |
| 11 | 6631151801 Lock, bearing | Buy now |
| 12 | 9034014M00 Plug, straight screw(62y) | Buy now |
| 13 | 9043014115 Gasket (663) | Buy now |
| 14 | 9360812063 Pin, dowel (626) | Buy now |
| 15 | 9044507M10 Hose (L770) | Buy now |


Cylinder & Crankcase 1



A6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9046807M02 Clip (6e5) | Buy now |
| 17 | 9751310590 Bolt, with washer | Buy now |
| 18 | 9011910M11 Bolt With Washer | Buy now |
| 19 | 9011906089 Bolt, with washer | Buy now |
| 20 | 9044507M03 Hose (l200) | Buy now |
| 21 | 9044507016 Hose (l60) | Buy now |
| 22 | 9044507M29 Hose (l200) | Buy now |
| 23 | 9044507MA6 Hose (l200) | Buy now |
| 24 | 6E02437800 Pipe, joint | Buy now |
| 25 | 6G51258100 Joint, hose | Buy now |
| 26 | 60V1132501 Anode | Buy now |
| 27 | 66M1132800 Grommet, anode | Buy now |
| 28 | 66M113270094 Cover, anode | Buy now |
| 29 | 66M1253500 Plate | Buy now |
| 30 | 9709505012 Bolt, hexagon | Buy now |


Cylinder & Crankcase 1



A6

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 9299505600 Washer, plain (646) | Buy now |
| 32 | 9701306020 Bolt(62y) | Buy now |
| 33 | 9290306600 Washer, plain (646) | Buy now |
| 34 | 60V113710094 Cover | Buy now |
| 35 | 60V2413500 Clamp 1 | Buy now |
| 36 | 9701305012 Bolt, hexagon | Buy now |
| 37 | 9290305600 Washer, plain (646) | Buy now |
| 38 | 60V1138100 Gasket 1 | Buy now |
| 39 | 9011906MA2 Bolt, with washer | Buy now |
| 40 | 60V1241100 Thermostat | Buy now |
| 41 | 60V12413001S Cover Thermostat | Buy now |
| 42 | 60V12414A0 Gasket, cover | Buy now |
| 43 | 9948006012 Pin | Buy now |
| 44 | 9011906055 Bolt, with washer | Buy now |
| 45 | 66M1132500 Anode | Buy now |


Cylinder & Crankcase 1




A6

| Ref | Part | |
|-----|--|-------------------------|
| 52 | 6E542761001S Stopper | Buy now |
| 54 | 68F4453300 Damper, upper mount rubber | Buy now |

Cylinder & Crankcase 2



Cylinder & Crankcase 2




60V1010-3040

B3

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V1119300 Gasket, head cover 1 | Buy now |
| 17 | 9011906MA4 Bolt, with washer | Buy now |
| 18 | 68F8391900 Clamp, harness | Buy now |
| 19 | 9959010114 Pin, dowel | Buy now |
| 20 | 9011908MA5 Bolt, with washer | Buy now |
| 21 | 9011908MA8 Bolt, with washer | Buy now |
| 22 | 60V1118100 Gasket, cylinder head 1 | Buy now |
| 23 | 60V11121001S Head, cylinder 2 | Buy now |
| 35 | 69J1111E00 Hanger, engine 2 | Buy now |
| 37 | 60V11192001S Cover, cylinder head 2 | Buy now |
| 45 | 9470200405 Plug, spark (bkr6eku) | Buy now |


Cylinder & Crankcase 3



B5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V411130094 Outer cover, exhaust | Buy now |
| 2 | 6761137200 Nipple, hose | Buy now |
| 3 | 60V4111200 Gasket, exhaust inner cover | Buy now |
| 4 | 60V4126700 Bushing, joint | Buy now |
| 5 | 9011906MA3 Bolt, with washer | Buy now |
| 6 | 60V113270094 Anode cover assembly | Buy now |
| 7 | 67F1132500 Anode | Buy now |
| 8 | 9707506020 Bolt(7u8) | Buy now |
| 9 | 9299506600 Washer, plain (646) | Buy now |
| 10 | 67F1132800 Grommet, anode | Buy now |
| 11 | 9707508030 Bolt, hexagon (fj1) | Buy now |
| 12 | 9299508600 Washer, plain (663) | Buy now |
| 13 | 9046708004 Clip, pipe 6162435600 | Buy now |
| 14 | 6G51241600 Valve, pressure control | Buy now |
| 15 | 9050116M11 Spring, compression (688) | Buy now |


Cylinder & Crankcase 3



B5

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9048020M05 Grommet (688) | Buy now |
| 17 | 60V11382A0 Gasket 2 | Buy now |
| 18 | 6G511372001S Cover, bypass 2 | Buy now |
| 19 | 9011906MA2 Bolt, with washer | Buy now |
| 20 | 61A1257600 Hose 1 | Buy now |
| 21 | 9046513M18 Clamp | Buy now |


Electrical 1



E5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V855420194 Bracket | Buy now |
| 2 | 60V8556400 Grommet | Buy now |
| 3 | 68F8612900 Collar | Buy now |
| 4 | 68F8612910 Collar | Buy now |
| 5 | 68F8511900 Bolt | Buy now |
| 6 | 60X8591A01 Engine Control Unit assembly | Buy now |
| 7 | 9011906MA3 Bolt, with washer | Buy now |
| 8 | 60V8554800 Holder | Buy now |
| 9 | 9701306014 Bolt(gj3) | Buy now |
| 10 | 9290306600 Washer, plain (646) | Buy now |
| 11 | 60V8591B00 Driver, injector assembly | Buy now |
| 12 | 9011906MA2 Bolt, with washer | Buy now |
| 13 | 6E58251900 Wire, Earth Lead | Buy now |
| 14 | 9709506012 Bolt(gh1) | Buy now |
| 15 | 9299506600 Washer, plain (646) | Buy now |


Electrical 1



E5

| Ref | Part | |
|-----|--|-------------------------|
| 18 | 60V8231000 Ignition coil assembly | Buy now |
| 19 | 9048025161 Grommet(656) | Buy now |
| 20 | 9044610M01 Tube (6e5) | Buy now |
| 21 | 60V8231010 Ignition coil assembly | Buy now |
| 22 | 9046418003 Clamp | Buy now |
| 23 | 9048022M15 Grommet (6e5) | Buy now |
| 24 | 9046511M10 Clamp | Buy now |
| 25 | 9701305020 Bolt, hexagon | Buy now |
| 26 | 9290305600 Washer, plain (646) | Buy now |
| 27 | 68F8237001 Plug cap assembly | Buy now |
| 28 | 60V8231400 Cover Ignition Coil | Buy now |
| 29 | 60V2419800 Seat, Rubber | Buy now |
| 30 | 60V2419810 Seat, Rubber | Buy now |
| 31 | 60V8818D00 Seat 1 | Buy now |
| 32 | 60V8818D10 Seat 1 | Buy now |


Electrical 1



| Ref | Part | |
|-----|---|-------------------------|
| 33 | 60V2311600 Seat 2 | Buy now |
| 34 | 60V2311610 Seat 2 | Buy now |
| 35 | 60V2318U00 Plate, Seat | Buy now |
| 36 | 60V2318U10 Plate, Seat | Buy now |
| 37 | 68F8551601 Spacer | Buy now |
| 40 | 6A08231700 Damper, ignition coil | Buy now |
| 41 | 6244254200 Collar | Buy now |
| 42 | 9011906M65 Bolt, with washer | Buy now |
| 43 | 60V8252U00 Cover | Buy now |
| 44 | 60V2311500 Seat 1 | Buy now |
| 45 | 9011106034 Bolt, hex. socket button | Buy now |
| 46 | 68V8195000 Relay assembly | Buy now |
| 47 | 9709506016 Bolt, hexagon deep recess | Buy now |

E5


Electrical 2




E7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9044707011 Hose, with spring | Buy now |
| 2 | 9046511M10 Clamp | Buy now |
| 3 | 61A8194900 Wire, lead | Buy now |
| 4 | 9709506012 Bolt(gh1) | Buy now |
| 5 | 9299506600 Washer, plain (646) | Buy now |
| 6 | 60X8210500 Battery cable | Buy now |
| 7 | 9533308600 Nut(6l2) | Buy now |
| 8 | 9290308100 Ybs67-8 washer, spring | Buy now |
| 9 | 6E58253110 Wire, lead | Buy now |
| 10 | 60V8259030 Wire Harness assembly | Buy now |
| 13 | 9046511M52 Clamp(6e7) | Buy now |
| 14 | 60V8259M00 Wire Harness assembly 2 | Buy now |
| 15 | 9046505M87 Clamp | Buy now |
| 17 | 9046411008 Clamp | Buy now |
| 19 | 69J8256300 Trim & tilt switch assembly | Buy now |

Electrical 2




| Ref | Part | |
|-----|---|-------------------------|
| 20 | 69J8258700 Gasket | Buy now |
| 21 | 69J4272300 Cover, Bottom | Buy now |
| 22 | 60V8361400 Bracket | Buy now |
| 23 | 60V8361410 Bracket | Buy now |
| 24 | 60V8363510 Bracket | Buy now |
| 25 | 9046420213 Clamp(4kj) | Buy now |
| 26 | 9709506014 Bolt(gj3) | Buy now |
| 27 | 9010906M86 Bolt | Buy now |
| 28 | 60V8361800 Plate | Buy now |
| 29 | 68F8363400 Grommet | Buy now |
| 30 | 67H8238000 Sensor, pressure | Buy now |
| 31 | 9858006520 Screw pan head | Buy now |
| 32 | 6E58258800 Plate | Buy now |
| 33 | 9589506020 Bolt, flange(jk3) | Buy now |



F2


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V8196001 Rectifier & regulator assembly | Buy now |
| 2 | 60V81975A0 Plate, rectifier fitting | Buy now |
| 3 | 60V81972001S Cover, rectifier | Buy now |
| 4 | 9011906MA3 Bolt, with washer | Buy now |
| 5 | 9011906MA4 Bolt, with washer | Buy now |
| 6 | 9044509M25 Hose (I1500) | Buy now |
| 7 | 9046708M18 Clip | Buy now |
| 8 | 6L28259901 Cover, connecter | Buy now |
| 9 | 9044710004 Hose, With Spring | Buy now |
| 10 | 60V8194800 Bracket | Buy now |
| 11 | 68F8511900 Bolt | Buy now |
| 12 | 9011906M65 Bolt, with washer | Buy now |
| 13 | 68F8551601 Spacer | Buy now |
| 14 | 68F8612900 Collar | Buy now |
| 15 | 6A08231700 Damper, ignition coil | Buy now |

Electrical 3




F2

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6244254200 Collar | Buy now |
| 17 | 60V8714900 Connector | Buy now |
| 18 | 9709506012 Bolt(gh1) | Buy now |
| 19 | 9299506600 Washer, plain (646) | Buy now |
| 20 | 60V8195000 Relay assembly | Buy now |
| 22 | 6828211901 Cover, lead wire | Buy now |
| 23 | 9709506010 Bolt | Buy now |
| 24 | 9299506100 Washer(6a1) | Buy now |
| 26 | 68V8194A00 Relay | Buy now |
| 27 | 68F8211700 Wire, lead | Buy now |
| 32 | 68V8195300 Stay, relay | Buy now |
| 33 | 9778060620 Screw, tapping(6k8) | Buy now |
| 34 | 9046423199 Clamp(4hm) | Buy now |
| 35 | 60V8217000 Fuse box assembly Go to P/N) PE0-OM-070041 | Buy now |
| 36 | 60V8215100 Fuse (100A) Go to P/N) PE0-OM-070041 | Buy now |




F2

| Ref | Part | |
|-----|--|-------------------------|
| 37 | 68F8195A00 Relay assembly | Buy now |
| 38 | 67F8215100 Fuse | Buy now |
| 39 | 67F8215110 Fuse | Buy now |
| 40 | 68F8284600 Screw, pan head (m5) | Buy now |
| 41 | 9778050620 Screw, tapping | Buy now |
| 42 | 60V8554400 Case | Buy now |
| 43 | 67F2812A00 Puller, fuse | Buy now |
| 44 | 60V8215700 Damper | Buy now |
| 45 | 60V8133600 Grommet | Buy now |
| 46 | 60V8133610 Grommet | Buy now |
| 47 | 60V8112800 Clamp | Buy now |
| 49 | 60V8194210 Cover | Buy now |
| 50 | 9046408004 Clamp | Buy now |
| 51 | 60V8217600 Damper | Buy now |
| 53 | 9016905M00 Screw truss head tapping | Buy now |



F2

| Ref | Part | |
|-----|---|-------------------------|
| 54 | 65L8588600 Thermosensor | Buy now |
| 55 | 60V8555300 Nut Rotor | Buy now |
| 56 | 9020112M34 Washer (692) | Buy now |
| 57 | 60V8191900 Graphic, Regulator Go to P/N) PEO-OM-070041 | Buy now |
| 58 | 60V8191910 Graphic, regulator | Buy now |
| 59 | 69J8194900 Wire, lead (isolator, 3.8m) AP | Buy now |




60V1010-3190

F5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V8258800 Plate | Buy now |
| 2 | 9709506012 Bolt(gh1) | Buy now |
| 3 | 9299506600 Washer, plain (646) | Buy now |
| 4 | 61A8579000 Thermosensor assembly | Buy now |
| 5 | 9299010600 Washer, plate | Buy now |
| 6 | 61A8589500 Crank position sender | Buy now |
| 7 | 9788505012 Screw,pan head (646) | Buy now |
| 8 | 6888256010 Thermo switch assembly | Buy now |
| 9 | 9044610M87 Hose | Buy now |


Fuel 1



D7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 61A2431300 Pipe 3 | Buy now |
| 2 | 9046413M34 Clamp(6r3) | Buy now |
| 3 | 9044513M17 Hose(l2700) | Buy now |
| 4 | 6R32437700 Pipe, joint 3 | Buy now |
| 5 | 6E58259400 Clamp | Buy now |
| 6 | 9046511M10 Clamp | Buy now |
| 7 | 68F2456010 Filter assembly | Buy now |
| 8 | 68F2456210 Cup, filter | Buy now |
| 9 | 68F2451910 Clip | Buy now |
| 10 | 68F2446910 Float Water Level | Buy now |
| 11 | 65L2453101 Nut | Buy now |
| 12 | 61A2456400 O-ring | Buy now |
| 13 | 68F2456310 Element, filter | Buy now |
| 14 | 65L2456400 Gasket | Buy now |
| 15 | 60H2455800 Holder, filter | Buy now |


Fuel 1



D7

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9759506416 Bolt, with washer(62x) | Buy now |
| 17 | 9020106068 Washer,plate (6k8) | Buy now |
| 18 | 68F2456600 Bracket, filter | Buy now |
| 19 | 9759506514 Bolt(gj3) | Buy now |
| 20 | 9038706M60 Collar (6h3) | Buy now |
| 21 | 9048010M23 Grommet(6k7) | Buy now |
| 22 | 9011906M88 Bolt, with washer | Buy now |
| 23 | 68F2431100 Pipe, Fuel 1 | Buy now |
| 25 | 6E52437800 Pipe, joint 3 | Buy now |
| 26 | 6G52431500 Pipe 5 | Buy now |
| 27 | 9044719004 Hose, with spring | Buy now |
| 28 | 6E52431500 Pipe 5 | Buy now |
| 29 | 6E52441003 Fuel pump assembly | Buy now |
| 30 | 6E52444400 Screw | Buy now |
| 31 | 6E52441300 Body 2 | Buy now |


Fuel 1



D7

| Ref | Part | |
|-----|---|-------------------------|
| 32 | 6E52447100 Diaphragm | Buy now |
| 33 | 6E52443500 Gasket, body 2 | Buy now |
| 34 | 6E52441100 Diaphragm | Buy now |
| 35 | 6482442400 Seat,spring | Buy now |
| 36 | 6E52442300 Spring, diaphragm | Buy now |
| 37 | 6E52443402 Gasket, body | Buy now |
| 38 | 6A02442101 Valve, check | Buy now |
| 39 | 6A01432500 Screw, pan head | Buy now |
| 40 | 9538003600 Nut (6g8) | Buy now |
| 41 | 6E52441210 Body 1 | Buy now |
| 42 | 65024431A0 Gasket,fuel pump | Buy now |
| 43 | 9010106M00 Bolt(682) | Buy now |
| 44 | 6G52431610 Pipe 6 | Buy now |
| 45 | 6E52431300 Pipe 3 | Buy now |
| 48 | 65L8355700 Tube | Buy now |

Fuel 1




D7

| Ref | Part | |
|-----|---|-------------------------|
| 49 | 9044615M07 Hose(6g4) | Buy now |
| 50 | 9044513M12 Hose (L235) | Buy now |
| 51 | 61H2819R31 Tag Warning | Buy now |
| 52 | 68F2810000 Tool kit | Buy now |
| 53 | 60V2819972A0 Om z250d/lz250d/z250f '04 UR (E,F,S) | Buy now |
| 53 | 60V2819972B0 Om z250deto, '04 UR (D,NL,I) | Buy now |
| 54 | 60V2819982A0 Om z250deto, '04 UR (DK,P,GR) | Buy now |
| 54 | 60V2819982B0 Om z250d/lz250d UR (N,S,SS) | Buy now |

Fuel 2


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6YK2430742 Fuel pipe comp. 2 AP | Buy now |
| 2 | 9045010M07 Hose, clamp AP | Buy now |



60X1300-3150

E3


Fuel Injection Nozzle



C6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68F1376700 Cap, injector | Buy now |
| 2 | 9011908M60 Bolt (682) | Buy now |
| 3 | 60V1378200 Stay | Buy now |
| 4 | 9038708M31 Collar | Buy now |
| 5 | 9011008M04 Bolt, hexagon socket head | Buy now |
| 6 | 60V1316100 Pipe Delivery 1 | Buy now |
| 7 | 60V1317100 Pipe Delivery 2 | Buy now |
| 8 | 60V1389800 Holder | Buy now |
| 9 | 68F2455100 Bolt, joint | Buy now |
| 10 | 68F2457600 Washer | Buy now |
| 11 | 60V1376100 Injector assembly | Buy now |
| 12 | 68F1410B00 Packing kit | Buy now |
| 13 | 60V1426400 Collar | Buy now |
| 14 | 65L1456500 Screw | Buy now |
| 15 | 60V8238900 Plate 2 | Buy now |


Fuel Injection Nozzle



C6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 60V8239800 Plate 3 | Buy now |
| 17 | 60V8154500 Screw 1 | Buy now |
| 18 | 60V8154600 Screw 2 | Buy now |
| 19 | 60V8238000 Sensor Pressure | Buy now |
| 20 | 68F8238800 Plate | Buy now |
| 21 | 68F8238400 Packing kit | Buy now |
| 22 | 60V1393800 Pipe | Buy now |
| 23 | 60V1397300 Pipe, fuel 3 | Buy now |
| 24 | 68F2466A00 Packing kit | Buy now |
| 25 | 60V1397400 Pipe, fuel 4 | Buy now |
| 27 | 65L1459600 Washer | Buy now |
| 28 | 9048010M23 Grommet(6k7) | Buy now |
| 29 | 9038705M00 Collar(6k7) | Buy now |
| 30 | 60V1397500 Pipe Fuel 5 | Buy now |
| 32 | 60V1397600 Pipe, fuel 6 | Buy now |


Fuel Injection Nozzle



C6

| Ref | Part | |
|-----|---|-------------------------|
| 34 | 68F1376400 Gasket (t=2.2) | Buy now |
| 35 | 9751308570 Bolt, with washer | Buy now |
| 36 | 9701308090 Bolt, with washer | Buy now |
| 37 | 9290308600 Washer, plain (663) | Buy now |
| 38 | 60V1371600 Collar | Buy now |
| 39 | 9701308055 Bolt, hexagon | Buy now |
| 42 | 9044722004 Hose, with spring | Buy now |
| 43 | 9044715001 Hose, with spring | Buy now |


Fuel Injection Pump



C4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1217000 Camshaft assembly 1 | Buy now |
| 2 | 60V1242400 Plate, Cartridge Inner | Buy now |
| 3 | 9330600001 Brg,r-b 6000 26mm 19g ky | Buy now |
| 4 | 68F1217300 Cap, camshaft 1 | Buy now |
| 5 | 93306001U0 Bearing | Buy now |
| 6 | 68F12222300 Seal | Buy now |
| 7 | 68F1243900 O-ring | Buy now |
| 8 | 60V1217100 Camshaft 1 | Buy now |
| 9 | 68F12222800 Bolt | Buy now |
| 10 | 68F1345500 Plug | Buy now |
| 11 | 68F1347300 O-ring | Buy now |
| 13 | 60V1399300 Cover, control rack | Buy now |
| 14 | 60W1399300 Cover Control Rack | Buy now |
| 15 | 65L1456500 Screw | Buy now |
| 16 | 68F2457900 Washer 2 | Buy now |


Fuel Injection Pump



C4

| Ref | Part | |
|-----|--|-------------------------|
| 17 | 60V1385400 Plate 4 | Buy now |
| 18 | 60V1391000 Fuel Pump assembly | Buy now |
| 19 | 60V1400500 Ring, seal | Buy now |
| 20 | 60V1412600 Gasket | Buy now |
| 21 | 68F2430000 Fuel pipe joint | Buy now |
| 22 | 60V2417800 Bolt 3 | Buy now |
| 23 | 60V2417600 Bolt 1 | Buy now |
| 24 | 60V2437800 Pipe Joint 4 | Buy now |
| 25 | 60V2486400 Tube | Buy now |
| 26 | 60V2510T00 Tube | Buy now |
| 27 | 68F1381500 Joint 1 | Buy now |
| 28 | 68F2466A00 Packing kit | Buy now |
| 29 | 60V1381600 Joint 2 | Buy now |
| 30 | 68F2448600 O-ring | Buy now |
| 32 | 60V1350500 Joint Comp. | Buy now |


Fuel Injection Pump



| Ref | Part | |
|-----|--|-------------------------|
| 34 | 60V1347300 Seal | Buy now |
| 35 | 60V1414800 Pipe | Buy now |
| 36 | 65L2438700 Clip | Buy now |
| 37 | 60V2431200 Pipe 2 | Buy now |
| 38 | 68F2435600 Clip, pipe 1 | Buy now |
| 39 | 60V2431300 Pipe 3 | Buy now |
| 41 | 60V1414900 Pipe | Buy now |
| 43 | 60V2431400 Pipe 4 | Buy now |
| 45 | 60V2431500 Pipe 5 | Buy now |
| 47 | 60V1397200 Pipe, fuel 2 | Buy now |

C4


Fuel Pump Drive Gear



B6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V115980094 Bracket, tensioner | Buy now |
| 2 | 9701308055 Bolt, hexagon | Buy now |
| 3 | 9290308600 Washer, plain (663) | Buy now |
| 4 | 60V1159000 Tensioner assembly | Buy now |
| 5 | 9011910M72 Bolt, with washer(6m6) | Buy now |
| 6 | 60V1211300 Spring Valve Inner | Buy now |
| 7 | 9044515002 Hose (l30) | Buy now |
| 8 | 60V1159500 Plate, valve | Buy now |
| 9 | 9701308012 Bolt(62e) | Buy now |
| 10 | 60V4624100 Belt | Buy now |
| 11 | 68F115790194 Coupling, flywheel | Buy now |
| 13 | 68F115360094 Gear, drive | Buy now |
| 14 | 9360510108 Pin, dowel (8g8) | Buy now |
| 15 | 60V1155700 Washer 1 | Buy now |
| 16 | 9020108M00 Washer, plate(6e0) | Buy now |

Fuel Pump Drive Gear




60V2100-C060

B6

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9709508025 Bolt (62g) | Buy now |
| 18 | 68F115370094 Gear, driven | Buy now |
| 19 | 9028003M01 Key woodruff 146115450000 | Buy now |
| 20 | 9570708600 Nut, flange(jn5) | Buy now |


Generator



E4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V8145000 Rotor assembly | Buy now |
| 2 | 60V8141001 Stator assembly | Buy now |
| 3 | 60V8558000 Coil, pulser | Buy now |
| 4 | 61A8372100 Cover | Buy now |
| 5 | 9701306035 Bolt(3rv) | Buy now |
| 6 | 9290306100 Washer(6a1) | Buy now |
| 7 | 9290306600 Washer, plain (646) | Buy now |
| 8 | 9788505030 Ybs86-530 screw,panhead | Buy now |
| 9 | 9299505100 Ybs67-5 washer, spring | Buy now |
| 10 | 9299505600 Washer, plain (646) | Buy now |
| 11 | 9028005015 Key, woodruff | Buy now |
| 12 | 9017024M22 Nut(61a) | Buy now |
| 13 | 9020125M02 Washer, plate(61a) | Buy now |
| 14 | 60V8133200 Plate Timing | Buy now |
| 15 | 9788506010 Screw pan head | Buy now |


Generator



E4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9299506600 Washer, plain (646) | Buy now |
| 17 | 9046506M86 Clamp | Buy now |
| 18 | 60V8133700 Cover, flywheel | Buy now |
| 19 | 6638231701 Damper, ignition coil | Buy now |
| 20 | 6244254200 Collar | Buy now |
| 21 | 6A08231700 Damper, ignition coil | Buy now |
| 22 | 9589506030 Bolt, flange deep recess | Buy now |
| 23 | 60V1448800 Label, caution | Buy now |
| 24 | 6A18362551 Mark 5 | Buy now |
| 25 | 6A18362541 Mark 5 | Buy now |
| 26 | 6E58571160 Mark Caution | Buy now |


Intake



D1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1361000 Reed valve assembly | Buy now |
| 2 | 60VW000400 Reed set | Buy now |
| 3 | 60V13621A0 Gasket, Valve Seat | Buy now |
| 4 | 9788005016 Screw, pan head(6b0) | Buy now |
| 5 | 9299005600 Washer, plain (646) | Buy now |
| 6 | 60V13624001S Plate Reed Valve | Buy now |
| 7 | 60V1355200 Nozzle | Buy now |
| 8 | 60V1357200 Nozzle | Buy now |
| 9 | 60V1137900 Valve, check | Buy now |
| 10 | 6F61137001 Check valve assembly | Buy now |
| 11 | 9044507M03 Hose (I200) | Buy now |
| 12 | 9044507016 Hose (I60) | Buy now |
| 13 | 9044507015 Hose (I65) | Buy now |
| 14 | 60V1136900 Valve Check | Buy now |
| 15 | 6501137001 Check valve assembly | Buy now |


Intake



D1


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9010506028 Bolt, washer based | Buy now |
| 17 | 60V1364600 Gasket, manifold 2 | Buy now |
| 18 | 60V1364500 Gasket, manifold 1 | Buy now |
| 19 | 9701306060 Bolt, hexagon | Buy now |
| 20 | 9290306600 Washer, plain (646) | Buy now |
| 21 | 9567006660 Bolt, stud | Buy now |
| 22 | 9017906M24 Nut(6j8) | Buy now |
| 23 | 60V1444000 Silencer assembly, intake | Buy now |
| 24 | 60V1447600 Seal | Buy now |
| 25 | 9044507M44 Hose (i390) | Buy now |
| 26 | 9015906M16 Screw, with washer(61a) | Buy now |
| 27 | 68F1111900 Hanger, engine | Buy now |
| 28 | 9011906MA2 Bolt, with washer | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60X4530010NA Lower unit assembly | Buy now |
| 2 | 60X4531100NA Casing, lower | Buy now |
| 3 | 9331183280 Ball bearing | Buy now |
| 4 | 93332000W1 Bearing(61a) | Buy now |
| 5 | 61A455670010 Shim (t:0.10mm) UR | Buy now |
| 5 | 61A455670012 Shim (t:0.12mm) UR | Buy now |
| 5 | 61A455670015 Shim (t:0.15mm) UR | Buy now |
| 5 | 61A455670018 Shim (t:0.18mm) UR | Buy now |
| 5 | 61A455670030 Shim (t:0.30mm) UR | Buy now |
| 5 | 61A455670040 Shim (t:0.40mm) UR | Buy now |
| 5 | 61A455670050 Shim (t:0.50mm) UR | Buy now |
| 6 | 6634436600 Damper, water seal 2 | Buy now |
| 7 | 9034008002 Plug, straight screw | Buy now |
| 8 | 6884534110 Plug, drain | Buy now |
| 9 | 9043008020 Gasket | Buy now |


Lower Casing & Drive 1



C6

| Ref | Part | |
|-----|---|-------------------------|
| 10 | 61A453760094 Guide, seal damper | Buy now |
| 11 | 65N4532100 Plate | Buy now |
| 12 | 9321033M49 O-ring(6l5) | Buy now |
| 13 | 9310609014 Oil seal | Buy now |
| 14 | 60X4431200 Cover, water pump housing | Buy now |
| 15 | 9709508030 Bolt, hexagon (fj1) | Buy now |
| 16 | 9299508600 Washer, plain (663) | Buy now |
| 17 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 18 | 9299506600 Washer, plain (646) | Buy now |
| 19 | 60X4415000 Shift cam assembly | Buy now |
| 20 | 9900108600 Circlip(2r6) | Buy now |
| 21 | 9050111M10 Spring, compression (663) | Buy now |
| 22 | 61A4431101 Housing, water pump | Buy now |
| 23 | 61A4432202 Insert, cartridge | Buy now |
| 24 | 9321086M38 O-ring (6e5) | Buy now |


Lower Casing & Drive 1



C6


| Ref | Part | |
|-----|---|-------------------------|
| 25 | 9321037160 O-ring (6g8) | Buy now |
| 26 | 6E54436500 Damper, water seal 1 | Buy now |
| 27 | 6E54431200 Cover, water pump housing | Buy now |
| 28 | 6E54435201 Impeller | Buy now |
| 29 | 9028004M05 Key, woodruff (6e5) | Buy now |
| 30 | 61A4553800 Spacer, 1 | Buy now |
| 31 | 61A4552700 Collar, drive shaft | Buy now |
| 32 | 9020122M01 Washer, plate(61a) | Buy now |
| 33 | 9020622M19 Washer, wave(61a) | Buy now |
| 34 | 60X4432300 Outer plate, cartridge | Buy now |
| 35 | 60X44315A0 Gasket, water pump | Buy now |
| 36 | 9360612019 Pin, dowel (614) | Buy now |
| 37 | 9011908M14 Bolt, with washer | Buy now |
| 38 | 61A453310094 Housing, bearing | Buy now |
| 39 | 9310128M16 Oil seal (6e5) | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|--|-------------------------|
| 40 | 93317330U2 Bearing, cylindrical(6k0) | Buy now |
| 41 | 61A455870010 Shim (t:0.10mm) UR | Buy now |
| 41 | 61A455870012 Shim (t:0.12mm) UR | Buy now |
| 41 | 61A455870015 Shim (t:0.15mm) UR | Buy now |
| 41 | 61A455870018 Shim (t:0.18mm) UR | Buy now |
| 41 | 61A455870030 Shim (t:0.30mm) UR | Buy now |
| 41 | 61A455870040 Shim (t:0.40mm) UR | Buy now |
| 41 | 61A455870050 Shim (t:0.50mm) UR | Buy now |
| 42 | 93341930U9 Bearing | Buy now |
| 43 | 9321055M14 O-ring (70e) | Buy now |
| 44 | 6E54534400 Cover, oil seal | Buy now |
| 45 | 9709508025 Bolt (62g) | Buy now |
| 47 | 60X4550110 Drive shaft comp. | Buy now |
| 48 | 60X4555100 Pinion | Buy now |
| 49 | 9020116M00 Washer, plate(6t5) | Buy now |


Lower Casing & Drive 1



C6


| Ref | Part | |
|-----|--|-------------------------|
| 50 | 9017016M19 Nut(6t5) | Buy now |
| 51 | 60X4556000 Gear | Buy now |
| 52 | 60V4561100 Shaft, propeller | Buy now |
| 53 | 61A4564102 Shifter | Buy now |
| 54 | 61A4563401 Slide, shift | Buy now |
| 55 | 61A4563200 Pin, cross | Buy now |
| 56 | 60V4563100 Clutch, dog | Buy now |
| 57 | 61A4563300 Ring, cross pin | Buy now |
| 58 | 6H14566800 Shaft, free 1 | Buy now |
| 59 | 61A4563500 Plunger, shift | Buy now |
| 60 | 9020102M00 Washer, plate(61a) | Buy now |
| 61 | 9018302M03 Nut, spring (61h) | Buy now |
| 62 | 9050110M77 Spring, compression(61a) | Buy now |
| 63 | 9350104011 Ball | Buy now |
| 64 | 60X453320094 Housing, bearing | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 65 | 9345045M02 Circlip(6t5) | Buy now |
| 66 | 9959014016 Pin, dowel(4jt) | Buy now |
| 67 | 93306210U0 Bearing(61a) | Buy now |
| 68 | 69L4557100 Gear | Buy now |
| 69 | 9020131M00 Washer, plate(61a) | Buy now |
| 70 | 61A455770010 Shim (t:0.10mm) UR | Buy now |
| 70 | 61A455770012 Shim (t:0.12mm) UR | Buy now |
| 70 | 61A455770015 Shim (t:0.15mm) UR | Buy now |
| 70 | 61A455770018 Shim (t:0.18mm) UR | Buy now |
| 70 | 61A455770030 Shim (t:0.30mm) UR | Buy now |
| 70 | 61A455770040 Shim (t:0.40mm) UR | Buy now |
| 70 | 61A455770050 Shim (t:0.50mm) UR | Buy now |
| 71 | 9331543061 Bearing | Buy now |
| 72 | 9310130002 Oil seal | Buy now |
| 73 | 9321104384 O-ring (705) | Buy now |


Lower Casing & Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 74 | 9011010006 Bolt, hexagon socket head | Buy now |
| 75 | 9011008030 Bolt, hexagon socket head | Buy now |
| 76 | 9370009M00 Nipple, grease(6t4) | Buy now |

C6

Lower Casing & Drive 2




60X110032901

D3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6E54436600 Damper, water seal 2 | Buy now |
| 2 | 66K4436100 Tube, water | Buy now |
| 3 | 6E54436500 Damper, water seal 1 | Buy now |
| 4 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 5 | 9709510045 Bolt(64d) | Buy now |
| 6 | 9299510100 Ybs67-10 washer, spring | Buy now |
| 7 | 9299510600 Washer, plate | Buy now |
| 8 | 9011610021 Bolt, stud | Buy now |
| 10 | 9578010300 Nut, nylon (6e5) | Buy now |
| 11 | 60X4537500 Damper, seal | Buy now |
| 12 | 60X4521400 Cover set, water inlet | Buy now |
| 13 | 60X4521500 Cover set, water inlet | Buy now |
| 14 | 9011005017 Bolt, Hexagon Socket Head | Buy now |
| 15 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 16 | 69L4537100 Tab-trim | Buy now |

Lower Casing & Drive 2




60X110032901

D3

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9010510M00 Bolt, hexagon (663) | Buy now |
| 18 | 60X4598710 Spacer 1 Go to P/N)PE0-OM-080083 | Buy now |
| 19 | 6884599701 Spacer 2 | Buy now |
| 20 | 9299018200 Washer (6e5) | Buy now |
| 21 | 9017118M04 Nut, castle (6e5) | Buy now |
| 22 | 9149040030 Pin, cotter (663) | Buy now |
| 23 | * item_description | Buy now |
| 24 | 60X4599500 Spacer 3 Go to P/N)PE0-OM-080083 | Buy now |

Meter




61A1700-2290

E2

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6Y58350T03 Digital tachometer assembly AP | Buy now |
| 2 | 9E45004433 Housing, connector (m-4-w) M-4-W | Buy now |
| 3 | 9E45004533 Housing, f-4-w(5pcs) F-4-W | Buy now |
| 4 | 9299004100 Ybs67-4 washer, spring | Buy now |
| 5 | 9538004600 Nut,hex | Buy now |
| 6 | 6Y583500S5 Meter assembly AP | Buy now |
| 7 | 6Y583570S5 Speedometer assembly | Buy now |
| 10 | 6Y583533T2 Grommet | Buy now |
| 11 | 6Y58355731 Tube | Buy now |
| 12 | 6Y58372800 Connector assembly | Buy now |
| 20 | 9046511M10 Clamp AP | Buy now |
| 14 | 6Y587122S0 Cord assembly 1 AP | Buy now |
| 15 | 6Y583553M0 Wire, lead (l=2.5m) AP | Buy now |
| 16 | 1E68215100 Fuse (10a) | Buy now |
| 17 | 6Y58211700 Wire, lead AP | Buy now |

Meter




61A1700-2290

E2

| Ref | Part | |
|-----|---|-------------------------|
| 18 | 68F8255380 Extension, wire lead (8m) AP | Buy now |
| 19 | 6Y58355710 Tube (8m) AP | Buy now |


Oil Pump



D3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V1320000 Oil injection pump assembly | Buy now |
| 2 | 6R31347100 Screw | Buy now |
| 3 | 6L21347500 Gasket, breather bolt | Buy now |
| 4 | 9321019M82 O-ring(6j8) | Buy now |
| 5 | 9010906M40 Bolt(6h0) | Buy now |
| 6 | 6G51341600 Pipe, oil 1 | Buy now |
| 7 | 9044617MA8 Hose (L200) | Buy now |
| 8 | 9046511M10 Clamp | Buy now |
| 9 | 9044607M35 Hose(62t) | Buy now |
| 10 | 9044507M96 Hose(62t) | Buy now |
| 11 | 9044607M48 Hose(62t) | Buy now |
| 12 | 9044507M44 Hose (I390) | Buy now |
| 13 | 9044507M46 Hose (I390) | Buy now |
| 14 | 9044507M10 Hose (L770) | Buy now |
| 15 | 9044507M04 Hose(62t) | Buy now |


Oil Pump



D3

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6R31318300 Valve, check | Buy now |
| 17 | 9046807M02 Clip (6e5) | Buy now |
| 18 | 9046407M05 Clamp (6g5) | Buy now |
| 20 | 9046407M20 Clamp(6h0) | Buy now |
| 21 | 61A1153700 Gear, driven | Buy now |
| 22 | 9020109M01 Washer, plate(61b) | Buy now |
| 23 | 61A1311700 Collar, distance | Buy now |
| 24 | 9321018MA9 O-ring(61a) | Buy now |
| 25 | 6R54123700 Joint, link | Buy now |
| 26 | 65L4124110 - | Buy now |
| 27 | 9538005600 Nut, hexagon (663) | Buy now |
| 28 | 6H14123700 Joint, link | Buy now |
| 29 | 9149012012 Pin, cotter (6g8) | Buy now |
| 30 | 9020205088 Washer, plate (666) | Buy now |
| 31 | 60V2431900 Pipe, oil | Buy now |

Oil Pump




D3

| Ref | Part | |
|-----|--|-------------------------|
| 33 | 9046708M18 Clip | Buy now |
| 34 | 68F1310000 Solenoid pump assembly | Buy now |
| 35 | 68F1341800 Hose 4 | Buy now |
| 36 | 68F1318400 Spring, oil pipe | Buy now |
| 37 | 68F1344000 Filter assembly | Buy now |
| 38 | 68F1316F00 Hose 1 | Buy now |
| 39 | 68F1313300 Clip | Buy now |
| 40 | 68F1316G00 Hose 2 | Buy now |
| 41 | 68F1316A00 Check Valve assembly | Buy now |
| 42 | 68F1341600 Hose 3 | Buy now |
| 43 | 68F1448500 Pipe, joint | Buy now |
| 44 | 60V1319K00 Plate | Buy now |
| 45 | 9709506020 Bolt(7u8) | Buy now |
| 46 | 9299506100 Washer(6a1) | Buy now |
| 47 | 9299506600 Washer, plain (646) | Buy now |


Oil Pump

| Ref | Part | |
|-----|---|-------------------------|
| 48 | 9011006M06 Bolt, hexagon socket head | Buy now |



D3


Oil Tank



D5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 61A2175000 Oil tank assembly | Buy now |
| 2 | 6E51344800 Cap, oil tank | Buy now |
| 3 | 9046513M11 Clamp (6e5) | Buy now |
| 4 | 61A8573001 Oil level gauge assembly | Buy now |
| 5 | 61A1341100 Strainer, oil | Buy now |
| 6 | 6E51341400 Gasket, strainer cover | Buy now |
| 7 | 9044505M07 Hose (I700) | Buy now |
| 8 | 6A08231700 Damper, ignition coil | Buy now |
| 9 | 6244254200 Collar | Buy now |
| 10 | 9011906M65 Bolt, with washer | Buy now |
| 11 | 6R38259E00 Switch assembly | Buy now |
| 12 | 6E52437900 Pipe, joint 4 | Buy now |
| 13 | 9044512M04 Hose (I3000) | Buy now |
| 14 | 9046511M10 Clamp | Buy now |
| 15 | 6E52432300 Pipe 12 | Buy now |


Oil Tank



D5

| Ref | Part | |
|-----|--|-------------------------|
| 18 | 9046413M34 Clamp(6r3) | Buy now |
| 19 | 61A2170820 Sub oil tank assembly. | Buy now |
| 20 | 6E52173320 Sub tank, oil (10.5l) | Buy now |
| 21 | 6E52177003 Oil tank cap assembly | Buy now |
| 22 | 6E52432200 Pipe 11 | Buy now |
| 24 | 6462425102 Strainer 1 | Buy now |
| 25 | 6E52431901 Pipe, oil | Buy now |
| 27 | 6E58190001 Oil feed pump assembly | Buy now |
| 28 | 6E58192200 Grommet | Buy now |
| 29 | 6E52432101 Pipe 10 | Buy now |
| 31 | 9044511M26 Hose (I8000) | Buy now |
| 33 | 6E58572005 Oil level gauge assembly | Buy now |
| 34 | 6R38572180 Wire, lead | Buy now |
| 35 | 6E5217340133 Holder, oil sub tank | Buy now |
| 36 | 6E5217980133 Bracket, damper | Buy now |


Oil Tank



| Ref | Part | |
|-----|---|-------------------------|
| 37 | 6E52174600 Damper | Buy now |
| 38 | 9708006100 Bolt, hexagon | Buy now |
| 39 | 9299006600 Washer, plain (646) | Buy now |
| 40 | 9538006600 Nut(661) | Buy now |
| 42 | 6E51343762 Mark Caution | Buy now |

D5


Power Trim & Tilt Assy 1



B7

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60X43800004D Power trim & tilt assembly | Buy now |
| 2 | 64E4382501 Housing Trim & Tilt | Buy now |
| 3 | 64E4388J00 Plug 2 | Buy now |
| 4 | 9321010M74 O-ring | Buy now |
| 5 | 64E4381700 Filter 2 | Buy now |
| 6 | 60X4381000 Tilt piston sub assembly | Buy now |
| 7 | 64E4389800 Seal, dust 2 | Buy now |
| 8 | 64E4386700 O-ring 7 | Buy now |
| 9 | 64E4386600 O-ring 6 | Buy now |
| 10 | 6E54386200 O-ring 2 | Buy now |
| 11 | 64E4388300 O-ring 10 | Buy now |
| 12 | 6E54387200 Ring, back-up 2 | Buy now |
| 13 | 6E54381402 Piston, free | Buy now |
| 15 | 64E4382000 Trim piston sub assembly | Buy now |
| 16 | 64E4382100 Screw, trim cylinder end | Buy now |

Power Trim & Tilt Assy 1




B7

| Ref | Part | |
|-----|--|-------------------------|
| 17 | 64E4382200 Seal, trim dust | Buy now |
| 18 | 64E4384J00 Seal, trim down | Buy now |
| 19 | 6G54386400 O-ring 4 | Buy now |
| 20 | 6E54386400 O-ring 4 | Buy now |
| 21 | 6E54387401 Ring, back-up 4 | Buy now |
| 22 | 64E4382800 Body, reservoir | Buy now |
| 23 | 64E4382900 Plug, reservoir | Buy now |
| 24 | 64E4389700 O-ring | Buy now |
| 25 | 64E4388E00 Bolt ,screw (l:14mm) | Buy now |
| 26 | 64E4386900 O-ring 9 | Buy now |
| 27 | 64E4381G00 Pin 1 | Buy now |
| 28 | 6E54385800 Ball 1 | Buy now |
| 29 | 64E4382G00 Valve seat | Buy now |
| 30 | 9020108M14 Washer, plate | Buy now |
| 31 | 9708008016 Bolt | Buy now |


Power Trim & Tilt Assy 1

| Ref | Part | |
|-----|---|-------------------------|
| 32 | 64E4381801 Lower shock mount pin set | Buy now |
| 33 | 9038622M98 Bush(61u) | Buy now |




B7

Power Trim & Tilt Assy 2



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 64E4388E10 Bolt ,screw (l:34.7mm) | Buy now |
| 2 | 64E4383100 Connector, shaft | Buy now |
| 3 | 64E4386800 O-ring 8 | Buy now |
| 4 | 64E4383000 Gear pump assembly | Buy now |
| 5 | 72X4385800 Ball | Buy now |
| 6 | 64E4384300 Screw, valve lock | Buy now |
| 7 | 64E4384100 Piston, shuttle | Buy now |
| 8 | 64E4380200 Valve sub assembly | Buy now |
| 9 | 6E54389600 O-ring | Buy now |
| 10 | 6G54386300 O-ring 3 | Buy now |
| 11 | 64E4385100 Seat, Relief Valve | Buy now |
| 12 | 64E4385800 Ball | Buy now |
| 13 | 64E4385900 Pin, Valve Support | Buy now |
| 14 | 64E4385500 Spring, up relief | Buy now |
| 15 | 64E4385000 Valve sub assembly | Buy now |


Power Trim & Tilt Assy 2



C2

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 64E4386500 O-ring 10 | Buy now |
| 17 | 64E4381600 Filter 1 | Buy now |
| 19 | 64E4381710 Filter 2 | Buy now |
| 20 | 64E4386000 Manual valve sub-assembly | Buy now |
| 21 | 72X85075L0 O-ring (nsd161) | Buy now |
| 22 | 64E4382700 Ring set | Buy now |
| 23 | 64E4387A00 O-ring | Buy now |
| 24 | 64E4387300 Ring, back up | Buy now |
| 25 | 64E4387500 Ring, snap | Buy now |
| 26 | 64E4387910 Screw, with washer | Buy now |
| 27 | 64E4387900 Screw, with washer | Buy now |
| 28 | 67H4388001 Motor assembly | Buy now |
| 29 | 6H14386K10 Spring, brush | Buy now |
| 30 | 64E4380J00 Holder Brush | Buy now |
| 31 | 64E4389100 Brush 1 | Buy now |


Power Trim & Tilt Assy 2



C2


| Ref | Part | |
|-----|---|-------------------------|
| 32 | 9760704310 Screw, pan head(6g8) | Buy now |
| 33 | 64E4380F00 Holder, brush 2 | Buy now |
| 34 | 64E4389200 Breaker comp. (brush 2) | Buy now |
| 35 | 6G54386500 O-ring | Buy now |
| 36 | 9310208M43 Oil seal(6b0) | Buy now |
| 37 | 64E4380500 Armature assembly | Buy now |
| 38 | 64E4384310 Screw valve lock | Buy now |

Remote Control Assy



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 7034826101 Arm, throttle | Buy now |
| 3 | 7034815300 Shaft, free accel. | Buy now |
| 4 | 7034823500 Bushing | Buy now |
| 5 | 7034826800 Spacer 3 | Buy now |
| 6 | 7034826400 Throttle, friction | Buy now |
| 7 | 9538005600 Nut, hexagon (663) | Buy now |
| 8 | 9738005025 Bolt | Buy now |
| 9 | 7034826500 Shaft Friction | Buy now |
| 10 | 9343006024 Circlip (701) | Buy now |
| 11 | 7034824500 Plate, lock | Buy now |
| 12 | 7034825200 Roller, cam | Buy now |
| 13 | 7014824800 Roller, free accel | Buy now |
| 14 | 7034819800 Washer, wave 3 | Buy now |
| 15 | 7034824300 Bushing 3 | Buy now |


Remote Control Assy



D6

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 7034823600 Bushing | Buy now |
| 17 | 7034818900 Retainer | Buy now |
| 18 | 7034823400 Roller, detent | Buy now |
| 19 | 7034834501 Cable end, remote control 2 | Buy now |
| 20 | 7034835800 Anchor, cable | Buy now |
| 21 | 7034824400 Spring, free accel. | Buy now |
| 22 | 7034823800 Spring, detent | Buy now |
| 23 | 7034824600 Spacer 1 | Buy now |
| 24 | 7034822700 Spring, neutral lock | Buy now |
| 25 | 7038259400 Clamp WITH PT/T SW. | Buy now |
| 26 | 7034822600 Plate, stopper | Buy now |
| 27 | 7034822200 Grip, control lever SINGLE | Buy now |
| 28 | 7034822300 Lock, neutral | Buy now |
| 29 | 7034822500 Cover | Buy now |
| 30 | 7034821900 Cover, lead | Buy now |


Remote Control Assy




D6

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 7034828100 Screw, flat head | Buy now |
| 32 | 7034828200 Screw | Buy now |
| 33 | 9738008030 Bolt, hexagon (fj1) | Buy now |
| 34 | 9299008600 Washer, plain (663) | Buy now |
| 35 | 9858004010 Screw, pan head (e56) | Buy now |
| 36 | 9858004006 Screw, pan head (7h3) | Buy now |
| 37 | 9858005010 Screw, pan head(62x) | Buy now |
| 38 | 9858003015 Screw, pan head (n151) | Buy now |
| 39 | 7034829110 Screw | Buy now |
| 40 | 9538006600 Nut(661) | Buy now |
| 41 | 7034829310 Spacer, remote control SINGLE | Buy now |
| 42 | 7014828700 Washer 1 | Buy now |
| 43 | 7034821500 Graphic | Buy now |
| 44 | 7038251043 Main switch assembly | Buy now |
| 45 | 7038257700 Cap, key | Buy now |

Remote Control Assy




Remote Control Assy



D6

| Ref | Part | |
|-----|--|-------------------------|
| 61 | 7034821101 Housing,1 | Buy now |
| 62 | 7034823200 Drive gear | Buy now |

Remote Control Box




67MO100-8280

D5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 7014832050 Cable, Remote Control L=15F UR | Buy now |
| 2 | 7014832060 Cable, Remote Control L=16F UR | Buy now |
| 2 | 7014832080 Cable, Remote Control L=17F UR | Buy now |
| 2 | 7014835000 Cable, Remote Control L=21F UR | Buy now |
| 2 | 7014835020 Cable, Remote Control L=23F UR | Buy now |


Repair Kit 1



E3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60VW000100 Power head gasket kit | Buy now |
| 2 | 60V1119300 Gasket, head cover 1 | Buy now |
| 3 | 60V1118100 Gasket, cylinder head 1 | Buy now |
| 4 | 9043014115 Gasket (663) | Buy now |
| 5 | 60V1138100 Gasket 1 | Buy now |
| 6 | 60V12414A0 Gasket, cover | Buy now |
| 7 | 60V4111200 Gasket, exhaust inner cover | Buy now |
| 8 | 60V11382A0 Gasket 2 | Buy now |
| 9 | 9310422M07 Oil seal(61a) | Buy now |
| 10 | 9310240010 Oil seal | Buy now |
| 11 | 60V1535300 Gasket, drain | Buy now |
| 12 | 60V1364600 Gasket, manifold 2 | Buy now |
| 13 | 60V1364500 Gasket, manifold 1 | Buy now |
| 14 | 60V1447600 Seal | Buy now |
| 15 | 9321018MA9 O-ring(61a) | Buy now |


Repair Kit 1



E3

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V13621A0 Gasket, Valve Seat | Buy now |
| 17 | 60V1147900 O-ring | Buy now |
| 18 | 60V4511301 Gasket, upper casing | Buy now |


Repair Kit 2



E4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60XW000120 Lower unit gasket kit | Buy now |
| 2 | 61A41134A0 Gasket, exhaust manifold | Buy now |
| 3 | 60V4511400 Gasket, upper casing | Buy now |
| 4 | 9043008020 Gasket | Buy now |
| 5 | 60X4512300 Gasket, muffler | Buy now |
| 6 | 6E54436500 Damper, water seal 1 | Buy now |
| 7 | 6E54436600 Damper, water seal 2 | Buy now |
| 8 | 9321033M49 O-ring(6l5) | Buy now |
| 9 | 9310609014 Oil seal | Buy now |
| 10 | 9321086M38 O-ring (6e5) | Buy now |
| 11 | 9321037160 O-ring (6g8) | Buy now |
| 12 | 60X44315A0 Gasket, water pump | Buy now |
| 13 | 9310128M16 Oil seal (6e5) | Buy now |
| 14 | 9321055M14 O-ring (70e) | Buy now |
| 15 | 9321104384 O-ring (705) | Buy now |


Repair Kit 2



E4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9310130002 Oil seal | Buy now |
| 17 | 60XW007800 Water pump repair kit | Buy now |
| 18 | 61A4432202 Insert, cartridge | Buy now |
| 21 | 6E54435201 Impeller | Buy now |
| 22 | 60X4432300 Outer plate, cartridge | Buy now |
| 24 | 9360612019 Pin, dowel (614) | Buy now |
| 25 | 9011908M14 Bolt, with washer | Buy now |
| 26 | 9028004M05 Key, woodruff (6e5) | Buy now |


Starting Motor



F6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60X8180000 Starting motor assembly | Buy now |
| 2 | 67F8185000 Armature assembly | Buy now |
| 3 | 67F8181000 Stator assembly | Buy now |
| 4 | 69J8184000 Brush holder assembly | Buy now |
| 5 | 69J8180100 Brush set | Buy now |
| 6 | 67F8181300 Spring, brush | Buy now |
| 7 | 68F8182000 Rear bracket assembly | Buy now |
| 8 | 67F8180800 Pinion assembly | Buy now |
| 9 | 67F8185700 Pinion stopper set | Buy now |
| 10 | 67F8180700 Gear assembly, starting motor | Buy now |
| 11 | 67F8183200 Clutch, over run | Buy now |
| 12 | 67F8183600 Shaft, pinion | Buy now |
| 13 | 67F8182100 Bracket, center 1 | Buy now |
| 14 | 67F8184100 Bearing | Buy now |
| 15 | 67F8189100 Gear, ring | Buy now |


Starting Motor



F6

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67F8183R00 Gasket | Buy now |
| 17 | 67F818300 Bracket, center 2 | Buy now |
| 18 | 60V8183T00 Gear, idler | Buy now |
| 19 | 67F8180900 Washer kit | Buy now |
| 20 | 60X8184200 Cover | Buy now |
| 21 | 69J8183900 Lever assembly | Buy now |
| 22 | 69J8194100 Starter relay assembly | Buy now |
| 23 | 69J8186900 Cover Dust | Buy now |
| 24 | 6K78182610 Bolt | Buy now |
| 25 | 69J8182800 Bolt 2 | Buy now |
| 26 | 67F8184600 Screw | Buy now |
| 27 | 9017908003 Nut | Buy now |
| 28 | 60V8192500 Terminal | Buy now |
| 29 | 68F8258200 Cover, wire harness | Buy now |
| 30 | 9701308045 Bolt | Buy now |


Starting Motor



| Ref | Part | |
|-----|---|-------------------------|
| 31 | 9290308600 Washer, plain (663) | Buy now |
| 32 | 67F8362701 Label, caution 7 | Buy now |

F6

Steering Guide




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6E56135002 Steering guide attachment kit AP | Buy now |
| 2 | 6E56135101 Rod, steering link | Buy now |
| 3 | 9038710M61 Collar (6e5) | Buy now |
| 4 | 9056012M01 Spacer (6e5) | Buy now |
| 5 | 6E56135500 Bolt | Buy now |
| 6 | 9018509M01 Nut, nylon (663) | Buy now |
| 7 | 9020110M20 Washer, plate (663) | Buy now |
| 8 | 6E54314501 Cap, clamp bracket | Buy now |
| 9 | 9321016275 O-ring | Buy now |

67H0100-9290

D4


Top Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60X4261000NA Top Cowling assembly | Buy now |
| 2 | 68F426470194 Holder, clamp band | Buy now |
| 3 | 68F426480194 Holder, clamp band | Buy now |
| 4 | 9299006100 Washer(6a1) | Buy now |
| 5 | 9538006600 Nut(661) | Buy now |
| 6 | 68F4266300 Damper 2 | Buy now |
| 7 | 60V4265101 Hook | Buy now |
| 8 | 60V4265200 Hook | Buy now |
| 9 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 10 | 9299506600 Washer, plain (646) | Buy now |
| 11 | 60X4261300NA - | Buy now |
| 12 | 9017906M24 Nut(6j8) | Buy now |
| 13 | 9038706011 Collar | Buy now |
| 14 | 9321006270 O-ring | Buy now |
| 15 | 60X4263600NA Louver 2 | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 60X4263610NA Louver 2 | Buy now |
| 17 | 60X4266200 Damper | Buy now |
| 18 | 9778050616 Screw, pan head tapping (ak5) | Buy now |
| 19 | 9299005200 Ybs66-5 washer, plain | Buy now |
| 20 | 60X4268700 Emblem Rear | Buy now |
| 21 | 60V4266200 Damper | Buy now |
| 22 | 60Y4267700 Graphic, front | Buy now |
| 23 | 60XW007000 Graphic Set | Buy now |
| 24 | 60X4268100 Mark Cowling | Buy now |
| 25 | 60X4268200 Mark, cowling | Buy now |
| 26 | 60X4267800 Graphic, front | Buy now |
| 27 | 67F1344800 Cap | Buy now |
| 28 | 60X4262600 Louver 1 | Buy now |
| 29 | 9778050620 Screw, tapping | Buy now |
| 30 | 60V4263700 Damper Form | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 60X4267A00 Graphic, rear 2 | Buy now |
| 32 | 60V4263710 Damper Form | Buy now |
| 33 | 60X4262610 Louver 1 | Buy now |
| 35 | 68F1343400 Label, Caution | Buy now |


Upper Casing



C4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60X45111008D Casing, upper | Buy now |
| 2 | 6N94279140 Mark 1 | Buy now |
| 3 | 6N94279240 Mark 2 | Buy now |
| 4 | 61A4515500 Cap | Buy now |
| 5 | 9709506010 Bolt | Buy now |
| 6 | 9299506600 Washer, plain (646) | Buy now |
| 7 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 8 | 9011908052 Bolt, with washer | Buy now |
| 9 | 66K4537800 Nipple, hose | Buy now |
| 10 | 9011906M17 Bolt, with washer | Buy now |
| 11 | 9360612019 Pin, dowel (614) | Buy now |
| 12 | 9044507MF0 Hose (I1160) | Buy now |
| 13 | 6E58355800 End, nipple | Buy now |
| 14 | 9046511M10 Clamp | Buy now |
| 15 | 60V4511400 Gasket, upper casing | Buy now |


Upper Casing



C4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V411371194 Guide, exhaust | Buy now |
| 18 | 60V4511301 Gasket, upper casing | Buy now |
| 19 | 9011908079 Bolt, with washer Go to P/N) PEO-OM-050009 | Buy now |
| 20 | 9011908072 Bolt, With Washer Go to P/N) PEO-OM-050009 | Buy now |
| 21 | 9011908060 Bolt, with washer | Buy now |
| 22 | 6H11137200 Nipple, hose | Buy now |
| 23 | 60V411310294 - | Buy now |
| 24 | 9011908056 Bolt With Washer | Buy now |
| 25 | 61A41132015B Manifold, exhaust | Buy now |
| 26 | 61A41134A0 Gasket, exhaust manifold | Buy now |
| 27 | 9011908059 Bolt, with washer | Buy now |
| 28 | 60X14711005B Muffler 1 | Buy now |
| 29 | 60X4512300 Gasket, muffler | Buy now |


Vapor Separator 1



B7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V2421600 Stay | Buy now |
| 2 | 6D02447300 Screw | Buy now |
| 3 | 60V1498000 Body, float chamber | Buy now |
| 4 | 60V1418201 Cover, float chamber | Buy now |
| 5 | 65L1454600 Valve, needle | Buy now |
| 6 | 66K1498500 Float | Buy now |
| 7 | 66K1454801 Pin, float arm | Buy now |
| 8 | 66K1498400 Gasket, float chamber | Buy now |
| 9 | 65L1412500 Screw | Buy now |
| 10 | 68F1390600 Regulator, pressure | Buy now |
| 11 | 66K1432501 Screw, pan head | Buy now |
| 12 | 60V1416300 Spacer | Buy now |
| 13 | 65L1390500 Filter comp | Buy now |
| 14 | 68F1397100 Pipe, fuel 1 | Buy now |
| 15 | 65L2438700 Clip | Buy now |


Vapor Separator 1



B7

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 65L1496600 Cap | Buy now |
| 17 | 65L2448600 O-ring | Buy now |
| 18 | 68F2425110 Strainer 1 | Buy now |
| 19 | 66K1424500 Screw, guide | Buy now |
| 20 | 68F8250900 Wire, sub lead | Buy now |
| 21 | 65L1422700 Washer | Buy now |
| 22 | 60V1390700 Fuel pump comp. | Buy now |
| 23 | 65L1415900 Clip | Buy now |
| 24 | 68F1378100 Damper, pump | Buy now |
| 25 | 68F1384400 Plate 2 | Buy now |
| 26 | 68F1391500 Filter | Buy now |
| 27 | 65L1416A00 O-ring | Buy now |
| 28 | 66K1427100 Insulator | Buy now |
| 29 | 65L8182A00 Nut | Buy now |
| 30 | 65L8182K00 Nut | Buy now |


Vapor Separator 1



B7

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 65L8182E00 Washer | Buy now |
| 32 | 65L8182F00 Washer | Buy now |
| 33 | 68F1384300 Plate 1 | Buy now |
| 34 | 65L1414700 O-ring | Buy now |
| 35 | 68F1427400 Connector | Buy now |
| 36 | 66K2437600 Pipe, joint 1 | Buy now |
| 37 | 66K2448900 O-ring | Buy now |
| 38 | 68F1427100 Insulator | Buy now |
| 39 | 65L1439700 O-ring | Buy now |
| 40 | 65L1499200 Screw, drain | Buy now |
| 41 | 65L1499700 Seal | Buy now |
| 42 | 60V2437501 Grommet | Buy now |
| 43 | 60V2439701 Collar | Buy now |
| 44 | 66K2457900 Washer 2 | Buy now |
| 45 | 65L2459200 Bolt | Buy now |


Vapor Separator 1



| Ref | Part | |
|-----|--|-------------------------|
| 46 | 65L2416900 Washer, lock | Buy now |
| 47 | 60V8250700 Wire, lead | Buy now |
| 48 | 66K1354200 Hose, vacuum sensing 1 | Buy now |
| 49 | 66K1354400 Hose, Vacuum Sensing 2 | Buy now |
| 50 | 66K1353200 Hose, vacuum sensing 3 | Buy now |
| 51 | 65L2446100 Pipe, joint 4 | Buy now |
| 52 | 66K1353300 Hose, vacuum sensing 4 | Buy now |
| 53 | 65L1389800 Plate 4 | Buy now |
| 54 | 65L1456500 Screw | Buy now |
| 55 | 60V2433901 Grommet | Buy now |
| 56 | 60V1353400 Hose, Vacuum Sensing 5 | Buy now |
| 57 | 9046511M10 Clamp | Buy now |

B7

Vapor Separator 2




60V1010-3080

C3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1375100 Body, throttle 1 | Buy now |
| 2 | 65L1452700 Plate | Buy now |
| 3 | 65L1456500 Screw | Buy now |
| 4 | 65L1433400 Spring, air adjusting | Buy now |
| 5 | 65L1452300 Screw, stop | Buy now |
| 6 | 6K51459200 Screw | Buy now |
| 7 | 9020105552 Washer, plate(65j) | Buy now |
| 8 | 65L1457800 Collar | Buy now |
| 9 | 68F1356800 Stud | Buy now |
| 10 | 61A8588500 Throttle sensor assembly | Buy now |
| 11 | 6K78588601 Bracket | Buy now |
| 12 | 9798505212 Screw, with washer(6g7) | Buy now |
| 13 | 9038705M00 Collar(6k7) | Buy now |
| 14 | 60V8551600 Spacer | Buy now |
| 15 | 60V1459600 Washer | Buy now |

Vapor Separator 2



60V1010-3080

60V1010-3080

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9798505330 Screw, with washer(61b) | Buy now |
| 17 | 65L1457300 Lever | Buy now |
| 18 | 65L1457900 Spring | Buy now |
| 19 | 65L4121700 Rod, accel. lever | Buy now |

C3

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.